

Product: New Holland T3.50F/T3.55F/T3.65F/T3.75F Tractor Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-t3-50f-t>

3-55f-t3-65f-t3-75f-tractor-service-repair-manual/

SERVICE MANUAL

T3.50F / T3.55F / T3.65F / T3.75F Tractor

Part number 47763567

English


August 2014



Sample of manual. Download All 407 pages at:

<https://www.arepairmanual.com/downloads/new-holland-t3-50f-t3-55f-t3-65f-t3-75f-tractor-service-repair-manual/>

Copyright © 2014 CNH U.K. Limited. All Rights Reserved.



T3000F TRACTORS

T3.50F - T3.55F - T3.65F - T3.75F

SERVICE MANUAL

SECTIONS

GENERAL	00
ENGINE	10
CLUTCH	18
TRANSMISSION	21
DRIVE LINES	23
FRONT AXLE MECHANICAL TRANSMISSION	25
REAR AXLE MECHANICAL TRANSMISSION	27
POWER TAKE-OFF	31
BRAKES	33
HYDRAULIC SYSTEMS	35
STEERING	41
AXLE AND WHEELS	44
CAB AIR CONDITIONING SYSTEM	50
ELECTRICAL SYSTEM	55
PLATFORM, CAB, BODYWORK	90

TECHNICAL SUPPORT

Sample of manual. Download All 407 pages at:

<https://www.arepairmanual.com/downloads/new-holland-t3-50f-t3-55f-t3-65f-t3-75f-tractor-service-repair-manual/>

CONTENTS

	Page	Date		Page	Date
00 - GENERAL GUIDELINES					
General instructions	1-2	06-11			
Safety regulations	3 -4 -5	06-11			
Tractor refuelling	6	06-11			
10 - ENGINE					
CHAPTER 1					
Summary	1	06-11			
General specifications	2 -3	06-11			
Engine removal - installation	4-5-6-7-8 -9-10	06-11			
Removal-Installation fuel tank	11-12	07-12			
Coolant radiator removal- installation	13-14-15	07-12			
Accelerator control cable adjustment	16	07-12			
18 - CLUTCH					
Main Data	1	07-12			
Torque Specifications	2	07-12			
Tools	2	07-12			
Sections	3	07-12			
Troubleshooting	4	07-12			
Removal-Installation Clutch	5	07-12			
Clutch Overhaul	6-7-8-9	07-12			
Checks and measurements - clutch	10-11	06-11			
Adjustments -- clutch disengagement levers	11	06-11			
Adjustments -- clutch pedal	12	06-11			
Sectional view of PTO clutch servo control	13	06-11			
Description and operation of PTO servo control	14-15	06-11			
PTO servo control adjustment	16	06-11			
PTO engaged switch adjustment	17	06-11			
21 TRANSMISSION					
Chapter 1 - Mechanical transmission					
Main Data	1-2	06-11			
Torque Specifications	2-3	06-11			
Tools	4	06-11			
Sections	5-6-7	06-11			
Description and operation	8	06-11			
Troubleshooting	8-9	06-11			
Removal-Installation - rear transmission - gearbox casing	10-11-12-13	06-11			
Disassembly-Assembly - transmission-gearbox casing	17-18	06-11			
Disassembly-Assembly - clutch casing	19-20-21	06-11			
Sealing compound application diagram	22	06-11			
Transmission oil cooler removal-installation	23	06-11			
CHAPTER 3 - Power Shuttle transmission					
Main Data	1-2	06-11			
Torque Specifications	3	06-11			
Tools	4	06-11			
Sections	5-6-7	06-11			
Description and operation	8	06-11			
Troubleshooting	8	06-11			
Disassembly-Assembly - clutch casing	9-10-11	06-11			
Main clutch adjustments ..	12	06-11			
23 - DRIVE LINES					
Main Data	1	06-11			
Torque Specifications	2	06-11			
Sections	3-4	06-11			
Description and operation	5	06-11			
Troubleshooting	6	06-11			
Drive shafts and guard. Disassembly - Assembly ..	7	06-11			

	Page	Date		Page	Date
Removal-Installation - drive gear casing	8	06-11	Adjustments - bevel drive	14-15-16	06-11
25 – FRONT AXLE MECHANICAL TRANSMISSION			Removal - Installation side gear casing	17-18-19- 20	06-11
CHAPTER 1 - Front mechanical transmission			Disassembly-Assembly - drive wheel shaft	21-22	06-11
Main Data	1-2	06-11	31 – POWER TAKE-OFF		
Torque Specifications	3-4	06-11	CHAPTER 1 - Mechanical power take-off		
Tools	5	06-11	Main Data	1-2	06-11
Sections	6	06-11	Torque Specifications	3-4	06-11
Removal-Installation - front axle	8-9-10	06-11	Sections	5-6	06-11
Disassembly - Assembly Front axle.....	11-12-13- 14-15-16- 17-18	06-11	Description and operation	7-8	06-11
Replacing steering knuckle pins and bearings	19	06-11	Troubleshooting	8	06-11
Adjustments - steering knuckle bearings	20-21	06-11	33 – BRAKES		
Adjustments - bevel drive	22-23-24- 25-26-27- 28	06-11	Main Data	1-2	06-11
Overhaul -- front differential	29	06-11	Torque Specifications	2	06-11
LIM--SLIP self-locking differential	30-31	06-11	Sections	3	06-11
Checking leading wheel alignment	32	06-11	Description and operation	4	06-11
Disassembly-Assembly - front epicyclic final drive ..	33-34	06-11	Troubleshooting	5-6	06-11
27 – REAR MECHANICAL TRANSMISSION			Removal-Installation - service brake	7	06-11
Main Data	1-2	06-11	Removal-Installation - service brake pump	8-9	06-11
Torque Specifications	3-4	06-11	Adjustments - service brake pedals travel	10	06-11
Tools	5	06-11	Service brake circuit air bleeding	11-12	06-11
Sections	6-7	06-11	35 - HYDRAULIC SYSTEMS		
Description and operation	8	06-11	CHAPTER 1 - Rear mechanical hydraulic lift		
Troubleshooting	8	06-11	Main Data	2	06-11
Disassembly-Assembly -- transmission-gearbox casing	9-10-11- 12	06-11	Torque Specifications	2-3	06-11
Adjustments - differential lock engagement sleeve position	13	06-11	Tools	3	06-11
			Sections	4	06-11
			Troubleshooting	5	06-11
			Description and operation	6-7-8-9- 10-11	06-11
			Lift internal controls. Disassembly -- Assembly	12-13-14- 15	06-11

	Page	Date		Page	Date																																																																																							
Draft reading unit			Bucket control cylinder																																																																																									
Disassembly - Assembly .	16-17	06-11	removal-installation	15	06-11																																																																																							
Lift arms shaft.			Replacement of pins	16	06-11																																																																																							
Disassembly - Assembly .	18-19	06-11	41 - STEERING																																																																																									
Removal--Installation --			CHAPTER 1 - Steering																																																																																									
lift control valve	20	06-11	Main Data	2	06-11																																																																																							
Adjusting the lift	21-22-23	06-11	Torque Specifications	2	06-11																																																																																							
CHAPTER 2 - Open centre system auxiliary control valves			Tools	3	06-11																																																																																							
Main Data	2	06-11	Description and operation	4-5-6	06-11																																																																																							
Tools	2	06-11	View of hydrostatic steering control valve components	7	06-11																																																																																							
Torque Specifications	2	06-11	Troubleshooting	8-9	06-11																																																																																							
Sections	3-4	06-11	Replacement - hydrostatic steering wheel	10	06-11																																																																																							
Description and operation	5-6-7-8	06-11	Removal-Installation - hydrostatic steering control valve	11-12	06-11																																																																																							
Auxiliary control valves.			Disassembly-Assembly - hydrostatic control valve ..	13-14-15-16-17-18-19-20-21-22-23-24-25-26-27-28	06-11																																																																																							
Disassembly- Assembly .	9-10-11	06-11	Hydrostatic steering control valve bench testing	29-30	06-11																																																																																							
CHAPTER 3 - Trailer brakes auxiliary control valves			Pressure relief valve testing	31	06-11																																																																																							
Sections	1	06-11	Steering control cylinder.																																																																																									
Description and operation	1-2-3-4-5-6-7	06-11	Troubleshooting	8-9-10	06-11	Removal - Installation ...	32-33	06-11	CHAPTER 8 - Front Loader			Steering control cylinder.			Main Data	1	06-11	Disassembly-Assembly ..	34-35	06-11	Sections	2	06-11	50 - 50 -- CAB A.CONDITION SYSTEM			Torque Specifications	3	06-11	Safety regulations	2	06-11	Troubleshooting	4-5	06-11	Main Data	3	06-11	Parking the front loader ..	6	06-11	Tools	4	06-11	Front loader arm connection bracket			Operating principles	5	06-11	Removal-Installation	7	06-11	Conditioning system components	6-7-8-9-10	06-11	Replacement of control struts (mod. MSL)	8	06-11	Cab controls	11-12-13	06-11	Replacement of triangular articulation levers (mod. MSL)	9	06-11	Testing operation and cooling	14-15	06-11	Bucket support device removal-installation	10	06-11				Position indicator disassembly-assembly ...	11	06-11				Bushing replacement	12-13	06-11				Loader cylinder removal-installation	14	06-11			
Troubleshooting	8-9-10	06-11	Removal - Installation ...	32-33	06-11																																																																																							
CHAPTER 8 - Front Loader			Steering control cylinder.																																																																																									
Main Data	1	06-11	Disassembly-Assembly ..	34-35	06-11																																																																																							
Sections	2	06-11	50 - 50 -- CAB A.CONDITION SYSTEM																																																																																									
Torque Specifications	3	06-11	Safety regulations	2	06-11																																																																																							
Troubleshooting	4-5	06-11	Main Data	3	06-11																																																																																							
Parking the front loader ..	6	06-11	Tools	4	06-11																																																																																							
Front loader arm connection bracket			Operating principles	5	06-11																																																																																							
Removal-Installation	7	06-11	Conditioning system components	6-7-8-9-10	06-11																																																																																							
Replacement of control struts (mod. MSL)	8	06-11	Cab controls	11-12-13	06-11																																																																																							
Replacement of triangular articulation levers (mod. MSL)	9	06-11	Testing operation and cooling	14-15	06-11																																																																																							
Bucket support device removal-installation	10	06-11																																																																																										
Position indicator disassembly-assembly ...	11	06-11																																																																																										
Bushing replacement	12-13	06-11																																																																																										
Loader cylinder removal-installation	14	06-11																																																																																										

	Page	Date	Sayfa	Tarih			
Air conditioning system maintenance	16-17	06-11	System testing	8%10			
Troubleshooting	18-19-20- 21	06-11	Starter motor removal-installation	11%13			
Refrigerant recovery - recycling and evacuation-charging stations	22-23	06-11	CHAPTER 3 – Sarj sistemi				
Dehydration, recharging and refrigeration check ...	24-25-26- 27-28-29- 30	06-11	Summary	1	06-11		
Checking for and eliminating any gas leaks	31-32	06-11	Technical data	2	06-11		
Cab heating/air - conditioning system.			Torque Specifications	2	06-11		
Removal - Installation ...	33-34	06-11	Tools	3	06-11		
Cab electric fan unit.			Description and operation	3-4	06-11		
Disassembly - Assembly .	35	06-11	System testing	5	06-11		
Air-conditioning system condenser removal - installation	36	06-11	Belt Tension	6	06-11		
55 - ELECTRICAL SYSTEM					Alternator motor removal and installation	7-8	06-11
CHAPTER 1 - Instruments					CHAPTER 4 - Battery		
Summary	1	06-11	Summary	1	06-11		
Digital analog enstrumental gauge	2	06-11	Technical data	2	06-11		
Speed gaugei	3	06-11	Description and operation	2	06-11		
LCD panel adjustment ...	3%7	06-11	Battery removal and installation	3	06-11		
Radiator water temprature	7	06-11	Battery testing and charging procedure	4%14	06-11		
Fuel level	7	06-11	CHAPTER 5 – Electrical circuits				
Instrumental panel and lights	8%9	06-11	Summary	1	06-11		
Switch, sensor and selonoid	10-20	06-11	Maxi power fuses	2%5	06-11		
Electronik kontrol unit input / output (ADIC))	21-23	06-11	Power fuses	5%34	06-11		
CHAPTER 2 – Starter system					Battery cut-out	34	06-11
Summary	1	06-11	Sockets	35-36	06-11		
Technical data	2	06-11	Grid heater	37	06-11		
Torque Specifications	2	06-11	Electronic modules	37-38	06-11		
Description and operation	3	06-11	Main Connectors	38-39	06-11		
Starter and recharging circuit	4-5	06-11	Ground points identification	40%42	06-11		
Troubleshooting	6-7	06-11	How to use the wiring diagrams	43%47	06-11		
Fuse and relay locations .	7-8	06-11	Components in descriptive order	48%52	06-11		
			List of tables for system without "standard and full optional" cab	53-54	06-11		
			Components with code in ascending order	55-57	06-11		

	Page	Date		Page	Date
Tables	58%96	06-11	90 - PLATFORM, CAB, BODYWORK		
List of tables for system with "standard and full optional" cab	97-98	06-11	CHAPTER 1 - Cab		
Components with code in ascending order	99%103	06-11	Bonnet. Removal -- Installation	2	06-11
Tables	104%160	06-11	Cab assembly with platform. Removal -- Installation ..	3-4-5-6- 7-8-9	06-11
CHAPTER 6 - Wiring Harnesses and Connectors			Cab right-hand pillar guard removal - installation	10	06-11
Summary	1	06-11	Cab right-hand top guard removal-installation	11	06-11
Components in descriptive order	2%7	06-11	Cab right-hand mudguard guard removal-installation	12	06-11
Components with code in ascending order	8%12	06-11	Cab left-hand top guard removal-installation	13	06-11
Harnesses	13%20	06-11	Windows. Replace	14-15-16	06-11
Connectors	21%92	06-11			

GENERAL INSTRUCTIONS

IMPORTANT NOTICE

All maintenance and repair work described in this manual must be performed exclusively by **NEW HOLLAND** service technicians, in strict accordance with the instructions given and using any specific tools necessary. Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.

BATTERY

Before carrying out any kind of service operation disconnect and isolate the battery negative lead, unless otherwise requested for specific operations (e.g.: operations requiring the engine to be running), after which it is necessary to disconnect the above-mentioned lead to complete the work.

SHIMMING

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated for each shim.

ROTATING SHAFT SEALS

For correct rotating shaft seal installation, proceed as follows:

- before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes;
- thoroughly clean the shaft and check that the working surface on the shaft is not damaged;
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal;
- smear the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- insert the seal in its seat and press down using a flat punch, do not tap the seal with a hammer or mallet;
- whilst inserting the seal, check that it is perpendicular to the seat; once settled, make sure that it makes contact with the thrust element, if required;
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations.

O-RING SEALS

Lubricate the O-RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

SEALING COMPOUNDS

Apply one of the following sealing compounds on the mating surfaces marked with an X: LOCTITE 518 or LOCTITE 5205 or SUPERBOND 559 or BETALOK A272M.

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a wire brush;
- thoroughly degrease the surfaces using one of the following cleaning agent: trichlorethylene, petrolior awater and soda solution.

BEARINGS

When installing bearings it is advised to:

- heat the bearings to 80 – 90 °C before fitting on the shafts;
- allow the bearings to cool before installing them from the outside.

SPRING PINS

When fitting split socket elastic pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral spring pins do not require special positioning.

SPARE PARTS

Use genuine parts only.

Only genuine spare parts guarantee the same quality, duration and safety as they are the same parts that are assembled during production.

Only **genuine parts** can offer this guarantee.

When ordering spare parts, always provide the following information:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found on the "Spare Parts Catalogue", which is the base for order processing.

NOTES FOR EQUIPMENT

The tools that **NEW HOLLAND** offer and illustrate in this manual are:

- specifically researched and designed for use with **NEW HOLLAND** vehicles;
- necessary to make a reliable repair;
- accurately built and strictly tested to offer efficient and long--lasting working means.

By using these tools, repair personnel will benefit from:

- operating in optimal technical conditions;
- obtaining the best results;
- save time and effort;
- working in safe conditions.

IMPORTANT NOTES

Wear limit values indicated for certain parts are recommended, but not binding. The terms "front", "rear", "right-hand" and "left-hand" (when referred to different parts) are intended as seen from the driving position with the tractor in the normal direction of movement.

MOVING THE TRACTOR WITH THE BATTERY REMOVED

External power supply cables should only be connected to the respective positive and negative cable terminals, using efficient clamps that guarantee adequate and secure contact.

Disconnect all services (lights, windshield wipers, etc.) before starting the vehicle.

If the tractor electrical system requires checking, carry out operations with the power supply connected. Once checking is completed, disconnect all services and switch off the power supply before disconnecting the cables.

SAFETY RULES

PAY ATTENTION TO THIS SYMBOL


This warning symbol points out important messages concerning your safety.

Carefully read the following safety regulations and observe advised precautions in order to avoid potential hazards and safeguard your health and safety.

In this manual the symbol is accompanied by the following key--words:

WARNING – Warnings concerning unsuitable repair operations that may jeopardise the safety of Repair personnel.

DANGER - Specific warnings concerning potential hazards for operator safety or for other persons directly or indirectly involved.



1

- Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a trained technician who is assisting with the operation in question.
- Do not operate the vehicle or use any of the implements from different positions, other than the driver's seat.
- Do not carry out operations on the vehicle with the engine running, unless specifically indicated.
- Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- All repair and maintenance operations must be carried out using extreme care and attention.
- Service steps and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- Disconnect the batteries and label all controls to indicate that the vehicle is being serviced. Block the machine and all equipment which should be raised.
- Do not check or fill fuel tanks, accumulator batteries, nor use starting liquid when smoking or near naked flames, as these fluids are inflammable.
- Brakes are inoperative when manually released for repair or maintenance purposes. Use blocks or similar devices to control the machine in these conditions.
- The fuel nozzle should always be in contact with the filling aperture: Maintain this contact until the fuel stops flowing into the tank to avoid possible sparks due to static electricity buildup.

TO PREVENT ACCIDENTS

Most accidents or injuries that occur in workshops are the result of non--observance of simple and fundamental safety regulations. For this reason, IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED by foreseeing possible causes and consequently acting with the necessary caution and care.

Accidents may occur with all types of vehicle, regardless of how well it was designed and built.

A careful and judicious service technician is the best guarantee against accidents.

Precise observance of the most basic safety rule is normally sufficient to avoid many serious accidents.

DANGER. Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

SAFETY RULES

GENERAL GUIDELINES

- Carefully follow specified repair and maintenance procedures.
- Do not wear rings, wristwatches, jewels, unbuttoned or flapping clothing such as ties, torn clothes, scarves, open jackets or shirts with open zips which could get caught on moving parts. Use approved safety clothing such as anti--slipping footwear, gloves, safety goggles, helmets, etc.

- Only use specified towing points for towing the vehicle. Connect parts carefully. Make sure that all pins and/or locks are secured in position before applying traction. Never remain near the towing bars, cables or chains that are operating under load.
- Transport vehicles that cannot be driven using a trailer or a low--loading platform trolley, if available.
- When loading or unloading the vehicle from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels. Firmly secure the vehicle to the truck or trailer and lock the wheels in the position used by the carrier.
- Electric heaters, battery--chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- Take extra care if bystanders are present.
- Never pour petrol or diesel oil into open, wide or low containers.
- Never use gasoline, diesel oil or other inflammable liquids as cleaning agents. Use non-inflammable, non-toxic commercially available solvents.
- Wear safety goggles with side guards when cleaning parts with compressed air.
- Limit the air pressure to a maximum of 2.1 bar, according to local regulations.
- Do not run the engine in confined spaces without suitable ventilation.
- Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- All movements must be carried out carefully when working under, on or near the vehicle. Wear suitable safety clothing, i.e., hard hat, safety goggles and special shoes.
- When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- If operating outside the workshop, position the vehicle on a flat surface and lock in position. If working on a slope, lock the vehicle in position. Move to a flat area as soon as is safely possible.
- If operating outside the workshop, position the vehicle on a flat surface and lock in position. If working on a slope, lock the vehicle in position. Move to a flat area as soon as is safely possible.
- Damaged or bent chains or cables are unreliable. Do not use them for lifting or towing. Always use suitable protective gloves when handling chains or cables.
- Chains should always be safely secured. Make sure that the hitch--up point is capable of sustaining the load in question. Keep the area near the hitch--up point, chains or cables free of all bystanders.
- Maintenance and repair operations must be carried out in a CLEAN and DRY area. Eliminate any water or oil spillage immediately.
- Do not create piles of oil or grease--soaked rags as they represent a serious fire hazard. Always place them into a metal container.
Before starting the tractor or its attachments, check, adjust and block the operator's seat. Also check that there are no persons within the vehicle or implement range of action.
- Empty pockets of all objects that may fall unobserved into the vehicle parts.
- In the presence of protruding metal parts, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles. NEVER LOOK DIRECTLY AT THE WELDING ARC WITHOUT SUITABLE EYE PROTECTION.
- Metal cables tend to fray with repeated use. Always use suitable protective devices (gloves, goggles, etc.) when handling cables.
- Handle all parts with great care. Do not put your hands or fingers between moving parts. Always wear suitable safety clothing -- safety goggles, gloves and shoes.

STARTING

- Never run the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- Never place the head, body, limbs, feet, hands or fingers near fans or rotating belts.

ENGINE

- Always loosen the radiator cap slowly before removing it to allow any remaining pressure in the system to be discharged. Filling up with coolant should only be carried out with the engine stopped or idling (if hot).
- Never fill up with fuel when the engine is running, especially if hot, in order to prevent the outbreak of fire as a result of fuel spillage.
- Never check or adjust fan belt tension when the engine is running.
Never adjust the fuel injection pump when the vehicle is moving.
- Never lubricate the vehicle when the engine is running.

ELECTRICAL SYSTEMS

- If it is necessary to use auxiliary batteries, remember that both ends of the cables must be connected as follows: (+) with (+) and (-) with (-). Avoid short-circuiting the terminals. GAS RELEASED FROM BATTERIES IS HIGHLY INFLAMMABLE. During charging, leave the battery compartment uncovered to improve ventilation. Never check the battery charge using "jumpers" (metal objects placed on the terminals). Avoid sparks or flames near the battery zone. Do no smoke to prevent explosion hazards.
- Before servicing operations, check for fuel or current leaks. Eliminate any eventual leaks before proceeding with work.
- Never charge batteries in confined spaces. Make sure that there is adequate ventilation in order to prevent accidental explosion hazards as a result of the accumulation of gases released during charging operations.
- Always disconnect the batteries before performing any kind of servicing on the electrical system.

HYDRAULIC SYSTEMS

- A liquid leaking from a tiny hole may be almost invisible but, at the same time, be powerful

enough to penetrate the skin. Therefore, use a piece of cardboard or wood for this purpose. NEVERDOITWITHYOURHANDS: If any liquid penetrates skin tissue, call for medical aid immediately. Failure to treat this condition with correct medical procedure may result in serious infection or dermatosis.

- In order to check the pressure in the system use suitable instruments.

WHEELS AND TYRES

- Make sure that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check possible damages to the rims and tyres.
- Stand away from (at the side of) the tyre when checking inflation pressure.
- Only check pressure when the vehicle is unloaded and the tyres are cold, to avoid incorrect readings as a result of over-pressure. Do not reuse parts of recovered wheels as improper welding, brazing or heating may weaken the wheel and make it fail.
- Never cut or weld a rim mounted with an inflated tyre.
- To remove the wheels, lock both the front and rear vehicle wheels. After having raised the vehicle, position supports underneath, according to regulations in force.
- Deflate the tyre before removing any object caught in the tyre tread.
- Never inflate tyres using inflammable gases, as this may result in explosions and injury to bystanders.

REMOVAL AND RE-FITTING

- Lift and handle all heavy parts using suitable hoisting equipment. Make sure that parts are sustained by appropriate hooks and slings. Use the hoisting eyebolts for lifting operations. Extra care should be taken if persons are present near the load to be lifted.
- Handle all parts with care. Do not put your hands or fingers between parts. Wear suitable safety clothing, i.e. safety goggles, gloves and footwear.
- Avoid twisting chains or metal cables. Always wear safety gloves when handling cables or chains.

TRACTOR REFUELING

COMPONENT TO BE FILLED OR TOPPED UP	QUANTITY dm ³ (litres)	RECOMMENDED NEW HOLLAND PRODUCTS	NEW HOLLAND SPECIFICATIONS	INTERNATIONAL SPECIFICATIONS
Cooling system: less cab	14.0	Water & liquid AKCELA PREMIUM ANTİFRİZ 50%+50%	MS1710	-
Fuel tank (bottom/rear) Additioanal Fuel Tank (optional)	10/20,5 10	Decanted, filtered diesel fuel	-	-
Engine oil sump	7,6	AKCELA No.1 ENGINE OIL	MS 1121	API CH-4 ACEA E5 SAE 15W-40
				API CH-4 SAE 10W-30
Brake control circuit	0.7	AKCELA BRAKE LHM	-	ISO 7308
Front axle: axle housing	4.5	AKCELA NEXPLORE	MAT 3525	API GL4 ISO 32/46 SAE 10W-30
final drives (each)	1.0			
Rear transmission (bevel drive, final drives and brakes), gearbox, hydraulic lift, PTO and hydraulic steering:	30.0			
- with mechanical transmissions	35.0			
Grease fittings	-	Grease AKCELA ÇOK AMAÇLI GRES	251H EP	NLGI 2
Air conditioner system - refrigerant	-	-	-	R-134a SP10
- oil	1.3 0.185			

SECTION 10 - ENGINE

Chapter 1 - Engine

CONTENTS

Section	Description	Page
10 000	General specifications	2
	Fuel System Technical Specifications	5
	Tightening torques	14
	Tools	15
	Cross-sectional views	17
	Lubrication and cooling system diagrams	19
	Troubleshooting	21
10 001	Removal - Installation - Overhaul	25

GENERAL SPECIFICATION	3 cylinder
Engine type :	-
- T 3.50 F model turbocharged - 8035.25A.313T- (BOSCH pompa)	BOSCH 1068-1 T
- T 3.55 F model turbocharged - 8035.25B.313T (BOSCH pompa)	BOSCH 1068-1
- T 3.65 F model turbocharged - 8035.25C.313T (BOSCH pompa)	BOSCH 1068-2
- T 3.75 F model turbocharged - 8035.25D.313T (BOSCH pompa)	BOSCH 1089
Type :	
Fuel injection	Diese, 4 stroke
Number of cylinders in line	Direct
	3
Piston diameter	
- T 3.50 F model	104 mm
- T 3.55 F model	104 mm
- T 3.65 F model	104 mm
- T 3.75 F model	104 mm
Piston stroke	115 mm
Total displacement :	
- T 3.50 F model	2931 cm ³
- T 3.55 F model	2931 cm ³
- T 3.65 F model	2931 cm ³
- T 3.75 F model	2931 cm ³
Compression ratio	
Maximum power	18 to:1
- T 3.50 F model	36,8 kW (50 HP)
- T 3.55 F model	40,4 kW (55 HP)
- T 3.65 F model	47,8 kW(65 HP)
- T 3.75 F model	53,0 kW (72 HP)
Maximum torque	
Maximum torque (Nm) at 1400 d/dak: T 3.50 F model	201
Maximum torque (Nm) at 1400 d/dak: T 3.55 F model	220
Maximum torque (Nm) at 1400 d/dak: T 3.65 F model	261
Maximum torque (Nm) at 1400 d/dak: T 3.75 F model	295
Number of main bearings	4
Sump	Structural, cast iron

f(devam)

GENERAL SPECIFICATION	
Lubrication	forced, with gear pump
Pump drive	from camshaft
Engine speed / oil pump speed ratio	2:1
Oil cleaning	mesh filter on oil intake and cartridge filter on delivery line
Normal oil pressure, with engine hot and at fast idling speed: ..	2.9 - 3.9 bar (3 - 4 kg/cm ²)
All models	
Lube pressure relief valve	built into pump housing
Valve opening pressure	3.5 bar (3.6 kg/cm ²)
For further lubrication data	See page NO TAG
Cooling system	
Radiator on T 3.50 F and T 3.55 F models	3 row vertical pipes with copper fins
Radiator on T 3.65 F and T 3.75 F models	4 row vertical pipes with copper fins
Fan, attached to coolant pump pulley T 3.50 F, T 3.55 F, T 3.65F, T 3.75 F models	10 blade steel exhauster fan
Coolant pump	centrifugal vane-type
Engine speed/coolant pump speed ratio	1.403/1
Temperature control	Thermostat
Coolant temperature gauge	Coloured scale, divided into 3 sections
Temperature ranges corresponding to each section:	
- initial white section	30 - 65 °C
- middle green section	65 - 105 °C
- final red section	105 - 115 °C
For further cooling system data	See page NO TAG
Rev counter	incorporated in instrument panel
Rev counter drive	from gear on camshaft

(devam)

GENERAL SPECIFICATIONS	
Timing	overhead valves operated by a camshaft located in the engine block through tappets, pushrods and rockers. Camshaft is driven by the crankshaft through helical gears.
Intake: - start: before T.D.C	12 ·
- end: after B.D.C	31 ·
Exhaust: - start: before B.D.C	50 ·
- end: after T.D.C	16 ·
Valve clearance for timing check	0.45 mm
Valve clearance for normal running (engine cold): - intake	0.30 è 0.05 mm
- exhaust	0.30 è 0.05 mm
For further timing data	See page NO TAG
Fuel System	
Air filter	dual cartridge dry air filter with clogged filter indicator, centrifugal pre-filter and automatic dust ejector
Fuel pump	double diaphragm
Fuel Filter	mesh filter in fuel supply pump and replaceable cartridge on delivery line to injection pump.
Minimum fuel flow rate with pump shaft rotating at 1600 rev/min	100 litres/hour
Operated by eccentric cam	on camshaft
BOSCH injection pump	distributor type
All-speed governor, incorporated in pump: BOSCH	centrifugal counterweights
For further fuel system data: For fixed advance (pump setting for start of delivery before TDC) - Pressure setting - Injection order, and other information regarding the BOSCH pump	see pages 10 to 99

TECHNICAL SPECIFICATIONS

Turbocharger	
- Holset	HX25
Fuel injection pump	distributor type with incorporated speed governor and automatic advance regulator
BOSCH pump:	
- T 3.50 F model	L 1135
- T 3.55 F model	L 1134
- T 3.65 F model	L 1136
- T 3.75 F model	L 1137
Direction of rotation	anti-clockwise
Injection order	1-2-3

Fuel Injectors:	
BOSCH	5090726 5090725
- Nozzle holder type	KBEL 83,535
- Nozzle type	0432291494
Number of nozzles	6
Diameter of nozzle orifices	0,23 mm
Pressure setting	260-272 bar
Fuel delivery lines - BOSCH pump	
- Type	4797506 (TT65) 5090730 (TT50, TT55, TT60)
- Dimensions	mm 6 x 1,5 x 475

FUEL SUPPLY PUMP DATA	mm
Eccentricity of drive shaft	3
Diameter of drive shaft at bushings	31.975 to 32.000
Internal diameter of installed and reamed bushings	32.050 to 32.075
Interference between bushings and seats	0.063 to 0.140
Assembly clearance between shaft and bushings	0.050 to 0.100
Thickness of internal washer	1.45 to 1.50
Thickness of external washer	2.93 to 3.00

CRANKCASE/CYLINDER BLOCK DATA	mm
Cylinder block	cast-iron monoblock without cylinder liners, incorporating seatings for crankshaft bearings, camshaft and pushrod/tappet assemblies
Internal diameter of cylinder liners	104.000 - 104.024 (1)
External diameter of cylinder liners	107.020 - 107.050
Diameter of cylinder bores	106.850 - 106.900
Interference fit between cylinder liners and bores	0.120 - 0.200
Liner internal diameter oversizes	0.4 - 0.8
Liner external diameter oversizes	0.2
Maximum permissible liner ovality or taper due to wear (2)	0.12
Diameter of main shell bearing seats	84.200 - 84.230
Diameter of camshaft bearing seats:	
- front	54.780 - 54.805
- middle	54.280 - 54.305
- rear	53.780 - 53.805
Diameter of standard tappet bores in crankcase	15.000 - 15.018
Spare tappet oversizes	0.1 - 0.2 - 0.3

(1) Measured after press-fitting and reaming.

(2) Measure in the area swept by piston rings, both parallel and perpendicular to the crankshaft axis.

CRANKSHAFT AND BEARINGS DATA	mm
Crankshaft	balanced with integral counterweights
Standard journal diameter	79.791 - 79.810 ⁽¹⁾
Journal undersizes	0.254 - 0.508 - 0.762 - 1.016
Standard main bearing shell thickness	2.168 - 2.178
Main bearing shell undersizes (internal diameter)	0.254 - 0.508 - 0.762 - 1.016
Bearing shell to journal clearance	0.034 - 0.103
Maximum permitted wear clearance	0.180
Standard crankpin diameter	63.725 - 63.744 ⁽¹⁾
Crankpin undersizes	0.254 - 0.508 - 0.762 - 1.016
Standard big-end bearing shell thickness	1.805 - 1.815
Big-end bearing shell undersizes (internal diameter)	0.254 - 0.508 - 0.762 - 1.016
Big-end bearing shell to crankpin clearance	0.033 - 0.087
Maximum permitted wear clearance	0.180
Standard crankshaft thrust washer thickness	3.378 - 3.429
Thrust washer oversizes (thickness)	0.127 - 0.254 - 0.381 - 0.508
Width of main bearing including thrust washers	31.766 - 31.918
Width of corresponding crankshaft journal	32.000 - 32.100
Crankshaft assembly endfloat	0.082 - 0.334
Maximum permitted wear endfloat	0.40
Maximum ovality or taper of journals and crankpin after regrinding	0.01
Maximum ovality or taper of journals and crankpin	0.05
Maximum tolerance for alignment of crankshaft journals with crankshaft supported on the two outer journals	0.10
Maximum tolerance for alignment, in both directions, of crankpins or each pair of crankpins	0.25
Maximum tolerance for run-out between the outer surfaces of the crankshaft journals and the crankshaft centreline	¶ 0.10

(continued)

(1) Crankshafts with 0.1 mm undersize journals and crankpins and consequently undersize bearing shells may be fitted in factory production.

(continued)

BENCH TEST PERFORMANCE DATA	mm
Maximum permitted tolerance on run-out of flywheel mounting flange surface relative to the crankshaft centreline, measured with 1/100 mm scale dial gauge resting on front flange surface at a diameter of 108 mm (total gauge reading)	0.025
Maximum permitted tolerance on co-axial alignment of flywheel centering seat relative to the crankshaft journals (total gauge reading)	0.04

CONNECTING ROD DATA	mm
Connecting rods	cast-iron with oil way
Diameter of small end bushing seat	41.846 - 41.884
Outside diameter of small end bushing	41.979 - 42.017
Interference between small end bushing and seat	0.095 - 0.171
Inside diameter of small end bushing (measured after fitting) ...	38.004 - 38.014
Diameter of big end shell bearing seats	67.407 - 67.422
Maximum tolerance for parallelism between the small end and big end axes measured at 25 mm	¶ 0,07
Maximum weight difference between con rods in same engine ..	25 grams

PISTON DATA	mm
	T3.50F, T3.55F, T3.65F and T3.75F
Pistons	Light alloy with two compression rings and one oil control ring
Standard piston diameter, measured at 57 mm from base and perpendicularly to the gudgeon pin axis	103.852 - 103.870
Piston clearance in cylinder liner	0.130 - 0.172
Maximum permitted wear clearance	0.30
Piston oversizes	0.6
Piston protrusion at TDC from cylinder block face	0.355 - 0.761
Gudgeon Pin Diameter	37.983 - 37.990
Diameter of gudgeon pin seat in piston	37.994 - 38.000
Gudgeon pin to seat clearance	0.004 - 0.017
Gudgeon pin to small end bearing clearance	0.014 - 0.031
Maximum permitted wear clearance	0.06
Maximum weight difference between pistons in same engine	20 grams
Piston ring groove clearance (measured vertically) :	
- Top	0.090 - 0.122
- Second	0.060 - 0.092
- Bottom	0.040 - 0.075
Maximum permissible clearance (wear limit) :	
- Top	0.50
- Second and bottom	0.20
Piston ring end gap (fitted) :	
- Top	0.40 - 0.65
- Second	0.30 - 0.55
- Bottom	0.30 - 0.55
Maximum permissible gap (wear limit)	1.20

VALVE TIMING GEAR DATA	mm
Timing gear tooth backlash	0,160
Inside diameter of intermediate gear bushings (fitted and reamed)	37.050 - 37.075
Diameter of intermediate gear journal	36.975 - 37.000
Journal to bushing clearance	0.050 - 0.100
Maximum permissible clearance (wear limit)	0.15
Bushing interference fit in seat in intermediate gear	0.063 - 0.140
Outside diameter of camshaft bearings:	
- front	54.875 - 54.930
- middle	54.375 - 54.430
- rear	53.875 - 53.930
Interference between bearings and seats in cylinder block	0.070 - 0.150
Inside diameter of camshaft bearings (fitted and reamed) :	
- front	51.080 - 51.130
- middle	50.580 - 50.630
- rear	50.080 - 50.130
Diameter of camshaft journals :	
- front	50.970 - 51.000
- middle	50.470 - 50.500
- rear	49.970 - 50.000
Clearance between camshaft journals and bearings	0.080 - 0.160
Maximum permissible clearance (wear limit)	0.20
Camshaft endfloat between thrust plate and seat on camshaft	0.070 - 0.220
For further valve timing gear data	See page NO TAG

TAPPET DATA	mm
Tappet bore in crankcase	15.000 - 15.018
Outside diameter of standard tappet	14.950 - 14.970
Tappet running clearance	0.030 - 0.068
Maximum permissible clearance (wear limit)	0.15
Spare tappet oversizes	0.1 - 0.2 - 0.3

ROCKER ARM - VALVE DATA	mm
Diameter of shaft bores in rocker arms	18.016 - 18.034
Rocker-arm shaft diameter	17.982 - 18.000
Rocker shaft to rocker arm bore clearance	0.016 - 0.052
Maximum permissible clearance (wear limit)	0.15
Rocker arm spacing springs:	
- free spring length	59.5
- length under load of 46 to 52 N (4.7 to 5.3 kg)	44
length under load of 46 to 52 N (4.7 to 5.3 kg)	0.45
Cam lift :	
- inlet valve	5.97
- exhaust valve	6.25

CYLINDER HEAD DATA	mm
Cylinder head	with valve seats cut directly in the casting and press-fitted steel valve guides.
Original height of cylinder head	92
Maximum surface regrinding depth	0.5
Diameter of standard valve guide bores in head	13.950 - 13.983
Outside diameter of standard valve guides	13.993 - 14.016
Guide interference fit in bores	0.010 - 0.066
Inside diameter of valve guide (fitted in head)	8.023 - 8.043
Valve stem diameter	7.985 - 8.000
Assembly clearance between valve stem and guide	0.023 - 0.058
Maximum permissible clearance (wear limit)	0.13
Maximum run-out of valve guide on its stem measured through 360° with dial gauge contact point resting on valve head contact band	0.03
Valve guide oversizes	0.2
Valve seat angle in head :	
- inlet valve	60 · ¶ 5'
- exhaust valve	45 · ¶ 5'
Valve face angle:	
- inlet valve	60 · 30' ¶ 7'
- exhaust valve	45 · 30' ¶ 7'
Valve head diameter :	
- inlet valve	45.300 - 45.500
- exhaust valve	37.500 - 37.750
Valve stand-in relative to cylinder head face	0.7 - 1.0
Maximum permissible valve stand-in	1.3
Inlet and exhaust valve springs:	
- free spring length	44.6
- length with valve closed, under load of 256 to 284 N (26.1 to 28.9 kg)	34
- length with valve open, under load of 502 to 544 N (51.2 to 56.6 kg)	23.8
Injector protrusion relative to pumphead face :	
M BOSCH injector	0.3 - 1.1

LUBRICATION SYSTEM DATA	mm	
	T3.50F , T3.55F	T3.65F , T3.75F
Assembly clearance between oil pump drive shaft and bushing .	0.016 - 0.055	-
Clearance between shaft and driven gear	0.033 - 0.066	-
Tooth backlash between drive and driven gears	0.100	-
Radial clearance between drive and driven gears and housing ..	0.060 - 0.170	-
Thickness of drive and driven gears	40.961 - 41.000	-
Height of gear seat in pump	41.025 - 41.087	-
Endfloat between gears and gear housing in pump	0.025 - 0.126	-
Pressure relief valve spring :		
- free length	45	35.9
- length under load of 45 to 49 N (4.6 to 5 kg)	37.5	-
- length under load of 88 to 94 N (9 to 9.6 kg)	30.5	-
- length under load of 127.8 to 141.2 N (130 to 144 kg) (2, Fig 146)	-	29
- length under load of 233.4 - 258 N (238 to 263kg) (2, Fig 146)	-	23.2
For further lubrication system data	See page NO TAG	

COOLING SYSTEM DATA	mm
Interference fit between pump impeller and shaft	0.017 - 0.059
Interference fit between fan hub and shaft	0.024 - 0.058
Interference fit between front seal bushing and impeller	0.012 - 0.058
For further cooling system data	See page NO TAG

ANGLE TIGHTENING TORQUE DATA

FASTENERS	Thread	Preliminary torque		Angle tightening
		Nm	kgm	
Cylinder head bolts (1) fig. 3	M 12 x 1.25	70	7.1	90° + 90°
Main bearing cap bolts (2) fig. 3	M 14 x 1.5	80	8.2	90°
Big-end cap bolts (3) fig. 3	M 12 x 1.5	40	4.1	60°
Flywheel mounting bolts (4) fig. 3	M 12 x 1.25	40	4.1	60°

TIGHTENING TORQUE DATA

FASTENERS	Thread	Tightening torque	
		Nm	kgm
Rocker shaft pedestal bolts (5) fig. 3	M 8	25	2.5
Crankshaft hub retaining nut (6) fig. 3	M 30 x 1.5	294	30
Fan and alternator pulley bolts (7) fig. 3	M 10 x 1.25	55	5.6
Inlet manifold retaining bolts	M 8	25	2.6
Alternator and belt tension adjustment nut	M 10 x 1.25	55	5.6
Coolant pump retaining bolts	M 10 x 1.25	55	5.6
Rocker cover nuts	M 8	25 (*)	2.6 (*)
Oil pump and pump cover retaining bolts	M 8	25	2.6
Timing gear case and cover bolts	M 8	25	2.6
Intermediate flanged journal bolts	M 10 x 1.25	55	5.6
Camshaft thrust plate retaining bolts	M 8	35	3.6
Rear crankcase cover bolts	M 8	25	2.6
Tappet adjuster screw locknuts	M 8	22	2.2
Exhaust manifold retaining bolts	M 8	25	2.6
Injection pump mounting nuts	M 8	25	2.6
Sump pan retaining bolts, to - inner rear timing cover and gear case	M 10 X 1.25	39 - 49	4 - 5
- cylinder block and flywheel case	M 10 X 1.25	49 - 59	5 - 6

(*)

TOOLS

WARNING: The operations described in this section can only be carried out with the **ESSENTIAL** tools indicated by an (X).

To work safely and efficiently and obtain the best results, it is also necessary to use the recommended specific tools listed below and certain other tools which are to be made according to the drawings included in this manual.

List of specific tools required for the various operations described in this section.

X 291883	Wrench for valve clearance adjustment.
X 291046	Punch for valve guide extraction / installation.
X 294027	Twist bit for enlarging valve guide bore.
X 294028	8 · Tapered grinder for swaging exhaust valve guides
X 293231	Bush for valve guide installation (with 291046).
X 291177	Valve guide reamer.
X 291050	Valve spring compressor.
X 293270	Set of grinding tools for regrinding injector seat.
X 291182	Puller for coolant pump impeller.
X 293280	Drift for installation of coolant pump impeller seal.
293814	Check set, turbocharger (TT65).
293786	Wrench for injection pump delivery line unions.
293671	Injector cleaning kit.
X 293761	Wrench set for injector dismantling.
293780	Injection check hand pump.
290284	Hand pump for injector calibration test.
X 291160	Injection pump bench test
X 291048	291754 Dial gauge (1/100 mm scale, 5 mm stroke, \sim 40 mm with 291755).
X 292248	291755 Device for BOSCH injection pump timing on engine.
X 291504	X 295042 Extractor for injection pump drive gear.

Sample of manual. Download All 407 pages at:

<https://www.arepairmanual.com/downloads/new-holland-t3-50f-t3-55f-t3-65f-t3-75f-tractor-service-repair-manual/>

47763567 - 11 - 2014