

# SERVICE MANUAL

## E175C EVO Tier III Crawler Excavator

Part number 48044247

English

September 2016



Product: New Holland E175C EVO Tier III Crawler Excavator Service Repair Manual  
Full Download: <https://www.arepairmanual.com/downloads/new-holland-e175c-evo-tier-iii-crawler-excavator-service-repair-manual/>



## **SERVICE MANUAL**

**E175C EVO Crawler excavator LC version (TIER 3)**

Sample of manual. Download All 3017 pages at:

<https://www.arepairmanual.com/downloads/new-holland-e175c-evo-tier-iii-crawler-excavator-service-repair-manual/>

48044247 05/09/2016

EN

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.102] Pan and covers .....	10.2
[10.106] Valve drive and gears .....	10.3
[10.101] Cylinder heads .....	10.4
[10.105] Connecting rods and pistons.....	10.5
[10.103] Crankshaft and flywheel.....	10.6
[10.216] Fuel tanks .....	10.7
[10.206] Fuel filters .....	10.8
[10.218] Fuel injection system.....	10.9
[10.202] Air cleaners and lines .....	10.10
[10.250] Turbocharger and lines.....	10.11
[10.254] Intake and exhaust manifolds and muffler .....	10.12
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.13
[10.400] Engine cooling system .....	10.14
[10.414] Fan and drive .....	10.15
[10.310] Aftercooler.....	10.16
[10.304] Engine lubrication system.....	10.17
[10.408] Oil cooler and lines.....	10.18
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.106] Variable displacement pump .....	35.4
[35.102] Pump control valves.....	35.5
[35.359] Main control valve.....	35.6

[35.357] Pilot system .....	35.7
[35.355] Hydraulic hand control .....	35.8
[35.356] Hydraulic foot control.....	35.9
[35.352] Hydraulic swing system .....	35.10
[35.353] Hydraulic travel system .....	35.11
[35.354] Hydraulic central joint .....	35.12
[35.736] Boom hydraulic system .....	35.13
[35.737] Dipper hydraulic system.....	35.14
[35.738] Excavator and backhoe bucket hydraulic system.....	35.15
[35.360] Hammer and rotating bucket hydraulic system .....	35.16
<b>Frames and ballasting .....</b>	<b>39</b>
[39.140] Ballasts and supports .....	39.1
<b>Tracks and track suspension.....</b>	<b>48</b>
[48.130] Track frame and driving wheels .....	48.1
[48.100] Tracks .....	48.2
[48.134] Track tension units .....	48.3
[48.138] Track rollers .....	48.4
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.200] Air conditioning.....	50.2
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.100] Harnesses and connectors.....	55.2
[55.525] Cab engine controls.....	55.3
[55.015] Engine control system.....	55.4
[55.201] Engine starting system .....	55.5
[55.301] Alternator.....	55.6
[55.302] Battery.....	55.7

[55.202] Cold start aid .....	55.8
[55.010] Fuel injection system .....	55.9
[55.014] Engine intake and exhaust system.....	55.10
[55.989] Exhaust Gas Recirculation (EGR) electrical system .....	55.11
[55.012] Engine cooling system .....	55.12
[55.013] Engine oil system .....	55.13
[55.640] Electronic modules .....	55.14
[55.512] Cab controls.....	55.15
[55.036] Hydraulic system control .....	55.16
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls.....	55.17
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.18
[55.416] Swing control system .....	55.19
[55.417] Travel control system .....	55.20
[55.530] Camera.....	55.21
[55.518] Wiper and washer system.....	55.22
[55.404] External lighting .....	55.23
[55.514] Cab lighting .....	55.24
[55.408] Warning indicators, alarms, and instruments .....	55.25
[55.992] Anti-theft system .....	55.26
[55.DTC] FAULT CODES.....	55.27
<b>Booms, dippers, and buckets .....</b>	<b>84</b>
[84.910] Boom.....	84.1
[84.912] Dipper arm .....	84.2
[84.100] Bucket.....	84.3
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.150] Cab.....	90.1
[90.156] Cab windshield and windows .....	90.2
[90.120] Mechanically-adjusted operator seat.....	90.3

[90.100] Engine hood and panels ..... 90.4





# INTRODUCTION

# Contents

---

## INTRODUCTION

Foreword - Important notice regarding equipment servicing .....	3
Safety rules .....	4
Safety rules - General information .....	5
Safety rules - Personal safety .....	6
Safety rules - Cab protective structure .....	8
Safety rules - Ecology and the environment .....	9
Torque - Bolt and nut .....	10
Torque - Special torque settings .....	11
Basic instructions - Shop and assembly .....	15
Hydraulic contamination .....	17
General specification - Main equipment .....	18
Weight .....	25
Dimension .....	27
Conversion factors .....	28
Consumables .....	40
Abbreviation .....	44
Product identification .....	47
Product identification - Machine orientation .....	49

---

## **Foreword - Important notice regarding equipment servicing**

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your NEW HOLLAND CONSTRUCTION Sales and Service Networks.

## Safety rules

### Personal safety



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

**FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.**

### Machine safety

**NOTICE:** Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

### Information

**NOTE:** Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

## **Safety rules - General information**

### **Cleaning**

Clean the metal parts with cleaning solution that meets the standard and steam cleaning. (except for bearings)

After cleaning, dry well, and inject oil in all parts.

Also inject oil into the bearings after drying.

### **Inspection**

When disassembling parts, check all the parts.

If there are any worn or damaged parts, replace them.

Inspect carefully to prevent initial breakdowns.

### **Bearing**

Replace any loose bearings.

Air dry bearings before installing them.

### **Needle bearing**

When inserting needle bearings, be very careful not to damage them.

Apply grease to the section where the needle bearing will be inserted.

### **Gear**

Check that there is no wear and no damage.

### **Oil seal, O-ring, gasket**

Always install new oil seals, O-rings, and gaskets.

Apply grease to sections where oil seals and O-rings will be inserted.

### **Shaft**

Check that there is no wear and no damage.

Check the bearings and check for damaged oil seals on the shaft.

### **Service parts**

Install NEW HOLLAND CONSTRUCTION genuine service parts.

When placing an order, check the parts catalog. It contains the NEW HOLLAND CONSTRUCTION genuine part numbers.

Any breakdowns arising from the installation of non-genuine parts are not covered by the warranty.

### **Lubricants (fuel, hydraulic oil)**

Use the oil from the specified company or specified in the operator's manual or service Manual.

Any breakdowns arising from any fuel or hydraulic oil other than those specified are not covered by the warranty.

## Safety rules - Personal safety

 **WARNING:**

This symbol indicates a precaution.  
It gives information concerning the safety of the operator and those in the surroundings.  
Read and understand these precautions thoroughly before performing the work.

Always comply with warnings and precautions so as to avoid any accidents.

This section covers information related to overall safety.

Check whether all warning labels are in place.

Additional labels can be ordered from Service Parts.

 **WARNING:**

Read the operator's manual to gain a thorough understanding of machine control operations.

 **WARNING:**

Perform any machine operations from the seating position.  
Any other method may cause severe injuries.

 **WARNING:**

Only the one operator is to ride on the machine. No one else is to ride on it.

 **WARNING:**

Check the safety messages in the operator's manual before starting the engine.  
Check all the warning labels on the machine.  
Check that no one is within the machine's operating range.  
Check the operating methods in a safe location before starting the actual work.  
Understand the machine operations well, then operate in compliance with all service-related laws and regulations.  
The operator's manual can be purchased at your NEW HOLLAND CONSTRUCTION dealer.

 **WARNING:**

Working with sloppy clothes or clothes with which safety cannot be ensured leads to damage to the machine and injury to the operator.  
Always wear clothes that ensures safety.  
In order to work more safely, it is recommended to wear additional safety equipment.  
Helmet, safety shoes, ear protection, goggles, work clothes, and gloves

 **WARNING:**

Pay careful attention when working with the engine running.

 **WARNING:**

Check hydraulic equipment.  
Work according to the procedure.  
Do not change the procedure.

## INTRODUCTION

 WARNING:

Check that there is no one in the surroundings before draining the pressure from hydraulic circuits during machine hydraulic cylinder inspection.

 WARNING:

Use gloves when handling high-temperature parts.

 WARNING:

Bring the lower parts or attachments in contact with the ground before inspecting or repairing them.

 WARNING:

Check that hoses and tubes are securely connected.  
If there is any damage to a hose or tube, replace it.  
Do not check for oil leaks by hand. Use cardboard or wood.

 WARNING:

When removing an attachment pin or other hardened pin, use a hammer that has a soft head.

 WARNING:

Wear eye protection when using a hammer to install a pin or when working with a grinder.  
At this time, use goggles or eye protectors that meet standards.

 WARNING:

Park the machine in a safe location when repairing or inspecting it.

 WARNING:

Use work site protection when repairing the machine.  
Check the oil, coolant, grease, and tools.  
Recover materials and parts as necessary.  
Pay enough attention to safety.

 WARNING:

Some of the machine's parts are extremely heavy.  
Use an appropriate lifting equipment for such parts.  
For weights and procedures, see the Service Manual.

 WARNING:

Exhaust gases are toxic.  
Always provide good ventilation when working indoors or in any other enclosed space.

 WARNING:

If the electrolytic battery solution freezes, it may explode.

## Safety rules - Cab protective structure


### Cab protective structure

Modifying the cab main components is prohibited in order to protect the operator.

### Prohibited items

- Modifications that reduce the strength of a platform that has a cab with a protective structure mounted on it. (Actions or modifications that reduce the functionality of the anchoring part at the left-rear of the cab)
- Modifications that effect the strength of the cab with a protective structure.

Modifications prohibited (red part)	All modifications (grinding, welding, drilling holes, removing, etc.) are prohibited.
Modifications permitted under conditions (gray part)	Removal of parts is prohibited. Bar welding and making holes (up to diameter <b>20 mm (0.787 in)</b> ) by drilling are possible.



SMPH15CEX6544FA 1

---

## Safety rules - Ecology and the environment

Soil, air, and water quality is important for all industries and life in general. When legislation does not yet rule the treatment of some of the substances that advanced technology requires, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

Familiarize yourself with the relative legislation applicable to your country, and make sure that you understand this legislation. Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, anti-freeze, cleaning agents, etc., with regard to the effect of these substances on man and nature and how to safely store, use, and dispose of these substances.

### Helpful hints

- Avoid the use of cans or other inappropriate pressurized fuel delivery systems to fill tanks. Such delivery systems may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of these products contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when you drain fluids such as used engine coolant mixtures, engine oil, hydraulic fluid, brake fluid, etc. Do not mix drained brake fluids or fuels with lubricants. Store all drained fluids safely until you can dispose of the fluids in a proper way that complies with all local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- The air-conditioning system contains gases that should not be released into the atmosphere. Consult an air-conditioning specialist or use a special extractor to recharge the system properly.
- Repair any leaks or defects in the engine cooling system or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding. Penetrating weld splatter may burn a hole or weaken hoses, allowing the loss of oils, coolant, etc.

### Battery recycling

Batteries and electric accumulators contain several substances that can have a harmful effect on the environment if the batteries are not properly recycled after use. Improper disposal of batteries can contaminate the soil, groundwater, and waterways. NEW HOLLAND CONSTRUCTION strongly recommends that you return all used batteries to a NEW HOLLAND CONSTRUCTION dealer, who will dispose of the used batteries or recycle the used batteries properly. In some countries, this is a legal requirement.



### Mandatory battery recycling

**NOTE:** The following requirements are mandatory in Brazil.


Batteries are made of lead plates and a sulfuric acid solution. Because batteries contain heavy metals such as lead, CONAMA Resolution 401/2008 requires you to return all used batteries to the battery dealer when you replace any batteries. Do not dispose of batteries in your household garbage.

Points of sale are obliged to:

- Accept the return of your used batteries
- Store the returned batteries in a suitable location
- Send the returned batteries to the battery manufacturer for recycling

## Torque - Bolt and nut

- Tighten alternating between left and right and top and bottom so that uniform tightening force is applied.



LPIL12CX00005EA 1

- If **LOCTITE®** was used on a removed bolt (there is something white sticking to the bolt when it is removed), clean the old **LOCTITE®** off with cleaning fluid, dry the bolt, then apply 2 - 3 drops of **LOCTITE®** to the thread section of the bolt.

### Torque table

Bolt nominal diameter (size)		M6	M8	M10	M12	M14	M16	M18	M20
Hexagon bolt	Wrench	10 mm	13 mm	17 mm	19 mm	22 mm	24 mm	27 mm	30 mm
	Tightening torque	6.9 N·m (5.089 lb ft)	19.6 N·m (14.456 lb ft)	39.2 N·m (28.912 lb ft)	58.8 N·m (43.369 lb ft)	98.1 N·m (72.355 lb ft)	156.9 N·m (115.72 m (115.72 3 lb ft)	196.1 N·m (144.63 m (144.63 6 lb ft)	294.2 N·m (216.99 m (216.99 1 lb ft)
Hexagon socket head bolt	Wrench	5 mm	6 mm	8 mm	10 mm	12 mm	14 mm	14 mm	17 mm
	Tightening torque	8.8 N·m (6.491 lb ft)	21.6 N·m (15.931 lb ft)	42.1 N·m (31.051 lb ft)	78.5 N·m (57.899 lb ft)	117.7 N·m (86.811 lb ft)	176.5 N·m (130.18 m (130.18 0 lb ft)	245.2 N·m (180.85 m (180.85 0 lb ft)	343.2 N·m (253.13 m (253.13 1 lb ft)

## Torque - Special torque settings






Code	Retightening location		Bolt nominal diameter	Wrench	Tightening torque
1*	Travel motor		M16	24 mm	267 - 312 N·m (196.93 - 230.12 lb ft)
2*	Drive sprocket		M16	24 mm	267 - 312 N·m (196.93 - 230.12 lb ft)
3*	Take-up roller		M16	24 mm	267 - 312 N·m (196.93 - 230.12 lb ft)
4*	Upper roller		M20	30 mm	521 - 608 N·m (384.27 - 448.44 lb ft)
5*	Lower roller		M18	27 mm	371 - 432 N·m (273.64 - 318.63 lb ft)
6*	Track guard		M18	27 mm	400 - 462 N·m (295.02 - 340.75 lb ft)
7	Shoe		M20	30 mm	755 - 853 N·m (556.86 - 629.14 lb ft)
8	Counterweight		M27	41 mm	1078 - 1274 N·m (795.09 - 939.65 lb ft)
9	Turntable bearing	Outside	M20	30 mm	468 - 545 N·m (345.18 - 401.97 lb ft)
		Inside	M20	30 mm	518 - 590 N·m (382.06 - 435.16 lb ft)
10*	Swing unit		M20	30 mm	539.4 - 629.6 N·m (397.84 - 464.37 lb ft)
11*	Engine	Mount	M16	24 mm	264.9 - 313.9 N·m (195.38 - 231.52 lb ft)
13*		Rear bracket	M12	19 mm	109 - 127 N·m (80.39 - 93.67 lb ft)
14	Radiator		M12	19 mm	63.8 - 73.6 N·m (47.06 - 54.28 lb ft)
15*	Hydraulic pump	Pump	M16	14 mm hexagon socket head	223 - 247 N·m (164.48 - 182.18 lb ft)
16*		Flange	M10	17 mm	63.7 - 72.6 N·m (46.98 - 53.55 lb ft)
17*	Hydraulic oil tank		M16	24 mm	232.4 - 276 N·m (171.41 - 203.57 lb ft)
18*	Fuel tank		M16	24 mm	232.4 - 276 N·m (171.41 - 203.57 lb ft)
19*	Control valve		M16	24 mm	267 - 312 N·m (196.93 - 230.12 lb ft)
20*	Center	Lock bar	M12	19 mm	88.3 - 107 N·m (65.13 - 78.92 lb ft)
21*	Joint	Joint	M12	19 mm	109 - 127 N·m (80.39 - 93.67 lb ft)
22	Cab		M16	24 mm	149 - 173 N·m (109.90 - 127.60 lb ft)
23			M16	17 mm	19.6 - 29.4 N·m (14.46 - 21.68 lb ft)



### CAUTION:

- For items marked with \*, always apply **LOCTITE® 262™** or the equivalent and tighten to the specified torque. The tightening torque in kgf·m is determined with  $N \cdot m \div 9.8$  (  $lbf \cdot ft \div 7.2$  ).







INTRODUCTION



5DBFE379

5DBFE379 1






INTRODUCTION



6C30DB40

6C30DB40 2

INTRODUCTION



74009C0B

74009C0B 3

---

## Basic instructions - Shop and assembly

### Shimming

For each adjustment operation, select adjusting shims and measure the adjusting shims individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value shown on each shim.

### Rotating shaft seals

For correct rotating shaft seal installation, proceed as follows:

1. Before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes.
2. Thoroughly clean the shaft and check that the working surface on the shaft is not damaged.
3. Position the sealing lip facing the fluid.

**NOTE:** *With hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will move the fluid towards the inner side of the seal.*

4. Coat the sealing lip with a thin layer of lubricant (use oil rather than grease). Fill the gap between the sealing lip and the dust lip on double lip seals with grease.
5. Insert the seal in its seat and press down using a flat punch or seal installation tool. Do not tap the seal with a hammer or mallet.
6. While you insert the seal, check that the seal is perpendicular to the seat. When the seal settles, make sure that the seal makes contact with the thrust element, if required.
7. To prevent damage to the seal lip on the shaft, position a protective guard during installation operations.

### O-ring seals

Lubricate the O-ring seals before you insert them in the seats. This will prevent the O-ring seals from overturning and twisting, which would jeopardize sealing efficiency.

### Sealing compounds

Apply a sealing compound on the mating surfaces when specified by the procedure. Before you apply the sealing compound, prepare the surfaces as directed by the product container.

### Spare parts

Only use CNH Original Parts or NEW HOLLAND CONSTRUCTION Original Parts.

Only genuine spare parts guarantee the same quality, duration, and safety as original parts, as they are the same parts that are assembled during standard production. Only CNH Original Parts or NEW HOLLAND CONSTRUCTION Original Parts can offer this guarantee.

When ordering spare parts, always provide the following information:

- Machine model (commercial name) and Product Identification Number (PIN)
- Part number of the ordered part, which can be found in the parts catalog

---

## Protecting the electronic and/or electrical systems during charging and welding

To avoid damage to the electronic and/or electrical systems, always observe the following practices:

1. Never make or break any of the charging circuit connections when the engine is running, including the battery connections.
2. Never short any of the charging components to ground.
3. Always disconnect the ground cable from the battery before arc welding on the machine or on any machine attachment.
  - Position the welder ground clamp as close to the welding area as possible.
  - If you weld in close proximity to a computer module, then you should remove the module from the machine.
  - Never allow welding cables to lie on, near, or across any electrical wiring or electronic component while you weld.
4. Always disconnect the negative cable from the battery when charging the battery in the machine with a battery charger.

**NOTICE:** *If you must weld on the unit, you must disconnect the battery ground cable from the machine battery. The electronic monitoring system and charging system will be damaged if this is not done.*

5. Remove the battery ground cable. Reconnect the cable when you complete welding.

### **WARNING**

**Battery acid causes burns. Batteries contain sulfuric acid.**

**Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately. Failure to comply could result in death or serious injury.**

W0111A

## Special tools

The special tools that NEW HOLLAND CONSTRUCTION suggests and illustrate in this manual have been specifically researched and designed for use with NEW HOLLAND CONSTRUCTION machines. The special tools are essential for reliable repair operations. The special tools are accurately built and rigorously tested to offer efficient and long-lasting operation.

By using these tools, repair personnel will benefit from:

- Operating in optimal technical conditions
- Obtaining the best results
- Saving time and effort
- Working in safe conditions

## Hydraulic contamination

Contamination in the hydraulic system is a major cause of the malfunction of hydraulic components. Contamination is any foreign material in the hydraulic oil.

Contamination can enter the hydraulic system in several ways:

- When you drain the oil or disconnect any line
- When you disassemble a component
- From normal wear of the hydraulic components
- From damaged seals or worn seals
- From a damaged component in the hydraulic system

All hydraulic systems operate with some contamination. The design of the components in this hydraulic system permits efficient operation with a small amount of contamination. An increase in this amount of contamination can cause problems in the hydraulic system.

The following list includes some of these problems:

- Cylinder rod seals that leak
- Control valve spools that do not return to neutral
- Movement of control valve spools is difficult
- Hydraulic oil that becomes too hot
- Pump gears, housing, and other parts that wear rapidly
- Relief valves or check valves held open by dirt
- Quick failure of components that have been repaired
- Slow cycle times are slow. The machine does not have enough power.

If your machine has any of these problems, check the hydraulic oil for contamination.

There are two types of contamination: microscopic and visible.

Microscopic contamination occurs when very fine particles of foreign material are suspended in the hydraulic oil. These particles are too small to see or feel. Microscopic contamination can be found by identification of the following problems or by testing in a laboratory.

Examples of problems caused by microscopic contamination:

- Cylinder rod seals that leak
- Control valve spools that do not return to neutral
- The hydraulic system has a high operating temperature

Visible contamination is foreign material that can be found by sight, touch, or odor. Visible contamination can cause a sudden failure of components.

Examples of problems caused by visible contamination:

- Particles of metal or dirt in the oil
- Air in the oil
- Dark or thick oil
- Oil with an odor of burned oil
- Water in the oil

If you find contamination, use a portable filter to clean the hydraulic system.

## General specification - Main equipment

### Lower component

#### Travel unit

Manufacturer	KYB Corporation
Motor type	Variable displacement piston motor
	Automatic 2-speed switchover with parking brake
Intake amount	<b>72.8 cm<sup>3</sup>/rev (4.44 in<sup>3</sup>/rev) / 143.5 cm<sup>3</sup>/rev (8.76 in<sup>3</sup>/rev)</b>
Operating pressure	<b>34.3 MPa (4975 psi)</b>
Operating flow	<b>143.0 L/min (37.8 US gpm)</b>
Brake torque	<b>25100 N·m (18513 lb ft) min.</b> (including reduction gear)
Relief valve set pressure	<b>35.3 MPa (5120 psi) at 40 l/min (10.57 US gpm)</b>
Automatic 2-speed switch over pressure	<b>25.8 MPa (3742 psi) / 26.5 MPa (3844 psi)</b>
Reduction gear	
Reduction gear type	Planetary gear 2-stage reduction gear
Reduction ratio	43.246
Dry weight	<b>260 kg (573.202 lb)</b>

#### Take-up roller

Weight	<b>96.4 kg (212.5256 lb)</b>
--------	------------------------------

#### Upper roller

Weight	<b>17.8 kg (39.2423 lb)</b>
--------	-----------------------------

#### Lower roller

Weight	<b>35.5 kg (78.2641 lb)</b>
--------	-----------------------------

#### Recoil spring

Weight	<b>43.9 kg (96.7829 lb)</b>
Outer diameter	<b>∅ 188 mm (7.402 in)</b>
Material	SUP11AM
Strand diameter	<b>∅ 42 mm (1.654 in)</b>
Mean diameter of coil	<b>146 mm (5.748 in)</b>
Total number of turns	9.3
Direction of helix	Right
Free height	<b>548 mm (21.575 in)</b>
Mounting length of spring	<b>478 mm (18.819 in)</b>
Mounting load	<b>94 kN (21132.04 lb)</b>
Stroke end height	<b>418 mm (16.457 in)</b>
Stroke end load	<b>175 kN (39341.57 lb)</b>

#### Grease cylinder

Weight	<b>28.3 kg (62.391 lb)</b>
--------	----------------------------

#### Yoke

Weight	<b>23.9 kg (52.690 lb)</b>
--------	----------------------------

#### Threaded rod

Weight	<b>21.9 kg (48.281 lb)</b>
--------	----------------------------

#### Total assembly

Weight	<b>119.25 kg (262.901 lb)</b>
--------	-------------------------------

INTRODUCTION

**Shoe**

	Weight or Quantity
600 grouser with M seal	<b>1181.02 kg (2603.703 lb)</b>
Link	1 set
Shoe	44
Bolt	176
Nut	176

**Upper component**

**Swing unit**

Swing motor assembly	
Swing motor	
Manufacturer	Toshiba Machine Co., Ltd.
Motor type	Fixed displacement piston motor
	With parking brake
Intake amount	<b>151 cm<sup>3</sup>/rev (9.21 in<sup>3</sup>/rev)</b>
Operating pressure	<b>27.9 MPa (4047 psi)</b>
Operating flow	<b>143 l/min (143.0000 US gpm)</b>
Mechanical brake torque	<b>821.5 N·m (605.907 lb ft) min.</b>
Brake off pressure	<b>3.2 MPa (464 psi) or less</b>
Relief valve set pressure	<b>27.9 MPa (4047 psi) at 120 L/min (31.7 US gpm)</b> <b>26.0 MPa (3771 psi) at 40 L/min (10.6 US gpm)</b>
Swing reduction gear	
Reduction gear type	Planetary gear 2-stage reduction gear
Reduction ratio	13.338
Dry weight	<b>235 kg (518.086 lb)</b>
Turntable bearing	
No. of teeth	92
Weight	<b>243.9 kg (537.707 lb)</b>
Counterweight	
Weight	<b>3400 kg (7495.717 lb)</b>

**Engine-related**

**Engine**

Engine model name	ISUZU 4JJ1XYSS diesel engine
Engine type	4-cycle, water-cooled, overhead camshaft type straight cylinder, direct fuel injection type (electronic control)
Number of cylinders-bore-stroke	4 - $\varnothing$ <b>95.4 mm (3.76 in) - 104.9 mm (4.13 in)</b>
Total displacement	<b>2.999 L (0.7923 US gal)</b>
Compression ratio	17.5
Rated output	<b>89.2 kW (121.28 Hp) / 2000 RPM</b>
Maximum torque	<b>391.0 N·m (288.39 lb ft) / about 1800 RPM</b>
Fuel consumption ratio	<b>230.6 g/kWh</b>
Engine dry weight	About <b>320 kg (705.479 lb)</b>
Engine dimension	<b>L 928 mm (36.5354 in) - W 760 mm (29.921 in) - H 888 mm (34.9606 in)</b>
Cooling fan	$\varnothing$ <b>550 mm (21.654 in)</b> - suction type - 8 vanes, plastic
	With bell mouth-type fan guide
Pulley ratio	0.95 (reduction)
Charging generator	<b>24 V 50 A</b> , AC type
Starter motor	<b>24 V 4 kW (5.4 Hp)</b> reduction type
Coolant capacity	<b>6.0 L (1.6 US gal)</b>
Oil pan capacity	Max: <b>15.0 L (4.0 US gal)</b> Min: <b>11.0 L (2.9 US gal)</b> (not including oil filter)

INTRODUCTION

Direction of rotation	Right (viewed from fan side)
	Compliant with JISD 0006-2010

**Muffler**

Manufacturer	Sankei Giken Kogyo Co., Ltd.
Type	D 240 x 650 L
Maximum displacement	<b>20500 L/min (5415.5 US gpm)</b>
Weight <sup>0</sup>	<b>13.2 kg (29.1010 lb)</b>

**Air cleaner (double element)**

Manufacturer	Nippon Donaldson, Ltd.
Element (outer)	
Element (inner)	
Weight	<b>5.4 kg (11.9050 lb)</b>

**Radiator**

Manufacturer	Tokyo Radiator MFG. Co., Ltd.	
Oil cooler	Weight	<b>17.5 kg (38.5809 lb)</b>
	Oil volume	<b>6.9 L (1.8 US gal)</b>
Radiator	Weight	<b>8.8 kg (19.4007 lb)</b>
	Coolant capacity	<b>6.3 L (1.7 US gal)</b>
Air cooler	Weight	<b>6.3 kg (13.8891 lb)</b>
	Capacity	<b>4.4 L (1.2 US gal)</b>
Fuel cooler	Weight	<b>0.7 kg (1.5432 lb)</b>
	Capacity	<b>0.2 L (0.05 US gal)</b>
Total weight	<b>75.9 kg (167.3 lb)</b>	

**Hydraulic device**

**Hydraulic pump**

Manufacturer	Kawasaki Heavy Industries, Ltd.		
Main pump			
	Pump type	Double variable displacement piston pump	
	Displacement capacity	<b>65.2 cm<sup>3</sup>/rev (3.979 in<sup>3</sup>/rev) x 2</b>	
	Operating pressure	Rated	<b>34.3 MPa (4975 psi)</b>
		Maximum	<b>36.3 MPa (5265.32 psi)</b>
	Input revolution speed	<b>2200 RPM</b>	
	Maximum discharge flow	143 x 2 L/min (0.5 US gpm) x 2 (at 2200 RPM)	
		142 x 2 L/min (0.5 US gpm) x 2 (at 2200 RPM)	
Pilot pump			
	Pump type	Gear pump	
	Displacement capacity	<b>10 cm<sup>3</sup>/rev (0.61 in<sup>3</sup>/rev)</b>	
	Operating pressure	<b>3.92 MPa (569 psi)</b>	
	Maximum discharge flow	<b>22 L/min (5.8 US gpm) (at 2200 RPM)</b>	
Control method	Hydraulic simultaneous constant output control		
	Maximum flow adjustment control through external commands (negative control)		
	Maximum flow adjustment control through external commands milli-amp (negative control, front side)		
	Setting through external command milli-amp (horsepower adjustment control)		
Dry weight	<b>86 kg (189.5975 lb)</b>		

**Control-related**

**Control valve**

Manufacturer	Nabtesco Corporation	
Maximum flow	<b>143.0 L/min (37.8 US gpm) (at 2200 RPM)</b>	
Overload set pressure	<b>32.3 MPa (4685 psi) boom down</b>	
	<b>38.2 MPa (5541 psi) other</b>	
Main relief set pressure	<b>34.3 MPa (4975 psi)</b>	
	(for pressure boost)	<b>36.3 MPa (5265 psi)</b>
Foot relief set pressure	<b>2.55 MPa (370 psi)</b>	
Function	Straight travel circuit	
	Boom-up/arm 2 pumps internal flow	
	Boom and arm load holding circuit	
	Boom-down regenerative circuit	
	Bucket-close regenerative circuit	
	Arm-in forced regenerative circuit	
	Swing priority variable orifice	
	2 pumps flow	
	Variable foot relief	
Weight	<b>160 kg (352.740 lb)</b>	

**Solenoid valve (4 stack)**

Manufacturer	Yuken Kogyo Co., Ltd.	
Valve specifications		
Maximum flow	P→B <b>20.0 L/min (5.3 US gpm)</b> Other <b>5 l/min (1.321 US gpm)</b>	
Rated pressure	<b>4.5 MPa (652 psi)</b>	
Port size	P.T.B port	<b>G3/8</b>
	C1, C2, C3, C4, C5 ports	<b>G1/4</b>
Solenoid specifications		
Operating voltage	DC <b>20 - 32 V</b>	
Power consumption	<b>17 W max.</b>	
Weight	<b>5.0 kg (11.0231 lb)</b>	

**Valve for left/right operations**

Manufacturer	Kawasaki Heavy Industries, Ltd.	
Operating pressure	<b>3.92 MPa (569 psi)</b>	
Secondary pressure	<b>0.64 - 2.45 MPa (92.8320 - 355 psi) primary short type</b>	
Operating angle	1,3 port	<b>19 °</b>
	2,4 port	<b>25 °</b>
Weight	<b>1.9 kg (4.1888 lb)</b>	

**Valve for travel operation**

Manufacturer	Kawasaki Heavy Industries, Ltd.	
Operating pressure	<b>3.92 MPa (569 psi)</b>	
Secondary pressure	<b>0.64 - 2.45 MPa (92.8320 - 355 psi) primary short type</b>	
Operating angle	<b>12.4 °</b>	
Weight	<b>5.5 kg (12.1254 lb)</b>	


**Remote control valve for option operations**

Manufacturer	Nishina Industrial Co., Ltd.	
Operating pressure	<b>39.2 bar (568.400 psi)</b>	
Secondary pressure	<b>6.4 - 24.5 bar (92.800 - 355.250 psi) primary short type</b>	
Operating angle	<b>11.4 ° - 12.6 °</b>	
Port size	P, T, A, B, C1, C2 G1/4	
Weight	<b>1.7 kg (3.748 lb)</b>	


**Remote control valve characteristic diagram**

**Operation remote control valve control diagram**

- A. Secondary pressure [MPa (psi)]
- B. Push rod stroke [mm (in)]
- C. Operating angle [deg.]
- 1 Secondary pressure




- A. Secondary pressure [MPa (psi)]
- B. Push rod stroke [mm (in)]
- C. Operating angle [deg.]
- 1 Secondary pressure




**Travel remote control valve control diagram**

- A. Secondary pressure [MPa (psi)]
- B. Push rod stroke [mm (in)]
- C. Pedal operating angle [deg.]
- 1 Secondary pressure



### Remote control valve control diagram

- A. Secondary pressure [MPa (psi)]
- B. Operating angle [deg.]
- 1 Secondary pressure



SML15CEX1698BB 4

### Cushion valve (heat circuit, with shuttle valve)

Manufacturer	Yanagisawa Seiki MFG. Co., Ltd.
Port size	G3/8 ( A - P ports)
	G1/4 ( Q - V ports)
Weight	12.5 kg (27.5578 lb)

### Center joint

Operating pressure	High-pressure passage (ABCD)	34.3 MPa (4975 psi)
	Drain port (E)	0.5 MPa (73 psi)
	Pilot port (F)	3.9 MPa (566 psi)
Flow	High-pressure passage (ABCD)	234 l/min (61.816 US gpm)
	Drain port (E)	10 l/min (2.642 US gpm)
	Pilot port (F)	21 l/min (5.548 US gpm)
Port A	Forward right	G3/4
Port B	Forward left	G3/4
Port C	Backward right	G3/4
Port D	Backward left	G3/4
Port E	Drain port	G1/2
Port F	Pilot port	G1/4
Weight		30 kg (66.139 lb)

### Backhoe attachment

#### Cylinder

Boom cylinder	
Manufacturer	KYB Corporation
Cylinder bore	∅ 115 mm (4.528 in)
Rod diameter	∅ 80 mm (3.150 in)
Maximum retracted length	1698 mm (66.850 in)