

# SERVICE MANUAL

## Boomer™ 3040 CVT / Boomer™ 3045 CVT / Boomer™ 3050 CVT Compact Tractor *PIN ZCMB11001 and above*

**Part number 48080061**

2<sup>nd</sup> edition English

November 2016 Download All 1975 pages at:

<https://www.aresairmanual.com/downloads/new-holland-boomer-3040-cvt-3045-cvt-3050-cvt-tractor-service-repair-manual/>



Product: New Holland Boomer? 3040 CVT/3045 CVT/3050 CVT Tractor Service Repair Manual  
Full Download: <https://www.arepairmanual.com/downloads/new-holland-boomer-3040-cvt-3045-cvt-3050-cvt-tractor-service-repair-manual/>



## SERVICE MANUAL

**Boomer™ 3040 CVT [ZCMB11001 - ], Boomer™ 3040 CVT [ZDMB11925 - ],  
Boomer™ 3045 CVT [ZCMB11001 - ], Boomer™ 3045 CVT [ZDMB11925 - ],  
Boomer™ 3050 CVT [ZCMB11001 - ], Boomer™ 3050 CVT [ZDMB11925 - ]**

Sample of manual. Download All 1975 pages at:

<https://www.arepairmanual.com/downloads/new-holland-boomer-3040-cvt-3045-cvt-3050-cvt-tractor-service-repair-manual/>

48080061 10/11/2016

EN

## Link Product / Engine

---

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
Boomer™ 3040 CVT [ZCMB11001 - ]	North America	N844
Boomer™ 3040 CVT [ZDMB11925 - ]	North America	N844
Boomer™ 3045 CVT [ZCMB11001 - ]	North America	N844L
Boomer™ 3045 CVT [ZDMB11925 - ]	North America	N844L
Boomer™ 3050 CVT [ZCMB11001 - ]	North America	N844L
Boomer™ 3050 CVT [ZDMB11925 - ]	North America	N844L

# Contents

---

## INTRODUCTION

<b>Engine</b> .....	<b>10</b>
[10.001] Engine and crankcase .....	10.1
[10.101] Cylinder heads .....	10.2
[10.102] Pan and covers .....	10.3
[10.103] Crankshaft and flywheel.....	10.4
[10.105] Connecting rods and pistons.....	10.5
[10.106] Valve drive and gears .....	10.6
[10.110] Balancer and damper .....	10.7
[10.114] Pump drives .....	10.8
[10.218] Fuel injection system.....	10.9
[10.254] Intake and exhaust manifolds and muffler .....	10.10
[10.304] Engine lubrication system.....	10.11
[10.400] Engine cooling system .....	10.12
[10.414] Fan and drive .....	10.13
<b>Transmission</b> .....	<b>21</b>
[21.504] Continuously Variable Transmission (CVT) .....	21.1
<b>Four-Wheel Drive (4WD) system</b> .....	<b>23</b>
[23.101] Mechanical control .....	23.1
<b>Front axle system</b> .....	<b>25</b>
[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.310] Final drives .....	25.3
<b>Rear axle system</b> .....	<b>27</b>
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential .....	27.2

<b>Power Take-Off (PTO)</b> .....	<b>31</b>
[31.104] Rear electro-hydraulic control .....	31.1
[31.110] One-speed rear Power Take-Off (PTO) .....	31.2
[31.120] Central Power Take-Off (PTO) .....	31.3
<b>Brakes and controls</b> .....	<b>33</b>
[33.110] Parking brake or parking lock .....	33.1
[33.120] Mechanical service brakes .....	33.2
<b>Hydraulic systems</b> .....	<b>35</b>
[35.000] Hydraulic systems .....	35.1
[35.104] Fixed displacement pump .....	35.2
[35.204] Remote control valves .....	35.3
[35.300] Reservoir, cooler, and filters.....	35.4
<b>Steering</b> .....	<b>41</b>
[41.200] Hydraulic control components.....	41.1
[41.206] Pump .....	41.2
[41.216] Cylinders .....	41.3
<b>Cab climate control</b> .....	<b>50</b>
[50.100] Heating .....	50.1
[50.104] Ventilation .....	50.2
[50.200] Air conditioning .....	50.3
<b>Electrical systems</b> .....	<b>55</b>
[55.000] Electrical system .....	55.1
[55.010] Fuel injection system .....	55.2
[55.100] Harnesses and connectors.....	55.3
[55.201] Engine starting system .....	55.4
[55.301] Alternator .....	55.5
[55.302] Battery.....	55.6
[55.404] External lighting .....	55.7

[55.408] Warning indicators, alarms, and instruments .....	55.8
[55.518] Wiper and washer system.....	55.9
[55.640] Electronic modules .....	55.10
[55.DTC] FAULT CODES.....	55.11
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.100] Engine hood and panels .....	90.1
[90.116] Fenders and guards.....	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.150] Cab.....	90.4
[90.151] Cab interior.....	90.5
[90.154] Cab doors and hatches .....	90.6





# INTRODUCTION

# Contents

---

## INTRODUCTION

Foreword - Important notice regarding equipment servicing .....	3
Foreword (*) .....	4
Safety rules .....	5
Safety rules - Ecology and the environment .....	6
Basic instructions - Important notice regarding equipment servicing (*) .....	7
Basic instructions Hardware (*) .....	8
Basic instructions - Shop and assembly .....	9
Torque Wheel Bolt Torques (*) .....	11
Basic instructions Tire ballast and pressures (*) .....	12
General specification Tire Pressures (*) .....	13
Special tools (*) .....	14
Special tools (*) .....	15
International symbols (*) .....	16
Hydraulic contamination .....	17
General specification (*) .....	18
Consumables (*) .....	19
Capacities (*) .....	20
General specification (*) .....	21
Weight (*) .....	26
General specification (*) .....	27
Dimension General (*) .....	28
Product identification General information (*) .....	33

(\*) See content for specific models

---

## **Foreword - Important notice regarding equipment servicing**

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your NEW HOLLAND Sales and Service Networks.

---

## Foreword

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

This repair manual provides the technical information needed to properly service the NEW HOLLAND Boomer 3040, Boomer 3045, Boomer 3050 CVT (Constant Velocity Transmission) model tractors. Use this manual in conjunction with the operator's manual for complete operation, adjustment, and maintenance information

On NEW HOLLAND equipment, left and right are determined by standing behind the unit, looking in the direction of travel.

## Safety rules

### Personal safety



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

**FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.**

### Machine safety

**NOTICE:** Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

### Information

**NOTE:** Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

---

## Safety rules - Ecology and the environment

Soil, air, and water quality is important for all industries and life in general. When legislation does not yet rule the treatment of some of the substances that advanced technology requires, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

Familiarize yourself with the relative legislation applicable to your country, and make sure that you understand this legislation. Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, anti-freeze, cleaning agents, etc., with regard to the effect of these substances on man and nature and how to safely store, use, and dispose of these substances.

### Helpful hints

- Avoid the use of cans or other inappropriate pressurized fuel delivery systems to fill tanks. Such delivery systems may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of these products contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when you drain fluids such as used engine coolant mixtures, engine oil, hydraulic fluid, brake fluid, etc. Do not mix drained brake fluids or fuels with lubricants. Store all drained fluids safely until you can dispose of the fluids in a proper way that complies with all local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- The air-conditioning system contains gases that should not be released into the atmosphere. Consult an air-conditioning specialist or use a special extractor to recharge the system properly.
- Repair any leaks or defects in the engine cooling system or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding. Penetrating weld splatter may burn a hole or weaken hoses, allowing the loss of oils, coolant, etc.

### Battery recycling

Batteries and electric accumulators contain several substances that can have a harmful effect on the environment if the batteries are not properly recycled after use. Improper disposal of batteries can contaminate the soil, groundwater, and waterways. NEW HOLLAND strongly recommends that you return all used batteries to a NEW HOLLAND dealer, who will dispose of the used batteries or recycle the used batteries properly. In some countries, this is a legal requirement.



### Mandatory battery recycling

**NOTE:** The following requirements are mandatory in Brazil.

Batteries are made of lead plates and a sulfuric acid solution. Because batteries contain heavy metals such as lead, CONAMA Resolution 401/2008 requires you to return all used batteries to the battery dealer when you replace any batteries. Do not dispose of batteries in your household garbage.

Points of sale are obliged to:

- Accept the return of your used batteries
- Store the returned batteries in a suitable location
- Send the returned batteries to the battery manufacturer for recycling

---

## Basic instructions - Important notice regarding equipment servicing

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The information in this manual is up-to-date at the date of the publication. It is the policy of the manufacturer for continuous improvement. Some information could not be updated due to modifications of a technical or commercial type, or changes to the laws and regulations of different countries.

In case of questions, refer to your NEW HOLLAND Sales and Service Networks.

---

## Basic instructions Hardware

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

### General

Your tractor has been built using metric hardware.

**NOTE:** Be sure to use the hardware specified when using tapped holes, as trying to install a metric bolt in an inch thread, or an inch bolt in a metric thread, will damage the thread.

Certain hardware must be tightened to specific torque specifications. If specific torque specifications are not noted, tighten the hardware to the standard torque chart specification listed in this manual.

### Plating

Hardware used on NEW HOLLAND balers is plated with zinc chromate (gold color). Gold colored hardware has different torquing requirements from unplated or zinc plated (silver color) hardware because of the difference in the coefficient of friction of the plating material. The torque charts in this manual list the correct specifications for gold, silver, and unplated bolts.

### Nut Tightening

Whenever possible, the nut should be tightened, not the head of the bolt. When tightening using the bolt head, the clamp load can be lost because some of the torque applied twists the bolt instead of tensioning (stretching) it. The tension on the bolt is what holds the joint together.

Approximately 90% of the torque applied during assembly goes to overcoming friction between the parts. The other 10% is used to tension (stretch) the bolt. After assembly, the frictional forces disappear, which is the basis for the saying 'If it does not fail during assembly, it will not fail in service.' The bolt may later fail due to other factors, but not from being over tightened.

### Locknuts

Most locknuts are coated with a special lubricant that is dry to the touch. Anytime a locknut is used, a lower than normal torque is required. Refer to the torque charts in this manual for specific values.

### Jam Nuts

When using a jam nut to lock a regular nut, the jam nut should be installed first and tightened to one half the recommended torque, then held in place while installing a regular nut to the recommended torque.

### Thread Lubrication

The addition of antiseize compound, Molykote, oil, graphite, or any other lubricant to a bolt decreases the friction between it and a nut. This makes it necessary to reduce the recommended torque to prevent over tensioning of the bolt. When using the torque charts in this manual, decrease the value by 20% whenever a lubricant is used.

---

## Basic instructions - Shop and assembly

### Shimming

For each adjustment operation, select adjusting shims and measure the adjusting shims individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value shown on each shim.

### Rotating shaft seals

For correct rotating shaft seal installation, proceed as follows:

1. Before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes.
2. Thoroughly clean the shaft and check that the working surface on the shaft is not damaged.
3. Position the sealing lip facing the fluid.

**NOTE:** *With hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will move the fluid towards the inner side of the seal.*

4. Coat the sealing lip with a thin layer of lubricant (use oil rather than grease). Fill the gap between the sealing lip and the dust lip on double lip seals with grease.
5. Insert the seal in its seat and press down using a flat punch or seal installation tool. Do not tap the seal with a hammer or mallet.
6. While you insert the seal, check that the seal is perpendicular to the seat. When the seal settles, make sure that the seal makes contact with the thrust element, if required.
7. To prevent damage to the seal lip on the shaft, position a protective guard during installation operations.

### O-ring seals

Lubricate the O-ring seals before you insert them in the seats. This will prevent the O-ring seals from overturning and twisting, which would jeopardize sealing efficiency.

### Sealing compounds

Apply a sealing compound on the mating surfaces when specified by the procedure. Before you apply the sealing compound, prepare the surfaces as directed by the product container.

### Spare parts

Only use CNH Original Parts or NEW HOLLAND Original Parts.

Only genuine spare parts guarantee the same quality, duration, and safety as original parts, as they are the same parts that are assembled during standard production. Only CNH Original Parts or NEW HOLLAND Original Parts can offer this guarantee.

When ordering spare parts, always provide the following information:

- Machine model (commercial name) and Product Identification Number (PIN)
- Part number of the ordered part, which can be found in the parts catalog

---

## Protecting the electronic and/or electrical systems during charging and welding

To avoid damage to the electronic and/or electrical systems, always observe the following practices:

1. Never make or break any of the charging circuit connections when the engine is running, including the battery connections.
2. Never short any of the charging components to ground.
3. Always disconnect the ground cable from the battery before arc welding on the machine or on any machine attachment.
  - Position the welder ground clamp as close to the welding area as possible.
  - If you weld in close proximity to a computer module, then you should remove the module from the machine.
  - Never allow welding cables to lie on, near, or across any electrical wiring or electronic component while you weld.
4. Always disconnect the negative cable from the battery when charging the battery in the machine with a battery charger.

**NOTICE:** *If you must weld on the unit, you must disconnect the battery ground cable from the machine battery. The electronic monitoring system and charging system will be damaged if this is not done.*

5. Remove the battery ground cable. Reconnect the cable when you complete welding.

### **WARNING**

**Battery acid causes burns. Batteries contain sulfuric acid.**

**Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately. Failure to comply could result in death or serious injury.**

W0111A

## Special tools

The special tools that NEW HOLLAND suggests and illustrate in this manual have been specifically researched and designed for use with NEW HOLLAND machines. The special tools are essential for reliable repair operations. The special tools are accurately built and rigorously tested to offer efficient and long-lasting operation.

By using these tools, repair personnel will benefit from:

- Operating in optimal technical conditions
- Obtaining the best results
- Saving time and effort
- Working in safe conditions

---

## Torque Wheel Bolt Torques

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

### All models

Front Wheel - Disc-to-Hub: FWD	<b>129 N·m (95 lb ft)</b>
Rear Wheel - Rear Wheel & Disc-to Axle Disc-to Rim .	<b>129 N·m (95 lb ft)</b> <b>244 N·m (180 lb ft)</b>

## Basic instructions Tire ballast and pressures

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

### LIQUID BALLAST (OPTIONAL)

It is a common practice to add weight to the tractor by filling the rear tires with liquid. A calcium chloride (CaCl<sub>2</sub>) and water solution is recommended due to its low freezing point and greater density (weight per gallon) than pure water.

Never exceed the total recommended weight for the tractor. Because special equipment is required to fill the tires, consult your NEW HOLLAND Dealer.

Tires should never be filled beyond **75 %**. At **75 %** full, the liquid will come to the valve stem when the valve stem is at its highest point at the top of the wheel.

### TIRE PRESSURE

Tire pressure must be considered when adding weights, implements, or attachments to the tractor or damage to the tractor may occur.

The chart below outlines tire inflation pressures.

FRONT TIRE INFLATION PRESSURES		
Tire Type	Tire Size	Inflation Pressure
Agricultural: FWD	8 x 16, 6PR, R1	<b>82.7 - 193.1 kPa (12 - 28 psi)</b> 1.4 - 1.9 bar (12 - 28 psi)
Turf: FWD	27 x 10.5-15, 4PR, R3 27/12LL x 15, 6PR, R3	<b>68.9 - 206.8 kPa (10 - 30 psi)</b> <b>55.2 - 68.9 kPa (8 - 10 psi)</b>
Industrial	10 x 16.5, 6PR, R4	<b>110.3 - 310.3 kPa (16 - 45 psi)</b>
REAR TIRE INFLATION PRESSURES		
Agricultural	14.9 x 24, 4 PR, R1	<b>82.7 - 96.5 kPa (12 - 14 psi)</b>
Turf	44 x 18-20, 4PR, R3 22.5LL x 16.1, 6PR, R3	<b>82.7 - 137.9 kPa (12 - 20 psi)</b> <b>41.4 - 55.2 kPa (6 - 8 psi)</b>
Industrial	17.5 x 24, 8PR, R4	<b>82.7 - 179.3 kPa (12 - 26 psi)</b>

**NOTE:** Do not underinflate or overinflate tires. Do not exceed maximum inflation pressure listed.

### REAR TIRE LIQUID

600 g/5 lb Gal Solution/CaCl<sub>2</sub>

### Ballast Weights (Per Tire)

Agricultural	14.9 x 24, 4PR, R1	<b>272 kg (600 lb)</b>
Turf	44 x 18-20, 4PR, R3	<b>249 kg (549 lb)</b>
Industrial (R4)	17.5 x 24, 6PR, R4	<b>272 kg (600 lb)</b>

## General specification Tire Pressures

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

FRONT TIRE INFLATION PRESSURES			
Tire Type	Tire Size	Inflation Pressure	
Agricultural:	2WD	5.50 x 16, 4PR, F2 7.5 x 15, 6 PR	<b>0.6 - 1.4 bar (8 - 20 psi)</b>
	FWD	7 x 16, 6PR, R1 8 x 16, 6PR, R1	<b>0.6 - 1.4 bar (8 - 20 psi)</b> <b>1.4 - 1.7 bar (20 - 24 psi)</b>
Turf:	2WD	25 x 8.50-14, 4PR, R3	<b>0.6 - 0.8 bar (8 - 12 psi)</b>
	FWD	27 x 8.50-15, 4PR, R3	
Industrial (FWD only)	10 x 16.5, 6PR, R4	<b>1.1 - 3.1 bar (16 - 45 psi)</b>	

REAR TIRE INFLATION PRESSURES		
Agricultural	13.6 x 24, 4PR, R1	<b>0.8 - 0.97 bar (12 - 14 psi)</b>
Turf	44 x 18-20, 4PR, R3	<b>0.83 - 1.38 bar (12 - 20 psi)</b>
Industrial (R4)	17.5 x 24, 6PR, R4	<b>0.83 - 1.79 bar (12 - 26 psi)</b>

---

## Special tools

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

Gauge (0-3000 psi)	OEM 1462
Gauge (6000 psi)	OEM 1464
Gauge (300 psi)	OEM 1457
Hose	Procure Locally
Tee Fitting	CNH299061
Adapter	FNH00227
Male Plug	Included with CNH299061
Female Cap	Included with CNH299061
Variseal Installation Tool	293955
Detent Tool	FNH00081
Seal Driver Set	FNH00293
Injector Test	FNH01721
Injector Adapter Set	FNH01728
Clutch Alignment Tool	FNH299006
Engine Compression Test Adapter	FNH00120
Engine Compression Test Gauge Assembly	OEM1074
Oil Pump Port Block Remover Tool	380002888
Oil Pump Port Block Installer Tool	380002887
Oil Pump Port Block Installer Pins	FNH11044
Micrometer	<b>0 - 25 mm (0 - 1 in)</b>
Micrometer	<b>25 - 51 mm (1 - 2 in)</b>
Micrometer	<b>76 - 102 mm (3 - 4 in)</b>
Small Hole Gauge	<b>19 - 25 mm (0.75 - 1 in)</b>
Cylinder Bore Gauge	<b>76 - 102 mm (3 - 4 in)</b>
Cylinder Bore Gauge	<b>25 - 51 mm (1 - 2 in)</b>
HST High Pressure Test Fitting	CNH299007
Engine Oil Pressure Test Fitting	FNH00011
PTO Clutch Pack Pressure Test Fitting	CNH299008
PTO Clutch Pack Press Tool	CNH299009

## Special tools

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

- Gauge - (0-3000 psi) . . . . . Procure Locally
- Gauge - (6000 psi) . . . . . Procure Locally
- Gauge - (300 psi) . . . . . Procure Locally
- Hose . . . . . Procure Locally
- Tee Fitting . . . . . **CNH299061**
- Adapter . . . . . **FNH00227**
- Male Plug . . . . . Included with **CNH299061**
- Female Cap . . . . . Included with **CNH299061**
- Variseal Installation Tool . . . . . **380000836**
- Detent Tool . . . . . **FNH00081**
- Seal Driver Set . . . . . **FNH00293**
- Injector Test . . . . . **FNH01721**
- Injector Adapter Set . . . . . **FNH01728**
- Injector Cleaning Kit . . . . . **FNH01720**
- Engine Compression Test Adapter . . . **FNH00120**
- Engine Compression Test Gauge Assembly . . **OEM1074**
- Oil Pump Port Block Remover Tool . . . . **FNH11097**
- Oil Pump Port Block Installer Tool . . . . **FNH00117**
- Oil Pump Port Block Remover Sleeve (Pair) . . **FNH11099**
- Oil Pump Port Block Installer Pins . . . . . **FNH11044**
- Micrometer . . . . . **0 - 25 mm (0 - 1 in)**
- Micrometer . . . . . **25 - 51 mm (1 - 2 in)**
- Micrometer . . . . . **76 - 102 mm (3 - 4 in)**
- Small Hole Gauge . . . . . **19 - 25 mm (0.75 - 1 in)**
- Cylinder Bore Gauge . . . . . **76 - 102 mm (3 - 4 in)**
- Cylinder Bore Gauge . . . . . **25 - 51 mm (1 - 2 in)**
- Engine Oil Pressure Test Fitting . . . . . **380002904**
- PTO/FWD Oil Pressure Test Fitting . . . . . **380001862**

## International symbols

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

As a guide to the operation of the machine, various universal symbols have been utilized on the instruments, controls, switches, and fuse box. The symbols are shown below with an indication of their meaning.

 Thermostart starting aid	 Radio	 PTO	 Position Control
 Alternator charge	 KAM Keep alive memory	 N Transmission in neutral	 Draft Control
 Fuel level	 Turn signals	 Creeper gears	 Accessory socket
 Automatic Fuel shut-off	 Turn signals -one trailer	 Slow or low setting	 Implement socket
 Engine speed (rev/min x 100)	 Turn signals -two trailers	 Fast or high setting	%age slip symbol" data-bbox="700 360 765 385"/> %age slip
 Hours recorded	 Front windshield wash/wipe	 Ground speed	 Hitch raise (rear)
 Engine oil pressure	 Rear windshield wash/wipe	 Differential lock	 Hitch lower (rear)
 Engine coolant temperature	 Heater temperature control	 Rear axle oil temperature	 Hitch height limit (rear)
 Coolant level	 Heater fan	 Transmission oil pressure	 Hitch height limit (front)
 Tractor lights	 Air conditioner	 FWD engaged	 Hitch disabled
 Headlamp main beam	 Air filter blocked	 FWD dis-engaged	 Hydraulic and transmission filters
 Headlamp dipped beam	 Parking brake	 Warning!	 Remote valve extend
 Work lamps	 Brake fluid level	 Hazard warning lights	 Remote valve retract
 Stop lamps	 Trailer brake	 Variable control	 Remote valve float
 Horn	 Roof beacon	 Pressurized! Open carefully	 Malfunction! See Operator's Manual
	 Warning ! Corrosive substance		 Malfunction! (alternative symbol)

## Hydraulic contamination

Contamination in the hydraulic system is a major cause of the malfunction of hydraulic components. Contamination is any foreign material in the hydraulic oil.

Contamination can enter the hydraulic system in several ways:

- When you drain the oil or disconnect any line
- When you disassemble a component
- From normal wear of the hydraulic components
- From damaged seals or worn seals
- From a damaged component in the hydraulic system

All hydraulic systems operate with some contamination. The design of the components in this hydraulic system permits efficient operation with a small amount of contamination. An increase in this amount of contamination can cause problems in the hydraulic system.

The following list includes some of these problems:

- Cylinder rod seals that leak
- Control valve spools that do not return to neutral
- Movement of control valve spools is difficult
- Hydraulic oil that becomes too hot
- Pump gears, housing, and other parts that wear rapidly
- Relief valves or check valves held open by dirt
- Quick failure of components that have been repaired
- Slow cycle times are slow. The machine does not have enough power.

If your machine has any of these problems, check the hydraulic oil for contamination.

There are two types of contamination: microscopic and visible.

Microscopic contamination occurs when very fine particles of foreign material are suspended in the hydraulic oil. These particles are too small to see or feel. Microscopic contamination can be found by identification of the following problems or by testing in a laboratory.

Examples of problems caused by microscopic contamination:

- Cylinder rod seals that leak
- Control valve spools that do not return to neutral
- The hydraulic system has a high operating temperature

Visible contamination is foreign material that can be found by sight, touch, or odor. Visible contamination can cause a sudden failure of components.

Examples of problems caused by visible contamination:

- Particles of metal or dirt in the oil
- Air in the oil
- Dark or thick oil
- Oil with an odor of burned oil
- Water in the oil

If you find contamination, use a portable filter to clean the hydraulic system.

## General specification

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

	Boomer 3040	Boomer 3045	Boomer 3050
<b>ENGINE</b>			
Type/Model . . . . .	Diesel/N844	Diesel/N844	Diesel/N844
Engine Gross Horsepower . . . . .	<b>29.8 kW (40.5 Hp)</b>	<b>33.6 kW (46 Hp)</b>	<b>33.6 kW (46 Hp)</b>
Cylinders . . . . .	4	4	4
Bore . . . . .	<b>84 mm (3.31 in)</b>	<b>84 mm (3.31 in)</b>	<b>84 mm (3.31 in)</b>
Stroke . . . . .	<b>90 mm (3.54 in)</b>	<b>100 mm (3.94 in)</b>	<b>100 mm (3.94 in)</b>
Displacement . . . . .	<b>2.0 l (122.0 in<sup>3</sup>)</b>	<b>2.2 l (134.3 in<sup>3</sup>)</b>	<b>2.2 l (134.3 in<sup>3</sup>)</b>
Compression Ratio . . . . .	22.5:1	22.5:1	22.5:1
Firing Order . . . . .	1-3-4-2	1-3-4-2	1-3-4-2
Low Idle Speed . . . . .	<b>1025 RPM</b>	<b>1025 RPM</b>	<b>1050 RPM</b>
Maximum Speed:			
High Idle . . . . .	<b>2850 RPM</b>	<b>2850 RPM</b>	<b>3050 RPM</b>
Rated . . . . .	<b>2600 RPM</b>	<b>2600 RPM</b>	<b>2800 RPM</b>

## Consumables

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

Lubricant	Type and Description	Part Number	Container Size
<b>Engine Oil</b>	<b>NEW HOLLAND AMBRA SUPER GOLD SSL ENGINE OIL 10W-40</b>	86994335	<b>9.46 l (2.5 US gal)</b>
	<b>NEW HOLLAND AMBRA AUTO SUPREME 10W-30</b>	86641050	<b>18.93 l (5 US gal)</b>
	<b>NEW HOLLAND AMBRA SUPER GOLD 10W-30</b>	9613313	<b>0.946 l (1 US qt)</b>
		86641052	<b>3.785 l (1 US gal)</b>
		9613314	<b>9.46 l (2.5 US gal)</b>
		9673508DS	<b>18.93 l (5 US gal)</b>
	<b>NEW HOLLAND AMBRA SUPER GOLD HSP ENGINE OIL 30</b>	9613286	<b>0.946 l (1 US qt)</b>
		86641043	<b>3.785 l (1 US gal)</b>
		9613289	<b>9.46 l (2.5 US gal)</b>
		86641044	<b>18.93 l (5 US gal)</b>
	<b>NEW HOLLAND AMBRA SUPER GOLD HSP ENGINE OIL 40</b>	9624812DS	<b>208.2 l (55 US gal)</b>
	<b>NEW HOLLAND AMBRA SUPER GOLD 15W-40</b>	86641081	<b>0.946 l (1 US qt)</b>
		86641082	<b>3.785 l (1 US gal)</b>
		86641084	<b>9.46 l (2.5 US gal)</b>
		86641083	<b>18.93 l (5 US gal)</b>
<b>NEW HOLLAND AMBRA SUPER GOLD 20W-50</b>	86994337	<b>18.93 l (5 US gal)</b>	
<b>NEW HOLLAND AMBRA AUTO SUPREME 5W-30</b>	9673589DS	<b>0.946 l (1 US qt)</b>	
<b>NEW HOLLAND AMBRA AUTO SUPREME 10W-30</b>	86641101	<b>0.946 l (1 US qt)</b>	
<b>Transmission Oil</b>	<b>NEW HOLLAND AMBRA MULTI TRAN</b>	86639558	<b>3.785 l (1 US gal)</b>
		86639559	<b>9.46 l (2.5 US gal)</b>
		86639560	<b>18.93 l (5 US gal)</b>
	<b>NEW HOLLAND AMBRA MULTI BIO S</b>	86994341	<b>9.46 l (2.5 US gal)</b>
<b>Hydraulic Oil</b>	<b>NEW HOLLAND AMBRA MULTI G 134™ HYDRAULIC TRANSMISSION OIL</b>	9624655DS	<b>0.946 l (1 US qt)</b>
		9624656DS	<b>3.785 l (1 US gal)</b>
		9624450	<b>9.46 l (2.5 US gal)</b>
		9624451	<b>18.93 l (5 US gal)</b>
<b>Grease</b>	<b>NEW HOLLAND AMBRA GR-9 MULTI-PURPOSE GREASE</b>	9613310	TUBE - 14 OZ.
<b>Coolant</b>	ESE-M97B18-D, Ethylene Glycol Coolant Concentrate	FGCC2701DS	<b>3.785 l (1 US gal)</b>

## Capacities

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

**All models**

### CAPACITIES

Fuel Tank	<b>49.2 l / 13 US gal</b>
Cooling System	<b>9.0 l / 9.6 US qt</b>
Engine Crankcase: With Filter	<b>6.0 l / 6.3 US qt</b>
Rear Axle & Transmission (Includes Hydraulics)	<b>35.2 l / 9.3 US gal</b>
Front Axle Differential/ Final Reduction Gear Case	<b>5.3 l / 5.6 US qt</b>

## General specification

Boomer™ 3040 CVT	NA
Boomer™ 3045 CVT	NA
Boomer™ 3050 CVT	NA

## Air conditioning system

	Boomer 3040	Boomer 3045	Boomer 3050
Compressor make/model . . . . .	SANDEN/SD5H11	SANDEN/SD5H11	SANDEN/SD5H11
. . . . .			
Bore . . . . .	<b>35 mm</b>	<b>35 mm</b>	<b>35 mm</b>
Stroke . . . . .	<b>22.6 mm</b>	<b>22.6 mm</b>	<b>22.6 mm</b>
Number of Cylinders . . . . .	5	5	5
Refrigerant . . . . .	R-134a	R-134a	R-134a
Capacity . . . . .	<b>1.1 kg (2.4 lb)</b>	<b>1.1 kg (2.4 lb)</b>	<b>1.1 kg (2.4 lb)</b>
Oil . . . . .	SP-20 (or equivalent)	SP-20 (or equivalent)	SP-20 (or equivalent)
Capacity . . . . .	<b>135 ml (4.56 US fl oz)</b>	<b>135 ml (4.56 US fl oz)</b>	<b>135 ml (4.56 US fl oz)</b>
Rotation . . . . .	Clockwise	Clockwise	Clockwise
Blower Motor . . . . .	3 Speed-Electric	3 Speed-Electric	3 Speed-Electric
Number of Interior Vents . . . . .	Switch 8	Switch 8	Switch 8

INTRODUCTION

	Boomer 3040	Boomer 3045	Boomer 3050
<b>COOLING SYSTEM</b>			
Type. . . . .	Pressurized Liquid with Recirculating Bypass	Pressurized Liquid with Recirculating Bypass	Pressurized Liquid with Recirculating Bypass
Water Pump:			
Type. . . . .	Centrifugal	Centrifugal	Centrifugal
Drive. . . . .	V-Belt	V-Belt	
Belt.			
Deflection. . . . .	<b>10 - 15 mm (7/16 - 9/16 in)</b> when <b>9 - 11 kg (20 - 25 lb)</b> thumb pressure is applied midway between belt pulleys	<b>10 - 15 mm (7/16 - 9/16 in)</b> when <b>9 - 11 kg (20 - 25 lb)</b> thumb pressure is applied midway between belt pulleys	<b>10 - 15 mm (7/16 - 9/16 in)</b> when <b>9 - 11 kg (20 - 25 lb)</b> thumb pressure is applied midway between belt pulleys
Fan Diameter. . . .	<b>410 mm (16.1 in)</b>	<b>410 mm (16.1 in)</b>	<b>410 mm (16.1 in)</b>
Number of Fan Blades. . . . .	6	6	6
Thermostat:			
Start to Open. . . .	<b>80 °C (176 °F)</b>	<b>80 °C (176 °F)</b>	<b>80 °C (176 °F)</b>
Fully Open. . . . .	<b>95 °C (203 °F)</b>	<b>95 °C (203 °F)</b>	<b>95 °C (203 °F)</b>
Radiator Cap. . . . .	<b>0.9 bar (13 psi)</b>	<b>0.9 bar (13 psi)</b>	<b>0.9 bar (13 psi)</b>
Antifreeze. . . . .	Ethylene Glycol	Ethylene Glycol	Ethylene Glycol

	Boomer 3040	Boomer 3045	Boomer 3050
<b>ELECTRICAL SYSTEM</b>			
Main System Protection.	<b>80 A</b> Maxifuse	<b>80 A</b> Maxifuse	<b>80 A</b> Maxifuse
Number Fuses for Circuit Protection.	23	23	23
Alternator.	<b>12 V</b> , Heavy Duty, <b>55 A</b>	<b>12 V</b> , Heavy Duty, <b>55 A</b>	<b>12 V</b> , Heavy Duty, <b>55 A</b>
Battery type.	<b>12 V</b> , w/ negative ground, 420 cca	<b>12 V</b> , w/ negative ground, 420 cca	<b>12 V</b> , w/ negative ground, 420 cca
Starter HP (KW) Ratin.	<b>2.0 kW (2.7 Hp)</b>	<b>2.0 kW (2.7 Hp)</b>	<b>2.0 kW (2.7 Hp)</b>
Battery Rating Amp Hrs.	<b>64 - 69 A·h</b>	<b>64 - 69 A·h</b>	<b>64 - 69 A·h</b>
Starting Motor.	Solenoid Pre-Engaged Reduction	Solenoid Pre-Engaged Reduction	
<b>FUEL SYSTEM</b>			
Fuel Type.	Diesel	Diesel	Diesel
Type of Fuel to Use if Above <b>40 °F</b>	No. 2-Diesel, Cetane Rating: Minimum 40	No. 2-Diesel, Cetane Rating: Minimum 40	No. 2-Diesel, Cetane Rating: Minimum 40
Type of Fuel to Use if Below <b>40 °F</b>	No. 1-Diesel, Cetane Rating: Minimum 40	No. 1-Diesel, Cetane Rating: Minimum 40	No. 1-Diesel, Cetane Rating: Minimum 40
Injection Pump:			
Type.	In-Line	In-Line	
Timing.	<b>21 ° BTDC</b>	<b>21 ° BTDC</b>	