


Product: New Holland TX60 Series Combines Service Repair Manual
Full Download: <https://www.arepairmanual.com/downloads/new-holland-tx60-series-combines-service-repair-manual/>



NEW HOLLAND TX60 Series

REPAIR MANUAL



Print No. 84019441

Sample of manual. Download All 1050 pages at:
<https://www.arepairmanual.com/downloads/new-holland-tx60-series-combines-service-repair-manual/>

Product: New Holland TX60 Series Combines Service Repair Manual
Full Download: <https://www.arepairmanual.com/downloads/new-holland-tx60-series-combines-service-repair-manual/>

Sample of manual. Download All 1050 pages at:
<https://www.arepairmanual.com/downloads/new-holland-tx60-series-combines-service-repair-manual/>

	Section
Introduction	01
Traction	02
Grain Header	03
Maize Header	Refer to separate publication
Straw Elevator	05
Threshing	06
Separation	07
Cleaning	08
Grain Storage	09
Straw Chopper	10
Functional Adjustments	11
Engine	12
Airconditioning	13
Hydraulic System	14
Hydrostatic System	15
Electrical System	16



INTRODUCTION


	Page
Explanation of machine and header serial numbers	3
Notes for Service Parts Catalogue consulting	4
Conversion chart	6
Tightening torques	7
Speed ranges	9
Oil application guide	13



EXPLANATION OF MACHINE AND HEADER SERIAL NUMBERS

Machine serial number

PRODUCT IDENTIFICATION




Explanation of model code

- Type 48 = TX62
- 49 = TX64
- 66 = TX65
- 50 = TX66
- 51 = TX68

Header number

PRODUCT IDENTIFICATION





AVAILABLE HEADERS

- 12: 12 ft width grain header
- 13: 13 ft width grain header
- 15: 15 ft width grain header
- 17: 17 ft width grain header
- 20: 20 ft width grain header
- 24: 24 ft width grain header
- 56: 5-row maize header
- 57: 7-row maize header



NOTES FOR SERVICE PARTS CATALOGUE CONSULTING

NOTES FOR CATALOGUE CONSULTING

UPDATING ONLY MICROFICHE



MODIF. ITEM	PART NR.	NT O. DESCRIPTION	DENOMINAZIONE	DESIGNATION	L.C.
	1	84007894	1 SPACER	ENTRETOISE	0750
0202	2	80380429	1 GREASE ZERK	INGRASSATORE	060
	3	84000265	1 BEARING	ROULEMENT	341C
	4	80100020	4 NUT, M16	ECROU	0100
	5	80140048	4 LOCKWASHER, 16MM	ROSETTA DI SICUREZZA	RONDELLE DE SECURITE 132R
	6	80120089	4 BOLT, M16x40	BOULON	140B
	7	80353308	2 NUT, M6	DADO	0100
	8	80140015	2 WASHER, 6MM	ROSETTA PIANA	RONDELLE
	9	84007920	1 CAM (10)	CAMMA	131R
	10	80062312	A 1 SCREW, M10x25	VITE	040C
				VIS	040Y



ENGLISH

1	ITEM	-	Reference - Code of Part Number.	9	Technical specifications relating to the Part indicated.
2	PART NR.	-	Part Number.	10	Model Trademark.
3	NT	-	Note - relating to the Part Number. There is a key to symbols and abbreviations at the bottom of the text page.	11	"Section" Code.
4	Q.	-	Total Quantity of the Part referred to in the page. The quantity can be replaced by the following indications: M = supplied in metres. AR = quantity as requested.	12	"Group" name.
5	MODIF.	-	Modification. C 0202 = Part valid UNTIL 0202. D 0300 = Part valid FROM 0300.	13	"Group" code.
6	Implementation of change.		Serial number from which the change starts. The numbers are indicated on the identification plate of the model (see page 5). E.g.: D0300 Serial n° 2503001 means that the part has been installed "FROM" serial number 2503001. Consequently, the parts marked by C0202, were installed UP TO serial number 2502999.	14	Page number.
7				15	Date of printing or updating of page (month-year).
8				16	Part Description.
				17	L.C.-Lexicon code for the identification of Part names in German and Spanish (see page 33).
				18	Further description of the Part. Besides the specific indications of the Part such as size and use, common descriptions can be utilized (see page 34).
				19	Specific Notes to the illustrations or to the text.
				20	Position of the "Section" on the machine.
				21	Running direction (see page 34).
				22	Parts illustrated without item number are shown in the following group.
				23	General information of the group.

CONVERSION CHART

	Foot	Yard	Mile	Inch	Metre
1 Foot	1	0.333	–	12	0.3048
1 Yard	3	1	–	36	0.9144
1 Mile	5280	1760	1	63360	1609.35
1 Inch	0.0833	0.0277	–	1	0.0254
1 Metre	3.281	1.0936	–	39.37	1

1 US bushel = 35.2391 litre

1 litre = 0.028 US bushel

1 US quart = 0.9464 litre

1 litre = 1.056 US quart

1 UK bushel = 36.3687 litre

1 litre = 0.027 UK bushel

1 UK quart = 1.1365 litre

1 litre = 0.879 UK quart

1 US gallon = 3.785 litre

1 litre = 0.264 US gallon

1 UK gallon = 4.5461 litre

1 litre = 0.22 UK gallon

1 barrel = 158.987 litre

1 litre = 0.0063 barrel

1 acre = 0.4047 ha

1 ha = 2.471 acre

1 pound = 0.4536 kg

1 kg = 2.204 pound

1 hp = 0.736 kW

1 kW = 1.358 hp

1 lb/ in² = 0.0689 bar
= 6.894 kPa

1 bar = 14.5 lbs/ in²
1 kPa = 0.145 lbs/ in²

1 pa = 10⁻⁵ bar
= 1.450x10⁻⁴ lbs/ in²

1 bar = 100 kPa
1 lb/ in² = 6.896 kPa

1 kgf.m = 9.806 Nm

1 Nm = 0.1019 kgf.m

1 lbf ft = 0.1385 kgm

1 kgf.m = 7.22 lbf ft



TIGHTENING TORQUES

Metric hardware

Nominal size	Property class 5-8 Torque Nm		Property class 8-8 Torque Nm			Property class 10-9 Torque Nm	
	plain	plated	lock nut	plain	plated	plain	plated
M4	1.7	2.2	2.3	2.6	3.4	3.7	4.8
M6	5.8	7.1	7.9	8.9	12	3	17
M8	14	18	19	22	28	31	40
M10	28	36	38	43	56	61	79
M12	49	63	66	75	97	107	138
M16	121	158	164	186	240	266	344
M20	237	307	331	375	485	519	671
M24	411	531	573	648	839	897	1160



Imperial hardware


Diameter	SAE GR 2	SAE GR 5		SAE GR 8	
	TORQUE				
	Nm	Nm		Nm	
		A	B	A	B
	1/4"	7	11	10	16
5/16"	14	24	20	35	29
3/8"	24	42	34	65	53
7/16"	42	72	58	102	81
1/2"	61	111	90	156	125
5/8"	111	231	190	319	258
3/4"	210	393	312	563	448
7/8"	224	583	461	814	651
1"	339	868	692	1220	976

A. Bolts not oiled

B. Bolts oiled

Identification

Specification



SAE - Grade 1

No identification

SAE - Grade 2



SAE - Grade 5



SAE - Grade 8


SPEED RANGES (maximum idle)


Fig. 1

Combine left-hand side (Fig. 1)
TX62-64-65-66
TX68

		rpm	rpm
1	Engine	2500	2100
2	Loose pulley on beater shaft	1340	1340
3	Intermediate shaft	800	800
4	Straw elevator top shaft	374	374
5	Header drive	433 (575 for Canada and Australia)	
6	Cleaning shoe drive	600 (540*)	600 (540*)
7	Returns cross auger and roto-thresher (TX68-66 only)	800 (720*)	800 (720*)
8	Returns auger and thrower (TX68-66 only)	600 (540*)	600 (540*)
9	Eccentric shaft	320 (288*)	320 (288*)
10	Chopper drive	2098	2098
11	Chopper	3500	3500
12	Chaff spreader (input shaft)	330	330

* When using small diameter drive pulley 3

Combine right-hand side (Fig. 2)




Fig. 2

	rpm		
1	Intermediate shaft	800	
2	Threshing drum	385 to 1140	
3	Beater	256 to 760	
4	Bubble-up auger speed (gearbox)		
	standard:	370	
	option:	441	
5	Grain elevator top shaft		
	standard:	382	
	option:	456	
6	Rotary separator	760 or 400	
7	Straw flow beater	760 or 400	
8	Straw walker	220	
9	Eccentric shaft	320	288*
10	Cleaning fan	500 to 920	450 to 838*
11	Graitank unloading intermediate shaft	1340	
12	Graitank unloading auger	604	
13	Returns cross auger and rotothresher	800	720*
14	Returns auger and thrower	600	540*


* When using small diameter drive pulley 3 on left-hand side



Combine engine compartment

Models TX62-64-65-66: Ford 675 TA (Fig. 3)

	TX62	TX64/65	TX66
	rpm	rpm	rpm
1 Engine	2100	2500	2500
2 Hydraulic pump	2564	2564	2564
3 Alternator	5817	6925	6925
4 Intermediate shaft	2600	2600	1552
5 Airconditioning compressor	2453	2453	2453
6 Rotary screen	300	300	300
7 Engine fan	1567	1866	1475




30220

Fig. 3

Model TX68: IVECO 8460SRI (Fig. 4)

	rpm
1 Engine	2100
2 Hydraulic pump	2564
3 Alternator	3934
4 Intermediate shaft	1563
5 Airconditioning compressor	2355
6 Rotary screen	302
7 Engine fan	1475



30219

Fig. 4

Grain header (Fig. 5)

- | | | |
|---|--|------------------------------|
| 1 | Knife speed | 575 rpm (1150 cuts/min) |
| 2 | Reel speed with
23-tooth sprocket
13-tooth sprocket | 21 to 57 rpm
12 to 32 rpm |
| 3 | Auger speed with
44-tooth sprocket
52-tooth sprocket | 176 rpm
150 rpm |




Fig. 5

Maize header (Fig. 6)

- | | | |
|---|--|--|
| 1 | Auger speed | 144 rpm |
| 2 | Stalk roll speed with
28-tooth sprocket
24-tooth sprocket
20-tooth sprocket | 892 rpm
1041 rpm
1249 rpm |
| 3 | Gathering chains with
28-tooth sprocket
24-tooth sprocket
20-tooth sprocket | 1.27 m/sec
1.47 m/sec
1.76 m/sec |




Fig. 6

OIL APPLICATION GUIDE

Lubricant	Recommended FNH product	Corresponding international classification
Engine oil	M2C-121-C (SAE 15W-40)	API CE/SF CCMC D4/G2 MIL-L-2104 D
Gearbox oil	M2C-94-A (SAE 80W-90)	API GL-5 MIL-L-2105 D
Hydraulic oil Hydrostatic oil	M2C-48-C3	ISO HV 46 DIN 51524 H-LP32 H-LP46
Chains Threaded rods Pivot points	M2C-94-A	SAE 90 gear oil
Grease nipples	M1C-137A	NLGI - class 2
Brake fluid	M6C-25-A	SAE J 1703A DOT 4
Tracks	M2C-159-B	API-CC-CD MIL-L-2104 C
Airconditioning compressor	—	—
Antifreeze	E 2218 - T - 9	BSS 6580

TRACTION AND STEERING AXLE

	Page
Models TX62-64-65-66-68	1 to 44
Model TX67	45 to 54



TRACTION AND STEERING AXLE

	Page
Traction gearbox	2
- Removal	4
- Disassembly	6
- Assembly	12
Brakes	
- Replacement of the brake linings	17
- Brake cylinders	18
- Bleeding the brakes	20
- Parking brake adjustment	22
- Disassembly and assembly of brake shoes and discs	23
Final drives	
- Removal and installation of final drives	25
- Gear ratio 11/68 and 10/75 with standard seals	27
- Gear ratio 11/68 and 10/75 with mud seals	30
- Gear ratio 11/111 with standard seals	32
- Gear ratio 11/111 with mud seals	36
Steering axles – General data	38
- Steering wheel spindles	38
- Fixed steering axle for TX62-64-65 and adjustable steering axle for TX62-64-65-66	38
- Fixed steering axle for TX68	40
- Heavy-duty adjustable steering axle	41

TRACTION GEARBOX

Oil change

- After the first 100 operating hours
- After 200 operating hours
- Thereafter, every 400 operating hours or annually


Gearbox capacity

15 litres

Oil specification

Use AMBRA Hypoid 90 oil (ref. NH520A) or an oil meeting the following specification:

- API-GL-5 or MIL-L-2105 D
- Viscosity grade: SAE 80W-90



Gear shifting diagram - Figure 1

Shaft A: half-shafts from differential

Shaft B: transmission main shaft

Shaft C: countershaft

Shaft D: drive shaft


Shifting diagram - Figure 2

First gear: 1 - 2 - 3 - 4 - differential


Second gear: 1 - 2 - 5 - 6 - differential

Third gear: 1 - 2 - 7 - 8 - differential

Fourth gear: 1 - 2 - 9 - differential



30694




55164

3

REMOVAL - Figures 3 to 6

1. Remove cover A and cover B.



55165


4



CAUTION:

Before removing any components, secure the machine safely in place by placing adequate wedges against both traction and steering wheels.

2. Remove hydrostatic motor C, and drive shaft D on both sides of the gearbox.



55166

5

3. Remove cover G.
4. Disconnect hand brake cable E and wires F on both sides.
5. Remove tubes H on both sides of the gearbox.
6. Remove the cable for the differential lock.


7. Install a suitable and safe support underneath the gearbox (e.g. a wooden pallet on a forklift).



CAUTION:

**The gearbox is heavy (± 350 kg).
Take extreme caution when removing!
Use a supporting device which can
handle this weight!**


8. Loosen bolts J on both sides of the gearbox and over the gearbox slowly.



6

INSTALLATION

Reinstall in reverse order of the removal sequence.
Refer to paragraph headed "Brakes" subheading
"Bleeding brakes".



7

DISASSEMBLY


NOTE:

To disassemble and reassemble a complete gearbox, the following special tools will be needed: 80434443, 84014512, 80434446, 80434450, 80434416.

Make sure these tools are available before starting any repair.

General - Figures 7 and 8

1. Remove the hydrostatic motor housing from the gearbox, if not done before.
2. Remove the cover by removing bolts A.
3. Refer to Figure 8 for the disassembly of the differential lock control.




8

Removal of selector forks and shifter shafts -

Figure 9


1. Drive out roll pins B.
2. Move shifter shafts C to the right-hand side and remove the selector forks D. Ensure balls and springs do not fall into the gearbox.



9


Removal of drive shaft - Figures 10 and 11

1. Remove the selector fork and shifter shafts.
2. Remove cover E.
3. Remove circlip F and slide it halfway the shaft G.
4. Drive shaft G to the left-hand side.



10


5. Remove ball bearing H and slide circlip F and gear I from the shaft G.
6. Remove shaft G from the left-hand side.




11

Removal of the countershaft - Figures 12 to 14

1. Remove the hand brake shoe and disc (Refer to paragraph headed "Brakes", subheading "Disassembly of brake shoes and discs").
2. Remove the five nuts J and drive out bearing housing K (Fig. 13) from the inside using a plastic hammer.




12



13

3. Install special tool L (80434443) and install bearing housing K the other way around (Fig. 14).




14

4. Drive the shaft out to the right until the left-hand part of the shaft is detached from the left-hand bearing.
5. Remove bearing housing K and special tool L (80434443).
6. Remove the shaft together with gears M and N. Finally remove gear O.

NOTE:

This shaft can be removed without removing the shifter shafts C (Fig. 9) or input shaft G (Fig. 11).




15

Removal of transmission main shaft -

Figures 15 to 18

1. Remove the brake shoes and discs on both sides (Refer to paragraph headed "Brakes", subheading "Disassembly of brake shoes and discs").
2. Remove the selector forks and shifter shafts (Refer to subheading "Removal of selector forks and shifter shafts").
3. Remove bearing housing P by removing the six nuts Q and by screwing two bolts into the bearing housing P.


4. Pull bearing R from the shaft using special puller S (84014512) on the right-hand side.



30315

16

5. Drive the shaft to the left-hand side and remove slotted nut 1, lock washer 2 and bearing R1.
6. Remove ring 3, gear 5, needle bearing 4, ring 6 and circlip 7 through the aperture in the left-hand side of the gearbox.
7. Remove the shaft with the remaining gears from the gearbox.




30304

17


NOTE:

This shaft can be removed without removing the input shaft or the countershaft.



55514


18



19

Removal of the half-shaft from the differential - Figures 19 and 20

1. Remove the brake shoes and brake discs on both sides (Refer to paragraph headed "Brakes", sub-heading "Disassembly and assembly of brake shoes and discs").
2. Carefully remove oil seal ring T, O-ring X and circlip U on both sides.
3. Pull out both shafts V, together with bearings W.



20

Removal of the differential - Figures 20 and 21

NOTE:

It is possible to remove the differential without removing the drive shaft, transmission main shaft and the countershaft.

1. Remove both half-shafts V.
2. Remove six nuts 8.
3. Remove bearing housing 9 by screwing in two bolts 10 (M8 x 60) instead of two M8 x 16 bolts.
4. Remove the differential lock jaws and spring together with housing 9.
5. Proceed in the same way on the other side and remove differential 11.