


Product: New Holland 18HB/21HB/25HB/30HB/36HB Draper Header Service Repair Manual
Full Download: <https://www.aresairmanual.com/downloads/new-holland-18hb-21hb-25hb-30hb-36hb-dra- per-header-service-repair-manual/>



NEW HOLLAND

18HB
21HB
25HB
30HB
36HB

SERVICE MANUAL



SERVICE

Sample of manual. Download All 152 pages at:

<https://www.aresairmanual.com/downloads/new-holland-18hb-21hb-25hb-30hb-36hb-dra- per-header-service-repair-manual/>
Replaces 87519332

18HB, 21HB, 25HB, 30HB, 36HB SERVICE MANUAL CONTENTS

SECTION 00 - GENERAL INFORMATION

SECTION 35 - HYDRAULICS

SECTION 55 - ELECTRICAL

SECTION 58 - ATTACHMENTS

SECTION 90 - DECALS

The sections used through out all New Holland product Service manuals may not be used for each product. Each Service manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Service manual and which sections are in each book.

The sections listed above are the sections utilized for the 18HB, 21HB, 25HB, 30HB and 36HB.

COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	2
	Safety	3
	General Safety	4
	Operating and Maintenance Safety	5
	Hydraulic Safety	5
	Welding Safety	5
	Before Transporting	6
	Transport Safety	6
	Transporting Checks	7
	Towing Restrictions on Public Roads	7
	Windrower Mounting	7
	Windrower Header	8
	Principal Components	8
	Product Identification Number (PIN)	9
	Ballast System	9
	Single Swath	10
	Double Swath	11
	HB Series Swather Delivery Kits	12
	Single Swath Delivery	12
	Double Swath Delivery	12
	Header Hydraulic Drive System	13
	Ecology and the Environment	14
	Helpful Hints	14
	International Symbols	15
	Minimum Hardware Tightening Torques	16
	Installation of Adjustable Fittings in Straight Thread O-ring Bosses	18
	Standard Torque Data for Hydraulic Tubes and Fittings	18
	Pipe Thread Fitting Torque	19
	Installation of O-ring Flat Faced Fittings	19
	Hydraulic Fitting Torque	20

SECTION 00 - GENERAL INFORMATION

Chapter 2 - Specifications

CONTENTS

Section	Description	Page
	Specifications	2
	Headers	2
	Options	2

SECTION 35 - HYDRAULICS

Chapter 1 - Draper Drive

CONTENTS

Section	Description	Page
	Draper Drive	2
	Hydraulic Schematic Symbols	2
	Fore and Aft	5
	Hydraulic Schematic Symbols	5
	Knife Drive	8
	Hydraulic Schematic Symbols	8
	Reel Drive	11
	Hydraulic Schematic Symbols	11
	Reel Lift	14
	Hydraulic Schematic Symbols	14
	Upper Tube Hydraulics	18
	Hydraulic Schematic Symbols	18

SECTION 35 - HYDRAULICS

Chapter 2 - Windrower Headers

CONTENTS

Section	Description	Page
	Single Reel Lift Circuit	2
	Double Reel Lift Circuit	2
	Single Reel Lift 36 Foot	2

SECTION 35 - HYDRAULICS

Chapter 3 - Schematics and Troubleshooting

CONTENTS

Section	Description	Page
	Troubleshooting	2
	Hydraulic Problems	2
	Oil Overheating	2
	Hydraulic System Tests	3
	Relief Valve	3
	Knife Circuit	3
	High Pressure Readings	4
	Draper Circuit Operation and Testing	4
	Draper Motor Circuit	5
	Reel Motor Circuit	5
	Low Pressure Readings	5
	Knife Relief Pressure Adjustment	5

SECTION 35 - HYDRAULICS

Chapter 4 - Pumps, Motors and Flow Dividers

CONTENTS

Section	Description	Page
	Description of Operation	2
	Hydraulic Motors	2
	Parker Motor	4
	White Motor	5
	Eaton Motor	6
	White (Roller Stator) Hydraulic Motor Seal Replacement	7
	Reverser Motor	7
	Removal	7
	Disassembly	7
	Assembly	11
	Hydraulic Manifold Block	15
	Removal	15
	Disassembly	16
	Assembly and Installation	16
	Flow Divider	17
	Removal	17
	Installation	18
	Draper Flow Control	19
	Removal	19
	Installation	19
	Cartridge	20
	Pressure Vent	21
	Removal	21
	Disassembly	21
	Assembly	22
	Installation	22

SECTION 35 - HYDRAULICS

Chapter 5 - Reel Lift

CONTENTS

Section	Description	Page
	Description of Operation	2
	Purging Air From Reel Positioning Systems	2
	Bleeding Slave Cylinders	2
	Purging Air From Reel Fore/Aft Systems	2
	Troubleshooting	3
	Troubleshooting Charts	3
	Hydraulic Cylinders	7
	Overhaul	9
	Hydraulic Cylinders - Removal	9
	Reel Fore/Aft	9
	Reel Lift Master Cylinder	9
	Reel Lift Slave Cylinder	9
	All Cylinders	10
	Disassembly	10
	Assembly	11
	Hydraulic Cylinders - Installation	13
	Reel Fore/Aft	13
	Reel Lift Master Cylinder	14
	Reel Lift Slave Cylinder	14

SECTION 55 - ELECTRICAL

Chapter 1 - Windrower Headers

CONTENTS

Section	Description	Page
	Description of Operation	2
	Electrical System	2
	Lights	5
	Remote Speed Control	6
	Sickle Drive Speed Sensor	6
	Sensor To Pulse Wheel Adjustment	6
	Automatic Reel Speed Control	7

SECTION 58 - ATTACHMENTS

Chapter 1 - Drivelines - Knife Drive

CONTENTS

Section	Description	Page
	Description of Operation and Overhaul	3
	Knife Drive	3
	Removal	4
	Replacement	5
	All Cutting Systems	7
	Knife	7
	Removal	7
	Installation	7
	Schumacher Cutting System	8
	Guards	8
	Sections	8
	Replacement	8
	New Holland Cutting System	9

SECTION 58 - ATTACHMENTS

Chapter 1 - Drivelines - Knife Drive (Continued)

CONTENTS

Section	Description	Page
	Knife Hold-Down Clips	9
	Adjustment	9
	Replacement	9
	Cutter Bar Shimming - NH System	10
	All Guards to Left of Center Guard	10
	Center Guard	10
	All Guards to Right of Center Guard	10
	Guards	11
	Guard Alignment	12
	All Cutting Systems	12
	Knife Drive/Knife Head	12
	Replacement	12
	Schumacher Cutting System Only Knife Head	13
	Attachment	13
	Connector Bar	13
	Attachment	13
	Schumacher Overlap Kit	14
	Inspection and Replacement	14
	New Holland Cutting System Only	15
	Connector Bar	15
	Installation	15
	Knife Head	15
	Installation	15
	Overlap Tail	16
	Installation	16
	Draper Splicing	17
	Hydraulic Double Swath	19

SECTION 58 - ATTACHMENTS

Chapter 2 - Feeding Components - Draper Decks

CONTENTS

Section	Description	Page
	Description of Operation and Overhaul	2
	Main Draper Decks	3
	Tracking	3
	Disassembly	5
	Assembly	8

SECTION 90 - DECALS

Chapter 1 - Decals

CONTENTS

Section	Description	Page
	Safety Decals	2

SECTION 00 - GENERAL INFORMATION

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	2
	Safety	3
	General Safety	4
	Operating and Maintenance Safety	5
	Hydraulic Safety	5
	Welding Safety	5
	Before Transporting	6
	Transport Safety	6
	Transporting Checks	7
	Towing Restrictions on Public Roads	7
	Windrower Mounting	7
	Windrower Header	8
	Principal Components	8
	Product Identification Number (PIN)	9
	Ballast System	9
	Single Swath	10
	Double Swath	11
	HB Series Swather Delivery Kits	12
	Single Swath Delivery	12
	Double Swath Delivery	12
	Header Hydraulic Drive System	13
	Ecology and the Environment	14
	Helpful Hints	14
	International Symbols	15
	Minimum Hardware Tightening Torques	16
	Installation of Adjustable Fittings in Straight Thread O-ring Bosses	18
	Standard Torque Data for Hydraulic Tubes and Fittings	18
	Pipe Thread Fitting Torque	19
	Installation of O-ring Flat Faced Fittings	19
	Hydraulic Fitting Torque	20

PRECAUTIONARY STATEMENTS

PERSONAL SAFETY

Throughout this manual and on machine decals, you will find precautionary statements (“**DANGER**”, “**WARNING**”, and “**CAUTION**”) followed by specific instructions. These precautions are intended for the personal safety of you and those working with you. Please take the time to read them.

 **DANGER** 

This word “**DANGER**” indicates an immediate hazardous situation that, if not avoided, will result in death or serious injury. The color associated with Danger is RED.

M1169

 **WARNING** 

This word “**WARNING**” indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury. The color associated with Warning is ORANGE.

M1170

 **CAUTION** 

This word “**CAUTION**” indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

M1171

FAILURE TO FOLLOW THE “DANGER”, “WARNING”, AND “CAUTION” INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS BODILY INJURY.

MACHINE SAFETY

The precautionary statement (“**NOTICE**”) is followed by specific instructions. This statement is intended for machine safety.

NOTICE: The word “**NOTICE**” is used to inform the reader of something he needs to know to prevent minor machine damage if a certain procedure is not followed.

INFORMATION

NOTICE: Instructions used to identify and present supplementary information.

SAFETY

PRECAUTIONARY STATEMENTS

A careful operator is the best operator. Most accidents can be avoided by observing certain precautions. To help prevent accidents, read the following precautions before operating this equipment. Equipment should be operated only by those who are responsible and instructed to do so.

Carefully review the procedures given in this manual with all operators. It is important that all operators be familiar with and follow safety precautions.

1. When transporting the machine on public roads, make sure the machine has lights in compliance with ASAE S279.13 standard and the machine is in compliance with all local road regulations.
2. Before operating the unit, be sure that it is assembled correctly and in good operating condition.
3. If machine maintenance work, repairs or adjustments must be done in the field, they should be done at a spot where the ground is firm and level. Turn off the tractor and apply the parking brake. Use the proper tools and wear suitable protection (safety goggles, work gloves, etc.).
4. If any maintenance work, repairs or adjustments are done which require disassembly, always make sure that everything is re-assembled or retightened as it had been prior to making repairs or adjustments.
5. Follow the schedule provided for maintenance. By following these suggestions, it will be possible to keep the machine operating safely and efficiently, to the benefit of the user.
6. General checking of bolts, security pins and split pins must be carried out initially after the first 8 hours of use. Subsequently, check every 50 hours and whenever the machine is laid up for extended periods.
7. Before applying pressure to the system, be sure all connections are tight and that hoses and connections are not damaged.
8. Fluid under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Always protect the skin and eyes from escaping fluid under pressure. If injured by escaping fluid, obtain medical assistance at once. Serious infection or reaction can develop if medical treatment is not administered immediately.
9. Do not weld on wheels. Welding on wheels may cause high stress and a wheel failure.
10. Do not weld on wheels with a mounted tire. Welding on wheels with a mounted tire may cause the tire to burst, causing serious injury or death.
11. Before leaving the cab, engage the parking brake, shut down the engine, and wait for all moving parts to stop.
12. Always keep bystanders away from machine during operation. Rotating elements may cause serious bodily injury.
13. Do not attempt to remove material from the draper header while it is in operation. Shut off the tractor and allow all rotating parts to stop before leaving the tractor.
14. Be sure the tractor header lift locks are engaged before working on or around a raised header.
15. Engage the lift locks or lower the header to the ground before performing any maintenance or lubrication.
16. Replace any damage knives or knife hardware immediately to prevent an accident.
17. Always wear heavy canvas or leather gloves when working with the knife.
18. Always engage the reel lift cylinder locks and header lift locks before working under or around a raised reel. Do not rely on the windrower hydraulic system for support. A rupture or a leak in any part of the system will allow the table to lower if the proper stops are not in place.
19. When mounting to a windrower, make sure the ends of the lift arms are securely in the mounting brackets under the header. Failure to do so could allow the header to fall or slide off the arms, causing damage to the header or personal injury.

GENERAL SAFETY

YOU are responsible for the safe operation and maintenance of your model HB Series draper header. YOU must ensure that you and anyone else who is going to operate, maintain or work around the draper header be familiar with the operating and maintenance procedures and related safety information contained in this manual.

Remember YOU are the key to safety. Good safety practices not only protect you, but also the people around you. Make these practices a working part of your safety program. Most accidents can be prevented. Do not risk injury or death by ignoring good safety practices.

Review the operating instructions for this header at least once a year per OSHA regulations 1928.57. Know the meaning and location of each decal before operating the draper header.

Watch for this symbol in this manual and on the draper header:



It will draw your attention to hazards that could cause injury or death.

1. Keep the hydraulic pump, gearbox and motors clean of all chaff and straw to prevent any possibility of fire.
2. Carry a multipurpose fire extinguisher in the machine in case of fire and know how to use it. Check the extinguisher regularly and keep it maintained.

3. Provide a first aid kit in the cab for emergencies and know how to use it.
4. Wear appropriate protective gear.
 - A hard hat
 - Protective shoes with slip resistant soles
 - Protective glasses or goggles
 - Leather gloves
 - Hearing protection
 - Respirator or filter mask
5. Do not allow any one to ride on the header while it is in motion.
6. Make certain that the park brake is engaged, and the power unit is in neutral before starting the engine.
7. Clear the area of bystanders, especially small children before starting the power unit.
8. Do not allow anyone to operate the header who has not been instructed in how to operate the machine.
9. All operators should familiarize themselves with the safety section in the power unit operator's manual.
10. Some pictures or illustrations may not show protective shields in place. Make certain that all protective shields are in place before operating the machines.

OPERATING AND MAINTENANCE SAFETY

1. STOP the power unit, engage the parking brake, place the power unit in neutral, remove the key, and wait for all movement to stop before leaving the cab.
2. Either lower both the table and reel or raise the header to its full height and use platform locks before leaving the power unit or servicing the header. If working under reel, use reel cylinder locks. A sudden loss of hydraulic pressure could cause the header and reel to fall.
3. NEVER operate the power unit and the header while tired, sick, or impaired.
4. DANGER, DO NOT stand between the power unit and the header while raising or lowering the header.
5. Do not operate the header in crowded or confined areas.
6. Ensure that all the pressure is released from the hydraulic lines before repairing. Replace or repair damaged hoses immediately.
7. Care should be taken when maintaining the knife. The sickle sections are very sharp and can easily cause injury. Use heavy leather or canvas gloves when working with the knife.

HYDRAULIC SAFETY

Release all the pressure from the hydraulic lines before making any repairs. Replace or repair damaged hoses immediately.



WARNING



Hydraulic oil leaking under pressure can penetrate the skin and cause infection or other injury.

To Prevent Personal Injury:

- Relieve all hydraulic pressure, before disconnecting fluid lines.
- Before applying pressure, make sure all connections are tight and components are in good condition.
- Never use your hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose.
- If injured by leaking fluid, seek medical attention immediately.

Failure to comply could result in death or serious injury.

M587A


WELDING SAFETY

DO NOT weld on wheels. Welding on wheels may cause high stress and wheel failure.

DO NOT weld on wheels with a mounted tire. Welding on wheels with a mounted tire may cause the tire to burst, causing serious injury or death.

BEFORE TRANSPORTING


1. Do a complete walk-around visual check to be sure there are no loose parts or components.
2. Check wheel bolts to make sure they are tight.
3. Check transport tire pressure. Recommended pressure is 3.4 bar (50 psi) for 225/75R15 radials.
4. Check spindle and hitch lockpins to make sure they are in place and securely fastened.
5. Do a visual check of all hoses to make sure they are securely tied so they will not pinch or drag during transporting.
6. Be sure hitch tongue and safety chain are fastened securely to the header and to the transporting vehicle.
7. Hand check all reel mounting, reel drive, and adapter assembly bolts to be sure no bolts/nuts are loose.



1

TRANSPORT SAFETY

1. Transport the header with the SMV (Slow Moving Vehicle) sign, 1, displayed on the rear of the header and use your hazard lights if the laws permit. Check local road laws before transporting.
2. When transporting the header on the road, be aware of the width of the header.
3. For long distance transporting, put the header into full transport.
4. Remove crop dividers and divider pipes.
5. Do not transport the machine at night, at dawn, or at dusk.
6. Do not exceed 32 km/h (20 mph) during transport.



86061879

2

TRANSPORTING CHECKS

1. If you are towing your header to a distant destination, stop after the first 5 - 10 kilometers (3 - 6 miles) and check to make sure the wheel bolts are tight and the wheel hubs are not hot. Make periodic checks 50 - 60 km (30 - 35 miles) if towing the header long distances.
2. Check the hitch bolt and safety chain periodically to make sure they are secure.

Towing Restrictions on Public Roads

Check with local and state authorities and follow all regulations concerning towed equipment on public roads.

Do not tow equipment, such as a draper header, that does not have brakes:

- at speeds over 32 km/h (20 mph); or
- that when fully loaded weighs more than 1.5 ton (3300 lb) and more than 1.5 times the weight of the towing unit.

WINDROWER MOUNTING

These mounting instructions will help you mount your HB draper header onto the windrower in a safe and easy manner. Follow the instructions in the given order, or possible difficulties may arise.

Windrower Terminology:

Front - Cab end of windrower

Rear - Engine end of windrower


Left and Right - As seen when sitting in the driver's seat, facing the header.

Header Terminology:

Front - Cutter bar side

Rear - Windrower attaching side

Left and Right - As seen when sitting in the driver's seat facing the header when mounted on the windrower or standing at the back of the header facing toward the cutter bar.



WINDROWER HEADER


The HB draper header used with a windrower consists of the main components listed below. The hydraulic pressure to run the header comes from the header drive pump of the windrower. A hydraulic motor powers the epicycle knife drive to cut the crop. The reel lays the crop onto the drapers. The drapers carry the crop to the opening of the header to create a windrow.

When in field position, flotation is achieved through the use of the hydraulic flotation on the windrower and optional caster gauge wheels on the header.

Principal Components

1. Cutter Bar
2. Reel
3. Drapers
4. Knife Drive
5. Transport Axle

NOTICE: The HB draper header cannot be used on HW300, HW320, HW340 or prior model windrowers.



PRODUCT IDENTIFICATION NUMBER (PIN)

The PIN is stamped on a metal tag, 1, located on the back of the upper frame, on the left hand side of the header.

The PIN will give the following information:

1. The first two numbers give the length in feet.
2. The next two letters represent the swather model.
3. The next two numbers represent the year built.

Example:


36WS091234

36 = thirty-six feet long

WS = swather model

09 = built in 2009


1234 = sequential numbering



5

BALLAST SYSTEM

The HB Series Draper Header is equipped with steel plates, 1, attached to one end of the header to act as a ballast for the other side. This ballasting helps balance the draper for the flotation system on the Windrower.



6

SECTION 00 - GENERAL INFORMATION - CHAPTER 1

Single Swath

Table Condition	Number of Plates	Counter-weight Side
Single knife drive w/out transport		
18 FT	n/a	n/a
21 FT	4	Left
25 FT	0	Right
30 FT	0	Right
36 FT	0	Right

Table Condition	Number of Plates	Counter-weight Side
Double knife drive w/out transport		
18 FT	n/a	n/a
21 FT	0	Left
25 FT	0	Left
30 FT	0	Left
36 FT	0	Left

Table Condition	Number of Plates	Counter-weight Side
Single knife drive with transport		
18 FT	n/a	n/a
21 FT	0	Right
25 FT	0	Right
30 FT	0	Right
36 FT	0	Right

Table Condition	Number of Plates	Counter-weight Side
Double knife drive with transport		
18 FT	1	Left
21 FT	n/a	n/a
25 FT	0	Left
30 FT	3	Left
36 FT	1	Left

NOTICE: n/a = not available

SECTION 00 - GENERAL INFORMATION - CHAPTER 1

Double Swath

Table Condition	Number of Plates	Counter-weight Side
Single knife drive w/out transport		
21 FT	8 (Plus 4 inside)	Left
25 FT	8	Left
30 FT	8	Left

Table Condition	Number of Plates	Counter-weight Side
Double knife drive w/out transport		
21 FT	2	Left
25 FT	1	Left
30 FT	0	Left


NOTICE: Transport package is available when ordering a double swath table, but the transport tongue **MUST BE REMOVED** for proper operation.

NOTICE: 18 ft models are not available in a double swath table configuration.

HB SERIES SWATHER DELIVERY KITS

Single Swath Delivery


Models	A	B	C
18HB 5.5 m (18 ft)	80 inch	50 inch	80 inch
21HB 6.4 m (21 ft)	99 inch	50 inch	99 inch
25HB 7.6 m (25 ft)	118 inch	56 inch	118 inch
	104 inch*	68 inch	118 inch
	104 inch*	80 inch	104 inch*
30HB 9.1 m (30 ft)	150 inch	56 inch	150 inch
	136 inch*	68 inch	150 inch
	136 inch*	80 inch	136 inch*
36HB 11 m (36 ft)	189 inch	56 inch	189 inch
	175 inch*	68 inch	189 inch
	175 inch*	80 inch	175 inch*



7

Double Swath Delivery

Models	A	B	C	D
21HB 6.4 mm (21 ft)	99 inch	45 inch	99 inch	6 inch
	99 inch	50 inch S	99 inch	-
25HB 7.6 mm (25 ft)	118 inch	54 inch	118 inch	6 inch
	118 inch	56 inch S	118 inch	-
	104 inch*	68 inch C	118 inch	-
	104 inch*	80 inch C	104 inch*	-
30HB 9.1 mm (30 ft)	150 inch	50 inch	150 inch	6 inch
	150 inch	56 inch S	150 inch	-
	136 inch*	68 inch C	150 inch	-
	136 inch*	80 inch C	136 inch*	-



8

NOTICE: Dimension "D" is to edge of the deflector.


NOTICE: No tables get a junior deck.

NOTICE: "C" denotes 'center delivery only' available.

NOTICE: "S" denotes 'shifted to center delivery.'

NOTICE: "*" denotes removal of 14 inch deck.

HEADER HYDRAULIC DRIVE SYSTEM (Single-Swath, Single Knife System Shown)



76075558

9

- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Draper deck motor, left hand 2. Draper deck motor, right hand 3. Reel drive motor 4. Draper speed flow control 5. 50/50 flow control 6. Pressure gauge (measures pressure after knife drive) | <ol style="list-style-type: none"> 7. Reel speed flow control 8. Knife drive motor 9. Pressure gauge (measures pressure before knife drive) 10. Manifold block 11. Tractor |
|--|---|

This section outlines the hydraulic system which drives the draper header components. The components, as well as the plumbing of the various systems, are also shown on the hydraulic schematics in the Specifications Section.

The header uses the tractor hydraulics to provide power to the various systems. The hydraulic pressure from the power unit flows into the hydraulic manifold block, mounted to the upper tube of the draper header. The manifold block regulates the flow of the hydraulic fluid from the power unit by sending 73.8 lpm (19.5 gpm) to knife drive motor and then splitting into individual left and right draper motors. An additional, secondary flow of approximately 35.9 lpm (9.5 gpm) is directed to the reel circuit from the manifold block. The draper and reel circuits have their own flow controls. This allows both the draper and reel speeds to be independently adjusted. The excess from the flow controls are sent directly to the return side of the system.

The system is protected with a pressure relief valve, which should be set at 207 bar (3000 psi).

The gauge on the hydraulic manifold block allows the operator to read the header's current hydraulic system operating pressure. The power unit connection to the draper header has three hoses. The two larger hoses provide pressure and return. The third hose is called the case drain hose which keeps the hydraulic fluid from stagnating and overheating.

NOTICE: If the double swath and/or fore/aft option is installed on the draper header, a separate hydraulic hose needs to be installed on the hydraulic manifold block.

⚠ **WARNING** ⚠

Care must be used when checking hydraulic components. Quick couplers must be securely coupled before the machine is started. Failure to comply could result in death or serious injury.

M1500

ECOLOGY AND THE ENVIRONMENT

Soil, air, and water are vital factors of agriculture and life in general. When legislation does not yet rule the treatment of some of the substances which are required by advanced technology, common sense should govern the use and disposal of products of a chemical and petrochemical nature.

The following are recommendations which may be of assistance:


- Become acquainted with and ensure that you understand the relative legislation applicable to your country.
- Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, antifreeze, cleaning agents, etc., with regard to their effect on man and nature and how to safely store, use and dispose of these substances. Agricultural consultants will, in many cases, be able to help you as well.

HELPFUL HINTS

1. Avoid filling tanks using cans or inappropriate pressurized fuel delivery systems which may cause considerable spillage.
2. In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of them contain substances which may be harmful to your health.
3. Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
4. Avoid spillage when draining off used engine coolant mixtures, engine, gearbox and hydraulic oils, brake fluids, etc. Do not mix drained brake fluids or fuels with lubricants. Store them safely until they can be disposed of in a proper way to comply with local legislation and available resources.
5. Modern coolant mixtures, i.e. antifreeze and other additives, must be replaced every two years. They should not be allowed to get into the soil but should be collected and disposed of safely.
6. Do not open the air-conditioning system yourself. It contains gases which should not be released into the atmosphere. Your dealer or air conditioning specialist has a special extractor for this purpose and will have to recharge the system properly.
7. Repair any leaks or defects in the engine cooling or hydraulic system immediately.
8. Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
9. Protect hoses during welding as penetrating weld splatter may burn a hole or weaken them, allowing the loss of oils, coolant, etc.

INTERNATIONAL SYMBOLS

As a guide to the operation of your tractor, various universal symbols have been utilized on the instruments, controls, switches, and fuse box. The symbols are shown below with an indication of their meaning.

	Thermostart starting aid		Radio		P.T.O.		Position Control
	Alternator charge		Keep alive memory		Transmission in neutral		Draft Control
	Fuel level		Turn signals		Creepers gears		Accessory socket
	Automatic Fuel shut-off		Turn signals -one trailer		Slow or low setting		Implement socket
	Engine speed (rev/min x 100)		Turn signals -two trailers		Fast or high setting		%age slip
	Hours recorded		Front wind-screen wash/wipe		Ground speed		Hitch raise (rear)
	Engine oil pressure		Rear wind-screen wash/wipe		Differential lock		Hitch lower (rear)
	Engine coolant temperature		Heater temperature control		Rear axle oil temperature		Hitch height limit (rear)
	Coolant level		Heater fan		Transmission oil pressure		Hitch height limit (front)
	Tractor lights		Air conditioner		Hitch disabled		Hydraulic and transmission filters
	Headlamp main beam		Air filter blocked		FWD engaged		Remote valve extend
	Headlamp dipped beam		Parking brake		FWD disengaged		Remote valve retract
	Work lamps		Brake fluid level		Warning!		Remote valve float
	Stop lamps		Trailer brake		Hazard warning lights		Malfunction! See Operator's Manual
	Horn		Roof beacon		Variable control		Malfunction! (alternative symbol) See Operator's Manual
			Warning! Corrosive substance		Pressurized! Open carefully		

MINIMUM HARDWARE TIGHTENING TORQUES

IN NEWTON-METERS (FOOT POUNDS) FOR NORMAL ASSEMBLY APPLICATIONS


METRIC NON-FLANGED HARDWARE AND LOCKNUTS

NOMINAL SIZE	CLASS 5.8		CLASS 8.8		CLASS 10.9		LOCKNUT CL.8 W/CL8.8 BOLT
	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr	
M4	1.7 (15)*	2.2 (19)*	2.6 (23)*	3.4 (30)*	3.7 (33)*	4.8 (42)*	2.3 (20)*
M6	5.8 (51)*	7.6 (67)*	8.9 (79)*	12 (102)*	13 (115)*	17 (150)*	7.8 (69)*
M8	14 (124)*	18 (159)*	22 (195)*	28 (248)*	31 (274)*	40 (354)*	19 (169)*
M10	28 (21)	36 (27)	43 (32)	56 (41)	61 (45)	79 (58)	38 (28)
M12	49 (36)	63 (46)	75 (55)	97 (72)	107 (79)	138 (102)	66 (49)
M16	121 (89)	158 (117)	186 (137)	240 (177)	266 (196)	344 (254)	164 (121)
M20	237 (175)	307 (226)	375 (277)	485 (358)	519 (383)	671 (495)	330 (243)
M24	411 (303)	531 (392)	648 (478)	839 (619)	897 (662)	1160 (855)	572 (422)

NOTICE: Torque values shown with * are inch pounds.

IDENTIFICATION HEX CAP SCREW AND CARRIAGE BOLTS CLASSES 5.6 AND UP


MANUFACTURER'S IDENTIFICATION



PROPERTY CLASS

HEX NUTS AND LOCKNUTS CLASSES 05 AND UP

MANUFACTURER'S IDENTIFICATION



PROPERTY CLASS

CLOCK MARKING

MINIMUM HARDWARE TIGHTENING TORQUES

IN NEWTON-METERS (FOOT POUNDS) FOR NORMAL ASSEMBLY APPLICATIONS

INCH NON-FLANGED HARDWARE AND LOCKNUTS


NOMINAL SIZE	SAE GRADE 2		SAE GRADE 5		SAE GRADE 8		LOCKNUTS		NOMINAL SIZE
	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	GR.B w/GR5 BOLT	GR.C w/GR8 BOLT	
1/4	6.2 (55)*	8.1 (72)*	9.7 (86)*	13 (112)*	14 (121)*	18 (157)*	8.5 (75)*	12.2 (109)*	1/4
5/16	13 (115)*	17 (149)*	20 (178)*	26 (229)*	28 (250)*	37 (324)*	17.5 (155)*	25 (220)*	5/16
3/8	23 (17)	30 (22)	35 (26)	46 (34)	50 (37)	65 (48)	31 (23)	44 (33)	3/8
7/16	37 (27)	47 (35)	57 (42)	73 (54)	80 (59)	104 (77)	50 (37)	71 (53)	7/16
1/2	57 (42)	73 (54)	87 (64)	113 (83)	123 (91)	159 (117)	76 (56)	108 (80)	1/2
9/16	81 (60)	104 (77)	125 (92)	163 (120)	176 (130)	229 (169)	111 (82)	156 (115)	9/16
5/8	112 (83)	145 (107)	174 (128)	224 (165)	244 (180)	316 (233)	153 (113)	215 (159)	5/8
3/4	198 (146)	256 (189)	306 (226)	397 (293)	432 (319)	560 (413)	271 (200)	383 (282)	3/4
7/8	193 (142)	248 (183)	495 (365)	641 (473)	698 (515)	904 (667)	437 (323)	617 (455)	7/8
1	289 (213)	373 (275)	742 (547)	960 (708)	1048 (773)	1356 (1000)	654 (483)	924 (681)	1

NOTICE: Torque values shown with * are inch pounds.

IDENTIFICATION CAP SCREWS AND CARRIAGE BOLTS




LOCKNUTS



INSTALLATION OF ADJUSTABLE FITTINGS IN STRAIGHT THREAD O-RING BOSSES

1. Lubricate the O-ring by coating it with a light oil or petroleum. Install the O-ring in the groove adjacent to the metal backup washer which is assembled at the extreme end of the groove, 4.
2. Install the fitting into the SAE straight thread boss until the metal backup washer contacts the face of the boss, 5.

NOTICE: Do not over tighten and distort the metal backup washer.



3. Position the fitting by turning out (counterclockwise) up to a maximum of one turn. Holding the pad of the fitting with a wrench, tighten the locknut and washer against the face of the boss, 6.

STANDARD TORQUE DATA FOR HYDRAULIC TUBES AND FITTINGS

TUBE NUTS FOR 37° FLARED FITTINGS					O-RING BOSS PLUGS ADJUSTABLE FITTING LOCKNUTS, SWIVEL JIC - 37° SEATS						
SIZE	TUBING OD		THREAD SIZE	TORQUE				TORQUE			
	mm	In.		NEWTON METERS		POUND FOOT		NEWTON METERS		POUND FOOT	
			Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	
4	6.4	1/4	7/16-20	12	16	9	12	8	14	6	10
5	7.9	5/16	1/2-20	16	20	12	15	14	20	10	15
6	9.5	3/8	9/16-18	29	33	21	24	20	27	15	20
8	12.7	1/2	3/4-18	47	54	35	40	34	41	25	30
10	15.9	5/8	7/8-14	72	79	53	53	47	54	35	40
12	19.1	3/4	1-1/16-12	104	111	77	82	81	95	60	70
14	22.2	7/8	1-3/16-12	122	136	90	100	95	109	70	80
16	25.4	1	1-5/16-12	149	163	110	120	108	122	80	90
20	31.8	1-1/4	1-5/8-12	190	204	140	150	129	158	95	115
24	38.1	1-1/2	1-7/8-12	217	237	160	175	163	190	120	140
32	50.8	2	2-1/2-12	305	325	225	240	339	407	250	300

These torques are not recommended for tubes of 12.7 mm (1/2 in) OD and larger with wall thickness of 0.889 mm (0.035 in) or less. The torque is specified for 0.889 mm (0.035 in) wall tubes on each application individually.

solvent or Loctite cleaner and apply hydraulic sealant Loctite™ no. 569 to the 37° flare and the threads.

Install fitting and torque to specified torque, loosen fitting and retorquing to specifications.

Before installing and torquing 37° flared fittings, clean the face of the flare and threads with a clean

PIPE THREAD FITTING TORQUE

Before installing and tightening pipe fittings, clean the threads with a clean solvent or Loctite cleaner and apply sealant Loctite no. 567 for all fittings including stainless steel or no. 565 for most metal fittings. For high filtration/zero contamination systems use no. 545.

THREAD SIZE	TORQUE (MAXIMUM)
1/8 inch - 27	13 N·m (10 lb ft)
1/4 inch - 18	16 N·m (12 lb ft)
3/8 inch - 14	22 N·m (16 lb ft)
1/2 inch - 14	41 N·m (30 lb ft)
3/4 inch - 14	54 N·m (40 lb ft)


INSTALLATION OF ORFS (O RING FLAT FACED) FITTINGS

When installing ORFS fittings thoroughly clean both flat surfaces of the fitting, 1, and lubricate the O-ring, 2, with light oil. Make sure both surfaces are aligned properly. Torque the fitting to specified torque listed throughout the repair manual.

NOTICE: If the fitting surfaces are not properly cleaned, the O-ring will not seal properly. If the fitting surfaces are not properly aligned, the fittings may be damaged and will not seal properly.

NOTICE: Always use genuine New Holland replacement oils and filters to ensure proper lubrication and filtration of engine and hydraulic system oils.

The use of proper oils, grease, and keeping the hydraulic system clean will extend machine and component life.



SECTION 00 - GENERAL INFORMATION - CHAPTER 1

HYDRAULIC FITTING TORQUE

Tightening flare type tube fittings:

1. Check flare and flare seat for defects that might cause leakage.
2. Align tube with fitting before tightening.
3. Lubricate connection and hand tighten swivel nut until snug.
4. To prevent twisting the tube(s), use two wrenches. Place one wrench on the connector body and with the second tighten the swivel nut to the torque shown.

Tightening O-ring fittings:

1. Inspect O-ring and seat for dirt or obvious defects.
2. On angle fittings, back the locknut off until washer bottoms out at top of groove.
3. Hand tighten fitting until back-up washer or washer face (if straight fitting) bottoms on face and O-ring is seated.
4. Position angle fittings by unscrewing no more than one turn.
5. Tighten straight fittings to torque shown.
6. Tighten angle fittings to torque shown while holding body of fitting with a wrench.