

Product: New Holland TD5010/TD5020/TD5030/TD5040/TD5050 Tractor Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-td5010-td5020-td5030-td5040-td5050-tractor-service-repair-manual/>

SERVICE MANUAL

TD5010 / TD5020 / TD5030 TD5040 / TD5050 Tractors

Print No. 84176561B





TD5010 - TD5020 - TD5030 - TD5040 - TD5050 MODEL TRACTORS SERVICE MANUAL

SECTIONS

GENERAL	00
ENGINE	10
CLUTCH	18
GEARBOX	21
TRANSMISSION OF MOTION	23
FRONT MECHANICAL TRANSMISSION	25
REAR MECHANICAL TRANSMISSION	27
POWER TAKE-OFF	31
BRAKES	33
HYDRAULIC SYSTEMS	35
STEERING	41
AXLE AND WHEELS	44
AUXILIARY EQUIPMENT	50
ELECTRICAL SYSTEM	55
CAB	90

S E R V I C E

Sample of manual. Download All 691 pages at:

<https://www.arepairmanual.com/downloads/new-holland-td5010-td5020-td5030-td5040-td5050-tractor-service-repair-manual/>

84176561 - 03-2008

INTRODUCTION

- This manual is divided into sections identified by two-figure numbers and each section has independent page numbering.
- The different sections can easily be found by consulting the table of contents on the following pages.
- The document number of the manual and the edition/update dates are given at the bottom of each page.
- Pages updated in the future will be identified by the same document number followed by an additional digit: first standard manual edition 84176561A - 1st update 84176561A1 - 2nd update 84176561A2 - etc. Updated pages can replace or supplement the pages of the standard manual; the necessary information for the procedure by which to add or replace the pages is given on the frontispiece of the update. An appropriately updated index will complete the publication. If it is necessary to issue a new updated manual (2nd edition) this will have the document number 84176561B, which indicates that the manual is composed of the standard version 87749051A complete with all the updates: 1st update 84176561A1 - 2nd update 84176561A2 - etc.
- The information contained in this manual was current on the date printed on each section. As NEW HOLLAND constantly improves its product range, some information may be out of date subsequent to modifications implemented for technical or commercial reasons, or to meet legal requirements in different countries.
In the event of conflicting information, consult the NEW HOLLAND Sales and Service Departments.

IMPORTANT WARNINGS

- ◊ All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND service technicians in strict accordance with the instructions given and using any specific tools necessary.
- ◊ Anyone who performs the operations described herein without strictly following the instructions is personally responsible for resulting injury or damage to property.
- ◊ The Manufacturer and all organisations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer.
In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.

TEXT AND ILLUSTRATIONS ARE THE PROPERTY
OF NEW HOLLAND



No part of the text or illustrations
may be reproduced

PRINTED IN TURKEY

NEW HOLLAND
SERVICE - Technical Publications & Special Tools
Part no. 84176561 - 03 - 2008

NEW HOLLAND

Repair Manual - TD Series Tractors

CONTENTS

GENERAL	SECTION 00	
General Instructions and Health and Safety		
Chapter 1		
Section	Description	Page
00 000	General instructions	1
	Notes for spare parts	2
	Notes for equipment	2
	Safety rules	3
	Consumables	6
ENGINE	SECTION 10	
Engine System (F5C)		
Chapter 1		
Section	Description	Page
10 001 10	Tools	2
	Engine Troubleshooting	3
	Engine R.I.	7
Engine System (NEF)		
Chapter 1		
Section	Description	Page
10 001 10	General specifications	2
	Data	5
	Tightening torques	11
	Tools	2
	Engine views	14
	Lubrication diagram	15
	Cooling system diagram	16
	Fault diagnosis	3
	Engine R.I.	7
10 001 53	Engine D.A. Checks, measurements and repairs	37
10 102 70	Crankshaft front seal - Replacement	89
10 102 74	Crankshaft rear seal - Replacement	92
10 106 12	Valve tappet and rocker arm clearance - Adjustment	95
10 218 30	Engine injector R.I.	98
10 246 14	Bosch injection pump R.I. Timing. Air bleed	100

10 402 10	Coolant pump R.I.	108
10 402 30	Thermostat valve R.I.	110
10 406 10	Radiator R.I.	112
10 414 10	Coolant pump and generator drive belts. Tension adjustment	116

CLUTCH

SECTION 18

Clutches

Chapter 1

Section	Description	Page
18 000	General specifications	1
	Tightening torques	4
	Tools	5
	Cross-sectional views	6
	Clutch Troubleshooting	8
18 110 10	Removal - Installation	9
	Overhaul	18
	Minimum permissible dimensions after refacing	22
	Adjustments	23
18 100 40	Adjustment of the main and PTO clutch control linkage	25

GEARBOX

SECTION 21

Mechanical Transmission (12x4)

Chapter 1

Section	Description	Page
21 000	Main data	1
	Tightening torques	2
	Tools	3
	Section views	3&5
	Description and operation	8
	Fault diagnosis	8
21 110	Removal - Refitting	see sect 27

Reverser (12x12)

Chapter 2

Section	Description	Page
21 000	Main data	1
	Tightening torques	2
	Tools	3
	Section views	3
	Description and operation	5
	Fault diagnosis	5
21 110	Removal-Refitting	6

Reverser and Creeper (20x12)

Chapter 3

Section	Description	Page
21 000	Main data	1
	Tightening torques	2
	Tools	3
	Section views	4
	Description and operation	6

21 110	Fault diagnosis	6
	Removal-Refitting	7

DRIVE LINES

SECTION 23

Drive Lines

Chapter 1

Section	Description	Page
23 000	Main specification	1
	Torque settings and Tools	2
	Cross-Sectional views	3
23 101 26	Transmission shafts and guard (Disassembly - Assembly)	4
23 101 40	Drive gear housing (Removal - Installation)	5
23 101 42	Drive gear housing removed (Disassembly - Assembly)	7

FRONT AXLE MECHANICAL TRANSMISSION

SECTION 25

Front Axle Mechanical Transmission

Chapter 1

Section	Description	Page
25 000	Main data	1
	Tightening torques	4
	Tools	6
	Cross-sectional views	7
	Description and operation	9
25 100 30	Complete front axle. Removal - Installation	10
25 100 38	Front axle. Removal - Installation	14
25 108 46-47	Steering knuckle bearing pins. Replacement	24
	Stub axle adjustment	25
	Wheel hub bearing adjustment	27
	Bevel drive adjustment	29
25 102 24	Front axle differential. Overhaul	36
25 100 27	Front axle differential with LIM-SLIP. Overhaul	37
	Front axle differential with NO SPIN. Overhaul	39
44 511 80	Leading drive wheels toe-in check	42

REAR AXLE AND TRANSMISSION

SECTION 27

Rear Axle And Transmission

Chapter 1

Section	Description	Page
27 000	Main data	1
	Tightening torques	4
	Special tools	6
	Cross-sectional views	8
	Description and operation and troubleshooting	10
21.118.10 - 12	Transmission-gearbox casing Removal-Installation	11
21.118.85	Transmission-gearbox casing Disassembly-Overhaul	35

Gearbox driven shaft end float adjustment	43
Differential lock engagement sleeve adjustment	44
Determining the bevel pinion positioning adjustment ring	45
Adjusting the taper roller bearings for the bevel pinion shaft	47
Adjusting the bearings and checking the backlash	48
Differential pinion and side gear backlash adjustment	52

POWER TAKE-OFF

SECTION 31

Mechanical Power Take - Off

Chapter 1

Section	Description	Page
31 000	Main specification	1
	Tools	3
	Torque settings	4
	Sectional drawings	5
	Description and operation	10
	Troubleshooting	12
31 101	Removal - Refitting	13
	Bench overhaul	16

BRAKING SYSTEM

SECTION 33

Braking System

Chapter 1

Section	Description	Page
33 000	Main data	1
	Tightening torques	2
	Cross-sectional views	2
	Description & Operation	9
	Tools - Troubleshooting	10
33.206	Front brake assembly mod. TD60D and TD70D removal and refitting - overhauling on the bench	11
33.202.60	Service brake removal and refitting	14
33.202.50	Removal-Refitting of front brake pumps	19
33.202.40	Bleeding air from the front braking system	23
33.120.08	Adjusting service brake pedals travel	24
33.110.08	Parking brake travel adjustment	24

HYDRAULIC SYSTEM

SECTION 35

Rear Mechanical Hydraulic Lift

Chapter 1

Section	Description	Page
35 000	Main specification	1
	Tightening torques	4
	Tools	7
	Cross-sectional views	8

	Description & Operation	10
	Hydraulic circuit	10
	Description and operation of lift phases	11
	Fault diagnosis	14
35 110.30	Hydraulic lift - disassembly reassembly	16
35.110.40-42-46	Hydraulic lift - bench overhaul	22
	Adjusting the lift	27
35.110.08	Linkage adjustment	33
35.110.30	Pressure relief valve - disassembly reassembly	35
35.110.32	Pressure relief valve - setting	35
35.110.14	Lift control valve - disassembly assembly and overhaul on bench	37
35.0101.10	Lift pump	42

Open Centre System Auxiliary Control Valves

Chapter 2

Section	Description	Page
35 000	Main data - Tools	1
	Auxiliary control valves - sectional views	2
	Description and operation	4
	Fault diagnosis	see chapter 1
35 204 46	Auxiliary control valves - Assembly-Disassembly	8
	Spool binding test	16
	Spool leakage test	17
	Adjustment of the automatic detent release pressure	18

Trailer Brake Auxiliary Control Valve

Chapter 3

Section	Description	Page
35 000	Section views	1
	Description and operation	1
	Hydraulic diagram	2
	Description and operation of valve phases	3
	Trailer brake auxiliary control valve linkage adjustment	6

STEERING

SECTION 41

Steering

Chapter 1

Section	Description	Page
41 000	Principal data	1
	Tightening torques	4
	Section views	4
	Hydraulic diagram	6
	Operation	8
	Fault diagnosis	9
	Tools	7
41 204 30	Hydrostatic steering control valve - Removal-Installation	11
41 204 34	Hydrostatic steering control valve - Disassembly-Assembly	14
41 204 38	Hydrostatic steering control valve - Bench testing	28
	Hydrostatic steering oil pump - Disassembly-Assembly	30
41 216 20	Steering cylinder (two-wheel drive axle) - Removal-Refitting	32
	Steering cylinder (four wheel drive axle) - Removal-Refitting	33

FRONT AXLE AND WHEELS

SECTION 44

Front Axle And Wheels

Chapter 1

Section	Description	Page
44 000	Principal data	1
	Sectional views	3
	Torque settings	4
	Equipment - Fault diagnosis	5
44 101 30	Removal-Refitting-Overhaul	6
44 101 22	Wheel hub disassembly-assembly	9
44 101 46	Stub axle overhaul	16
44 101 80	Checking wheel alignment	20

AUXILIARY UNITS

SECTION 50

Auxiliary Units

Chapter 1

Section	Description	Page
50 000	Safety instructions	2
	General characteristics	3
	Equipment	4
	Operating principles	5
	Fault diagnosis	7
	Cab controls	11
	Use	14
	Main components of the cab air conditioning system	15
	Refrigerant recovery-recycling and evacuation-charging stations	20
50 200 04	Drying recharging and checking cooling	22
50 200 03	Functional testing of air conditioning system	27
	Summary of the cab air-conditioning system charging operations	28
	Checking for refrigerant leaks using an electronic leak detector	30
	Summary of fault diagnosis and maintenance	31
	Air conditioning and heating pipes - Replacement	33
50 200 04-74	Receiver-drier - Replacement	36
50 200 04-72	Condenser - Replacement	38
50 200 04-26	Compressor - Removal-Refitting	39
50 200 10	Compressor drive belt tension adjustment	41

ELECTRICAL SYSTEM

SECTION 55

Instruments

Chapter 1

Section	Description	Page
55 418	Analogue instruments and introduction	1
	Transmitter and switches	4

Components

Chapter 2

Section	Description	Page
55 500	Introduction	1
	Component description	1

Starting System **Chapter 3**

Section	Description	Page
55 000	Technical information	1
	Tightening torques	1
	Description and operation	2
	Starting circuit	3
	System tests	5
55 201	Removal and re-installation of starter motor	8
	Servicing	9
	Bench tests	10

Charging System **Chapter 4**

Section	Description	Page
55 000	Technical information	1
	Tightening torques	1
	Description and operation	2
	System testing and trouble-shooting	4
55 301	Removal, re-installation and servicing	10

Battery **Chapter 5**

Section	Description	Page
55 000	Technical information	1
	Description and operation	1
55.301.040	Removal and re-installation	2
	Battery checking and maintenance	3
	Charging the battery	4
	Battery problems - Frequent causes	7

Electrical Circuits **Chapter 6**

Section	Description	Page
55 100	Contents	1
	Fuses (all versions)	2
	Symbols used in electrical circuits	4
	Electrical wire colour coding	5
	Ground locations	5
	Electrical diagrams	
	- General diagrams (W/Cab)	9

- General diagrams (W/Out Cab)	15
- Analogue instrument circuit and connector overview	19
- Start-up circuit and connector overview	21
- Direction indicator & hazard warning light circuit and connector overview	25
- Windscreen and rear window wiper/washer circuit and connector overview	31
- Brake light circuit and connector overview	35
- Heating and air-conditioning system circuit and connector overview	41
- Work lamp (without cab circuit and connector overview)	45
- Work lamp (without cab circuit and connector overview)	49
- Side lights, main and dipped headlights, parking light circuit and connector overview	
	53

BODYWORK AND DRIVER POSITION

SECTION 90

Bodywork And Driver Position

Chapter 1

Section	Description	Page
90 000	Disassembly-Assembly	1

GENERAL INSTRUCTIONS

IMPORTANT NOTICE

All maintenance and repair operations described in this manual should be carried out exclusively by the NEW HOLLAND authorised workshops. All instructions detailed should be carefully observed and special equipment indicated should be used if necessary.

Everyone who carries out service operations described without carefully observing these prescriptions will be directly responsible of deriving damages.

SHIMMING

At each adjustment, select adjusting shims, measure them individually using a micrometer and then sum up recorded values. Do not rely on measuring the whole shimming set, which may be incorrect, or on rated value indicated for each shim.

ROTATING SHAFT SEALS

To correctly install rotating shaft seals, observe the following instructions:

- Let the seal soak into the same oil as it will seal for at least half an hour before mounting;
- Thoroughly clean the shaft and ensure that the shaft working surface is not damaged;
- Place the sealing lip towards the fluid. In case of a hydrodynamic lip, consider the shaft rotation direction and orient grooves in order that they deviate the fluid towards the inner side of the seal;
- Coat the sealing lip with a thin layer of lubricant (oil rather than grease) and fill with grease the gap between the sealing lip and the dust lip of double lip seals;
- Insert the seal into its seat and press it down using a flat punch. Do no tap the seal with a hammer or a drift;
- Take care to insert the seal perpendicularly to its seat while you are pressing it. Once the seal is settled, ensure that it contacts the thrust element if required.;
- To prevent damaging the sealing lip against the shaft, place a suitable protection during installation.

O RINGS

Lubricate the O rings before inserting them into their seats. This will prevent the O rings from rolling over and twine during mounting which will jeopardise sealing.

SEALERS

Apply one of the following sealers: RTV SILMATE, RHODORSIL CAF 1, or LOCTITE PLASTIC GASKET over the mating surfaces marked with an X.

Before applying the sealer, prepare the surface as follows:

- remove possible scales using a metal brush;
- thoroughly degrease the surfaces using one of the following cleaning agent: trichlorethylene, petrol or a water and soda solution.

BEARINGS


It is advisable to heat the bearings to 80 to 90°C before mounting them on their shafts and cool them down before inserting them into their seats with external tapping.

ROLL PINS

When fitting straight roll pins, ensure that the pin notch is oriented in the direction of the effort to stress the pin. Coil roll pins can be installed in any position.

NOTES FOR SPARE PARTS

Use exclusively **genuine NEW HOLLAND spare parts**, the only ones bearing this logo.



Only genuine parts guarantee same quality, life, safety as original components as they are the same as mounted in production.

Only the **NEW HOLLAND genuine spare parts** can offer this guarantee.

All spare parts orders should be complete with the following data:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found on the "Microfiches" or the "Spare Parts Catalogue", which is the base for order processing.

NOTES FOR EQUIPMENT

Equipment which NEW HOLLAND proposes and shows in this manual are as follows:

- studied and designed expressly for use on NEW HOLLAND tractors;
- necessary to make a reliable repair;
- accurately built and strictly tested to offer efficient and long-lasting working means.

We also remind the Repair Personnel that having these equipment means:

- work in optimal technical conditions;
- obtain best results;
- save time and effort;
- work more safely.

NOTICES

Wear limits indicated for some details should be intended as advised, but not binding values. The words "front", "rear", "right hand", and "left hand" referred to the different parts should be intended as seen from the operator's seat oriented to the normal sense of movement of the tractor.

HOW TO MOVE THE TRACTOR WITH THE BATTERY REMOVED

Cables from the external power supply should be connected exclusively to the respective terminals of the tractor positive and negative cables using pliers in good condition which allow proper and steady contact.

Disconnect all services (lights, wind-shield wipers, etc.) before starting the tractor.

If it is necessary to check the tractor electrical system, check it only with the power supply connected. At check end, disconnect all services and switch the power supply off before disconnecting the cables.

SAFETY RULES

PAY ATTENTION TO THIS SYMBOL



This warning symbol points out important messages involving personal safety. Carefully read the safety rules contained herein and follow advised precautions to avoid potential hazards and safeguard your safety and personal integrity. In this manual you will find this symbol together with the following key-words:



WARNING - it gives warning about improper repair operations and deriving potential consequences affecting the service technician's personal safety.

DANGER - it gives specific warning about potential dangers for personal safety of the operator or other persons directly or indirectly involved.

TO PREVENT ACCIDENTS

Most accidents and personal injuries taking place in workshops are due from non-observance of some simple and essential prudential rule and safety precautions. For this reason, IN MOST CASES THEY CAN BE AVOIDED. It suffices to foresee possible causes and act consequently with necessary caution and care.

The possibility that an accident might occur with any type of machines should not be disregarded, no matter how well the machine in question was designed and built.

A wise and careful service technician is the best precautions against accidents.

Careful observance of this only basic precaution would be enough to avoid many severe accidents.

DANGER: Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

if they are certified operators to assist in the operation to be carried out.

- ◊ Never operate the machine or use attachments from a place other than sitting at the operator's seat.
- ◊ Never carry out any operation on the machine when the engine is running, except when specifically indicated.
- ◊ Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- ◊ All repair and maintenance operations should be carried out with the greatest care and attention.
- ◊ Service stairs and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- ◊ Disconnect the batteries and label all controls to warn that the tractor is being serviced. Block the machine and all equipment which should be raised.
- ◊ Never check or fill fuel tanks and accumulator batteries, nor use starting liquid if you are smoking or near open flames as such fluids are flammable.
- ◊ Brakes are inoperative when they are manually released for maintenance purposes. In such cases, the machine should be kept constantly under control using blocks or similar devices.
- ◊ The fuel filling gun should remain always in contact with the filler neck. Maintain this contact until the fuel stops flowing into the tank to avoid possible sparks due to static electricity buildup.

SAFETY RULES

GENERALITIES

- ◊ Carefully follow specified repair and maintenance procedures.
- ◊ Do not wear rings, wristwatches, jewels, unbuttoned or flapping clothing such as ties, torn clothes, scarves, open jackets or shirts with open zips which could get hold into moving parts. We advise to use approved safety clothing such as anti-slipping footwear, gloves, safety goggles, helmets, etc.
- ◊ Never carry out any repair on the machine if someone is sitting on the operator's seat, except

- ◊ Use exclusively specified towing points for towing the tractor. Connect parts carefully. Ensure that foreseen pins and/or locks are steadily fixed before applying traction. Do not stop near towing bars, cables or chains working under load.
- ◊ To transfer a failed tractor, use a trailer or a low loading platform trolley if available.
- ◊ To load and unload the machine from the transportation mean, select a flat area providing a firm support to the trailer or truck wheels. Firmly tie the machine to the truck or trailer platform and block wheels as required by the forwarder.
- ◊ For electrical heaters, battery-chargers and similar equipment use exclusive auxiliary power supplies with a efficient ground to avoid electrical shock hazard.
- ◊ Always use lifting equipment and similar of appropriate capacity to lift or move heavy components.
- ◊ Pay special attention to bystanders.
- ◊ Never pour gasoline or diesel oil into open, wide and low containers.
- ◊ Never use gasoline, diesel oil or other flammable liquids as cleaning agents. Use non-flammable non-toxic proprietary solvents.
- ◊ Wear protection goggles with side guards when cleaning parts using compressed air.
- ◊ Do not exceed a pressure of 2.1 bar, in accordance with local regulations.
- ◊ Do not run the engine in a closed building without proper ventilation.
- ◊ Do not smoke, use open flames, cause sparks in the nearby area when filling fuel or handling highly flammable liquids.
- ◊ Do not use flames as light sources when working on a machine or checking for leaks.
- ◊ Move with caution when working under a tractor, and also on or near a tractor. Wear proper safety accessories: helmets, goggles and special footwear.
- ◊ During checks which should be carried out with the engine running, ask an assistant to seat at the operator's seat and keep the service technician under visual control at any moment.
- ◊ In case of operations outside the workshop, drive the tractor to a flat area and block it. If working on an incline cannot be avoided, first block the tractor carefully. Move it to a flat area as soon as possible with a certain extent of safety.
- ◊ Ruined or plied cables and chains are unreliable. Do not use them for lifting or trailing. Always handle them wearing gloves of proper thickness.
- ◊ Chains should always be safely fastened. Ensure that fastening device is strong enough to hold the load foreseen. No persons should stop near the fastening point, trailing chains or cables.
- ◊ The working area should be always kept CLEAN and DRY. Immediately clean any spillage of water or oil.
- ◊ Do not pile up grease or oil soaked rags, as they constitute a great fire hazard. Always place them into a metal container.
Before starting the tractor or its attachments, check, adjust and block the operator's seat. Also ensure that there are no persons within the tractor or attachment operating range.
- ◊ Do not keep into your pockets any object which might fall unobserved into the tractor's inner compartments.
- ◊ Whenever there is the possibility of being reached by ejected metal parts or similar, use protection eye mask or goggles with side guards, helmets, special footwear and heavy gloves.
- ◊ Wear suitable protection such as tinted eye protection, helmets, special clothing, gloves and footwear whenever it is necessary to carry out welding procedures. All persons standing in the vicinity of the welding process should wear tinted eye protection. NEVER LOOK AT THE WELDING ARC IF YOUR EYES ARE NOT SUITABLY PROTECTED.
- ◊ Metal cables with the use get frayed. Always wear adequate protections (heavy gloves, eye protection, etc.)
- ◊ Handle all parts with the greatest caution. Keep your hands and fingers far from gaps, moving gears and similar. Always use approved protective equipment, such as eye protection, heavy gloves and protective footwear.

START UP

- ◊ Never run the engine in confined spaces which are not equipped with adequate ventilation for exhaust gas extraction.
- ◊ Never bring your head, body, arms, legs, feet, hands, fingers near fans or rotating belts.

ENGINE

- ◊ Always loosen the radiator cap very slowly before removing it to allow pressure in the system to dissipate. Coolant should be topped up only when the engine is stopped or idle if hot.
- ◊ Do not fill up fuel tank when the engine is running, mainly if it is hot, to avoid ignition of fires in case of fuel spilling.
- ◊ Never check or adjust the fan belt tension when the engine is running.
Never adjust the fuel injection pump when the tractor is moving.
- ◊ Never lubricate the tractor when the engine is running.

ELECTRICAL SYSTEMS

- ◊ If it is necessary to use auxiliary batteries, cables must be connected at both sides as follows: (+) to (+) and (-) to (-). Avoid short-circuiting the terminals. GAS RELEASED FROM BATTERIES IS HIGHLY FLAMMABLE. During charging, leave the battery compartment uncovered to improve ventilation. Avoid checking the battery charge by means of "jumpers" made by placing metallic objects across the terminals. Avoid sparks or flames near the battery area. Do no smoke to prevent explosion hazards.
- ◊ Prior to any service, check for fuel or current leaks. Remove these leaks before going on with the work.
- ◊ Do not charge batteries in confined spaces. Ensure that ventilation is appropriate to prevent accidental explosion hazard due to build-up of gases released during charging.
- ◊ Always disconnect the batteries before performing any type of service on the electrical system.

HYDRAULIC SYSTEMS

- ◊ Some fluid slowly coming out from a very small port can be almost invisible and be strong enough to penetrate the skin. For this reason, NEVER USE YOUR HANDS TO CHECK FOR LEAKS, but use a piece of cardboard or a piece of wood to this purpose. If any fluid is injected into the skin, seek medical aid immediately. Lack of immediate medical attention, serious infections or dermatosis may result.

- ◊ Always take system pressure readings using the appropriate gauges.

WHEELS AND TYRES

- ◊ Check that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check possible damages to the rims and tyres.
- ◊ Keep off and stay at the tyre side when correcting the inflation pressure.
- ◊ Check the pressure only when the tractor is unloaded and tyres are cold to avoid wrong readings due to over-pressure. Do not reuse parts of recovered wheels as improper welding, brazing or heating may weaken the wheel and make it fail.
- ◊ Never cut, nor weld a rim with the inflated tyre assembled.
- ◊ To remove the wheels, block both front and rear tractor wheels. Raise the tractor and install safe and stable supports under the tractor in accordance with regulations in force.
- ◊ Deflate the tyre before removing any object caught into the tyre tread.
- ◊ Never inflate tyres using flammable gases as they may originate explosions and cause injuries to bystanders.

REMOVAL AND INSTALLATION

- ◊ Lift and handle all heavy components using lifting equipment of adequate capacity. Ensure that parts are supported by appropriate slings and hooks. Use lifting eyes provided to this purpose. Take care of the persons near the loads to be lifted.
- ◊ Handle all parts with great care. Do not place your hands or fingers between two parts. Wear approved protective clothing such as safety goggles, gloves and footwear.
- ◊ Do not twine chains or metal cables. Always wear protection gloves to handle cables or chains.

CONSUMABLES

COMPONENT TO BE FILLED OR TOPPED UP	QUANTITY			RECOMMENDED PRODUCTS	INTERNATIONAL SPECIFICATION
	liters/dm ³	US gal	IMP gal		
Cooling system: without cab: TD 5010, TD5020	12	3.17	2.64	Water & liquid AMBRA AGRIFLU 50% + 50% (NH 900 A)	-
TD 5030, TD5040, TD5050	14	3.69	3.08		
with cab: TD 5010, TD5020	14	3.69	3		
TD 5030, TD5040, TD5050	16	4.22	3.52		
Windscreen washer bottle	2	0.53	0.44	Water & cleaning liquid	-
Fuel tank.....	90	24.3	19.80	Decanted and filtered diesel fuel	-
Engine sump: TD 5010, TD 5020, TD5030 : TD 5040, TD5050 :	8.5 10.0	2.25 2.64	1.87 2.20	AMBRA MASTERGOLD SAE 15W - 40 (NH 330H)	API CH-4 ACEA E5
Brake control circuit	0.4	0.1	0.09	AMBRA BRAKE LHM Oil (NH 610 A)	ISO 7308
Hydrostatic steering circuit	2.0	0.52	0.44	Oil AMBRA MULTI G (NH 410B)	API GL4 ISO 32/46 SAE 10W-30
Front axle: - axle housing	7.0	1.8	1.54		
- final drives (each):	1.25	0.3	0.28		
Rear transmission (bevel drive and brakes), gearbox, hydraulic lift and PTO	46	12.15	10.12		
Rear final drives (each)	5.3	1.40	1.17	Grease AMBRA GR9 (NH 710A)	NLGI 2
Front wheel hubs	-	-	-		
Grease fittings	-	-	-		

SECTION 10 - ENGINE

Chapter 1 - Engine

CONTENTS

Operation	Description	Page
	Tools	2
	Engine Troubleshooting	3
10 001 10	Engine R.I.	7

TOOLS

Warning - The operations described in this section can only be carried out with **ESSENTIAL** tools indicated by an (X).

To work safely and efficiently and obtain the best results, it is also necessary to use the recommended specific tools listed below and certain other tools, which are to be made according to the drawings included in this manual.

List of specific tools required for the various operations described in this Section.

380000569 Movable tool for dismantling tractors with bracket **380000500** and adapter plate **380000844**.

ENGINE TROUBLESHOOTING

Problems	Possible Causes	Solutions
Engine does not start.	<ol style="list-style-type: none"> 1. Batteries partially discharged. 2. Battery terminal connections corroded or loose. 3. Injection pump timing incorrect. 4. Impurities or water in fuel lines. 5. No fuel in tank. 6. Fuel supply pump malfunction. 7. Air in fuel system. 8. Starter motor faulty. 9. Thermostarter faulty. 	<p>Check and recharge batteries. Replace if necessary.</p> <p>Clean, inspect and tighten terminal nuts. Replace terminals and nuts if excessively corroded.</p> <p>Adjust injection pump timing.</p> <p>Disconnect fuel lines from injection pump and clean thoroughly. If necessary clean and dry the fuel tank.</p> <p>Fill tank.</p> <p>Check and replace pump if necessary.</p> <p>Check fuel lines, unions, supply pump, filters and injection pump for air; then bleed the air from the circuit.</p> <p>Repair or replace starter motor.</p> <p>Check and replace thermostarter if necessary.</p>
Engine stalls.	<ol style="list-style-type: none"> 1. Idle speed too low. 2. Injection pump delivery irregular. 3. Impurities or water in fuel lines. 4. Fuel filters clogged. 5. Incorrect valve - rocker arm clearances. 6. Burnt or cracked valves. 7. Air in fuel system. 8. Injection pump drive mechanism damaged. 	<p>Adjust idle speed.</p> <p>Check injection pump delivery on test bench.</p> <p>Disconnect fuel lines from injection pump and clean thoroughly. If necessary clean and dry the fuel tank.</p> <p>Replace the filter cartridges.</p> <p>Adjust the clearance between the rocker arms and the valves.</p> <p>Replace the valves.</p> <p>Check fuel lines, unions, supply pump, filters and injection pump for air; then bleed the air from the circuit.</p> <p>Replace damaged parts.</p>

(continued)

ENGINE TROUBLESHOOTING

(cont)

Problems	Possible Causes	Solutions
Engine overheating.	<ol style="list-style-type: none"> 1. Coolant pump malfunction. 2. Thermostat faulty. 3. Radiator inefficient. 4. Deposits in cylinder head and crankcase coolant passages. 5. Coolant pump and fan drive belt slack. 6. Coolant level low. 7. Incorrect engine timing. 8. Injection pump calibration incorrect - delivering too much or too little fuel. 9. Air filter clogged. 	<p>Overhaul pump and replace if necessary.</p> <p>Replace the thermostat.</p> <p>Remove internal deposits by flushing. Check for leaks and repair.</p> <p>Flush out coolant system.</p> <p>Check and adjust belt tension.</p> <p>Top up expansion tank with specified coolant mixture.</p> <p>Check and adjust engine timing.</p> <p>Calibrate pump on test bench to values specified in calibration tables.</p> <p>Clean filter unit and replace filter element if necessary.</p>
Engine lacks power and runs unevenly.	<ol style="list-style-type: none"> 1. Injection pump timing incorrect. 2. Auto advance regulator in injection pump damaged. 3. Control valve journal worn. 4. Injection pump delivery irregular. 5. All-speed governor damaged. 6. Injectors partially obstructed or damaged. 7. Impurities or water in fuel lines. 	<p>Adjust injection pump timing.</p> <p>Overhaul injection pump and adjust on test bench to values specified in calibration table.</p> <p>Overhaul injection pump and adjust on test bench to values specified in calibration table.</p> <p>Overhaul injection pump and adjust on test bench to values specified in calibration table.</p> <p>Overhaul injection pump and adjust on test bench to values specified in calibration table.</p> <p>Clean and overhaul injectors and adjust pressure setting.</p> <p>Disconnect fuel lines from injection pump and clean thoroughly. If necessary clean and dry the fuel tank.</p>

(continued)

ENGINE TROUBLESHOOTING

(cont)

Problems	Possible Causes	Solutions
Engine produces abnormal knocking noises.	8. Fuel supply pump damaged. 9. Incorrect valve - rocker arm clearances. 10. Cylinder compression low. 11. Air filter clogged. 12. Tie-rod in linkage between accelerator and injection pump incorrectly adjusted. 13. Fast idling speed screw on injection pump incorrectly adjusted. 1. Injectors partially obstructed or damaged. 2. Impurities accumulating in fuel lines. 3. Injection pump timing incorrect. 4. Crankshaft knocking due to excessive play in one or more main or big-end bearings or excessive endfloat. 5. Crankshaft out of balance. 6. Flywheel bolts loose. 7. Connecting rod axes not parallel. 8. Pistons knock due to excessive wear. 9. Noise caused by excessive play of gudgeon pins in small-end and piston bushings. Loose fit of small-end bushing. 10. Excessive tappet / valve noise.	Replace fuel supply pump. Adjust the clearance between the rocker arms and the valves. Test compression and overhaul engine if necessary. Clean filter unit and replace filter element if necessary. Adjust to correct length. Adjust fast idling speed screw. Clean and overhaul injectors and adjust pressure setting. Clean fuel lines and replace severely dented pipes; clean injection pump if necessary. Adjust injection pump timing. Re-grind crankshaft journals and crankpins. Fit oversize shell bearings and thrust washers. Check crankshaft alignment and balance; replace if necessary. Replace any bolts that have worked loose and tighten all bolts to the specified preliminary and angular torque values. Straighten connecting rods, check axes parallelism; replace con rods if necessary. Re bore cylinder liners and fit oversize pistons. Fit oversize gudgeon pin, re bore piston seats and small-end bushings. Replace with new bushings. Check for broken springs or excessive play between valve stems and guides, cam followers and bores; adjust valve clearances.

(continued)

ENGINE TROUBLESHOOTING

(cont)

Problems	Possible Causes	Solutions
Engine produces excessive black or dark grey smoke.	<ol style="list-style-type: none"> 1. Maximum delivery of injection pump too high. 2. Injection pump delivery excessively retarded or automatic advance regulator damaged. 3. Injection pump delivery excessively advanced. 4. Injectors partially or totally obstructed or incorrectly adjusted. 5. Air filter clogged. 6. Loss of engine compression due to: <ul style="list-style-type: none"> - piston rings sticking; - cylinder liner wear; - worn or incorrectly adjusted valves. 7. High-pressure fuel lines damaged. 	<p>Calibrate pump on test bench to values specified in calibration tables.</p> <p>Adjust injection pump timing or check automatic advance regulator.</p> <p>Adjust injection pump timing.</p> <p>Clean and overhaul injectors and adjust pressure setting; replace if necessary.</p> <p>Clean filter unit and replace filter element if necessary.</p> <p>Replace damaged parts or, if necessary, overhaul the engine.</p> <p>Inspect and replace if necessary.</p>
Blue, grey-blue or grey--white smoke.	<ol style="list-style-type: none"> 1. Injection pump delivery excessively retarded or automatic advance regulator damaged. 2. Injectors obstructed or damaged. 3. Oil leaking past piston rings due to sticking rings or cylinder liner wear. 4. Oil leaking through the inlet valve guides due to guide or valve stem wear. 5. Engine does not reach correct operating temperature (thermostat faulty). 	<p>Adjust injection pump timing or check automatic advance regulator.</p> <p>Clean, overhaul and calibrate injectors, replace if necessary.</p> <p>Replace damaged parts or, if necessary, overhaul the engine.</p> <p>Overhaul cylinder head.</p> <p>Replace the thermostat.</p>
Engine runs on after switching off.	<ol style="list-style-type: none"> 1. Engine stop electromagnet damaged. 2. All-speed governor damaged. 	<p>Replace electromagnet.</p> <p>Overhaul injection pump and adjust on test bench to values specified in calibration table.</p>

Op. 10 001 10
ENGINE R.I.



DANGER



Lift and handle all heavy parts using suitable lifting equipment.

Make sure that assemblies or parts are supported by means of suitable slings and hooks. Check that no one is in the vicinity of the load to be lifted.




CAUTION




Always use appropriate tools to align fixing holes.
NEVER USE FINGERS OR HANDS.

1. Disconnect the battery negative lead (1).
2. Drain the oil from the transmission-gearbox housing.
3. Drain the cooling system.




1




2

4. Remove the exhaust pipe, attach lifting chains (2) to the bonnet (1) and attach the chain to the hoist.
5. Disconnect the electrical connection (1) of bonnet.




3

6. Detach the gas struts (1) from the bonnet.




4

7. Remove the four bonnet hinge bolts (1) and lift the bonnet clear.




5

8. Remove the three retaining bolts (1) and the guard (2) on the right-left hand side of the fan.




6

9. Unscrew the nut (1) from the weight retaining pin. Remove the weights from the front support.




7

10. Unscrew the front central and rear retaining bolts on the front axle shaft guard, then remove the guard (1).




8

11. Remove the circlip (2) and move the front sleeve (1) in the direction indicated by the arrow until it is released from the groove on the front axle.




9

12. Remove the circlip (2) and move the rear sleeve (1) in the direction indicated by the arrow until it is released from the groove on the drive.




10

13. Remove the propeller shaft central support (1) retaining bolts and extract the shaft together with the support.




11

14. Disconnect the pressure pipe connection (1) of the lift pump.




12

15. Disconnect the delivery lines of both hydraulic lift pump (1) and hydrostatic steering pump (2).




13

16. Detach the cab heating pipes (1) and (2).




14

17. Detach the cab air-conditioning pipes (1) and (2).




15

18. Extract the plastic fasteners (2) and detach the diesel recovery pipe (3) and delivery pipe (4) to the diesel pump (1).




16

19. Remove two metal clamps (1) and the rigid pipe of drawing oil from the transmission housing via lift pump.




17

20. Remove the electrical connection from the brake fluid reservoir and take the brake fluid reservoir (1) from the bracket.




18

21. Disconnect the steering oil delivery and return hoses (1) and (2). Disconnect the steering cylinder lines (3) and (4).




19

22. Disconnect the delivery and return lines (1) to the power steering cylinders.




20

23. Disconnect rear brakes oil distribution connection pipes (1) and (2).




21

24. Disconnect brake distributor valve connections (1) and (2).




22

25. Disconnect A/C compressor inlet (1) and outlet (2) hoses.




23

26. Remove the fusebox (1) from the bonnet support.




24

27. Remove the electrical oil pressure switch (1).




25

28. Remove the electrical connections of coolant temperature sender (1).



26

29. Remove the electrical connection of pump cut-out solenoid sender (1) and hydrostatic steering pump oil pressure switch (2).



27