


# SERVICE MANUAL

## TD65F / TD75F / TD85F Tractors

Print No. 84285941





# TD65F – TD75F – TD85F

## MODEL TRACTORS

## SERVICE MANUAL

### SECTIONS

<b>GENERAL</b> .....	<b>00</b>
<b>ENGINE</b> .....	<b>10</b>
<b>CLUTCH</b> .....	<b>18</b>
<b>GEARBOX</b> .....	<b>21</b>
<b>TRANSMISSION OF MOTION</b> .....	<b>23</b>
<b>FRONT MECHANICAL TRANSMISSION</b> .....	<b>25</b>
<b>REAR MECHANICAL TRANSMISSION</b> .....	<b>27</b>
<b>POWER TAKE-OFF</b> .....	<b>31</b>
<b>BRAKES</b> .....	<b>33</b>
<b>HYDRAULIC SYSTEMS</b> .....	<b>35</b>
<b>STEERING</b> .....	<b>41</b>
<b>ELECTRICAL SYSTEM</b> .....	<b>55</b>

S E R V I C E

Sample of manual. Download All 503 pages at:

<https://www.arepairmanual.com/downloads/new-holland-td65f-td75f-td85f-tractor-service-repair-manual-2/>

84285941 – 02-2010

## INTRODUCTION

- ◊ *This manual is divided into sections identified by two-figure numbers. Each section has independent page numbering.*  
*For ease of reference, these sections have the same numbers and names as the Repairs Rate Book sections.*
- ◊ *The different sections can easily be found by consulting the table of contents on the following pages.*
- ◊ *The document number of the manual and the edition/update dates are given at the bottom of each page.*
- ◊ *The information contained in this manual was current on the date printed on each section. As NEW HOLLAND constantly improves its product range, some information may be out of date subsequent to modifications implemented for technical or commercial reasons or to meet legal requirements in different countries.*  
*In the event of conflicting information, consult the NEW HOLLAND Sales and Service Departments.*

## IMPORTANT WARNINGS

- ◊ *All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND service technicians in strict accordance with the instructions given and using any specific tools necessary.*
- ◊ *Anyone who performs the operations described herein without strictly following the instructions is personally responsible for resulting injury or damage to property.*
- ◊ *The Manufacturer and all organisations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer.*  
*In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.*

TEXT AND ILLUSTRATIONS ARE THE PROPERTY  
OF NEW HOLLAND



No part of the text or illustrations  
may be reproduced

PRINTED IN TURKEY

**NEW HOLLAND**  
SERVICE – Technical Publications & Special Tools  
Part no.

# NEW HOLLAND

## Repair Manual – TD F Series Tractors

---

### CONTENTS

#### GENERAL

#### SECTION 00

##### General Instructions and Health and Safety Chapter 1

Section	Description	Page
00 000	General instructions .....	1
	Notes for spare parts .....	2
	Notes for equipment .....	2
	Safety rules .....	3
	Consumables .....	6

#### ENGINE

#### SECTION 10

##### Engine System Chapter 1

Section	Description	Page
10 000	General specification .....	2
	Injection pump calibration data .....	5
	General specifications .....	9
	Tightening torques .....	17
	Tools .....	18
	Cross-sectional views .....	21
	Lubrication and cooling system diagrams .....	23
	Fault diagnosis .....	25
10 001 10	Engine <i>Removal–Installation</i> .....	29
10 001 54	Engine <i>Bench overhaul</i> .....	40
	Checks, measurements and repairs .....	61
10 406 10	Radiator <i>Removal–Installation</i> .....	81
10 102 70	Crankshaft front oil seal <i>removal installation</i> .....	83
10 402 10	Coolant pump <i>removal installation</i> .....	89
10 402 30	Cooling system thermostat .....	92
10 206 14	Bosch injection pump <i>removal installation</i> .....	95
	Bosch injection pump <i>timing</i> .....	98
	Bosch injection pump <i>air bleeding</i> .....	100
10 218 30	Injectors <i>removal installation</i> .....	101

<b>10 106 12</b>	Valve clearance adjustment .....	103
<b>10 402 28</b>	Coolant pump overhaul .....	106
<b>10 001 30</b>	Compression test .....	107

## CLUTCH

## SECTION 18

### Clutches

### Chapter 1

Section	Description	Page
<b>18 000</b>	General specifications .....	1
	Torque settings .....	2
	Tools .....	3
	Section views .....	3
	Troubleshooting .....	5
<b>18 110 10</b>	Clutch – Removal–Installation .....	6
<b>18 110 30</b>	Dual disk clutch 11"/11" Test bench overhaul .....	16
<b>18 100 40</b>	Clutch adjustments .....	24

## GEARBOX

## SECTION 21

### Mechanical Transmission (12x12)

### Chapter 1

Section	Description	Page
<b>21 000</b>	Main data .....	1
	Tightening torques .....	2
	Tools .....	3
	Section views .....	3&5
	Description and operation .....	8
	Fault diagnosis .....	8
<b>21 110</b>	Removal – Refitting .....	see sect 27

### Reverser

### Chapter 2

Section	Description	Page
<b>21 000</b>	Main data .....	1
	Tightening torques .....	2
	Tools .....	3
	Section views .....	3
	Description and operation .....	5
	Fault diagnosis .....	5
<b>21 110</b>	Removal–Refitting .....	6

### Reverser and Creeper

### Chapter 3

Section	Description	Page
<b>21 000</b>	Main data .....	1
	Tightening torques .....	2
	Tools .....	3
	Section views .....	4
	Description and operation .....	6
	Fault diagnosis .....	6
<b>21 110</b>	Removal–Refitting .....	7

## DRIVE LINES

## SECTION 23

### Drive Lines

### Chapter 1

Section	Description	Page
23 000	Main specification .....	1
	Torque settings and Tools .....	3
	Cross-Sectional views .....	4
23 101 26	Transmission shafts and guard (Disassembly – Assembly) .....	10
23 101 40	Drive gear housing (Removal – Installation) .....	11
23 101 42	Drive gear housing removed (Disassembly – Assembly) .....	13

## FRONT AXLE MECHANICAL TRANSMISSION

## SECTION 25

### Front Axle Mechanical Transmission

### Chapter 1

Section	Description	Page
25 000	Main data .....	1
	Tightening torques .....	3
	Tools .....	5
	Cross-sectional views .....	6
	Description and operation .....	8
25 100 30	Complete front axle. Removal – Installation .....	9
25 100 38	Front axle. Removal – Installation .....	14
25 108 46–47	Steering knuckle bearing pins. Replacement .....	21
	Stub axle adjustment .....	22
	Wheel hub bearing adjustment .....	24
	Bevel drive adjustment .....	25
25 102 24	Front axle differential. Overhaul .....	32
25 100 27	Front axle differential with LIM–SLIP. Overhaul .....	33
44 511 80	Leading drive wheels toe-in check .....	35

## REAR AXLE AND TRANSMISSION

## SECTION 27

### Rear Axle And Transmission

### Chapter 1

Section	Description	Page
27 000	Main data .....	1
	Tightening torques .....	3
	Special tools .....	5
	Cross-sectional views .....	7
	Description and operation and troubleshooting .....	9
21.118.10 – 12	Transmission–gearbox casing Removal–Installation .....	10
21.118.85	Transmission–gearbox casing Disassembly–Overhaul .....	28
	Gearbox driven shaft end float adjustment .....	36
	Differential lock engagement sleeve adjustment .....	37
	Determining the bevel pinion positioning adjustment ring .....	38
	Adjusting the taper roller bearings for the bevel pinion shaft .....	40
	Adjusting the bearings and checking the backlash .....	41
	Differential pinion and side gear backlash adjustment .....	45

## POWER TAKE-OFF

## SECTION 31

### Mechanical Power Take – Off

### Chapter 1

Section	Description	Page
31 000	Main specification .....	1
	Tools .....	3
	Torque settings .....	4
	Sectional drawings .....	5
	Description and operation .....	7
	Troubleshooting .....	11
	Removal – Refitting .....	12
31 101	Bench overhaul .....	15

## BRAKING SYSTEM

## SECTION 33

### Braking System

### Chapter 1

Section	Description	Page
33 000	Main data .....	1
	Tightening torques .....	2
	Cross-sectional views .....	2
	Description & Operation .....	5
	Tools – Troubleshooting .....	6
33.202.60	Service brake removal and refitting .....	7
33.202.50	Removal–Refitting of brake pumps .....	13
33.202.40	Bleeding air from the braking system .....	18
33.120.08	Adjusting service brake pedals travel .....	19
33.110.08	Parking brake travel adjustment .....	19

## HYDRAULIC SYSTEM

## SECTION 35

### Rear Mechanical Hydraulic Lift

### Chapter 1

Section	Description	Page
35 000	Main specification .....	1
	Tightening torques .....	5
	Tools .....	6
	Cross-sectional views .....	7
	Description & Operation .....	9
	Hydraulic circuit .....	9
	Description and operation of lift phases .....	10
	Fault diagnosis .....	13
35 110.30	Hydraulic lift – disassembly reassembly .....	15
35.110.40–42–46	Hydraulic lift – bench overhaul .....	19
	Adjusting the lift .....	24
35.110.08	Linkage adjustment .....	30
35.110.30	Pressure relief valve – disassembly reassembly .....	32
35.110.32	Pressure relief valve – setting .....	32
35.110.14	Lift control valve – disassembly assembly and overhaul on bench .....	34
35.0101.10	Lift pump .....	39

## Open Centre System Auxiliary Control Valves

## Chapter 2

Section	Description	Page
35 000	Main data – Tools .....	1
	Auxiliary control valves – sectional views .....	2
	Description and operation .....	3
	Fault diagnosis .....	see chapter 1
35 204 46	Auxiliary control valves – Assembly–Disassembly .....	7
	Spool binding test .....	15
	Spool leakage test .....	16
	Adjustment of the automatic detent release pressure .....	17

## Trailer Brake Auxiliary Control Valve

## Chapter 3

Section	Description	Page
35 000	Section views .....	1
	Description and operation .....	1
	Hydraulic diagram .....	2
	Description and operation of valve phases .....	3
	Trailer brake auxiliary control valve linkage adjustment .....	6

## STEERING

## SECTION 41

### Steering

### Chapter 1

Section	Description	Page
41 000	Principal data .....	1
	Tightening torques .....	5
	Section views .....	4
	Hydraulic diagram .....	6
	Operation .....	7
	Fault diagnosis .....	9
	Tools .....	6
41 204 30	Hydrostatic steering control valve – Removal–Installation .....	11
41 204 34	Hydrostatic steering control valve – Disassembly–Assembly .....	16
41 204 38	Hydrostatic steering control valve – Bench testing .....	30
	Hydrostatic steering oil pump – Disassembly–Assembly .....	32
41 216 20	Steering cylinder – Removal–Refitting .....	34

## ELECTRICAL SYSTEM

## SECTION 55

### Instruments

### Chapter 1

Section	Description .....	Page
	Analogue instruments Introduction .....	1
	Transmitter and switch .....	4

### Components

### Chapter 2

Section	Description .....	Page
55 500	Introduction .....	1
	Component description .....	1

## Starting System

## Chapter 3

Section	Description	Page
<b>55 000</b>	Technical information .....	1
	Tightening torques .....	1
	Description and operation .....	2
	Starting circuit .....	2
	System tests .....	5
<b>55 201</b>	Removal and re-installation of starter motor .....	8
	Servicing .....	9
	Bench tests .....	10

## Charging System

## Chapter 4

Section	Description	Page
<b>55 000</b>	Technical information .....	1
	Tightening torques .....	1
	Description and operation .....	2
	System testing and trouble-shooting .....	4
<b>55 301</b>	Removal, re-installation and servicing .....	10

## Battery

## Chapter 5

Section	Description	Page
<b>55 000</b>	Technical information .....	1
	Description and operation .....	1
<b>55.301.040</b>	Removal and re-installation .....	2
	Battery checking and maintenance .....	3
	Charging the battery .....	4
	Battery problems – Frequent causes .....	7

## Electrical Circuits

## Chapter 6

Section	Description	Page
<b>55 100</b>	Contents .....	1
	Fuses (all versions) .....	2
	Symbols used in electrical circuits .....	3
	Electrical wire colour coding .....	4
	Ground locations .....	4
	Electrical diagrams .....	
	– General diagrams .....	7
	– Start-up circuit .....	3
	– Direction indicator & hazard warning light circuit .....	13
	– Brake light circuit .....	15
	– Work lamp .....	17
	– Side lights, main and dipped headlights, parking light circuit .....	19
	– Connector overview .....	21

## GENERAL INSTRUCTIONS

### IMPORTANT NOTICE

All maintenance and repair operations described in this manual should be carried out exclusively by the NEW HOLLAND authorised workshops. All instructions detailed should be carefully observed and special equipment indicated should be used if necessary.

Everyone who carries out service operations described without carefully observing these prescriptions will be directly responsible of deriving damages.

### SHIMMING

At each adjustment, select adjusting shims, measure them individually using a micrometer and then sum up recorded values. Do not rely on measuring the whole shimming set, which may be incorrect, or on rated value indicated for each shim.

### ROTATING SHAFT SEALS

To correctly install rotating shaft seals, observe the following instructions:

- Let the seal soak into the same oil as it will seal for at least half an hour before mounting;
- Thoroughly clean the shaft and ensure that the shaft working surface is not damaged;
- Place the sealing lip towards the fluid. In case of a hydrodynamic lip, consider the shaft rotation direction and orient grooves in order that they deviate the fluid towards the inner side of the seal;
- Coat the sealing lip with a thin layer of lubricant (oil rather than grease) and fill with grease the gap between the sealing lip and the dust lip of double lip seals;
- Insert the seal into its seat and press it down using a flat punch. Do no tap the seal with a hammer or a drift;
- Take care to insert the seal perpendicularly to its seat while you are pressing it. Once the seal is settled, ensure that it contacts the thrust element if required.;
- To prevent damaging the sealing lip against the shaft, place a suitable protection during installation.

### O RINGS

Lubricate the O rings before inserting them into their seats. This will prevent the O rings from rolling over and twine during mounting which will jeopardise sealing.

### SEALERS

Apply one of the following sealers: RTV SILMATE, RHODORSIL CAF 1, or LOCTITE PLASTIC GASKET over the mating surfaces marked with an X.

Before applying the sealer, prepare the surface as follows:

- remove possible scales using a metal brush;
- thoroughly degrease the surfaces using one of the following cleaning agent: trichlorethylene, petrol or a water and soda solution.

### BEARINGS


It is advisable to heat the bearings to 80 to 90°C before mounting them on their shafts and cool them down before inserting them into their seats with external tapping.

### ROLL PINS

When fitting straight roll pins, ensure that the pin notch is oriented in the direction of the effort to stress the pin. Coil roll pins can be installed in any position.

### NOTES FOR SPARE PARTS

Use exclusively **genuine NEW HOLLAND spare parts**, the only ones bearing this logo.



Only genuine parts guarantee same quality, life, safety as original components as they are the same as mounted in production.

Only the **NEW HOLLAND genuine spare parts** can offer this guarantee.

All spare parts orders should be complete with the following data:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found on the “Microfiches” or the “Spare Parts Catalogue”, which is the base for order processing.

### NOTES FOR EQUIPMENT

Equipment which NEW HOLLAND proposes and shows in this manual are as follows:

- studied and designed expressly for use on NEW HOLLAND tractors;
- necessary to make a reliable repair;
- accurately built and strictly tested to offer efficient and long-lasting working means.

We also remind the Repair Personnel that having these equipment means:

- work in optimal technical conditions;
- obtain best results;
- save time and effort;
- work more safely.

### NOTICES

Wear limits indicated for some details should be intended as advised, but not binding values. The words “front”, “rear”, “right hand”, and “left hand” referred to the different parts should be intended as seen from the operator’s seat oriented to the normal sense of movement of the tractor.

### HOW TO MOVE THE TRACTOR WITH THE BATTERY REMOVED

Cables from the external power supply should be connected exclusively to the respective terminals of the tractor positive and negative cables using pliers in good condition which allow proper and steady contact.

Disconnect all services (lights, wind-shield wipers, etc.) before starting the tractor.

If it is necessary to check the tractor electrical system, check it only with the power supply connected. At check end, disconnect all services and switch the power supply off before disconnecting the cables.

## SAFETY RULES

### PAY ATTENTION TO THIS SYMBOL



*This warning symbol points out important messages involving personal safety. Carefully read the safety rules contained herein and follow advised precautions to avoid potential hazards and safeguard your safety and personal integrity. In this manual you will find this symbol together with the following key-words:*



**WARNING** – it gives warning about improper repair operations and deriving potential consequences affecting the service technician's personal safety.

**DANGER** – it gives specific warning about potential dangers for personal safety of the operator or other persons directly or indirectly involved.

## TO PREVENT ACCIDENTS

Most accidents and personal injuries taking place in workshops are due from non-observance of some simple and essential prudential rule and safety precautions. For this reason, IN MOST CASES THEY CAN BE AVOIDED. It suffices to foresee possible causes and act consequently with necessary caution and care.

The possibility that an accident might occur with any type of machines should not be disregarded, no matter how well the machine in question was designed and built.

A wise and careful service technician is the best precautions against accidents.

Careful observance of this only basic precaution would be enough to avoid many severe accidents.

**DANGER:** Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

if they are certified operators to assist in the operation to be carried out.

- ◊ Never operate the machine or use attachments from a place other than sitting at the operator's seat.
- ◊ Never carry out any operation on the machine when the engine is running, except when specifically indicated.
- ◊ Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- ◊ All repair and maintenance operations should be carried out with the greatest care and attention.
- ◊ Service stairs and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- ◊ Disconnect the batteries and label all controls to warn that the tractor is being serviced. Block the machine and all equipment which should be raised.
- ◊ Never check or fill fuel tanks and accumulator batteries, nor use starting liquid if you are smoking or near open flames as such fluids are flammable.
- ◊ Brakes are inoperative when they are manually released for maintenance purposes. In such cases, the machine should be kept constantly under control using blocks or similar devices.
- ◊ The fuel filling gun should remain always in contact with the filler neck. Maintain this contact until the fuel stops flowing into the tank to avoid possible sparks due to static electricity buildup.

## SAFETY RULES

### GENERALITIES

- ◊ Carefully follow specified repair and maintenance procedures.
- ◊ Do not wear rings, wristwatches, jewels, unbuttoned or flapping clothing such as ties, torn clothes, scarves, open jackets or shirts with open zips which could get hold into moving parts. We advise to use approved safety clothing such as anti-slipping footwear, gloves, safety goggles, helmets, etc.
- ◊ Never carry out any repair on the machine if someone is sitting on the operator's seat, except

- ◊ Use exclusively specified towing points for towing the tractor. Connect parts carefully. Ensure that foreseen pins and/or locks are steadily fixed before applying traction. Do not stop near towing bars, cables or chains working under load.
- ◊ To transfer a failed tractor, use a trailer or a low loading platform trolley if available.
- ◊ To load and unload the machine from the transportation mean, select a flat area providing a firm support to the trailer or truck wheels. Firmly tie the machine to the truck or trailer platform and block wheels as required by the forwarder.
- ◊ For electrical heaters, battery–chargers and similar equipment use exclusive auxiliary power supplies with a efficient ground to avoid electrical shock hazard.
- ◊ Always use lifting equipment and similar of appropriate capacity to lift or move heavy components.
- ◊ Pay special attention to bystanders.
- ◊ Never pour gasoline or diesel oil into open, wide and low containers.
- ◊ Never use gasoline, diesel oil or other flammable liquids as cleaning agents. Use non–flammable non–toxic proprietary solvents.
- ◊ Wear protection goggles with side guards when cleaning parts using compressed air.
- ◊ Do not exceed a pressure of 2.1 bar, in accordance with local regulations.
- ◊ Do not run the engine in a closed building without proper ventilation.
- ◊ Do not smoke, use open flames, cause sparks in the nearby area when filling fuel or handling highly flammable liquids.
- ◊ Do not use flames as light sources when working on a machine or checking for leaks.
- ◊ Move with caution when working under a tractor, and also on or near a tractor. Wear proper safety accessories: helmets, goggles and special footwear.
- ◊ During checks which should be carried out with the engine running, ask an assistant to seat at the operator's seat and keep the service technician under visual control at any moment.
- ◊ In case of operations outside the workshop, drive the tractor to a flat area and block it. If working on an incline cannot be avoided, first block the tractor carefully. Move it to a flat area as soon as possible with a certain extent of safety.
- ◊ Ruined or plied cables and chains are unreliable. Do not use them for lifting or trailing. Always handle them wearing gloves of proper thickness.
- ◊ Chains should always be safely fastened. Ensure that fastening device is strong enough to hold the load foreseen. No persons should stop near the fastening point, trailing chains or cables.
- ◊ The working area should be always kept CLEAN and DRY. Immediately clean any spillage of water or oil.
- ◊ Do not pile up grease or oil soaked rags, as they constitute a great fire hazard. Always place them into a metal container. Before starting the tractor or its attachments, check, adjust and block the operator's seat. Also ensure that there are no persons within the tractor or attachment operating range.
- ◊ Do not keep into your pockets any object which might fall unobserved into the tractor's inner compartments.
- ◊ Whenever there is the possibility of being reached by ejected metal parts or similar, use protection eye mask or goggles with side guards, helmets, special footwear and heavy gloves.
- ◊ Wear suitable protection such as tinted eye protection, helmets, special clothing, gloves and footwear whenever it is necessary to carry out welding procedures. All persons standing in the vicinity of the welding process should wear tinted eye protection. NEVER LOOK AT THE WELDING ARC IF YOUR EYES ARE NOT SUITABLY PROTECTED.
- ◊ Metal cables with the use get frayed. Always wear adequate protections (heavy gloves, eye protection, etc.)
- ◊ Handle all parts with the greatest caution. Keep your hands and fingers far from gaps, moving gears and similar. Always use approved protective equipment, such as eye protection, heavy gloves and protective footwear.

**START UP**

- ◊ Never run the engine in confined spaces which are not equipped with adequate ventilation for exhaust gas extraction.
- ◊ Never bring your head, body, arms, legs, feet, hands, fingers near fans or rotating belts.

**ENGINE**

- ◊ Always loosen the radiator cap very slowly before removing it to allow pressure in the system to dissipate. Coolant should be topped up only when the engine is stopped or idle if hot.
- ◊ Do not fill up fuel tank when the engine is running, mainly if it is hot, to avoid ignition of fires in case of fuel spilling.
- ◊ Never check or adjust the fan belt tension when the engine is running. Never adjust the fuel injection pump when the tractor is moving.
- ◊ Never lubricate the tractor when the engine is running.

**ELECTRICAL SYSTEMS**

- ◊ If it is necessary to use auxiliary batteries, cables must be connected at both sides as follows: (+) to (+) and (–) to (–). Avoid short-circuiting the terminals. GAS RELEASED FROM BATTERIES IS HIGHLY FLAMMABLE. During charging, leave the battery compartment uncovered to improve ventilation. Avoid checking the battery charge by means of “jumpers” made by placing metallic objects across the terminals. Avoid sparks or flames near the battery area. Do no smoke to prevent explosion hazards.
- ◊ Prior to any service, check for fuel or current leaks. Remove these leaks before going on with the work.
- ◊ Do not charge batteries in confined spaces. Ensure that ventilation is appropriate to prevent accidental explosion hazard due to build-up of gases released during charging.
- ◊ Always disconnect the batteries before performing any type of service on the electrical system.

**HYDRAULIC SYSTEMS**

- ◊ Some fluid slowly coming out from a very small port can be almost invisible and be strong enough to penetrate the skin. For this reason, NEVER USE YOUR HANDS TO CHECK FOR LEAKS, but use a piece of cardboard or a piece of wood to this purpose. If any fluid is injected into the skin, seek medical aid immediately. Lack of immediate medical attention, serious infections or dermatosis may result.

- ◊ Always take system pressure readings using the appropriate gauges.

**WHEELS AND TYRES**

- ◊ Check that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check possible damages to the rims and tyres.
- ◊ Keep off and stay at the tyre side when correcting the inflation pressure.
- ◊ Check the pressure only when the tractor is unloaded and tyres are cold to avoid wrong readings due to over-pressure. Do not reuse parts of recovered wheels as improper welding, brazing or heating may weaken the wheel and make it fail.
- ◊ Never cut, nor weld a rim with the inflated tyre assembled.
- ◊ To remove the wheels, block both front and rear tractor wheels. Raise the tractor and install safe and stable supports under the tractor in accordance with regulations in force.
- ◊ Deflate the tyre before removing any object caught into the tyre tread.
- ◊ Never inflate tyres using flammable gases as they may originate explosions and cause injuries to bystanders.

**REMOVAL AND INSTALLATION**

- ◊ Lift and handle all heavy components using lifting equipment of adequate capacity. Ensure that parts are supported by appropriate slings and hooks. Use lifting eyes provided to this purpose. Take care of the persons near the loads to be lifted.
- ◊ Handle all parts with great care. Do not place your hands or fingers between two parts. Wear approved protective clothing such as safety goggles, gloves and footwear.
- ◊ Do not twine chains or metal cables. Always wear protection gloves to handle cables or chains.

## CONSUMABLES

COMPONENT TO BE FILLED OR TOPPED UP	QUANTITY		RECOMMENDED PRODUCTS	INTERNATIONAL SPECIFICATION
	liters/dm <sup>3</sup>	US gal		
Cooling system: without cab:	12	3.17	Water & liquid <b>AMBRA AGRIFLU</b> 50% + 50% (NH 900 A)	-
Fuel tank.....	80	21.1	Decanted and filtered diesel fuel	-
Engine sump without filter: Engine sump with filter:	6.6 7.3	1.74 1.93	<b>AMBRA</b> <b>MASTERGOLD HSP</b> <b>15W – 40</b> (NH 330H) / <b>10W-30</b> (NH 324 H)	API CH-4 ACEA E5
Brake control circuit .....	0.4	0.1	<b>AMBRA BRAKE</b> <b>LHM Oil</b> (NH 610 A)	ISO 7308
Front axle: - axle housing - final drives (each):	7.0 1.25	1.8 0.3	Oil <b>AMBRA MULTI G</b> (NH 410B)	API GL4 ISO 32/46 SAE 10W-30
Rear transmission (bevel drive and brakes), gearbox, hydraulic lift and PTO	45	11.89		
Front wheel hubs .....	-	-	Grease <b>AMBRA GR9</b> (NH 710A)	NLGI 2
Grease fittings .....	-	-		

## SECTION 10 – ENGINE

### Chapter 1 – Engine

#### CONTENTS

Section	Description	Page
<b>10 000</b>	General specification .....	2
	Injection pump calibration data .....	5
	General specifications .....	9
	Tightening torques .....	17
	Tools .....	18
	Cross-sectional views .....	21
	Lubrication and cooling system diagrams .....	23
	Fault diagnosis .....	25
<b>10 001 10</b>	Engine <i>Removal–Installation</i> .....	29
<b>10 001 54</b>	Engine <i>Bench overhaul</i> .....	40
<b>10 406 10</b>	Radiator <i>Removal–Installation</i> .....	81
<b>10 102 70</b>	Crankshaft front oil seal <i>removal installation</i> .....	83
<b>10 402 10</b>	Coolant pump <i>removal installation</i> .....	89
<b>10 402 30</b>	Cooling system thermostat .....	92
<b>10 206 14</b>	Bosch injection pump <i>removal installation</i> .....	95
	Bosch injection pump <i>timing</i> .....	98
	Bosch injection pump <i>air bleeding</i> .....	100
<b>10 218 30</b>	Injectors <i>removal installation</i> .....	101
<b>10 106 12</b>	Valve clearance adjustment .....	103
<b>10 402 28</b>	Coolant pump <i>overhaul</i> .....	106
<b>10 001 30</b>	Compression test .....	107

GENERAL SPECIFICATIONS	3 cylinders
<b>Engine type:</b>	
– mod. TD65F turbocharged – type TTF 8035.25F.939T (BOSCH pump) .....	see data pages 6
– mod. TD75F turbocharged – type TTF 8035.25G.939T (BOSCH pump) .....	see data pages 7
– mod. TD85F turbocharged – type TTF8035.25E.939T (BOSCH pump) .....	see data pages 8
Cycle .....	Diesel, 4-stroke
Fuel injection .....	Direct
Number of cylinders in line .....	3
Piston diameter	
– mod. TD65F .....	104 mm (4.0945 in.)
– mod. TD75F .....	104 mm (4.0945 in.)
– mod. TD85F .....	104 mm (4.0945 in.)
Piston stroke (All models) .....	115 mm (4.5276 in.)
Total displacement:	
– mod. TD65F–TD75F–TD85F .....	2931 cm <sup>3</sup> (178.8496 in. <sup>3</sup> )
Compression ratio .....	18 to 1 turbo- charged
Maximum power to spec ECE R120:	
– mod. TD65F at 2500 rpm .....	51 kW (69 hp)
– mod. TD75F at 2300 rpm .....	56 kW (76 hp)
– mod. TD85F at 2300 rpm .....	62 kW (84 hp)
Maximum power ECE R 24 at 2500 rpm:	
– mod. TD65F at 2500 rpm .....	48 kW (65 hp)
– mod. TD75F at 2300 rpm .....	53 kW (72 hp)
– mod. TD85F at 2300 rpm .....	59 kW (80 hp)
Fast idling speed:	
– mod. TD65F .....	2700 rpm
– mod. TD75F .....	2500 rpm
– mod. TD85F .....	2500 rpm
Maximum torque (Nm) at 1400 rpm: TD65F (ECE R24) .....	270
Maximum torque (Nm) at 1400 rpm: TD75F (ECE R24) .....	310
Maximum torque (Nm) at 1400 rpm: TD85F (ECE R24) .....	330
Number of main bearings .....	4
Sump .....	Structural, cast iron

(continued)

GENERAL SPECIFICATIONS	3 cylinders
<b>Lubrication</b> .....	forced, with gear pump
Pump drive .....	camshaft
Engine speed/oil pump speed ratio .....	2:1
Oil cleaning .....	mesh filter on oil intake and cartridge filter on delivery line
Normal oil pressure, with engine hot and at fast idling speed: ..	2.9 to 3.9 bar (42.06 to 56.56 psi)
Pressure relief valve .....	built into pump housing
Valve opening pressure .....	3.5 bar (50.76 psi)
For further lubrication data .....	See page 16
<b>Cooling system</b> .....	coolant circulation
Radiator on TD65F, TD75F and TD85F models .....	two-row vertical pipes with copper fins
Fan, attached to coolant pump pulley .....	ten-blade steel exhauster fan
Coolant pump .....	centrifugal vane-type
Engine speed/coolant pump speed ratio .....	1:1,403
Temperature control .....	Thermostat
Coolant temperature gauge .....	coloured scale divided into three sections
Temperature ranges corresponding to each section:	
– initial white section .....	from 30° to 65° C (86° to 149° F)
– middle green section .....	from 65° to 105° C (149° to 221° F)
– final red section .....	from 105° to 115° C (221° to 300.2° F)
For further cooling system data .....	See page 16
<b>Rev counter</b> .....	incorporated in control panel
Rev counter drive .....	from gear on camshaft
Hour counter calibrated for engine speed of .....	1800 rpm.

(Continued)

(continued)

GENERAL SPECIFICATIONS	3 cylinders
<b>Timing</b>	overhead valves operated by a camshaft located in the engine block through tappets, pushrods and rockers. Camshaft is driven by the crankshaft through helical gears.
Intake:	
– start: before T.D.C .....	12°
– end: after B.D.C .....	31°
Exhaust:	
– start: before B.D.C .....	50°
– end: after T.D.C .....	16°
Valve clearance for timing check .....	0.45 mm (0.0177 in.)
Valve clearance for normal running (engine cold):	
– intake .....	0.30 ± 0.05 mm (0.0118 ± 0.0020 in.)
– exhaust .....	0.30 ± 0.05 mm (0.0118 ± 0.0020 in.)
For further timing data .....	See page 13
<b>Fuel System</b>	
Air cleaning .....	dual cartridge dry air filter, with clogged filter indicator with centrifugal pre-filter and automatic dust ejector.
Fuel pump .....	with double diaphragm
Fuel filter .....	mesh filter in fuel supply pump, and replaceable cartridge on delivery line to injection pump.
Minimum fuel flow rate with pump shaft rotating at 1600 rev/min.	100 litres/hour
Operated by eccentric cam .....	on camshaft
BOSCH Injection pump .....	rotary distributor type
All-speed governor, incorporated in pump: BOSCH	centrifugal counterweights
Automatic advance regulator, incorporated in pump: BOSCH	hydraulic
For further fuel system data:	see pages 5 to 8
For fixed advance (pump setting for start of delivery before TDC) – Pressure setting – Injection order, and other information regarding the BOSCH pump	refer to the data for the relevant engine type in the tables from page 6 to page 8.

## DATA

Fuel injection pump .....	distributor type with incorporated speed governor and automatic advance regulator
BOSCH pump:	
– .... TD65F model .....	VE 3/12 F 1150 L-1118
– .... TD75F model .....	VE 3/12 F 1150 L 1089
– .... TD85F model .....	VE 3/12 F 1150 L 1089-1
Direction of rotation .....	anticlockwise
Injection order .....	1-2-3

Fuel injectors:	
BOSCH .....	
– Nozzle holder type .....	
– Nozzle type .....	
Number of nozzle holes .....	5
Diameter of nozzle orifices .....	
Pressure setting .....	248–272 bar (3596.9176–3945.0064 psi)

## TD65F Model – VE 3/12 F 1150 L-1118

## TEST SPECIFICATIONS FOR MECHANICALLY-GOVERNED DISTRIBUTOR PUMP

## ASSEMBLY DATA and DIMENSIONS

Pump timing on engine : Delivery start 0 ° before TDC of cylinder 1 compression stroke.

Plunger pre-lift for timing on engine: 1 mm from BDC Cyl. # 1 delivery line union on pump : marked by "A".

				Control lever shift spacing	
SYMBOL	SVS (max)	KF	MS	$Y_a$ (mm)/- $^0$ )	$Y_b$ (mm)/- $^0$ )
mm	–	–		37,5 ± 2,0	43,0 ± 4,0

## TEST CONDITIONS

Calibration nozzle and holder assy. : 1 688 901 027

Test fuel-injection tubing size :  $\varnothing_a$  6,0 x  $\varnothing_i$  2,0 x 450 mm

Calibrating-oil supply : ISONORM

Calibration-oil inlet pressure : 35,0 ± 5,0 kPa (0,35 +0,05 bar)

Calibration-oil overflow temperature : 55,0 ± 1,0 °C

Injector opening pressure: 250 ± 1 bar (25,0 ± 0,3 MPa or 254,93 ± 3,06 kgf/cm<sup>2</sup>).

Overflow restriction ( $\varnothing$ ): 0,55 mm

Test Point	Speed (min <sup>-1</sup> )	Tolerance	Delivery	LDA	ELAB (V)
<b>Pump overflow rate (litre / h)</b>					
USMO	1150	32,0 ± 20,0		1000	12
<b>Supply-pump pressure (MPa)</b>					
PSU	500	0,37 ± 0,08		1000	12
PSEP	1000	0,63 ± 0,08		1000	12
<b>Travel distance of plunger (mm) micrometer</b>					
SVEP	1000	1,3 ± 0,6		1000	12
SVO	1150	2,1 ± 0,5		1000	12
SVU	900	0,6 ± 0,5		1000	
<b>Full-load starting rate (mm<sup>3</sup>/h)</b>					
STAM	100	112,0 ± 20,0		0	12
<b>Full-load (mm<sup>3</sup>/h)</b>					
VEP	700	83,5 ± 2,5	≤ 2,5	1000	12
VEPM	600	80,5 ± 3,0		275	12
VEPU	600	73,0 ± 3,0		0	12
VO	1150	71,0 ± 3,5		1000	12
<b>Speed regulation breakaway (mm<sup>3</sup>/h)</b>					
AB1	1320	1,5 ± 1,5		1000	
<b>Idling speed (mm<sup>3</sup>/h)</b>					
LEP	300	10,0 ± 7,0	≤ 5,0	0	12
LK	400	1,5 ± 1,5		0	12
<b>Electric shut-off (mm<sup>3</sup>/h)</b>					
SPE1	300	1,5 ± 1,5	≤ 5,0	0	0
<b>LFB rate (mm<sup>3</sup>/h)</b>					
Q3	1000	45,0 ± 1,0		1000	12
Q4	1000	15,0 ± 1,0		1000	12
DQ2	1000	-13,5 ± 5,0		1000	12
<b>LFB travel distance of plunger (mm) micrometer</b>					
DS2	1000	-0,5 ± 0,1		1000	12
DS3	1000	-0,8 ± 0,4		1000	12
S4	1000	1,3 ± 0,6		1000	12

## TD75F Model – VE 3/12 F 1150 L 1089

## TEST SPECIFICATIONS FOR MECHANICALLY-GOVERNED DISTRIBUTOR PUMP

## ASSEMBLY DATA and DIMENSIONS

Pump timing on engine : Delivery start  $0^\circ \text{ to } 0^\circ$  before TDC of cylinder 1 compression stroke.

Plunger pre-lift for timing on engine: 1 mm from BDC Cyl. # 1 delivery line union on pump : marked by "A".

				Control lever shift spacing	
SYMBOL	SVS (max)	KF	MS	$Y_a$ (mm)/ $-0^\circ$	$Y_b$ (mm)/ $-0^\circ$
mm	–	–	–	$37.5 \pm 2.0$	$42.5 \pm 4.0$

## TEST CONDITIONS

Calibration nozzle and holder assy. : 1 688 901 027  
Test fuel-injection tubing size :  $\text{Ø}_a$  6.0 x  $\text{Ø}_i$  2.0 x 450 mm

Calibrating-oil supply : ISONORM

Calibration-oil inlet pressure : 35.0  $\pm$  5.0 kPa (0.35 +0.05 bar)

Calibration-oil overflow temperature : 55.0  $\pm$  1.0 °C

Injector opening pressure: 250  $\pm$  1 bar (25.0  $\pm$  0.3 MPa or 254.93  $\pm$  3.06 kgf/cm<sup>2</sup>).

Overflow restriction ( $\text{Ø}$ ): 0.75 mm

Test Point	Speed (min <sup>-1</sup> )	Tolerance	Delivery	LDA	ELAB (V)
<b>Pump overflow rate (litre / h)</b>					
USMO	1150	$59.0 \pm 12.0$		1000	12
<b>Supply-pump pressure (MPa)</b>					
PSU	500	$0.50 \pm 0.08$		1000	12
PSEP	1150	$0.84 \pm 0.08$		1000	12
<b>Travel distance of plunger (mm) micrometer</b>					
SVEP	1150	$1.4 \pm 0.6$		1000	12
SVU	1030	$0.6 \pm 0.5$		1000	12
<b>Full-load starting rate (mm<sup>3</sup>/h)</b>					
STAM	100	$85.0 \pm 20.0$		0	12
<b>Full-load (mm<sup>3</sup>/h)</b>					
VEP	700	$88.0 \pm 2.5$	$\leq 3.5$	1000	12
VEPM	600	$76.0 \pm 3.0$		300	12
VEPU	600	$64.5 \pm 3.0$		0	12
VO	1150	$74.5 \pm 3.0$		1000	12
<b>Speed regulation breakaway (mm<sup>3</sup>/h)</b>					
AB1	1280	$1.5 \pm 1.5$		1000	12
<b>Idling speed (mm<sup>3</sup>/h)</b>					
LEP	300	$17.5 \pm 7.0$	$\leq 5.0$	0	12
LK	375	$1.5 \pm 1.5$		0	12
<b>Electric shut-off (mm<sup>3</sup>/h)</b>					
SPE1	300	$1.5 \pm 1.5$	$\leq 5.0$	0	0
<b>LFB rate (mm<sup>3</sup>/h)</b>					
Q3	1150	$42.5 \pm 1.0$		1000	12
Q4	1150	$25.0 \pm 1.0$		1000	12
DQ2	1150	$-11.0 \pm 5.0$		1000	12
<b>LFB travel distance of plunger (mm) micrometer</b>					
DS2	1150	$-0.4 \pm 0.1$		1000	12
DS3	1150	$-0.8 \pm 0.4$		1000	12
S4	1150	$1.6 \pm 0.6$		1000	12

## TD85F Model – VE 3/12 F 1150 L 1089–1

## TEST SPECIFICATIONS FOR MECHANICALLY-GOVERNED DISTRIBUTOR PUMP

## ASSEMBLY DATA and DIMENSIONS

Pump timing on engine : Delivery start  $0 \pm 0.0^0$  before TDC of cylinder 1 compression stroke.

Plunger pre-lift for timing on engine: 1 mm from BDC  
Cyl. # 1 delivery line union on pump : marked by "A".

				Control lever shift spacing	
SYMBOL	SVS (max)	KF	MS	$Y_a$ (mm)/ $-0^0$	$Y_b$ (mm)/ $-0^0$
mm	–	–		$37,5 \pm 2,0$	$43,0 \pm 4,0$

## TEST CONDITIONS

Calibration nozzle and holder assy. : 1 688 901 027

Test fuel-injection tubing size :  $\varnothing_a$  6.0 x  $\varnothing_i$  2.0 x 450 mm

Calibrating-oil supply : ISONORM

Calibration-oil inlet pressure : 35.0  $\pm$  5.0 kPa (0.35 +0.05 bar)

Calibration-oil overflow temperature : 55.0  $\pm$  1.0 °C

Injector opening pressure: 250  $\pm$  1 bar (25.0  $\pm$  0.3 MPa or 254.93  $\pm$  3.06 kgf/cm<sup>2</sup>).

Overflow restriction ( $\varnothing$ ): 0.75 mm

Test Point	Speed (min <sup>-1</sup> )	Tolerance	Delivery	LDA	ELAB (V)
<b>Pump overflow rate (litre / h)</b>					
USMO	1050	$59,0 \pm 12,0$		1000	12
<b>Supply-pump pressure (MPa)</b>					
PSU	500	$0,81 \pm 0,08$		1000	12
PSEP	1050	$0,53 \pm 0,08$		1000	12
<b>Travel distance of plunger (mm) micrometer</b>					
SVEP	1050	$1,0 \pm 0,6$		1000	12
SVU	1150	$2,0 \pm 0,5$		1000	12
<b>Full-load starting rate (mm<sup>3</sup>/h)</b>					
STAM	100	$110,0 \pm 20,0$		0	12
<b>Full-load (mm<sup>3</sup>/h)</b>					
VEP	700	$95,0 \pm 2,5$	$\leq 3,5$	1000	12
VEPM	600	$84,5 \pm 3,0$		300	12
VEPU	600	$73,0 \pm 3,0$		0	12
VO	1150	$81,0 \pm 3,0$		1000	12
<b>Speed regulation breakaway (mm<sup>3</sup>/h)</b>					
AB1	1320	$1,5 \pm 1,5$		1000	12
<b>Idling speed (mm<sup>3</sup>/h)</b>					
LEP	325	$12,5 \pm 7,0$	$\leq 5,0$	0	12
LK	380	$1,5 \pm 1,5$		0	12
<b>Electric shut-off (mm<sup>3</sup>/h)</b>					
SPE1	325	$1,5 \pm 1,5$	$\leq 5,0$	0	0
<b>LFB rate (mm<sup>3</sup>/h)</b>					
Q3	1050	$55,0 \pm 1,0$		1000	12
Q4	1050	$30,0 \pm 1,0$		1000	12
DQ2	1050	$-11,0 \pm 5,0$		1000	12
<b>LFB travel distance of plunger (mm) micrometer</b>					
DS2	1050	$-0,4 \pm 0,1$		1000	12
DS3	1050	$-0,8 \pm 0,4$		1000	12
S4	1050	$1,3 \pm 0,6$		1000	12

FUEL SUPPLY PUMP DATA	mm (in.)
Eccentricity of drive shaft .....	3 (0.1181)
Diameter of drive shaft at bushings .....	31.975 to 32.000 (1.1049 to 1.1050)
Internal diameter of installed and reamed bushings .....	32.050 to 32.075 (1.2589 to 1.2628)
Interference between bushings and seats .....	0.063 to 0.140 (0.0025 to 0.0055)
Assembly clearance between shaft and bushings .....	0.050 to 0.100 (0.0020 to 0.0039)
Thickness of internal washer .....	1.45 to 1.50 (0.0571 to 0.0591)
Thickness of external washer .....	2.93 to 3.00 (0.1154 to 0.1181)

CRANKCASE/CYLINDER BLOCK DATA	mm (in.)
Diameter of main shell bearing seats .....	84.200 to 84.230 (3.3150 to 3.3161)
Diameter of camshaft bearing seats:	
– front .....	54.780 to 54.805 (2.1567 to 2.1577)
– middle .....	54.280 to 54.305 (2.1370 to 2.1380)
– rear .....	53.780 to 53.805 (2.1173 to 2.1183)
Diameter of standard tappet bores in crankcase .....	15.000 to 15.018 (0.5906 to 0.5913)
Spare tappet oversizes .....	0.1–0.2–0.3 (0.0039–0.0079–0.0118)

<sup>(1)</sup> Measured after press-fitting and reaming.

<sup>(2)</sup> Measure in the area swept by piston rings, both parallel and perpendicular to the crankshaft axis.

CRANKSHAFT AND BEARINGS DATA	mm (in.)
Crankshaft .....	balanced with integral counterweights
Standard journal diameter .....	79.791 to 79.810 (3.1414 to 3.1421) (1)
Journal undersizes .....	0.254 – 0.508 – 0.762 – 1.016 (0.01 – 0.02 – 0.03 – 0.04)
Standard main bearing shell thickness .....	2.168 to 2.178 (0.0854 to 0.0857)
Main bearing shell undersizes (internal diameter) .....	0.254 – 0.508 – 0.762 – 1.016 (0.01 – 0.02 – 0.03 – 0.04)
Bearing shell to journal clearance .....	0.034 to 0.103 (0.0013 to 0.0041)
Maximum permitted wear clearance .....	0.180 (0.0071)
Standard crankpin diameter .....	63.725 to 63.744 (2.5089 to 2.5096) (1)
Crankpin undersizes .....	0.254 – 0.508 – 0.762 – 1.016 (0.01 – 0.02 – 0.03 – 0.04)
Standard big-end bearing shell thickness .....	1.805 to 1.815 (0.0711 to 0.0715)
Big-end bearing shell undersizes (internal diameter) .....	0.254 – 0.508 – 0.762 – 1.016 (0.01 – 0.02 – 0.03 – 0.04)
Big-end bearing shell to crankpin clearance .....	0.033 to 0.087 (0.0013 to 0.0034)
Maximum permitted wear clearance .....	0.180 (0.0071)
Standard crankshaft thrust washer thickness .....	3.378 to 3.429 (0.133 to 0.135)
Thrust washer oversizes (thickness) .....	0.127 – 0.254 – 0.381 – 0.508 (0.005 – 0.010 – 0.015 – 0.020)
Width of main bearing including thrust washers .....	31.766 to 31.918 (1.2506 to 1.2566)
Width of corresponding crankshaft journal .....	32.000 to 32.100 (1.2598 to 1.2638)
Crankshaft assembly endfloat .....	0.082 to 0.334 (0.0032 to 0.0131)
Maximum permitted wear endfloat .....	0.40 (0.0157)
Maximum ovality or taper of journals and crankpin after regrinding .....	0.01 (0.0004)
Maximum ovality or taper of journals and crankpin .....	0.05 (0.002)
Maximum tolerance for alignment of crankshaft journals with crankshaft supported on the two outer journals .....	0.10 (0.0039)
Maximum tolerance for alignment, in both directions, of crankpins (3-cylinder engines) .....	0.25 (0.0098)
Maximum tolerance for run-out between the outer surfaces of the crankshaft journals and the crankshaft centreline .....	± 0.10 (0.004)

(continued)

(1) Crankshafts with 0.1 mm (0.0039 in.) undersize journals and crankpins and consequently undersize bearing shells may be fitted in factory production.

(continued)

BENCH TEST PERFORMANCE DATA	mm (in.)
Maximum permitted tolerance on run-out of flywheel mounting flange surface relative to the crankshaft centreline, measured with 1/100 mm (0.0394/3.94 in.) scale dial gauge resting on front flange surface at a diameter of 108 mm (4.252 in.) (total gauge reading) .....	0.025 (0.001)
Maximum permitted tolerance on co-axial alignment of flywheel centering seat relative to the crankshaft journals (total gauge reading) .....	0.04 (0.0016)

CONNECTING ROD DATA	mm (in.)
Connecting Rods .....	cast-iron with oil way
Diameter of small end bushing seat .....	41.846 to 41.884 (1.6475 to 1.6490)
Outside diameter of small end bushing .....	41.979 to 42.017 (1.6527 to 1.6542)
Interference between small end bushing and seat .....	0.095 to 0.171 (0.0037 to 0.0067)
Inside diameter of small end bushing (measured after fitting) ...	38.004 to 38.014 (1.4962 to 1.4966)
Diameter of big end shell bearing seats .....	67.407 to 67.422 (2.6538 to 2.6544)
Maximum tolerance for parallelism between the small end and big end axes measured at 25 mm (0.9843 in.) .....	± 0.07 (0.0028)
Maximum weight difference between con rods in same engine ..	25 grams (0.0551 lb)

<b>PISTON DATA</b>	<b>mm (in.)</b>
	<b>TD65F, TD75F, TD85F</b>
Pistons .....	Light alloy with two compression and one oil control rings
Standard piston diameter, measured at 57 mm (2.2441 in.) from base and perpendicularly to the gudgeon pin axis .....	103.852 to 103.870 (4.0886 to 4.0893)
Piston clearance in cylinder liner .....	0.130 to 0.172 (0.0051 to 0.0067)
Maximum permitted wear clearance .....	0.30 (0.0118)
Piston oversizes .....	0.6 (0.0236)
Piston protrusion at TDC from cylinder block face .....	0.355 to 0.761 (0.014 to 0.030)
Gudgeon Pin Diameter .....	37.983 to 37.990 (1.4954 to 1.4957)
Diameter of gudgeon pin seat in piston .....	37.994 to 38.000 (1.4958 to 1.4960)
Gudgeon pin to seat clearance .....	0.004 to 0.017 (0.0001 to 0.0007)
Gudgeon pin to small end bearing clearance .....	0.014 to 0.031 (0.0006 to 0.0012)
Maximum permitted wear clearance .....	0.06 (0.0024)
Maximum weight difference between pistons in same engine .....	20 grams (0.00441 lb)
Maximum permissible clearance (wear limit):	
– Top .....	0.50 (0.0197)
– Second and bottom .....	0.20 (0.0079)
Piston ring end gap (fitted):	
– Top .....	0.40 to 0.65 (0.0157 to 0.0256)
– Second .....	0.30 to 0.55 (0.0118 to 0.0217)
– Bottom .....	0.30 to 0.55 (0.0118 to 0.0217)
Maximum permissible gap (wear limit) .....	1.20 (0.0472)

VALVE TIMING GEAR DATA	mm (in.)
Timing gear tooth backlash .....	0.160 (0.0063)
Inside diameter of intermediate gear bushings (fitted and reamed) .....	37.050 to 37.075 (1.4578 to 1.4596)
Diameter of intermediate gear journal .....	36.975 to 37.000 (1.4557 to 1.4567)
Journal to bushing clearance .....	0.050 to 0.100 (0.0020 to 0.0039)
Maximum permissible clearance (wear limit) .....	0.15 (0.0059)
Bushing interference fit in seat in intermediate gear .....	0.063 to 0.140 (0.0025 to 0.0055)
Outside diameter of camshaft bearings:	
– front .....	54.875 to 54.930 (2.1604 to 2.1626)
– middle .....	54.375 to 54.430 (2.1407 to 2.1429)
– rear .....	53.875 to 53.930 (2.1175 to 2.1232)
Interference between bearings and seats in cylinder block .....	0.070 to 0.150 (0.0028 to 0.0059)
Inside diameter of camshaft bearings (fitted and reamed):	
– front .....	51.080 to 51.130 (2.0110 to 2.0130)
– middle .....	50.580 to 50.630 (1.9913 to 1.9933)
– rear .....	50.080 to 50.130 (1.9716 to 1.9736)
Diameter of camshaft journals:	
– front .....	50.970 to 51.000 (2.0067 to 2.0079)
– middle .....	50.470 to 50.500 (1.9870 to 1.9882)
– rear .....	49.970 to 50.000 (1.9913 to 1.9933)
Clearance between camshaft journals and bearings .....	0.080 to 0.160 (0.0031 to 0.0063)
Maximum permissible clearance (wear limit) .....	0.20 (0.0079)
Camshaft endfloat between thrust plate and seat on camshaft .....	0.070 to 0.220 (0.0028 to 0.0087)
For further valve timing gear data .....	See page 4

TAPPET DATA	mm (in.)
Tappet bore in crankcase .....	15.000 to 15.018 (0.5906 to 0.5913)
Outside diameter of standard tappet .....	14.950 to 14.970 (0.5886 to 0.5894)
Tappet running clearance .....	0.030 to 0.068 (0.0012 to 0.0027)
Maximum permissible clearance (wear limit) .....	0.15 (0.0059)
Spare tappet oversizes .....	0.1 – 0.2 – 0.3 (0.0039–0.0079–0.0118)

ROCKER ARM – VALVE DATA	mm (in.)
Diameter of shaft bores in rocker arms .....	18.016 to 18.034 (0.7093 to 0.71)
Rocker-arm shaft diameter .....	17.982 to 18.000 (0.708 to 0.7087)
Rocker shaft to rocker arm bore clearance .....	0.016 to 0.052 (0.0006 to 0.0020)
Maximum permissible clearance (wear limit) .....	0.15 (0.0059)
Rocker arm spacing springs:	
– free spring length .....	59.5 (2.3425)
– length under load of 46 to 52 N (10.4 to 11.7 lb) .....	44 (1.7323)
Valve clearance for timing check .....	0.45 (0.0177)
Cam lift:	
– inlet valve .....	5.97 (0.2350)
– exhaust valve .....	6.25 (0.2460)

CYLINDER HEAD DATA	mm (in.)
Cylinder Head .....	with valve seats cut directly in the casting and press-fitted steel valve guides.
Original height of cylinder head .....	92 (3.622)
Maximum surface regrinding depth .....	0.5 (0.0197)
Diameter of standard valve guide bores in head .....	13.950 to 13.983 (0.5492 to 0.5505)
Outside diameter of standard valve guides .....	13.993 to 14.016 (0.5509 to 0.5518)
Guide interference fit in bores .....	0.010 to 0.066 (0.0004 to 0.0026)
Inside diameter of valve guide (fitted in head) .....	8.023 to 8.043 (0.3159 to 0.3167)
Valve stem diameter .....	7. 985 to 8.000 (0.3144 to 0.3150)
Assembly clearance between valve stem and guide .....	0.023 to 0.058 (0.0009 to 0.0023)
Maximum permissible clearance (wear limit) .....	0.13 (0.0051)
Maximum run-out of valve guide on its stem measured through 360° with dial gauge contact point resting on valve head contact band .....	0.03 (0.0012)
Valve guide oversizes .....	0.2 (0.0079)
Valve seat angle in head:	
– inlet valve .....	60° ± 5'
– exhaust valve .....	45° ± 5'
Valve face angle:	
– inlet valve .....	60° 30' ± 7'
– exhaust valve .....	45° 30' ± 7'
Valve head diameter:	
– inlet valve .....	45.300 to 45.500 (1.7835 to 1.7913)
– exhaust valve .....	37.500 to 37.750 (1.4764 to 1.4862)
Valve stand-in relative to cylinder head face .....	0.7 to 1.0 (0.0276 to 0.0394)
Maximum permissible valve stand-in .....	1.3 (0.0512)
Inlet and exhaust valve springs:	
– free spring length .....	4.6 (1.7559)
– length with valve closed, under load of 256 to 284 N (57.54 to 63.71 lb) .....	34 (1.3386)
– length with valve open, under load of 502 to 544 N (112.87 to 124.78 lb) .....	23.8 (0.9370)
Injector protrusion relative to head face:	
● BOSCH injector	0.3 to 1.1 (0.0118 to 0.0433)