

Product: New Holland L865/Lx865/Lx885/Lx985 Skid-Steer Loader Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-l865-lx865-lx885-lx985-skid-steer-loader-service-repair-manual/>

65-lx885-lx985-skid-steer-loader-service-repair-manual/

**Please cut where indicated and insert the label into the plastic pocket on the spine of the binder.**



**SKID-STEER  
LOADER  
REPAIR**

**L865, Lx865, Lx885,  
Lx985**

**Vol. 1  
86584316**



**SKID-STEER  
LOADER  
REPAIR**

**L865, Lx865, Lx885,  
Lx985**


**Vol. 1  
86584316**



Product: New Holland L865/Lx865/Lx885/Lx985 Skid-Steer Loader Service Repair Manual

Full Download: <https://www.aresairmanual.com/downloads/new-holland-l865-lx865-lx885-lx985-skid-steer-loader-service-repair-manual/>

65-lx885-lx985-skid-steer-loader-service-repair-manual/



# NEW HOLLAND

## L865 Lx865

## Lx885 Lx985

### Section 1 - General Information

# REPAIR MANUAL



NEW HOLLAND

**SERVICE**

Sample of manual. Download All 1000 pages at:

<https://www.aresairmanual.com/downloads/new-holland-l865-lx865-lx885-lx985-skid-steer-loader-service-repair-manual/>

86584317\_1/99

# **L865, Lx865, Lx885, Lx985 SKID-STEER LOADER REPAIR MANUAL CONTENTS**



## **SECTION 1 - GENERAL INFORMATION**

**SECTION 2 - ENGINE**

**SECTION 3 - ELECTRICAL SYSTEM**

**SECTION 4 - FINAL DRIVE, AXLES, BRAKES, GEARBOXES**

**SECTION 5 - HYDROSTATIC SYSTEM AND STEERING SYSTEM**

**SECTION 6 - HYDRAULIC SYSTEM**

**SECTION 7 - SEAT, CAB, ROPS, BOOM LOCK, BOOM,  
ATTACHMENT MOUNTING PLATE**

**SECTION 8 - OPTIONAL EQUIPMENT**

---

# SECTION 1

## GENERAL INFORMATION

### CONTENTS

|  |             |
|--|-------------|
| <b>INTRODUCTION .....</b>  | <b>1-2</b>  |
| <b>IMPROVEMENTS .....</b>  | <b>1-2</b>  |
| <b>PRECAUTIONARY STATEMENTS .....</b>                            | <b>1-3</b>  |
| <b>PERSONAL SAFETY .....</b>                                     | <b>1-3</b>  |
| <b>MACHINE SAFETY .....</b>                                      | <b>1-3</b>  |
| <b>SAFETY PRECAUTIONS .....</b>                                  | <b>1-4</b>  |
| <b>SAFETY DECALS .....</b>                                       | <b>1-7</b>  |
| <b>GENERAL SAFETY INFORMATION .....</b>                          | <b>1-11</b> |
| <b>MODEL AND SERIAL NUMBER LOCATION .....</b>                    | <b>1-14</b> |
| <b>MINIMUM HARDWARE TIGHTENING TORQUES, INCH .....</b>           | <b>1-15</b> |
| <b>MINIMUM HARDWARE TIGHTENING TORQUES, METRIC .....</b>         | <b>1-16</b> |
| <b>HYDRAULIC TUBE AND FITTING INFORMATION .....</b>              | <b>1-17</b> |
| <b>PROPERLY SUPPORTING A RAISED MACHINE .....</b>                | <b>1-18</b> |
| <b>PROPERLY SUPPORT BOOM ON BOOM LOCK PINS .....</b>             | <b>1-18</b> |
| <b>MAJOR UNIT OVERHAUL .....</b>                                 | <b>1-18</b> |
| <b>CAB TILTING PROCEDURE .....</b>                               | <b>1-19</b> |
| <b>TILTING CAB AND BOOM BACK ON FRAME .....</b>                  | <b>1-24</b> |
| <b>CRANING THE SKID-STEER LOADER .....</b>                       | <b>1-26</b> |
| <b>DRILLING HOLES IN OVERHEAD DASH .....</b>                     | <b>1-28</b> |
| <b>ADAPTING ATTACHMENTS REQUIRING 12V ELECTRICAL POWER .....</b> | <b>1-29</b> |
| <b>HYDRAULIC SYSTEM COMPATIBILITY .....</b>                      | <b>1-31</b> |
| <b>ACCESSORY RELAY AND ENGINE FUSE BLOCK .....</b>               | <b>1-32</b> |
| <b>SPECIFICATIONS L865, Lx865, Lx885 .....</b>                   | <b>1-33</b> |
| <b>SPECIFICATIONS Lx985 .....</b>                                | <b>1-38</b> |
| <b>INDEX .....</b>   | <b>1-43</b> |

## INTRODUCTION

This service manual provides the technical information needed to properly service and maintain the Models L865, Lx865, Lx885, and Lx985 skid-steer loaders. Use it in conjunction with the operator's manual which is supplied with the loader. Keep both manuals available for ready reference.

The L\_ \_ \_ designates a factory standard built unit.

The Lx\_ \_ \_ designates a factory Deluxe built unit. Factory options installed include work lights, taillights, and auxiliary boom hydraulics.

The L865, Lx865, Lx885, and Lx985 have many similarities with the major difference being a two-speed hydrostatic motor used on the Lx885 and Lx985.

The L865, Lx865, Lx885 loaders are equipped with the 332T non-emissionized or the 332T/JF emissionized three-cylinder 60 net horsepower turbocharged engine.

The Lx985 is equipped with the 450/NC emissionized four cylinder 75 net horsepower naturally aspirated engine.

Whenever working on New Holland equipment, left and right sides of the machine are determined by standing behind the unit, looking in the direction of travel.

The easiest and least time-consuming removal, disassembly, and reassembly procedure are detailed in the manual. Modifying these procedures is not recommended.

New Holland skid-steer loaders are designed with emphasis on safety for operator protection. However, careless and negligent operation can still result in serious injury to persons or property. Be sure to read and follow all safety instructions in this manual.

Your New Holland dealer is interested in your obtaining the most from your investment and will be glad to answer any questions you may have about your loader. When major service is required, your dealer's staff of trained service technicians is ready to serve you.

When in need of parts, always order genuine New Holland service parts from your New Holland dealer. Be prepared to give your dealer the model and serial number of the engine and loader (the location of these numbers is described later in this section). Record the serial numbers here.

Loader Model \_\_\_\_\_

Loader Serial Number \_\_\_\_\_

Engine Model \_\_\_\_\_

Engine Serial Number \_\_\_\_\_



**CAUTION: THIS SYMBOL IS USED THROUGHOUT THIS BOOK WHENEVER YOUR OWN PERSONAL SAFETY IS INVOLVED. TAKE TIME TO BE CAREFUL!**

## IMPROVEMENTS

New Holland is continually striving to improve its products. We must, therefore, reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

## **PRECAUTIONARY STATEMENTS**

### **PERSONAL SAFETY**

Throughout this manual and on machine decals, you will find precautionary statements (“CAUTION”, “WARNING”, and “DANGER”) followed by specific instructions. These precautions are intended for the personal safety of you and those working with you. Please take the time to read them.



**CAUTION: THE WORD “CAUTION” IS USED WHERE A SAFE BEHAVIORAL PRACTICE ACCORDING TO OPERATING AND MAINTENANCE INSTRUCTIONS AND COMMON SAFETY PRACTICES WILL PROTECT THE OPERATOR AND OTHERS FROM ACCIDENT INVOLVEMENT.**



**WARNING: THE WORD “WARNING” DENOTES A POTENTIAL OR HIDDEN HAZARD WHICH HAS A POTENTIAL FOR SERIOUS INJURY. IT IS USED TO WARN OPERATORS AND OTHERS TO EXERCISE EVERY APPROPRIATE MEANS TO AVOID A SURPRISE INVOLVEMENT WITH MACHINERY.**



**DANGER: THE WORD “DANGER” DENOTES A FORBIDDEN PRACTICE IN CONNECTION WITH A SERIOUS HAZARD.**

**FAILURE TO FOLLOW THE “CAUTION”, “WARNING”, AND “DANGER” INSTRUCTIONS MAY RESULT IN SERIOUS BODILY INJURY OR DEATH.**

### **MACHINE SAFETY**

Additional precautionary statements (“ATTENTION” and “IMPORTANT”) are followed by specific instructions. These statements are intended for machine safety.

*ATTENTION: The word “ATTENTION” is used to warn the operator of potential machine damage if a certain procedure is not followed.*

*IMPORTANT: The word “IMPORTANT” is used to inform the reader of something he needs to know to prevent minor machine damage if a certain procedure is not followed.*



## **SAFETY PRECAUTIONS**

**UNSAFE OPERATING PRACTICES AND IMPROPER USE OF THE SKID-STEER LOADER AND ITS ATTACHMENTS ON THE PART OF THE OPERATOR CAN RESULT IN INJURIES. OBSERVE THE FOLLOWING SAFETY PRECAUTIONS AT ALL TIMES:**

- 1. FOR SERVICING, THE LOADER SHOULD BE ON LEVEL TERRAIN, ENGINE STOPPED WITH THE WHEELS BLOCKED OR THE ENTIRE LOADER SOLIDLY SUPPORTED WITH THE WHEELS OFF THE GROUND BEFORE SERVICING ANY COMPONENT OF THE DRIVETRAIN.**
- 2. FOR SERVICING UNDER THE OPERATOR'S SEAT, RAISE THE SEAT AND PAN ASSEMBLY UP TO THE RAISED LATCHED POSITION AND SECURELY LATCH.**
- 3. DO NOT OPERATE THE LOADER UNLESS THE SEAT IS LATCHED IN THE OPERATE POSITION.**
- 4. DO NOT SERVICE THE LOADER WITH A RAISED BOOM UNLESS THE BOOM IS RESTING ON THE BOOM LOCK PINS.**
- 5. DO NOT SERVICE THE LOADER WITH THE ENGINE RUNNING UNLESS THE LOADER IS PROPERLY AND SECURELY SUPPORTED WITH ALL FOUR WHEELS OFF THE GROUND.**
- 6. USE CAUTION WHEN SERVICING THE UNIT AROUND MOVING PARTS.**
- 7. DO NOT TILT THE BOOM AND CAB WITHOUT PROPER INSTRUCTION.**
- 8. DO NOT TILT THE BOOM AND CAB WITHOUT USING THE PROPER CAB TILTING TOOL.**
- 9. REINSTALL ALL SHIELDS REMOVED FOR SERVICE.**
- 10. NEVER LOOSEN ANY HYDRAULIC CONNECTIONS BEFORE RELIEVING THE PRESSURE IN THE HYDRAULIC SYSTEM.**
- 11. WEAR EYE PROTECTION SUCH AS GOGGLES, ETC.**
- 12. WEAR EAR PROTECTION SUCH AS EAR PLUGS, ETC. WHEN YOU FEEL THE NOISE LEVEL IS UNCOMFORTABLE.**
- 13. IF ANY SERVICING OR ADJUSTMENTS REQUIRE THE BATTERY TO BE DISCONNECTED, DISCONNECT THE (-) NEGATIVE GROUND CABLE.**
- 14. WHEN SERVICING ELECTRICAL COMPONENTS, DISCONNECT THE (-) NEGATIVE GROUND CABLE.**
- 15. IF THE ELECTRONIC INSTRUMENT CLUSTER (EIC) REQUIRES REMOVAL FROM THE DASH AREA OR THE SKID-STEER LOADER DISCONNECT THE (-) NEGATIVE GROUND BATTERY CABLE. THIS WILL SHUT OFF POWER TO THE EIC AND PREVENT DAMAGE TO THE EIC BOARD OR BLOWING THE 5-AMP FUSES IF THE BOARD IS ACCIDENTALLY GROUNDED.**
- 16. IF WELDING IS REQUIRED ON THE SKID-STEER LOADER, DISCONNECT THE (-) NEGATIVE GROUND CABLE. FAILURE TO DISCONNECT THE BATTERY MAY RESULT IN DAMAGE TO THE EIC (ELECTRONIC INSTRUMENT CLUSTER) MONITORING SYSTEM AND OTHER ELECTRICAL COMPONENTS.**
- 17. IF WELDING IS REQUIRED ON AN ATTACHMENT, REMOVE THE ATTACHMENT FROM THE SKID-STEER LOADER.**

18. **GIVE COMPLETE AND UNDIVIDED ATTENTION TO THE JOB AT HAND SO THAT COMPLETE CONTROL OF THE LOADER IS MAINTAINED AT ALL TIMES.**
19. **DRIVE SLOWLY OVER ROUGH GROUND AND ON SLOPES; KEEP ALERT FOR HOLES, DITCHES AND OTHER IRREGULARITIES THAT MAY CAUSE THE LOADER TO OVERTURN.**
20. **AVOID STEEP HILLSIDE OPERATION WHICH COULD CAUSE THE LOADER TO OVERTURN.**
21. **NEVER TRANSPORT A LOADED BUCKET AT FULL HEIGHT. OPERATE THE LOADER WITH THE LOAD AS LOW AS POSSIBLE UNTIL IT BECOMES NECESSARY TO RAISE THE BOOM TO DISCHARGE THE LOAD INTO A TRUCK, CONTAINER, ETC.**
22. **REDUCE SPEED WHEN TURNING SO THERE IS NO DANGER OF THE LOADER OVERTURNING.**
23. **NEVER DRIVE UP OR BACK UP A HILL OR INCLINE WITH A RAISED BOOM OR THE LOADER COULD OVER TURN.**
24. **ALWAYS LOOK BEHIND YOU BEFORE BACKING THE LOADER.**
25. **MAINTAIN PROPER TRANSMISSION OIL LEVEL TO PREVENT LOSS OF HYDROSTATIC BRAKING.**
26. **DO NOT ALLOW PASSENGERS TO RIDE ON THE LOADER AT ANY TIME.**
27. **DO NOT ALLOW CHILDREN TO OPERATE THE LOADER OR RIDE ON THE LOADER AT ANY TIME.**
28. **DO NOT ALLOW ANYONE TO OPERATE THE LOADER WITHOUT PROPER INSTRUCTION.**  
**OSHA REQUIRES THAT ALL OPERATORS BE INSTRUCTED ON THE PROPER OPERATION OF THE MACHINE BEFORE THEY OPERATE THE UNIT.**
29. **DO NOT OPERATE THE LOADER IN ANY POSITION OTHER THAN WHILE IN THE OPERATOR'S SEAT WITH THE SEAT BELT SECURELY FASTENED.**
30. **BEFORE STARTING THE ENGINE, BE SURE THAT ALL OPERATING CONTROLS ARE IN NEUTRAL AND THE PARKING BRAKE IS ENGAGED.**
31. **NEVER OPERATE THE LOADER ENGINE IN A CLOSED BUILDING WITHOUT ADEQUATE VENTILATION.**
32. **REFUEL THE LOADER OUTDOORS WITH THE ENGINE SHUT OFF. REPLACE THE FUEL CAP SECURELY. USE AN APPROVED FUEL CONTAINER. DO NOT SMOKE WHEN HANDLING FUEL. AVOID SPILLING FUEL.**
33. **AFTER OPERATING THE ENGINE, NEVER TOUCH THE MUFFLER, EXHAUST PIPE, ENGINE OR RADIATOR UNTIL THEY HAVE HAD TIME TO COOL.**
34. **DRESS APPROPRIATELY - WEAR RELATIVELY TIGHT-FITTING CLOTHING WHEN OPERATING THE LOADER. LOOSE OR TORN CLOTHING CAN CATCH IN MOVING PARTS OR CONTROLS.**
35. **BEFORE SERVICING THE LOADER OR ANY OF ITS ATTACHED EQUIPMENT, BE SURE THAT THE ATTACHMENTS ARE LOWERED TO THE GROUND OR THAT THE BOOM ARMS ARE SUPPORTED BY THE BOOM LOCK PINS.**
36. **DO NOT WORK UNDER OVERHANGS, ELECTRIC WIRES, OR WHERE THERE IS DANGER OF A SLIDE.**
37. **WEAR AN APPROVED SAFETY HAT WHEN OPERATING THE MACHINE AND WHILE IN ANY WORK AREA.**

38. WHEN DRIVING THE LOADER ON A ROAD OR HIGHWAY, USE WARNING LIGHTS OR WARNING DEVICES AS MAY BE REQUIRED BY LOCAL OR STATE GOVERNMENT REGULATIONS. HEADLIGHTS, WARNING LIGHTS AND SMV SIGNS ARE AVAILABLE THROUGH YOUR NEW HOLLAND DEALER.
39. KEEP THE LOADER CLEAN. DO NOT ALLOW TRASH, DEBRIS OR OTHER ARTICLES TO ACCUMULATE IN THE CAB, FLOOR OR FOOT CONTROL PEDAL AREA THAT MAY HINDER SAFE MACHINE OPERATION.
40. NEVER OPERATE THE LOADER WITH ANY OF THE SHIELDING REMOVED.
41. NEVER OPERATE THE LOADER WITHOUT WINDOWS AND/OR SCREENS IN PLACE.
42. NEVER EXTEND ANY PART OF THE BODY OUTSIDE OF THE OPERATOR'S AREA.
43. ALWAYS PROPERLY TIE DOWN THE SKID-STEER LOADER TO A TRUCK OR TRAILER BEFORE TRANSPORT.
44. MAKE SURE ALL BYSTANDERS ARE AT A SAFE DISTANCE AWAY FROM THE LOADER BEFORE STARTING THE ENGINE.
45. DO NOT ALLOW ANYONE NEAR THE LOADER WHILE THE ENGINE IS RUNNING AND THE LOADER IS OPERATIONAL.
46. WHEN USING THE SKID-STEER LOADER TO CRANE OBJECTS, DO NOT ALLOW ANY PERSON TO RIDE ON OBJECTS BEING CRANED.
47. DO NOT USE THE SKID-STEER LOADER AS A WORK PLATFORM FOR SUPPORTING MATERIALS.
48. DO NOT LIFT PERSONNEL OR ALLOW PERSONNEL TO WORK WHILE STANDING IN THE BUCKET OR ON OTHER ATTACHMENTS. THIS IS NOT A MAN-LIFT.

OSHA REQUIREMENTS NOW MAKE IT THE EMPLOYER'S RESPONSIBILITY TO FULLY INSTRUCT EACH OPERATOR IN THE PROPER AND SAFE OPERATION OF ALL OPERATIVE EQUIPMENT. BOTH EMPLOYER AND EMPLOYEE SHOULD THOROUGHLY FAMILIARIZE THEMSELVES WITH THE FOLLOWING SECTIONS.



**CAUTION!**

SOME PICTURES IN THIS MANUAL SHOW SAFETY SHIELDS REMOVED OR OPEN TO SHOW PARTS BEING SERVICED OR FOR CLARITY. ALL SHIELDS SHOULD BE CLOSED OR REPLACED PRIOR TO OPERATING THE MACHINE.

**DANGER!**

**FASTEN SEAT BELT**

**BEFORE STARTING ENGINE!**

**THIS LOADER IS A VERY STABLE UNIT BUT IT CAN BE UPSET IF STOPPED SUDDENLY WHEN THE BUCKET IS RAISED AND LOADED.**


**THEREFORE, DO NOT START THE ENGINE BEFORE SECURELY FASTENING THE SEAT BELT, AND CARRY THE LOAD LOW.**

## SAFETY DECALS

The following safety decals have been placed on your machine in the areas indicated. They are intended for the personal safety of you, and those working with you. Please take this manual, walk around your machine and note the content and

location of these warning signs. Review these decals with your machine operators.

Keep the decals legible. If they are not, obtain replacements from your New Holland dealer. The decal part numbers are listed with each decal.



1. **DANGER: DO NOT ALLOW PASSENGERS TO RIDE ON THE LOADER AT ANY TIME. DO NOT GET UNDER BOOM UNLESS SUPPORTED BY THE BOOM LOCK PINS.**

Part #86521685

# NO RIDERS

# ! DANGER

AVOID DEATH

- LIFT ARM STOPS MUST BE ENGAGED
- OPENING LINES FOR SERVICE OR PART FAILURE CAN CAUSE LIFT ARMS TO DROP

2. **CAUTION: DO NOT ALLOW ANYONE TO OPERATE THE LOADER WITHOUT PROPER INSTRUCTION.**

Part #86521688

# ! CAUTION

AVOID INJURY

- READ OPERATORS MANUAL
- KNOW LOCATION AND FUNCTION OF CONTROLS
- KEEP SAFETY DEVICES WORKING
- KEEP SCREENS AND WINDOWS IN PLACE.
- KEEP CHILDREN AND OTHERS AWAY
- NEVER CARRY RIDERS  
LOWER LIFT ARMS. ENGAGE PARK BRAKE, STOP ENGINE AND REMOVE KEY BEFORE LEAVING.
- KEEP CAB CLEAN, ESPECIALLY PEDAL AREA.

3. **DANGER: BEFORE EXITING THE LOADER, LOWER THE LIFT ARMS AND ATTACHMENT TO THE GROUND OR REST LIFT ARMS ON THE BOOM STOPS. STOP ENGINE AND ENGAGE THE PARKING BRAKE.**

Part #86521683



4. **WARNING: DO NOT OVERLOAD! NEVER LIFT MORE THAN THE MAXIMUM SAE LOAD RATING OF THE LOADER. NEVER TRANSPORT A LOADED BUCKET AT FULL HEIGHT. OPERATE THE LOADER WITH THE LOAD AS LOW AS POSSIBLE.**

L865, Lx865, Lx885 - 2200 lbs. (998 kg)  
(Mfg. Rating)

Part #86521718

Lx985 - 2800 lbs. (1270 kg)  
(Mfg. Rating)

Part #86548195




5. **WARNING: NEVER OPERATE THE LOADER WITHOUT THE SEAT BELT SECURELY FASTENED.**

Part #86521686



6. **WARNING: KEEP CLEAR OF MOVING PARTS. KEEP BYSTANDERS CLEAR OF THE LOADER AT ALL TIMES UNLESS THE BOOM IS DOWN ON THE GROUND OR THE BOOM IS RESTING ON THE BOOM LOCK PINS AND ENGINE IS OFF. NEVER EXTEND ANY PART OF THE BODY OUTSIDE OF THE OPERATOR'S AREA.**

Part #86521673



7. **WARNING: KEEP CLEAR! ROTATING FAN - STOP ENGINE.**

Part #9828825



8. **WARNING: DO NOT ALLOW ANYONE NEAR THE LOADER WHILE THE ENGINE IS RUNNING AND THE LOADER IS OPERATIONAL.**

Part #86509972




9. CAUTION: DO NOT SPRAY ETHER INTO AIR INTAKE. EXPLOSION AND INJURY COULD RESULT.

Part #796286




10. DANGER: USE ONLY THE NEW HOLLAND CAB JACK KIT TO TILT THE CAB. READ INSTRUCTIONS BEFORE TILTING CAB. DO NOT REMOVE CAB HARDWARE UNTIL CAB JACK IS INSTALLED. FAILURE TO DO SO MAY CAUSE CAB TO FALL CAUSING SERIOUS INJURY OR DEATH.

Part #86521713



11. DANGER: LOCATED ON THE CAB TILTING JACK. NEW HOLLAND SKID-STEER LOADER CAB TILTING TOOL. READ CAB TILTING INSTRUCTIONS AND USE WITH PROPER MOUNTING BRACKETS BEFORE TILTING CAB.

Part #86508506



## GENERAL SAFETY INFORMATION

### HANDLE FLUIDS SAFELY

When you work around fuel or other flammable material, do not smoke, work near heaters or other fire hazards.

Do not store flammable material in open containers.

Store flammable fluids away from fire hazards.

Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, oil, and debris.

Do not store oily rags; they can ignite and burn spontaneously.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

### AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders.

Do not heat by welding, soldering, or using a torch near pressurized fluid lines.

Pressurized lines can be accidentally cut or damaged when heat goes beyond the immediate flame area.

### USE CARE AROUND HIGH-PRESSURE FLUID LINES

Escaping fluid under pressure can penetrate the skin causing serious injury.


Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines.

Tighten all line connections before applying pressure.

Check for leaks with a piece of cardboard.

Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source.



## **USE CARE IN HANDLING AND SERVICING BATTERIES**

### **Prevent Battery Explosions**

Keep sparks, lighted matches, and open flame away from the top of the battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Do not charge a frozen battery; it may explode. Warm the battery to 60° F (16° C).



**WARNING: IF ANY SERVICING OR ADJUSTMENTS REQUIRE THE BATTERY TO BE DISCONNECTED, OR WELDING IS REQUIRED ON THE SKID-STEER LOADER, DISCONNECT THE (-) NEGATIVE GROUND CABLE. FAILURE TO DISCONNECT THE BATTERY MAY RESULT IN DAMAGE TO THE EIC (ELECTRONIC INSTRUMENT CLUSTER) MONITORING SYSTEM AND OTHER ELECTRICAL COMPONENTS.**

**WARNING: IF WELDING ON AN ATTACHMENT IS REQUIRED, FIRST REMOVE THE ATTACHMENT FROM THE LOADER BOOM ATTACHING PLATE.**



**WARNING: ENGINE STARTING WITH A BOOSTER BATTERY REQUIRES EXTREME CARE AS BATTERIES PRODUCE EXPLOSIVE GASES. THE SLIGHTEST SPARK CAN CAUSE AN EXPLOSION.**

### **FOLLOW THESE SAFETY TIPS:**

- 1. ALWAYS SHIELD YOUR EYES WHEN CHARGING OR WORKING NEAR A BATTERY. ALWAYS PROVIDE GOOD VENTILATION.**
- 2. COVER THE BATTERY WITH A PIECE OF CARPET OR OTHER HEAVY MATERIAL. DO NOT REMOVE THE BATTERY VENT CAPS.**
- 3. CONNECT ONE CABLE TO THE (+) POSITIVE TERMINAL OF THE WEAK BATTERY. CONNECT THE OTHER END OF THE CABLE TO THE (+) POSITIVE TERMINAL OF THE STRONGER BATTERY.**
- 4. CONNECT THE SECOND CABLE TO THE (-) NEGATIVE TERMINAL OF THE STRONGER BATTERY.**
- 5. CONNECT THE REMAINING (-) NEGATIVE CABLE END TO THE ENGINE BLOCK OR STARTER GROUND TERMINAL.**
- 6. REVERSE THIS PROCEDURE WHEN DISCONNECTING THE BOOSTER.**

## **USE SAFE SERVICE PROCEDURES**

### **Wear Protective Clothing**

Do not wear loose clothing.

Wear close-fitting clothing.

Wear safety glasses or face shield as required.

Wear other safety equipment appropriate to the job.

Wear earplugs or earmuffs as required.

### **SERVICE MACHINES SAFELY**

Use caution when working around moving parts.

If servicing requires the boom to be in the raised position, support the boom on the boom locks and remove any attachment from the boom mounting plate. If servicing requires the complete loader to be in the supported position, support all four wheels off the ground using adequate jack stands or blocks.

If servicing requires the engine to be operated, raise the machine and properly support the unit with adequate jack stands or blocking with all four wheels off the ground.



**BEFORE SERVICING THE LOADER OR ANY OF ITS ATTACHED EQUIPMENT, BE SURE THAT THE ATTACHMENTS ARE LOWERED TO THE GROUND OR THE BOOM ARMS ARE SUPPORTED BY THE BOOM LOCK PINS.**

## **USE PROPER TOOLS**

Use tools appropriate for the job.

If tilting of the cab is required, use the proper tools and follow the procedure for tilting the cab in Section 1 of this manual.

## **REVIEW SAFETY EQUIPMENT, SIGNS AND SHIELDS**

Replace missing or damaged safety decals.

Reinstall all shielding removed for servicing.

Replace any damaged or missing shielding.

## **CONTROLS**

Operate unit and check machine functions for proper operation.

Check seat belt for proper operation, wear, and damage - Replace as needed.

Check operator restraint system - EIC for proper operation.

Check boom and bucket spool locks for proper operation.

Check mechanical boom locks for proper operation.

Check parking brake for proper operation and adjustment.

## MODEL AND SERIAL NUMBER LOCATION

The skid-steer loader model and serial number tag is located on the right front interior of the operator's cab at 1.




Figure 1-1

The engine model is located on the left side of the block at 1, and the engine serial number is located at 2.




Figure 1-2

For the tightening torques for reassembly, use the following hardware torque charts unless the torque is specified in the instructions.

# MINIMUM HARDWARE TIGHTENING TORQUES

IN FOOT POUNDS (NEWTON-METERS) FOR NORMAL ASSEMBLY APPLICATIONS

## INCH HARDWARE AND LOCKNUTS



| NOMINAL SIZE | SAE GRADE 2               |                    | SAE GRADE 5               |                    | SAE GRADE 8               |                    | LOCKNUTS        |                 | NOMINAL SIZE |
|--------------|---------------------------|--------------------|---------------------------|--------------------|---------------------------|--------------------|-----------------|-----------------|--------------|
|              | UNPLATED or PLATED SILVER | PLATED W/ZnCr GOLD | UNPLATED or PLATED SILVER | PLATED W/ZnCr GOLD | UNPLATED or PLATED SILVER | PLATED W/ZnCr GOLD | GR.B w/GR5 BOLT | GR.C w/GR8 BOLT |              |
| 1/4          | 55* (6.2)                 | 72* (8.1)          | 86* (9.7)                 | 112* (13)          | 121* (14)                 | 157* (18)          | 61* (6.9)       | 86* (9.8)       | 1/4          |
| 5/16         | 115* (13)                 | 149* (17)          | 178* (20)                 | 229* (26)          | 250* (28)                 | 324* (37)          | 125* (14)       | 176* (20)       | 5/16         |
| 3/8          | 17 (23)                   | 22 (30)            | 26 (35)                   | 34 (46)            | 37 (50)                   | 48 (65)            | 19 (26)         | 26 (35)         | 3/8          |
| 7/16         | 27 (37)                   | 35 (47)            | 42 (57)                   | 54 (73)            | 59 (80)                   | 77 (104)           | 30 (41)         | 42 (57)         | 7/16         |
| 1/2          | 42 (57)                   | 54 (73)            | 64 (87)                   | 83 (113)           | 91 (123)                  | 117 (159)          | 45 (61)         | 64 (88)         | 1/2          |
| 9/16         | 60 (81)                   | 77 (104)           | 92 (125)                  | 120 (163)          | 130 (176)                 | 169 (229)          | 65 (88)         | 92 (125)        | 9/16         |
| 5/8          | 83 (112)                  | 107 (145)          | 128 (174)                 | 165 (224)          | 180 (244)                 | 233 (316)          | 90 (122)        | 127 (172)       | 5/8          |
| 3/4          | 146 (198)                 | 189 (256)          | 226 (306)                 | 293 (397)          | 319 (432)                 | 413 (560)          | 160 (217)       | 226 (306)       | 3/4          |
| 7/8          | 142 (193)                 | 183 (248)          | 365 (495)                 | 473 (641)          | 515 (698)                 | 667 (904)          | 258 (350)       | 364 (494)       | 7/8          |
| 1            | 213 (289)                 | 275 (373)          | 547 (742)                 | 708 (960)          | 773 (1048)                | 1000 (1356)        | 386 (523)       | 545 (739)       | 1            |

NOTE: Torque values shown with \* are inch pounds.

### IDENTIFICATION CAP SCREWS AND CARRIAGE BOLTS



### LOCKNUTS



# MINIMUM HARDWARE TIGHTENING TORQUES

IN FOOT POUNDS (NEWTON-METERS) FOR NORMAL ASSEMBLY APPLICATIONS

## METRIC HARDWARE AND LOCKNUTS


| NOMINAL SIZE | CLASS 5.8 |               | CLASS 8.8 |               | CLASS 10.9 |               | LOCKNUT CL.8 W/CL8.8 BOLT |
|--------------|-----------|---------------|-----------|---------------|------------|---------------|---------------------------|
|              | UNPLATED  | PLATED W/ZnCr | UNPLATED  | PLATED W/ZnCr | UNPLATED   | PLATED W/ZnCr |                           |
| M4           | 15* (1.7) | 19* (2.2)     | 23* (2.6) | 30* (3.4)     | 33* (3.7)  | 42* (4.8)     | 16* (1.8)                 |
| M6           | 51* (5.8) | 67* (7.6)     | 79* (8.9) | 102* (12)     | 115* (13)  | 150* (17)     | 56* (6.3)                 |
| M8           | 124* (14) | 159* (18)     | 195* (22) | 248* (28)     | 274* (31)  | 354* (40)     | 133* (15)                 |
| M10          | 21 (28)   | 27 (36)       | 32 (43)   | 41 (56)       | 45 (61)    | 58 (79)       | 22 (30)                   |
| M12          | 36 (49)   | 46 (63)       | 55 (75)   | 72 (97)       | 79 (107)   | 102 (138)     | 39 (53)                   |
| M16          | 89 (121)  | 117 (158)     | 137 (186) | 177 (240)     | 196 (266)  | 254 (344)     | 97 (131)                  |
| M20          | 175 (237) | 226 (307)     | 277 (375) | 358 (485)     | 383 (519)  | 495 (671)     | 195 (265)                 |
| M24          | 303 (411) | 392 (531)     | 478 (648) | 619 (839)     | 662 (897)  | 855 (1160)    | 338 (458)                 |

NOTE: Torque values shown with \* are inch pounds.

### IDENTIFICATION

#### HEX CAP SCREW AND CARRIAGE BOLTS CLASSES 5.6 AND UP


##### MANUFACTURER'S IDENTIFICATION



##### PROPERTY CLASS

#### HEX NUTS AND LOCKNUTS CLASSES 05 AND UP

##### MANUFACTURER'S IDENTIFICATION



##### PROPERTY CLASS

##### CLOCK MARKING

### INSTALLATION OF ADJUSTABLE FITTINGS IN STRAIGHT THREAD O RING BOSSES

1. Lubricate the O ring by coating it with a light oil or petroleum. Install the O ring in the groove adjacent to the metal backup washer which is assembled at the extreme end of the groove, 1.
2. Install the fitting into the SAE straight thread boss until the metal backup washer contacts the face of the boss, 2.

**NOTE: Do not over tighten and distort the metal backup washer.**

3. Position the fitting by turning out (counterclockwise) up to a maximum of one turn. Holding the pad of the fitting with a wrench, tighten the locknut and washer against the face of the boss, 3.




Figure 1-3

### STANDARD TORQUE DATA FOR HYDRAULIC TUBES AND FITTINGS

| TUBE NUTS<br>FOR 37° FLARED FITTINGS |              |      |                |                | O RING BOSS PLUGS<br>ADJUSTABLE FITTING<br>LOCKNUTS, SWIVEL<br>JIC - 37° SEATS |                  |      |                |      |                  |     |
|--------------------------------------|--------------|------|----------------|----------------|--|------------------|------|----------------|------|------------------|-----|
| SIZE                                 | TUBING<br>OD |      | THREAD<br>SIZE | TORQUE         |  |                  |      | TORQUE         |      |                  |     |
|                                      | In.          | mm   |                | FOOT<br>POUNDS |  | NEWTON<br>METERS |      | FOOT<br>POUNDS |      | NEWTON<br>METERS |     |
|                                      |              |      | Min.           | Max.           | Min.   | Max.             | Min. | Max.           | Min. | Max.             |     |
| 4                                    | 1/4          | 6.4  | 7/16-20        | 9              | 12   | 12               | 16   | 6              | 10   | 8                | 14  |
| 5                                    | 5/16         | 7.9  | 1/2-20         | 12             | 15   | 16               | 20   | 10             | 15   | 14               | 20  |
| 6                                    | 3/8          | 9.5  | 9/16-18        | 21             | 24   | 29               | 33   | 15             | 20   | 20               | 27  |
| 8                                    | 1/2          | 12.7 | 3/4-18         | 35             | 40   | 47               | 54   | 25             | 30   | 34               | 41  |
| 10                                   | 5/8          | 15.9 | 7/8-14         | 53             | 53   | 72               | 79   | 35             | 40   | 47               | 54  |
| 12                                   | 3/4          | 19.1 | 1-1/16-12      | 77             | 82   | 104              | 111  | 60             | 70   | 81               | 95  |
| 14                                   | 7/8          | 22.2 | 1-3/16-12      | 90             | 100  | 122              | 136  | 70             | 80   | 95               | 109 |
| 16                                   | 1            | 25.4 | 1-5/16-12      | 110            | 120  | 149              | 163  | 80             | 90   | 108              | 122 |
| 20                                   | 1-1/4        | 31.8 | 1-5/8-12       | 140            | 150  | 190              | 204  | 95             | 115  | 129              | 158 |
| 24                                   | 1-1/2        | 38.1 | 1-7/8-12       | 160            | 175  | 217              | 237  | 120            | 140  | 163              | 190 |
| 32                                   | 2            | 50.8 | 2-1/2-12       | 225            | 240  | 305              | 325  | 250            | 300  | 339              | 407 |

These torques are not recommended for tubes of 1/2" (12.7 mm) OD and larger with wall thickness of 0.035" (0.889 mm) or less. The torque is specified for 0.035" (0.889 mm) wall tubes on each application individually.

Before installing and torquing 37° flared fittings, clean the face of the flare and threads with a

clean solvent or Loctite cleaner and apply hydraulic sealant Loctite no. 569 to the 37° flare and the threads.

Install fitting and torque to specified torque, loosen fitting and retorque to specifications.

**PROPERLY SUPPORT A RAISED MACHINE**

If servicing, neutral adjustment, final drive adjustment or repairs require the machine to be raised, securely support the machine with adequate jack stands or blocks as shown.

Support the machine at 1, to the front of the final drive cases and the rear at 2, making sure the supports are on the flat area of the final drive cases.




Figure 1-4

**PROPERLY SUPPORT BOOM ON BOOM LOCK PINS**

Before servicing the machine or any of its attached equipment, be sure that the attachments are lowered to the ground or the boom arms are supported by the boom lock pins, 1.

If the boom is to be raised on boom lock pins, remove any attachment. Opening a hydraulic line could cause a mounted attachment to dump over unexpectedly.




Figure 1-5

**MAJOR UNIT OVERHAUL**

For a major hydrostatic component or engine repair, the skid-steer loader cab and boom assembly can be tilted forward for easier access to the components area. The loader is shown properly supported at 1, and the cab tilted forward.



**WARNING: NEVER ATTEMPT TO TILT THE SKID-STEER LOADER CAB WITHOUT USING THE PROPER TOOL AND INSTRUCTIONS. SEE MORE DETAIL LATER IN THIS SECTION OF THE MANUAL AND/OR CONTACT YOUR NEW HOLLAND DEALER.**




Figure 1-6

### CAB TILTING PROCEDURE

The cab and boom assembly can be tilted forward for easier access to the major skid-steer loader hydrostatic transmission or engine components. To tilt the cab, the proper cab tilting tool must be used to insure a safe operation and to prevent damage to the loader frame, cab, and boom structure. Contact your New Holland dealer for major service or repairs of the skid-steer loader. Using the proper cab tilting tool and following these steps, the cab and boom can be tilted forward.

### CAB TILTING JACK AND SUPPORT BRACKET

- 1 Jack and screw assembly
- 2 Lower jack support
- 3 Upper jack support
- 4 Spacer plate (not required)




Figure 1-7

### CAB AND BOOM TILT PROCEDURE

1. Remove any attachment, bucket etc. from the boom quick-attach plate.




Figure 1-8

## SECTION 1 - GENERAL INFORMATION

2. Raise the boom and lower onto boom lock pins, 1.
  - a. Raise boom above boom lock pins.
  - b. Engage boom lock pins.
  - c. Stop engine, ignition key off position.
  - d. Turn ignition key to the on position.
  - e. Lower boom onto boom lock pins.
  - f. Turn the ignition key to the "OFF" position.




Figure 1-9

3. Jack up the loader and block it securely with all four wheels off the ground, as shown. Position the front blocks to the front of the final drive cases and the rear blocks to the rear of the flat area of the final drive cases.



**WARNING: NEVER ATTEMPT TO TILT THE SKID-STEER LOADER CAB OVER UNLESS THE LOADER IS SECURELY SUPPORTED.**




Figure 1-10

4. Open the rear door, 1; raise and latch the top engine shield, 2, in the raised position.
5. Remove engine side covers, 3.
6. Remove fenders, 4; rear fender supports, 6; and right and left sides.
7. Remove foam material, 5, from both sides.




Figure 1-11

SECTION 1 - GENERAL INFORMATION

8. Disconnect the battery negative (-) cable, 1.




Figure 1-12

9. Raise the seat and lock in the up position, 1. Make sure the seat pan assembly is latched securely.



**CAUTION: DO NOT WORK UNDER THE SEAT AND PAN UNLESS IT IS PROPERLY LATCHED IN THE RAISED POSITION.**

10. Remove the front step shield, 2.




Figure 1-13

11. Remove the cotter pins, 1, from the parking brake linkage right and left sides, unhook link rod, 2, and raise the parking brake lever to the engaged position.




Figure 1-14

SECTION 1 - GENERAL INFORMATION

12. Install the lower cab jack support, 1. Hook the support over the end of the front left final drive case and attach with a 1/2" x 8" cap screw and spacers at 2.




Figure 1-15

13. Install the upper cab jack support, 1. Pivot the retaining plate, 3, up behind the boom top link and secure with 1/2" x 1-1/4" carriage bolt and 1/2" wing nut. Install retaining bolt, 4, 1/2" x 2-1/2" cap screw through side of cab with a large 1/2" flat washer, 1/2" wing nut to the inside of the cab and tighten.

**NOTE: Spacer, 2, is not required to be used on the L865, Lx865, Lx885, and Lx985 loaders.**




Figure 1-16

14. Install the jack assembly, 1, between the upper and lower supports using two pins and retaining clips.
15. Loosen the front cab mounting bolts, 2, enough to allow the bolt to rotate in post and remove the rear front cab bolts, 3, one each side.



**CAUTION: NEVER REMOVE THE FRONT CAB BOLTS, 2, AS THESE ARE THE PIVOT BOLTS DURING THE CAB TILTING PROCEDURE. REMOVAL OF THESE BOLTS COULD CAUSE THE CAB TO FALL AND MAY CAUSE INJURY AND MACHINE DAMAGE.**




Figure 1-17

16. Remove the rear cab post bolts, 4, two or four bolts each side.

**NOTE:** If the rear bolts, 4, have spacers under the bolt heads, they must be reinstalled during reassembly for proper torquing.



**CAUTION: NEVER LOOSEN OR REMOVE ANY CAB RETAINING HARDWARE BEFORE THE JACK ASSEMBLY IS INSTALLED.**




Figure 1-18

17. Jack cab and boom assembly over with the loader properly supported off the ground. Support the boom at 1, to support the boom and cab to prevent tipping of the loader when heavy components, engine, hydrostatic pumps, etc. are removed from the lower frame. Jack travel will limit the travel of the cab assembly to prevent over travel. Be sure all wire harnesses, hydraulic hoses, and throttle cable clear any obstructions during cab tilting.



**WARNING: NEVER ATTEMPT TO TILT THE SKID-STEER LOADER CAB WITHOUT PROPER INSTRUCTIONS AND USING THE PROPER TOOL. SEE THE SERVICE MANUAL AND/OR YOUR NEW HOLLAND DEALER.**

**CAUTION: NEVER ATTEMPT TO OPERATE OR MOVE THE SKID-STEER LOADER WITHOUT FIRST INSTALLING AND PROPERLY TIGHTENING ALL CAB RETAINING HARDWARE.**




Figure 1-19

## TILTING CAB AND BOOM BACK ON FRAME

To jack the cab and boom assembly back into position, do the following:

1. Pull the hydrostatic control handles forward and hold in this position with rubber tie straps from the handle to the front cab post.
2. Jack the cab and boom back into position.
3. Keep the wire harness, 1 and throttle cable, 2, in position to prevent damage from setting the cab on them.
4. Pull the wire harness through the loop, 3.



**CAUTION: KEEP THE WIRE HARNESS FROM BEING DAMAGED. A DAMAGED WIRE HARNESS COULD RESULT IN DAMAGE TO THE LOADER ELECTRICAL COMPONENTS.**

5. Remove rubber tie straps from the hydrostatic control handles.
6. Reinstall all cab support bolts front and rear.
 

**NOTE: If the rear bolts, 1, had spacers under the bolt heads, they must be reinstalled during reassembly for proper torquing.**

Torque the rear bolts, 1, to 80 ft. lbs. (108 N·m).
7. Reinstall the parking brake linkage, 2.
8. Position the throttle cable, 3, inside frame.




Figure 1-20




Figure 1-21

## SECTION 1 - GENERAL INFORMATION

The Lx985 will have four cab retaining bolts on each side at 1.

**NOTE:** If the rear bolts, 1, had spacers under the bolt heads at 2, they must be reinstated during reassembly for proper torquing.




Figure 1-22

9. Torque the front bolts, 1, to 160 ft. lbs. (217 N·m).
10. Reinstall the foam, 2; fenders, 3; and front step shield, 4.
11. Remove jack and supports.
12. Reconnect the battery cable.



**WARNING: NEVER ATTEMPT TO TILT THE SKID-STEER LOADER CAB WITHOUT PROPER INSTRUCTIONS AND USING THE PROPER TOOL. SEE THE SERVICE MANUAL AND/OR YOUR NEW HOLLAND DEALER.**

**WARNING: NEVER ATTEMPT TO OPERATE OR MOVE THE SKID-STEER LOADER WITHOUT FIRST INSTALLING AND PROPERLY TIGHTENING ALL CAB RETAINING HARDWARE.**

**CAUTION: REINSTALL ALL SHIELDS THAT WERE REMOVED FOR SERVICING AND ADJUSTMENT PROCEDURES.**




Figure 1-23

### CRANING THE SKID-STEER LOADER

If the skid-steer loader is inoperative and located in an area where it cannot be loaded onto a truck or trailer, the unit may be craned to load the unit.

To crane the loader, only use chain or cable with a rated capacity to handle the weight of the model skid-steer loader being craned. Refer to the "Specifications" section of the operator's manual for the operating weight of the model loader being craned. Use three chains, minimum of 12' (3.66 m) long for the models L865, Lx865, Lx885, and 14' (4.27 m) long for the Lx985, to prevent sharp angles and damage to the loader cab, boom, and lifting chains.




Figure 1-24

Remove any attachment except a standard bucket from the loader boom attaching plate.



**CAUTION: DO NOT LIFT ANY ATTACHMENTS ON THE LOADER MOUNTING PLATE THAT WEIGH 600 LBS. (272 kg) OR MORE. LIFT SUCH ATTACHMENTS SEPARATELY.**




Figure 1-25

The lifting points are at the rear of the loader, 1.




Figure 1-26

The front is located in the center of the main frame, 1.




Figure 1-27

The lifting chains or cables must be minimum, 12' (3.66 m). The lifting hook point must be minimum of 75" (1.9 m) above the cab, 1, to prevent the chains or cables from damaging the loader frame or cab.



**WARNING: ALWAYS USE PROPERLY RATED LIFTING DEVICES TO PREVENT PERSONAL INJURY OR DAMAGE TO THE LOADER.**




Figure 1-28