

70/70A SERIES REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	2
SECTION 21 - TRANSMISSION	7
SECTION 23 - DRIVE LINES	12
SECTION 25 - FRONT MECHANICAL DRIVE	12
SECTION 27 - REAR DRIVE AXLE	15
SECTION 31 - POWER TAKE-OFF	16
SECTION 33 - BRAKES AND CONTROLS	17
SECTION 35 - HYDRAULIC SYSTEMS	20
SECTION 41 - STEERING	29
SECTION 44 - TWO-WHEEL DRIVE AXLE AND WHEELS	30
SECTION 50 - CLIMATE CONTROL	32
SECTION 55 - ELECTRICAL SYSTEMS	33
SECTION 90 - PLATFORM, CAB, AND BODYWORK	40

The following pages are the collation of the contents pages from each section and chapter of the 70/70A Series Repair manual.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the 70/70A Series Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87018723

Chapter 1 - General Information

CONTENTS

Section	Description	Page
00 000	Forward	2
	Precautionary Statements	3
	Safety Precautions	4
	Health and Safety Precautions	7
	Tractor Identification	14
	Service Techniques	21
	Sealer Specifications	23
	Hardware Torque Values	23
	Lubrication	26
	Recommended Lubricants and Coolants	26

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 1 - Engine and Lubrication System

CONTENTS

Section	Description	Page
10 000	Specifications	3
	Torque Values	12
	Grease and Sealants	14
	Special Tools	15
	Description of Operation	16
	Cylinder Head Assembly	22
	Camshaft Assembly	22
	Crankshaft Assembly	22
	Connecting Rods	22
	Pistons	22
	Manifolds	22
	Cylinder Block Assembly	22
	Timing Gears	22

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 1 - Engine and Lubrication System (Continued)

CONTENTS

Section	Description	Page
	Engine Lubrication	23
	Troubleshooting	27
	Disassembly and Repair	30
	Cylinder Head	30
	Cylinder Head Reassembly	42
	Additional Information	45
	Crankcase Front Cassette Seal	47
	Parts Affected	47
	Additional Information	47
	Removal of Old Style Seal and Installation of the New Cassette Seal	47
	Front Cassette Seal Removal	53
	Engine Front Cover and Timing Gear	58
	Oil Pan	60
	Connecting Rods, Bearings, Pistons and Rings	61
	Cylinder Block Overhaul	64
	Piston Assembly Installation	69
	Main Bearings, Flywheel and Crankshaft	70
	Rear Cover Plate	72
	Oil Pump	75
	Oil Filter Support Assembly	77
	Crankshaft	78
	Camshaft	82
	Engine Timing Gears	84
	Engine Compression Test	85
	Test Procedure	85
	Test Reading	85
	Test Conclusion	85

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 2 - Cooling System

CONTENTS

Section	Description	Page
10 000	Specifications	2
	Description of Operation	4
	Cooling System	4
	Troubleshooting	6
	Disassembly and Repair	7
	Radiator	7
	Thermostat	9
	Temperature Warning Sender	10
	Fan Blade	10
	Viscous Clutch Assembly	10
	Fan Belt Tensioner	11
	Idler Pulley	11
	Water Pump	12

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 3 - Induction System

CONTENTS

Section	Description	Page
10 000	Specifications	2
	Description of Operation	4
	Air Cleaner	4
	Turbocharger	6
	Intercooler	9
	Troubleshooting	10
	Intercooler Leak Test	12
	Disassembly and Repair	13
	Air Cleaner	13
	Turbocharger	15
	Intercooler	21

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 4 - Fuel System

CONTENTS

Section	Description	Page
10 000	Specifications	3
	Fuel System Torque Chart	4
	Special Tools	4
	Description of Operation	5
	Testing and Diagnosis	19
	Low Pressure Fuel System	20
	Fuel Tank Valves	20
	Filter Inlet and Outlet Pressure Tests	20
	High Pressure Fuel System	25
	Injection Timing Check	25
	Fuel Injector Nozzle Check	28
	Injector Assembly Bench Testing	28
	Preliminary Setup Procedure	29
	Perform Opening Pressure Test	29
	Perform Nozzle Seat Leakage Test	30
	Perform Chatter and Spray Pattern Test	31
	Surging	31
	Fuel Shutoff Diagnosis	32
	Shutoff Solenoid Specifications	32
	Preliminary Checks	32
	Checking Electrical Feed	32
	Adjustments	34
	Bleeding the Fuel System	34
	Adjustment of Foot and Hand Throttle Cables	35
	Adjustment of High Idle Speed	35
	Adjustment of Low Idle and Antisurge	36
	Removal and Installation	37
	Fuel Lift Pump	37
	Fuel Shutoff Solenoid	38
	Fuel Injection Pump	39
	Fuel Injection Lines	47
	Low-pressure Fuel Injection Lines	47
	High-pressure Fuel Lines	48

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 4 - Fuel System (Continued)

CONTENTS

Injector Leak-off Line	50
Fuel Filter	51
Fuel Filter Manifold	52
Injection Nozzles	53

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 5 - Engine Removal

CONTENTS

Section	Description	Page
10 000	Specifications	2
	Description of Operation	3
	Disassembly and Repair	4
	Engine Removal	4
	Engine Installation	8

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 6 - Fuel Tank Removal

CONTENTS

Section	Description	Page
10 000	Specifications	2
	Description of Operation	3
	Disassembly and Repair	4
	Lower Tank Removal	4
	Lower Tank Installation	5
	Top Tank Removal	6
	Top Tank Installation	6

SECTION 21 - TRANSMISSION

BOOK 1 - 87018723

Chapter 1 - Operation and Overview

CONTENTS

Section	Description	Page
21 000	Specifications	2
	Powershift Transmission	2
	Gear Ratios	2
	Ground Speed	3
	Electrical System	5
	Description of Operation	6
	Transmission Housing	7
	Powershift Transmission Controls	8
	Digital Display	8
	Inching Pedal	9
	Starting the Engine and Moving Forward	10
	Starting the Engine and Moving in Reverse	11
	Shuttle Operations	12
	Speed Matching	13
	Auto Shift	14
	Creeper Gears (optional)	15
	Programmable Upshift - Downshift	15
	Transmission Components	17
	Clutches	17
	Speed Clutches	17
	Directional Clutches	21
	Clutch Engagement	22
	Troubleshooting and Diagnosis	33

SECTION 21 - TRANSMISSION

BOOK 1 - 87018723

Chapter 2 - Separating the Engine and Front Axle from the Transmission

CONTENTS

Section	Description	Page
21 000	Specifications	2
	Special Tools	2
	Description of Operation	3
	Disassembly and Repair	4
	Engine and Side Rail Separation from the Transmission	4
	Four-wheel Drive Shaft Removal (if equipped)	8
	Engine and Side Rail Reassembly	10

SECTION 21 - TRANSMISSION

BOOK 1 - 87018723

Chapter 3 - Separating the Rear Axle from the Transmission

CONTENTS

Section	Description	Page
21 000	Specifications	2
	Special Tools	2
	Description of Operation	3
	Disassembly and Repair	4
	Rear Axle to Transmission Separation	4
	Reassembly	8
	Minimum Hardware Tightening Torques	9

SECTION 21 - TRANSMISSION

BOOK 1 - 87018723

Chapter 4 - Mechanical System

CONTENTS

Section	Description	Page
21 000	Specifications	2
	Torque Specifications	3
	Special Tools	4
	Description of Operation	5
	Troubleshooting and Diagnosis	6
	Disassembly and Repair	7
	Removal and Disassembly	7
	Rear Housing and Directional Clutches - Removal	8
	Front Housing and Speed Clutches - Removal	12
	Main Input Gear Assembly - Removal	14
	Speed Clutches - Disassembly	16
	Speed Clutches - Inspection	21
	Directional Clutches - Disassembly	23
	Directional Clutches - Inspection and Overhaul	26
	Speed/Directional Clutch - Reassembly	27
	Main Input Gear and Oil Seal - Disassembly Inspection, Overhaul and Reassemble	29
	Two Gear Clusters in Front and Rear Housing - Disassembly, Inspection and Reassembly	30
	Front and Rear Housings and Center Section - Inspection and Overhaul	30
	Torque Limiting Clutch and Sprung Damper Hub Drive Assembly - Removal, Inspection and Replacement	32
	Reassembly	33
	Speed Clutches and Front Housing	33
	Directional Clutches and Rear Housing	34
	Transmission Shimming	36
	Front Housing Shimming	36
	Rear Housing Shimming	37
	Shimming the Output Shaft	38
	Creeper Gear	39
	Creeper Gear Repair	41
	Installation	44

SECTION 21 - TRANSMISSION

BOOK 1 - 87018723

Chapter 5 - Hydraulic System

CONTENTS

Section	Description	Page
21 000	Specifications	3
	Low-pressure Hydraulic System	3
	Special Tools	4
	Description of Operation	5
	Regulator Valve Operation	7
	Clutch Valve Operation	7
	Modulator Valve Operation	8
	Electro-hydraulic Pilot Line	9
	Troubleshooting and Diagnosis	10
	70/70A Series Transmission Test Sheet	11
	Electrical/Electronic System Checks	11
	Hydraulic System Checks	13
	Clutch Apply Pressure Chart	14
	Pressure Testing and Adjustments	15
	Clutch Apply Circuit Pressure Testing	17
	Transmission Pressure Checklist	19
	Transmission Programming	21
	Programming the Programmable Upshift, Downshift	21
	Programming Reverse Gear Ratios	23
	Transmission Calibration	25
	Check Powershift Transmission Clutch Calibration	25
	Calibration Review	26
	Calibrate F1 Directional Clutch	26
	Calibrate F2 Directional Clutch	27
	Calibrate Reverse Directional Clutch	27
	Exit Calibration Mode	28

SECTION 21 - TRANSMISSION

BOOK 1 - 87018723

Chapter 6 - Electrical System

CONTENTS

Section	Description	Page
21 000	Specifications	2
	Electrical System	2
	Description of Operation	3
	Clutch Apply Circuits	4
	Modulation Solenoids	4
	Shift Control Lever	5
	Inching Pedal	6
	Speed Sensors	6, 10
	Display Module	6
	Troubleshooting and Diagnosis	7
	Transmission Solenoid and Pressure Testing	8
	Disassembly and Repair	9
	Control Valve Solenoids	9
	Chassis Control Module	11
	Inching Pedal Switches	12
	Transmission Shift Control	14
	Calibration of Shift Constant	28
	Disassembly and Repair	31
	Removal and Disassembly	31
	Removal of the Complete Valve Assembly from the Tractor	31
	Disassembly	33
	Solenoid and Valve Assembly	34
	Speed and Directional Clutch Circuit Valves	34
	Modulator Valves	35
	Regulator Valve	37
	Lubrication and Cooling Circuit Relief Valve	39
	Removal	39
	Installation	39
	Inspection	40
	Reassembly	40
	Installation	41

SECTION 23 - DRIVE LINES

BOOK 2 - 87018724

Chapter 1 - Four-wheel Drive Clutch

CONTENTS

Section	Description	Page
23 202	Description of Operation	2
	70 Series FWD Electronic Control Operation	4
	70A Series FWD Electronic Control Operation	5
	Engaging and Disengaging Four Wheel Drive	5
	FWD Operating Precautions	5
	Disassembly and Repair	8
	Removal	8
	Disassembly	12
	Inspection	13
	Reassembly	15
	Installation	18
	Pressure Testing	23

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 2 - 87018724

Chapter 1 - Four-Wheel Drive Dana Axle

CONTENTS

Section	Description	Page
25 000	Specifications	2
	Special Tools	4
25 100	Description of Operation	6
	Troubleshooting	15
41 106	Adjustments	16
41 106	Wheel Toe-in	16
25 108	FWD Steering Stop	17
25 108	Hub Bearing Preload Adjustment	18
25 102	Check for Correct Pinion to Ring Gear Tooth Contact	21
25 102	Wrong Tooth Contact Pattern	21
25 108	Swivel Pin Bearing Adjustment	23
25 104	FWD Ratios	23

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 2 - 87018724

Chapter 1 - Four-Wheel Drive Dana Axle (Continued)

CONTENTS

Section	Description	Page
25 104	FWD Tire vs Gear Ratios	24
	Four Wheel Drive Lead Factor	28
	Front Axle Serviceability	30
00 400	Lubrication	30
	Disassembly and Repair	35
25 100	Front Axle	35
41 216	Steering Cylinders	38
25 108	Planetary Reduction	40
25 108	Hub	44
25 108	Swivel Housing	47
25 108	Center Housing Swivel Bearing	50
25 108	Drive Shaft	51
25 108	Outer Yoke	54
25 102	Differential	56
25 102	Crown Wheel to Backlash Adjustment	69

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 2 - 87018724

Chapter 2 - Dana Supersteer™ Linkage

CONTENTS

Section	Description	Page
25 100	Description of Operation	2
25 100	Supersteer Linkage Removal	3
25 100	Removal of Rear Support Assembly and Spherical Ball Bushing	5
41 106	Supersteer Linkage Adjustment	9

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 2 - 87018724

Chapter 3 - Four Wheel Drive Carraro Axle

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	General Information	7
	Front Axle Differential Line	8
	Overall Dimensions	11
	General Checks Prior to Disassembly	16
	Disassembly Operations	17
25 100	Front Axle Removal/Installation	17
41 216	Steering Cylinders Group Disassembly	17
41 216	Steering Cylinders Group Assembly	23
25 310	Final Drive Removal	25
25 108	Wheel Hub Disassembly	27
25 108	Wheel Hub Assembly	29
25 108	Swivel Housing Removal	32
25 100	Swivel Housing Assembly	33
25 100	Axle Housing Swivel Bearing	34
25 102	Differential Support Group Disassembly	36
25 102	Differential Support Group Assembly	38
25 102	Input Flange End Play Adjustment	39
25 102	Limited Slip Differential Removal	40
25 102	Limited Slip Pinion Disassembly	41
25 104	Limited Slip Differential Disassembly	43
25 104	Limited Slip Differential Assembly	45
25 102	Lockable Differential Removal	48
25 102	Lockable Pinion Disassembly	50
25 104	Lockable Differential Disassembly	52
25 104	Lockable Differential Assembly	54
25 102	Adjustment - Pinion Shaft	57
25 104	Differential - Adjustments	61
25 102	Pinion to Ring Gear Tooth Contact Adjustment	64
	Wrong Tooth Contact Pattern	64
25 108	Swivel Housing Bearing Adjustment	66
41 106	Standard Steer/Toe-In Adjustment	67
41 106	Supersteer Linkage Adjustment	68
25 108	Potentiometer Removal	70
25 108	Potentiometer Installation	70
25 108	Potentiometer Calibration	72
	Mode 12: Tractor Features Configuration	72
	Mode 13: Steering Angle Sensor Operation/Calibration	73
	New Parameter Code	74
	New Fault Codes	77
	Testing After Assembly	78
	Troubleshooting	79

SECTION 27 - REAR DRIVE AXLE

BOOK 2 - 87018724

Chapter 1 - Rear Axle Assembly

CONTENTS

Section	Description	Page
27 000	Specifications	2
	Special Tools	3
	Description of Operation	10
	Differential Carrier	12
	Final Reduction Drive	13
	Differential Lock Mechanical Operation	14
	70 Series Differential Lock Control System Operation	15
	70A Series Differential Lock Control System Operation	16
	Differential Lock Electrical Circuit Operation	17
	Differential Lock Hydraulic Circuit Operation	19
	Front Axle Differential Line	19
	Troubleshooting	21
	Adjustments	30
	Disassembly and Repair	51
27 100	Axle Assembly	51
27 120	Axle Housing	64
27 120	Planetary Overhaul	85
	Axle Seal	91
	Top Cover	93
27 106	Differential Assembly	95
27 106	Pinion Assembly	112
27 110	Differential Lock Solenoid	125
	Pressure Testing	127
	Circuit Pressure Test	129

SECTION 31 - POWER TAKE-OFF

BOOK 3 - 87018725

Chapter 1 - Mechanical System

CONTENTS

Section	Description	Page
31 000	Specifications	2
	Special Tools	3
	Description of Operation	4
	Introduction	4
	Power Flow - All Models	5
	Engaging and Disengaging the PTO	7
	Troubleshooting and Diagnosis	8
	Disassembly and Repair	9
	PTO Assembly - Removal and Installation	9
	Upper PTO Input Shaft - Removal and Installation	15
	PTO Output Shaft and Driven Gear - Overhaul	30
	PTO Clutch Assembly - Overhaul	39

SECTION 31 - POWER TAKE-OFF

BOOK 3 - 87018725

Chapter 2 - Electro-hydraulic System

CONTENTS

Section	Description	Page
31 000	Specifications	2
	Special Tools	3
	Description of Operation	4
	Introduction	4
	Engaging and Disengaging the PTO	5
	PTO Hydraulic System Operation	6
	PTO Control Valve Operation	8
	Lubrication Oil	12
	PTO Electrical System Operation	14
	Troubleshooting	22

SECTION 31 - POWER TAKE-OFF

BOOK 3 - 87018725

Chapter 2 - Electro-hydraulic System (Continued)

CONTENTS

Section	Description	Page
	PTO will not Engage	23
	PTO will not Disengage	25
	PTO Clutch Slips Under Load	30
	PTO Shaft Continually Turns Slowly with Engine Running when PTO is Turned Off	32
	PTO Retaining Ring is Difficult to Replace	33
	Adjustments	34
	PTO Clutch Brake Band	34
	Disassembly and Repair	35
	PTO Solenoid	35
	PTO Control Valve Assembly	38
	PTO System Pressure Testing	44
	Introduction	44
	Pre-test Preparation	44
	Pilot Oil Circuit Pressure Test	45
	Clutch Apply Circuit Pressure Test	46
	PTO Lubrication Circuit Pressure Test	47

SECTION 33 - BRAKES AND CONTROLS

BOOK 3 - 87018725

Chapter 1 - Power Brakes

CONTENTS

Section	Description	Page
33 202	Specifications	2
	Description of Operation	4
	Boosters	7
	Master Cylinders	11
	Rear Axle Brake Assemblies	15
	Four Wheel Braking	17
	Troubleshooting	18

SECTION 33 - BRAKES AND CONTROLS

BOOK 3 - 87018725

Chapter 1 - Power Brakes (Continued)

CONTENTS

Section	Description	Page
	Adjustments	21
	Bleeding the Brakes	21
	Brake Pedal Adjustment	25
	Brake Switch Adjustment	25
	Disassembly and Repair	26
	Power Brake Valve - Overhaul	26
	Inspection	33
	Reassembly	34
	Installation of the Brake Lube Kit	39
	Rear Axle Brakes - Overhaul	44
	Hydraulic Trailer Brake	SEE SECTION 35

SECTION 33 - BRAKES AND CONTROLS

BOOK 3 - 87018725

Chapter 2 - Parking Brake

CONTENTS

Section	Description	Page
33 110	Specifications	2
	Special Tools	2
	Description of Operation	3
	Adjustments	4
	Adjust the Park Brake	4
	Troubleshooting	5
	Disassembly and Repair	6
	Parking Brake - Overhaul	6

SECTION 33 - BRAKES AND CONTROLS

BOOK 3 - 87018725

Chapter 3 - Trailer Air Brakes (Not Used in North America)

CONTENTS

Section	Description	Page
33 000	Specifications	2
	Torque Specifications	3
	Safety	7
	General Air Brake Safety	7
	General Maintenance Instructions	7
	Description of Operation	8
	System Operation	9
	Air Compressor	10
	Unloader Valve	10
	Reservoir Tank	14
	Right Hand Brake Lamp Switch	14
	Solenoid Valve	14
	Dual Control Valve	15
	Single Control Valve	20
	Air Pressure Switch	24
	Trailer Brake Solenoid Power	24
	Disassembly and Repair	25
	Air Compressor	25
	Air Compressor Lubrication Supply Line	29
	Air Compressor Lubrication Return Line	29
	Air Pressure Supply Line	32
	Unloader/Valve Silencer	33
	Reservoir	34
	Pressure Switch	34
	Single Control Valve	35
	Dual Control Valve	38
	Solenoid Control Valve	39
	Coupler Connectors	41
	Adjustments	42
	Adjusting the Air Brake Parking Brake	42
	System Testing	44
	Troubleshooting - Air Brake System	47
	Towed Vehicle	51
	Troubleshooting - Towed Vehicle	52

SECTION 33 - BRAKES AND CONTROLS

BOOK 3 - 87018725

Chapter 4 - Trailer Air Brake Electrical System (Not Used in North America)

CONTENTS

Section	Description	Page
33 000	Description of Operation	2
	Trailer Brake light	2
	Low Pressure Alarm	2
	Air Pressure Switch Power	3
	Harness Removal and Installation	4
	Cab Trailer Wiring Harness	4
	Rear Trailer Harness	8
	Troubleshooting	11

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 1 - Introduction

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Description of Operation	4
	Introduction	4
	Closed Center Load Sensing (CCLS) Pump and Remote Valve System	5
	Standard Flow Hydraulic System	13
	Megaflow Hydraulic System	15
	Variable Displacement Pump	16
	Priority Flow Divider	16
	Remote Control Valves	17
	Standard Flow Tractors	17
	Megaflow Tractor	17
	Low-pressure Return Circuit	18

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 2 - Low-Pressure System

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Description of Operation	3
	Hydraulic Pump Drive Assembly	3
	Tandem Gear Pump Assembly	4
	Tandem Gear Pump Fluid Supply	6
	Oil Filters	7
	Oil Reservoir	7
	Oil Cooler and Bypass Valve	8
	Low-Pressure Control Hydraulic Schematic	11
35 260	Removal and Disassembly	12
27 170	Hydraulic Pump Inlet Screen	12
27 170	Charge Pressure Regulator Valve	12
21 102	Filters	14
21 102	Filter Head	15
21 136	Cooler Bypass Valve	16
10 408	Hydraulic Oil Cooler	19
33 202	Accumulator	21
	Hydraulic Pump Driven Gear Case	22
	Repairing the Pump Drive Gear Case Bearings	23

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 3 - Tandem Gear Pump

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Special Tools	2
	Description of Operation	3
	Operation	4
35 105	Disassembly and Repair	5
	Removal	5
	Disassembly	7
	Inspection of Parts	12
	Assembly	16
	Performance Testing	21
	Installation	22

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 4 - Axial Piston Pump

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Special Tools	2
	Description of Operation	3
35 106	Disassembly and Repair	16
	Removal	16
	Tools Required	17
	Disassembly	17
	Input Shaft Seal Replacement	17
	Seal Installation	18
	Compensator Valve Disassembly	20
	Main Pump Disassembly	24

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 4 - Axial Piston Pump (Continued)

CONTENTS

Section	Description	Page
	Swash Plate Removal	28
	Input Shaft	31
	Pump Reassembly	34
	Rotating Group Assembly	37
	Flow and Pressure Compensator Valves	41
	Pump Installation	43

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 5 - Flow Divider

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Description of Operation	3
	Priority Flow Divider	3
41 200	Disassembly and Repair	6
	Removal	6
	Teardown	7
	Assembly	8

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 6 - 70 Series Remote Valves

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Special Tools	2
	Description of Operation	3
	Remote Valve Assembly	3
	Remote Valve Section (Series Logic)	9
	Remote Valve Section (Parallel Logic)	15
	Control Cables	21
	Return Tube	22
	Primary and Secondary Shuttles	22
	Order of Priority Operation	28

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 7 - 70A Series Electro-Hydraulic Remote Valves

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Electro Hydraulic Remote Valves	3
	Control Switches	3
	Flow Control Adjustment	4
	Description of Operation	4
	Flow Control Operation	9
	Order of Priority Operation	14

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 8 - Remote Valve Couplers

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Coupler Mounting Block and Coupler Repair (70 Series BSN D408953)	3
	Coupler Mounting Block and Coupler Repair (70 Series ASN D408952)	9

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 9 - Remote Valve Removal and Repair

CONTENTS

Section	Description	Page
35 000	Removal	2
	Remote Valve Removal	2
	Removing Individual Valve Assemblies	6
	Valve Reassembly	11
35 204	Teardown and Reassembly	16
	Individual Valve Section Disassembly	16
	Valve Section Overhaul (70 Series)	19
	Detent Release Overhaul (70 Series)	22

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 10 - Three-Point Hitch

CONTENTS

Section	Description	Page
35 000	Specifications	1
	Description of Operation	2
	Three-Point Hitch	2
	Three-Point Hitch External Linkage Components	15
	Quick Hitch	19
	Troubleshooting	20
	Disassembly and Repair	24
	Rockshaft Removal	24
	Seal and Bushing Replacement	26
	Rockshaft Installation	27
	Lift Cylinder Removal	29

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 11 - Power-Beyond Applicators

CONTENTS

Section	Description	Page
	Special Tools	2
35 204	Power-Beyond Applications	3

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 12 - Hydraulic Brake System

CONTENTS

Section	Description	Page
35 000	Closed Center Load Sensing (CCLS) Hydraulic Brake System	4
35 000	Operation of the European Trailer Brake System	4
	Operation of the 10 Bar (147 PSI) Trailer Brake System (Italian Market Only)	6
	Trailer Brake Valve Pilot Head Operation	9
	Trailer Brake Valve Operation	10
	Trailer Brake Valve	18
	Specifications	18
	Torques	18
	Special Tools	18
	Description	18
	Trailer Brake Valve Removal	19
	Trailer Brake Valve Disassembly	20
	Inspection and Repair	23
	Re-Assembly and Installation	23
	Bleeding the Brakes	24
	Bleeding Rear Axle Brakes	24
	Trailer Brake Valve Bleed Screws	25
	Trailer Brake Pressure Test	25

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 13 - Pressure and Flow Testing

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Special Tools	4
	Description of Operation	5
35 105	Low-pressure System Testing	6
	Testing Low-pressure System	6
35 106	High-pressure System Testing	9
	Axial Piston Pump	9
	Steering Flow Divider Relief Pressure	14
	Steering Flow Divider Flow Test	15
	Remote Valve	16
	Detent Release Operation	17
	Timed Detent Release Operation	18
	Three-point Hitch	19
	Three-point Hitch and Remote Valve Troubleshooting Aid Tool	24

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 14 - EHR Calibration, Diagnostics and Hydraulic System Troubleshooting

CONTENTS

Section	Description	Page
35 000	Calibration of the Electro-hydraulic Control System (EHR)	2
	Functions of the PDT	2
	Set Up	3
	Start Calibration	7
	Set Defaults	8
	Deadband	9
	Calibration of the Pod Levers	10

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 4 - 87018726

Chapter 14 - EHR Calibration, Diagnostics and Hydraulic System Troubleshooting

CONTENTS

Section	Description	Page
	Set Currents	13
	Setting the Flow Control Potentiometer	17
	Changing the Lever Deadband	18
	Diagnostics of the Electro-hydraulic Remote Valve Control System	19
	Solenoid Errors	19
	Lever Errors	20
	System Errors	20
	Other Screens	21
	Troubleshooting Electro-hydraulic Self Test	22
	Troubleshooting Hydraulic System	23
	Hydraulic System Quick Checks	28

SECTION 41 - STEERING

BOOK 5 - 87018727

Chapter 1 - Hydrostatic Steering

CONTENTS

Section	Description	Page
41 000	Specifications	2
	Minimum Hardware Tightening Torques	3
	Description of Operation	5
	Steering System Control Valve	7
	Steering Control Valve Types	11
	Steering Cylinders	12
	Troubleshooting	13
	Removal and Disassembly	18
	Steering Control Valve	18
	Parts Inspection	23
	Assembling the Steering Control Unit	24
	Installing the Steering Control Valve	29

SECTION 44 - TWO-WHEEL DRIVE AXLE AND WHEELS

BOOK 5 - 87018727

Chapter 1 - Two-wheel Drive Front Axle

CONTENTS

Section	Description	Page
44 000	Specifications	2
	Special Tools	2
	Description of Operation	3
	Two-wheel Drive Front Axle	3
	Troubleshooting	6
	Adjustments	7
	Front Wheel Track Spacing	7
	2WD Axle Adjustment	9
	Front Wheel Position	10
	Front Wheel Toe-in	11
	Disassembly and Repair	13
	Axle Removal	13
	Axle Installation	17
	Axle Center Beam Bushing Replacement	21
	Axle Extension Installation	21
	Spindle Removal and Disassembly	21
	Axle Extension/Spindle Bushing Replacement	22
	Spindle Reassembly	22
	Front Wheel Bearing	23
	Steering Cylinder	25
	Center Steering Arm	30
	Steering Rod	32