

# TN65F-TN95F REPAIR MANUAL

## COMPLETE CONTENTS

SECTION 00 - GENERAL .....	2
SECTION 10 - ENGINE .....	2
SECTION 18 - CLUTCH .....	3
SECTION 21 - TRANSMISSIONS .....	3
SECTION 23 - DRIVE LINES .....	6
SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION .....	6
SECTION 27 - REAR MECHANICAL WHEEL DRIVE .....	7
SECTION 31 - MECHANICAL POWER TAKE-OFF .....	7
SECTION 33 - BRAKING SYSTEM .....	8
SECTION 35 - HYDRAULIC SYSTEM .....	8
SECTION 41 - STEERING .....	12
SECTION 44 - AXLE AND WHEELS .....	12
SECTION 50 - CAB AIR CONDITIONING SYSTEM .....	13
SECTION 55 - ELECTRICAL SYSTEMS .....	13
SECTION 90 - CAB .....	22

The following pages are the collation of the contents pages from each section and chapter of the TNF Series Repair manual. Complete Repair part # 87026001.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TNF Series Tractors.

## SECTION 00 - GENERAL

### BOOK 1 - 87026002

#### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	General instructions .....	1

## SECTION 10 - ENGINE

### BOOK 1 - 87026002

#### Chapter 1 - Engine

#### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
<b>10 000</b>	General specifications .....	2
	Data .....	5
	Torque settings .....	20
	Tools .....	21
	Cross-sectional views .....	23
	Lubrication and cooling system diagrams .....	25
	Troubleshooting .....	27
<b>10 001</b>	Removal - Installation - Overhaul .....	31
	Checks, dimensions and repairs .....	73

---

## SECTION 18 - CLUTCH

BOOK 1 - 87026002

### Chapter 1 - Clutch

#### CONTENTS

Section	Description	Page
18 000	General Characteristics .....	1
	Tightening Torque .....	2
	Tools .....	3
	Sectional diagrams .....	3
	Clutch Troubleshooting .....	5
	Stacco - Riattacco .....	6
	Overhaul .....	11
	Checks, measurements and repairs .....	16
	Adjustments .....	17

## SECTION 21 - TRANSMISSIONS

BOOK 2 - 87026003

### Chapter 1 - Mechanical Transmission

#### CONTENTS

Section	Description	Page
21 000	Main data .....	1
	Torque settings .....	2
	Tools .....	5
	Cross-sectional views .....	7
	Description and operation .....	12
	Troubleshooting .....	12
21 110	Installment - Removal .....	13

---

## SECTION 21 - TRANSMISSIONS

BOOK 2 - 87026003

### Chapter 2 - Mechanical Transmission and Splitter

#### CONTENTS

Section	Description	Page
21 000	Main data .....	1
	Torque settings .....	2
	Tools .....	2
	Cross-sectional views .....	3
	Description and operation .....	6
	Troubleshooting .....	7
21 110	Removal-Instalment .....	8

## SECTION 21 - TRANSMISSIONS

BOOK 2 - 87026003

### Chapter 3 - Power Shuttle Transmission

#### CONTENTS

Section	Description	Page
21 000	Main data .....	1
	Tightening Torques .....	3
	Tools .....	4
	Cross-sectional views .....	6
	Description and operation .....	11
	Troubleshooting gearbox, gear range, reverser .....	11
21 110	Installation - Removal .....	12
	Automatic Self Diagnosis (ECM) .....	23
	ECM - First Start-up (self configuration) .....	24
	Diagnosis During Operation .....	25
	Fault Codes Indication .....	26
	Calibration and Diagnostic Unit (CDU) .....	27
	Power Shuttle Fault Code Priority .....	28
	Calibration Unit Use (CDU) .....	31
H1 - Clutches A (LO) and (B) HI Calibration .....	34	

---

## SECTION 21 - TRANSMISSIONS

BOOK 2 - 87026003

### Chapter 3 - Power Shuttle Transmission (Continued)

#### CONTENTS

Section	Description	Page
	Calibration Error Codes .....	38
	H2 - Clutches A (LO) and (B) HI Calibration Values .....	39
	H3 - System Configuration .....	40
	Operator's Presence Seat Switch Configuration .....	42
	H4 - Power Shuttle Hardware/Software Revision Level .....	43
	H5 - Control Switch Diagnosis .....	44
	H6 - Clutch A Fill Time .....	50
	H7 - Clutch B Fill Time .....	52
	H8 - Erasure of Data Stored in NVM .....	53
	H9 - Voltmeter Functions .....	55
	HA - Clutch Pedal Potentiometer and Status Switch .....	61
	Clutch Pedal Potentiometer Replacement .....	63
	HC - Transmission Oil Temperature Sender .....	64
	HD - HI/LO Synchronizer Operation .....	65
	HE - HI/LO Speed Shift Adjustment .....	67
	HF - Stored Error Codes .....	68
	Access to Error Codes via HI/LO Speed Switches .....	69
	Troubleshooting Fault Codes .....	74

---

## SECTION 23 - DRIVE LINES

BOOK 3 - 87026004

### Chapter 1 - Drive Lines

#### CONTENTS

Section	Description	Page
<b>23 000</b>	Main data .....	1
	Torque settings .....	2
	Cross-sectional views .....	3
	Description, operation and 4WD circuit diagram .....	5
	Troubleshooting .....	6
	Removal-Installation .....	7
	<b>23 101</b>	Removal-Installation .....
	Automatic four-wheel drive faults diagnosis .....	12
	Automatic four-wheel drive faults code signals .....	13
	Automatic four-wheel drive faults code .....	15
	Automatic four-wheel calibrations .....	23
	Troubleshooting Fault Codes .....	35

## SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION

BOOK 3 - 87026004

### Chapter 1 - Front Axle Mechanical Transmission

#### CONTENTS

Section	Description	Page
<b>25 000</b>	Main data .....	1
	Torque settings .....	3
	Tools .....	6
	Cross-sectional views .....	7
	Description and operation .....	11
	Troubleshooting .....	13
	<b>25 100</b>	Removal - Installation - Front axle overhaul .....

---

## SECTION 27 - REAR MECHANICAL WHEEL DRIVE

BOOK 3 - 87026004

### Chapter 1 - Rear Mechanical Wheel Drive

#### CONTENTS

Section	Description	Page
27 000	Main specifications .....	1
	Tightening Torque .....	3
	Equipment .....	5
	Sectional drawings .....	8
	Description and operation .....	9
	Troubleshooting .....	11
27 100	Removal - Refitting - Overhaul .....	13

## SECTION 31 - MECHANICAL POWER TAKE-OFF

BOOK 3 - 87026004

### Chapter 1 - Mechanical Power Take-off

#### CONTENTS

Section	Description	Page
31 000	Technical specifications .....	1
	Tools .....	4
	Tightening torque .....	5
	Sectional drawings .....	7
	Description and operation .....	9
	Troubleshooting .....	11
	Removal and refitting .....	11

---

## SECTION 33 - BRAKING SYSTEM

BOOK 3 - 87026004

### Chapter 1 - Braking System

#### CONTENTS

Section	Description	Page
<b>33 000</b>	Technical specifications .....	1
	Tightening torque .....	2
	Sectional drawings .....	3
	Tools .....	5
	Description and operation .....	6
	Troubleshooting .....	7
	<b>33 202</b>	Removal-Refitting - Overhauling service brakes .....
	Removal-Refitting - Service brake pump .....	11
<b>33 110</b>	Removal-Refitting - Parking brake disc .....	18

## SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87026005

### Chapter 1 - Rear Mechanical Hydraulic Lift

#### CONTENTS

Section	Description	Page
<b>35 000</b>	Main data .....	1
	Torque settings .....	3
	Tools .....	5
	Cross-sectional views .....	6
	Description and operation .....	11
	Troubleshooting .....	15
	<b>35 114</b>	Removal - Refitting - Overhaul .....

---

## SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87026005

### Chapter 2 - Open Centre System Auxiliary Control Valves

#### CONTENTS

Section	Description	Page
<b>35 000</b>	Main data – Tools .....	1
	Torque settings .....	2
	Cross-sectional views .....	3
	Description and operation .....	6
	Troubleshooting .....	see lift chapter 1
<b>35 204</b>	Overhaul .....	10

## SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87026005

### Chapter 3 - Trailer Brake Auxiliary Control Valve

#### CONTENTS

Section	Description	Page
<b>35 000</b>	Section .....	1
	Description and operation .....	1
	Troubleshooting .....	8
	Installation - Removal .....	11

---

## SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87026005

### Chapter 4 - Electronically Controlled Hydraulic Lift (Rear)

#### CONTENTS

Section	Description	Page
35 000	Main data .....	1
	Torque settings .....	4
	Tools .....	5
	Cross-sectional views .....	6
	Description and operation .....	11
	Electronic control unit replacement .....	18
	Draft sensor replacement .....	19
	Position sensor replacement .....	22
	Lift calibration .....	24
	HH Menu .....	29
	35 114	Overhaul - Removal-Installation .....
Electronic lift faults diagnosis (postmodification) .....		63
Electronic lift faults signals (postmodification) .....		64
Electronic lift faults codes (postmodification) .....		66
Electronic lift calibration (postmodification) .....		88
Troubleshooting fault codes .....		103

## SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87026005

### Chapter 5 - Non-stop Flow Gear Pump

#### CONTENTS

Section	Description	Page
35 000	Main data .....	1
	Torque settings .....	3
	Description and operation .....	4
	Troubleshooting .....	see chapter 1
35 104	Overhaul .....	5

---

## SECTION 35 - HYDRAULIC SYSTEM

BOOK 5 - 87026006

### Chapter 6 - Front Electronic Lift and Front Power Take-off

#### CONTENTS

Section	Description	Page
	Main data .....	1
	Tightening Torques .....	3
	Cross-sectional views .....	6
	Description and operation .....	11
	Troubleshooting .....	16
<b>31 140 30</b>	Front power take-off transmission shaft R.I. ....	18
<b>31 140 34</b>	Front power take-off transmission shaft A.D. ....	26
<b>31 140 43</b>	Front power take-off electromagnetic coupling R.I. ....	28
<b>31 140 46</b>	Front power take-off electromagnetic coupling A.D. ....	31
<b>31 162 52</b>	Front lift support R.I. ....	35
	Front power take-off faults diagnosis .....	38
	Front power take-off faults code signals .....	39
	Front power take-off faults codes .....	41
	Front power take-off calibration .....	46
	Front electronic lift faults diagnosis .....	58
	Front electronic lift faults code signals .....	59
	Front electronic lift faults codes .....	61
	Front electronic lift calibration .....	72
	Troubleshooting fault codes .....	89

---

## SECTION 41 - STEERING

BOOK 5 - 87026006

### Chapter 1 - Steering

#### CONTENTS

Section	Description	Page
<b>41 000</b>	Torque settings main data .....	1
	Components .....	2
	Operation .....	3
	Troubleshooting .....	5
	Tools .....	6
<b>41 204</b>	Hydrostatic steering control valve - Removal-Refitting .....	7
	Hydrostatic steering control valve - Disassembly-Assembly .....	12
	Hydrostatic steering control valve - Bench testing .....	26

## SECTION 44 - AXLE AND WHEELS

BOOK 5 - 87026006

### Chapter 1 - Axle and Wheels

#### CONTENTS

Section	Description	Page
<b>44 000</b>	Main specifications .....	1
	Sectional Diagrams .....	3
	Tightening Torque .....	4
	Equipment .....	6
	Troubleshooting .....	7
<b>44 101</b>	Removal - Refitting .....	8
<b>44 101</b>	Wheel hub disassembly - Assembly .....	11
<b>44 101</b>	Snub axle overhaul .....	14

---

## SECTION 50 - CAB AIR CONDITIONING SYSTEM

BOOK 5 - 87026006

### Chapter 1 - Cab Air Conditioning System

#### CONTENTS

Section	Description	Page
50 000	Safety instructions .....	2
	General characteristics .....	3
	Tools .....	4
	Operating principles .....	5
	Main components of the cab air conditioning system .....	6
	Cab controls .....	12
	Use .....	15
	Refrigerant recovery - recycling and evacuation - charging stations .....	16
	Troubleshooting .....	29
50 200	Functional testing of air conditioning system .....	23
	Compressor drive belt tension adjustment .....	34
	Air conditioning unit removal and re-fitting .....	35

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 1 - Instruments (Below S/N 1180245)

#### CONTENTS

Section	Description	Page
55100	Analog instruments .....	1
	Transmitters, sensors and switches .....	5
	Digital instruments .....	13
	Maintenance .....	16

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 2 - Instruments (Between S/N's 1180245 and 1203065)

#### CONTENTS

#### UNDER DEVELOPMENT

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 3 - Instruments (After S/N 1203065)

#### CONTENTS

Section	Description	Page
55 100	Analog instruments .....	1
	Transmitters, sensors and switches .....	5
	Digital instruments .....	13
	Maintenance .....	16

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 4 - Components (Below S/N 1180245)

#### CONTENTS

Section	Description	Page
55 440	Introduction .....	1
	Dashboard component description .....	1
	Cap component description .....	7
	External controls .....	12
	Central panel controls .....	12
	Maintenance .....	14

---

**SECTION 55 - ELECTRICAL SYSTEMS**

BOOK 6 - 87026007

**Chapter 5 - Components (Between S/N's 1180245 and 1203065)**

CONTENTS

**UNDER DEVELOPMENT**

**SECTION 55 - ELECTRICAL SYSTEMS**

BOOK 6 - 87026007

**Chapter 6 - Components (After S/N 1203065)**

CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
<b>55 440</b>	Introduction .....	1
	Description of components .....	1
	Maintenance .....	18

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 7 - Starting System (Below S/N 1180245)

#### CONTENTS

Section	Description	Page
<b>55 000</b>	Technical information .....	1
	Tightening torque .....	1
	Description and operation .....	2
	Starting circuit wiring diagram .....	3
	Troubleshooting .....	4
	System tests .....	5
<b>55 201</b>	Starter motor removal and refitting .....	7
	Overhaul .....	8
	Bench tests .....	10

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 8 - Starting System (Between S/N's 1180245 and 1203065)

#### CONTENTS

**UNDER DEVELOPMENT**

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 9 - Starting System (After S/N 1203065)

#### CONTENTS

Section	Description	Page
<b>55 000</b>	Technical data .....	See chapter 7, page 1
	Tightening torque .....	See chapter 7, page 1
	Troubleshooting .....	See chapter 7, page 4
	System testing .....	See chapter 7, page 5
<b>55 201</b>	Starter motor removal–installation .....	See chapter 7, page 7
	Overhaul .....	See chapter 7, page 8
	Bench tests .....	See chapter 7, page 10
	Description and operation .....	1
	Starting circuit wiring diagram .....	2

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 10 - Charging System (Below S/N 1180245)

#### CONTENTS

Section	Description	Page
<b>55 000</b>	Technical information .....	1
	Tightening torque .....	1
	Description and operation .....	2
	System testing and troubleshooting .....	4
<b>55 301</b>	Removal, re–installation and servicing .....	9

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 11 - Charging System (Between S/N's 1180245 and 1203065)

CONTENTS

**UNDER DEVELOPMENT**

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 12 - Charging System (After S/N 1203065)

CONTENTS

Section	Description	Page
<b>55 000</b>	Technical information .....	See chapter 10, page 1
	Tightening torques .....	See chapter 10, page 1
	Description and operation .....	See chapter 10, page 2
<b>55 301</b>	Removal-installation and overhaul .....	See chapter 10, page 9
	System testing and troubleshooting .....	1

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87026007

### Chapter 13 - Battery

#### CONTENTS

Section	Description	Page
55 000	Technical information .....	1
	Description and operation .....	1
55 300	Removal and re-installation .....	2
	Battery checking and maintenance .....	3
	Charging the battery .....	4
	Battery problems - Frequent causes .....	7

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 7 - 87026008

### Chapter 14 - Electrical Circuits (Below S/N 1180245)

#### CONTENTS

Section	Description	Page
55 100	Tractor with cab - Component location .....	3
	Tractor without cab - Component location .....	4
	Electrical circuit components .....	5
	Dashboard - Component location .....	9
	Main wiring (version with cab) .....	10
	Fuse and relays (version with cab) .....	11
	Main wiring (version without cab) .....	14
	Fuse and relays (version without cab) .....	15
	Symbols used in electrical circuits .....	17
	Electric wire colour coding .....	18
	Electrical diagram and connector identification code .....	18
	Wiring diagrams .....	20
	- General diagrams .....	20

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 7 - 87026008

### Chapter 14 - Electrical Circuits (Below S/N 1180245) (Continued)

#### CONTENTS

Section	Description	Page
	- Connector overview .....	27
	Main front wiring (engine and light circuits) .....	32
	- Ignition circuit .....	33
	- Side light, main beam and dipped headlight, parking light circuits .....	39
	Main cab wiring (version with cab) .....	46
	Main platform wiring (version without cab) .....	48
	- Direction indicator and hazard light circuits .....	49
	- Ventilation, air conditioning, windscreen and rear window wiper, work and internal lighting circuits .....	54
	Main rear wiring (transmission circuit) .....	61
	- Differential lock and brake light circuit .....	63
	- Trailer brake light circuit .....	70
	- Rear electronic lift circuit .....	76
	- Front lift and PTO circuits .....	87
	- Power Shuttle circuit .....	90
	- Digital instrument circuit .....	100
	Alarm circuit wiring (N.A.S.O. version) .....	106
	- Alarm circuit (N.A.S.O. version) .....	107

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 7 - 87026008

### Chapter 15 - Electrical Circuits (Between S/N's 1180245 and 1203065)

#### CONTENTS

**UNDER DEVELOPMENT**

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 7 - 87026008

## Chapter 16 - Electrical Circuits (After S/N 1203065)

### CONTENTS

Section	Description	Page
<b>55 100</b>	Electrical circuit components .....	3
	Tractor with cab - Location of components .....	5
	Tractor without cab - Location of components .....	6
	Dashboard - Location of components .....	7
	Main wiring (Model with cab) .....	8
	Fuses and relays (Model with cab) .....	9
	Main wiring (Model without cab) .....	17
	Fuses and relays (Model without cab) .....	18
	Electrical circuit symbols .....	24
	Electrical wires colour coding .....	25
	Electrical diagram and connector identification code .....	25
	Wiring diagrams .....	26
	- General diagrams .....	26
	- Connector overview .....	56
	Main front wiring (engine and lights circuit) .....	61
	- Start-up circuit .....	62
	- Side lights, main beam and dipped headlights, parking lights circuits .....	68
	Main cab wiring (Model with cab) .....	75
	Main platform wiring (Model without cab): .....	76
	- Direction indicator and hazard light circuit .....	77
	- Ventilation, air conditioning, windscreen and rear window wiper, work and internal lighting circuits .....	82
	- Ventilation, air conditioning, windscreen and rear window wiper, work and internal lighting circuits .....	85
	Main rear wiring (Transmission circuit): .....	91
	- Differential lock and brake lights circuit .....	92
	- Trailer brake circuit .....	100
	- Rear mechanical lift transmission circuit .....	104

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 7 - 87026008

### Chapter 16 - Electrical Circuits (After S/N 1203065) (Continued)

#### CONTENTS

Section	Description	Page
	- Front PTO and lift circuit .....	114
	- POWER-SHUTTLE circuit .....	122
	- Digital instrument circuit .....	130
	Alarm circuit wiring (N.A.S.O. model) .....	136
	- Alarm circuit (N.A.S.O. model) .....	137
	ECU input/output wiring diagram for the front PTO and 4WD units .....	140
	ECU input/output wiring diagram for the POWER-SHUTTLE unit .....	143
	ECU input/output wiring diagram for the electronic lift unit .....	144

## SECTION 90 - CAB

BOOK 7 - 87026008

### Chapter 1 - Cab Removal - Re-fitting

#### CONTENTS

Section	Description	Page
90 150	Cab Removal - Re-fitting .....	1

## SECTION 90 - CAB

BOOK 7 - 87026008

### Chapter 2 - Internal Cab Components

#### CONTENTS

Section	Description	Page
55...	Removal-Re-fitting cab electrical components .....	1
90 156	Removal-Re-fitting glued cab windows .....	9

---

## GENERAL INSTRUCTIONS

### IMPORTANT NOTICE

All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND service technicians, in strict accordance with the instructions given and using any specific tools necessary. Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.

### SHIMMING

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the recorder values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated for each on shim.

### ROTATING SHAFT SEALS

For correct rotating shaft seal installation, proceed as follows:

- before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes;
- thoroughly clean the shaft and check that the working surface on the shaft is not damaged;
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal;
- coat the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- insert the seal in its seat and press down using a flat punch, do not tap the seal with a hammer or mallet;
- whilst inserting the seal, check that it is perpendicular to the seat; once settled, make sure that it makes contact with the thrust element, if required;
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations.

### O-RING SEALS

Lubricate the O-RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

### SEALING COMPOUNDS

Apply one of the following sealing compounds on the mating surfaces marked with an X: RTV SILMATE, RHO-DORSIL CAF 1 or LOCTITE PLASTIC GASKET.

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a metal brush;
- thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, petrol or a water and soda solution.

### BEARINGS

When installing bearings it is advised to:

- heat the bearings to 80 to 90 °C before fitting on the shafts;
- allow the bearings to cool before installing them from the outside.

### SPRING PINS

When fitting split socket spring pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral spring pins do not require special positioning.

## SPARE PARTS

Only use **original NEW HOLLAND spare parts** bearing the logo shown below.



Only original spare parts guarantee the same quality, duration and safety as they are the same parts that are assembled during production.

Only **original NEW HOLLAND parts** can offer this guarantee.

When ordering spare parts, always provide the following information:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found in the "Microfiches" or the "Spare Parts Catalogue", used for order processing.

## TOOLS

The tools that NEW HOLLAND propose and illustrate in this manual are:

- specifically researched and designed for use with NEW HOLLAND tractors;
- essential for reliable repair operations;
- accurately built and rigorously tested so as to offer efficient and long-lasting operation.

By using these tools, Repair Personnel will benefit from:

- operating in optimal technical conditions;
- obtaining the best results;
- saving time and effort;
- working in safe conditions.

## NOTE

Wear limit values indicated for certain parts should be considered to be recommended, but not binding. The terms "front", "rear", "right-hand" and "left-hand" (when referred to different parts) are intended as seen from the driving position with the tractor in the normal direction of movement.

## MOVING THE TRACTOR WITH THE BATTERY REMOVED

External power supply cables should only be connected to the respective positive and negative cable terminals, using efficient clamps that guarantee adequate and secure contact.

Disconnect all services (lights, windshield wipers, etc.) before starting the tractor.

If the tractor electrical system requires checking, carry out operations with the power supply connected. Once checking is completed, disconnect all services and switch off the power supply before disconnecting the cables.

## SAFETY REGULATIONS

### WARNING AND DANGER SYMBOL



*This warning symbol points out important personal safety messages. Carefully read the following safety regulations and observe advised precautions in order to avoid potential hazards and safeguard your health and safety. In this manual the symbol is accompanied by the following key-words:*



**WARNING** - Warnings concerning unsuitable repair operations that may jeopardise the safety of Repair personnel.

**DANGER** - Specific warnings concerning potential hazards for operator safety or for other persons directly or indirectly involved.

## ACCIDENT PREVENTION

Most accidents or injuries that occur in workshops are the result of non-observance of simple and fundamental safety regulations. For this reason, IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED by foreseeing possible causes and consequently acting with the necessary caution and care.

Accidents may occur with all types of machine, regardless of how well the machine in question was designed and built.

A careful and judicious service technician is the best guarantee against accidents.

Precise observance of the most basic safety rule is normally sufficient to avoid many serious accidents.

**DANGER.** Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

## SAFETY RULES

### GENERAL GUIDELINES

- ◇ Carefully follow specified repair and maintenance procedures.
- ◇ Do not wear rings, wristwatches, jewellery, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips that may remain entangled in moving parts. It is advised to wear approved safety clothing, e.g.: non-slip footwear, gloves, safety goggles, helmets, etc.
- ◇ Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a

trained technician who is assisting with the operation in question.

- ◇ Do not operate the machine or use any of the implements from different positions, other than the driver's seat.
- ◇ Do not carry out operations on the machine with the engine running, unless specifically indicated.
- ◇ Stop the engine and check that the hydraulic circuits are pressure-free before removing caps, covers, valves, etc.
- ◇ All repair and maintenance operations must be carried out using extreme care and attention.
- ◇ Service steps and platforms used in the workshop or elsewhere should be built according to standard accident prevention regulations.
- ◇ Disconnect the batteries and label all controls to indicate that the tractor is being serviced. Any parts that are to be raised must be locked in position.
- ◇ Do not check or fill fuel tanks, accumulator batteries, nor use starting liquid when smoking or near naked flames, as these fluids are inflammable.
- ◇ Brakes are inoperative when manually released for repair or maintenance purposes. Use blocks or similar devices to control the machine in these conditions.
- ◇ The fuel nozzle should always be in contact with the filling aperture. Maintain this position until filling operations are completed in order to avoid possible sparks caused by the accumulation of static electricity.

- ◇ Only use specified towing points for towing the tractor. Connect parts carefully. Make sure that all pins and/or locks are secured in position before applying traction. Never remain near the towing bars, cables or chains that are operating under load.
- ◇ Transport tractors that cannot be driven using a trailer or a low-loading platform trolley, if available.
- ◇ When loading or unloading the tractor from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels. Firmly secure the tractor to the truck or trailer and lock the wheels in the position used by the carrier.
- ◇ Electric heaters, battery-chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- ◇ Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- ◇ Take extra care if bystanders are present.
- ◇ Never pour gasoline or diesel oil into open, wide or low containers.
- ◇ Never use gasoline, diesel oil or other inflammable liquids as cleaning agents. Use non-inflammable, non toxic commercially available solvents.
- ◇ Wear safety goggles with side guards when cleaning parts with compressed air.
- ◇ Limit the air pressure to a maximum of 2.1 bar, according to local regulations.
- ◇ Do not run the engine in confined spaces without suitable ventilation.
- ◇ Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- ◇ Never use naked flames for lighting when working on the machine or checking for leaks.
- ◇ All movements must be carried out carefully when working under, on or near the tractor. Wear protective equipment: helmets, goggles and special footwear.
- ◇ When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- ◇ If operating outside the workshop, position the tractor on a flat surface and lock in position. If working on a slope, lock the tractor in position. Move to a flat area as soon as is safely possible.
- ◇ Damaged or bent chains or cables are unreliable. Do not use them for lifting or towing. Always use suitable protective gloves when handling chains or cables.
- ◇ Chains should always be safely secured. Make sure that the hitch-up point is capable of sustaining the load in question. Keep the area near the hitch-up point, chains or cables free of all bystanders.
- ◇ Maintenance and repair operations must be carried out in a CLEAN and DRY area. Eliminate any water or oil spillage immediately.
- ◇ Do not create piles of oil or grease-soaked rags as they represent a serious fire hazard. Always store rags in a closed metal container. Before starting the tractor or implements, make sure that the driver's seat is locked in position. Also check that there are no persons within the tractor or implement range of action.
- ◇ Empty pockets of all objects that may fall unobserved into the tractor parts.
- ◇ In the presence of protruding metal parts, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- ◇ When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles. NEVER LOOK DIRECTLY AT THE WELDING ARC WITHOUT SUITABLE EYE PROTECTION.
- ◇ Metal cables tend to fray with repeated use. Always use suitable protective devices (gloves, goggles, etc.) when handling cables.
- ◇ Handle all parts carefully. Do not put your hands or fingers between moving parts. Wear suitable safety clothing - safety goggles, gloves and shoes.

**START UP**

- ◇ Never run the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- ◇ Never place the head, body, limbs, feet, hands or fingers near fans or rotating belts.

**ENGINE**

- ◇ Always loosen the radiator cap slowly before removing it to allow any remaining pressure in the system to be discharged. Filling up with coolant should only be carried out with the engine stopped or idling (if hot)..
- ◇ Never fill up with fuel when the engine is running, especially if hot, in order to prevent the outbreak of fire as a result of fuel spillage.
- ◇ Never check or adjust fan belt tension when the engine is running.  
Never adjust the fuel injection pump when the tractor is moving.
- ◇ Never lubricate the tractor when the engine is running.

**ELECTRICAL SYSTEMS**

- ◇ If it is necessary to use auxiliary batteries, remember that both ends of the cables must be connected as follows: (+) with (+) and (-) with (-). Avoid short-circuiting the terminals. **GAS RELEASED FROM BATTERIES IS HIGHLY INFLAMMABLE.** During charging, leave the battery compartment uncovered to improve ventilation. Never check the battery charge using "jumpers" (metal objects placed on the terminals). Avoid sparks or flames near the battery zone. Do not smoke to prevent explosion hazards.
- ◇ Before servicing operations, check for fuel or current leaks. Eliminate any eventual leaks before proceeding with work.
- ◇ Never charge batteries in confined spaces. Make sure that there is adequate ventilation in order to prevent accidental explosion hazards as a result of the accumulation of gases released during charging operations.
- ◇ Always disconnect the batteries before performing any kind of servicing on the electrical system.

**HYDRAULIC SYSTEMS**

- ◇ A liquid leaking from a tiny hole may be almost invisible but, at the same time, be powerful enough to penetrate the skin. Therefore, **NEVER USE HANDS TO CHECK FOR LEAKS** but use a piece of cardboard or wood for this purpose. If any liquid penetrates skin tissue, call for medical aid immediately. Failure to treat this condition with correct medical procedure may result in serious infection or dermatosis.

- ◇ In order to check the pressure in the system use suitable instruments.

**WHEELS AND TYRES**

- ◇ Make sure that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check the rims and tyres for damage.
- ◇ Stand away from (at the side of) the tyre when checking inflation pressure.
- ◇ Only check pressure when the tractor is unloaded and the tyres are cold, to avoid incorrect readings as a result of over-pressure. Do not use parts of recovered wheels as incorrect welding brazing or heating may weaken and eventually cause damage to the wheel.
- ◇ Never cut or weld a rim mounted with an inflated tyre.
- ◇ To remove the wheels, lock both the front and rear tractor wheels. After having raised the tractor, position supports underneath, according to regulations in force.
- ◇ Deflate the tyre before removing any objects that may be jammed in the tyre tread.
- ◇ Never inflate tyres using inflammable gases, as this may result in explosions and injury to bystanders.

**REMOVAL AND RE-FITTING**

- ◇ Lift and handle all heavy parts using suitable hoisting equipment. Make sure that parts are sustained by appropriate hooks and slings. Use the hoisting eyebolts for lifting operations. Extra care should be taken if persons are present near the load to be lifted.
- ◇ Handle all parts carefully. Do not put your hands or fingers between parts. Wear suitable safety clothing - safety goggles, gloves and shoes.
- ◇ Avoid twisting chains or metal cables. Always wear safety gloves when handling cables or chains.

**CONSUMABLES**

<b>PARTS TO BE FILLED</b>	<b>QUANTITY dm<sup>3</sup> (litres)</b>	<b>NEW HOLLAND RECOMMENDED PRODUCT</b>	<b>NEW HOLLAND SPECIFICATION</b>	<b>INTERNATIONAL SPECIFICATION</b>
Cooling system: without cab models TN65F, TN70F TN75F and TN80F . . . . models TN90F and TN95F with cab models TN65F, TN70F TN75F and TN80F . . . . models TN90F and TN95F .	10.5 11.5  12.5 13.5	Water and liquid <b>AMBRA AGRIFLU 50% + 50%</b>	NH 900 A	-
Windscreen washer tank . .	2	Water and liquid <b>AREXONS DP1*</b>	-	-
Fuel tank: main tank . . . . . side tank . . . . .	36.5 25.5	Decanted and fil- tered fuel oil	-	-
Crankcase sump: without filter: . . . . .  with filter: . . . . .	9.5  10.5	<b>AMBRA SUPER GOLD 15W - 40</b>	NH 330G (SAE 15W-40)	API CF-4/SG CCMC D4 MIL-L-2104E
Brake control circuit . . . . . With front brakes . . . . .	0.5 0.2	<b>AMBRA BRAKE LHM</b>	NH 610 A	ISO 7308
Front axle: axle case . . . . . lateral final drives without brakes (each) . . . . . lateral final drives with brakes (each) . . . . .	2.8 1.0 1.75	<b>AMBRA MULTI G</b>	NH 410 B	API GL4 ISO 32/46 SAE 10W-30
Rear transmission (bevel gear pair, lateral final drives and brakes), gearbox, hy- draulic lift, power take-off and hydrostatic steering: all models . . . . .  With Power-Shuttle: all models . . . . .	44  55			
Compression cups . . . . .	-	Grease <b>AMBRA GR9</b>	NH 710 A	NLGI 2

(\*) Detergent and anti-freeze to -10 °C with 50% of **AREXONS DP1** liquid. For temperatures below -10 °C use exclusively **AREXONS DP1** liquid.

## LUBRICANTS

COMPONENT TO BE FILLED OR TOPPED UP	QUANTITY gal. (litres)	RECOMMENDED NEW HOLLAND PRODUCTS	NEW HOLLAND NA SPECIFICATION	INTERNATIONAL SPECIFICATIONS
Cooling system: - without cab models TN70F, TN80F model TN95F . . . . .	2.3 (10.5) 2.5 (11.5)	Water and <b>AMBRA</b> <b>AGRIFLU</b> liquid <b>50% + 50%</b> (NH 900 A)	<b>50%</b> Antifreeze Ethylene Glycol Concentrate plus <b>50%</b> Clean Soft Water	M97B18-D
- with cab models TN70F, TN80F . model TN95F . . . . .	2.7 (12.5) 2.9 (13.5)			
Windscreen washer bottle .	0.43 (2)	Water and windscreeener wash fluid	Water and windscreeener wash	-
Fuel tank: - main tank . . . . .	8.0 (36.5)	Decanted and filtered diesel fuel	Decanted and filtered diesel fue	-
- side tank . . . . .	5.6 (25.5)			
Engine sump: - without filter: . . . . .	2.0 (9.5)	<b>AMBRA</b> <b>SUPER GOLD</b> oil <b>15W - 40</b> NH 330G (SAE 15W-40)	Premium Multi-Grade 15w-40	API CF-4/SG CCMC D4 MIL-L-2104E
- with filter: . . . . .	2.3 (10.5)			
Brake circuit . . . . .	0.1 (0.5)	<b>AMBRA BRAKE</b> <b>LHM</b> oil (NH 610 A)	NH mineral Based-BRAKE Oil (86541699 DS)	ISO 7308
with front brakes . . . . .	0.04 (0.2)			
Front axle: - axle housing . . . . .	0.6 (2.8)	<b>AMBRA</b> <b>MULTI G</b> oil (NH 410 B)	Multigrade Transmission, Rear Axle 134-D Hydraulic Oil	API GL4 ISO 32/46 SAE 10W-30
- final drives without brakes (each) . . . . .	0.21 (1.0)			
- final drives with brakes (each) . . . . .	0.38 (1.75)			
Rear transmission (bevel drive, final drives and brakes), gearbox, hydraulic lift, PTO and hydraulic steering: . . . . .	9.67 (44)			
- with Power Shuttle: All models . . . . .	14.5 (55)			
Grease fittings . . . . .	-	Grease <b>AMBRA GR9</b> (NH 710 A)	Multipurpose Grease Extreme Pressure (EP)	NLGI 2 ESE-M1C75-B ESN-M1C137-B
Air conditioning system - coolant . . . . .	kg 0.80 (1.65 lbs)	-	-	R-134a SP20
- oil . . . . .	kg 0.15 (0.33lbs)			

Product: New Holland TN65F/TN70F/TN75F/TN80F/TN90F/TN95F Tractor Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-tn65f-tn70f-tn75f-tn80f-tn90f-tn95f-tractor-service-repair-manual/>

---

70f-tn75f-tn80f-tn90f-tn95f-tractor-service-repair-manual/

8

## SECTION 00 - GENERAL - CHAPTER 1

Sample of manual. Download All 1574 pages at:

<https://www.arepairmanual.com/downloads/new-holland-tn65f-tn70f-tn75f-tn80f-tn90f-tn95f-tractor-service-repair-manual/>