

TN55, TN65, TN70, TN75 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	2
SECTION 18 - CLUTCH	3
SECTION 21 - TRANSMISSIONS	3
SECTION 23 - DRIVE LINES	5
SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION	6
SECTION 27 - REAR MECHANICAL TRANSMISSION	6
SECTION 31 - MECHANICAL POWER TAKE-OFF	7
SECTION 33 - BRAKING SYSTEM	8
SECTION 35 - HYDRAULIC SYSTEM	8
SECTION 41 - STEERING	10
SECTION 44 - AXLES AND WHEELS	11
SECTION 55 - ELECTRICAL SYSTEM	11
SECTION 90 - PLATFORM, CAB, BODYWORK	15

The following pages are the collation of the contents pages from each section and chapter of the TN55, TN65, TN70, TN75 Repair manual. Complete Repair part # 87034092.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book. The sections listed above are the sections utilized for the TN55, TN65, TN70, TN75 Tractors.

Sample of manual. Download All 886 pages at:

<https://www.arepairmanual.com/downloads/new-holland-tn55-tn65-tn70-tn75-tractor-service-repair-manual/>

SECTION 00 - GENERAL

BOOK 1 - 87034093

Chapter 1 - General Instructions

CONTENTS

Section	Description	Page
10 000	General Instructions	1

SECTION 10 - ENGINE

BOOK 1 - 87034093

Chapter 1 - Engine

CONTENTS

Section	Description	Page
10 000	General specifications	2
	Data	5
	Torque settings	22
	Tools	23
	Cross-sectional views	25
	Lubrication and cooling system diagrams	27
	Troubleshooting	29
10 001 10	Engine, Removal-Installation	33
10 001 30	Compression test	35
10 001 54	Engine, Removal-Assembly	36
10 414 10	Coolant Pump and Alternator Drive Belt - Tension adjustment	72
10 101 53	Valve guides, Replacement	73
10 101 60	Injector holder casing, Replacement	76
10 102 70	Front engine oil seal, Removal-Installation	78
10 106 12	Valve clearance adjustment	80
10 126 10	Fuel tank, Removal-Installation	82
10 218 30	Engine injectors, Removal-Installation	84
10 246 14	Bosch injection pump, Removal-Installation, timing and air bleed check	86
10 254 44	Exhaust pipe, Removal-Installation	92
10 402 11	Coolant pump, Removal-Installation, with radiator removed	93
10 402 28	Coolant pump, Overhaul	94
10 402 30	Thermostat, Removal-Installation	95
10 406 10	Radiator, Removal-Installation	97

SECTION 18 - CLUTCH

BOOK 1 - 87034093

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
18 000	General specifications	1
	Torque settings	2
	Tools	2
	Cross-sectional views	3
	Troubleshooting	5
18 110 10	Clutch - Removal-Installation	6
18 110 30	11"/11" Dual disk clutch - Test bench overhaul	11
18 110 30	11" Single disk clutch (Version with Power-Shuttle) - Test bench overhaul	15
18 100 40	Clutch adjustments	19

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87034094

Chapter 1 - Mechanical Transmission (8 x 8), (16 + 16) Synchro-Command, and 8 x 8 Non-Synchronized Transmissions

CONTENTS

Section	Description	Page
21 000	Main data	1
	Torque settings	2
	Special Tools	4
	Cross-sectional views	8
	Description and operation	14
	Troubleshooting	14
21 118 10	Rear Transmission/Gearbox, Removal-Installation	
21 118 12	16
21 118 85	Rear Transmission/Gearbox, Disassembly-Assembly	23
	Rear Transmission/Gearbox, driving and driven shafts clearance adjustments	31
21 130 10	Gearbox Control Lever, Removal-Installation	33
21 130 11	Range Gear Control Lever, Removal-Installation	34

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87034094

Chapter 2 - Power Shuttle Transmission (8 + 8 and 16 + 16 versions)

CONTENTS

Section	Description	Page
21 000	Main data	2
	Torque values	4
	Special tools	5
	Cross-sectional views	10
	Description and operation	15
21 118 85	Transmission-Gearbox, Disassembly-Assembly	16
21 134 46	Power shuttle control valve, Disassembly-Assembly	18
21 134 70	A + B Clutch valve solenoids, Removal-Installation	21
21 134 70	Dump valve solenoid, Removal-Installation	22
21 154 34		
21 154 60	Clutch casing, Disassembly-Assembly	23
	Description of systems (ECM and CDU)	28
	Automatic self-diagnosis (ECM)	29
	ECM First start up	30
	Diagnosis during operation	31
	Calibration and diagnostic unit (CDU)	32
	Power shuttle fault code priority	33
	Fault codes indication	36
	Calibration and diagnostics unit use	37
	HH menu access	38
	H1 - Clutches A and B calibration error codes	40
	H2 - Clutches A and B calibration values display	45
	H3 - System configuration	46
	H4 - Power shuttle hardware and software revision levels	48
	H5 - Control switch diagnosis	49
	H6 - Clutch A fill time	54
	H7 - Clutch B fill time	56
	H8 - Erasure of data stored in NVM	58
	H9 - Voltmeter functions	59
	HA - Clutch pedal potentiometer and status switch	63
	Clutch pedal potentiometer replacement	65

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87034094

Chapter 2 - Power Shuttle Transmission (8 + 8 and 16 + 16 versions) (Continued)

CONTENTS

Section	Description	Page
	HC - Transmission oil temperature sender	66
	HD - Hi/Lo Synchronizer operation (not used in standard)	67
	HE - Gear change adjustments	69
	HF - Stored error codes	70
	Troubleshooting fault codes	72
	Power Shuttle (8 x 8 and 16 x 16) electronic control unit input/output wiring diagram . .	276

SECTION 23 - DRIVE LINES

BOOK 3 - 87034095

Chapter 1 - Drive Lines

CONTENTS

Section	Description	Page
23 000	Main data	1
	Torque settings	2
	Cross-sectional views	3
	Description, operation and hydraulic diagrams	7
	Troubleshooting	7
23 101 26	Transmission shafts and guard, Disassembly - Assembly	8
23 101 40	Drive gear housing assembly, Removal - Installation	9
23 202 50	Drive gear housing assembly, Removal - Installation	9
23 101 42	Drive gear housing assembly removed, Disassembly - Assembly	11
23 202 52	Drive gear housing assembly removed, Disassembly - Assembly	13

SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION

BOOK 3 - 87034095

Chapter 1 - Front Axle Mechanical Transmission

CONTENTS

Section	Description	Page
25 000	Main Data	1
	Torque Settings	4
	Tools	7
	Cross-sectional Views	10
	Description and Operation	11
25 100 30	Front Axle, Removal-Installation	12
25 108 30	Front Epicyclic Final Drive, Disassembly-Assembly	16
25 108 46	Steering Knuckle Bearing Pins, Replacement	22
25 100 38	Wheel Hubs and Steering Knuckle Pins and Bearings, Removal-Replacement-Installation	22
25 100 38	Bevel Drive and Front Axle Differential Axle Housing, Disassembly-Assembly	25
25 102 20	Front Axle Bevel Drive, Overhaul	30
	Bevel Drive Adjustments	33
25 102 24	Front Axle Differential, Overhaul	40
25 102 27	Front Axle Differential with LIM-Slip Unit, Overhaul	41
44 511 80	Leading Drive Wheels Toe-in Check	43

SECTION 27 - REAR MECHANICAL TRANSMISSION

BOOK 3 - 87034095

Chapter 1 - Rear Mechanical Wheel Drive

CONTENTS

Section	Description	Page
27 000	Main data	1
	Torque settings	3
	Tools	5
	Cross-sectional views	9
	Description and operation	11
	Troubleshooting	11

SECTION 27 - REAR MECHANICAL TRANSMISSION

BOOK 3 - 87034095

Chapter 1 - Rear Mechanical Wheel Drive (Continued)

CONTENTS

Section	Description	Page
27 106 16	Rear Transmission/Gearbox, Removal-Installation	12
27 110 10	Differential Lock Engagement Sleeve, Adjusting	18
27 120 10	Final Drive Housing Assembly, Removal-Installation	
27 120 20	25
27 120 34	Drive Wheel Shaft, Removal-Installation	27
27 120 32	Epicyclic Final Drive, Removal-Installation	29

SECTION 31 - MECHANICAL POWER TAKE-OFF

BOOK 3 - 87034095

Chapter 1 - Mechanical Power Take-Off

CONTENTS

Section	Description	Page
31 000	Main data	1
	Tools	3
	Tightening torque	4
	Cross-sectional views	4
	Description and operation	6
	Troubleshooting	7
31 112 20	Mechanical power take-off, Removal-Installation	8

SECTION 33 - BRAKING SYSTEM

BOOK 3 - 87034095

Chapter 1 - Braking System

CONTENTS

Section	Description	Page
33 000	Main data	1
	Torque settings	2
	Cross-sectional views	3
	Tools	4
	Description and operation	5
	Troubleshooting	6
33 202 60	Right or left-hand brake, Removal-Installation	8
33 202 46	Braking system hydraulic pump, Removal-Installation	10
33 202 04	Brake hydraulic system - Air Bleeding	15
33 110 40	Parking brake, Brake disks Removal-Installation	
33 110 44	17
33 110 08	Handbrake control, Travel adjustment	18

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87034096

Chapter 1 - Rear Mechanical Hydraulic Lift

CONTENTS

Operation	Description	Page
35 000	Main data	1
	Torque settings	3
	Tools	5
	Cross-sectional views	7
	Description and operation	12
	Troubleshooting	16
35 110 40	Lift internal controls, Disassembly-Assembly	18
	Lift adjustments	22
35 110 08	Tie-rod adjustments	28
	Various adjustments	30
35 110 42	Lift cylinder and arms shaft, Disassembly-Assembly	32
35 114 14	Lift control valve (with control valve removed), Disassembly-Assembly	36
35 114 30	Lift pressure relief valve, Removal-Installation	40
35 114 32	Lift pressure relief valve (Setting)	40

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87034096

Chapter 2 - Open Centre System Auxiliary Control Valves

CONTENTS

Operation	Description	Page
35 000	Main data - Tools - Torque settings	2
	Cross-sectional views	3
	Description and operation	5
	Troubleshooting	see Lift - Chapter 1
35 204 46	Auxiliary control valves, Disassembly-Assembly (with the unit removed)	9

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87034096

Chapter 3 - Trailer Brake Auxiliary Control Valve

CONTENTS

Operation	Description	Page
35 000	Description and operation	1
	Cross-sectional view	1
	Troubleshooting	8
33 220 40	Trailer brake valve, Removal-Installation	11

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87034096

Chapter 4 - Non-Stop Flow Gear Pump

CONTENTS

Operation	Description	Page
35 000	Main data	1
	Torque settings - Description and operation	2
	Troubleshooting	see Lift - Chapter 1
35 104 30	Lift circuit hydraulic pump, Disassembly-Assembly (with unit removed)	4

SECTION 41 - STEERING

BOOK 4 - 87034096

Chapter 1 - Steering

CONTENTS

Operation	Description	Page
41 000	Torque settings main data - tools	2
	Operation	3
	Components	6
	Troubleshooting	7
41 204 10	Hydrostatic steering wheel, Replacement	9
41 204 30	Hydrostatic steering control valve, Removal - Installation	10
41 204 34	Hydrostatic steering control valve, (removed) Disassembly - Assembly	15
41 204 38	Hydrostatic steering control valve - Bench testing	30

SECTION 41 - STEERING

BOOK 4 - 87034096

Chapter 2 - Non-Stop Flow Gear Pump

CONTENTS

Operation	Description	Page
41 000	Main data	1
	Torque settings - Description and operation	2
	Troubleshooting	see Lift - Chapter 1 Section 35
41 206 20	Power steering oil pump Disassembly - Assembly (with unit removed)	3

SECTION 44 - AXLES AND WHEELS

BOOK 4 - 87034096

Chapter 1 - Axles and Wheels

CONTENTS

Section	Description	Page
44 000	Main data	1
	Cross-sectional views	3
	Torque settings	4
	Tools	6
	Troubleshooting	7
44 101 22	Front axle hub, Removal-Installation	8
44 101 30	Front axle, Removal-Installation	11
44 101 46	Stub axle, Overhaul	14
44 511 80	Checking the alignment of the leading wheels	18

SECTION 55 - ELECTRICAL SYSTEM

BOOK 5 - 87034097

Chapter 1 - Instruments

CONTENTS

Section	Description	Page
55 000	Analog instruments	2
	Controls	4
	Transmitters, sensors and switches	6

SECTION 55 - ELECTRICAL SYSTEM

BOOK 5 - 87034097

Chapter 2 - Starting System

CONTENTS

Section	Description	Page
55 000	Technical information	1
	Torque settings	1
	Description and operation	2
	Troubleshooting	3
	System testing	4
55 201 50	Starter motor, Removal-Installation	6
55 201 54	Starter motor, Disassembly-Assembly	7
	Bench tests	9

SECTION 55 - ELECTRICAL SYSTEM

BOOK 5 - 87034097

Chapter 3 - Charging System

CONTENTS

Section	Description	Page
55 000	Technical information	1
	Torque settings	1
	Description and operation	2
	System testing and troubleshooting	4
55 301 10	Alternator, Removal-Installation	9
55 301 12	Alternator, Removed, Disassembly-Assembly	14

SECTION 55 - ELECTRICAL SYSTEM

BOOK 5 - 87034097

Chapter 4 - Battery

CONTENTS

Section	Description	Page
55 000	Technical information	1
	Description and operation	1
55 301 40	Battery removal-Installation	2
	Battery checking and maintenance	3
	Battery charging	4
	Battery problems - frequent causes	6

SECTION 55 - ELECTRICAL SYSTEM

BOOK 5 - 87034097

Chapter 5 - Electrical Circuits (Before S/N 1268128)

CONTENTS

Section	Description	Page
55 000	Fuses and relays (Model with cab)	2
	Symbols used in electrical circuits	4
	Electric wire colour code	5
	General diagram - Central part (electrohydraulic 4WD version. ISO version)	6
	General diagram - Central part (mechanical 4WD version. ISO version)	9
	General diagram - Front part (ISO version)	10
	General diagram - Rear part (ISO version)	13
	Lighting circuit diagram (ISO version)	14
	Electrohydraulic 4WD and brake lights circuit diagram	15
	Mechanical 4WD and brake lights circuit diagram	16
	Front corner lights and rear work lights circuit diagram	17
	General diagram - Central part (Power Shuttle version. NASO version)	18
	General diagram - Central part (Standard version. NASO version)	21
	General diagram - Front part (NASO version)	22
	General diagram - Rear part (NASO version)	23
Lighting circuit diagram (NASO version)	24	

SECTION 55 - ELECTRICAL SYSTEM

BOOK 5 - 87034097

Chapter 6 - Electrical Circuits (After S/N 1268128)

CONTENTS

Section	Description	Page
55 000	Electrical circuit components	2
	Location of fuses and relays (mechanical shuttle and power shuttle versions)	4
	Symbols used in electrical circuits	7
	Electric wire color code	9
	How to use the linear wiring diagrams	10
	Electrical circuits (mechanical shuttle and power shuttle versions)	11
	Ground location points (mechanical shuttle and power shuttle versions)	11
	Front part circuit (mechanical shuttle and power shuttle versions)	13
	Starting circuit (mechanical shuttle version)	18
	Starting circuit (power shuttle version)	A
	Operator safety circuit description and operation	B
	Operator safety circuit (mechanical shuttle version)	C
	Operator safety circuit (power shuttle version)	D
	Front lights circuit (mechanical shuttle and power shuttle versions)	E
	Lighting circuit (mechanical shuttle version)	F
	Lighting circuit (power shuttle version)	G
	4WD and brake lights circuit (mechanical shuttle version)	H
	4WD and brake lights circuit (power shuttle version)	I
	Transmission circuit (mechanical shuttle version)	J
	Transmission circuit (power shuttle version)	K
	Transmission circuit (power shuttle version)	L
	Power Shuttle electronic control unit inputs/outputs wiring diagram	M

SECTION 55 - ELECTRICAL SYSTEM

BOOK 5 - 87034097

Chapter 7 - Electrical Components

CONTENTS

Section	Description	Page
55 418 10	Multi-function instrument panel, Removal-Installation	2
55 440 08	Electronic Control Module (ECM), Replacement	3
55 510 20	Fuse box, Replacement	4
55 510 22	Fuses-Relays, Replacement	5

SECTION 90 - PLATFORM, CAB, BODYWORK

BOOK 5 - 87034097

Chapter 1 - Bodywork

CONTENTS

Section	Description	Page
90 100 22	Hood opening, Removal - Installation	2
90 100 80	Protective grill, Removal - Installation	3
90 100 84	Hood guard, Removal - Installation	4
90 110 50	Dashboard, Removal - Installation	5
90 114 26	ROPS (Roll Over Protection Structure), Removal - Installation	9
90 116 10	Right or left-hand mudguard, Removal - Installation	11
90 116 24	Rear guard, Replacement	13



GENERAL INSTRUCTIONS

IMPORTANT NOTICE

All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND service technicians, in strict accordance with the instructions given and using any specific tools necessary. Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.

BATTERY

Before carrying out any kind of service operations, disconnect and isolate the battery negative lead, unless otherwise requested for specific operations (e.g.: operations that require the engine running). Once the specific operation has been completed, disconnect the lead in order to complete the operation.

SHIMMING

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the recorder values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated for each on shim.

ROTATING SHAFT SEALS

For correct rotating shaft seal installation, proceed as follows:

- before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes;
- thoroughly clean the shaft and check that the working surface on the shaft is not damaged;
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal;
- coat the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- insert the seal in its seat and press down using a flat punch, do not tap the seal with a hammer or mallet;
- whilst inserting the seal, check that the it is perpendicular to the seat; once settled, make sure that it makes contact with the thrust element, if required;
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations.

O-RING SEALS

Lubricate the O-RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

SEALING COMPOUNDS

Apply one of the following sealing compounds on the mating surfaces marked with an X: LOCTITE 518, LOCTITE 5205, SUPERBOND 559 MASCHERPA or BETABLOCK A272M GURIT ESSEX.

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a metal brush;
- thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, petrol or a water and soda solution.

BEARINGS

When installing bearings it is advised to:

- heat the bearings to 80 to 90 °C (176 to 194 °F) before fitting on the shafts;
- allow the bearings to cool before installing them from the outside.


SPRING PINS

When fitting split socket spring pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral spring pins do not require special positioning.

SPARE PARTS

Only use original NEW HOLLAND spare parts bearing the logo shown below.



1

Only original spare parts guarantee the same quality, duration and safety as they are the same parts that are assembled during production.

Only **original NEW HOLLAND parts** can offer this guarantee.

When ordering spare parts, always provide the following information:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found in the "Microfiches" or the "Spare Parts Catalogue", used for order processing.

TOOLS

The tools that NEW HOLLAND propose and illustrate in this manual are:

- specifically researched and designed for use with NEW HOLLAND tractors;
- essential for reliable repair operations;
- accurately built and rigorously tested so as to offer efficient and long-lasting operation.

By using these tools, Repair Personnel will benefit from:

- operating in optimal technical conditions;
- obtaining the best results;
- saving time and effort;
- working in safe conditions.

NOTE

Wear limit values indicated for certain parts are recommended, but not binding. The terms "front", "rear", "right-hand" and "left-hand" (when referred to different parts) are intended as seen from the driving position with the tractor in the normal direction of movement.

MOVING THE TRACTOR WITH THE BATTERY REMOVED

External power supply cables should only be connected to the respective positive and negative cable terminals, using efficient clamps that guarantee adequate and secure contact.

Disconnect all services (lights, windshield wipers, etc.) before starting the tractor.

If the tractor electrical system requires checking, carry out operations with the power supply connected. Once checking is completed, disconnect all services and switch off the power supply before disconnecting the cables.

SAFETY REGULATIONS

WARNING AND DANGER SYMBOL

This warning symbol points out important messages concerning your safety.

Carefully read the following safety regulations and observe advised precautions in order to avoid potential hazards and safeguard your health and safety. In this manual the symbol is accompanied by the following key-words:

WARNING - Warnings concerning unsuitable repair operations that may jeopardise the safety of Repair personnel.

DANGER - Specific warnings concerning potential hazards for operator safety or for other persons directly or indirectly involved.



2

ACCIDENT PREVENTION

Most accidents or injuries that occur in workshops are the result of non-observance of simple and fundamental safety regulations. For this reason, IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED by foreseeing possible causes and consequently acting with the necessary caution and care.

Accidents may occur with all types of machine, regardless of how well the machine in question was designed and built.

A careful and judicious service technician is the best guarantee against accidents.

Precise observance of the most basic safety rule is normally sufficient to avoid many serious accidents.

DANGER. Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

SAFETY REGULATIONS

GENERAL GUIDELINES

- Carefully follow specified repair and maintenance procedures.
- Do not wear rings, wristwatches, jewellery, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips that may remain entangled in moving parts. It is advised to wear approved safety clothing, e.g.: non-slip footwear, gloves, safety goggles, helmets, etc.

- Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a trained technician who is assisting with the operation in question.
- Do not operate the machine or use any of the implements from different positions, other than the driver's seat.
- Do not carry out operations on the machine with the engine running, unless specifically indicated.
- Stop the engine and check that the hydraulic circuits are pressure-free before removing caps, covers, valves, etc.
- All repair and maintenance operations must be carried out using extreme care and attention.
- Service steps and platforms used in the workshop or elsewhere should be built according to standard accident prevention regulations.
- Disconnect the batteries and label all controls to indicate that the tractor is being serviced. Any parts that are to be raised must be locked in position.
- Do not check or fill fuel tanks, accumulator batteries, nor use starting liquid when smoking or near naked flames, as these fluids are inflammable.
- Brakes are inoperative when manually released for repair or maintenance purposes. Use blocks or similar devices to control the machine in these conditions.
- The fuel nozzle should always be in contact with the filling aperture. Maintain this position until filling operations are completed in order to avoid possible sparks caused by the accumulation of static electricity.

- Only use specified towing points for towing the tractor. Connect parts carefully. Make sure that all pins and/or locks are secured in position before applying traction. Never remain near the towing bars, cables or chains that are operating under load.
- Transport tractors that cannot be driven using a trailer or a low-loading platform trolley, if available.
- When loading or unloading the tractor from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels. Firmly secure the tractor to the truck or trailer and lock the wheels in the position used by the carrier.
- Electric heaters, battery-chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- Take extra care if bystanders are present.
- Never pour gasoline or diesel oil into open, wide or low containers.
- Never use gasoline, diesel oil or other inflammable liquids as cleaning agents. Use non-inflammable, non toxic commercially available solvents.
- Wear safety goggles with side guards when cleaning parts with compressed air.
- Limit the air pressure to a maximum of 2.1 bar (31 PSI), according to local regulations.
- Do not run the engine in confined spaces without suitable ventilation.
- Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- Never use naked flames for lighting when working on the machine or checking for leaks.
- All movements must be carried out carefully when working under, on or near the tractor. Wear protective equipment: helmets, goggles and special footwear.
- When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- If operating outside the workshop, position the tractor on a flat surface and lock in position. If working on a slope, lock the tractor in position. Move to a flat area as soon as is safely possible.
- Damaged or bent chains or cables are unreliable. Do not use them for lifting or towing. Always use suitable protective gloves when handling chains or cables.
- Chains should always be safely secured. Make sure that the hitch-up point is capable of sustaining the load in question. Keep the area near the hitch-up point, chains or cables free of all bystanders.
- Maintenance and repair operations must be carried out in a CLEAN and DRY area. Eliminate any water or oil spillage immediately.
- Do not create piles of oil or grease-soaked rags as they represent a serious fire hazard. Always store rags in a closed metal container. Before starting the tractor or implements, make sure that the driver's seat is locked in position. Also check that there are no persons within the tractor or implement range of action.
- Empty pockets of all objects that may fall unobserved into the tractor parts.
- In the presence of protruding metal parts, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles. NEVER LOOK DIRECTLY AT THE WELDING ARC WITHOUT SUITABLE EYE PROTECTION.
- Metal cables tend to fray with repeated use. Always use suitable protective devices (gloves, goggles, etc.) when handling cables.
- Handle all parts carefully. Do not put your hands or fingers between moving parts. Wear suitable safety clothing - safety goggles, gloves and shoes.

START UP

- Never run the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- Never place the head, body, limbs, feet, hands or fingers near fans or rotating belts.

ENGINE

- Always loosen the radiator cap slowly before removing it to allow any remaining pressure in the system to be discharged. Filling up with coolant should only be carried out with the engine stopped or idling (if hot)..
- Never fill up with fuel when the engine is running, especially if hot, in order to prevent the outbreak of fire as a result of fuel spillage.
- Never check or adjust fan belt tension when the engine is running. Never adjust the fuel injection pump when the tractor is moving.
- Never lubricate the tractor when the engine is running.

ELECTRICAL SYSTEMS

- If it is necessary to use auxiliary batteries, remember that both ends of the cables must be connected as follows: (+) with (+) and (-) with (-). Avoid short-circuiting the terminals. **GAS RELEASED FROM BATTERIES IS HIGHLY INFLAMMABLE.** During charging, leave the battery compartment uncovered to improve ventilation. Never check the battery charge using "jumpers" (metal objects placed on the terminals). Avoid sparks or flames near the battery zone. Do not smoke to prevent explosion hazards.
- Before servicing operations, check for fuel or current leaks. Eliminate any eventual leaks before proceeding with work.
- Never charge batteries in confined spaces. Make sure that there is adequate ventilation in order to prevent accidental explosion hazards as a result of the accumulation of gases released during charging operations.
- Always disconnect the batteries before performing any kind of servicing on the electrical system.

HYDRAULIC SYSTEMS

- A liquid leaking from a tiny hole may be almost invisible but, at the same time, be powerful enough to penetrate the skin. Therefore, **NEVER USE HANDS TO CHECK FOR LEAKS** but use a piece of cardboard or wood for this purpose. If any liquid penetrates skin tissue, call for medical aid immediately. Failure to treat this condition with correct medical procedure may result in serious infection or dermatosis.
- In order to check the pressure in the system use suitable instruments.

WHEELS AND TIRES

- Make sure that the tires are correctly inflated at the pressure specified by the manufacturer. Periodically check the rims and tires for damage.
- Stand away from (at the side of) the tire when checking inflation pressure.
- Only check pressure when the tractor is unloaded and the tires are cold, to avoid incorrect readings as a result of over-pressure. Do not use parts of recovered wheels as incorrect welding brazing or heating may weaken and eventually cause damage to the wheel.
- Never cut or weld a rim mounted with an inflated tire.
- To remove the wheels, lock both the front and rear tractor wheels. After having raised the tractor, position supports underneath, according to regulations in force.
- Deflate the tire before removing any objects that may be jammed in the tire tread.
- Never inflate tires using inflammable gases, as this may result in explosions and injury to bystanders.

REMOVAL AND RE-FITTING

- Lift and handle all heavy parts using suitable hoisting equipment. Make sure that parts are sustained by appropriate hooks and slings. Use the hoisting eyebolts for lifting operations. Extra care should be taken if persons are present near the load to be lifted.
- Handle all parts carefully. Do not put your hands or fingers between parts. Wear suitable safety clothing - safety goggles, gloves and shoes.
- Avoid twisting chains or metal cables. Always wear safety gloves when handling cables or chains.

CONSUMABLES

PARTS TO BE FILLED	QUANTITY liter (gal.)	NEW HOLLAND RECOMMENDED PRODUCT	NEW HOLLAND SPECIFICATION	INTERNATIONAL SPECIFICATION
Cooling system: without cab	10.0 (2.64)	Water and liquid AMBRA AGRIFLU 50% + 50%	Water and liquid Antifreeze Fleetguard ES Coolant EG (Ethylene Glycol) 50% + 50%	SAE1941 ASTM D4985 (EG)
Fuel tank:	65 (17.17)	Decanted and filtered fuel oil	-	-
Crankcase sump: without filter:	6.7 (1.77)	AMBRA Break-In Engine Oil (10W40)	NH Break-In Engine Oil (10W40)	API SE/CC 10W40
with filter:	7.5 (1.98)	AMBRA SUPER GOLD HSP Engine Oil (15W40)	NH Super Premium (15W40) Engine Oil	API CH-4/SS CCMC 04 UNI 20153 MIL-L2104C ACEA E3/E5
Brake control circuit	0.7 (0.18) 0.5 (0.13)	AMBRA BRAKE LHM Mineral Brake Oil	NH Brake Oil (86541699DS)	ISO 7308
Front axle: axle case	4.5 (1.19)	AMBRA MULTI G134 Hydraulic Oil	NH 134D Hydraulic Oil	API GL4 ISO 32/46 SAE 10W-30
TN55 lateral final drives without brakes (each)	0.8 (0.21)			
TN55 lateral final drives with brakes (each)	1.3 (0.34)			
TN65, TN70 and TN75 lateral final drives without brakes (each)	1.0 (0.26)			
TN65, TN70 and TN75 lateral final drives with brakes (each)	1.5 (0.40)			
Rear transmission (bevel gear pair, lateral final drives and brakes), gearbox, hydraulic lift, power take-off and hydrostatic steering: ..	42 (11.10)			
Compression cups	-	AMBRA GR9 Multipurpose Grease	NH Super Premium MP Lithium Grease (86506331)	NLGI 2

SECTION 10 - ENGINE

Chapter 1 - Engine

CONTENTS

Section	Description	Page
10 000	General specifications	2
	Data	5
	Torque settings	22
	Tools	23
	Cross-sectional views	25
	Lubrication and cooling system diagrams	27
	Troubleshooting	29
10 001 10	Engine, Removal-Installation	33
10 001 30	Compression test	35
10 001 54	Engine, Removal-Assembly	36
10 414 10	Coolant Pump and Alternator Drive Belt - Tension adjustment	72
10 101 53	Valve guides, Replacement	73
10 101 60	Injector holder casing, Replacement	76
10 102 70	Front engine oil seal, Removal-Installation	78
10 106 12	Valve clearance adjustment	80
10 126 10	Fuel tank, Removal-Installation	82
10 218 30	Engine injectors, Removal-Installation	84
10 246 14	Bosch injection pump, Removal-Installation, timing and air bleed check	86
10 254 44	Exhaust pipe, Removal-Installation	92
10 402 11	Coolant pump, Removal-Installation, with radiator removed	93
10 402 28	Coolant pump, Overhaul	94
10 402 30	Thermostat, Removal-Installation	95
10 406 10	Radiator, Removal-Installation	97

GENERAL SPECIFICATIONS	
Engine type:	
- Hp TN 55 - type 8035.05B.529	See data page 6-7
- Hp TN 65 - type 8035.05R.539	See data page 8-9
- Hp TN 70 - type 8035.25R.520	See data page 97
- Hp TN 75 - type 8035.25.529	See data page 10-11
Cycle	diesel, 4-stroke
Fuel injection	direct
No. of in-line cylinders	3
Cylinder liners	dry force-fitted in cylinder block
Piston diameter:	
- Hp TN 55	104 mm (4.09 inches)
- Hp TN 65	104 mm (4.09 inches)
- Hp TN 70	104 mm (4.09 inches)
- Hp TN 75	104 mm (4.09 inches)
Piston stroke	115 mm (4.53 inches)
Total displacement:	
- Hp TN 55	2931 cm ³ (0.77 gallons)
- Hp TN 65	2931 cm ³ (0.77 gallons)
- Hp TN 70	2931 cm ³ (0.77 gallons)
- Hp TN 75	2931 cm ³ (0.77 gallons)
Compression ratio, models TN 55 and TN 65	17:1 normal intake
Compression ratio, model TN 70 and TN 75	16.5:1 turbocharged
Maximum power:	
- Hp TN 55	37 kW (50 HP)
- Hp TN 65	44 kW (60 HP)
- Hp TN 70	51 kW (70 HP)
- Hp TN 75	53 kW (72 HP)
Max. power speed	2300 rpm
Max. torque speed: model TN 55	1400 rpm
Max. torque speed: model TN 65	1400 rpm
Max. torque speed: model TN 70	1400 rpm
Max. torque speed: model TN 75	1400 rpm
Number of main bearings	4
Sump pan	structural, cast iron

(continued)

(continued)

GENERAL SPECIFICATIONS	
Lubrication	forced, with gear pump
1st 50 hr oil (Break-in Engine Oil)	10W-40 - API SE/CC 10W-40
After 50 hr oil (AMBRA SUPER GOLD HSP Engine Oil)	15W-40 - API CH-4/SD
Pump drive	camshaft
Engine speed/oil pump speed ratio	2:1
Oil cleaning	mesh screen on oil pick-up and filter cartridge in delivery line
Normal oil pressure.	
Ideal pressure readings obtained at Oil Pan Temperature of 100 °C ± 5 °C (212 °F ± 9 °F)	
TN 55 and TN 65 at min ERPM (650 ± 25)	* > .69 bar (> 9.94 psi)
TN 55 and TN 65 at max ERPM (2475 ± 25)	* > 2.94 to 3.92 bar (> 42.6 to 56.8 psi)
TN 70 and TN 75 at min ERPM (650 ± 25)	* > 1.08 bar (> 15.62 psi)
TN 70 and TN 75 at max ERPM (2500 ± 25)	* > 1.96 bar (> 28.4 psi)
Pressure relief valve	built into pump housing
Valve opening pressure	3.5 bar (50.8 psi)
For further lubrication technical data	See page 19
Cooling system	water circulation
Radiator on models TN 55, TN 65	3-row vertical pipes with copper fins
Radiator on model TN 70 and TN 75	4-row vertical pipes with copper fins
Fan, attached to coolant pump pulley	6-blade steel exhauster fan
Coolant pump	centrifugal vane-type
Engine speed/coolant pump speed ratio	1:1.25
Temperature control	thermostat
Coolant thermometer	coloured scale divided into 3 sections
Temperature ranges corresponding to each section:	
- initial white section	30° to 65° C (86° to 149° F)
- middle green section (normal working conditions)	65° to 105° C (149° to 221° F)
- final red section	105° to 115° C (221° to 239° F)
For further cooling system data	See page 19
Rev counter	incorporated in control panel
Operating system	from gear on camshaft
Hour counter calibrated for engine speed of	1800 rpm

(continued overleaf)

* > means greater than

(continued)

GENERAL SPECIFICATIONS	
<p>Timing</p> <p>Inlet:</p> <ul style="list-style-type: none"> - start: before TDC - end: after BDC <p>Exhaust:</p> <ul style="list-style-type: none"> - start: before BDC - end: after TDC <p>Valve clearance for timing check</p> <p>Valve clearance for normal running (engine cold):</p> <ul style="list-style-type: none"> - inlet - exhaust <p>For further timing data</p>	<p>overhead valves operated camshaft located in engine block through tappets, pushrods and rockers; camshaft is driven by the crankshaft through helical gears</p> <p>12°</p> <p>31°</p> <p>50°</p> <p>16°</p> <p>0.45 mm (0.02 inches)</p> <p>0.30 ± 0.05 mm (0.01 ± 0.002 inches)</p> <p>0.30 ± 0.05 mm (0.01 ± 0.002 inches)</p> <p>See page 16</p>
<p>Fuel system</p> <p>Air cleaning</p> <p>Fuel supply pump</p> <p>Fuel filtering</p> <p>Minimum fuel flow rate with pump shaft rotating at 1600 rpm .</p> <p>Operated by eccentric cam</p> <p>BOSCH injection pump</p> <p>All-speed governor, incorporated in pump:</p> <p>BOSCH</p> <p>Automatic advance regulator, incorporated in pump:</p> <p>BOSCH</p> <p>For further fuel system data:</p> <p>For fixed advance (pump setting for start of delivery before TDC) - Pressure setting - Injection order, and other information regarding the BOSCH pump</p>	<p>dual cartridge dry air filter, with clogged filter indicator with centrifugal pre-filter and automatic dust ejector</p> <p>double diaphragm</p> <p>through wire filter in fuel supply pump, and replaceable cartridge on delivery line to injection pump</p> <p>100 litres/hour (26.42 gallons/hour)</p> <p>on camshaft</p> <p>distributor type</p> <p>centrifugal counterweights</p> <p>hydraulic</p> <p>refer to the data for the relevant engine type in the table on page 2</p>

FUEL SYSTEM DATA

Turbocharger (model TN 70 and TN 75):	
- GARRETT type	T 25
Injection pump	distributor type with incorporated speed governor and automatic advance regulator
BOSCH pump:	
- Hp TN 55	VE 3/11 F 1150 L 767
- Hp TN 65	VE 3/11 F 1150 L 766
- Hp TN 70	VE 3/11 F 1150 L 764-2
- Hp TN 75	VE 3/11 F 1150 L 764
Direction of rotation	counter-clockwise
Injection order	1-2-3

Injectors:	
BOSCH type	500307714
- Nozzle holder type	4791124
- Nozzle type	DLLA 132S 1320 - 99469341
Number of nozzle orifices	5
Diameter of nozzle orifices	0.23 mm (0.01 inches)
Pressure setting	260 to 272 bar (3771.2 to 3945.2 psi)
Fuel delivery lines - BOSCH pump	
- type	99441952
- dimensions	6 x 1.75 x 540 mm (0.24 x 0.07 x 21.26 in.)

**MODEL TN 55 - CALIBRATION DATA FOR BOSCH INJECTION PUMP
TYPE VE 3/11 F 1150 L 767 - VE 3/11 F 1150 L 767-1**

ASSEMBLY DATA

Pump timing on engine: delivery start $9^{\circ} \pm 0.5^{\circ}$ before TDC of cylinder 1 compression stroke.

Plunger pre-lift for timing on engine: mm 1 from P.M.I. (with tools **291754 - 291755**).

Cylinder No.1 delivery line union on pump: marked with letter A.

ASSEMBLY DIMENSIONS

SYMBOL	K	MS	ya	yb
mm (in.)	-	-	38.5 to 40.5 (1.52 to 1.59)	42.8 to 48.0 (1.69 to 1.89)

CALIBRATION TEST CONDITIONS

Test bench conforming to ISO 4008/1 .../2

Injectors conforming to ISO 7440-A61 - (1.688.901.027 and pad with calibrated hole \varnothing 0.5 mm; 0.02 in.).

Injector pressure setting 250 to 253 bar (3626.1 to 5120.1 psi).

Supply pressure:

..... 0.35 \pm 0.05 bar (5.1 \pm 0.7 psi).

Delivery pipes (conforming to ISO 4093.2):

..... 6 x 2 x 450 mm (0.24 x 0.08 x 17.72 in.)

Graduate drain time: : 30".

Test liquid: ISO 4113 at a temperature of $45^{\circ} \pm 1^{\circ}\text{C}$ ($113^{\circ} \pm 33.8^{\circ}\text{F}$).

1. START OF DELIVERY

Plunger pre-lift from TDC: mm -	Pump rotation (viewed from drive side): counter-clockwise	Injection order: 1-2-3
------------------------------------	--	------------------------

2. ADVANCE REGULATOR STROKE

Rpm: 1200	Advance stroke: mm 0.7 to 1.1 (inches 0.03 to 0.04)
-----------	---

3. FUEL SUPPLY PUMP PRESSURE

Rpm: 1200	Internal pressure: bar 8.1 to 8.7 (psi 117.5 to 126.2)
-----------	--

4. FULL LOAD DELIVERY

Rpm: 700	Delivery per 1000 shots: cm ³ 59.5 to 60.5 (gal. 0.0157 to 0.0159)	Spread: cm ³ - 3.5 (gal. -0.000925)
----------	--	---

5. SPREAD GOVERNOR AT IDLE SPEED

Rpm: 325	Delivery per 1000 shots: cm ³ 8.4 to 12.4 (gal. 0.0022 to 0.0032)	Spread: cm ³ (gal.)
----------	---	--------------------------------

6. SPREAD GOVERNOR AT MAXIMUM SPEED

Rpm: 1220	Delivery per 1000 shots: cm ³ 27 to 33 (gal. 0.007 to 0.008)	Spread: -
-----------	--	-----------

7. DELIVERY AT STARTING

Rpm: 100	Delivery per 1000 shots: cm ³ 60 to 100 (gal. 0.016 to 0.026)
----------	--

8. INJECTION ADVANCE PROGRESSION

Rpm	1200	1250
Advance stroke	mm (in.) 0.7 to 1.1 (0.03 to 0.04)	1.4 to 1.8 (0.06 to 0.07)

9. TRANSFER PRESSURE PROGRESSION

Rpm	1200	400	700
Internal pressure supply	bar (psi) 8.1 to 8.7 (117.5 to 126.2)	3.2 to 3.8 (46.4 to 55.1)	4.7 to 6.1 (68.1 to 88.5)

10. BACKFLOW

Rpm	400	1150
Backflow	l/h (gal./h) 13 to 33 (3.43 to 8.72)	25 to 37 (6.60 to 9.77)

(continued overleaf)

Note: the values shown above in brackets must be used for checking purposes only.

(continued)

11. DELIVERY PROGRESSION

Rpm	Delivery per 1000 shots: cm ³ (gallons)
1280	0 to 3.0 (0 to 0.0008)
1220	27 to 33 (0.007 to 0.008)
1150	50.5 to 53.5 (0.013 to 0.014)
700	59.5 to 60.5 (0.0157 to 0.0159)
400	52.8 to 60.8 (0.0139 to 0.016)

12. ZERO CAPACITY (STOP)

Rpm	Voltage (volts)	Delivery per 1000 shots: cm ³ (gal.)
325	0	0 to 3 (0 to 0.0008)

13. DELIVERY CHECK AT IDLE SPEED

Rpm		325	400	250
Delivery per 1000 shots:	cm ³ (gal.)	8.4 to 12.4 (0.002 to 0.003)	0 to 3.0 (0 to 0.0008)	31.2 to 39.2 (0.008 to 0.010)

Note: the values shown above in brackets must be used for checking purposes only.

14. AUTOMATIC START SUPPLEMENT

Rpm	Delivery per 1000 shots: cm ³ (gallons)
100	60 to 100 (0.0158 to 0.0264)
250	49 to 57 (0.0129 to 0.0151)
150	75 to 105 (0.0198 to 0.0277)

BENCH TEST PERFORMANCE DATA

BENCH TEST PERFORMANCE DATA					
Test conditions					
Fixed advance before TDC cylinder No.1 in compression stroke: (see previous page)			Relative humidity 70% ± 5.		
Engine without fan, air filter and exhaust silencer.			Ambient temperature 25° ± 3° C (77° ± 37.4° F).		
Atmospheric pressure 990 ± 10 mbar (14.36 ± 0.15 psi).			Specific gravity of diesel fuel 840 g/l. (7 lb./gal.)		
Throttle lever position	Braking load applied	Engine speed rpm	Power output with engine run-in for a total of:		Fuel consumption kg/h (lb./h)
			2 hours kW (hp)	50 hours kW (hp)	
Maximum	For maximum power output	2300	≥ 34.9 (47.4)	35.7 to 37.9 (48.5 to 51.5)	8.0 to 8.5 (17.64 to 18.74)
Maximum	For maximum torque	1400	≥ 27.3 (37.1)	27.9 to 29.6 (37.9 to 40.3)	6.0 to 6.4 (13.23 to 14.11)
Maximum	None (no-load)	2470 to 2500	-	-	-
Minimum	None (no-load)	625 to 675	-	-	-

MODEL TN 65 - CALIBRATION DATA FOR BOSCH INJECTION PUMP

TYPE VE 3/11 F 1150 L 766 - VE 3/11 F 1150 L 766-1

ASSEMBLY DATA

Pump timing on engine: delivery start $9^{\circ} \pm 0.5^{\circ}$ before TDC of cylinder 1 compression stroke.
 Plunger pre-lift for timing on engine: mm 1 (0.04 in.) from P.M.I. (with tools **291754 - 291755**).
 Cylinder No.1 delivery line union on pump: marked with letter A.

CALIBRATION TEST CONDITIONS

Test bench conforming to ISO 4008/1 .../2
 Injectors conforming to ISO 7440-A61 - (1.688.901.027 and pad with calibrated hole \varnothing 0.5 mm; 0.02 in.).
 Injector pressure setting 250 to 253 bar (3626.1 to 5120.1 psi).
 Supply pressure:
 0.35 \pm 0.05 bar (5.1 \pm 0.7 psi).
 Delivery pipes (conforming to ISO 4093.2):
 6 x 2 x 450 mm (0.24 x 0.08 x 17.72 in.)
 Graduate drain time: : 30".
 Test liquid: ISO 4113 at a temperature of $45^{\circ} \pm 1^{\circ}C$ ($113^{\circ} \pm 33.8^{\circ}F$).

ASSEMBLY DIMENSIONS

SYMBOL	K	MS	ya	yb
mm (in.)	-	-	36.5 to 38.5 (1.44 to 1.52)	41.4 to 46.6 (1.63 to 1.83)

1. START OF DELIVERY

Plunger pre-lift from TDC: mm -	Pump rotation (viewed from drive side): counter-clockwise	Injection order:1-2-3
---------------------------------	---	-----------------------

2. ADVANCE REGULATOR STROKE

Rpm: 1240	Advance stroke: mm 0.4 to 1.4 (inches 0.016 to 0.055)
-----------	---

3. FUEL SUPPLY PUMP PRESSURE

Rpm: 1200	Internal pressure: bar 7.7 to 8.9 (psi 111.7 to 129.1)
-----------	--

4. FULL LOAD DELIVERY

Rpm: 700	Delivery per 1000 shots: cm ³ 64.1 to 69.1 (gal. 0.017 to 0.018)	Spread: cm ³ \leq 3.5 (gal. \leq 0.000925)
----------	---	---

5. SPREAD GOVERNOR AT IDLE SPEED

Rpm: 325	Delivery per 1000 shots: cm ³ 15.9 to 23.9 (gal. 0.004 to 0.006)	Spread: cm ³ \leq 4.0 (gal. \leq 0.00106)
----------	---	--

6. SPREAD GOVERNOR AT MAXIMUM SPEED

Rpm: 1200	Delivery per 1000 shots: cm ³ 43.5 to 54.5 (gal. 0.011 to 0.014)	Spread:-
-----------	---	----------

7. DELIVERY AT STARTING

Rpm: 100	Delivery per 1000 shots: cm ³ 55 to 95 (gal. 0.015 to 0.025)
----------	---

8. INJECTION ADVANCE PROGRESSION

Rpm	1240	1280
Advance stroke	mm (in.) 0.4 to 1.4 (0.016 to 0.055)	1.3 to 1.9 (0.051 to 0.075)

9. TRANSFER PRESSURE PROGRESSION

Rpm	1200	400	
Internal pressure supply	bar (psi) 7.7 to 8.9 (111.7 to 129.1)	3.5 to 4.7 (50.8 to 68.17)	

10. BACKFLOW

Rpm	400	1100
Backflow	l/h (gal./h) 14 to 22 (3.70 to 5.81)	22 to 42 (5.81 to 11.10)