

# SERVICE MANUAL

Wheel Loaders LW190.B



Product: New Holland LW190.B Wheel Loaders Service Repair Manual  
Full Download: <https://www.atepairmanual.com/downloads/new-holland-lw190-b-wheel-loaders-service-repair-manual/>



**NEW HOLLAND**  
**CONSTRUCTION**

Product: New Holland LW190.B Wheel Loaders Service Repair Manual  
Full Download: <https://www.arepairmanual.com/downloads/new-holland-lw190-b-wheel-loaders-service-repair-manual/>

Sample of manual. Download All 490 pages at:  
<https://www.arepairmanual.com/downloads/new-holland-lw190-b-wheel-loaders-service-repair-manual/>

## **PROPRIETARY NOTICE**

The contents of this manual are proprietary data of New Holland Construction. Reproduction or use of any part for other than the operation and maintenance of New Holland Construction equipment is permissible only if expressly authorized in writing by New Holland Construction. Additional copies may be obtained from your New Holland Construction Dealer. Address requests for copies to your Dealer and refer to the publication number appearing on the bottom of the manual cover.

## **COMPANY POLICY**

Company policy, which is one of continuous improvement, reserves the right to change prices and to make changes in design and specification at any time without notice and without obligation to modify units previously built.

All data given in this book is subject to production variations. Dimensions and weights are approximate only and the illustrations do not necessarily show machines in standard condition. For exact information about any particular machine please consult your New Holland Construction Dealer.

## **PARTS AND ACCESSORIES**

Genuine parts and accessories have been specifically designed for these machines. We would like to point out that “non-genuine” parts and accessories have NOT been examined and released by the Company. The installation and or use of such products could have negative effects upon the design characteristics of your machine and thereby affect its safety. The company is not liable for any damage caused by the use of “non-genuine” parts and accessories.

## **MODEL CODES**

The range of machines listed may not be available in all countries or markets therefore, for the latest information consult your local New Holland Construction Dealer.

### **MODEL**

LW190.B

### **ENGINE TYPE - H.P.**

## **OWNER ASSISTANCE**

We at New Holland and your New Holland dealer want you to be completely satisfied with your investment. Normally any problems with your equipment will be handled by your dealer's Service Department. Sometimes, however, misunderstandings can occur. If your problem has not been handled to your satisfaction, we suggest the following.

1. Contact the owner or General Manager of the dealership, explain the problem, and request assistance. When additional assistance is needed, your dealer has direct access to our office.

2. If you cannot obtain satisfaction by doing this, contact the New Holland Construction office and provide them with:

- Your name, address, and telephone number
- Machine model and serial number
  - Dealership name and address
  - Machine purchase date and amount of use
  - Nature of problem

### **NEW HOLLAND CONSTRUCTION**

**245 E North Ave**

**Carol Stream, IL 60188**

**Ph # (630) 260-4000**

When contacting New Holland, be aware that your problem will likely be resolved in the dealership using the dealer's facilities, equipment, and personnel. So it is important that your initial contact be with the dealer.

---

## **SPARE PARTS**

---

To maintain operating efficiency, use NEW HOLLAND original spare parts. When ordering parts, give the following information:

- Machine model
- Machine and engine serial numbers
- Part number from the Parts Catalog

## TO THE OWNER:

The warranty coverage that is extended to your machine is explained in the Warranty and Limitation of Liability form. Your dealer will provide you with a copy of the warranty and retain a copy which you have signed. After you read the warranty, ask your dealer to explain any points that you may not understand.

The machine was designed to power and propel itself. It is intended to move material in the normal and customary applications.

Do not modify or alter or permit anyone else to modify or alter this machine or any of its components mechanical function with first consulting an authorized New Holland Construction dealer. If you have any questions regarding machine modifications, contact New Holland Construction, 245 E. North Ave., Carol Stream, IL 60188.

Your safety and the safety of those around you depend upon the care and good judgment you use while operating this equipment. Read the safety precautions carefully.

After you have operated the machine for 50 hours, take your machine and this manual to your selling dealer. He will perform the factory recommended 50-hour service. You will be responsible for the cost of lubricants, fluids, filters and other items replaced as part of normal maintenance. Prior to taking the machine to your selling dealer for service, it is recommended that you contact them to determine any other charges for which you may be responsible.

All data given in this book is subject to product variations. Dimensions and weights are approximate only and the illustrations do not necessarily show machines in standard condition. For exact information about any particular machine, please consult your New Holland Construction dealer.



**CAUTION: THIS SYMBOL IS USED THROUGHOUT THIS BOOK WHENEVER PERSONAL SAFETY IS INVOLVED. TAKE TIME TO READ AND FOLLOW THE INSTRUCTIONS. BE CAREFUL!**

**CAUTION: PICTURES IN THIS MANUAL MAY SHOW PROTECTIVE SHIELDING OPEN OR REMOVED TO BETTER ILLUSTRATE A PARTICULAR FEATURE OR ADJUSTMENT.**

**BE CERTAIN, HOWEVER, TO CLOSE OR REPLACE ALL SHIELDING BEFORE OPERATING THE MACHINE.**

## IMPROVEMENTS

New Holland Construction is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

# PRECAUTIONARY STATEMENTS

## PERSONAL SAFETY

Throughout this manual and on machine decals, you will find precautionary statements (“CAUTION”, “WARNING”, and “DANGER”) followed by specific instructions. These precautions are intended for the personal safety of you and those working with you. Please take the time to read them.



**CAUTION: THE WORD “CAUTION” IS USED WHERE A SAFE BEHAVIORAL PRACTICE ACCORDING TO OPERATING AND MAINTENANCE INSTRUCTIONS AND COMMON SAFETY PRACTICES WILL PROTECT THE OPERATOR AND OTHERS FROM ACCIDENT INVOLVEMENT.**



**WARNING: THE WORD WARNING DENOTES A POTENTIAL OR HIDDEN HAZARD WHICH HAS A POTENTIAL FOR SERIOUS INJURY. IT IS USED TO WARN OPERATORS AND OTHERS TO EXERCISE EVERY APPROPRIATE MEANS TO AVOID A SURPRISE INVOLVEMENT WITH MACHINERY.**



**DANGER: THE WORD “DANGER” DENOTES A FORBIDDEN PRACTICE IN CONNECTION WITH A SERIOUS HAZARD.**

**FAILURE TO FOLLOW THE “CAUTION”, “WARNING”, “DANGER”, AND “STOP” INSTRUCTIONS MAY RESULT IN SERIOUS BODILY INJURY OR DEATH.**

## MACHINE SAFETY

Additional precautionary statements (“ATTENTION” and “IMPORTANT”) are followed by specific instructions. These statements are intended for machine safety.

*ATTENTION: The word “ATTENTION” is used to warn the operator of potential machine damage if a certain procedure is not followed.*

*IMPORTANT: The word “IMPORTANT” is used to inform the reader of something he needs to know to prevent minor machine damage if a certain procedure is not followed.*

## SAFETY RULES

This symbol is your safety alert sign. It means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

Read and heed all safety instruction carrying the signal words **WARNING** and **DANGER**.

**STUDY THE OPERATION AND MAINTENANCE INSTRUCTION MANUAL THOROUGHLY BEFORE STARTING, OPERATING, MAINTAINING, FUELING OR SERVICING THIS MACHINE.**



MOST ACCIDENTS ARE CAUSED BY FAILURE OF SOME INDIVIDUAL TO FOLLOW SIMPLE AND FUNDAMENTAL SAFETY RULES OR PRECAUTION. FOR THIS REASON MOST ACCIDENTS CAN BE PREVENTED BY RECOGNIZING THE REAL CAUSE AND DOING SOMETHING ABOUT IT BEFORE ACCIDENT OCCURS. REGARDLESS OF THE CARE USED IN THE DESIGN AND CONSTRUCTION OF ANY TYPE OF EQUIPMENT THERE ARE MANY CONDITIONS THAT CAN'T BE COMPLETELY SAFEGUARDED AGAINST WITHOUT INTERFERING WITH REASONABLE ACCESSIBILITY AND EFFICIENT OPERATION.



**“live with it”**

**CALIFORNIA**

**PROPOSITION 65 WARNING**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



## **SAFETY PRECAUTION INFORMATION**

**UNSAFE OPERATING PRACTICES AND IMPROPER USE OF THE MACHINE AND ITS ATTACHMENTS ON THE PART OF THE OPERATOR OR SERVICE TECHNICIAN CAN RESULT IN INJURIES. OBSERVE THE FOLLOWING SAFETY PRECAUTIONS AT ALL TIMES:**

- 1. FOR SERVICING, THE MACHINE SHOULD BE ON LEVEL TERRAIN, ENGINE STOPPED WITH THE WHEELS BLOCKED OR THE ENTIRE MACHINE SOLIDLY SUPPORTED WITH THE WHEELS OFF THE GROUND BEFORE SERVICING ANY COMPONENT OF THE DRIVETRAIN.**
- 2. FOR SERVICING UNDER THE MOVABLE EQUIPMENT, SUCH AS OPERATOR'S SEAT, ENGINE HOODS, ETC. MOVE THE EQUIPMENT ASSEMBLY TO THE LATCHED POSITION AND SECURELY LATCH.**
- 3. DO NOT OPERATE THE MACHINE UNLESS ALL MOVABLE EQUIPMENT IS LATCHED IN THE OPERATE POSITION.**
- 4. DO NOT SERVICE THE MACHINE WITH A RAISED HYDRAULIC EQUIPMENT UNLESS THE HYDRAULIC EQUIPMENT IS RESTING ON LOCK PINS OR CYLINDER LOCKING TOOLS OR FIXTURES.**
- 5. DO NOT SERVICE THE MACHINE WITH THE ENGINE RUNNING UNLESS THE MACHINE IS PROPERLY AND SECURELY SUPPORTED WITH ALL FOUR WHEELS OFF THE GROUND.**
- 6. USE CAUTION WHEN SERVICING THE UNIT AROUND MOVING PARTS.**
- 7. DO NOT TILT ANY MOVABLE EQUIPMENT WITHOUT PROPER INSTRUCTION.**
- 8. DO NOT TILT ANY MOVABLE EQUIPMENT WITHOUT USING THE PROPER TOOLS.**
- 9. REINSTALL ALL SHIELDS REMOVED FOR SERVICE.**
- 10. NEVER LOOSEN ANY HYDRAULIC CONNECTIONS BEFORE RELIEVING THE PRESSURE IN THE HYDRAULIC SYSTEM.**
- 11. WEAR EYE PROTECTION SUCH AS GOGGLES, ETC.**
- 12. WEAR EAR PROTECTION SUCH AS EARPLUGS, ETC. WHEN YOU FEEL THE NOISE LEVEL IS UNCOMFORTABLE.**
- 13. IF ANY SERVICING OR ADJUSTMENTS REQUIRE THE BATTERY TO BE DISCONNECTED, DISCONNECT THE (-) NEGATIVE GROUND CABLE.**
- 14. WHEN SERVICING ELECTRICAL COMPONENTS, DISCONNECT THE (-) NEGATIVE GROUND CABLE.**
- 15. IF AN ELECTRONIC EQUIPMENT REQUIRES REMOVAL FROM THE DASH AREA OR THE MACHINE, DISCONNECT THE (-) NEGATIVE GROUND BATTERY CABLE. THIS WILL SHUT OFF POWER TO THE ELECTRICAL SYSTEM AND PREVENT DAMAGE TO THE ELECTRICAL SYSTEM.**
- 16. IF WELDING IS REQUIRED ON THE MACHINE, DISCONNECT THE (-) NEGATIVE GROUND CABLE. FAILURE TO DISCONNECT THE BATTERY MAY RESULT IN DAMAGE TO THE ELECTRICAL SYSTEM, MONITORING SYSTEM AND/OR OTHER ELECTRICAL COMPONENTS.**
- 17. IF WELDING IS REQUIRED ON AN ATTACHMENT, REMOVE THE ATTACHMENT FROM THE MACHINE.**

18. GIVE COMPLETE AND UNDIVIDED ATTENTION TO THE JOB AT HAND SO THAT COMPLETE CONTROL OF THE MACHINE IS MAINTAINED AT ALL TIMES.
19. DRIVE SLOWLY OVER ROUGH GROUND AND ON SLOPES; KEEP ALERT FOR HOLES, DITCHES AND OTHER IRREGULARITIES THAT MAY CAUSE THE MACHINE TO OVERTURN.
20. AVOID STEEP HILLSIDE OPERATION WHICH COULD CAUSE THE MACHINE TO OVERTURN.
21. NEVER TRANSPORT A LOADED BUCKET AT FULL HEIGHT. OPERATE THE MACHINE WITH THE LOAD AS LOW AS POSSIBLE UNTIL IT BECOMES NECESSARY TO RAISE THE BOOM TO DISCHARGE THE LOAD INTO A TRUCK, CONTAINER, ETC.
22. REDUCE SPEED WHEN TURNING SO THERE IS NO DANGER OF OVERTURNING.
23. NEVER DRIVE UP OR BACK UP A HILL OR INCLINE WITH A RAISED BOOM OR THE MACHINE COULD OVERTURN.
24. ALWAYS LOOK BEHIND YOU BEFORE BACKING UP THE MACHINE.
25. MAINTAIN PROPER FLUID LEVELS TO PREVENT LOSS OF POWER, BRAKING OR OTHER FUNCTIONS.
26. DO NOT ALLOW PASSENGERS TO RIDE ON THE MACHINE AT ANY TIME.
27. DO NOT ALLOW CHILDREN TO OPERATE THE MACHINE OR RIDE ON THE MACHINE AT ANY TIME.
28. DO NOT ALLOW ANYONE TO OPERATE OR SERVICE THE MACHINE WITHOUT PROPER INSTRUCTION.
29. OSHA REQUIRES THAT ALL OPERATORS BE INSTRUCTED ON THE PROPER OPERATION OF THE MACHINE BEFORE THEY OPERATE THE UNIT.
30. DO NOT OPERATE THE LOADER IN ANY POSITION OTHER THAN WHILE IN THE OPERATOR'S SEAT WITH THE SEAT BELT SECURELY FASTENED.
31. BEFORE STARTING THE ENGINE, BE SURE THAT ALL OPERATING CONTROLS ARE IN NEUTRAL AND THE PARKING BRAKE IS ENGAGED.
32. NEVER OPERATE THE ENGINE IN A CLOSED BUILDING WITHOUT ADEQUATE VENTILATION.
33. REFUEL THE MACHINE OUTDOORS WITH THE ENGINE SHUT OFF. REPLACE THE FUEL CAP SECURELY. USE AN APPROVED FUEL CONTAINER. DO NOT SMOKE WHEN HANDLING FUEL. AVOID SPILLING FUEL.
34. AFTER OPERATING THE ENGINE, NEVER TOUCH THE MUFFLER, EXHAUST PIPE, ENGINE OR RADIATOR UNTIL THEY HAVE HAD TIME TO COOL.
35. DRESS APPROPRIATELY – WEAR RELATIVELY TIGHT-FITTING CLOTHING WHEN OPERATING OR SERVICING THE MACHINE. LOOSE OR TORN CLOTHING CAN CATCH IN MOVING PARTS OR CONTROLS.
36. BEFORE SERVICING THE MACHINE, OR ANY OF ITS ATTACHED EQUIPMENT, BE SURE THAT THE ATTACHMENTS ARE LOWERED TO THE GROUND OR ARE SUPPORTED.
37. DO NOT WORK UNDER OVERHANGS, ELECTRIC WIRES, OR WHERE THERE IS DANGER OF A SLIDE.

38. WEAR AN APPROVED SAFETY HAT WHEN OPERATING THE MACHINE AND WHILE IN ANY WORK AREA.
39. WHEN DRIVING THE MACHINE ON A ROAD OR HIGHWAY, USE WARNING LIGHTS OR WARNING DEVICES AS MAY BE REQUIRED BY LOCAL OR STATE GOVERNMENT REGULATIONS. HEADLIGHTS, WARNING LIGHTS AND SMV SIGNS ARE AVAILABLE THROUGH YOUR NEW HOLLAND DEALER.
40. KEEP THE MACHINE CLEAN. DO NOT ALLOW TRASH, DEBRIS OR OTHER ARTICLES TO ACCUMULATE IN THE CAB, FLOOR OR FOOT CONTROL PEDAL AREA THAT MAY HINDER SAFE MACHINE OPERATION.
41. NEVER OPERATE THE MACHINE WITH ANY OF THE SHIELDING REMOVED.
42. NEVER OPERATE THE MACHINE WITHOUT WINDOWS AND/OR SCREENS IN PLACE.
43. NEVER EXTEND ANY PART OF THE BODY OUTSIDE OF THE OPERATOR'S AREA.
44. ALWAYS PROPERLY TIE DOWN THE MACHINE TO A TRUCK OR TRAILER BEFORE TRANSPORT.
45. MAKE SURE ALL BYSTANDERS ARE AT A SAFE DISTANCE AWAY FROM THE MACHINE BEFORE STARTING THE ENGINE.
46. DO NOT ALLOW ANYONE NEAR THE MACHINE WHILE THE ENGINE IS RUNNING AND THE MACHINE IS OPERATIONAL.
47. WHEN USING THE MACHINE TO CRANE OBJECTS, DO NOT ALLOW ANYONE TO RIDE ON OBJECTS BEING CRANED.
48. DO NOT USE THE MACHINE AS A WORK PLATFORM FOR SUPPORTING MATERIALS.
49. DO NOT LIFT PERSONNEL OR ALLOW PERSONNEL TO WORK WHILE STANDING IN THE BUCKET OR ON OTHER ATTACHMENTS. THIS IS NOT A MAN-LIFT.

OSHA REQUIREMENTS NOW MAKE IT THE EMPLOYER'S RESPONSIBILITY TO FULLY INSTRUCT EACH OPERATOR IN THE PROPER AND SAFE OPERATION OF ALL OPERATIVE EQUIPMENT. BOTH EMPLOYER AND EMPLOYEE SHOULD THOROUGHLY FAMILIARIZE THEMSELVES WITH THE MACHINE OPERATION.



**CAUTION!**

SOME PICTURES IN THIS MANUAL SHOW SAFETY SHIELDS REMOVED OR OPEN TO SHOW PARTS BEING SERVICED OR FOR CLARITY. ALL SHIELDS SHOULD BE CLOSED OR REPLACED PRIOR TO OPERATING THE MACHINE.

**DANGER!**

**FASTEN SEAT BELT**

**BEFORE STARTING ENGINE!**



---

# LW190.B

## WHEEL LOADER

### Service Manual

Print N° 603.67.051.00 English



THIS ALERT SYMBOL SIGNALS IMPORTANT MESSAGES INVOLVING YOUR SAFETY.

Read and heed carefully the safety instructions listed and follow the precautions recommended to avoid potential risks and to safeguard your health and your safety.

You will find this symbol in the text of this Manual referred to the following key words:

**WARNING** - Cautions directed to avoid improper repair interventions involving potential consequences for the operator's safety.

**DANGER** - These warnings qualify specifically potential dangers for the safety of the operator or other persons directly or indirectly involved.

#### IMPORTANT NOTICE

All maintenance and repair interventions explained in this Manual **must be performed exclusively by the Service Organization of the Manufacturer**, observing strictly the instructions explained using, whenever necessary, the recommended specific tools.

Whoever performs the operations reported without following exactly the precautions is responsible on his own, for the damages that may result.

Neither the Factory nor any Organizations in its Distribution Network, including but not limited to national, regional or local distributors, are responsible for any liability arising from any damage resulting from defects caused by parts and/or components not approved by the Factory for use in maintaining and/or repairing products manufactured or merchandized by the Factory.

In any case, no warranty of any kind is made or shall be imposed with respect to products manufactured or merchandized by the Factory, when failures are caused by the use of parts and/or components not approved by the Factory.

---



# SUMMARY

|   |         |
|---|---------|
| SAFETY RULES .....                          | page 1  |
| SPECIFICATIONS - WHEEL LOADER LW190.B ..... | page 8  |
| TABLE OF FLUID CAPACITIES .....             | page 11 |
| UNITS OF MEASURE .....                      | page 12 |
| TORQUE TABLES .....                         | page 13 |

|                                      |                  |
|--------------------------------------|------------------|
| <b>ENGINE .....</b>                  | <b>Section 1</b> |
| <b>TRANSMISSION .....</b>            | <b>Section 2</b> |
| <b>BRAKE SYSTEM .....</b>            | <b>Section 3</b> |
| <b>STEERING SYSTEM .....</b>         | <b>Section 4</b> |
| <b>BUCKET BOOMS AND FRAME.....</b>   | <b>Section 5</b> |
| <b>EQUIPMENT HYDRAULIC SYSTEM ..</b> | <b>Section 6</b> |
| <b>ELECTRICAL SYSTEM .....</b>       | <b>Section 7</b> |
| <b>CAB .....</b>                     | <b>Section 8</b> |



## SAFETY RULES

### GENERALITIES

Read this Manual carefully before starting, operating, maintaining, fuelling or servicing the machine.

Read and comply with all safety precautions before any intervention.

Do not allow unauthorised personnel to operate or service this machine.

Do not wear rings, wrist watches, jewellery, loose or hanging garments, such as ties, torn clothing, scarves, unbuttoned or unzipped jackets that can get caught in moving parts. Wear certified safety clothes such as: hard hat, no-slip footwear, heavy gloves, ear protection, safety glasses, reflector vests, respirators. Ask your employer about specific safety equipment requirements.

Keep the operator's compartment, step plates, grab-rails and handles clean and clear of foreign objects, oil, grease, mud or snow to minimize the danger of slipping or stumbling. Remove mud or grease from your shoes before attempting to mount or operate the machine.

Do not jump on or off the machine. Always keep both hands and one foot, or both feet and one hand in contact with steps and grab rails.

Do not use controls or hoses as hand holds when climbing on or off the machine. Hoses and controls are movable parts and do not provide solid support. Besides, controls may be inadvertently moved and cause unexpected movement of the machine or its attachments.

Never operate the machine or its attachments from any position other than sitting in the driver's seat.

Keep head, body, limbs, hands and feet inside the operator's compartment at all times to reduce exposure to external hazards .

Be careful of possible slippery conditions of the steps and hand rails as well as of the ground around the machine.

Do not leave the machine until it has come to a complete stop.

Check the seat safety belt at least twice per year and replace it if it shows signs of wear, fraying or other weakness that could lead to failure.

### STARTING

**NEVER START OR OPERATE A FAILED MACHINE.** Before operating the machine, always ensure that any unsafe condition has been satisfactorily corrected.

Check brakes, steering and attachment controls before moving off. Report any malfunctioning part or system to the maintenance managers for proper action.

Ensure all protective guards and panels as well as all safety devices provided are in place and in good operating condition.

Ensure that nobody is in the machine operating range before moving off or operating the attachment. **WALK COMPLETELY AROUND** the machine before mounting. Sound the horn.

Before starting machine, check, adjust and lock the driver's seat for maximum comfort and control of the machine.

Fasten your seat belts(when fitted).

Obey all flag signals and signs.

Due to the presence of flammable fluids on the machine, never check or fill fuel tanks or accumulator batteries near fires, open flames, or sparks.

**REMEMBER THAT SPECIAL STARTING FLUIDS ARE FLAMMABLE.** Scrupulously follow recommendations printed on the containers and in this Manual.

**DO NOT PUNCTURE OR BURN CONTAINERS.**

Containers must be stored in fresh, well ventilated places and out of the reach of unauthorised persons. Strictly follow the instructions provided by the Manufacturer.

Never use these products near fires, open flames, or sparks.

### OPERATING

Check wheel and rim retainers before each working shift. If necessary, tighten to the torque specified.

Do not run the engine of this machine in closed buildings without proper ventilation capable to remove harmful exhaust gases.

Roll Over Protective Structures (ROPS) are required on wheel or crawler loaders, dozers, or graders. **NEVER OPERATE** the machine if such protective structure is removed.

Keep the operator's compartment free of foreign objects, especially if not firmly secured. Never use the machine to transport objects, unless proper securing points are provided.

**DO NOT CARRY RIDERS ON THE MACHINE**

Study and familiarize with escape routes alternate to normal exit routes.

According to law provisions, seat belts must be fitted with Roll Over Protection Structures or cabs. Keep safety belts fastened during operation.

For your personal safety, do not climb on or off the machine while it is in motion.

Make sure that bystanders are clear of the machine operating range before starting the engine and operating the attachment. Sound the horn. Obey all indications provided by flags, signs and signals.

**DO NOT COAST OR FREEWHEEL** down hills. Engage the most suitable gear speed to keep the machine under control.

## SAFETY RULES

Do not operate the machine if you are extremely tired or feel ill. Be especially careful towards the end of the working shift.

Do not operate a machine with misadjusted brakes.

Operate the machine at low speed which can ensure complete control at all times.

Travel slowly over very rough terrain, slopes or near drop-offs, in congested areas or on frozen or slippery surfaces.

When backing, always look to where the machine is to be moved. Be alert of the position of bystanders. Should someone enter the work area, STOP THE MACHINE.

Maintain a safe distance from other machines or obstacles to ensure required visibility conditions. Give way to loaded machines.

Maintain a clear vision of the surroundings of the travel or work area at all times. Keep cab windows clean and repaired.

When machines are operating in tandem, the pusher (rear) must be equipped with the appropriate deflectors to protect the front unit driver against the air stream coming from the blower fan.

When pulling or towing through a cable or chain, do not start suddenly at full throttle. Take-up slack carefully.

Carefully inspect the towing items for flaws or problems before proceeding.

Avoid kinking or twisting chains or cables. Do not pull through a kinked chain or cable as the high stresses existing in this condition may induce failures. Always wear heavy gloves when handling chains or cables.

Chains and cables should be securely anchored. Anchor points should be strong enough to withstand the expected load. Keep anyone clear of anchor points and cables or chains.

**DO NOT PULL UNLESS THE OPERATOR'S COMPARTMENTS OF THE MACHINES INVOLVED ARE PROPERLY PROTECTED AGAINST POSSIBLE BACKLASH IN CASE OF CABLE OR CHAIN FAILURE OR DETACHMENT.**

Be alert of soft ground conditions close to newly constructed walls. The fill material and machine weight may cause the wall to collapse.

In darkness, check area of operation carefully before moving in with the machine. Use all lights provided. Do not move into low visibility areas.

If the engine tends to stall for whatever reason under load or at idle, immediately report this problem to the maintenance managers for proper action. Do not operate the machine until this condition has been corrected.

On machines fitted with suction radiator fans, regularly check the engine exhaust system for leaks, as exhaust fumes expelled towards the operator are toxic.

Operators must know thoroughly the performances of the machine they are driving.

When working on slopes or near sudden level drops in the terrain, avoid areas where ground is loose or soft since overturn or loss of machine control could result.

If noise level is high and continuously exceeds 90 dBA over 8 hours at the operator's ear, wear approved ear protection in compliance with local regulations.

Where counterweights are provided, do not operate the machine if they have been removed.

When transporting a loaded bucket, keep it as rolled-back and low as possible for maximum visibility, stability and safety of the machine. Ground speed should be adequate to the load and ground conditions.

The load must always be properly arranged in the bucket; move with extreme care when transporting oversized loads.

Use only the type of bucket recommended for the machine and the materials to be handled. Follow the recommendations concerning loading capacity, arrangement of the materials, characteristics of the ground and job to be performed.

Do not lift and move loads overhead where persons are standing or working, nor downhill when working cross-wise on slopes. In this case, the bucket should be unloaded on the uphill side, whenever possible.

Start and stop the machine carefully when the bucket is full. Do not move off without first reducing engine speed.

Overtaking manoeuvres should be performed only when absolutely necessary and unavoidable. Beware possible uneven terrains, poor visibility, presence of other machinery or persons out of sight.

Operate the machine at a speed adequate to the working site conditions and in any case slow enough to ensure complete control at all times.

Check instruments at start-up and frequently during operation. Stop the machine immediately should any malfunction be signalled.

Never use the bucket as a man lift or to carry riders.

Never use the machine as a work platform or scaffolding, nor for other improper use (such as pushing railway cars, trucks or other machines).

Pay attention to people within the machine operating range. Load trucks from the driver's side whenever possible.

Prior to operating the machine, check which obstacles and/or difficulties you will encounter, such as narrow streets, overhead doors, cables, piping, as well as ground, bridges, paving and ramps bearing load limitations.

In case of road transfers, find out beforehand what conditions are likely to be encountered, such as size restrictions, heavy traffic, paving type, etc. Beware fog, smoke or dust that obscure visibility.

When crossing gullies or ditches, move at an angle with reduced speed after ensuring ground conditions will permit a safe traverse.

## SAFETY RULES

Always inspect the working area to identify potential risks such as: inclines, overhangs, trees, demolition rubble, fires, ravines, steep slopes, rough terrain, ditches, crowns, ridge trenches, heavy traffic, crowded parking and service areas, closed ambients. In such conditions, proceed with extreme care.

Whenever possible, avoid going over obstacles such as very rough terrain, rocks, logs, steps, ditches, railroad tracks. When obstructions must be crossed, do so with extreme care and at an angle, if possible. Slow down and select a lower gear. Ease up to the break-over point, pass the balance point slowly and ease down the other side.

In steep down-hill operation, do not allow the engine to over-speed. Select the proper gear before starting down grade.

Avoid crosswise hill travel, whenever possible. Drive up and down the slope. Should the machine start slipping sideways when going uphill, steer and turn machine front immediately downhill.

The gradient you may attempt to overcome is limited by factors such as ground conditions, load being handled, machine type and speed, and visibility.

There is no substitute for good judgement and experience when working on slopes.

Avoid operating the attachment too close to an overhang or high wall, either above or below the machine. Beware of caving edges, falling objects and landslips. Remember that such hazards are likely to be concealed by bushes, undergrowth and such.

When pushing-over trees, the machine must be equipped with proper overhead guards. Never drive a machine up the roots, particularly while the tree is being felled. Use extreme care when pushing over any tree with dead branches.

Avoid faggots, bushes, logs and rocks.

NEVER DRIVE OVER THEM, nor over any other surface irregularities that discontinue adherence or traction with the ground, especially near slopes or drop-offs.

Be alert to avoid changes in traction conditions that could cause loss of control. AVOID driving on ice or frozen ground when working on steep slopes or near drop-offs.

Working in virgin rough terrains is characterized by the presence of all the perils and risks listed above. In these conditions, it is emphasised the danger represented by large tree limbs (possibly falling on the machine), large roots (which may act as a leverage under the machine when up-rooted and cause the unit to overturn), etc.

### STOPPING

When the machine is to be stopped for whatever reason, do so following the instructions given in chapters "**Stopping the machine**" and "**Shutting off the engine**" in the Operation and Maintenance Instruction Manual.

Always remember to move the gearshift lever to the neutral position and engage the control lever lock for safety purposes.

Apply the parking brake (if fitted).

NEVER LEAVE THE MACHINE UNATTENDED with the engine running.

Prior to leaving the operator's seat, and after making sure that all people are clear of the machine, always slowly lower the attachment until resting it safely to the ground

Park the machine in a non-operating and no-traffic area. Park on firm level ground. If this is not possible, position the machine at a right angle to the slope, making sure there is no danger of uncontrolled sliding. Apply the parking brake.

If parking in traffic lanes cannot be avoided, provide appropriate flags, barriers, flares and signals as required to adequately warn the oncoming drivers.

Keep head, body, limbs, hands and feet clear of the dozer, arms, bucket or ripper when raised.

Always switch off the battery isolator switch before servicing the machine in whatever manner (i.e., cleaning, repairing, maintaining, etc.). Do the same when the machine is to remain parked for prolonged periods of time to avoid accidental or unauthorized starting.

Never lower the attachments other than sitting in the operator's seat. Sound the horn. Make sure that nobody is within the machine operating range. Lower the attachment slowly. DO NOT USE FLOAT POSITION in case of hydraulic controls.

Securely block the machine and lock it every time you leave it unattended. Return keys to authorized security. Perform all necessary operations as detailed in the Operation and Maintenance Instruction Manual. Apply the parking brake (if fitted) every time you leave the machine.

## MAINTENANCE

### GENERALITIES

Before operating or performing any intervention on the machine:

- carefully read all the norms contained in this Manual;
- read and observe all safety plates and instructions located on the machine.

Do not allow unauthorized personnel to service the machine. Do not carry out any maintenance work without prior authorization. Follow all recommended maintenance and service procedures.

Keep the operator's compartment free of loose objects that are not properly secured.

Do not wear rings, wrist watches, jewellery, loose or hanging garments, such as ties, torn clothing, scarves, unbuttoned or unzipped jackets that can get caught in moving parts.

## SAFETY RULES

Wear certified safety clothes such as: hard hat, no-slip footwear, heavy gloves, ear protection, safety glasses, reflector vests, respirators. Ask your employer about specific safety equipment requirements.

Never service the machine with someone sitting in the driver's seat, unless this person is an authorized operator assisting in the maintenance being carried out.

Keep the operator's compartment, step plates, grab rails and handles clear of foreign objects, oil, grease, mud or snow to minimize the danger of slipping or stumbling.

Clean mud or grease from your shoes before climbing on the machine or driving it.

Never attempt to operate the machine or its attachments from any position other than sitting in the operator's seat.

Never stand under the boom.

Should it be necessary to move the attachment through the hydraulic controls for maintenance purposes, remember that this should be done while sitting in the operator's seat. Before starting the machine or moving its attachment, apply the brakes, sound the horn and call that you are about to manoeuvre. Raise the attachment slowly.

Always lock machine arms or any other parts that must be lifted for maintenance purposes using adequate external means. Do not allow anyone to pass near or even below a raised yet unlocked attachment. If you are not absolutely sure about your safety, do not stay under a raised attachment, even if it is locked.

Do not place body, limbs, or fingers near articulated cutting edges of uncontrolled machine parts or deprived of the necessary guards, unless they are suitably and safely locked.

Never perform any work on the machine with the engine running, except when this is specifically required. Do not wear loose clothing, jewellery or such near moving parts.

When service or maintenance require access to areas that cannot be reached from the ground, use a ladder or step platform conforming to regulations in force. If such means are not available, use machine grab rails and steps. Always perform all service or maintenance work with the greatest care and attention.

Shop and/or field service platforms or ladders should be manufactured in accordance with safety regulations in force.

Disconnect batteries and label all controls to warn that service work is in progress. Block the machine and all attachments to be raised.

Do not check or fill fuel tanks, batteries and accumulators, nor use the starting liquid if you are smoking or near open flames. These fluids are flammable!

**BRAKES ARE INOPERATIVE** when manually released for servicing. Provisions must be made to maintain control of the machine using suitable blocks or other means.

The fuel filler pipe nozzle must be constantly kept in contact with the filler neck. Keep this contact from the beginning to the end of the fuelling operation to avoid possible generation of sparks due to static electricity.

Tow the machine only from the attaching points provided. Use care in making connections and ensure pins and/or bolt are firmly secured before pulling. Stay clear of draw-bars, cables or chains under load.

To move a failed machine, use a trailer or a low platform truck, if available. In case towing is needed, use all necessary signals required by local regulations, and follow directions provided in this Manual.

Load/unload the machine from transporter on firm level ground providing safe support to the wheels of the truck or trailer. Use strong access ramps, with adequate height and angle. Keep the loading platform free of mud, oil or slippery materials.

Tie the machine securely to the platform of the truck or trailer and opportunely wedge machine wheels or tracks as required.

Never align holes or slots using your fingers; always use appropriate aligning tools.

Remove all sharp edges and burrs from re-worked parts.

Use only approved and effectively grounded auxiliary power sources for heaters, battery chargers, pumps and similar equipment to reduce electrical shock hazard.

Lift and handle heavy components using hoisting devices of appropriate capacity. Ensure the sling has been correctly applied. Use lifting eyes if provided. Pay attention to bystanders.

Never pour gasoline or diesel fuel into open, wide and low containers. Never use gasoline, solvents or other flammable fluids to clean parts. Use proprietary certified non-flammable, non-toxic solvents only.

When using compressed air to clean parts, wear safety glasses with side shields. Limit pressure to max 2 bars, in accordance with local safety regulations in force.

Do not run the engine in closed buildings without proper ventilation capable to remove lethal fumes.

Do not smoke, use open flames or produce sparks nearby while refuelling the unit or handling highly flammable materials.

Do not use any flame as a light source during maintenance work or to look for leaks anywhere on the machine.

Make sure that all tools provided are in good condition at all times. NEVER USE tools with mushroomed or damaged heads. Always wear eye protections.

Move with extreme care when working under the machine, its attachments, and even on or near them. Always wear protective safety equipment as required, such as hard hat, goggles, safety shoes, and ear plugs.

## SAFETY RULES

In case tests during which the engine should be kept running, a qualified operator must sit in the driver's seat with the mechanic in sight at all times. Place the transmission in neutral, apply and lock the brakes. **KEEP HANDS OFF MOVING PARTS.**

In case of field service, move machine to level ground, if possible, and block it. If work on an incline cannot be advised, block the machine and its attachments securely. Move damaged to level ground as soon as possible.

Do not trust worn and/or kinked chains and cables. Never use them for lifting or pulling. Always wear heavy gloves to handle chains or cables.

Be sure chains and cables are firmly fastened and that anchor points are strong enough to withstand the expected load. Nobody should stay near the anchor points, cables or chains. **DO NOT PULL OR TOW UNLESS THE OPERATOR'S COMPARTMENTS OF THE MACHINES INVOLVED ARE FITTED WITH THE PROPER GUARDS AGAINST BACKLASH IN CASE OF CABLE OR CHAIN FAILURE OR DETACHMENT.**

Keep the area where maintenance is carried out **CLEAN** and **DRY** at all times. Clean immediately all water and oil spillages.

Do not pile up oily or greasy rags as they represent a major fire hazard. Always store them in closed metal containers.

Before starting the machine or its attachment, check, adjust and lock the operator's seat. Also ensure that nobody is within the machine operating range. Sound the horn.

Rust inhibitors are volatile and flammable. Use them only in well ventilated areas. Keep open flames away - **DO NOT SMOKE** - Store containers in a cool well ventilated place where they could not be reached by unauthorised people.

Do not carry loose objects in your pockets that might fall unnoticed into open compartments.

Wear safety glasses with side shields, hard hat, safety shoes, heavy gloves when metal particles or similar may be ejected and hit you.

Wear appropriate protective equipment such as dark safety glasses, hard hat, protective clothing, special gloves and footwear while welding. Nearby persons should also wear dark safety glasses even if they are not welding. **DO NOT LOOK THE WELDING ARC WITHOUT PROPER EYE PROTECTION.**

Become acquainted with all your jacking equipment and its capacity. Remember that the jacking point on the machine should be appropriate for the load applied. Also, be sure the support area of the jack at the machine and on the ground is appropriate and stable.

Any load supported by a jack represents a possible hazard. Always transfer the load onto appropriate support means according to local or national safety requirements before proceeding with service or maintenance work.

Metal cables get frayed after prolonged use. Always wear appropriate protections (heavy gloves, goggles, etc.) while handling them.

Handle all parts carefully. Keep hands and fingers away from gaps, gears, and similar. Always use and wear the appropriate protections.

Water can build up in pneumatic systems from condensate moisture due to changes in atmospheric conditions. If necessary, drain such deposits following instructions.

Before carrying out any maintenance work or service, lock the machine articulated frame modules using the appropriate safety device. Remember to remove and store it properly at the end of work.

If the machine is equipped with hydraulic brakes, make sure that the reservoir is always filled up to the correct level.

Always block all wheels, front and rear, before bleeding the braking system or disconnecting control hoses and/or cylinders.

### STARTING

Do not run the engine in closed buildings without proper ventilation capable to remove lethal exhaust fumes.

Do not place head, body, limbs, feet, hands or fingers near rotating fans or belts.

Be especially careful near blower fans.

**REMEMBER THAT THE STARTING FLUID IS HIGHLY FLAMMABLE.** Follow recommendations provided in this Manual and printed on the containers. Containers must be stored in a cool, well ventilated place out of the reach of unauthorised persons.

**DO NOT PUNCTURE OR BURN CONTAINERS.**

### ENGINE

Loosen the radiator cap very slowly to relieve system pressure before removing it. Always top-up coolant level with the engine off.

Avoid that flammable materials could touch exhaust parts. If not possible, provide necessary protections.

Do not refuel with the engine running, especially if hot, as this increases fire hazard.

Never attempt to check or adjust fan belt tensions when the engine is running.

Do not adjust the fuel pump when the machine is motion.

Do not lubricate the machine with the engine running.

Do not run the engine with air intakes, door or guards open.

## SAFETY RULES

### ELECTRICAL SYSTEM

Always disconnect the batteries prior to any intervention on the machine or its electrical system (cleaning, repair, maintenance).

Should booster batteries be used, remember to connect ends of the booster cables in the proper manner: (+) to (+) and (-) to (-). Do not short-circuit terminals. Thoroughly follow instructions given in this Manual.

Before any intervention, make sure that the battery isolator switch is off.

**BATTERY GAS IS HIGHLY FLAMMABLE.** Leave the battery compartment open during recharging to improve ventilation. Never check battery charge by placing metal objects across the posts. Keep sparks or open flames away from batteries. Do not smoke near the battery to prevent explosion hazard.

Before any intervention, make sure that there are no fuel or electrolyte leakages. If any, correct prior to proceeding with further work. Do not recharge batteries in confined spaces. Ensure proper ventilation is provided to avoid accidental explosions due to build-up of gas released during charging.

### HYDRAULIC SYSTEM

Pressure fluid escaping from a very small hole can be almost invisible and still have sufficient force to penetrate the skin. Always check any suspected pressure leaks using a piece of cardboard or wood. **DO NOT USE HANDS.** If injured by escaping fluid, obtain medical attention immediately or serious infection or reaction may develop.

Stop the engine and relieve all system pressure before removing panels, housings, caps, plugs or covers.

Always use gauges of adequate capacity (end-of-scale reading) and follow recommended procedures.

### TOOLS

Always keep head, body, limbs, feet, or hands away from bucket, blade, or ripper when in the raised position. Prior to any intervention, install all safety devices according to current regulations. In case the attachment is to be operated through the machine hydraulic system for maintenance purposes, remember to do so only while sitting in the driver's seat. Make sure that nobody is within the machine operating range. Before operating the attachment, alert people by sounding the horn and by voice. Raise the attachment slowly.

Do not use the machine to transport loose objects, unless proper devices to this purpose are provided.

Clutches and brakes of this machine as well as auxiliary devices and attachments (such as drive cylinder or winch control valves) should always be properly adjusted in accordance with the instructions provided by the Manufacturer. Never perform adjustments with the engine running, except when this is specifically required by the relevant procedures.

### TYRES AND WHEELS

Make sure that the tyre inflation pressure corresponds to specifications issued by the Manufacturer. Regularly check inflation pressure.

Should pressure be changed, do this while staying on the tyre side and at a safe distance.

Pressure checks should always be carried out with the machine unloaded and cold tyres.

Never use reconditioned tyre rims, since possible weldings, incorrect heat-treatments or repairs can weaken the wheels and cause damages or failures.

Do not cut, nor weld rims with inflated tyres installed.

The spare tyre should be inflated only enough to keep the rim components assembled. Remember that when not installed on the disc, a tyre inflated to maximum pressure can **explode**.

Therefore, maximum care must be taken when handling a fully inflated tyre.

Before servicing tyres, block all wheels, front and rear. After jacking up the machine, block it in the raised position using suitable stands conforming to current safety regulations.

Deflate the tyre before removing objects from the tyre tread.

Never inflate tyres with flammable gas: explosions and severe bodily injuries may result.

When starting your work shift, check for loose wheel or rim bolts and brackets and retighten to correct torque as necessary.

---

## SAFETY RULES

### DECOMMISSIONING THE MACHINE

For the decommissioning of the machine, the availability of particular tooling (hoists, hydraulic presses, containers for liquids etc.) is required as well as specific tools listed in the Repair Manuals, available from **NEW HOLLAND** Dealers.

This has the purpose of avoiding that during disassembly operations, dangerous situations may arise both for the personnel involved and the environment.

In the machine are present:

- Fluids under pressure (hydraulic system, cooling system etc.)
- Gases (air conditioning system and accumulator, if installed)
- Mechanical devices mounted under pressure (track tensioner etc.)
- Heavy machine components (frames, blades, buckets etc.)

### WARNING

- **The decommissioning of the machine must be performed exclusively by personnel trained, qualified and authorised to perform such operation.**
- **Start the disassembly of hydraulic components only after the same, the hydraulic oil and lubricants have fully cooled-off and after all residual pressures have been released, as described by the Repair Instruction Manual.**
- **Prior to proceeding with disassembly operations, comply with the GENERAL SAFETY RULES and drain each components of the machine filled with fluids, both in the reservoirs and the relevant systems.**

---

### WARNING

**Ensure that the attachment is safely resting on to the ground before repairing, adjusting, or servicing machines fitted with hydraulically, mechanically or cable controlled attachments (such as excavators, loaders, dozers, scrapers, etc.). Should it be necessary to partially or fully raise the hydraulically, mechanically, or cable controlled attachment to gain access to certain items, make sure the attachment is adequately retained in the raised position by means other than the hydraulic lift cylinders, cable and/or mechanical devices used for controlling it.**



**EQUIPMENT HYDRAULIC SYSTEM**

Type ..... sealed w/ anti-cavitation and safety valve

Pumps ..... gear, steel made w/ wear automatic compensation

A sequence valve cuts-off the pump when the pressure exceeds 175 bar.

- max. flow ..... 325 lt/min between (71.49 USG/min) 175 and 210 bar

- max. operating pressure ..... 210 bar

Control valve ..... 2-spool 3-spool

Control ..... piloted, dual lever piloted, single lever

Hydraulic cylinders, double stroke

boom control ..... 2

bore x stroke ..... 140x960 mm

bucket control ..... 1

bore x stroke ..... 190x505 mm

Times of equipment manoeuvres

lifting ..... 6.2 sec.

lowering ..... 3.1 sec.

dumping ..... 1.4 sec.

Pipes and connecting flanges are equipped with O-Ring seals.

**L.T.S. device**

Electronic Load Travel Stabiliser device. Ideal during loading applications and travel over rough ground.

- Setting of accumulator safety valve ..... 120 bar

**ELECTRICAL SYSTEM**

Operating voltage ..... 24 Volt

Batteries in series ..... 2 - 160 Amph  
- Maintenance-free


Starter motor ..... 24 Volt

Alternator w/ voltage regulator ..... 24 Volt - 70 Amp

**WEIGHT**

Weight of machine with tyres 23.5 R25 and 3.1 cu m bucket, supplied and w/operator 17,200 kg (37,920 lbs).

**DIMENSIONS AND WEIGHT**



Dimensions in mm (in)

Operating weight: 17,200 kg (37919 lbs)

**Note** – Machine equipped with tyres 23.5R25XHA, fluids and operator.

\* Please refer to the table

**Type of bucket**

|   |          | With teeth and segments |              | With suppl. cutting edge |              | With teeth   |              |
|---|----------|-------------------------|--------------|--------------------------|--------------|--------------|--------------|
| Bucket capacity                             | cu cm    | 3.2                     | 3.5          | 3.2                      | 3.5          | 3.1          | 3.4          |
| Bucket weight                               | kg (lbs) | 1520 (3351)             | 1605 (3538)  | 1465 (3229)              | 1550 (3417)  | 1425 (3141)  | 1510 (3328)  |
| Bucket width                                | mm (in)  | 2960 (116.5)            | 2960 (116.5) | 2920 (114.9)             | 2920 (114.9) | 2960 (116.5) | 2960 (116.5) |
| Dumping height at 45°                       | mm (in)  | 2890 (113.7)            | 2810 (110.6) | 2980 (117.3)             | 2895 (113.9) | 2890 (113.7) | 2810 (110.6) |
| Dumping reach at 45°                        | mm (in)  | 1135 (44.6)             | 1200 (47.2)  | 1060 (41.7)              | 1125 (44.2)  | 1135 (44.6)  | 1200 (47.2)  |
| Max. length (w/ bucket on ground)           | mm (in)  | 8030 (316.1)            | 8110 (319.3) | 7920 (311.8)             | 8000 (314.9) | 8030 (316.1) | 8110 (319.3) |
| Max. height (w/ bucket raised)              | mm (in)  | 5380 (211.8)            | 5435 (213.9) | 5380 (211.8)             | 5435 (213.9) | 5380 (211.8) | 5435 (213.9) |
| Turning radius (in transportation position) | m (ft)   | 6.5 (21.3)              | 6.5 (21.3)   | 6.5 (21.3)               | 6.4 (21)     | 6.5 (21.3)   | 6.5 (21.3)   |

TABLE OF FLUID CAPACITIES

| ITEM                       | QUANTITY LITRES (USG)       | FLUIDS OR LUBRICANT<br><i>Ambra</i> | CLASSIFICATION SPECIFICATIONS                   | VISCOSITY (SAE)  | OUT DOOR TEMPERAT. OF REFERENCE (°C)                       |
|----------------------------|-----------------------------|-------------------------------------|---|------------------|--|
| ENGINE                     | 15 (4)                      | Ambra – Super Gold                  | API CF-4/SG<br>MIL-L-2104E<br>ACEA E2           | 15W-40<br>10W-30 | -10 To 50° C (14 To 122° F)<br>-30 To 20° C (-22 To 68° F) |
| OIL FILTER                 | 1 (3)                       | Ambra-SuperGold HSP*                | API CH-4<br>ACEA E3                             | 15W-40           | -10 To 50° C (14 To 122° F)                                |
| RADIATOR                   | 42 (11)                     | Ambra-Agriflu                       | NH-900A   | -                | -35 To 50° C (-31 To 122° F)                               |
| TRANSMISSION               | 22 (5.8)                    | Ambra-SuperGold                     | API CF-4/SG<br>MIL-L-2104E<br>ACEA E2           | 10W-30           | -30 To 20° C (-22 To 68° F)                                |
| HYDRAULIC SYSTEM           | 132 (34.87)                 | Ambra-HITECH 46                     | ISO VG 46, DIN 51524<br>item 1 and 2, QFH583/HD | -                | -20 To 50° C (-4 To 122° F)                                |
| AXLES                      | front 30 (8)<br>rear 30 (8) | Ambra-TX Fluid                      | API GL5<br>QFH 584 TR                           | 85W-90           | -20 To 50° C (-4 To 122° F)                                |
| FUEL TANK                  | 252 (66.57)                 | -                                   | -   | -                | -  |
| GREASE FITTINGS            | -                           | Ambra-MG-2                          | QFH585 GR, NLG12                                | -                | -40 To 50° C (-40 To 122° F)                               |
| AIR CONDITIONER COMPRESSOR | 0.2 (0.05)                  | L BAR 134                           | -   | -                | -  |

Oil quantities indicated are those required for periodical changes following the draining and filling procedures indicated in detail for each group.  
 \* In the event engine oil with "CH4" classification is used, the change interval can be prolonged to 500 hours providing that the outer temperature of operation does not exceed 38 °C (100 °F) and that the percentage of sulphur in the fuel does not exceed 0.5 %.  
 In the event of really heavy duty conditions, reduce the greasing intervals.

## UNITS OF MEASURE

Units of measure used in this manual are those adopted by the International System which replace the units previously used by the M.K.S. system.

**Force:** decanewton (daN) replaces kilogram (kg)

**Pressure:** bar, replaces kg/cm<sup>2</sup>

**Torque:** decanewton x meter (daNm) replaces kgm

The following tables is to be used to convert units of measure:

|          | multiply           | by     | to obtain |
|----------|--------------------|--------|-----------|
| Force    | kg                 | 9.807  | daN       |
| Pressure | kg/cm <sup>2</sup> | 0.9807 | bar       |
| Torque   | kgm                | 9.807  | daNm      |

**Note** – For current service use, the following equivalences can be considered to be valid:  
 $kg = daN$ ;  $kg/cm^2 = bar$ ;  $kgm = daNm$ .

## CLASSIFICATION OF STANDARD COMPONENTS TO DETERMINE THE TIGHTENING TORQUES

**Note** – In case, in the different sections, the tightening torque is not listed, refer to the table "TIGHTENING TORQUES", only after identifying exactly the component.

The latter is identified by a coded eight digit number, allowing a complete description of the item.

Example.

1 / a b c d e / f g

### 1 - Standard index digit

It is always represented by the digit 1. This number indicates that the item can be fabricated in a number of versions differing for material and coating.

### a - b - c - d - e - Standard base digits

It is a number always composed of five digits identifying dimensional specifications of the item.

### f - Material index digit

This digit indicates the material used for a defined item. Its meaning is indicated in the table that follows.

### g - Coating index digit

It indicates the coating applied to a defined item.

| Material index (f) | Resistance class and material      |              |           |           |           |           |
|--------------------|------------------------------------|--------------|-----------|-----------|-----------|-----------|
|                    | FIAT                               | UNI          | DIN       | SAE       | BSI       | BNA       |
| 0                  | R40                                | 4D - 4S - 4A |           | 1         | A         | 42        |
| 1                  | R50                                | 5S - 6S      |           | 3         | P         | 56        |
| 2                  | R80                                | 8G           |           | 5         | T         | 80        |
| 3                  | R100                               | 100          | 10K       | 8         | V         | 100       |
| 4                  | Brass                              | Brass        | Messing   | Brass     | Brass     | Laiton    |
| 5                  | Aluminium                          | Aluminium    | Aluminium | Aluminium | Aluminium | Aluminium |
| 6                  | Copper                             | Copper       | Kupfer    | Copper    | Copper    | Cuivre    |
| 7                  | Blank for other metallic materials |              |           |           |           |           |

**WARNING**

- Lubricate all hardware until 24 dia., with engine oil. Use grease for larger diameters.
- Tolerance on torque:  $\pm 5\%$
- Resistance classes R80, R100, R120 must be understood as follows:

|                    |  |            |
|--------------------|--|------------|
| 10.9 replaces R100 |  | for screws |
| 12.9 " R120        |  |            |
| 10 replaces R80    |  | for nuts   |
| 12 " R100          |  |            |

**TORQUE TABLES**

If correct torque is not specifically indicated in the relevant pages, refer to the following tables.

CDT= cadmed; FOSF= phosphated; ZNT= galvanized.

| NUTS (ZNT)               |        |          |                     |               | SCREWS (ZNT/DEIDR)          |                 |                       |
|--------------------------|--------|----------|---------------------|---------------|-----------------------------|-----------------|-----------------------|
| Strength grade: 10 (R80) |        |          |                     |               | Strength grade: 10.9 (R100) |                 |                       |
| Diameter and pitch mm    | normal | low type | with polyamide ring |               | Diameter and pitch mm       | normal ZNT daNm | self-locking ZNT daNm |
|                          | daNm   | daNm     | normal daNm         | low type daNm |                             |                 |                       |
| M6 x 1                   | 1.3    | 1.2      | -                   | -             | M6 x 1                      | 1.3             | -                     |
| M8 x 1.25                | 3.2    | 2.6      | 3.9                 | 3.2           | M8 x 1.25                   | 1.3             | 3.5                   |
| M10 x 1.25               | 7.2    | 5.2      | 8.2                 | 6.2           | M10 x 1.25                  | 7.1             | 7.9                   |
| M10 x 1.5                | 6.5    | 5        | 7.7                 | 6             | M10 x 1.5                   | 6.5             | 7                     |
| M12 x 1.25               | 13     | 8.7      | 14.5                | 10.2          | M12 x 1.25                  | 12.7            | 13.9                  |
| M12 x 1.75               | 11     | 8.1      | 12.9                | 9.6           | M12 x 1.75                  | 11              | 12                    |
| M14 x 1.5                | 19.5   | 13       | 21.6                | 15            | M14 x 1.5                   | 20              | 22                    |
| M14 x 2                  | 18     | 12.5     | 20                  | 14.6          | M14 x 2                     | 18              | 19                    |
| M16 x 1.5                | 30     | 17       | 34                  | 20            | M16 x 1.5                   | 30              | 33                    |
| M16 x 2                  | -      | -        | -                   | -             | M16 x 2                     | -               | -                     |
| M18 x 1.5                | 45     | 25       | 50                  | 29            | M18 x 1.5                   | 45              | 48                    |
| M18 x 2.5                | -      | -        | -                   | -             | M18 x 2.5                   | -               | -                     |
| M20 x 1.5                | 60     | 30.5     | 64.5                | 35            | M20 x 1.5                   | 60              | 65                    |
| M20 x 2.5                | -      | -        | -                   | -             | M20 x 2.5                   | -               | -                     |
| M22 x 1.5                | 80     | 41       | -                   | -             | M22 x 1.5                   | 80              | 90                    |
| M22 x 2.5                | -      | -        | -                   | -             | M22 x 2.5                   | -               | -                     |
| M24 x 2                  | 100    | 47       | 108                 | 52.5          | M24 x 2                     | 100             | 110                   |
| M24 x 3                  | -      | -        | -                   | -             | M24 x 3                     | -               | -                     |
| M27 x 2                  | 95     | 40.1     | -                   | -             | M27 x 2                     | 100             | -                     |
| M30 x 2                  | 130    | 49.4     | -                   | -             | M30 x 2                     | 140             | -                     |
| M33 x 2                  | 170    | -        | -                   | -             | M33 x 2                     | 190             | -                     |
| M36 x 3                  | 220    | -        | -                   | -             | M36 x 3                     | 240             | -                     |