



# NEW HOLLAND

LS 140  
LS 150

Workshop  
Manual



## SECTION 00 – GENERAL INFORMATION

### CONTENTS

Section	Description	Page
	Introduction .....	00-2
	About Improvements .....	00-2
	Company Policy .....	00-3
	Parts and Accessories .....	00-3
	Model Codes .....	00-3
	Precautionary Statements .....	00-4
	Safety Precaution Information .....	00-5
	General Safety Information .....	00-7
	Machine Model and Serial Number Location .....	00-9
	Engine Model and Serial Number Location .....	00-9
	Hardware Torque Specifications .....	00-10
	Installation of Adjustable Fittings in Straight Thread O Ring Bosses .....	00-12
	Standard Torque Data for Hydraulic Tubes and Fittings .....	00-12
	Pipe Thread Fitting Torque .....	00-13
	Lubricants and Coolants .....	00-13
	Sealants .....	00-13
	Properly Support a Raised Machine .....	00-14
	Properly Support Boom on Boom Lock Pins .....	00-14
	Raising Boom Without Hydraulic Oil Flow .....	00-14
	Raising Boom Without Battery Voltage (12V) .....	00-15
	Reattaching Cylinders After Repair with Boom Resting on Boom Lock Pins .....	00-17
	Major Unit Overhaul .....	00-18
	Cab and Boom Tilt Procedure .....	00-19
	Craning the Skid Steer .....	00-26
	Special Tools .....	00-29
	Specifications .....	00-30
	Dimensions .....	00-33

## INTRODUCTION

This service manual provides the technical information needed to properly service and maintain the Models LS140 and LS150 skid steers. Use it in conjunction with the operator's manual which is supplied with the skid steer. Keep both manuals available for ready reference.

The LS140 and LS150 have many similarities with the major differences being engine horsepower and lifting capacity.

Whenever working on New Holland equipment, left and right sides of the machine are determined by standing behind the unit, looking in the direction of travel.

The easiest and least time-consuming removal, disassembly, and reassembly procedures are detailed in the manual. Modifying these procedures is not recommended.

New Holland skid steers are designed with emphasis on safety for operator protection. However, careless and negligent operation can still result in serious injury to persons or damage to property. Be sure to read and follow all safety instructions in this manual.

Your New Holland dealer is interested in your obtaining the most from your investment and will be glad to answer any questions you may have about your skid steer. When major service is required, your dealer's staff of trained service technicians is ready to serve you.

When in need of parts, always order genuine New Holland service parts from your New Holland dealer. Be prepared to give your dealer the model and serial number of the engine and skid steer (the location of these numbers is described later in this section). Record the serial numbers here.

Skid Steer Model \_\_\_\_\_

Skid Steer Serial Number \_\_\_\_\_

Engine Model \_\_\_\_\_

Engine Serial Number \_\_\_\_\_



**This symbol is used throughout this book whenever your own personal safety is involved. Take time to be careful!**

---

## ABOUT IMPROVEMENTS

New Holland is continually striving to improve its products. We must, therefore, reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

### **COMPANY POLICY**

Company policy, which is one of continuous improvement, reserves the right to make changes in design and specifications at any time without notice and without obligation to modify units previously built.

All data given in this book is subject to production variations. Dimensions and weights are approximate only and the illustrations do not necessarily show skid steers in standard condition.

### **PARTS AND ACCESSORIES**

Genuine NEW HOLLAND parts and accessories have been specifically designed for HEW HOLLAND MACHINES.

We would like to point out that "NON-GENUINE" parts and accessories have not been examined and released by NEW HOLLAND. The installation and or use of such products could have negative effects upon the design characteristics of your machine and thereby affect its safety. NEW HOLLAND is not liable for any damage caused by the use of "NON-GENUINE" NEW HOLLAND parts and accessories.

### **MODEL CODES**

The range of Skid Steers described in this manual is identified in the text by the engine horsepower Pferdestärke. (PS). The skid steers listed below may not be available in all countries or markets.

ENGINE	PS	MODEL
N843	30	LS140
N843H	36	LS150

## PRECAUTIONARY STATEMENTS

### PERSONAL SAFETY

Throughout this manual and on machine decals, you will find precautionary statements (“**CAUTION**”, “**WARNING**”, and “**DANGER**”) followed by specific instructions. These precautions are intended for the personal safety of you and those working with you. Please take the time to read them.

---

—————  **CAUTION**  —————

The word “**CAUTION**” is used where a safe behavioral practice according to operating and maintenance instructions and common safety practices will protect the operator and others from accident involvement.

---

---

—————  **WARNING**  —————

The word “**WARNING**” denotes a potential or hidden hazard which has a potential for serious injury. It is used to warn operators and others to exercise every appropriate means to avoid a surprise involvement with machinery.

---

---

—————  **DANGER**  —————

The word “**DANGER**” denotes a forbidden practice in connection with a serious hazard.

---

FAILURE TO FOLLOW THE “**CAUTION**”, “**WARNING**”, AND “**DANGER**” INSTRUCTIONS MAY RESULT IN SERIOUS BODILY INJURY OR DEATH.

### MACHINE SAFETY

Additional precautionary statement (“**IMPORTANT**”) is followed by specific instructions. This statement is intended for machine safety.

**IMPORTANT:** *The word “**IMPORTANT**” is used to inform the reader of something he needs to know to prevent minor machine damage if a certain procedure is not followed.*

**SAFETY PRECAUTION INFORMATION**

Unsafe operating practices and improper use of the skid steer and its attachments on the part of the operator can result in injuries. Observe the following safety precautions at all times:

1. For servicing, the skid steer should be on level terrain, engine stopped with the wheels blocked or the entire skid steer solidly supported with the wheels off the ground before servicing any component of the drivetrain.
2. For servicing under the operator's seat, raise the seat and pan assembly to the raised latched position and securely latch.
3. Do not operate the skid steer unless the seat is latched in the operate position.
4. Do not service the skid steer with a raised boom unless the boom is resting on the boom lock pins.
5. Do not service the skid steer with the engine running unless the skid steer is properly and securely supported with all four wheels off the ground.
6. Use caution when servicing the unit around moving parts.
7. Do not tilt the boom and cab without proper instruction.
8. Do not tilt the boom and cab without using the proper cab tilting tool.
9. Reinstall all shields removed for service.
10. Never loosen any hydraulic connections before relieving the pressure in the hydraulic system.
11. Wear eye protection such as goggles, etc.
12. Wear ear protection such as earplugs, etc. When you feel the noise level is uncomfortable.
13. If any servicing or adjustments require the battery to be disconnected, disconnect the (-) negative ground cable.
14. When servicing electrical components, disconnect the (-) negative ground cable.
15. If the electronic instrument cluster (EIC) requires removal from the dash area of the skid steer, disconnect the (-) negative ground battery cable. this will shut off power to the eic and prevent damage to the eic board or blowing the 5-amp fuses if the board is accidentally grounded.
16. If welding is required on the skid steer, disconnect the (-) negative ground cable. Failure to disconnect the battery may result in damage to the EIC (electronic instrument cluster) monitoring system and other electrical components.
17. If welding is required on an attachment, remove the attachment from the skid steer.
18. Give complete and undivided attention to the job at hand so that complete control of the skid steer is maintained at all times.
19. Drive slowly over rough ground and on slopes; keep alert for holes, ditches and other irregularities that may cause the skid steer to overturn.
20. Avoid steep hillside operation which could cause the skid steer to overturn.
21. Never transport a loaded bucket at full height. Operate the skid steer with the load as low as possible until it becomes necessary to raise the boom to discharge the load into a truck, container, etc.
22. Reduce speed when turning so there is no danger of the skid steer overturning.
23. Never drive up or back up a hill or incline with a raised boom or the skid steer could overturn.
24. Always look behind you before backing up the skid steer.
25. Maintain proper transmission oil level to prevent loss of hydrostatic braking.
26. Do not allow passengers to ride on the skid steer at any time.
27. Do not allow children to operate the skid steer or ride on the skid steer at any time.
28. Do not allow anyone to operate the skid steer without proper instruction. OSHA requires that all operators be instructed on the proper operation of the machine before they operate the unit.
29. Do not operate the skid steer in any position other than while in the operator's seat with the seat belt securely fastened.

30. Before starting the engine, be sure that all operating controls are in neutral and the parking brake is engaged.
31. Never operate the skid steer engine in a closed building without adequate ventilation.
32. Refuel the skid steer outdoors with the engine shut off. replace the fuel cap securely. Use an approved fuel container. Do not smoke when handling fuel. Avoid spilling fuel.
33. After operating the engine, never touch the muffler, exhaust pipe, engine or radiator until they have had time to cool.
34. Dress appropriately - wear relatively tight-fitting clothing when operating the skid steer. Loose or torn clothing can catch in moving parts or controls.
35. Before servicing the skid steer, or any of its attached equipment, be sure that the attachments are lowered to the ground or that the boom arms are supported by the boom lock pins.
36. Do not work under overhangs, electric wires, or where there is danger of a slide.
37. Wear an approved safety hat when operating the machine and while in any work area.
38. When driving the skid steer on a road or highway, use warning lights or warning devices as may be required by local or state government regulations. headlights, warning lights and smv signs are available through your new holland dealer.
39. Keep the skid steer clean. do not allow trash, debris or other articles to accumulate in the cab, floor or foot control pedal area that may hinder safe machine operation.
40. Never operate the skid steer with any of the shielding removed.
41. Never operate the skid steer without windows and/or screens in place.
42. Never extend any part of the body outside of the operator's area.
43. Always properly tie down the skid steer to a truck or trailer before transport.
44. Make sure all bystanders are at a safe distance away from the skid steer before starting the engine.
45. Do not allow anyone near the skid steer while the engine is running and the skid steer is operational.
46. When using the skid steer to crane objects, do not allow anyone to ride on objects being craned.
47. Do not use the skid steer as a work platform for supporting materials.
48. Do not lift personnel or allow personnel to work while standing in the bucket or on other attachments. This is not a man-lift.

OSHA requirements now make it the employer's responsibility to fully instruct each operator in the proper and safe operation of all operative equipment. Both employer and employee should thoroughly familiarize themselves with the following sections.

---

—————  CAUTION  —————

Some pictures in this manual show safety shields removed or open to show parts being serviced or for clarity. All shields should be closed or replaced prior to operating the machine.

---

—————  DANGER  —————

**Fasten seat belt before starting engine!**  
This skid steer is a very stable unit but it can be upset if stopped suddenly when the bucket is raised and loaded.  
Therefore, do not start the engine before securely fastening the seat belt, and carry the load low.

---

## GENERAL SAFETY INFORMATION

### HANDLE FLUIDS SAFELY

When you work around fuel or other flammable material, do not smoke or work near heaters or other fire hazards.

Do not store flammable material in open containers.

Store flammable fluids away from fire hazards.


Do not incinerate or puncture pressurized containers.

Make sure machine is clean of dirt, grease, oil, and debris.

Do not store oily rags; they can ignite and burn spontaneously.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



### USE CARE AROUND HIGH-PRESSURE FLUID LINES

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines.

Tighten all line connections before applying pressure.

Check for leaks with a piece of cardboard.

Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source.

### AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders.

Do not heat by welding, soldering, or using a torch near pressurized fluid lines.

Pressurized lines can be accidentally cut or damaged when heat goes beyond the immediate flame area.

### USE CARE IN HANDLING AND SERVICING BATTERIES

#### Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of the battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Do not charge a frozen battery; it may explode. Warm the battery to 16° C (60° F).

### ⚠ WARNING ⚠

If any servicing or adjustments require the battery to be disconnected, or welding is required on the skid steer, disconnect the (-) negative ground cable. Failure to disconnect the battery may result in damage to the eic (electronic instrument cluster) monitoring system and other electrical components.

If welding on an attachment is required, first remove the attachment from the skid steer boom attaching plate.

**WARNING**

Starting an engine with a booster battery requires extreme care as batteries produce explosive gases. The slightest spark can cause an explosion.

Follow these safety tips:

1. Always shield your eyes when charging or working near a battery. Always provide good ventilation.
2. Cover the battery with a piece of carpet or other heavy material. Do not remove the battery vent caps.
3. Connect one cable to the (+) positive terminal of the weak battery. Connect the other end of the cable to the (+) positive terminal of the stronger battery.
4. Connect the second cable to the (-) negative terminal of the stronger battery.
5. Connect the remaining (-) negative cable end to the engine block or starter ground terminal.
6. Reverse this procedure when disconnecting the booster.

**USE SAFE SERVICE PROCEDURES****Wear Protective Clothing**

Wear close-fitting clothing.

Wear safety glasses or face shield as required.

Wear other safety equipment appropriate to the job.

Wear earplugs or earmuffs as required.

**SERVICE MACHINE SAFELY**

Use caution when working around moving parts.

If servicing requires the boom to be in the raised position, remove any attachment from the boom mounting plate and support the boom on the boom lock pins. If servicing requires the complete skid steer to be in the supported position, support the unit with adequate jack stands or blocking with all four wheels off the ground.

If servicing requires the engine to be operated, raise the machine and properly support the unit with adequate jack stands or blocking with all four wheels off the ground.

**CAUTION**

Before servicing the skid steer or any of its attached equipment, be sure that the attachments are lowered to the ground or the boom arms are supported by the boom lock pins.

**USE PROPER TOOLS**

Use tools appropriate for the job.

If tilting of the cab is required, use the proper tools and follow the procedure for tilting the cab in Section 1 of this manual.

**REVIEW SAFETY EQUIPMENT, SIGNS AND SHIELDS**

Replace missing or damaged safety decals.

Reinstall all shielding removed for servicing.

Replace any damaged or missing shielding.

**CONTROLS**

Operate unit and check machine functions for proper operation.

Check seat belt for proper operation, wear, and damage - Replace as needed.

Check operator restraint system and EIC for proper operation.


Check boom and bucket spool locks for proper operation.

Check mechanical boom locks for proper operation.

Check parking brake for proper operation and adjustment.

**MACHINE MODEL AND SERIAL NUMBER LOCATION**


The skid steer model and serial number tag is located on the right front interior of the operator's cab at 1.



1

**ENGINE MODEL AND SERIAL NUMBER LOCATION**

The engine model and serial number is located on the left side of the block at 1.



2

For the tightening torques for reassembly, use the following hardware torque chart unless the torque is specified in the instructions.

# MINIMUM HARDWARE TIGHTENING TORQUES

IN FOOT POUNDS (NEWTON-METERS) FOR NORMAL ASSEMBLY APPLICATIONS

## INCH HARDWARE AND LOCKNUTS

NOMINAL SIZE	SAE GRADE 2		SAE GRADE 5		SAE GRADE 8		LOCKNUTS		NOMINAL SIZE
	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	GR.B w/GR5 BOLT	GR.C w/GR8 BOLT	
1/4	55* (6.2)	72* (8.1)	86* (9.7)	112* (13)	121* (14)	157* (18)	61* (6.9)	86* (9.8)	1/4
5/16	115* (13)	149* (17)	178* (20)	229* (26)	250* (28)	324* (37)	125* (14)	176* (20)	5/16
3/8	17 (23)	22 (30)	26 (35)	34 (46)	37 (50)	48 (65)	19 (26)	26 (35)	3/8
7/16	27 (37)	35 (47)	42 (57)	54 (73)	59 (80)	77 (104)	30 (41)	42 (57)	7/16
1/2	42 (57)	54 (73)	64 (87)	83 (113)	91 (123)	117 (159)	45 (61)	64 (88)	1/2
9/16	60 (81)	77 (104)	92 (125)	120 (163)	130 (176)	169 (229)	65 (88)	92 (125)	9/16
5/8	83 (112)	107 (145)	128 (174)	165 (224)	180 (244)	233 (316)	90 (122)	127 (172)	5/8
3/4	146 (198)	189 (256)	226 (306)	293 (397)	319 (432)	413 (560)	160 (217)	226 (306)	3/4
7/8	142 (193)	183 (248)	365 (495)	473 (641)	515 (698)	667 (904)	258 (350)	364 (494)	7/8
1	213 (289)	275 (373)	547 (742)	708 (960)	773 (1048)	1000 (1356)	386 (523)	545 (739)	1

NOTE: Torque values shown with \* are inch pounds.

## IDENTIFICATION CAP SCREWS AND CARRIAGE BOLTS



SAE GRADE 2



SAE GRADE 5



SAE GRADE 8



REGULAR NUTS




SAE GRADE 5  
HEX NUTS



SAE GRADE 8  
HEX NUTS

## LOCKNUTS



GRADE IDENTIFICATION

GRADE A NO NOTCHES

GRADE B ONE CIRCUMFERENTIAL NOTCH

GRADE C TWO CIRCUMFERENTIAL NOTCHES




GRADE IDENTIFICATION

GRADE A NO MARKS

GRADE B THREE MARKS

GRADE C SIX MARKS

MARKS NEED NOT BE LOCATED  
AT CORNERS



GRADE IDENTIFICATION

GRADE A NO MARKS

GRADE B LETTER B

GRADE C LETTER C

# MINIMUM HARDWARE TIGHTENING TORQUES

## IN FOOT POUNDS (NEWTON-METERS) FOR NORMAL ASSEMBLY APPLICATIONS

### METRIC HARDWARE AND LOCKNUTS

NOMINAL SIZE	CLASS 5.8		CLASS 8.8		CLASS 10.9		LOCKNUT CL.8 W/CL8.8 BOLT
	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr	
M4	15* (1.7)	19* (2.2)	23* (2.6)	30* (3.4)	33* (3.7)	42* (4.8)	16* (1.8)
M6	51* (5.8)	67* (7.6)	79* (8.9)	102* (12)	115* (13)	150* (17)	56* (6.3)
M8	124* (14)	159* (18)	195* (22)	248* (28)	274* (31)	354* (40)	133* (15)
M10	21 (28)	27 (36)	32 (43)	41 (56)	45 (61)	58 (79)	22 (30)
M12	36 (49)	46 (63)	55 (75)	72 (97)	79 (107)	102 (138)	39 (53)
M16	89 (121)	117 (158)	137 (186)	177 (240)	196 (266)	254 (344)	97 (131)
M20	175 (237)	226 (307)	277 (375)	358 (485)	383 (519)	495 (671)	195 (265)
M24	303 (411)	392 (531)	478 (648)	619 (839)	662 (897)	855 (1160)	338 (458)


NOTE: Torque values shown with \* are inch pounds.

### IDENTIFICATION

#### HEX CAP SCREW AND CARRIAGE BOLTS

#### CLASSES 5.6 AND UP

#### MANUFACTURER'S IDENTIFICATION




#### PROPERTY CLASS

#### HEX NUTS AND LOCKNUTS

#### CLASSES 05 AND UP

#### MANUFACTURER'S IDENTIFICATION




#### PROPERTY CLASS

#### CLOCK MARKING

**INSTALLATION OF ADJUSTABLE FITTINGS IN STRAIGHT THREAD O RING BOSSES**

1. Lubricate the O ring by coating it with a light oil or petroleum. Install the O ring in the groove adjacent to the metal backup washer which is assembled at the extreme end of the groove, 4.
2. Install the fitting into the SAE straight thread boss until the metal backup washer contacts the face of the boss, 5.

**NOTE:** Do not over tighten and distort the metal backup washer.



3. Position the fitting by turning out (counterclockwise) up to a maximum of one turn. Holding the pad of the fitting with a wrench, tighten the locknut and washer against the face of the boss, 6.

**STANDARD TORQUE DATA FOR HYDRAULIC TUBES AND FITTINGS**

SIZE	TUBING OD mm      In.		THREAD SIZE	TUBE NUTS FOR 37° FLARED FITTINGS				O RING BOSS PLUGS ADJUSTABLE FITTING LOCKNUTS, SWIVEL JIC - 37° SEATS			
				TORQUE		TORQUE		TORQUE		TORQUE	
				NEWTON METERS Min.    Max.	FOOT POUNDS Min.    Max.	NEWTON METERS Min.    Max.	FOOT POUNDS Min.    Max.	NEWTON METERS Min.    Max.	FOOT POUNDS Min.    Max.		
4	6.4	1/4	7/16-20	12	16	9	12	8	14	6	10
5	7.9	5/16	1/2-20	16	20	12	15	14	20	10	15
6	9.5	3/8	9/16-18	29	33	21	24	20	27	15	20
8	12.7	1/2	3/4-18	47	54	35	40	34	41	25	30
10	15.9	5/8	7/8-14	72	79	53	53	47	54	35	40
12	19.1	3/4	1-1/16-12	104	111	77	82	81	95	60	70
14	22.2	7/8	1-3/16-12	122	136	90	100	95	109	70	80
16	25.4	1	1-5/16-12	149	163	110	120	108	122	80	90
20	31.8	1-1/4	1-5/8-12	190	204	140	150	129	158	95	115
24	38.1	1-1/2	1-7/8-12	217	237	160	175	163	190	120	140
32	50.8	2	2-1/2-12	305	325	225	240	339	407	250	300

These torques are not recommended for tubes of 12.7 mm (1/2") OD and larger with wall thickness of 0.889 mm (0.035") or less. The torque is specified for 0.889 mm (0.035") wall tubes on each application individually.

solvent or Loctite cleaner and apply hydraulic sealant Loctite no. 569 to the 37° flare and the threads.

Install fitting and torque to specified torque, loosen fitting and retorque to specifications.

Before installing and torquing 37° flared fittings, clean the face of the flare and threads with a clean

SECTION 00 - GENERAL INFORMATION

**PIPE THREAD FITTING TORQUE**

Thread Size	Torque (Maximum)
1/8" – 27	13 N·m (10 ft. lbs.)
1/4" – 18	16 N·m (12 ft. lbs.)
3/8" – 14	22 N·m (16 ft. lbs.)
1/2" – 14	41 N·m (30 ft. lbs.)
3/4" – 14	54 N·m (40 ft. lbs.)

Before installing and tightening pipe fittings, clean the threads with a clean solvent or Loctite cleaner and apply sealant Loctite no. 567 for all fittings including stainless steel or no. 565 for most metal fittings. For high filtration/zero contamination systems use no. 545.

**LUBRICANTS AND COOLANTS**

Application	New Holland Part Number	Specification
Final Drive chain case	1 qt. - #9613313 2.5 gal. - #9613314 1 L - #9613358 20 L - #9613360	API Service SH-CG4 10W-30
Hydraulic/Transmission	1 qt. - #9613313 2.5 gal. - #9613314 1 L - #9613358 20 L - #9613360	API Service SH-CG4 10W-30
All lubrication fittings	Tube - #9613310	High viscosity lithium base grease
Engine	1 qt. - #9613313 2.5 gal. - #9613314 1 L - #9613358 20 L - #9613360	API Service SH-CG4 10W-30 Refer to Operator's Manual for Temperature/Oil usage Chart
Cooling System	1 gal. - #FGCC2701DS	Antifreeze/Water 50/50 Mixture (Ethylene Glycol)


**SEALANTS**

Description	New Holland Part No.	Typical Applications	Strength	Color
Thread Lock	L22200 (222)	Small screws/hardware	Low	Purple
	L24231 (242)	Nuts & Bolts	Medium	Blue
	L29000 (290)	Wicking Type	Medium	Green
	L26231 (262)	Nuts & Bolts	High	Red
Thread Sealants	L54531 (545)	Hydraulic/Pneumatic	Non-fouling	
	L56531 (565)	Pipe Sealant	Controlled strength	
	L56747 (567)	Pipe Sealant	High Temperature	
Silicones	L81724 (3.5 oz. tube)	Ultra Blue RTV Gasket	Non-corrosive	Blue
	L58775 (10.2 oz. cartridge)	Ultra Blue RTV Gasket	Non-corrosive	Blue
	L82180 (3.35 oz. tube)	Ultra Blue RTV Gasket	Non-corrosive	Black
	L59875 (10.2 oz. cartridge)	Ultra Blue RTV Gasket	Non-corrosive	Black

**PROPERLY SUPPORT A RAISED MACHINE**

If servicing neutral adjustment, final drive adjustment or repairs requiring the machine to be raised, securely support the machine with adequate jack stands or blocks as shown.

Support the machine at 1 to the front of the final drive cases and to the rear at 2, making sure the supports are on the flat area of the final drive cases.




4

**PROPERLY SUPPORT BOOM ON BOOM LOCK PINS**

Before servicing the machine or any of its attached equipment, be sure that the attachments are lowered to the ground or the boom arms are supported by the boom lock pins, 1.

If the boom is to be raised on the boom lock pins, remove any attachment. Opening a hydraulic line could cause a mounted attachment to dump over unexpectedly.




5

**RAISING BOOM WITHOUT HYDRAULIC OIL FLOW**

**(Engine Or Hydraulic System Not Functioning)**

1. Remove any attachment from the boom mounting plate.
2. Block the rear of the skid steer under the rear of the final drive cases, 1, as shown.

This will prevent the front wheels from raising during boom lifting.




6

- Attach a fork lift or overhead hoist to the main boom, 1 and lifting device, 2.

Attach chain or strap securely to prevent unhooking during boom lifting.



**Attach suitable chains or straps capable of handling the weight of the boom, 454 kg (1000 lbs). Attach chains securely to prevent them from coming loose during lifting of the boom.**




7

- With an Operator sitting in the Operator's seat with the seat belt buckled.
- Turn the ignition key to the "ON" position. Foot controls, press the toe of the left foot pedal, boom control, or hand controls, pivot the left-hand control lever down, into the boom float position.
- Slowly raise the boom above the boom lock pins, 1.
- Operator sitting in seat, engage the boom lock pins, 1.
- Lower the boom and rest on the boom lock pins, 1.
- Return the boom control to the "NEUTRAL" position.
- Turn the ignition key to the "OFF" position.



**The operator must not leave the operator's seat until the boom is resting solidly on the boom lock pins. The boom could drop suddenly if lifting devices should fail.**




8

### RAISING BOOM WITHOUT BATTERY VOLTAGE (12 VOLTS)

- Remove any attachment from the boom mounting plate.
- Block the rear of the skid steer under the rear of the final drive cases, 1, as shown.

This will prevent the front wheels from raising during boom lifting.




9

3. Attach a fork lift or overhead hoist to the main boom, 1 and lifting device, 2.

Attach chain or strap securely to prevent unhooking during boom lifting.




**Attach suitable chains or straps capable of handling the weight of the boom, 454 kg (1000 lbs). Attach chains securely to prevent them from coming loose during lifting of the boom.**




10

4. Remove the rod end (top) pivot pins, 1, from both cylinders. By remove retaining hardware, 2, from pivot pin and boom.



11

5. Support the cylinders on the fenders, 1, as shown.




12

6. With an Operator sitting in the Operator's seat with the seat belt buckled.
7. Slowly raise the boom above the boom lock pins, 1.
8. Operator sitting in seat, engage the boom lock pins, 1.
9. Lower the boom and rest on the boom lock pins, 1.




**The operator must not leave the operator's seat until the boom is resting solidly on the boom lock pins. The boom could drop suddenly if lifting devices should fail.**



13


### REATTACHING CYLINDERS AFTER REPAIR WITH BOOM RESTING ON BOOM LOCK PINS

1. Support the rod end of cylinders, 1, off the boom upper links, 2, to align with main boom cylinder pivot pin holes, 3.



14

2. Operator sitting in the Operator's seat with seat belt buckled.
3. Start the engine and hydraulically extend cylinder rods to align cylinder with pivot pin, 1. Stop engine.
4. Turn the ignition key to the "ON" position. Foot controls, press the toe of the left foot pedal, boom control, or hand controls, pivot the left hand control lever down, into the boom float position, turn the ignition key to the "OFF" position.
5. If cylinder and boom are not properly aligned, use a pry bar to align cylinder and boom.
6. Install pivot pin, 1, and secure with retaining hardware, 2. Torque bolts to 38 N-m (28 ft. lbs.)
7. Start the engine and hydraulically extend the second cylinder rod to align cylinder with pivot pin. Stop engine.
8. If cylinder and boom are not properly aligned, sit in the operator's seat with seat buckled, turn the ignition key to the "ON" position.



15


9. Move the boom control to the "DETENT" (float) position and turn the ignition key to the "OFF" position.
10. Use a pry bar and align cylinder with boom and install pivot pin, 1, and retaining hardware, 2, and torque to 38 N·m (28 ft. lbs.).

### MAJOR UNIT OVERHAUL

For a major hydrostatic component or engine repair, the skid steer cab and boom assembly can be tilted forward for easier access to the components area. Figure 16 shows the skid steer properly supported and the cab tilted forward.



**Never attempt to tilt the skid steer cab without using the proper tool and instructions. See more detail later in this section of the manual and/or contact your New Holland dealer.**




**CAB AND BOOM TILT PROCEDURE**


The cab and boom assembly can be tilted forward for easier access to the major skid steer hydrostatic transmission or engine components. To tilt the cab, the proper cab tilting tool must be used to ensure safety and to prevent damage to the skid steer frame, cab, and boom structure. Contact your New Holland dealer for major service or repairs of the skid steer. Using the proper cab tilting tool and following these steps, the cab and boom can be tilted forward.

**Cab Tilting Jack and Support Bracket**

1. Jack and Screw Assembly
  2. Lower Support
  3. Upper Support
1. Remove any attachment, bucket, etc. from the boom quick-attach plate.




17



18

2. Raise the boom and lower onto boom lock pins, 1.
  - a. Raise boom above boom lock pins.
  - b. Engage boom lock pins.
  - c. Stop engine, ignition key off position.
  - d. Turn ignition key to the on position.
  - e. Lower boom onto boom lock pins.
  - f. Turn the ignition key to the "OFF" position.




19

3. Jack up the skid steer and block it securely with all four wheels off the ground, as shown. Position the front blocks, 1, to the front of the final drive housings and the rear blocks, 2, to the rear of the flat area of the final drive housings.




**Never attempt to tilt the skid steer cab over unless the skid steer is securely supported.**




20

4. Open the rear door, 1. Raise and remove the top engine shield, 2.
5. Remove engine side covers, 3.



21


6. Disconnect the battery negative (-) cable, 1.



22

SECTION 00 - GENERAL INFORMATION

7. Remove fenders, 1, right and left sides.
8. Remove the front step shield, 2.
9. Remove the front engine shield supports, 3, right and left sides.




23

10. Raise the seat and lock in the up position, 1.  
Make sure the seat pan assembly is latched securely.




**CAUTION**

**Do not work under the seat and pan unless it is properly latched in the raised position.**



24


11. Remove the cotter pins from the parking brake linkage at 1, unhook link rod, 2, and raise the parking brake lever to the engaged position.



25


SECTION 00 - GENERAL INFORMATION

12. Install the lower cab jack support, 1, by sliding the support over the attaching pin at 2, on the left front final drive. Rest the other end of the support on top of the front tie down loop, 3, and secure with a 5/8" x 3" cap screw and nut, 4.




26

13. Install the upper cab jack support, 1, by pivoting the retaining plate, 2, up behind the boom top link and retaining with a 1/2" x 1-1/4" carriage bolt and 1/2" wing nut at 3. Install a 1/2" x 2-1/2" retaining bolt, 4, through the side of the cab and secure on the inside with a large 1/2" flat washer and 1/2" wing nut. Tighten securely.



27

14. Install the jack assembly, 1, between the upper and lower supports using two pins and retaining clips at 2.




28

15. Loosen the front cab mounting bolts, 1, only enough to allow the bolt to rotate in the support. Remove the rear front cab bolts, 2.

**CAUTION**

Never remove the front cab bolts, 1, as these are the pivot bolts during the cab tilting procedure. Removal of these bolts could cause the cab to fall and may cause injury and machine damage.




29

16. Remove the two rear cab post bolts, 1.

**CAUTION**

Never loosen or remove any cab retaining hardware before the jack assembly is installed.




30

17. Jack cab and boom assembly over with the skid steer properly supported off the ground. Support the boom at 1, to prevent tipping of the skid steer when heavy components, engine, hydrostatic pumps, etc. are removed from the lower frame. Jack travel or length of hydraulic hoses will limit the travel of the cab assembly when tilting. Be sure all wire harnesses, hydraulic hoses, and throttle cable clear any obstructions during cab tilting.

**WARNING**

Never attempt to tilt the skid steer cab without proper instructions and without using the proper tool.



31

**CAUTION**

Never attempt to operate or move the skid steer without first installing and properly tightening all cab retaining hardware.

To jack the cab and boom assembly back into position:

1. Pull the hydrostat control handles forward and hold in this position with rubber tie straps from the handle to the front cab post.
2. Jack the cab and boom back into position.
3. Keep the wire harness, 1, and throttle cable, 2, in position to prevent damage from setting the cab on them.
4. Pull the wire harness through the loop, 3.




**Keep the wire harness from being damaged. A damaged wire harness could result in damage to the skid steer electrical components.**

5. Remove rubber tie straps from the hydrostatic control handles.
6. Reinstall all cab support bolts front and rear.


**NOTE:** Replace any standard 7/8" nuts with 7/8" locknuts, part #280658.

Torque the rear bolts, 1, to 312 N·m (230 ft. lbs.).

7. Reinstall the parking brake linkage, 2.
8. Position the throttle cable, 3, inside frame.




32




33

9. Reinstall the rear fender supports at 1. Do not tighten hardware at this time.




34

10. Torque the front bolts, 1, to 190 N·m (140 ft. lbs.).



35

11. Reinstall the parking brake linkage, 1, with cotter pins, 2.



36

12. Install fenders, 1, engine shields, 2, and front step shield, 3.

13. Tighten the rear fender support bracket hardware at 4.


14. Remove the cab jack and supports.

15. Reconnect the battery cable.



**WARNING**

**Never attempt to operate or move the skid steer without first installing and properly tightening all cab retaining hardware.**




37

**CRANING THE SKID STEER**

If the skid steer is inoperative and located in an area where it cannot be loaded onto a truck or trailer, the unit may be craned to load the unit.

To crane the skid steer, only use chain or cable with a rated capacity to handle the weight of the model skid steer being craned. Refer to "Specifications" in this manual for the operating weight of the model skid steer being craned. Use three chains minimum of 3.66 m (12') long to prevent sharp angles and damage to the skid steer cab, boom, and lifting chains.




38

Remove any attachment except a standard bucket from the skid steer boom attaching plate.


— **⚠ CAUTION ⚠** —

**Do not lift any attachments on the skid steer mounting plate that weigh 272 kg (600 lbs) or more. Lift such attachments separately.**



39


The lifting points at the rear of the skid steer, 1.



40

SECTION 00 - GENERAL INFORMATION

The front lift point is located in the center of the main frame, 1.




41

The lifting chains or cables must be minimum of 3.66 m (12'). The lifting hook point must be minimum of 1.9 m (75") above the cab, 1, to prevent the chains or cables from damaging the skid steer frame or cab.



**Always use properly rated lifting devices to prevent personal injury or damage to the skid steer.**



42

When craning (lifting or lowering) a skid steer, observe these **“CAUTIONS”**.



**CAUTION**



1. **No riders (including the operator) in or on the machine while lifting or lowering.**
  2. **Do not lift any attachments on the skid steer mounting plate that weigh 272 kg (600 lbs) or more. lift such attachments separately.**
  3. **Always use a chain or cable capable of safely hoisting the weight of the skid steer.**
  4. **Before hoisting the skid steer, always inspect the lifting chain or cable and the lifting points on the skid steer main frame to insure they are in good condition. If worn or damaged, do not use.**
  5. **Do not lift the skid steer with any frame-mounted attachments such as a backhoe or rear stabilizers.**
  6. **Do not attach lifting devices to the skid steer boom or attachments on the skid steer.**
  7. **Make sure the skid steer boom is in the completely lowered position.**
  8. **Make sure that any attachment to be lifted on the skid steer is securely fastened to the skid steer mounting plate with the over-center handles and pins fully engaged. Pivot the attachment fully back.**
  9. **Make sure that the engine is off and the parking brake is engaged before lifting.**
  10. **Keep bystanders away from the machine a safe distance while lifting.**
-

SECTION 00 - GENERAL INFORMATION

**SPECIAL TOOLS**

Tool Number	Order From	Description	LS140	LS150
86590084	New Holland	Cab Tilting Tool	***	***
<b>Engine</b>				
NH 00011	OTC	Oil pressure adapter	***	***
NH 00120	OTC	Compression test adapter	***	***
NH 00117	OTC	Oil pump port block installer	***	***
NH 11097	OTC	Oil pump port block remover	***	***
<b>Hydraulic System</b>				
238 Bar (3500 Psi) Test Gauge	OTC	Main system pressure	***	***
Flow meter	OTC	Main system/Hydrostatic pumps	***	***
3/4" -16 UNF O ring fitting	Local	Main system at Boom cylinder	***	***
1/2" Quick coupler	New Holland	Main system at Auxiliary boom couplers	*	*
FNH22ESS95	OTC	Hydraulic tank pressuring tool	*	*

\* Recommended Tool

\*\*\* Essential Tool