

TC21DA, TC24DA REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE SYSTEMS	3
SECTION 18 - SINGLE CLUTCH	10
SECTION 21 - TRANSMISSION SYSTEMS	11
SECTION 25 - FRONT AXLE - FRONT WHEEL DRIVE	13
SECTION 27 - DIFFERENTIAL AND REAR AXLE	14
SECTION 29 - HYDROSTATIC TRANSMISSION	15
SECTION 31 - POWER TAKE-OFF SYSTEMS	19
SECTION 33 - BRAKES	20
SECTION 35 - HYDRAULIC SYSTEM	21
SECTION 41 - POWER STEERING SYSTEM	24
SECTION 44 - WHEELS AND TIRES	26
SECTION 55 - ELECTRICAL SYSTEM	26
SECTION 90 - PLATFORM	32

The following pages are the collation of the contents pages from each section and chapter of the TC21DA and TC24DA Repair manual. Complete Repair part # 87053135.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TC21DA and TC24DA Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87053136

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Introduction	2
	Precautionary Statements	3
	Safety	4
	The Tractor	4
	Servicing the Tractor	4
	Operating the Tractor	5
	Driving the Tractor	5
	Operating the PTO	6
	Diesel Fuel	6
	Safety Frame (ROPS)	6
	Safety Decals	7
	Instruction Decals	9
	Product Identification Plate	13
	International Symbols	14
	Specifications - TC21DA, TC24DA	15
	General Dimensions - TC21DA, TC24DA	20
	Minimum Hardware Tightening Torques	23
	Lubricants	25
	Adjustments	26

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87053136

Chapter 1 - Engine Systems

CONTENTS

Section	Description	Page
	Description and Operation - General Information	6
	Identification Chart	6
	Cylinder Head and Valve Train Components	6
	Cylinder Block Assembly	7
	Overhaul - Engine	8
	Engine Preparation	8
	Disassembly	8
	Fuel Injector and Glow Plug	10
	Removal	10
	Oil Pressure Switch	10
	Removal	10
	Temperature Sending Switch and Alternator	11
	Removal	11
	Fan, Water Pump, and External Oil Tube	11
	Removal	11
	Valve Cover	11
	Removal	11
	Rocker Shaft and Push Rod	12
	Removal	12
	Cylinder Head	12
	Removal	12
	Valve Tappet	12
	Removal	12
	Fuel Shut-off Solenoid	13
	Removal	13
	Engine Timing Gear Cover	13
	Removal	13
	Timing Gears and Camshaft	15
	Removal	15
	Oil Sump	15
	Removal	15

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87053136

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Oil Suction Pipe and Strainer	16
	Removal	16
	Connecting Rods, Bearing and Pistons	16
	Removal	16
	Flywheel	17
	Removal	17
	Backplate and Oil Seal	17
	Removal	17
	Crankshaft and Main Bearing	17
	Removal	17
18 110	Cylinder Head	18
	Disassembly	18
	Inspection	18
	Valve Seats	19
	Inspection	19
	Valves	20
	Inspection	20
	Valve Guides	22
	Inspection	22
	Valve Springs	22
	Inspection	22
	Rocker Arms	23
	Inspection	23
	Push Rods	23
	Inspection	23
	Cylinder Head	24
	Assembly	24
	Cylinder Block	24
	Inspection	24
10 105	Pistons, Piston Rings, and Connecting Rods	25
	Disassembly	25

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87053136

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Piston	25
	Inspection	25
	Piston Rings	27
	Inspection	27
	Connecting Rods	28
	Inspection	28
	Bearing Oil Clearance Check	30
10 105	Pistons, Piston Rings, and Connecting Rod	30
	Assembly	30
10 103	Crankshaft Main Bearings	31
	Removal	31
	Inspection	31
	Crankshaft	32
	Inspection	32
	Crankshaft Journal Wear Limit and Bearing Usage	32
	Crankshaft Front Main Bearing (Bushing)	33
	Inspection	33
	Replacement	33
	Crankshaft Main Bearing	34
	Assembly	34
	Port Block	34
	Removal	34
	Installation	34
	Timing Gear	35
	Inspection	35
	Camshaft	35
	Disassembly	35
	Inspection	36
	Assembly	36
10 103	Flywheel	37
	Inspection	37

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87053136

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Timing Gear Housing	37
	Front Oil Seal and Steering Pump Seal	37
	Replacement	37
	Crankshaft and Bearing Holder	38
	Assembly	38
	Rear Oil Seal and Backplate	38
	Assembly	38
	Flywheel	39
	Installation	39
	Piston and Connecting Rod	39
	Installation	39
	Oil Suction Pipe and Suction Strainer	40
	Installation	40
	Oil Sump	40
	Installation	40
	Camshaft and Camshaft Gear	40
	Assembly	40
	Idle Gear, Oil Pump and Injection Timing	41
	Installation	41
	Timing Gear Cover	41
	Installation	41
	Crankshaft Pulley	41
	Installation	41
	Fuel Injection Pump	42
	Installation	42
	Power Steering Pump	42
	Installation	42
	Head Gasket	43
	Cylinder Head	44
	Assembly	44
	Valve Clearance Adjustment	45

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87053136

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Valve Cover	45
	Installation	45
	Fan, Water Pump and External Oil Tube	46
	Installation	46
	Glow Plug and Connector	46
	Installation	46
	Fuel Injector	46
	Installation	46
	Fuel Piping	47
	Installation	47
	Alternator and Temperature Sending Switch	47
	Installation	47
	Exhaust Manifold, Radiator, and Air Cleaner	48
	Installation	48
10 304	Description of Operation - Engine Lubrication System	49
10 206	Engine Oil Filter	52
10 304	Oil Pump	52
	Removal	52
	Inspection	52
	Installation and Adjustment	53
	Engine Oil Pressure Check	54
	Oil Pressure Relief Valve	54
	Removal	54
	Installation	54
10 400	Description of Operation - Cooling System	55
	Maintenance	57
	Coolant	57
	Thermostat	57
	Water Pump	57
	Cooling Fan	57
	Radiator	57
	Radiator Cap	57

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87053136

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Overhaul - Cooling System	58
10 406	Radiator	58
	Removal	58
	Inspection and Repair	59
	Installation	59
10 402	Water Pump and Thermostat	60
	Removal	60
	Inspection and Repair	62
	Assembly	62
	Installation	62
	Troubleshooting	64
10 000	Specification	70
	Cylinder Head	70
	Cylinder Block	71
	Piston	71
	Piston Ring	72
	Connecting Rod	72
	Crankshaft	73
	Crankshaft	74
	Valves	75
	Push Rods	76
	Rocker Arms	76
	Lubrication System	76
	Cooling System	77
	Torque Specifications	78
	Special Tools	79
	Compression Test and Tools	79

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87053136

Chapter 2 - Fuel System

CONTENTS

Section	Description	Page
10 242	Description and Operation - Injection Pump	2
10 236	Pumping Elements	4
10 214	Delivery Valves	4
	Injection Pump	6
10 214	Removal	6
	Repair	6
	Installation	6
	Timing and Governor Adjustments	7
10 230	Installation Using Original Pump and Drive Components	7
	Install a New Pump or Drive Component	7
	Spill-timing Procedure	8
	Bleeding the Fuel System	12
	Full Screw/High Idle Adjustment	12
10 230	Description of Operation - Governor	13
	Governor	15
	Disassembly	15
	Assembly	16
	Adjustments	17
10 218	Description and Operation - Injectors	18
	Injector	19
	Removal	19
	Disassembly	20
	Assembly and Adjustment	20
	Troubleshooting - General	21
	Troubleshooting - Fuel Injectors	24
	Troubleshooting - Governor	25
	Specifications	26

SECTION 18 - SINGLE CLUTCH

BOOK 1 - 87053136

Chapter 1 - Single Clutch

CONTENTS

Section	Description	Page
	Description and Operation – General Information	2
	Single Clutch	3
	Free Play Adjustment	3
	Separating the Tractor Between the Engine and Clutch Housing – 9 x 3 Transmissions	4
	Disassembly	4
	Removal	13
	Installation	13
	Assembly	15
	Description and Overhaul – Servicing Clutch-Related Components	23
18 110	Clutch Pilot Bearing – 9 x 3 Gear Transmission Only	23
	Removal	23
	Inspection	23
	Installation	23
	Clutch Release Bearing	24
	Removal	25
	Inspection	26
	Assembly	26
	Flywheel Dimensions	27
	Clutch Cross Shaft Bushings	27
	Removal	27
	Assembly	27
	Clutch Pedal Bushings	28
	Removal	28
	Assembly	28
	Clutch Linkage Adjustment	29
	Troubleshooting	30
	Specifications	31
	Special Tools	32

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87053137

Chapter 1 - Transmission Systems

CONTENTS

Section	Description	Page
	Introduction	3
	Description and Operation - 9 x 3 Gear Transmission	4
	9 x 3 Gear Transmission - Power Flow	5
	Overhaul	11
	Transmission Preparation	11
	Separating the Tractor - Between the Clutch Housing and the Rear Transmission - 9x3 Transmission	12
	Removal	12
	Transmission Shift Cover	16
	Disassembly	18
	Assembly	22
	Input Shaft, Idler Gear, and Countershaft Gear	26
	Removal	26
	Main Shaft	27
	Removal	27
	Front Wheel Drive Shaft	28
	Removal	28
	Countershaft	29
	Removal	29
	Range and Rear PTO Shift Rail and Fork	30
	Removal	30
	Pinion Shaft	31
	Removal	31
	PTO Front Countershaft	32
	Removal	32
	Mid-Mount PTO Idler Shaft	33
	Removal	33
	Mid-Range Gear Case	34
	Disassembly	34
	Inspection	34
	Mid-Range Gear Case	35
	Assembly	35

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87053137

Chapter 1 - Transmission Systems (Continued)

CONTENTS

Section	Description	Page
	Mid-Mount PTO Idler Shaft	36
	Assembly	36
	PTO Front Countershaft	36
	Assembly	36
	Rear PTO Countershaft	37
	Assembly	37
	Pinion Shaft	38
	Installation	38
	Shift Rail and Fork	39
	Installation	39
	Countershaft	40
	Assembly	40
	Front Wheel Drive Shaft	41
	Assembly	41
	Front Wheel Drive Shift Cover	41
	Assembly	41
	Main Shaft	42
	Assembly	42
	Input Shaft, Idler Gear and Countershaft Gear	43
	Assembly	43
	Reconnecting the Tractor - Between the Clutch Housing and the Rear Transmission - 9 x 3 Transmission	44
	Installation	44

SECTION 25 - FRONT AXLE - FRONT WHEEL DRIVE

BOOK 2 - 87053137

Chapter 1 - Front Axle - Front Wheel Drive

CONTENTS

Section	Description	Page
25 100	Description and Operation - Front Axle - Front Wheel Drive	2
	Overhaul	3
	Front-Wheel Drive Front Axle	3
	Removal	3
25 108	Front Axle	4
	Disassembly	4
25 102	Differential	6
	Disassembly	6
	Differential	6
	Inspection	6
	Axle	6
	Inspection	6
	Differential	8
	Assembly	8
	Pinion	8
	Assembly	8
	Ring Gear to Pinion Backlash Check (Using Original Components)	10
	Ring Gear to Pinion Backlash Check (Using New Components)	11
	Shim Calculation - Alternate Method	12
	Pinion-To-Ring Gear Tooth Contact Adjustment	13
	Front-Wheel Drive Front Axle	14
	Installation	14
	Final Pinion and Wheel Shaft	14
	Backlash Adjustment	14
	Troubleshooting	15
	Front Axle	15
	Specifications	16
	Front Wheel Drive	16

SECTION 27 - DIFFERENTIAL AND REAR AXLE

BOOK 2 - 87053137

Chapter 1 - Differential and Rear Axle

CONTENTS

Section	Description	Page
27 106	Description and Operation – General Information	2
	Differential	2
27 110	Differential Lock	2
27 126	Rear Axle and Brakes	2
	Overhaul	8
27 106	Differential	8
	Removal	8
	Drive Pinion	10
	Removal	10
	Differential	11
	Disassembly	11
	Inspection	11
	Assembly	12
	Rear Axle	16
	Disassembly	16
	Inspection	16
	Assembly	16
27 110	Differential Lock	18
	Disassembly	18
	Assembly	19
	Specifications	20
	Ring Gear and Pinion Gear Pattern Specification and Adjustment	21
	Special Tools	21

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87053137

Chapter 1 - Hydrostatic Transmission

CONTENTS

Section	Description	Page
29 202	Description and Operation - Hydrostatic Transmission	5
29 212	Variable Displacement Pump Operation	7
29 212	Fixed Displacement Motor Operation	8
	Fluid Flow	9
	Neutral Position	10
	Forward Position	10
	Reverse Position	11
	Overhaul - Hydrostatic Transmission	12
	Transmission Preparation	12
	Separation between the Clutch Housing and the Extension Housing - the Extension Housing and Rear Transmission	13
29 202	Hydrostatic Unit	17
	Removal	17
	Precautions Before Disassembly	20
	Motor and Port Block	20
	Disassembly	20
	Hydrostatic Motor	22
	Disassembly	22
	Hydrostatic Motor Shaft	24
	Disassembly	24
	Charge Pump	24
	Disassembly	24
	Swash Plate	25
	Disassembly	25
	Inspection	27
	Swash Plate/Charge Pump	30
	Assembly	30
	HST Piston Pump Cylinder Block	31
	Assembly	31
	HST Motor Cylinder Block	33
	Assembly	33
29 130	Port Block	34

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87053137

Chapter 1 - Hydrostatic Transmission (Continued)

CONTENTS

Section	Description	Page
	Neutral and Feed Valves	34
	Disassembly	34
	Inspection	34
	Assembly	35
	Charge Pump Relief Valve	35
	Disassembly	35
	Inspection	35
	High Pressure Relief Valve	36
	Removal	36
	Installation	36
	Hydrostatic Pump and Port Block	36
	Assembly	36
	Motor and Port Block	38
	Assembly	38
29 204	Check Valve	39
	Disassembly	39
	Inspection	39
	Assembly	39
	Installation of the Clutch Housing and the Extension Housing - the Extension Housing and Rear Transmission	40
	Pressure Tests	45
	High Pressure Relief Valve	45
	Charge Pump Pressure Relief Valve	46
	Description and Operation - Gearbox	48
29 300	Gearbox	48
	Overhaul - Gearbox	51
	Gearbox	51
	Removal	51
	Separation between the Clutch Housing and the Extension Housing - the Extension Housing and Rear Transmission	51

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87053137

Chapter 1 - Hydrostatic Transmission (Continued)

CONTENTS

Section	Description	Page
	Transmission Drive Shaft and PTO Input Shaft	55
	Removal	55
	Main Bearing Holder Plate	56
	Removal	56
	Main Shaft	57
	Removal	57
	FWD Drive Shaft (FWD Model only)	57
	Removal	57
	Countershaft	59
	Removal	59
	Range and Rear PTO Shift Rail and Fork	60
	Removal	60
	Pinion Shaft	61
	Removal	61
	PTO Front Countershaft	62
	Removal	62
	Mid-Mount PTO Idler Shaft	63
	Removal	63
	Inspection	63
	Shift Rail and Fork	64
	Installation	64
	Mid-Mount PTO Idler Shaft	65
	Assembly	65
	PTO Front Countershaft	66
	Assembly	66
	Pinion Shaft	67
	Installation	67
	Countershaft	67
	Assembly	67
	FWD Shaft (FWD Models only)	68
	Assembly	68

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87053137

Chapter 1 - Hydrostatic Transmission (Continued)

CONTENTS

Section	Description	Page
	Main Shaft	69
	Assembly	69
	Input Shaft, Transmission Drive Shaft, and Retaining Plate	69
	Assembly	69
	Front Wheel Drive Shaft Cover	71
	Assembly	71
	Installation of the Clutch Housing and the Extension Housing - the Extension Housing and Rear Transmission	72
	Overhaul and Adjustments - Control Linkage	77
29 200	Control Linkage	77
	Initial Adjustments	78
	Control Rod	78
	Pedal Stop	78
	HST Neutralizer	79
	Removal	79
	Disassembly	80
	Inspection	81
	Assembly	82
	Installation	83
	HST Neutral Adjustment	84
	Linkage Damper	85
	Removal	85
	Pedal	86
	Removal	86
	Pedal Pivot Shaft	88
	Removal	88
	Damper, Pivot Shaft, Pedal and FWD Drive Shaft	89
	Assembly	89
	Troubleshooting	91
	Specifications	92
	Metric Bolt Torque Specifications	94
	Special Tools	95

SECTION 31 - POWER TAKE-OFF SYSTEMS

BOOK 3 - 87053138

Chapter 1 - Power Take-Off Systems

CONTENTS

Section	Description	Page
	Description and Operation - PTO System	3
31 110	9 x 3 Gear Transmission	3
31 110	Hydrostatic Transmission	4
	Overhaul - Rear PTO	5
31 114	9 X 3 Rear PTO Output Shaft	5
	Removal	5
	Inspection	5
	Assembly	5
	HST Rear PTO Output Shaft	7
	Removal	7
	Inspection	7
	Assembly	8
	Description and Operation - Mid-Mount PTO	9
	Mid-Mount Power Take-Off	9
	Overhaul - Mid-Mount PTO	11
31 120	9 x 3 Optional Mid-Mount PTO	12
	Gearbox and Countershaft	12
	Removal	12
	Output Shaft	12
	Removal	12
	Inspection	13
	Assembly	13
	Gearbox and Countershaft	13
	Assembly	13
	Hydrostatic Transmission, Standard Mid-Mount PTO	15
	Gearbox and Countershaft	15
	Removal	15
	Output Shaft	15
	Removal	15
	Inspection	16
	Assembly	16

SECTION 31 - POWER TAKE-OFF SYSTEMS

BOOK 3 - 87053138

Chapter 1 - Power Take-Off Systems (Continued)

CONTENTS

Section	Description	Page
Section	Description	Page
	Gearbox and Countershaft	16
	Assembly	16
	Specifications	17
	Rear PTO	17
	Mid-Mount PTO	17
	Metric Bolt Torque Specifications	18

SECTION 33 - BRAKES

BOOK 3 - 87053138

Chapter 1 - Brakes

CONTENTS

Section	Description	Page
	Overhaul	2
33 120	Brakes and Final Pinion	2
	Removal	2
	Inspection	3
	Assembly	3
	Brake Adjustment	4
	Specifications	5

SECTION 35 - HYDRAULIC SYSTEM

BOOK 3 - 87053138

Chapter 1 - Hydraulic System

CONTENTS

Section	Description	Page
	Description and Operation - Hydraulic System	4
35 000	Hydraulic System Circuits	4
	Oil Filter	5
35 080	Combination System Relief - Diverter Valve Manifold	6
35 200	Control Valve Assembly (HPL)	7
35 210	Oil Flow	8
	Neutral Position	8
35 210	Lifting Position	9
35 210	Lowering Position	10
	Cylinder Head and Flow Control Valve	11
	Overhaul - Hydraulic System	12
35 110	Lift Cylinder	12
	Removal	12
	Disassembly	16
	Inspection and Repair	17
	Assembly	18
35 183	Cylinder Head (Flow Control Valve)	19
	Disassembly	19
	Inspection	19
	Assembly	19
	Control Valve	20
	Disassembly	20
	Inspection	22
	Assembly	22
	Lowering Valve	25
	Adjustment	25
	Diverter Valve and Relief Valve Manifold Assembly	25
	Removal	25
	Disassembly	26
	Inspection	26
	Assembly	26

SECTION 35 - HYDRAULIC SYSTEM

BOOK 3 - 87053138

Chapter 1 - Hydraulic System (Continued)

CONTENTS

Section	Description	Page
	Adjustments	27
35 124	Linkage	27
	Adjustment Procedure	27
	Control Lever	27
	Adjustment Procedure	27
	Description and Operation - Hydraulic Pump	28
35 304	Hydraulic Pump and Filter	28
	Hydraulic Pump	29
	Disassembly	29
	Inspection and Repair	29
	Assembly	29
	Description and Operation - Remote Valves	30
35 204	Remote Control Valves	30
	Hydraulic Manifold Block/Diverter Valve	30
	Single Spool Remote Control System	32
	Oil Flow	32
	Neutral Position	32
	Raising Position	33
	Lowering Position	34
35 184	Front (Double Spool) Remote Valve	36
	Double Spool Remote Control System	37
	Oil Flow	37
	Bucket and Lift Control - Neutral Position	37
	Bucket Cylinder - Dumping	38
	Bucket Cylinder - REGEN	39
	Bucket Cylinder - Rollback	40
	Lift Cylinder - Raising	41
	Lift Cylinder - Lowering	42
	Lift Cylinder - Float Position	43

SECTION 35 - HYDRAULIC SYSTEM

BOOK 3 - 87053138

Chapter 1 - Hydraulic System (Continued)

CONTENTS

Section	Description	Page
	Overhaul - Remote Valves	44
	Single Spool Valve (Rear Remote Valve)	45
	Removal	45
	Disassembly	46
	Inspection	46
	Assembly	46
	Double Spool Remote Valve	47
	Double Spool Remote Valve (Front Remote Valve)	48
	Removal	48
	Disassembly	49
	Lift Spool	49
	Bucket REGEN Spool	49
	Inspection	49
	Assembly	51
	Lift Spool	51
	Bucket REGEN Spool	51
	Front Remote Valve Linkage	53
	Removal	53
	Installation	53
	Troubleshooting	55
	Pressure Testing	56
	Main System Relief Valve	56
	Specifications	57
	Metric Bolt Torque Specifications	58
	Special Tools	59

SECTION 41 - POWER STEERING SYSTEM

BOOK 3 - 87053138

Chapter 1 - Power Steering System

CONTENTS

Section	Description	Page
	Description and Operation	3
41 204	Power Steering System	3
	Power Steering Control Valve	3
	Spool and Sleeve	3
	Drive Shaft	4
	Gerotor Pump	4
	Check Valve	4
	Relief Valve	4
41 206	Power Steering Pump	5
	Power Steering Cylinder	6
	Power Steering Operation	7
	Fluid Flow - Neutral Position	7
	Fluid Flow - Left Turn	8
	Fluid Flow - Right Turn	9
	Power Steering Manual Operation	10
	Overhaul	11
	Power Steering System	11
	Removal	11
	Steering Control Valve	15
	Disassembly	15
	Inspection	18
	Assembly	18
41 216	Steering Cylinder	24
	Removal	24
	Disassembly	24
	Inspection	25
	Assembly	27
	Oil Pump	28
	Disassembly	29
	Inspection	29
	Assembly	29

SECTION 41 - POWER STEERING SYSTEM

BOOK 3 - 87053138

Chapter 1 - Power Steering System (Continued)

CONTENTS

Section	Description	Page
	Power Steering System	30
	Installation	30
	Power Steering Tubes	34
	Troubleshooting	35
	Pressure Testing	37
	Pump, Steering Valve, and Relief Valve	37
	Test Results	37
	Steering Cylinder	38
	Test Results	38
	Specifications	39
	Special Tools	40
	Metric Bolt Torque Specifications	42

SECTION 44 - WHEELS AND TIRES

BOOK 3 - 87053138

Chapter 1 - Wheels and Tires

CONTENTS

Section	Description	Page
	Specifications	2
	Wheels and Tires - Tread Setting	2
	Weights	3
	Wheels and Tires - Weight Limitation	4
	Liquid Ballast	4
	Tire Inflation vs. Permissible Load	5
	Wheels and Tires Lug Bolt Torque	6
	Front and Rear Wheel Hub Bolt Torque Sequence	6

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87053139

Chapter 1 - Electrical System

CONTENTS

Section	Description	Page
55 000	Component Location and Function - Description and Operation	6
	Wiring Harnesses	7
	Ground Locations	10
	Battery	11
	Removal	12
	Installation	12
	Fuse Block	13
	Main Fuse	13
	Replacement	13

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87053139

Chapter 1 - Electrical System (Continued)

CONTENTS

Section	Description	Page
	Electrical System Components - Description and Testing	14
	Key Start Switch	14
	Replacement	15
	Installation	16
	Testing	17
	Light Switch (Combination Switch)	18
	Removal	19
	Testing	19
	Installation	20
	Hazard/Turn Signal Combination Switch	21
	Removal	21
	Testing	22
	Installation	23
55 408	9 x 3 Transmission Main (Speed) Gears, Safety Switch	24
	Adjustment	24
	Testing	25
	Transmission Range Gear Safety Switch (HST Models), Rear PTO Safety Switch and Mid PTO Safety Switch	26
	Range Switch Adjustment - HST Transmission	26
	Testing	27
55 408	Seat Safety Switch	28
	Removal	28
	Testing	28
	Installation	29
	Parking Brake Switch	29
	Testing	30
	Cruise Control Brake Release Switch (HST Only)	31
	Testing	31
	Relays	33
	Testing	34
	Flasher Controller	35
	Removal	35
	Testing	35

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87053139

Chapter 1 - Electrical System (Continued)

CONTENTS

Section	Description	Page
	Safety Controller	37
	Glow Plug Indicator Light	38
	Testing	38
	Fuel Shut Off Solenoid (Safe Operation)	39
	Testing	40
	Safety Start Circuit (Safety Controller)	41
	Testing	41
	Parking Brake Indicator Light (Safety Controller)	43
	Testing	43
	Rear PTO Indicator Light (Safety Controller)	44
	Testing	44
	Diodes	45
	Testing	45
	Cruise Control Magnet (HST Models)	46
	Testing	47
	HST Speed Control (Cruise Control) Switch (HST Models Only)	47
	Testing	48
	Glow Plugs	49
	Testing	49
55 414	Engine Sensors	50
55 404	Fuel Shutoff Solenoid	52
	Testing	52
55 404	Lighting	53
	Flasher Warning Light	54
	Rear Work Light (Optional)	55
	Electrical Wiring Diagram	56
	Starting Circuit (Operator Present) HST Transmission	58
	Starting Circuit (Operator Present) Gear Transmission	62
	Starting Circuit (No Operator Present) HST Transmission	66
	Starting Circuit (No Operator Present) Gear Transmission	70
	Safe Operation Circuit (Operator Present) All Transmissions	74
	Safe Operation Circuit (Operator Not Present) HST Transmission PTO(s) Not Engaged	78

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87053139

Chapter 1 - Electrical System (Continued)

CONTENTS

Section	Description	Page
	Safe Operation Circuit (Operator Not Present) Gear Transmission PTO(s) Not Engaged	82
	Safe Operation Circuit (Operator Not Present) HST Transmission Rear PTO Engaged	86
	Safe Operation Circuit (Operator Not Present) Gear Transmission Rear PTO Engaged	90
	Glow Plug Circuit	94
	HST Cruise Control Circuit	98
	Front Work Lights Circuit	102
	Front Road Lights Circuit	106
	Hazard Flasher Circuit	110
	Left Turn Signal Circuit	114
	Right Turn Signal Circuit	116
	Engine Temperature Gauge Circuit	120
	Engine Oil Pressure Indicator Light Circuit	124
	Fuel Level Sender Circuit	128
	Parking Brake Indicator Light Circuit	132
	Rear PTO Indicator Light Circuit	136
	Tachometer Circuit	140
	Charging Circuit	144
	Component Operation and Servicing	147
	Instrument Panel	147
	Removal	149
	Component Testing and Replacement	149
	Fuel Gauge Testing	149
	Testing	149
	Replacement	150
	Temperature Gauge	151
	Testing	151
	Replacement	151
	Tachometer	152
	Testing	152
	Replacement	153

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87053139

Chapter 1 - Electrical System (Continued)

CONTENTS

Section	Description	Page
	Instrument Panel, Indicator and Illumination Lights	155
	Bulb Replacement	156
55 201	Description of Operation – Starting System	158
	Overhaul – Starter Motor	159
	Starter Motor	159
	Removal	159
	Disassembly	159
	Inspection and Repair	163
	Electrical Tests	167
	Assembly	169
55 301	Description of Operation – Charging System	170
	Stator	171
	Rotor	171
	Rectifier	171
	End Frame	172
	IC Regulator	172
	Improvement of Charging System	172
	Detention Function	172
	Function	173
	Overhaul – Charging System	174
	Pulley	174
	Removal	174
	Rear End Cover	175
	Removal	175
	Brush Holder	175
	Removal	175
	IC Regulator	175
	Removal	175
	Regulator	176
	Removal	176
	Bushing	176
	Removal	176