

TD75D, TD95D, TD95D HIGH CLEARANCE REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCH	6
SECTION 21 - FRONT TRANSMISSION	7
SECTION 23 - FWD TRANSFER BOX	8
SECTION 25 - FWD AXLE	9
SECTION 27 - REAR TRANSMISSION	10
SECTION 31 - POWER TAKE-OFF	11
SECTION 33 - BRAKES	12
SECTION 35 - HYDRAULIC SYSTEMS	13
SECTION 41 - STEERING	16
SECTION 44 - FRONT AXLE AND WHEELS (2WD)	17
SECTION 55 - ELECTRICAL SYSTEM	18
SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS	23

The following pages are the collation of the contents pages from each section and chapter of the TD75D, TD95D, and TD95D High Clearance Repair manual. Complete Repair part # 87572972.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TD75D, TD95D, and TD95D High Clearance Tractors.

Sample of manual. Download All 642 pages at:

<https://www.aresairmanual.com/downloads/new-holland-td75d-td95d-td95d-tractor-service-repair-manual/>

SECTION 00 - GENERAL

BOOK 1 - 87572973

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Health and Safety	5
	Precautionary Statements	15
	Safety	16
	Ecology and the Environment	19
	Minimum Hardware Tightening Torques	20
	Federal Emissions Warranty	22
	California Emission Control Warranty Statement	23
	Consumables	25

SECTION 10 - ENGINE

BOOK 1 - 87572973

Chapter 1 - Engine

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	10
	Tightening Torques	14
	Sectional Views	15
	Troubleshooting	17
	Overhaul	21
10 001 10	Engine	21
	Removal	21
10 001 54	Installation	33
	Disassembly	35
	Assembly	50
	Compression Test	60
	Checks, Dimensions, and Repairs	61
	Cylinder Block	61
	Crankshaft, Main Bearings, and Flywheel	63
	Connecting Rods	67
	Pistons	68
	Valves	71
	Tappets	71
	Camshaft	72
	Valve Timing Check	73
	Cylinder Head	74
10 102 70	Rotating Counterweight Dynamic Balancer	75
	Valve Guides	76
	Valve Seats in Cylinder Head	79
	Crankshaft Front Oil Seal	80
	Valve Clearance	86

SECTION 10 - ENGINE

BOOK 1 - 87572973

Chapter 2 - Cooling System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Sectional Views	4
	Description and Operation	5
	Cooling System	5
	Radiator	5
	Thermometer	5
	Thermostat	5
	Thermostatic Switch	5
	Overhaul	6
10 406 10	Water Pump	6
	Removal	6
	Disassembly	9
	Assembly	9
	Installation	10
10 402 30	Cooling System Thermostat	10
	Removal	10
	Installation	13
10 402 28	Radiator	14
	Removal	14
	Installation	17

SECTION 10 - ENGINE

BOOK 1 - 87572973

Chapter 3 - Lubrication System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Sectional Views	4
	Description and Operation	5
	Oil Filter	5
	Low Oil Indicator	5
10 001 10	Oil Pump	6

SECTION 10 - ENGINE

BOOK 1 - 87572973

Chapter 4 - Fuel System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	4
	Tightening Torques	5
	Description and Operation	6
	Fuel Injection Pump (Bosch)	6
	Turbocharged Models	6
	All Models	8
	Overhaul	10
10 218 30	Fuel Injectors	10
	Removal	10
	Installation	11
	Fuel Injector Sleeves	12
	Checking Injector Protrusion	12
	Removal	12
	Installation	13
10 246 14	Injection Pump	14
	Removal	14
	Installation	18
	Checking the Fuel Injection Pump Timing with the Pump on the Tractor	19
	Lock-time the Fuel Injection Pump with the Pump Removed from the Tractor ...	23
	Fuel System Air Bleeding	28

SECTION 18 - CLUTCH

BOOK 2 - 87572974

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	Clutches	2
	Main Clutch (11 in./11 in.) (Model TD75D)	2
	Main Clutch (12 in./12 in.) (Model TD95D)	3
	Tightening Torques	4
	Special Tools	4
	Sectional Views	5
	Valeo Clutches (11 in./11 in. and 12 in./12 in.)	5
	Luk Clutches (11 in./11 in. and 12 in./12 in.)	6
	Troubleshooting	7
	Overhaul	8
	11 in./11 in. and 12 in./12 in. Clutches	8
	Removal	8
	Installation	15
	Disassembly	16
	Assembly	19
	Checks, Measurements and Repairs	20
	Dimensions of the Valeo 11 in./11 in. Dual Clutch	20
	Dimensions of the Luk 11 in./11 in. Dual Clutch	20
	Dimensions of the Valeo 12 in./12 in. Dual Clutch	20
	Dimensions of the Luk 12 in./12 in. Dual Clutch	20
	Minimum Permissible Dimensions After Refacing 11 in./11 in. and 12 in./12 in. Dual Clutches	20
	Valeo 11 in. Flywheel	21
	Luk 11 in. Flywheel	21
	Valeo 12 in. Flywheel	21
	Luk 12 in. Flywheel	21
	Clutch Release Lever Coplanarity Adjustment	22
	Main Clutch Control Linkage Adjustment	23
	PTO Clutch Linkage Adjustment	23

SECTION 21 - FRONT TRANSMISSION

BOOK 2 - 87572974

Chapter 1 - 12 x 12 Transmission with Synchronized Mechanical Shuttle

CONTENTS

Section	Description	Page
	Specifications	2
	Synchronizer Reverser	2
	Gearbox/Reduction Unit	2
	Torque Values	3
	Special Tools	4
	Sectional Views	4
	Description and Operation	6
	Synchronizer Reverser Troubleshooting	6
	Overhaul	7
	Clutch-Reverser Casing	7
	Disassembly	7
	Assembly	11

SECTION 21 - FRONT TRANSMISSION

BOOK 2 - 87572974

Chapter 2 - 20 x 12 Transmission with Synchronized Mechanical Shuttle and Creeper

CONTENTS

Section	Description	Page
	Specifications	2
	Synchronizer Reverser-Creeper Unit	2
	Creeper Unit	2
	Gearbox	2
	Torque Values	3
	Special Tools	4
	Sectional Views	5
	Description and Operation	7
	Troubleshooting - Synchronizer Reverser-Creeper Unit	7
	Overhaul	8
	Clutch Casing-Synchronizer Reverser and Creeper Unit	8
	Disassembly	8
	Assembly	13

SECTION 23 - FWD TRANSFER BOX

BOOK 2 - 87572974

Chapter 1 - FWD Transfer Box

CONTENTS

Section	Description	Page
	Specifications	2
	Drive Shaft	2
	Tightening Torques	3
	Special Tools	3
	Description and Operation	4
	Sectional Views	4
	Overhaul	5
	Transmission Shafts and Guard	5
	Removal	5
	Installation	5
	Drive Gear Housing Assembly	6
	Removal	6
	Installation	7
	Transfer Box, Unit Removed	8
	Disassembly	8
	Assembly	9

SECTION 25 - FWD AXLE

BOOK 2 - 87572974

Chapter 1 - Front Mechanical Axle

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	4
	Special Tools	6
	Description of Operation	7
	Sectional Views	7
	Overhaul	10
	Complete Front Axle Assembly	10
	Removal	10
	Installation	13
	Disassembly	14
	Assembly	21
	Steering Knuckle Pins and Bearings	22
	Replacement	22
	Wheel Hub Seal Replacement	23
	Limited-Slip Differential	24
	Operation	24
	Removal	24
	Disassembly	25
	Assembly	25
	Adjustments	26
	Steering Knuckle	26
	Wheel Hub Bearing	28
	Bevel Drive Adjustments	29
	Front Axle Differential	29
	Determining Pinion Shaft Pre-load Shim Thickness	30
	Determining Pinion Shaft Position Shim Thickness	31
	Pinion Shaft Installation and Pre-load Check	33
	Differential Installation and Backlash Adjustment	34
	Differential Bearing Pre-load Adjustment	35
	Sealing Compound Application	36
	Toe-In Adjustments	37

SECTION 27 - REAR TRANSMISSION

BOOK 2 - 87572974

Chapter 1 - Rear Axle and Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	4
	Special Tools	6
	Description of Operation	7
	Sectional Views	7
	Troubleshooting	10
	Pinion and Differential	10
	Final Drives	10
	Overhaul	11
	Rear Axle Transmission - Gearbox Case	11
	Removal	11
	Installation	28
	Transmission-Gearbox Case	29
	Disassembly	29
	Assembly	33
	Adjustments	36
	Gearbox Driving Shaft Axial Clearance	36
	Differential Lock Engagement Sleeve Position Adjustment	37
	Pinion Shaft Positioning Adjustment Ring	38
	Taper-Roller Bearings for Pinion Shaft	40
	Differential Bearings and Backlash of Ring and Pinion Teeth	41
	Differential Planetary and Side Gear Backlash	43

SECTION 31 - POWER TAKE-OFF

BOOK 3 - 87572975

Chapter 1 - Power Take-Off

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Tightening Torques	4
	Description of Operation	5
	Sectional Views	5
	Troubleshooting	8
	Overhaul	9
	Mechanical PTO	9
	Removal	9
	Installation	11
	540 RPM PTO	12
	Disassembly	12
	Assembly	14
	540/1000 RPM PTO	15
	Disassembly	15
	Assembly	20

SECTION 33 - BRAKES

BOOK 3 - 87572975

Chapter 1 - Brakes

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	3
	Description of Operation	4
	Sectional Views	4
	Service Brake	6
	Parking Brake	6
	Special Tools	6
	Troubleshooting	7
	Overhaul	8
	Right Hand or Left Hand Brake (Service Brakes)	8
	Removal	8
	Installation	11
	Adjustments	13
	Height of Service Brake Pedals	13
	Hand Brake Control Travel	14

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87572975

Chapter 1 - Hydraulic Systems

CONTENTS

Operation	Description	Page
	Precautionary Statements	2
	Description and Operation	3
	Hydraulic Oil Specification	5
	Hydraulic System Configuration	5
	Hydraulic System Diagrams	6
	Hydraulic Diagram On TD75D and TD95D Models	6
	Hydraulic Diagram On TD95D High Clearance Models	7
	Auxiliary Control Valve Oil Flow	8
	Double-Acting Cylinder Lift Phase	8
	Double-Acting Cylinder Lower Phase	8
	Single-Acting Cylinder Lift Phase	8
	Single-Acting Cylinder Lower Phase	9
	Double-Acting Cylinder with Automatic Detent Release Lift Phase	9
	Double-Acting Cylinder with Automatic Detent Release Lower Phase	10
	Rear Remote Valve Control Levers	10
	Control Lever Positions	11
	Quick-Release Couplers	11
	Switching Between Single and Double Acting Cylinders	12
	Mechanically Controlled Hydraulic Lift	12
	Fast Raise/Lower Control Device	12
	Principles of Draft Control	13
	Principles of Position Control	13
	Principles of Float	14
	Principles of Draft and Position Control Combined	14
	Hydraulic Lift Valve Oil Flow	15
	Hydraulic Lift Oil Flow (Lift Phase)	15
	Hydraulic Lift Oil Flow (Neutral Phase)	16
	Hydraulic Lift Oil Flow (Lowering Phase)	17
	Three-Point Hitch (Category I and II)	18
	Adjustable Length Top Link	18
	Right-Hand Lift Rod	18
	Telescopic Lateral Stabilizer Struts	19
	Lower Links	19
	Left-Hand Lift Rod	20

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87572975

Chapter 2 - Hydraulic System Overhaul

CONTENTS

Operation	Description	Page
	Specifications	3
	Tightening Torques	8
	Special Tools	9
	Sectional Views	10
	Troubleshooting	13
	Overhaul	15
	Mechanically Controlled Hydraulic Lift	15
	Removal	15
	Installation	21
	Disassembly	22
	Assembly	24
	Adjustments	27
	Position Control	27
	Lift Arms Maximum Height	28
	Draft Control	29
	Position Control Linkage	33
	Draft Control Linkage	33
	Fast Raise/Lower Control Device	34
	Lift Pressure Relief Valve	35
	Installation	35
	Calibration	35
	Lift Control Valve Block	37
	Disassembly	37
	Assembly	41
	High-pressure (Lift) Pump	42
	Disassembly	42
	Inspection and Repair	42
	Assembly	43

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87572975

Chapter 2 - Hydraulic System Overhaul (Continued)

CONTENTS

Operation	Description	Page
	Convertible Single/Double Acting Auxiliary Control Valve	44
	Disassembly	44
	Assembly	44
	Convertible Single/Double Acting Auxiliary Control Valve with Float Control and Detent Release	45
	Disassembly	45
	Assembly	51
	Spool Binding Test	52
	Spool Leakage Test	53
	Auxiliary Control Valve Leakage Test	53
	Adjustment of the Auxiliary Control Valve Automatic Detent Release Pressure	54

SECTION 41 - STEERING

BOOK 3 - 87572975

Chapter 1 - Steering

CONTENTS

Operation	Description	Page
	Specifications	2
	Hydraulic Pump C25	3
	Torque Settings	4
	Special Tools	4
	Components	5
	Troubleshooting	6
	Description and Operation	10
	Hydrostatic Power Steering (2WD)	10
	Hydrostatic Power Steering (FWD)	12
	Operation	14
	Steering Right	14
	Steering Left	14
	Manual Steering to Right	14
	Manual Steering to Left	14
41 204 30	Hydrostatic Steering Control Valve	15
	Removal	15
	Installation	18
41 204 34	Disassembly	19
	Assembly	24
41 204 38	Steering Control Valve Testing	33
41 206 20	Hydrostatic Steering Pump	36
	Disassembly	36
	Assembly	36
41 216 20	Steering Cylinder (2WD)	37
	Removal	37
	Installation	37
	Steering Cylinder (FWD)	38
	Removal	38

SECTION 44 - FRONT AXLE AND WHEELS (2WD)

BOOK 4 - 87572976

Chapter 1 - Axle and Wheels

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	5
	Special Tools	6
	Troubleshooting	6
	Overhaul	7
	Front Axle	7
	Removal	7
	Installation	9
	Axle Wheel Hub	10
	Removal	10
	Installation	12
	Stub Axle	13
	Removal	13
	Installation	15
	Adjustments	17
	Toe-in	17

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87572976

Chapter 1 - Instrument Cluster

CONTENTS

Section	Description	Page
	Instrument Cluster Description	2
	Analog Instrument Panel	2
	Warning and Indicator Lights	3
	Fuel Level Gauge	4
	Tachometer and Hourmeter	4
	Engine Coolant Temperature Gauge	4

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87572976

Chapter 2 - Components

CONTENTS

Section	Description	Page
	Electrical Components Description	2
	Instrument Console Controls	2
	Lights Control Lever	2
	Rear Hood Controls	2
	Starter Switch	2
	Cab Controls	3
	Fender Mounted Controls	3
	Heating and Air Conditioning Controls	4
	Radio (where applicable)	4
	Applicable Components, Sensors and Switches	5
	Description	5
	Locations	6

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87572976

Chapter 3 - Starting System

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Description and Operation	3
	Overhaul	5
	Starting System Test on Tractor	5
	Power Absorption in Starter Motor Circuit	5
	Resistance in Ignition System Circuit (Voltage Drop)	6
	Battery Positive Cable Check	6
	Starter Motor Ground Lead Check	7
	Battery Ground Cable Check	7
55 201 50	Starter Motor	7
	Removal	7
	Installation	7
55 201 54	Disassembly	8
	Assembly	9
	Starter Motor Tests and Inspections	9
	Armature Shaft End-Play	9
	Starter Motor Test Without Load	10
	Armature	10
	Field Windings	11
	Bearing Bushings	11
	Driving Pinion	11

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87572976

Chapter 4 - Charging System

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Description and Operation	3
	Troubleshooting	5
	Precautions	5
	Preliminary Checks	5
	Tests and Checks	6
	Alternator Wire Connections	7
	Charging Current and Regulated Voltage	8
	Charging Circuit Voltage Drop	9
	Alternator Maximum Output	10
	Alternator Component Tests	11
	Overhaul	12
	Alternator	12
	Removal	12
	Disassembly	13
	Alternator Component Testing	14
	Assembly	21
	Repair	21
	Installation	22

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87572976

Chapter 5 - Battery

CONTENTS

Section	Description	Page
	Specifications	2
	Troubleshooting	2
	Description and Operation	3
	Overhaul	4
	Battery	4
	Removal	4
	Installation	4
	Battery Maintenance	5
	Relative Density	5
	Precautions	5
	Dry-Charged Batteries	6
	Charging the Battery	6
	Normal Charging (Top Up)	6
	Charging Very Flat Batteries	6
	Testing	7

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87572976

Chapter 6 - Electrical Circuits

CONTENTS

Section	Description	Page
	Description and Operation	2
	Electrical Diagram Symbols	2
	Wire Color Coding	3
	Fuse Box/Fuses	4
	Main Wiring Diagrams (Cab or ROPS)	5
	Diagrams A, B, C and D	5
	Diagram A (Main Harness)	8
	Diagram B (Dash Harness)	10
	Diagram C (Rear Harness)	12
	Diagram D (Cab/Platform Harness)	14
	Individual Circuits	16
	Start-up Circuit	16
	High and Low Beam Headlights, Cornering and Parking Lights	18
	Direction Indicators and Hazard Lights Circuit	20
	Work Lamp Circuit	22
	Operator's Presence Circuit	24
	Analog Instrument Circuit	26
	Heating and Air-Conditioning System Circuit	27

SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS

BOOK 4 - 87572976

Chapter 1 - Cab

CONTENTS

Section	Description	Page
	Overhaul	2
	Control Levers, Seat, Electrical Controls	2
	Disassembly	2
	Assembly	9
	Rear Window, Handle and Lock	10
	Disassembly	10
	Assembly	10
	Lock and Exterior Handle	11
	Disassembly	11
	Assembly	11
	LH Door	12
	Disassembly	12
	Assembly	12
	Front Wiper Motor	13
	Disassembly	13
	Assembly	14
	Cab Windows	15
	Removal	15
	Installation	16

SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS

BOOK 4 - 87572976

Chapter 2 - Air Conditioning System

CONTENTS

Section	Description	Page
	Safety	3
	Specifications	4
	Special Tools	5
	Description of Operation	6
	Cab Heating and Ventilation Controls	8
	Ventilation	8
	Fan	8
	Air Filter	8
	Heating	9
	Temperature Control Knob	9
	Ignition Switch	9
	Switching on the Air Conditioning and Temperature Control	10
	Air Conditioning and Temperature Control Button	10
	Heating Control Knob	10
	3-Speed Fan Control Knob	10
	Use of the Air Conditioning System	11
	Switching On the Air Conditioning	11
	Adjustment	11
	Switching Off the Air Conditioning System	11
	Main Components of the Air Conditioning System	12
	SANDEN SD 7H15 Compressor	12
	Condenser	13
	Receiver/Dryer	13
	Thermostatic Expansion Valve	14
	Air Conditioner Temperature Cycling Control Switch	15
	Thermostatic Switch (ANTIFROST)	15
	Evaporator	16
	Low Pressure Cut-out Switch	17
	Combined High/Low Pressure Cut-out Switch	17
	System Pressure Relief Valve	17
	Condenser	18
	Receiver/Dryer	18

SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS

BOOK 4 - 87572976

Chapter 2 - Air Conditioning System (Continued)

CONTENTS

Section	Description	Page
	Refrigerant Recovery-Recycling and Evacuation- Charging Stations	19
	Air Conditioning System	21
	Function Testing of Cab Air Conditioning System	26
	Summary of the Air Conditioning System Charging Operations	27
	Checking for Refrigerant Leaks Using an Electronic Leak Detector	29
	Maintenance of the Air Conditioning System	31
	Troubleshooting	32
	Overhaul	36
	Air Conditioning and Heating Pipes	36
	Removal	36
	Installation	39
	Receiver-Dryer	40
	Removal	40
	Installation	41
	Condenser	42
	Removal	42
	Installation	42
	Compressor	43
	Removal	43
	Installation	44
	Compressor Oil - Type and Quantity	44
	Adjustments	45
	Compressor Drive Belt	45
	Tension Adjustment	45
	Fitting the Compressor Drive Belt	45
	Checking Compressor Drive Belt Tension	45
	Periodic Checking of Drive Belt	45



SECTION 00 - GENERAL

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Health and Safety	5
	Precautionary Statements	15
	Safety	16
	Ecology and the Environment	19
	Minimum Hardware Tightening Torques	20
	Federal Emissions Warranty	22
	California Emission Control Warranty Statement	23
	Consumables	25

⚠ WARNING ⚠

All maintenance and repair work described in this manual must be performed exclusively by CASE IH service technicians in strict accordance with the instructions given and using any specific tools necessary.

⚠ WARNING ⚠

Anyone who performs the operations described herein without strictly following the instructions is personally responsible for resulting injury or damage to property.

⚠ WARNING ⚠

The Manufacturer and all organizations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer. In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.

GENERAL INSTRUCTIONS

IMPORTANT NOTICE

All maintenance and repair operations described in this manual should be carried out exclusively by the authorized workshops. All instructions detailed should be carefully observed and special equipment indicated should be used if necessary.

Everyone who carries out service operations described without carefully observing these directives will be directly responsible for resulting consequences.

SHIMMING

At each adjustment, select adjusting shims, measure them individually using a micrometer and then sum up recorded values. Do not rely on measuring the whole shimming set, which may be incorrect, or on the rated value indicated for each shim.

ROTATING SHAFT SEALS

To correctly install rotating shaft seals, observe the following instructions:

- Let the seal soak into the same oil as it will seal for at least half an hour before mounting;
- Thoroughly clean the shaft and ensure that the shaft working surface is not damaged;
- Place the sealing lip towards the fluid. In case of a hydrodynamic lip, consider the shaft rotation direction and orient grooves in order that they deviate the fluid towards the inner side of the seal;
- Coat the sealing lip with a thin layer of lubricant (oil rather than grease) and fill the gap between the sealing lip and the dust lip of double lip seals with grease;
- Insert the seal into its seat and press it down using a flat punch. Do not tap the seal with a hammer or a drift;

- Take care to insert the seal perpendicular to its seat while you are pressing it. Once the seal is settled, ensure that it contacts the thrust element, if required;
- To prevent damaging the sealing lip against the shaft, place a suitable protection during installation.

O RINGS

Lubricate the O rings before inserting them into their seats. This will prevent the O rings from roll over and twisting during mounting, which will jeopardize sealing.

SEALERS

Apply silicone/gasket eliminator over the mating surfaces marked with an X. Before applying the sealer, prepare the surface as follows:

- remove possible scales using a metal brush;
- thoroughly degrease the surfaces using one of the following cleaning agents: trichlorethylene, diesel fuel or a water and soda solution.

BEARINGS

It is advisable to heat the bearings to 80° to 90°C (176° to 194°F) before mounting them on their shafts and cool them down before inserting them into their seats with external tapping.

SPRING PINS

When mounting split socket spring pins, ensure that the pin notch is oriented in the direction of the effort to stress the pin.

Spiral spring pins should not be oriented during installation.

GENERAL INSTRUCTIONS

PRECAUTIONARY NOTICE

Only authorized workshops should carry out maintenance and repair operations on the tractor, or tractor components. Carefully observe all instructions, safety precautions, and the use of equipment such as special tools, as detailed in this manual. Damage to the tractor, or injury to personnel is the direct responsibility of anyone who fails to observe these precautions.

EQUIPMENT NOTICE

The equipment proposed in this manual is:

- Designed and studied expressly for use on Case IH tractors
- Necessary for adequate and reliable repair of the tractor
- Strictly tested for the efficient and long lasting life cycle of the tractor

SPARE PARTS NOTICE

Genuine CASE IH spare parts guarantee the same quality, safety and life cycle as original components. These parts bear the logo.

GENERAL NOTICES

In this manual, the description 'FRONT', 'REAR', 'RIGHT-HAND' and 'LEFT-HAND' refer to the view seen by the operator while in the operator's seat, looking in the direction in which the tractor normally moves.

Wear limits detailed in this manual, although advised, are not binding.