

TD80D, TD95D REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	2
SECTION 18 - CLUTCH	7
SECTION 21 - FRONT TRANSMISSION	8
SECTION 23 - FWD TRANSFER BOX	10
SECTION 25 - MFD AXLE	11
SECTION 27 - REAR TRANSMISSION	12
SECTION 31 - POWER TAKE-OFF	13
SECTION 33 - BRAKES	14
SECTION 35 - HYDRAULIC SYSTEMS	15
SECTION 41 - STEERING	18
SECTION 44 - FRONT AXLE AND WHEELS (2WD)	19
SECTION 55 - ELECTRICAL SYSTEM	19
SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS	25

The following pages are the collation of the contents pages from each section and chapter of the TD80D, TD95D Tractor Repair manual. Complete Repair part # 87658938.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TD80D, TD95D Tractors.

SECTION 00 - GENERAL

BOOK 1 - 87658939

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Health and Safety	5
	Precautionary Statements	15
	Safety	16
	Ecology and the Environment	19
	Minimum Hardware Tightening Torques	20
	Federal Emissions Warranty	22
	California Emission Control Warranty Statement	23
	Consumables	25

SECTION 10 - ENGINE

BOOK 1 - 87658939

Chapter 1 - Engine

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	10
	Tightening Torques	14
	Angular Torque Data	14
	Sectional Views	15
	Troubleshooting	17
	Overhaul	21
10 001 10	Engine	21
	Removal	21
10 001 54	Installation	32
	Disassembly	34
	Assembly	49

Sample of manual. Download All 702 pages at:

<https://www.arepairmanual.com/downloads/new-holland-td80d-td95d-tractor-service-repair-manual/>

SECTION 10 - ENGINE

BOOK 1 - 87658939

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
	Rotating Counterweight Dynamic Balancer	49
	Compression Test	59
	Checks, Dimensions, and Repairs	60
	Cylinder Block	60
	Crankshaft, Main Bearings, and Flywheel	62
	Connecting Rods	66
	Pistons	67
	Valves	70
	Tappets	70
	Camshaft	71
	Valve Timing Check	72
	Cylinder Head	73
10 102 70	Rotating Counterweight Dynamic Balancer	74
	Valve Guides	75
	Valve Seats in Cylinder Head	78
	Crankshaft Front Oil Seal	79
	Valve Clearance	85

SECTION 10 - ENGINE

BOOK 1 - 87658939

Chapter 2 - Cooling System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Sectional Views	4
	Description and Operation	5
	Cooling System	5
	Radiator	5
	Thermometer	5
	Thermostat	5
	Thermostatic Switch	5
	Overhaul	6
10 406 10	Water Pump	6
	Removal	6
	Disassembly	9
	Assembly	9
	Installation	10
10 402 30	Cooling System Thermostat	10
	Removal	10
	Installation	13
10 402 28	Radiator	14
	Removal	14
	Installation	17

SECTION 10 - ENGINE

BOOK 1 - 87658939

Chapter 3 - Lubrication System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Sectional Views	4
	Description and Operation	5
	Oil Filter	5
	Low Oil Indicator	5
10 001 10	Oil Pump	6

SECTION 10 - ENGINE

BOOK 1 - 87658939

Chapter 4 - Fuel System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	4
	Tightening Torques	5
	Description and Operation	6
	Fuel Injection Pump (Bosch)	6
	Turbocharged Models	6
	All Models	8
	Overhaul	10
10 218 30	Fuel Injectors	10
	Removal	10
	Installation	11

SECTION 10 - ENGINE

BOOK 1 - 87658939

Chapter 4 - Fuel System (Continued)

CONTENTS

Section	Description	Page
	Fuel Injector Sleeves	12
	Checking Injector Protrusion	12
	Removal	12
	Installation	13
10 246 14	Injection Pump	14
	Removal	14
	Installation	18
	Checking the Fuel Injection Pump Timing with the Pump on the Tractor	19
	Lock-time the Fuel Injection Pump with the Pump Removed from the Tractor ...	23
	Fuel System Air Bleeding	28

SECTION 18 - CLUTCH

BOOK 1 - 87658939

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	Clutches	2
	Main Clutch (11 in./11 in.) (Models TD80D)	2
	Main Clutch (12 in./12 in.) (Model TD95D)	3
	Tightening Torques	4
	Special Tools	4
	Sectional Views	5
	Valeo Clutches (11 in./11 in. and 12 in./12 in.)	5
	Longitudinal Section of Clutch – Luk Clutches (11 in./11 in. and 12 in./12 in.)	6
	Troubleshooting	7
	Overhaul	8
	11 in./11 in. and 12 in./12 in. Clutches	8
	Removal	8
	Installation	15
	Disassembly	16
	Assembly	19
	Checks, Measurements and Repairs	20
	Dimensions of the Valeo 11 in./11 in. Dual Clutch	20
	Dimensions of the Luk 11 in./11 in. Dual Clutch	20
	Dimensions of the Valeo 12 in./12 in. Dual Clutch	20
	Dimensions of the Luk 12 in./12 in. Dual Clutch	20
	Minimum Permissible Dimensions After Refacing 11 in./11 in. and 12 in./12 in. Dual Clutches	20
	Valeo 11 in. Flywheel	21
	Luk 11 in. Flywheel	21
	Valeo 12 in. Flywheel	21
	Luk 12 in. Flywheel	21
	Clutch Release Lever Coplanarity Adjustment	22
	Main Clutch Control Linkage Adjustment	23
	PTO Clutch Linkage Adjustment	23

SECTION 21 - FRONT TRANSMISSION

BOOK 2 - 87658940

Chapter 1 - 12 x 12 Transmission with Synchronized Mechanical Shuttle

CONTENTS

Section	Description	Page
	Specifications	2
	Synchronizer Reverser	2
	Gearbox/Reduction Unit	2
	Torque Values	3
	Special Tools	4
	Sectional Views	4
	Description and Operation	6
	Synchronizer Reverser Troubleshooting	6
	Overhaul	7
	Clutch-Reverser Casing	7
	Disassembly	7
	Assembly	11

SECTION 21 - FRONT TRANSMISSION

BOOK 2 - 87658940

Chapter 2 - 20 x 12 Transmission with Synchronized Mechanical Shuttle and Creeper

CONTENTS

Section	Description	Page
	Specifications	2
	Synchronizer Reverser-Creeper Unit	2
	Creeper Unit	2
	Gearbox	2
	Torque Values	3
	Special Tools	4
	Sectional Views	5
	Description and Operation	7
	Troubleshooting	7
	Overhaul	8
	Clutch Casing-Synchronizer Reverser and Creeper Unit	8
	Disassembly	8
	Assembly	13

SECTION 23 - FWD TRANSFER BOX

BOOK 2 - 87658940

Chapter 1 - FWD Transfer Box

CONTENTS

Section	Description	Page
	Specifications	2
	Drive Shaft	2
	Tightening Torques	3
	Special Tools	3
	Description and Operation	4
	Sectional Views	4
	Overhaul	5
	Transmission Shafts and Guard	5
	Disassembly	5
	Assembly	5
	Drive Gear Housing Assembly	6
	Removal	6
	Installation	7
	Transfer Box, Unit Removed	8
	Disassembly	8
	Assembly	9

SECTION 25 - MFD AXLE

BOOK 2 - 87658940

Chapter 1 - Front Mechanical Axle

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	5
	Special Tools	7
	Description of Operation	8
	Sectional Views	8
	Overhaul	11
	Complete Front Axle Assembly	11
	Removal	11
	Installation	14
	Disassembly	15
	Assembly	22
	Steering Knuckle Pins and Bearings	23
	Replacement	23
	Wheel Hub Seal Replacement	24
	Limited-Slip Differential	25
	Operation	25
	Removal	25
	Disassembly	26
	Assembly	26
	Adjustments	27
	Steering Knuckle	27
	Wheel Hub Bearing	29
	Bevel Drive Adjustments	30
	Front Axle Differential	30
	Determining Pinion Shaft Pre-load Shim Thickness	31
	Determining Pinion Shaft Position Shim Thickness	32
	Pinion Shaft Installation	34
	Differential Installation and Backlash Adjustment	35
	Differential Bearing Pre-Load Adjustment	36
	Sealing Compound Application	37
	Toe-in Adjustment	38

SECTION 27 - REAR TRANSMISSION

BOOK 2 - 87658940

Chapter 1 - Rear Axle and Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	4
	Special Tools	6
	Description and Operation	8
	Sectional Views	9
	Troubleshooting	12
	Pinion and Differential	12
	Final Drives	12
	Overhaul	13
	Rear Axle Transmission - Gearbox Case	13
	Removal	13
	Installation	29
	Transmission-Gearbox Case	30
	Disassembly	30
	Assembly	35
	Adjustments	38
	Gearbox Driving Shaft Axial Clearance	38
	Differential Lock Engagement Sleeve Position Adjustment	39
	Pinion Shaft Positioning Adjustment Ring	40
	Pinion Shaft Pre-Load Adjustment	42
	Differential Bearings and Backlash of Ring and Pinion Teeth	43
	Differential Planetary and Side Gear Backlash	47
	Final Drive Removal	49
	Disassembly (Cover)	49
	Disassembly (Housing)	50
	Assembly	51

SECTION 31 - POWER TAKE-OFF

BOOK 2 - 87658940

Chapter 1 - Power Take-Off

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	4
	Tightening Torques	5
	Sectional Views	6
	Description and Operation of Mechanical PTO	11
	Independent PTO	11
	Ground Speed PTO	12
	PTO Speed Selector Lever	12
	Single Lever PTO Operation	13
	Troubleshooting for Mechanical PTO	14
	Overhaul	15
	540 Mechanical PTO	15
	Removal	15
	Installation	18
	540 RPM PTO	19
	Disassembly	19
	Assembly	21
	540/1000 RPM PTO	22
	Disassembly	22
	Assembly	27

SECTION 33 - BRAKES

BOOK 3 - 87658941

Chapter 1 - Brakes

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	3
	Sectional View	4
	Brakes	5
	Description and Operation	7
	Service Brakes	7
	Parking Brake	7
	Special Tools	7
	Troubleshooting	8
	Overhaul	9
	Right Hand or Left Hand Brake (Service Brakes)	9
	Removal	9
	Installation	12
	Hydraulic Brake Slave Cylinder	14
	Removal-Refitting	14
	Installation	14
	Service Brake Pedals	15
	Adjusting Height of Service Brake Pedals	15
	Hand Brake Control	17
	Adjustment Travel	17

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87658941

Chapter 1 - Hydraulic Systems

CONTENTS

Section	Description	Page
	Precautionary Statements	2
	Hydraulic System - Description and Operation	3
	Hydraulic System Diagrams	5
	Auxiliary (Rear) Control Valves	7
	Double-Acting Cylinder Lift Phase	7
	Double-Acting Cylinder Lower Phase	7
	Single-Acting Cylinder Lift Phase	7
	Single-Acting Cylinder Lower Phase	8
	Double-Acting Cylinder with Automatic Detent Release Lift Phase	8
	Double-Acting Cylinder with Automatic Detent Release Lower Phase	9
	Rear Remote Valve Control Levers	9
	Control Lever Positions	10
	Quick-Release Couplers	10
	Switching Between Single and Double Acting Cylinders	11
	Mechanically Controlled Hydraulic Lift	11
	Fast Raise/Lower Control Device	11
	Principles of Draft Control	12
	Principles of Position Control	12
	Principles of Float	13
	Principles of Draft and Position Control Combined	13
	Hydraulic Lift Oil Flow (Lift Phase)	14
	Hydraulic Lift Oil Flow (Neutral Phase)	15
	Hydraulic Lift Oil Flow (Lowering Phase)	16
	Three-Point Hitch (Category I and II)	17
	Adjustable Length Top Link	17
	Right-Hand Lift Rod	17
	Telescopic Lateral Stabilizer Struts	18
	Lower Links	18
	Left-Hand Lift Rod	19

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87658941

Chapter 2 - Hydraulic System Overhaul

CONTENTS

Section	Description	Page
	Specifications	3
	Tightening Torques	8
	Special Tools	9
	Sectional Views	10
	Troubleshooting	13
	Overhaul	15
	Mechanically Controlled Hydraulic Lift	15
	Removal	15
	Installation	21
	Disassembly	22
	Assembly	24
	Adjustments	27
	Adjusting the HPL on a Workbench	27
	HPL on the Workbench	27
	Installation	40
	Position Control Linkage	41
	Draft Control Linkage	41
	Fast Raise/Lower Control Device	42
	Lift Pressure Relief Valve	43
	Installation	43
	Calibration	43
	Lift Control Valve Block	45
	Disassembly	45
	Assembly	49
	High-pressure (Lift) Pump	50
	Disassembly	50
	Inspection and Repair	50
	Assembly	51

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87658941

Chapter 2 - Hydraulic System Overhaul (Continued)

CONTENTS

Section	Description	Page
	Convertible Single/Double Acting Auxiliary Control Valve	52
	Disassembly	52
	Assembly	52
	Convertible Single/Double Acting Auxiliary Control Valve with Float Control and Detent Release	53
	Disassembly	53
	Assembly	59
	Spool Binding Test	60
	Spool Leakage Test	61
	Adjustment of the Auxiliary Control Valve Automatic Detent Release Pressure	62

SECTION 41 - STEERING

BOOK 3 - 87658941

Chapter 1 - Steering

CONTENTS

Section	Description	Page
	Specifications	2
	Hydraulic Pump C25	3
	Torque Settings	4
	Special Tools	4
	Components	5
	Troubleshooting	6
	Description and Operation	10
	Hydrostatic Power Steering (2WD)	10
	Hydrostatic Power Steering (FWD)	12
	Operation	14
	Steering Right	14
	Steering Left	14
	Manual Steering to Right	14
	Manual Steering to Left	14
	Hydrostatic Steering Control Valve	15
	Removal	15
	Installation	18
41 204 34	Disassembly	19
	Assembly	24
	Steering Control Valve Testing	33
	Checking the Hydrostatic Steering Pressure Relief Valve with Steering Control Valve Installed on Tractor	34
41 206 20	Hydrostatic Steering Pump	36
	Disassembly	36
	Assembly	36
	Steering Cylinder (2WD)	37
	Removal	37
	Installation	37
	Steering Cylinder (FWD)	38
	Removal	38

SECTION 44 - FRONT AXLE AND WHEELS (2WD)

BOOK 3 - 87658941

Chapter 1 - Axle and Wheels

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	5
	Special Tools	6
	Troubleshooting	6
	Overhaul	7
	Front Axle	7
	Removal	7
	Installation	9
	Axle Wheel Hub	10
	Removal	10
	Installation	13
	Stub Axle	17
	Removal	17
	Installation	19
	Adjustments	21
	Toe-in	21

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87658942

Chapter 1 - Instrument Cluster

CONTENTS

Section	Description	Page
	Instrument Cluster Description	2
	Analog Instrument Panel	2
	Warning and Indicator Lights	3
	Fuel Level Gauge	4
	Tachometer and Hourmeter	4
	Engine Coolant Temperature Gauge	4

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87658942

Chapter 2 - Components

CONTENTS

Section	Description	Page
	Electrical Components Description	2
	Instrument Console Controls	2
	Lights Control Lever	2
	Rear Hood Controls	2
	Starter Switch	2
	In-Cab Controls	3
	Fender Mounted Controls	3
	Heating and Air Conditioning Controls	4
	Radio (where applicable)	4
	Applicable Components, Sensors and Switches	5
	Description	5
	Transmitters and Switches	6

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87658942

Chapter 3 - Starting System

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Description and Operation	3
	Overhaul	5
	Starting System Test on Tractor	5
	Power Absorption in Starter Motor Circuit	5
	Resistance in Ignition System Circuit (Voltage Drop)	6

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87658942

Chapter 3 - Starting System (Continued)

CONTENTS

Section	Description	Page
	Battery Positive Cable Check	6
	Starter Motor Ground Lead Check	7
	Battery Ground Cable Check	7
55 201 50	Starter Motor	7
	Removal	7
	Installation	7
55 201 54	Disassembly	8
	Assembly	9
	Starter Motor Tests and Inspections	9
	Armature Shaft End-Play	9
	Starter Motor Test Without Load	10
	Armature	10
	Field Windings	11
	Bearing Bushings	11
	Driving Pinion	11

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87658942

Chapter 4 - Charging System

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Description and Operation	3
	Troubleshooting	5
	Precautions	5
	Preliminary Checks	5
	Tests and Checks	6
	Alternator Wire Connections	7
	Charging Current and Regulated Voltage	8
	Charging Circuit Voltage Drop	9
	Alternator Maximum Output	10
	Alternator Component Tests	11
	Overhaul	12
	Alternator	12
	Removal	12
	Disassembly	13
	Alternator Component Testing	14
	Rotor	18
	Assembly	21
	Repair	21
	Installation	22

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87658942

Chapter 5 - Battery

CONTENTS

Section	Description	Page
	Specifications	2
	Troubleshooting	2
	Description and Operation	3
	Overhaul	4
	Battery	4
	Removal	4
	Installation	4
	Battery Maintenance	5
	Relative Density	5
	Precautions	5
	Dry-Charged Batteries	6
	Charging the Battery	6
	Normal Charging (Top Up)	6
	Charging Very Flat Batteries	6
	Testing	7

SECTION 55 - ELECTRICAL SYSTEM

BOOK 4 - 87658942

Chapter 6 - Electrical Circuits

CONTENTS

Section	Description	Page
	Description and Operation	2
	Electrical Diagram Symbols	2
	Electrical Wire Color Coding	3
	Ground Locations	3
	Fuses and Relays Main Box	7
	Fuses and Relay Box (Inside Cab)	8
	General Diagram - Center (With Cab)	9
	General Diagram - Center without Cab (ROPS)	12
	Starter Circuit	14
	Connector Overview	16
	Direction Indicator and Hazard Warning Light Circuit	18
	Connector Overview	20
	Windscreen Washer/Wiper Circuit	24
	Connector Overview	26
	Brake Light Circuit	28
	Connector Overview	30
	Heating and Air Conditioning Circuit	33
	Connector Overview	35
	ROPS Work Light Circuit	36
	Connector Overview	38
	Work Lamp (with Cab) Circuit	40
	Connector Overview	42
	Parking/Headlights and Turn Signal Circuit	44
	Connector Overview	46
	Operator Presence Switch Circuit	50
	Analogue Instrument Circuit	52

SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS

BOOK 4 - 87658942

Chapter 1 - Cab

CONTENTS

Section	Description	Page
	Overhaul	2
	Control Levers, Seat, Electrical Controls	2
	Disassembly	2
	Assembly	9
	Rear Window, Handle and Lock	10
	Disassembly	10
	Assembly	10
	Lock and Exterior Handle	11
	Disassembly	11
	Assembly	11
	LH Door	12
	Disassembly	12
	Assembly	12
	Front Wiper Motor	13
	Disassembly	13
	Assembly	14
	Cab Windows	15
	Removal	15
	Installation	16

SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS

BOOK 4 - 87658942

Chapter 2 - Air Conditioning System

CONTENTS

Section	Description	Page
	Safety	3
	Specifications	4
	Special Tools	5
	Description of Operation	6
	Cab Heating and Ventilation Controls	8
	Ventilation	8
	Fan	8
	Air Filter	8
	Heating	9
	Temperature Control Knob	9
	Ignition Switch	9
	Switching on the Air Conditioning and Temperature Control	10
	Air Conditioning and Temperature Control Button	10
	Heating Control Knob	10
	3-Speed Fan Control Knob	10
	Use of the Air Conditioning System	11
	Switching On the Air Conditioning	11
	Adjustment	11
	Switching Off the Air Conditioning System	11
	Components of the Air Conditioning System	12
	Compressor	12
	Condenser	13
	Receiver/Dryer	14
	Thermostatic Expansion Valve	15
	Air Conditioner Temperature Cycling Control Switch	16
	Thermostatic Switch (ANTIFROST)	16
	Evaporator	17
	Low Pressure Cut-out Switch	18
	Combined High/Low Pressure Cut-out Switch	18

SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS

BOOK 4 - 87658942

Chapter 2 - Air Conditioning System (Continued)

CONTENTS

Section	Description	Page
	System Pressure Relief Valve	18
	Refrigerant Recovery-Recycling and Evacuation- Charging Stations	19
	Air Conditioning System	21
	Function Testing of Cab Air Conditioning System	26
	Summary of the Air Conditioning System Charging Operations	27
	Checking for Refrigerant Leaks Using an Electronic Leak Detector	29
	Maintenance of the Air Conditioning System	31
	Troubleshooting	32
	Overhaul	36
	Air Conditioning and Heating Pipes	36
	Removal	36
	Installation	39
	Receiver-Dryer	40
	Removal	40
	Installation	41
	Condenser	42
	Removal	42
	Installation	42
	Compressor	43
	Removal	43
	Installation	44
	Compressor Oil - Type and Quantity	44
	Adjustments	45
	Compressor Drive Belt	45
	Tension Adjustment	45
	Fitting the Compressor Drive Belt	45
	Checking Compressor Drive Belt Tension	45
	Periodic Checking of Drive Belt	45

SECTION 00 - GENERAL

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Health and Safety	5
	Precautionary Statements	15
	Safety	16
	Ecology and the Environment	19
	Minimum Hardware Tightening Torques	20
	Federal Emissions Warranty	22
	California Emission Control Warranty Statement	23
	Consumables	25

⚠ WARNING ⚠

All maintenance and repair work described in this manual must be performed exclusively by New Holland service technicians in strict accordance with the instructions given and using any specific tools necessary.

⚠ WARNING ⚠

Anyone who performs the operations described herein without strictly following the instructions is personally responsible for resulting injury or damage to property.

⚠ WARNING ⚠

The Manufacturer and all organizations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer. In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.