

MDF0730A

# T4020 Deluxe – T4020 Supersteer – T4030 Deluxe – T4030 Supersteer – T4040 Deluxe – T4040 Supersteer – T4050 Deluxe – T4050 Supersteer TRACTORS SERVICE MANUAL

## SECTIONS

<b>GENERAL GUIDELINES</b> .....	<b>00</b>
<b>ENGINE</b> .....	<b>10</b>
<b>CLUTCH</b> .....	<b>18</b>
<b>TRANSMISSIONS</b> .....	<b>21</b>
<b>DRIVE LINES</b> .....	<b>23</b>
<b>FRONT MECHANICAL TRANSMISSION</b> .....	<b>25</b>
<b>REAR MECHANICAL TRANSMISSION</b> .....	<b>27</b>
<b>POWER TAKE-OFF</b> .....	<b>31</b>
<b>BRAKES</b> .....	<b>33</b>
<b>HYDRAULIC SYSTEMS</b> .....	<b>35</b>
<b>STEERING</b> .....	<b>41</b>
<b>AXLE AND WHEELS</b> .....	<b>44</b>
<b>CAB AIR CONDITIONING SYSTEM</b> .....	<b>50</b>
<b>ELECTRICAL SYSTEM</b> .....	<b>55</b>
<b>PLATFORM, CAB, BODYWORK</b> .....	<b>90</b>

## T E C H N I C A L   S U P P O R T

Sample of manual. Download All 1725 pages at:

<https://www.aresairmanual.com/downloads/new-holland-t4020-t4030-t4040-t4050-deluxe-supersteer-tractor-service-repair-manual/>

## INTRODUCTORY NOTES

- *This manual is divided into sections identified by two-figure numbers and each section has independent page numbering.*
- *The different sections can easily be found by consulting the table of contents on the following pages.*
- *The document number of the manual and the edition/update dates are given at the bottom of each page.*
- *Pages updated in the future will be identified by the same document number followed by an additional digit: first edition standard manual 87666787A – 1st update 87666787A1 – 2nd update 87666787A2 – etc. The update pages can replace or supplement the pages of the standard manual; the information necessary for the procedure for adding or replacing pages is given on the title page of the update. The publication will be completed with an appropriate index. If it is necessary to issue a new updated manual (2nd edition) it will have document number 87666787B, this indicates that the manual is composed of the standard version 87666787A completed with all the updates: 1st update 87666787A1 – 2nd update 87666787A2 – etc.*
- *The information contained in this manual was current on the date printed on each section. As NEW HOLLAND constantly improves its product range, some information may be out of date subsequent to modifications implemented for technical or commercial reasons, or to meet legal requirements in different countries. In the event of conflicting information, consult the NEW HOLLAND Sales and Service Departments.*

## IMPORTANT WARNINGS

- *All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND service technicians, in strict accordance with the instructions given and using any specific tools necessary.*
- *Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.*
- *The Manufacturer and all organisations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer. In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.*

No part of the text or illustrations  
may be reproduced



PRINTED IN FRANCE

© CNH GLOBAL N.V.

Print No. **87666787A1** – 03 – 2008

CONTENT

	Page	Date		Page	Date
<b>00 – GENERAL GUIDELINES</b>			Engine disassembly– assembly .....	33–34–35– 36–37–38– 39–40–41– 42–43–44– 45–46–47– 48–49–50– 51–52–53– 54–55–56– 57–58–59– 60–61–62– 63–64–65– 66	11–07
General instructions .....	1–2	11–07			
Safety regulations .....	3–4–5	11–07			
Tractor refuelling .....	6	11–07			
<b>10 – ENGINE</b>					
<b>CHAPTER 1 – Engine T4040 and T4050 models</b>					
Summary .....	1	11–07	Checks and measurements – cylinder block and liners	67–68–69	11–07
General specifications .....	2–3–4	11–07	Checks and measurements – crankshaft, bearings and flywheel .....	70–71	11–07
Fuel system data .....	4	11–07	Checks and measurements – connecting rods .....	72–73	11–07
Engine block data .....	5	11–07	Checks and measurements – pistons .....	74–75–76– 77	11–07
Crankshaft data .....	5	11–07	Checks and measurements – camshaft, tappets and valves .....	78–79–80– 81	11–07
Connecting rod data .....	6	11–07	Checks and measurements – cylinder head	82	11–07
Piston data .....	6–7	11–07	Checks and measurements – lubrication system .....	83	11–07
Timing gear data .....	7	11–07	Checks and measurements – cooling system .....	84	11–07
Cylinder head data .....	8–9	11–07	Removal–Installation – crankshaft front seal .....	85–86	11–07
Tightening torques .....	10–11	11–07	Replacing crankshaft rear seal .....	87–88–89	11–07
Tools .....	12	11–07	Valve clearance adjustment .....	90–91	11–07
Engine diagrams .....	13	11–07	Removal–Installation – in- jectors .....	92–93–94	11–07
Lubrication diagrams .....	14	11–07	Removal – Installation – Bosch injection pump .....	95–96–97	11–07
Cooling diagram .....	15	11–07	Bosch injection pump – tim- ing .....	98–99–100	11–07
Additional counterweight diagrams .....	16	11–07	Bosch injection pump – air bleeding .....	100	11–07
Exhaust gas recirculation system (EGR) .....	17	11–07			
Fault finding .....	18–19–20– 21	11–07			
Engine removal–installa- tion .....	22–23–24– 25–26–27– 28–29–30– 31–32	11–07			

	Page	Date		Page	Date
Removal-Installation – coolant pump .....	101-102	11-07			
Removal-Installation – thermostat valve .....	103-104	11-07			
Removal-Installation – radiator .....	105-106- 107-108	11-07			
Coolant pump and gener- ator drive belt .....	109-110	11-07			
<b>CHAPTER 2 – Engine T4020 and T4030 models</b>			<b>21 – TRANSMISSIONS</b>		
Summary .....	1	03-08	<b>CHAPTER 1 – Transmission and range gear (16x16)</b>		
General specifications ....	2-3	03-08	Data .....	1-2	11-07
Engine removal-installa- tion .....	4-5-6-7-8 -9-10-11- 12-13-14- 15-16-17	03-08	Tightening torques .....	2-3	11-07
			Tools .....	4-5-6-7	11-07
			Sections .....	8-9-10-11	11-07
			Description and operation	12	11-07
			Fault finding .....	12-13	11-07
			Removal-Installation – rear transmission – gear- box casing .....	14-15-16- 17-18-19- 20	11-07
			Disassembly-Assembly – transmission-gearbox cas- ing .....	21-22-23- 24-25-26- 27-28	11-07
			Gearbox driving and driven shafts end float adjustment	29	11-07
			Sealing compound applica- tion diagram .....	30	11-07
			Gearbox control lever. Re- moval – Installation .....	31	11-07
			Range gear control lever. Removal – Installation ....	32	11-07
			Shuttle control lever. Re- moval – Installation .....	33	11-07
			Fuel tank. Removal – In- stallation .....	34-35	11-07
			<b>CHAPTER 2 – Mechanical transmission and splitter</b>		
			Data .....	1-2	11-07
			Tightening torques .....	2	11-07
			Tools .....	2	11-07
			Sections .....	3-4-5	11-07
			Description and operation .	6	11-07
			Fault finding .....	7	11-07
			Splitter device and creeper unit casing, shafts and bearings disassembly ....	8-9-10	11-07
<b>18 – CLUTCH</b>					
Data .....	1-2	11-07			
Tightening torques .....	2	11-07			
Tools .....	2-3	11-07			
Sections .....	3-4	11-07			
Fault finding .....	5	11-07			
Removal-Installation – clutch .....	6-7-8-9- 10-11-12- 13-14-15	11-07			
Clutch Overhaul .....	16-17-18- 19-20	11-07			
Checks and measurements – clutch .....	21-22	11-07			
Adjustments – clutch disen- gagement levers .....	22-23	11-07			
Adjustments – clutch pedal	24	11-07			
PTO control adjustment ..	25	11-07			
Sectional view of PTO clutch servo control .....	26	11-07			
Description and operation of PTO servo control .....	27-28	11-07			
PTO servo control adjust- ment .....	29	11-07			
PTO engaged switch ad- justment .....	30	11-07			

	Page	Date
<b>CHAPTER 3 – Power Shuttle transmission with dual command (2 Speed Power Shift) function</b>		
Data .....	1-2	11-07
Tightening torques .....	3	11-07
Tools .....	4-5-6	11-07
Sections .....	7-8-9-10-11	11-07
Clutch control pressure test	10	11-07
Description and operation .	12	11-07
Fault finding .....	12	11-07
Disassembly-Assembly – transmission-gearbox casing .....	13-14	11-07
Disassembly-Reassembly – Power Shuttle control valve .....	15-16-17	11-07
Disassembly-Assembly – accumulator .....	18	11-07
Gearbox control valve solenoid valve. Removal – Installation .....	19-20	11-07
Disassembly-Assembly – clutch casing .....	21-22-23-24	11-07

**CHAPTER 4 – Power Shuttle transmission (16 + 16 and 8 + 8 versions)**

Data .....	1	11-07
Tightening torques .....	2	11-07
Sections .....	3-4-5-6	11-07
Clutch control pressure test	6	11-07

**23 – DRIVE LINES**

Data .....	1	11-07
Tightening torques .....	2	11-07
Tools .....	3-4	11-07
Sections .....	5-6-7	11-07
Description and operation .	8-9	11-07
Fault finding .....	9	11-07
Drive shafts and guard. Disassembly- Assembly ..	10-11-12	11-07
Removal-Installation – drive gear casing .....	13-14	11-07

Disassembly-Assembly – drive gear casing .....	15-16-17-18	11-07
--	-------------	-------

**25 – FRONT AXLE MECHANICAL TRANSMISSION**

**CHAPTER 1 – Front mechanical transmission (mod. T4040 Supersteer and T4050 Supersteer)**

Data .....	1-2-3	11-07
Tightening torques .....	4-5-6	11-07
Tools .....	7-8-9	11-07
Sections .....	10-11-12-13	11-07
Description and operation	13-14	11-07
Fault finding .....	15	11-07
Removal-Installation – front axle .....	16-17-18-19	11-07
Removal-Installation – front axle differential and bevel drive support .....	20-21-22-23	11-07
Overhaul – front axle bevel drive .....	24-25	11-07
Adjustments – bevel drive	26-27-28-29-30-31	11-07
Overhaul – front differential	32	11-07
Overhaul – differential lock unit .....	33-34-35	11-07
Disassembly-Assembly – front epicyclic final drive with brake .....	36-37-38-39	11-07
Disassembly-Assembly – front epicyclic final drive ..	40-41-42	11-07
Wheel hub seal. Renew ..	43	11-07
Wheel hub and steering knuckle. Disassembly- Assembly .....	44	11-07
Adjustments – steering knuckle bearings .....	45	11-07
Replacing steering knuckle pins and bearings .....	46	11-07
Lead-drive wheel position check .....	47	11-07

	Page	Date		Page	Date
<b>CHAPTER 2 – Front mechanical transmission (mod. T4040 Deluxe and T4050 Deluxe)</b>			Adjustments – differential lock engagement sleeve position .....	20	11-07
Data .....	1-2	11-07	Adjustments – bevel drive	21-22-23- 24-25	11-07
Tightening torques .....	3-4	11-07	Removal-Installation – final drive casing .....	26-27-28- 29	11-07
Tools .....	5-6	11-07	Disassembly-Assembly – drive wheel shaft .....	29-30-31	11-07
Sections .....	7-8	11-07	Disassembly-Assembly – epicyclic final drive .....	31	11-07
Description and operation	8-9	11-07			
Fault finding .....	10	11-07			
Removal-Installation – front axle .....	11-12-13- 14	11-07			
Front axle. Disassembly- Assembly .....	15-16-17- 18-19-20- 21-22-23	11-07			
Overhaul – differential lock unit .....	24-25	11-07			
Replacing steering knuckle pins and bearings .....	26	11-07			
Adjustments – steering knuckle bearings .....	27-28	11-07			
Adjustments – bevel drive	29-30-31- 32-33-34- 35	11-07			
Overhaul – front differential	36	11-07			
LIM-SLIP self-locking dif- ferential .....	37-38	11-07			
Checking leading wheel alignment .....	39	11-07			
Disassembly-Assembly – front epicyclic final drive ..	40-41	11-07			
Disassembly-Assembly – front epicyclic final drive with brake .....	42-43-44	11-07			
<b>27 – REAR MECHANICAL TRANSMISSION</b>					
Data .....	1-2	11-07			
Tightening torques .....	3-4	11-07			
Tools .....	5-6-7-8	11-07			
Sections .....	9-10	11-07			
Description and operation .	11-12	11-07			
Fault finding .....	12-13	11-07			
Disassembly-Assembly – transmission-gearbox cas- ing .....	14-15-16- 17-18-19	11-07			
			<b>31 – POWER TAKE-OFF</b>		
			<b>CHAPTER 1 – Mechanical power take-off</b>		
			Data .....	1-2-3	11-07
			Tools .....	4	11-07
			Tightening torques .....	5-6	11-07
			Sections .....	7-8	11-07
			Description and operation .	9-10-11	11-07
			Fault finding .....	11	11-07
			Disassembly – Assembly – power take-off .....	12-13-14- 15	11-07
			<b>33 – BRAKES</b>		
			Data .....	1-2	11-07
			Tightening torques .....	2	11-07
			Sections .....	3-4-5	11-07
			Tools .....	5-6	11-07
			Description and operation .	6	11-07
			Fault finding .....	7-8	11-07
			Removal-Installation – ser- vice brake .....	9-10	11-07
			Removal-Installation – ser- vice brake pump .....	11-12-13- 14	11-07
			Adjustments – service brake pedals travel .....	15-16	11-07
			Service brake circuit air bleeding .....	16-17-18	11-07
			Removal-Installation – parking brake .....	19-20	11-07

	Page	Date
Adjustments – parking handbrake travel .....	21	11-07

**35 – HYDRAULIC SYSTEMS**

**CHAPTER 1 – Rear mechanical hydraulic lift**

Data .....	1-2-3	11-07
Tightening torques .....	3-4	11-07
Tools .....	5-6	11-07
Sections .....	7-8-9-10-11	11-07
Description and operation .	12-13-14-15	11-07
Fault finding .....	16-17	11-07
Lift internal controls. Disassembly- Assembly .....	18-19-20-21	11-07
Adjusting the lift .....	22-23-24-25-26-27-28-29-30-31	11-07
Lift cylinder and arms shaft. Disassembly- Assembly ..	32-33-34-35	11-07
Disassembly-Assembly – lift control valve .....	36-37-38-39	11-07
Lift pressure relief valve ..	40	11-07

**CHAPTER 2 – Open centre system auxiliary control valves**

Data .....	2	11-07
Tools .....	2	11-07
Tightening torques .....	2	11-07
Sections .....	3-4	11-07
Description and operation .	5-6-7-8	11-07
Lift electronic control unit. Renew .....	9	11-07
Auxiliary control valves. Disassembly- Assembly ..	10-11-12	11-07

**CHAPTER 3 – Trailer brakes auxiliary control valves**

Sections .....	1	11-07
Description and operation .	1-2-3-4-5-6-7	11-07
Fault finding .....	8-9-10	11-07

	Page	Date
Removal-Installation – trailer brake valve .....	11	11-07

**CHAPTER 4 – Electronically controlled hydraulic lift**

Data .....	2-3	11-07
Tightening torques .....	4	11-07
Tools .....	4-5-6	11-07
Sections .....	7-8-9	11-07
Location of Components ..	10-11-12	11-07
Description and operation .	13-14-15-16-17-18	11-07
Removal-Installation – lift .	19-20-21-22-23	11-07
Draft sensor support. Removal – Installation .....	24	11-07
Replacement – control unit	25	11-07
Lift arm potentiometer. Renew .....	26-27	11-07
Replacement – draft sensor .....	28-29	11-07
Electronically controlled hydraulic lift. Disassembly-Assembly .....	30-31-32-33-34	11-07
Removal-Installation – hydraulic control valve .....	35	11-07
Hydraulic control valve. Disassembly- Assembly ..	36-37-38	11-07

**CHAPTER 5 – Constant flow gear pump**

Data .....	1-2	11-07
Description and operation .	2	11-07
Diagrams .....	3	11-07
Disassembly-Assembly – lift oil pump .....	4	11-07

**CHAPTER 6 – Electronic lift and front Power Take-Off**

Main specifications of front lift .....	1-2-3	11-07
Tightening torques .....	3-4-5	11-07
Cross-sectional views of implement linkage .....	6-7	11-07
Cross-sectional views of front PTO .....	8-9-10	11-07

	Page	Date		Page	Date
Description and operation .	11-12-13-14	11-07	Description and operation of front electronic lift hydraulic control valve . . . . .	17-18-19-20	03-08
Front lift hydraulic diagram	15	11-07	Fault finding . . . . .	21-22	03-08
Front lift troubleshooting . .	16-17	11-07	Front electronic lift operating instructions . . . . .	23-24-25-26	03-08
Removal-Installation -			Front electronic lift calibration . . . . .	27-28-29	03-08
Front power take-off transmission shaft . . . . .	18-19-20-21-22-23-24-25	11-07	Removal-Installation - front mechanical/electronic lift . . . . .	30-31	03-08
Disassembly-Assembly - Front PTO transmission shaft . . . . .	26	11-07	Removal-Installation - front power take-off . . . . .	32-33	03-08
Front PTO casing cross-sectional view . . . . .	27	11-07	Disassembly-Assembly - front power take-off . . . . .	34-35	03-08
Removal-Installation - Front PTO electromagnetic coupling . . . . .	28-29-30	11-07	Removal-Installation - front electronic lift control unit . . . . .	36	03-08
Disassembly-Assembly - Front PTO electromagnetic coupling . . . . .	31-32-33-34	11-07	Removal-Installation - front electronic lift hydraulic control valve . . . . .	37	03-08
Removal-Installation - Front lift support . . . . .	35-36-37	11-07	Fault code indication . . . . .	38	03-08
<b>CHAPTER 7 - Front lift and power take-off (for mod. T4030 Deluxe, T4040 Deluxe and T4050 Deluxe)</b>			Diagnostics . . . . .	39-40-41-42-43-44-45-46-47-48-49-50-51-52-53-54-55-56	06-09
Data . . . . .	1-2	03-08	<b>41 - STEERING</b>		
Tightening torques . . . . .	3-4	03-08	<b>CHAPTER 1 - Steering</b>		
Sections . . . . .	5-6	03-08	Data . . . . .	2	11-07
Description and operation of front power take-off . . . . .	7	03-08	Tightening torques . . . . .	2	11-07
Front power take-off control adjustment . . . . .	8	03-08	Tools . . . . .	2	11-07
Front power take-off control valve . . . . .	9	03-08	Description and operation . . . . .	3-4-5	11-07
Sectional view of front power take-off clutch . . . . .	10	03-08	View of hydrostatic steering control valve components . . . . .	6	11-07
Front mechanical lift . . . . .	11	03-08	Fault finding . . . . .	7-8	11-07
Electronic front lift . . . . .	12-13-14	03-08	Replacement - hydrostatic steering wheel . . . . .	9	11-07
Front electronic lift hydraulic control valve diagram . . . . .	15	03-08	Removal-Installation - hydrostatic steering control valve . . . . .	10-11-12	11-07
Front electronic lift hydraulic control valve . . . . .	16	03-08			

	Page	Date
Disassembly–Assembly – hydrostatic control valve . . . . .	13–14–15–16–17–18–19–20–21–22–23–24–25–26–27–28	11–07
Hydrostatic steering control valve bench testing . . . . .	29–30	11–07
Pressure relief valve testing	31	11–07
Steering control cylinder. Removal – Installation . . . . .	32–33	11–07
Steering control cylinder. Disassembly–Assembly . . . . .	34–35	11–07

**CHAPTER 2 – Constant flow gear pump**

Data . . . . .	1–2	11–07
Diagrams . . . . .	3–4	11–07
Description and operation . . . . .	4	11–07
Disassembly–Assembly – hydrostatic steering oil pump . . . . .	5	11–07

**44 – AXLES AND WHEELS**

Data . . . . .	1–2	11–07
Front wheel track diagram	2	11–07
Sections . . . . .	3	11–07
Tightening torques . . . . .	4–5–6	11–07
Tools . . . . .	6–7	11–07
Fault finding . . . . .	7	11–07
Disassembly–Assembly – wheel axle hub . . . . .	8–9–10	11–07
Removal–Installation – front axle . . . . .	11–12–13	11–07
Stub axle hub overhaul . . . . .	14–15–16–17	11–07
Checking leading wheel alignment . . . . .	18	11–07

**50 – CAB AIR CONDITIONING SYSTEM**

Safety regulations . . . . .	2	11–07
Data . . . . .	3	11–07
Tools . . . . .	4	11–07
Operating principles . . . . .	5	11–07

Conditioning system components . . . . .	6–7–8–9–10	11–07
Cab controls . . . . .	11–12–13	11–07
Testing operation and cooling . . . . .	14–15	11–07
Air conditioning system maintenance . . . . .	16–17	11–07
Fault finding . . . . .	18–19–20–21	11–07
Refrigerant recovery – recycling and evacuation – charging stations . . . . .	22–23	11–07
Dehydration, recharging and refrigeration check . . . . .	24–25–26–27–28–29–30	11–07
Checking for and eliminating any gas leaks . . . . .	31–32	11–07
Compressor drive belt tension adjustment . . . . .	33	11–07
Cab air infeed vents. Removal – Installation . . . . .	34	11–07
Cab heating/air-conditioning system. Removal – Installation . . . . .	35–36	11–07
Cab heater. Disassembly–Assembly . . . . .	37	11–07
Cab air conditioning system evaporator unit. Disassembly– Assembly . . . . .	38	11–07
Cab electric fan unit. Disassembly– Assembly . . . . .	39	11–07

**55 – ELECTRICAL SYSTEM**

**CHAPTER 1 – Instruments**

Analogue instrumentation . . . . .	1–2–3–4	11–07
Digital instrumentation . . . . .	5–6–7–8–9	11–07
Transmitters, sensors and switches . . . . .	10–11–12–13–14–15–16–17	11–07

**CHAPTER 2 – Components**

Introduction . . . . .	1	11–07
------------------------	---	-------

	Page	Date		Page	Date
Components .....	1-2-3-4-5 -6-7	11-07			
Service .....	8-9-10-11 -12	11-07			
<b>CHAPTER 3 – Starting System</b>					
Technical data .....	1	11-07			
Description and operation .	2	11-07			
Fault finding .....	3	11-07			
System testing .....	4-5-6	11-07			
View of starter motor components .....	7	11-07			
Revision .....	8-9	11-07			
Starter motor testing .....	9-10	11-07			
<b>CHAPTER 4 – Charging system</b>					
Technical data .....	1	11-07			
Tightening torques .....	1	11-07			
Description and operation .	2-3	11-07			
System testing .....	4-5-6-7-8 -9	11-07			
Removal-Installation and Overhaul – alternator ....	9-10-11- 12-13-14- 15-16	11-07			
<b>CHAPTER 5 – Battery</b>					
Technical data .....	1	11-07			
Description and operation .	1	11-07			
Removal-Installation – battery .....	2	11-07			
Battery Service .....	3	11-07			
Battery charging .....	4-5-6	11-07			
Battery troubleshooting ...	6	11-07			
<b>CHAPTER 6 – Electrical circuits for tractors with cab</b>					
Index .....	1	06-09			
<b>CHAPTER 7 – Electrical circuits for tractors with platform</b>					
Index .....	1	11-07			
<b>CHAPTER 8 – Connectors</b>					
Index .....	1	11-07			
<b>CHAPTER 9 – Error codes</b>					
Index .....	1	06-09			
<b>CHAPTER 10 – HH Menu and calibrations</b>					
Index .....	1	06-09			
<b>CHAPTER 11 – Front electronic lift (mod. T4030 Deluxe, T4040 Deluxe and T4050 Deluxe)</b>					
Index .....	1	03-08			
Electrical circuit components .....	2-3	03-08			
Wiring diagrams .....	4	03-08			
Wiring diagrams .....	6-7-8-9- 10-11	03-08			
Connectors .....	14-15-16- 17-18-19- 20	03-08			
<b>90 – PLATFORM, CAB, BODYWORK</b>					
<b>CHAPTER 1 – Cab</b>					
Hood. Removal – Installation .....	2	11-07			
Instrument panel lower guard. Removal – Installation ....	3	11-07			
Platform assembly. Removal – Installation ....	4-5-6-7- 8-9-10	11-07			
Canopy for rops. Removal – Installation .....	11	11-07			
Cab assembly with platform. Removal – Installation ....	12-13-14- 15-16-17- 18-19	11-07			
Cab windows. Renew ....	20-21-22	11-07			
Right/left-hand upright seals. Removal – Installation ....	23	11-07			
Cab ceiling fitting. Removal – Installation ....	24-25	11-07			
Sunshade. Removal – Installation ....	26	11-07			

## GENERAL INSTRUCTIONS

### IMPORTANT NOTICE

All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND service technicians, in strict accordance with the instructions given and using any specific tools necessary. Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.

### BATTERY

Before carrying out any kind of service operation disconnect and isolate the battery negative lead, unless otherwise requested for specific operations (e.g.: operations that require the engine running). Once the specific operation has been completed, disconnect the lead in order to complete the operation.

### SHIMMING

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the recorder values: Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated for each on shim.

### ROTATING SHAFT SEALS

For correct rotating shaft seal installation, proceed as follows:

- before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes;
- thoroughly clean the shaft and check that the working surface on the shaft is not damaged;
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal;
- smear the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- insert the seal in its seat and press down using a flat punch; do not tap the seal with a hammer or mallet;
- whilst inserting the seal, check that the it is perpendicular to the seat; once settled, make sure that it makes contact with the thrust element, if required;
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations.

### O-RING SEALS

Lubricate the O-RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

### SEALING COMPOUNDS

Apply one of the following sealing compounds on the mating surfaces marked with an X: RTV SILMATE, RHODORSIL CAF 1 or LOCTITE PLASTIC GASKET.

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a wire brush;
- thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, petrol or a water and soda solution.

### BEARINGS

When installing bearings it is advised to:

- heat the bearings to 80 ÷ 90 °C before fitting on the shafts;
- allow the bearings to cool before installing them from the outside.

### SPRING PINS

When fitting split socket elastic pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral spring pins do not require special positioning

### SPARE PARTS

Use genuine parts only.

Only genuine spare parts guarantee the same quality, duration and safety as they are the same parts that are assembled during production.

Only **genuine parts** can offer this guarantee.

When ordering spare parts, always provide the following information:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found in the "Microfiches" or the "Spare Parts Catalogue", used for order processing.

### NOTES FOR EQUIPMENT

The tools that NEW HOLLAND propose and illustrate in this manual are:

- specifically researched and designed for use with NEW HOLLAND vehicles;
- necessary to make reliable repair;
- accurately built and strictly tested to offer efficient and long-lasting working means.

By using these tools, repair personnel will benefit from:

- operating in optimal technical conditions;
- obtaining the best results;
- saving time and effort;
- working in safe conditions.

### IMPORTANT NOTES

Wear limit values indicated for certain parts are recommended, but not binding. The terms "front", "rear", "right-hand" and "left-hand" (when referred to different parts) are intended as seen from the driving position with the tractor in the normal direction of movement.

### MOVING THE TRACTOR WITH THE BATTERY REMOVED

External power supply cables should only be connected to the respective positive and negative cable terminals, using efficient clamps that guarantee adequate and secure contact.

Disconnect all services (lights, windshield wipers, etc.) before starting the vehicle.

If the vehicle electrical system requires checking, carry out operations with the power supply connected; once checking is completed, disconnect all services and switch off the power supply before disconnecting the cables.

## SAFETY REGULATIONS

### WARNING AND DANGER SYMBOL

This warning symbol points out important messages concerning your safety.

Carefully read the following safety regulations and observe advised precautions in order to avoid potential hazards and safeguard your health and safety.

In this manual the symbol is accompanied by the following key-words:

**WARNING** - Warnings concerning unsuitable repair operations that may jeopardise the safety of Repair personnel.

**DANGER** - Specific warnings concerning potential hazards for operator safety or for other persons directly or indirectly involved.

### TO PREVENT ACCIDENTS

Most accidents or injuries that occur in workshops are the result of non-observance of simple and fundamental safety regulations. For this reason, IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED: by foreseeing possible causes and consequently acting with the necessary caution and care.

Accidents may occur with all types of vehicle, regardless of how well it was designed and built.

A careful and judicious service technician is the best guarantee against accidents.

Precise observance of the most basic safety rule is normally sufficient to avoid many serious accidents.

**DANGER.** Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

## SAFETY REGULATIONS

### GENERAL

- Carefully follow specified repair and maintenance procedures.
- Do not wear rings, wristwatches, jewellery, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips that may remain entangled in moving parts. It is advised to wear approved safety clothing, e.g.: non-slip footwear, gloves, safety goggles, helmets, etc.



1

- Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a trained technician who is assisting with the operation in question.
- Do not operate the vehicle or use any of the implements from different positions, other than the driver's seat.
- Do not carry out operations on the vehicle with the engine running, unless specifically indicated.
- Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- All repair and maintenance operations must be carried out using extreme care and attention.
- Service steps and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- Disconnect the batteries and label all controls to indicate that the vehicle is being serviced. Block the machine and all equipment which should be raised.
- Do not check or fill fuel tanks, accumulator batteries, nor use starting liquid when smoking or near naked flames, as these fluids are inflammable.
- Brakes are inoperative when manually released for repair or maintenance purposes: Use blocks or similar devices to control the machine in these conditions.
- The fuel nozzle should always be in contact with the filling aperture: Maintain this contact until the fuel stops flowing into the tank to avoid possible sparks due to static electricity build-up.

- Only use specified towing points for towing the vehicle. Connect parts carefully: make sure that all pins and/or locks are secured in position before applying traction. Never remain near the towing bars, cables or chains that are operating under load.
- Transport vehicles that cannot be driven using a trailer or a low-loading platform trolley, if available.
- When loading or unloading the vehicle from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels. Firmly secure the vehicle to the truck or trailer and lock the wheels in the position used by the carrier.
- Electric heaters, battery-chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- Take extra care if bystanders are present.
- Never pour petrol or diesel oil into open, wide or low containers.
- Never use gasoline, diesel oil or other inflammable liquids as cleaning agents: use non-inflammable, non toxic commercially available solvents.
- Wear safety goggles with side guards when cleaning parts with compressed air.
- Limit the air pressure to a maximum of 2.1 bar, according to local regulations.
- Do not run the engine in confined spaces without suitable ventilation.
- Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- Never use naked flames for lighting when working on the machine or checking for leaks.
- All movements must be carried out carefully when working under, on or near the vehicle. Wear protective equipment: helmets, goggles and special footwear.
- When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- If operating outside the workshop, position the vehicle on a flat surface and lock in position. If working on a slope, lock the vehicle in position. Move to a flat area as soon as is safely possible.
- Damaged or bent chains or cables are unreliable: do not use them for lifting or towing. Always use suitable protective gloves when handling chains or cables.
- Chains should always be safely secured: make sure that the hitch-up point is capable of sustaining the load in question. Keep the area near the hitch-up point, chains or cables free of all bystanders.
- Maintenance and repair operations must be carried out in a CLEAN and DRY area. Eliminate any water or oil spillage immediately.
- Do not create piles of oil or grease-soaked rags: as they represent a serious fire hazard. Always store rags in a closed metal container. Before starting the tractor or its attachments, check, adjust and block the operator's seat. Also check that there are no persons within the vehicle or implement range of action.
- Empty pockets of all objects that may fall unobserved into the vehicle parts.
- In the presence of protruding metal parts, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles. NEVER LOOK DIRECTLY AT THE WELDING ARC WITHOUT SUITABLE EYE PROTECTION.
- Metal cables tend to fray with repeated use: always use suitable protective devices (gloves, goggles, etc.) when handling cables.
- Handle all parts with great care. Do not put your hands or fingers between moving parts. Always wear suitable safety clothing - safety goggles, gloves and shoes.

**START UP**

- Never run the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- Never place the head, body, limbs, feet, hands or fingers near fans or rotating belts.

**ENGINE**

- Always loosen the radiator cap slowly before removing it to allow any remaining pressure in the system to be discharged. Filling up with coolant should only be carried out with the engine stopped or idling (if hot).
- Never fill up with fuel when the engine is running, especially if hot, in order to prevent the outbreak of fire as a result of fuel spillage.
- Never check or adjust fan belt tension when the engine is running.  
Never adjust the fuel injection pump when the vehicle is moving.
- Never lubricate the vehicle when the engine is running.

**ELECTRICAL SYSTEMS**

- If it is necessary to use auxiliary batteries, remember that both ends of the cables must be connected as follows: (+) with (+) and (-) with (-). Avoid short-circuiting the terminals. **GAS RELEASED FROM BATTERIES IS HIGHLY INFLAMMABLE.** During charging, leave the battery compartment uncovered to improve ventilation. Never check the battery charge using "jumpers" (metal objects placed on the terminals). Avoid sparks or flames near the battery zone. Do not smoke to prevent explosion hazards.
- Before servicing operations, check for fuel or current leaks: eliminate any eventual leaks before proceeding with work.
- Do not charge batteries in confined spaces: make sure that there is adequate ventilation in order to prevent accidental explosion hazards as a result of the accumulation of gases released during charging operations.
- Always disconnect the batteries before performing any kind of servicing on the electrical system.

**HYDRAULIC SYSTEMS**

- A liquid leaking from a tiny hole may be almost invisible but, at the same time, be powerful enough to penetrate the skin. **NEVER USE HANDS TO CHECK FOR LEAKS:** but use a piece of cardboard or wood for this purpose. If any liquid penetrates skin tissue, call for medical aid immediately. Failure to treat this condition with correct medical procedure may result in serious infection or dermatosis.
- In order to check the pressure in the system use suitable instruments.

**WHEELS AND TYRES**

- Make sure that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check the rims and tyres for damage.
- Stand away from (at the side of) the tyre when checking inflation pressure.
- Only check pressure when the vehicle is unloaded and the tyres are cold, to avoid incorrect readings as a result of over-pressure. Do not use parts of recovered wheels as incorrect welding brazing or heating may weaken and eventually cause damage to the wheel.
- Never cut or weld a rim mounted with an inflated tyre.
- To remove the wheels, lock both the front and rear vehicle wheels. After having raised the vehicle, position supports underneath, according to regulations in force.
- Deflate the tyre before removing any object caught in the tyre tread.
- Never inflate tyres using inflammable gases; as this may result in explosions and injury to bystanders.

**REMOVAL AND RE-FITTING**

- Lift and handle all heavy parts using suitable hoisting equipment. Make sure that parts are sustained by appropriate hooks and slings. Use the hoisting eyebolts for lifting operations. Extra care should be taken if persons are present near the load to be lifted.
- Handle all parts extremely carefully. Do not put your hands or fingers between parts. Wear suitable safety clothing – safety goggles, gloves and shoes.
- Avoid twisting chains or metal cables. Always wear safety gloves when handling cables or chains.

## CONSUMABLES

COMPONENT TO BE FILLED OR TOPPED UP	QUANTITY dm <sup>3</sup> (litres)	RECOMMENDED NEW HOLLAND PRODUCT	NEW HOLLAND SPECIFICATION	INTERNATIONAL SPECIFICATION
Cooling system: less cab: .....	14.0	Water and <b>AMBRA AGRIFLU fluid 50% + 50%</b>	NH 900 A	-
with cab .....	16.0			
Windscreen wash reservoir	2.0	Water and antifreeze	-	-
Fuel tank: .....	88	Decanted, filtered diesel fuel	-	-
Engine oil sump: without filter: .....	8.9	<b>Oil AMBRA MASTERGOLD HSP</b>	NH 324H (SAE 10W-30) NH 330H (SAE 15W-40))	API CI-4/CH-4 ACEA E7/E5
with filter: .....	9.5			
Brake circuit .....	0.7	<b>AMBRA BRAKE LHM oil</b>	NH 610 A	ISO 7308
With front brakes .....	1.0			
Front axle: axle housing .....	4.5	<b>AMBRA MULTI G oil</b>	NH 410 B	API GL4 ISO 32/46 SAE 10W-30
final drives without brakes (each) .....	1.0			
final drives with brakes (each) .....	1.5			
Rear transmission (bevel drive, final drives and brakes), gearbox, hydraulic lift, PTO and hydraulic steering: .....	42			
Grease fittings .....	-	<b>AMBRA GR9 grease</b>	NH 710 A	NLGI 2
Air conditioning system - coolant .....	- 0.80	-	-	R-134a SP20
- oil .....	0.15			

## SECTION 10 - ENGINE

### Chapter 1 - Engine

#### CONTENT

Section	Description	Page
<b>10 000</b>	General specifications .....	2
	Specifications .....	4
	Torque settings .....	10
	Tools .....	12
	Cross-sectional views .....	13
	Schematic diagrams .....	14
	Troubleshooting .....	17
<b>10 001 10</b>	Engine Removal-Installation .....	22
<b>10 001 54</b>	Engine Disassembly - Assembly .....	33
<b>10 102 70</b>	Crankshaft front seal - Replacement .....	85
<b>10 102 74</b>	Crankshaft rear seal - Replacement .....	87
<b>10 106 12</b>	Valve/rocker arm clearance .....	90
<b>10 218 30</b>	Engine injectors Removal-Installation .....	92
<b>10 246 14</b>	Bosch injection pump Removal-Installation, timing and air bleeding .....	95
<b>10 402 10</b>	Coolant pump Removal-Installation .....	101
<b>10 402 30</b>	Thermostatic valve Removal/Installation .....	103
<b>10 406 10</b>	Radiator Removal-Installation .....	105
<b>10 414 10</b>	Coolant pump and generator drive belts Adjusting tension .....	109

<b>GENERAL SPECIFICATIONS</b>	
Engine, technical type:	
- Model T4040 type F4CE9484N*J601 (BOSCH pump) . . . .	
- Model T4050 - type F4CE9484M*J601 (BOSCH pump) . .	
Cycle . . . . .	diesel, 4-stroke
Fuel injection . . . . .	Direct
Number of cylinders in line . . . . .	4
Piston diameter . . . . .	104 mm
Piston stroke . . . . .	132 mm
Total displacement . . . . .	4485 cm <sup>3</sup>
Compression ratio . . . . .	16.5:1
Maximum Power Output:	
- Model T4040 - type F4CE9484N*J601 . . . . .	63 kW (86 Hp)
- Model T4050 - type F4CE0454C*D600/*D603 . . . . .	71 kW (97 Hp)
Maximum power speed . . . . .	2300 rpm
- Maximum torque: Model T4040 - type F4CE9484N*J601 .	370 Nm
- Maximum torque: Model T4050 - type F4CE9484M*J601	418 Nm
Maximum torque speed . . . . .	1300 rpm
Number of main bearings . . . . .	5
Sump pan . . . . .	structural, cast iron
<b>Lube</b> . . . . .	forced, with lobe pump
Pump drive . . . . .	from crankshaft
Engine speed/oil pump speed ratio . . . . .	1:1
Oil filtration . . . . .	mesh screen on oil pick-up and filter cartridge in delivery line
Normal oil pressure with motor warmed-up	
at slow idling . . . . .	1.2 bar
at fast idling . . . . .	3.9 bar

(continued)

(overleaf)

<b>GENERAL SPECIFICATIONS</b>	
<b>Cooling</b> .....	coolant circulation
Radiator .....	4 lines of vertical pipes with copper fins
Fan, attached to the pulley .....	intake, in plastic with 11 blades
Coolant pump .....	centrifugal vane-type
Engine speed/coolant pump speed ratio .....	1:1.977
Coolant thermometer .....	coloured scale divided into three sections
Temperature ranges corresponding to each section:	
- Initial blue section .....	40° ÷ 60 °C
- Middle green section (normal working conditions) .....	60° ÷ 110 °C
- Final red section .....	110° ÷ 120 °C
Temperature Control .....	via thermostat valve
- initial opening .....	81 ± 2 °C
<b>Valve Timing</b> .....	overhead valves operated by tappets, rods and rocker arms via the camshaft located in the engine block; the camshaft is driven by the crankshaft using straight-tooth gears
Intake:	
- start: before T.D.C. ....	10° ± 30'
- end: after B.D.C. ....	10° ± 30'
Exhaust:	
- start: before B.D.C. ....	64°
- end: after T.D.C. ....	26°
Clearance between valves and rocker arms with engine cold:	
- intake .....	0.25 ± 0.05 mm
- exhaust .....	0.50 ± 0.05 mm
<b>Power supply</b>	
Air filtering .....	dual cartridge dry air filter, with clogged filter indicator with centrifugal pre-filter and automatic dust ejector
Fuel pump .....	with double diaphragm
Fuel filtration .....	through wire filter in fuel supply pump, and replaceable cartridge on delivery line to injection pump
Minimum fuel flow rate with pump shaft rotating at 1800 rpm .	127.6 l/h
Cam operated .....	via engine timing

(continued)

(overleaf)

<b>GENERAL SPECIFICATIONS</b>	
BOSCH Injection pump .....	rotating distributor type
All-speed governor, incorporated in pump:	
BOSCH .....	centrifugal counterweights
Automatic advance regulator, incorporated in pump:	
BOSCH .....	hydraulic
Turbocharger:	
- type .....	HOLSET HX25
Injection pump .....	rotating distributor with speed governor and advance variator incorporated
BOSCH pump:	
- Model T4040 - type F4CE9484N*J601 .....	VE 4/12 F1150-2856534
- Model T4050- type F4CE9484M*J601 .....	VE 4/12 F1150-2856537
Direction of rotation .....	anticlockwise
Injection order .....	1-3-4-2 (for all models)

**SPECIFICATIONS**

BOSCH-type injectors:	
F4CE9484N*J601/F4CE9484M*J601 .....	2856255
Number of nozzle holes .....	6
Nozzle hole diameter mm:	
F4CE9484N*J601/F4CE9484M*J601 .....	0.237
Calibration pressure bar .....	260 ÷ 274



CONNECTING ROD DATA	mm
Connecting rods .....	printed in steel, oblique-cut type
Diameter of small end bushing seat .....	40.987 ÷ 41.013
Outside diameter of small end bushing .....	41.279 ÷ 41.553
Interference between small end bushing and seat .....	0.266 ÷ 0.566
Internal diameter of small end bushing (after press-fitting) .....	38.019 ÷ 38.033
Diameter of seat for bearing shells on connecting rod .....	72.987 ÷ 73.013
Connecting rod-crankpin end float .....	0.100 ÷ 0.330

PISTON DATA	mm
Pistons .....	light alloy with three compression rings, including two seal rings and one scraper ring
Standard piston diameter, measured at 61 mm from skirt base and perpendicularly to the gudgeon pin axis .....	103.714 ÷ 103.732
Piston clearance in cylinder liner .....	0.268 ÷ 0.310
Spare piston oversizes .....	0,400
Piston protrusion at T.D.C. from cylinder block face .....	0.280 ÷ 0.520
Gudgeon pin diameter .....	37.994 ÷ 38.000
Diameter of gudgeon pin seat in piston .....	38.010 ÷ 38.016
Gudgeon pin to seat clearance .....	0.010 ÷ 0.022
Gudgeon pin to small end bearing clearance .....	0.019 ÷ 0.039
Piston ring seat depth:	
- 1st ring (measured on a diameter of 99 mm) .....	2.705 ÷ 2.735
- 2nd ring .....	2.440 ÷ 2.460
- 3rd ring .....	4.030 ÷ 4.050
Piston ring thickness:	
- 1st ring .....	2.560 ÷ 2.605
- 2nd ring .....	2.350 ÷ 2.380
- 3rd ring .....	3.970 ÷ 3.990

(continued)

(overleaf)

<b>PISTON DATA</b>	<b>mm</b>
Piston ring groove clearance (measured vertically):	
- 1st ring .....	0.100 ÷ 0.175
- 2nd ring .....	0.060 ÷ 0.110
- 3rd ring .....	0.040 ÷ 0.080
Assembly clearance between piston ring ends in cylinder sleeves:	
- 1st ring .....	0.30 ÷ 0.40
- 2nd ring .....	0.60 ÷ 0.80
- 3rd ring .....	0.30 ÷ 0.55
Spare piston ring oversizing .....	0.400

<b>VALVE TIMING GEAR DATA</b>	<b>mm</b>
Internal diameter of camshaft support bushings (press-fitted and finished in seats):	
- front .....	54.083 ÷ 54.147
- mid .....	54.083 ÷ 54.147
- rear .....	54.083 ÷ 54.147
Diameter of camshaft journals:	
- front .....	53.995 ÷ 54.045
- mid .....	53.995 ÷ 54.045
- rear .....	53.995 ÷ 54.045
Clearance between camshaft journals and bushings .....	0.038 ÷ 0.152
Camshaft end float .....	0.230 ± 0.130
Crankshaft to camshaft teeth clearance .....	0.076 ÷ 0.280

<b>TAPPET DATA</b>	<b>mm</b>
Tappet bore in crankcase .....	16.000 ÷ 16.030
Outside diameter of standard tappets .....	15.929 ÷ 15.959
Tappet running clearance .....	0.041 ÷ 0.101

<b>ROCKER ARM - VALVE DATA</b>	<b>mm</b>
Rocker-arm shaft diameter .....	18.963 ÷ 18.975
Rocker-arm shaft seat diameter .....	19.000 ÷ 19.026
Rocker arm bore to shaft clearance .....	0.025 ÷ 0.063
Valve clearance for normal running (engine cold):	
- inlet valve .....	0.25 ± 0.05
- exhaust valve .....	0.50 ± 0.05
Cam lift:	
- inlet valve .....	6.045
- exhaust valve .....	7.239

<b>CYLINDER HEAD DATA</b>	<b>mm</b>
Cylinder head .....	in cast iron with fitted valve seats and seats for injectors and thermostat valve
Maximum face re-grinding depth, that can be removed from the cylinder head in the event of reboring .....	0.130
Diameter of valve stem seat in cylinder head .....	8.019 ÷ 8.039
Valve stem diameter .....	7.960 ÷ 7.980
Assembly clearance between valve stem and seat .....	0.039 ÷ 0.079
Valve seat angle in head:	
- inlet valve .....	60°
- exhaust valve .....	45°
Valve face angle:	
- inlet valve .....	60°
- exhaust valve .....	45°
Diameter on head for fitting valve seat:	
- inlet valve .....	46.987 ÷ 47.013
- exhaust valve .....	43.637 ÷ 43.663
Valve seat insert outside diameter:	
- inlet valve .....	47.063 ÷ 47.089
- exhaust valve .....	43.713 ÷ 43.739
Valve stand-in relative to cylinder head face:	
- inlet valve .....	1.00 ÷ 1.52
- exhaust valve .....	1.00 ÷ 1.52
Interference between valve seat and head:	
- inlet valve .....	0.050 ÷ 0.102
- exhaust valve .....	0.050 ÷ 0.102

(continued)

*(overleaf)*

CYLINDER HEAD DATA	mm
Valve head diameter:	
- inlet valve .....	44.870 ÷ 45.130
- exhaust valve .....	41.870 ÷ 42.130
Inlet and exhaust valve springs:	
- spring free length .....	63.500
- length under load of 329 N .....	49.020
- length under load of 641 N .....	38.200
Injector protrusion relative to head face:	
● BOSCH injectors 2856255 .....	Not adjustable

TORQUE SETTINGS WITH ANGLE				
PARTS TO BE TIGHTENED	Thread	Tightening torque		Angle
		Nm	kgm	
Main bearing cap bolts				
phase 1 .....	M12 x 1.5	50 ± 6	5.0 ± 0.6	-
phase 2 .....	M12 x 1.5	80 ± 6	8.0 ± 0.6	-
phase 3 .....	M12 x 1.5	-	-	90° ± 5°
Big-end cap bolts				
phase 1 .....	M 10 x 1.25	30 ± 3	3.0 ± 0.3	-
phase 2 .....	M 10 x 1.25	60 ± 5	6.0 ± 0.5	-
phase 3 .....	M 10 x 1.25	-	-	60° ± 5°
Bolts securing cylinder head .....	M 12 x 1.75 x 70	50 ± 5	5.0 ± 0.5	90°
<b>Note:</b> For the tightening sequence, see page 56, Fig. 124.	M 12 x 1.75 x 140	40 ± 5	4.0 ± 0.5	180°
	M 12 x 1.75 x 180	70 ± 5	7.0 ± 0.5	180°
Bolts securing engine flywheel .....	M 12 x 1.25	30 ± 4	3.0 ± 0.4	60° ± 5°

<b>TORQUE WRENCH SETTINGS</b>			
PARTS TO BE TIGHTENED	Thread	Tightening torque	
		Nm	kgm
Bolts fastening pulley on crankshaft .....	M 12 x 1.75	110 ± 5	11.0 ± 0.5
Flywheel casing retaining bolts .....	M 12 x 120	85 ± 10	8.5 ± 1
	M 12 x 80	85 ± 10	8.5 ± 1
	M 10 x 80	49 ± 5	4.9 ± 0.5
	M 10 x 40	49 ± 5	4.9 ± 0.5
Oil sump retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
	M 8 x 1.50	60 ± 9	6 ± 0.9
Oil sump threaded plugs .....	M 22 x 1.5	50 ± 5	5 ± 0.5
Rocker arm support retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Tappet cover retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Exhaust manifold retaining bolts .....	M 10 x 1.50	53 ± 6	4.3 ± 0.6
Intake manifold retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Oil cooler retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Coolant pump retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Coolant inlet manifold retaining bolts .....	M 10 x 1.50	24 ± 4	2.4 ± 0.4
Thermostat valve assembly retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Fan support retaining bolts .....	M 8 x 1.25 x 50	10 ± 2	1 ± 0.2
	M 10 x 1.50 x 25	43 ± 6	4.3 ± 0.6
Injector fastener .....	-	60 ± 5	6.0 ± 0.5
Fuel pump retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Nuts securing turbine mod. T4050 .....	M 10 x 1.25	43 ± 6	4.3 ± 0.5
Alternator retaining bolts .....	M 8 x 1.50	24 ± 4	2.4 ± 0.4
Starter motor retaining bolts .....	M 10 x 1.50	49 ± 5	4.9 ± 0.5
Camshaft plate retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Injection pump retaining bolts .....	M 8 x 1.25	12 ± 5	1.2 ± 0.5
Oil pump gear casing retaining bolts .....	M 8 x 1.25	24 ± 4	2.4 ± 0.4
Additional counterweight retaining bolts .....	M 10 x 1.5	48 ± 8	4.8 ± 0.8
Bolts securing camshaft gear .....	M 8 x 1.25	36 ± 4	3.6 ± 0.4


**SPECIAL TOOLS**

**Warning** - The operations described in this section can only be carried out with **ESSENTIAL** tools indicated by an **(X)**.

To work safely and efficiently and obtain the best results, it is also necessary to use the recommended specific tools listed below and certain other tools, which are to be made according to the drawings included in this manual.

**List of specific tools required for the various operations described in this Section.**


<b>X 380000216</b>	Engine removal and installation tool.	<b>X 380000664</b>	Splining tool for fitting rear seal on crankshaft.
<b>380000220</b>	Clamp for fitting piston in cylinder liner (60-125 mm).	<b>X 380000665</b>	Tool to extract crankshaft front seal.
<b>X 380000221</b>	Pliers for piston ring disassembly and reassembly (65-110 mm).	<b>X 380000666</b>	Splining tool for fitting front seal on crankshaft.
<b>380000301</b>	Rotating stand for overhaul operations (capacity 1000 daN, torque 120 daN/m).	<b>X 380000667</b>	Drift for camshaft bushing disassembly and reassembly (use with <b>380000668</b> ).
<b>X 380000302</b>	Tool for engine valve disassembly and reassembly.	<b>380000668</b>	Grip for interchangeable drifts.
<b>380000304</b>	Pair of gauges for angular tightening with 1/2" and 3/4" square connection.	<b>X 380000669</b>	Gasket extraction tool.
<b>380000362</b>	Crankshaft lifting tool.	<b>X 380000670</b>	Tool for cartridge filter disassembly.
<b>X 380000364</b>	Dial gauge base for various measurements (use with <b>380000228</b> ).	<b>380000671</b>	Injector extraction tool.
<b>380000569</b>	Movable tool for dismantling tractors with bracket <b>380000500</b> and adapter plate <b>380000844</b> .	<b>380000975</b>	Box with full set of tools to regrind valve seats.
<b>X 380000661</b>	Engine mounting brackets for rotating stand <b>380000301</b> .	<b>380000976</b>	Spring load test appliance.
<b>X 380000663</b>	Tool to extract crankshaft rear seal.	<b>380001003</b>	Complete square to check for connecting rod distortion.
		<b>380001268</b>	Belt tension gauge.
		<b>Injection pump bench test.</b>	
		<b>380000228</b>	Dial gauge (0-5 mm).
		<b>X 380000732</b>	Tool for engine flywheel rotation (use with <b>380000988</b> ).
		<b>X 380000914</b>	Dial-gauge holder tool for rotary injection pump timing (use with <b>380000228</b> ).
		<b>X 380000988</b>	Plate for engine flywheel rotation tool with flywheel timing pin (use with <b>380000732</b> ).



MIF1096A

Engine view

1



MIF1098A

#### Engine lubrication diagram

Forced-circulation lubrication is accomplished by the following components:

- oil pump, housed at the front of the crankcase, driven by the grooved bushing keyed onto the shank of the crankshaft;
- water / oil cooler, housed in the crankcase;
- oil pressure control valve incorporated in the cooler assembly;
- by-pass valve to cut off clogged oil filter, incorporated in the cooler assembly;
- cartridge oil filter.