

T1010, T1030, T1110 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE SYSTEMS	4
SECTION 25 - FWD	12
SECTION 27 - DIFFERENTIAL AND REAR AXLES	14
SECTION 29 - HYDROSTATIC TRANSMISSION	15
SECTION 31 - PTO	18
SECTION 33 - BRAKES	20
SECTION 35 - HYDRAULIC SYSTEM	21
SECTION 41 - POWER STEERING	26
SECTION 44 - WHEELS	28
SECTION 55 - ELECTRICAL SYSTEM	29
SECTION 58 - 230GM MID MOUNT MOWER	38
SECTION 90 - PLATFORM	40

The following pages are the collation of the contents pages from each section and chapter of the T1010, T1030, T1110 Repair manual. Complete Repair part # 87739173.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the T1010, T1030, T1110 Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87739174

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	3
	Personal Safety	3
	Machine Safety	3
	Information	3
	Safety	4
	Precautionary Statements	4
	The Tractor	4
	Servicing the Tractor	4
	Operating the Tractor	5
	Driving the Tractor	5
	Operating the PTO	6
	Diesel Fuel	6
	Safety Frame (ROPS)	6
	Safety Decals	7
	Instruction Decals	10
	Ecology and the Environment	16
	Helpful Hints	16
	Universal Symbols	17
	General Information	18
	Minimum Hardware Tightening Torques	19
	Metric Bolt Torque Specifications	20
	Lubrication and Maintenance	21
	General Information	21
	Grease Fittings	21
	Chains	21
	Lubrication and Maintenance Chart	23
	Lubrication Fittings	24
	Diesel Fuel	24
	Fuel Usage Safety	24

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87739174

Chapter 1 - General Information (Continued)

CONTENTS

Section	Description	Page
	Specifications	25
	Engine	25
	Capacities	25
	Cooling System	26
	Electrical System	26
	Fuel System	26
	Brakes	27
	Steering	27
	Power Take-Off (PTO)	27
	Hydraulic Lift Section	27
	Transmission Speeds	28
	Cast Iron Weights	29
	Drawbars	29
	3-Point Hitch	29
	Tires	29
	Wheel Bolt Torques	29
	ROPS Attaching Bolt Torques	29
	General Dimensions	30
	Wheel Tread Settings	30
	Liquid Ballast (optional)	32
	Tire Pressure	32

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 1 - Engine Systems

CONTENTS

Section	Description	Page
	Specifications	6
	Torque Specifications	15
	Metric Bolt Torque Specifications	15
	Special Tools	16
	General Information - Description of Operation	17
	Identification Chart	17
	Cylinder Head and Valve Train Components	17
	Cylinder Block Assembly	19
	Troubleshooting	20
	Overhaul	26
	Engine Access	26
	Disassembly	26
	Fuel Injector and Glow Plug	29
	Removal	29
	Hydraulic Pump	30
	Removal	30
	Fan, Water Pump and External Oil Tube	30
	Removal	30
	Fuel Shutoff Solenoid	30
	Removal	30
	Oil Pressure Switch	31
	Removal	31
	Temperature Sending Switch and Alternator	31
	Removal	31
	Throttle Cable	31
	Disconnection	31
	Support Frame	32
	Removal	32
	Engine	32
	Removal	32
	Valve Cover	33
	Removal	33

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Rocker Shaft and Push Rod	34
	Removal	34
	Cylinder Head	34
	Removal	34
	Valve Tappet	35
	Removal	35
	Engine Timing Gear Cover, Timing Gears and Camshaft	35
	Timing Gears and Camshaft	36
	Removal	36
	Oil Sump	36
	Removal	36
	Oil Suction Pipe and Strainer	37
	Removal	37
	Connecting Rods, Bearings and Piston	37
	Removal	37
	Flywheel	38
	Removal	38
	Backplate and Oil Seal	38
	Removal	38
	Crankshaft and Main Bearings	38
	Removal	38
	Cylinder Head	39
	Disassembly	39
	Inspection and Repair	39
	Valve Seats	40
	Inspection and Repair	40
	Valves	40
	Inspection and Repair	40
	Valve Guides	42
	Inspection and Repair	42
	Valve Springs	42
	Inspection and Repair	42

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Rocker Arms	43
	Inspection and Replacement	43
	Push Rods	43
	Inspection and Replacement	43
	Cylinder Head	44
	Assembly	44
	Cylinder Block	44
	Inspection and Repair	44
	Pistons	45
	Disassembly and Inspection	45
	Piston Rings	47
	Inspection and Replacement	47
	Connecting Rods	48
	Inspection and Repair	48
	Connecting Rod Bearing Oil Clearance Check	50
	Pistons, Rings and Connecting Rod	50
	Assembly	50
	Main Bearing and Thrust Bearing	51
	Removal and Inspection	51
	Crankshaft	52
	Inspection	52
	Crankshaft Journal Wear Limit and Bearing Usage	52
	Crankshaft Front Main Bearing (Bushing)	53
	Inspection	53
	Replacement	53
	Crankshaft Main Bearing	54
	Assembly	54
	Port Block	54
	Removal	54
	Installation	55
	Timing Gear	55
	Inspection	55

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Camshaft	55
	Disassembly	55
	Inspection	56
	Assembly	56
	Flywheel	57
	Inspection	57
	Timing Gear Housing	57
	Front Oil Seal and Steering Pump Seal	57
	Replacement	57
	Crankshaft and Bearing Holder	58
	Assembly	58
	Rear Oil Seal and Backplate	58
	Assembly	58
	Flywheel	59
	Installation	59
	Piston and Connecting Rod	59
	Installation	59
	Oil Suction Pipe and Suction Strainer	60
	Installation	60
	Oil Sump	60
	Installation	60
	Timing Gear Cover, Timing Gears and Camshaft	60
	Assembly	60
	Head Gasket Selection	62
	Cylinder Head	63
	Assembly	63
	Valve Clearance Adjustment	64
	Valve Cover	64
	Installation	64
	Engine	65
	Installation	65

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Drive Train	66
	Installation	66
	Support Frame	66
	Installation	66
	Tachometer and Throttle Cables	66
	Installation	66
	Alternator and Temperature Sending Switch	67
	Installation	67
	Oil Pressure Switch	67
	Installation	67
	Fuel Shutoff Solenoid	67
	Installation	67
	Fan, Water Pump and External Oil Tube	68
	Installation	68
	Hydraulic Pump	68
	Installation	68
	Glow Plug and Connector	68
	Installation	68
	Fuel Injection Pump	69
	Installation	69
	Fuel Injector	70
	Installation	70
	Fuel Line	70
	Installation	70
	Exhaust Manifold, Air Cleaner and Radiator	71
	Installation	71
	Engine Lubrication System - Description of Operation	74
	Engine Oil Filter	77
	Construction and Function	77
	Maintenance	77

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Oil Pump	77
	Removal	77
	Inspection	77
	Installation and Adjustment	78
	Engine Oil Pressure Check	79
	Oil Pressure Relief Valve	79
	Removal	79
	Installation	79
	Oil Consumption	80
	Cooling System - Description of Operation	81
	Maintenance	83
	Coolant	83
	Thermostat	83
	Water Pump	83
	Cooling Fan	83
	Radiator	83
	Radiator Cap	83
	Cooling System Overhaul	84
	Radiator	84
	Removal	84
	Inspection and Repair	85
	Installation	86
	Water Pump and Thermostat	87
	Removal	87
	Inspection and Repair	89
	Installation	90
	Testing	93
	Compression Test and Tools	93

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 2 - Fuel System

CONTENTS

Section	Description	Page
	Specifications - T1010	2
	Torque Specifications	2
	Special Tools	2
	Specifications - T1030, T1110	3
	Torque Specifications	3
	Special Tools	3
	Fuel System - Description of Operation	4
	Injection Pump - Description of Operation	6
	Pumping Elements	7
	Delivery Valves	9
	Troubleshooting - General	11
	Troubleshooting - Fuel Injectors	14
	Troubleshooting - Governor	15
	Troubleshooting - Engine Breather Valve	16
	Overhaul	17
	Injection Pump	17
	Removal	17
	Repair	17
	Installation	17
	Timing and Governor Adjustments	18
	Using Original Pump and Drive Components	18
	New Pump or Drive Component	18
	Installation	18
	Spill-Timing Procedure	19
	Bleeding the Fuel System	23
	Bleeding Procedure	23
	Full Screw High Idle Adjustment	23
	Governor - Description of Operation	24
	Governor	26
	Disassembly	26
	Assembly	27
	Adjustments	28

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87739174

Chapter 2 - Fuel System (Continued)

CONTENTS

Section	Description	Page
	Injectors - Description of Operation	29
	Injector	30
	Removal	30
	Disassembly	31
	Assembly and Adjustment	31
	Engine Breather Valve	32
	Removal	33
	Installation	33

SECTION 25 - FWD

BOOK 1 - 87739174

Chapter 1 - Front Axle

CONTENTS

Section	Description	Page
	Front Wheel Drive Axle - Description of Operation	3
	FWD Tread Setting	3
	FWD	4
	Manual	4
	Auto	4
	Auto Position (Engaged)	5
	Auto Position (Disengaged)	5
	Full Time FWD (Locked Down)	5
	Power Flow	6
	Front Axle	6
	Overhaul	7
	FWD Axle	7
	Removal	7
	Final Drive Case Cover	9
	Removal	9
	Steering Cylinder	9
	Removal	9
	Final Drive Case	9
	Removal	9
	Idler Case	10
	Removal	10
	Disassembly	10
	Differential	10
	Removal	10
	Drive Pinion	11
	Removal	11
	Differential	11
	Disassembly	11
	Inspection	11
	Assembly	11

SECTION 25 - FWD

BOOK 1 - 87739174

Chapter 1 - Front Axle (Continued)

CONTENTS

Section	Description	Page
	Drive Pinion	12
	Installation	12
	Differential	12
	Installation	12
	Backlash Adjustment	13
	Idler Case	15
	Assembly	15
	Axle Seal Installation	15
	Installation	16
	FWD Box	17
	Removal (Manual and Auto)	17
	Manual FWD Box	17
	Disassembly	17
	Inspection	18
	Assembly	19
	Auto FWD Box	21
	Disassembly	21
	Inspection	22
	Assembly	23
	Two Way Clutch (Sensitrack™)	26
	Disassembly	26
	Inspection	26
	Assembly	27
	Front to Rear Axle Ratio	28
	Specifications	30
	Front Wheel Drive	30

SECTION 27 - DIFFERENTIAL AND REAR AXLES

BOOK 1 - 87739174

Chapter 1 - Differential

CONTENTS

Section	Description	Page
	Specifications	2
	Bolt Torque Specifications	3
	Metric Bolt Torque Specifications	3
	Special Tool	3
	Description of Operation (T1010/T1030)	4
	Description of Operation (T1110)	5
	Differential	6
	Differential Lock	7
	Rear Axle	8
	Overhaul	9
	Differential	9
	Removal	9
	Drive Pinion	12
	Removal	12
	Differential	13
	Disassembly (T1010/T1030)	13
	Differential	14
	Disassembly (T1110)	14
	Inspection	17
	Assembly	17
	Ring Gear and Pinion Gear Pattern Specification and Adjustment	21

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87739175

Chapter 1 - Hydrostatic Transmission

CONTENTS

Section	Description	Page
	Specifications	3
	HST	3
	Metric Bolt Torque Specifications	4
	Special Tools	5
	Description of Operation	6
	HST	6
	Variable Displacement Pump	8
	Operation	8
	Fixed Displacement Motor	9
	Operation	9
	Hydraulic Fluid Flow	10
	Neutral Position	10
	Forward Position	11
	Reverse Position	12
	Range Gear	13
	Operation	13
	Power Flow	14
	High Range	14
	Low Range	14
	Troubleshooting	15
	Pressure Testing	18
	High Pressure Relief Valves	18
	Forward Testing	18
	Reverse Testing	19
	Low (Charge) Pressure Relief Valve	20
	Overhaul	21
	Transmission/Differential	21
	Separating	21
	Attaching	25

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87739175

Chapter 1 - Hydrostatic Transmission (Continued)

CONTENTS

Section	Description	Page
	HST Unit	31
	Removal	31
	Disassembly	32
	Inspection	38
	Assembly	42
	Installation	51
	HST Adjustment	52
	Neutral Adjustment	52
	HST Forward Pedal Travel Adjustment	53
	Cooling Fan	54
	Transmission Range Gears	54
	Removal	54
	Inspection	56
	Installation	57

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87739175

Chapter 2 - Electric Cruise Control (Optional)

CONTENTS

Section	Description	Page
	Description of Operation	2
	HST Cruise Control (optional)	2
	Cruise Control Switch	3
	Description and Location	3
	Removal	3
	Testing	4
	Installation	5

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87739175

Chapter 2 - Electric Cruise Control (Optional) (Continued)

CONTENTS

Section	Description	Page
	Cruise Magnet	5
	Description and Location	5
	Removal	5
	Testing	6
	Installation	6
	Cruise Relays	7
	Description and Location	7
	Removal (all)	9
	Testing	10
	Testing Cruise Latch and Instrument Panel Relays (normally open)	10
	Installation	10
	Testing Cruise Brake Relay (normally closed)	11
	Installation	11
	Relay Installation (all)	11
	Cruise Diode	12
	Description and Location	12
	Removal	12
	Testing	13
	Installation	13
	Cruise Control Circuit "On Position"	14
	Cruise Control Circuit "Denergizing"	15
	Cruise Control Circuit	16
	Ground Circuits	16
	Cruise Control "ON"	16
	Cruise Control Indicator Lights	17
	Denergizing the Cruise Control Circuit	17
	Relay Identification	17
	Troubleshooting - HST Cruise Control Circuit	18

SECTION 31 - PTO

BOOK 2 - 87739175

Chapter 1 - PTO

CONTENTS

Section	Description	Page
	Specifications	3
	Metric Bolt Torque Specifications	4
	Special Tools	5
	Description of Operation	6
	Power Flow	7
	PTO Off	7
	Rear and Mid PTO On	7
	Rear PTO On	8
	Mid PTO On	8
	Troubleshooting	9
	Overhaul	10
	PTO Clutch	10
	Removal	10
	Disassembly	11
	Inspection	15
	Assembly	16
	Installation	20
	PTO Clutch Shaft	21
	Removal	21
	PTO Change Lever	21
	Removal	21
	Rear Case Cover	22
	Removal	22
	Disassembly	22
	PTO Shift Rod and Input Shaft	24
	Removal	24
	Mid PTO Shaft and Gears	27
	Removal	27
	Inspection	28
	Mid PTO Shaft and Gears	29
	Installation	29

SECTION 31 - PTO

BOOK 2 - 87739175

Chapter 1 - PTO (Continued)

CONTENTS

Section	Description	Page
	PTO Shift Rod and Input Shaft	31
	Installation	31
	Rear Case Cover	34
	Assembly	34
	Installation	35
	PTO Clutch Shaft	36
	Installation	36
	PTO Change Lever	36
	Installation	36
	PTO Clutch Brake	37
	Adjustment	37
	PTO Clutch Brake Release	38
	Adjustment	38

SECTION 33 - BRAKES

BOOK 2 - 87739175

Chapter 1 - Brakes

CONTENTS

Section	Description	Page
	Specifications	2
	Metric Bolt Torque Specifications	3
	Description of Operation	4
	Brakes	5
	Park Brake	7
	Troubleshooting	8
	Overhaul	9
	Brakes	9
	Removal	9
	Disassembly	9
	Inspection	11
	Assembly	12
	Installation	14
	Adjustments	15
	Brake	15
	Park Brake	16

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 87739175

Chapter 1 - Hydraulics

CONTENTS

Section	Description	Page
	Specifications (T1010, T1030)	6
	Specifications (T1110)	7
	Metric Bolt Torque Specifications	8
	Special Tools	9
	Description and Operation - Hydraulic System Circuits	10
	Oil Filter	12
	Control Valve Assembly (HPL) (T1010 and T1030)	12
	Flow Priority Valve	13
	Relief Valve	13
	Check Valves	13
	Safety Valve	13
	Detent Balls	13
	Oil Flow (T1010 and T1030)	14
	Neutral Position	14
	Lifting Position	15
	Lowering Position	16
	Drop Rate Control Valve (T1010 and T1030)	17
	Troubleshooting (T1010 and T1030)	18
	Control Valve Assembly (HPL) (T1110)	19
	Flow Priority Valve	19
	Relief Valve	19
	Check Valve	19
	Safety Valve	20
	Unload Valve	20
	Lowering Valve	20
	Oil Flow (T1110)	21
	Neutral Position	21
	Lifting Position	22
	Lowering Position	23
	Drop Rate Control Valve (T1110)	24
	Troubleshooting (T1110)	25
	Overhaul - Lift Cylinder	26
	Removal	26

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 87739175

Chapter 1 - Hydraulics (Continued)

CONTENTS

Section	Description	Page
	Lift Cylinder	30
	Disassembly	30
	Inspection and Repair	31
	Assembly	32
	Drop Rate Control Valve	33
	Disassembly	33
	Inspection	33
	Assembly	33
	Control Valve (T1010 and T1030)	34
	Disassembly	34
	Inspection	34
	Lift Check Valve	35
	Disassembly	35
	Inspection	35
	Assembly	35
	Safety Valve	36
	Disassembly	36
	Inspection	36
	Assembly	36
	Relief Valve	37
	Disassembly	37
	Inspection	37
	Assembly	37
	Spool	38
	Disassembly	38
	Inspection	38
	Assembly	39
	Flow Priority Valve	40
	Disassembly	40
	Inspection	40
	Assembly	40
	Control Valve	41
	Assembly	41

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 87739175

Chapter 1 - Hydraulics (Continued)

CONTENTS

Section	Description	Page
	Control Valve (T1110)	42
	Disassembly	42
	Inspection	44
	Lift Check Valve	45
	Inspection	45
	Assembly	45
	Safety Valve	45
	Inspection	45
	Assembly	45
	Relief Valve	46
	Inspection	46
	Assembly	46
	Flow Priority Valve	47
	Inspection	47
	Assembly	47
	Lowering Valve	47
	Assembly	47
	Check Valve	48
	Assembly	48
	Unload Valve	48
	Assembly	48
	Spool	48
	Disassembly	48
	Inspection	49
	Assembly	49
	Control Valve	50
	Installation	50
	Lift Cover	51
	Installation	51
	Adjustment	54
	Hydraulic System Circuit (T1010, T1030)	54
	Feedback Plate Adjustment	54

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 87739175

Chapter 1 - Hydraulics (Continued)

CONTENTS

Section	Description	Page
	Hydraulic Control Lever Preload	55
	Adjustment (T1110)	55
	HPL Linkage Adjustments (T1110)	55
	Adjustment Procedure	56
	Description and Operation - Hydraulic Pump and Filter	57
	Disassembly	58
	Inspection and Repair	58
	Assembly	59
	Installation	60
	Break-in Procedure	60
	Overhaul - Hydraulic Pump (All Models)	61
	Removal	61
	Description and Operation - Remote Control Valves	61
	Single-Spool Control Valve	62
	Double-Spool Control Valve	63
	Single-Spool Remote Control Valve - Oil Flow	65
	Neutral Position	65
	Raising Position	66
	Lowering Position	67
	Two Spool Remote Control Valve - Oil Flow	68
	Bucket and Lift Control - Neutral Position	68
	Bucket Cylinder - Dumping	69
	Bucket Cylinder - Rollback	70
	Lift Cylinder - Raising	71
	Lift Cylinder - Lowering	72
	Lift Cylinder - Float Position	73
	Hydraulic Fluid Flow With 2-Spool Valve (T1010, T1030)	74
	Hydraulic Fluid Flow With Remote Valve (T1010, T1030)	74
	Hydraulic Fluid Flow With Remote Valve and 2-Spool Valve Combination (T1010, T1030)	75
	Hydraulic Fluid Flow With 2-Spool Valve (T1110)	75
	Hydraulic Fluid Flow With Remote Valve (T1110)	76
	Hydraulic Fluid Flow With Remote Valve and 2-Spool Valve Combination (T1110) ..	76

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 87739175

Chapter 1 - Hydraulics (Continued)

CONTENTS

Section	Description	Page
	Troubleshooting - Front and Rear Remote Valves	77
	Overhaul - Remote Control Valve	78
	Removal	78
	Single-Spool Valve (Rear Remote Valve)	79
	Disassembly	79
	Inspection	79
	Assembly	80
	Installation	81
	Two Spool Remote Valve (Front Remote Valve)	82
	Removal	83
	Front Remote Valve	84
	Disassembly	84
	Inspection	84
	Assembly	86
	Installation	88
	Description and Operation - Mower Lift Linkage (T1010, T1030)	89
	Adjustment (T1010, T1030)	92
	Mower Deck Height	92
	Description and Operation - Mower Lift Linkage (T1110)	93
	Mower Deck Lifting Position (Adjustment) (T1110)	95
	Inspection	95
	Adjustment	95
	Lowering Position Adjustment (T1110)	95
	Pressure Testing	96
	Main System Relief Valve (T1010, T1030)	96
	Main System Relief Valve (T1110)	97
	Pressure Testing	97
	Pump Efficiency	99

SECTION 41 - POWER STEERING

BOOK 2 - 87739175

Chapter 1 - Power Steering

CONTENTS

Section	Description	Page
	Description of Operation	3
	Power Steering Control Valve	6
	Spool and Sleeve	6
	Drive Shaft	7
	Gerotor Pump	7
	Check Valve	7
	Relief Valve	7
	Hydraulic Pump	9
	Power Steering Cylinder	9
	Power Steering Operation	10
	Fluid Flow - Neutral Position	10
	Fluid Flow - Left Turn	11
	Fluid Flow - Right Turn	12
	Manual Operation	13
	Overhaul	14
	Steering Control Valve	14
	Removal	14
	Disassembly	15
	Inspection	18
	Assembly	19
	Installation	24
	Control Valve Assembly (HPL)	26
	Flow Priority Valve	26
	Disassembly	26
	Inspection	26
	Assembly	26
	Steering Cylinder	27
	Removal	27
	Disassembly	28
	Inspection	29
	Assembly	29
	Installation	30

SECTION 41 - POWER STEERING

BOOK 2 - 87739175

Chapter 1 - Power Steering (Continued)

CONTENTS

Section	Description	Page
	Troubleshooting	31
	Hydraulic Pump	31
	Power Steering Tubes	31
	Troubleshooting Chart	32
	Pressure Testing	33
	Pump, Steering Valve and Relief Valve	33
	Testing	33
	Test Results	33
	Steering Cylinder	34
	Testing	34
	Test Results	34
	Steering Control Relief Valve	34
	Adjustment	34
	Priority Flow Valve	37
	Testing	37
	Specifications	39
	Special Tools	39

SECTION 44 - WHEELS

BOOK 3 - 87739176

Chapter 1 - Wheels

CONTENTS

Section	Description	Page
	Wheel Tread Settings	2
	Front Wheel Settings	2
	Rear Wheel Settings	2
	Tractor Weighting	3
	Weighting for Stability	3
	Weighting Limitations	3
	Cast Iron Weights (optional)	4
	Front End Weights	4
	Rear Wheel Weights	4
	Liquid Ballast (optional) (T1010/T1030)	5
	Tire Pressure	5
	Liquid Ballast (optional) (T1110)	6
	Tire Pressure	6

SECTION 55 - ELECTRICAL SYSTEM

BOOK 3 - 87739176

Chapter 1 - Electrical System

CONTENTS

Section	Description	Page
	Electrical Component Location and Function	5
	Component Locations and Functions	6
	Ground Locations	8
	Description of Operation - Electrical System Components	9
	Battery	9
	Checking the Battery Electrolyte Level	10
	Removal	10
	Installation	10
	Main Fuse (40 Amp)	11
	Replacement	11
	Fuse Block	11
	Key Switch	12
	Removal	13
	Troubleshooting - Continuity Test	14
	Troubleshooting - Connector Wiring	15
	Installation	16
	Light Switch	16
	Removal	16
	Testing	17
	Installation	17
	Headlights	18
	Replacement	18
	Taillights	18
	Removal	18
	Inspection	19
	Installation	19
	Hazard Flasher / Turn Signal / Horn Switch	19
	Removal	20
	Testing	20
	Installation	21

SECTION 55 - ELECTRICAL SYSTEM

BOOK 3 - 87739176

Chapter 1 - Electrical System (Continued)

CONTENTS

Section	Description	Page
	Hazard/Turn Signal Lights	22
	Removal	22
	Inspection	22
	Installation	22
	Horn	23
	Inspection	23
	Safety Switches	23
	Transmission Range Safety Switch	23
	Removal	23
	Testing	24
	Installation	24
	Seat Safety Switch	24
	Removal	24
	Testing	25
	Switch Plunger Retracted (In)	25
	Switch Plunger Extended (Out)	25
	Installation	25
	Park Brake Safety Switch	26
	Removal	26
	Testing	26
	Installation	27
	Adjustment	27
	HST Cruise Brake Release Switch (Optional)	27
	Removal	28
	Testing	28
	Installation	28
	Adjustment	28
	PTO Position Safety Switch	29
	Removal	29
	Inspection	29
	Adjustment	29