

# INDEX

## 745, 745H WHEEL LOADERS

## SERVICE MANUAL SET

## FORM NO. 73058628


<b>Service manual set is arranged in the following order</b>	<b>Individual manuals are also available in translation in form numbers listed below</b>
--	--

Service Manuals	English Form No.	Español (Spanish)	Français (French)	Portugues (Portuguese)
Engine.....	70645121	73112593	70690759	70650411
Turbocharger.....	70677064	70678570	70678727	70679482
Transmission & Converter..	73050386	73052632		73052633
Axle.....	76053547	73061828	73061841	73051866
Brakes.....	73067178	73061838	73061851	73052638
Power Steering System.....	73055601	73061839	73061852	73100554
Hydraulic System.....	73124400	73061829	73061842	73052636
Bucket & Chassis.....	73055458	73061830	73061843	73054308
Electrical System (Used Prior To Serial #1717	73155403	73053922	73061853	73054307
Electrical System (Serial #1717 and Up and 96M02050 and 87L02050)	73056512			

The following additional Service Manuals, in English, are not included in the Manual Set, but may be ordered from a Fiatallis representative:

Injection Nozzles & Holders.....	70682797
Injection Pump, Roosa Master.....	73111954 (Prior to S/N 96M02452, 87L02452)
Injection Pump, Robert Bosch.....	73112989 (Effective with S/N 96M02452 – Up, 87L02452 – Up)

Cut along the dotted lines and insert in spine of binder



**FIATALLIS**

Sample of manual. Download All 808 pages at:

<https://www.arepairmanual.com/downloads/fiatallis-745-745h-wheel-loader-service-repair-manual/>

**INDEX CARD 75124923**

Product: Fiatallis 745/745H Wheel Loader Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/fiatallis-745-745h-wheel-loader-service-repair-manual/>

Sample of manual. Download All 808 pages at:

<https://www.arepairmanual.com/downloads/fiatallis-745-745h-wheel-loader-service-repair-manual/>



**10000  
11000  
11000 MKII  
685T  
ENGINES  
service manual**

## AVOID ACCIDENTS

Most accidents, whether they occur in industry, on the farm, at home or on the highway, are caused by the failure of some individual to follow simple and fundamental safety rules or precautions. For this reason MOST ACCIDENTS CAN BE PREVENTED by recognizing the real cause and doing something about it before the accident occurs.

Regardless of the care used in the design and construction of any type of equipment there are conditions that cannot be completely safeguarded against without interfering with reasonable accessibility and efficient operation.

A careful operator is the best insurance against an accident.  
The complete observance of one simple rule would prevent many thousand serious injuries each year.  
That rule is:

*Never attempt to clean, oil or adjust a machine while it is in motion.*

## WARNING

On machines having hydraulically, mechanically, and/or cable controlled equipment (such as shovels, loaders, dozers, scrapers, etc.) be certain the equipment is lowered to the ground before servicing, adjusting and/or repairing. If it is necessary to have the hydraulically, mechanically, and/or cable controlled equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the hydraulic lift cylinders, cable and/or mechanical devices used for controlling the equipment.

## COPYRIGHT BY FIATALLIS



All rights reserved. Reproduction of text and illustrations  
in whole or in part, is strictly prohibited.

---

# 10000 11000 11000 MKII 685T

## service manual

## ENGINES

FORM 70645121 English



### WARNING

STUDY THE OPERATION AND MAINTENANCE  
INSTRUCTION MANUAL THROUGH BEFORE STARTING,  
OPERATING, MAINTAINING, FUELING OR SERVICING  
THIS MACHINE.



The Operation and Maintenance Instruction Manual provides the instructions and procedures for starting, operating, maintaining, fueling, shutdown and servicing that are necessary for properly conducting the procedures for overhaul of the related components outlined in this Service Manual.



This symbol is your safety alert sign. It MEANS ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED.



Read and heed all safety instructions carrying the signal words WARNING and DANGER.



Machine mounted safety signs have been color coded yellow with black borders and lettering for warning and red with white borders and lettering for danger points.





SUPPLEMENT NO. 6  
SERVICE MANUAL FORM 70645121  
10000, 11000, 11000 MKII, 685T ENGINES

( 5-80 )

ATTENTION: Insert this sheet in the front of publication as record of receipt. Replace or add pages in the publication according to instructions below.

Additional copies of this supplement are available. Please direct your request to:

*Fiat-Allis Construction Machinery, Inc., Publications Services Dept.,  
3000 South 6th Street, Springfield, Illinois 62710 U.S.A.*

or

*Fiat-Allis M.M.T. S.p.A. - MAGAZZINO STAMPATI - Viale Torino, 0  
STUPINIGI (Torino) - Italy*

Replace the following pages

5-1	Revised	14-1	Revised	18-11	No change
5-2	No change	14-2	No change	18-12	Revised
5-3	Revised	14-3	Revised	18-13	Revised
5-4	No change	14-3A	Added	18-14	No change
5-4A	Revised	14-3B	Added	18-15	Revised
Blank		14-4	No change	18-16	No change
5A-1	Revised	18-2	These changes are included in this copy	18-17	No change
5A-2	No change	18-3	change	18-18	Revised
5A-9	Revised	18-4	revised	18-19	No change
5A-10	Revised	18-5	No change	18-20	Revised
5A-11	Added	18-6	Revised	20-1	Revised
Blank		18-7	Revised	20-2	Revised
13-3	Revised	18-8	No change		
13-4	No change	18-9	Revised		

**NOTICE**

These changes are included in this copy

Reason: Update and revise service tools and procedures.



## SUPPLEMENT NO. 5

### SERVICE MANUAL FORM 70645121

10000, 11000, 11000 MK II ENGINES

( 4-79 )

ATTENTION: Insert this sheet in the front of publication as record of receipt. Replace or add pages in the publication according to instructions below.

Additional copies of this supplement are available. Please direct your request to:  
*Fiat-Allis Construction Machinery, Inc., Publications Services Dept.,  
3000 South 6th Street, Springfield, Illinois 62710 U. S. A.*

Write in the following changes:

Section 4, Pg. 7

#### C. FUEL INJECTION NOZZLE-HOLDER SERVICE

The fuel injection nozzle-holder assemblies should be removed after approximately every 2000 hours of operation, tested and adjusted if necessary. The nozzle-holder assembly when properly adjusted should require an opening pressure of (refer to FUEL INJ. NOZZLE ASSEMBLIES S.M. 70682797).

When adjusting "popping" pressure of a new nozzle-holder or a rebuilt nozzle-holder in which a new

#### NOTICE

THESE CHANGES ARE INCLUDED IN THIS COPY

Section 4, Pg. 8

1. Using a nozzle tester similar to the one shown in Fig. 10, operate tester handle a few quick strokes and observe "popping" pressure of fuel injection nozzle-holder as indicated by pressure gauge of the nozzle tester. For specified pressure, refer to FUEL INJ. NOZZLE ASSEMBLIES S.M. 70682797.

#### NOTE

Reason: Fuel injection nozzle pressure changes.



SUPPLEMENT NO. 4  
SERVICE MANUAL FORM 70645121  
10000, 11000, 11000 MKII ENGINES

( 5-78 )

ATTENTION: Insert this sheet in the front of publication as record of receipt. Replace or add pages in the publication according to instructions below.

Additional copies of this supplement are available. Please direct your request to:  
Fiat-Allis Construction Machinery, Inc., Publications Service Dept.,  
3000 South 6th Street, Springfield, Illinois 62710 U. S. A.

Reason: This supplement updates manual to cover the 11000 MKII engine.

Replace or add the following like pages:

1-1 (No change)	5-1 (Revised)	5-15 (Added)	11-6E (Added)
1-2 (Revised)	5-2 (Revised)	5-16 (Added)	
2-2A (Added)	5-4A (Added)	1 (Revised)	13-1 (Revised)
		(Revised)	13-2 (No change)
2-23 (Revised)	5-7 (Revised)	1-6A (Added)	15-3 (Revised)
2-24 (Revised)	5-8 (No change)	11-6B (Added)	15-4 (No change)
2-25 (Revised)	5-13 (No change)	11-6C (Added)	Section 18: Entire
2-26 (Revised)	5-14 (No change)	11-6D (Added)	section revised.
2-27 (Revised)			20-1 (Revised)
2-28 (Revised)			20-2 (Revised)

Write in the following changes (changes are underlined):

Page 2-2

TOPIC 1

Add new sentence before first paragraph:  
Refer to FIG. 1A.

4-12

Paragraph H. 2

Add new first sentence to paragraph:  
Coat nozzle-holder threads with anti-seize compound.

4-12

Paragraph H. 2

Change "Position a new rubber dust shield ..." to "Position two new rubber dust shields..."

(continued)

8-3	Legend for FIG. 1	Add to item 8: <u>(One piece gasket effective with engine serial number 11-25689).</u>
8-5	Paragraph A. 6 NOTE	Add to item 16 ... <u>or rotator.</u>
8-6	Paragraph B. 2	Add to item 32: <u>(Used prior to engine serial number 11-25689).</u>
8-8	Paragraph B. 5	Change "cams" to " <u>arms.</u> "
8-9	Legend for FIG. 10	Change "... 19-22 lbs. ft." to "... <u>10-35 lb-ft (1.4-4.8 kg-m) for stud nuts and 14-45 lb-ft (1.9-6.2 kg-m) for place bolts.</u> "
10-4	Paragraph C. 3	Change first sentence to read: <u>Tighten 1/2 in. nuts to 100 lb-ft (13.8 kg-m), 1/2 in. cap-screws to 115 lb-ft (15.9 kg-m) and 5/8 in. nuts or capscrews to 185 lb-ft (25.6 kg-m).</u>
10-4A	Paragraph i.	Add to item 4: <u>(Not necessary with one piece gasket).</u>
11-3	Legend for FIG. 2 (cont.)	Change "45-50 lb-ft" to " <u>70 lb-ft (9.7 kg-m).</u> "
11-5	FIG. 5, Title	Add: <u>If flywheel is fastened by socket head capscrews, tighten to 135 lb-ft (18.7 kg-m).</u>
11-10	Paragraph B. 6	Omit: Legend for FIG. 2 (continued), items 25 through 28.
12-4	Paragraph 9	Change next to last sentence to read: <u>"... tighten nut to 125-135 lb-ft (17.3 - 18.7 kg-m)."</u>
13-3	Paragraph E. 1	Add new sentence and change first sentence: <u>Apply sealant to camshaft bore plug. Install a new plug in camshaft hole ... .</u>
		Replace piston ring end gap dimensions with the following new data:
		Top Ring: First Type Pistons 0.013-0.033 in (0.33-0.84 mm) Second Type Pistons 0.013-0.028 in (0.33-0.71 mm)
		2nd and 3rd rings 0.013-0.33 in (0.33-0.84 mm)
		4th ring 0.008-0.028 in (0.20 0.71 mm)

(continued)

13-4                    **Paragraph E. 2**                    Replace piston ring-to-groove clearance dimensions with the following new data:  
Top ring                0.004-0.007 in (0.10-0.18 mm)  
2nd and 3rd rings    0.003-0.005 in (0.08-0.13 mm)  
4th ring                0.0015-0.004 in (0.04-0.10 mm)

13-6                    **TOPIC 2**                    Add to paragraph 4: On current engines with twelve-point capscrews instead of nuts, tighten capscrews to 160 lb-ft (22.1 kg-m) (217 Nm).

14-3                    **Legend FIG. 1**                    Add to item 3: (Used prior to engine serial number 11-19386).

14-4                    **Paragraph 6**                    Add: On current engines with twelve-point capscrews instead of nuts, tighten capscrews to 160 lb-ft (22.1 kg-m) (217 Nm).

15-5                    **Section 4, right-hand column, third paragraph.**                    Change second sentence to read:  
If this lubricant is not available, use liquid edible vegetable oil.  
Delete sub-paragraphs a. and b.

**SUPPLEMENT NO.3**  
**SERVICE MANUAL FORM 0645121-5 (7-66)**  
**10000 -11000 ENGINES**  
**CONSTRUCTION MACHINERY DIVISION**

(10-71)

**ATTENTION:** Insert this sheet into the front of publication as record of receipt. Replace or add pages in the publication according to instructions below.

**Replace** the following like pages:

Index Pg. 3 (Revised)

Sect. 1 Pg. 1 (No change)  
Sect. 1 Pg. 2 (Revised)

Sect. 2 Pg. 1 (Revised)  
Sect. 2 Pg. 2 (No change)

Sect. 2 Pg. 11 (No change)  
Sect. 2 Pg. 12 (Revised)

Sect. 2 Pg. 27 (Revised)  
Sect. 2 Pg. 28 (Revised)

Sect. 3 Pg. 1 (Revised)  
Sect. 3 Pg. 2 (No change)

Sect. 3 Pg. 3 (No change)  
Sect. 3 Pg. 4 (Revised)

Sect. 3 Pg. 4a (Added)

Sect. 5A Pg. 1 (Added)  
Sect. 5A Pg. 2 (Added)

Sect. 5A Pg. 3 (Added)  
Sect. 5A Pg. 4 (Added)

Sect. 5A Pg. 5 (Added)  
Sect. 5A Pg. 6 (Added)

**NOTICE**  
THESE CHANGES ARE  
INCLUDED IN THIS COPY

Sect. 5A Pg. 7 (Added)  
Sect. 5A Pg. 8 (Added)

Sect. 5A Pg. 9 (Added)  
Sect. 5A Pg. 10 (Added)

Sect. 8 Pg. 11 (No change)  
Sect. 8 Pg. 12 (Revised)

Sect. 8 Pg. 13 (Revised)  
Sect. 8 Pg. 14 (Revised)

Sect. 10 Pg. 3 (Revised)  
Sect. 10 Pg. 4 (Revised)

Sect. 10 Pg. 4a (Added)

Sect. 13 Pg. 1 (Revised)  
Sect. 13 Pg. 2 (Revised)

Sect. 13 Pg. 3 (Revised)  
Sect. 13 Pg. 4 (Revised)

Sect. 13 Pg. 5 (Revised)  
Sect. 13 Pg. 6 (Revised)

Sect. 13 Pg. 7 (Added)

Sect. 15 Pg. 5 (Revised)  
Sect. 15 Pg. 6 (Revised)

**Reason:** This supplement adds the Bosch (Germany) injection pump data and other miscellaneous changes.



## NOTICE OF CHANGE

TO

SERVICE MANUAL 645121 (7-66)

10000 11000

ENGINES

CONSTRUCTION MACHINERY DIVISION

**Write** in the following changes:

Section 2, Page 16

Legend for Fig. 11c

Add: 33. Spider Kit

**Replace** the following like pages:

Section 1 Pg. 1 (No change)  
Section 1 Pg. 2 (Revised)

Section 4 Pg. 7 (Revised)  
Section 4 Pg. 8 (Revised)

Section 10 Pg. 3 (Revised)  
Section 10 Pg. 4 (No change)

Section 2 Pg. 3 (No change)  
Section 2 Pg. 4 (Revised)

Section 5 Pg. 7 (No change)  
Section 5 Pg. 8 (Revised)

Section 14 Pg. 1 (No change)  
Section 14 Pg. 2 (Revised)

Section 2 Pg. 13 (Revised)  
Section 2 Pg. 14 (Revised)

Section 8 Pg. 3 (No change)  
Section 8 Pg. 4 (Revised)

Section 14 Pg. 7 (Revised)  
Section 14 Pg. 8 (No change)

Section 2 Pg. 21 (Revised)  
Section 2 Pg. 22 (No change)

Section 8 Pg. 5 (Revised)  
Section 8 Pg. 6 (No change)

Section 15 Pg. 5 (Revised)  
Section 15 Pg. 6 (No change)

Section 2 Pg. 23 (Revised)  
Section 2 Pg. 24 (Revised)

Section 8 Pg. 13 (No change)  
Section 8 Pg. 14 (Revised)

Section 18 Pg. 5 (Revised)  
Section 18 Pg. 6 (Revised)

Section 2 Pg. 25 (Revised)  
Section 2 Pg. 26 (Revised)

Section 8 Pg. 15 (No change)  
Section 8 Pg. 16 (Revised)

Section 18 Pg. 7 (Revised)  
Section 18 Pg. 8 (Revised)

Section 3 Pg. 1 (Revised)  
Section 3 Pg. 2 (No change)

Section 9 Pg. 1 (Revised)  
Section 9 Pg. 2 (No change)

**Reason:** This mailing provides latest information on 10000 & 11000 engines.

INSERT THIS SHEET INTO THE FRONT OF MANUAL 0645121 (7-66) TO INDICATE RECEIPT OF THIS MAILING.

Additional copies of this mailing are available. Please direct your order to the Technical Publications Department, Springfield Plant.

**NOTICE**  
THESE CHANGES ARE  
INCLUDED IN THIS COPY

REPLACEMENT PAGES FOR

645121 (7-66)

SERVICE MANUAL

Mailing No. 1

10000 11000

ENGINES

CONSTRUCTION MACHINERY DIVISION

The following replace like pages:

Sect. 1 Pg. 1 (Revised)  
Sect. 1 Pg. 2 (Revised)

Sect. 2 Pg. 1 (Revised)  
Sect. 2 Pg. 2 (Revised)

Sect. 2 Pg. 3 (Revised)  
Sect. 2 Pg. 4 (Revised)

Sect. 2 Pg. 5 (Revised)  
Sect. 2 Pg. 6 (Revised)

Sect. 2 Pg. 7 (Revised)  
Sect. 2 Pg. 8 (Revised)

Sect. 2 Pg. 9 (Revised)  
Sect. 2 Pg. 10 (Revised)

Sect. 2 Pg. 11 (Revised)  
Sect. 2 Pg. 12 (Revised)

Sect. 2 Pg. 13 (Revised)  
Sect. 2 Pg. 14 (Revised)

Sect. 2 Pg. 15 (Revised)  
Sect. 2 Pg. 16 (Revised)

Sect. 2 Pg. 17 (Revised)  
Sect. 2 Pg. 18 (Revised)

Sect. 2 Pg. 19 (Revised)  
Sect. 2 Pg. 20 (Revised)

Sect. 2 Pg. 21 (Revised)  
Sect. 2 Pg. 22 (Revised)

Sect. 2 Pg. 23 (Added)  
Sect. 2 Pg. 24 (Added)

Sect. 2 Pg. 25 (Added)  
Sect. 2 Pg. 26 (Added)

Sect. 2 Pg. 27 (Added)  
Sect. 2 Pg. 28 (Added)

Sect. 5 Pg. 1 (Revised)  
Sect. 5 Pg. 2 (No change)

Sect. 5 Pg. 5 (No change)  
Sect. 5 Pg. 6 (Revised)

Sect. 5 Pg. 7 (Revised)  
Sect. 5 Pg. 8 (Revised)

Sect. 5 Pg. 9 (Revised)  
Sect. 5 Pg. 10 (Revised)

Sect. 5 Pg. 11 (Added)  
Sect. 5 Pg. 12 (Added)

Sect. 8 Pg. 1 (No change)  
Sect. 8 Pg. 2 (Revised)

Sect. 11 Pg. 1 (No change)  
Sect. 11 Pg. 2 (Revised)

INSERT THIS SHEET INTO THE FRONT OF MANUAL 645121 (7-66) TO INDICATE RECEIPT OF THIS MAILING. Additional copies of this mailing are available. Please direct your order to Parts Order Department.

This mailing incorporates recent engine changes.

## SAFETY RULES

### GENERAL

Study the Operation and Maintenance Instruction Manual before starting, operating, maintaining, fueling, or servicing machine.

Read and heed all machine-mounted safety signs before starting, operating, maintaining, fueling or servicing machine.

Machine-mounted safety signs have been color coded yellow with black border and lettering for **WARNING** and red with white border and lettering for **DANGER** points.

Never attempt to operate the machine or its tools from any position other than seated in the operator's seat. Keep head, body, limbs, hands and feet inside operator's compartment at all times to reduce exposure to hazards outside the operator's compartment.

Do not allow unauthorized personnel to operate service or maintain this machine.

Always check work area for dangerous features. The following are examples of dangerous work areas: slopes, overhangs, timber, demolitions, fire, high walls, drop off, back fills, rough terrain, ditches, ridges, excavations, heavy traffic, crowded parking, crowded maintenance and closed areas. Use extreme care when in areas such as these.

An operator must know the machine's capabilities. When working on slopes or near drop offs be alert to avoid loose or soft conditions that could cause sudden tipping or loss of control.

Do not jump on or off machine. Keep two hands and one foot, or two feet and one hand, in contact with steps grab rails and handles at all times.

Do not use controls or hoses as hand holds when climbing on or off machine. Hoses and controls are movable and do not provide a solid support. Controls also may be inadvertently moved causing accidental machine or equipment movement.

Keep operator's compartment, stepping points, grab-rails and handles clear of foreign objects, oil, grease, mud or snow accumulation to minimize the danger of slipping or stumbling. Clean mud or grease from shoes before attempting to mount or operate the machine.

Be careful of slippery conditions on stepping points, hand rails, and on the ground. Wear safety boots or shoes that have a high slip resistant sole material.

For your personal protection. Do not attempt to climb on or off machine while machine is in motion.

Never leave the machine unattended with the engine running.

Always lock up machine when leaving it unattended. Return keys to authorized security. Heed all shut down procedures of the Operation and Maintenance Instruction Manual. Always set the parking brake when leaving the machine for any reason.

Do not wear rings, wrist watches, jewelry, loose or hanging apparel, such as ties, torn clothing, scarves, unbuttoned or unzipped jackets that can catch on moving parts. Wear proper safety equipment as authorized for the job. Examples: hard hats, safety shoes, heavy gloves, ear protectors, safety glasses or goggles, reflector vests, or respirators. Consult your employer for specific safety equipment requirements.

Do not carry loose objects in pockets that might fall unnoticed into open compartments. Do not use machine to carry loose objects by means other than attachments for carrying such objects.

**DO NOT CARRY RIDERS** unless the machine is equipped for carrying people to reduce personal exposure to being thrown off.

Do not operate machinery in a condition of extreme fatigue or illness. Be especially careful towards the end of the shift.

Roll Over Protective Structures are required on wheel loaders, dozer tractors, track type loaders, graders and scrapers by local or national requirements. **DO NOT** operate this machine without a Roll Over Protective Structure.

Do not operate a machine without a falling object protective structure (FOPS).

Do not operate this machine without a rear canopy screen when machine is equipped with rear mounted towing winch.

Seat belts are required to be provided with roll over protective structures or roll protection cabs by local or national regulations. Keep the safety belt fastened around you during operation.

Where noise exposure exceeds 90 dBA for 8 hours, wear authorized ear protective equipment per local or national requirements that apply.

Keep clutches and brakes on machine and attachments such as power control units, winches and master clutches adjusted according to Operation and Maintenance Instruction Manuals of the manufacturers at all times. **DO NOT** adjust machine with engine running except as specified.

Do not operate a machine with brakes out of adjustment. See the Operation and Maintenance Instruction Manual.

Move carefully when under, in or near machine or implements. Wear required protective equipment, such as hard hat, safety glasses, safety shoes, ear protectors.

To move a disabled machine, use a trailer or low boy truck if available. If towing is necessary, provide warning signals as required by local rules and regulations and follow Operation and Maintenance Instruction Manual recommendations. Load and unload on a level area that gives full support to the trailer wheels. Use ramps of adequate strength, low angle and proper height. Keep trailer bed clean of clay, oil and all materials that become slippery. Tie machine down securely to truck or trailer bed and block tracks (or wheels) as required by the carrier.

## SAFETY RULES

To prevent entrapment in cabs or mounted enclosures, observe and know the mechanics of alternate exit routes.

On machines equipped with suction radiator fans, be sure to periodically check all engine exhaust parts for leaks as exhaust gases are dangerous to the operator. Keep a vent open to outside air at all times when operating within a closed cab.

**STARTING FLUID IS FLAMMABLE.** Follow the recommendations as outlined in the Operation and Maintenance Instruction Manual and as marked on the containers. Store containers in cool, well-ventilated place secure from unauthorized personnel. **DO NOT PUNCTURE OR BURN CONTAINERS.**

Follow the recommendations of the manufacturer for storage and disposal.

Wire rope develops steel slivers. Use authorized protective equipment such as heavy gloves, safety glasses when handling.

### OPERATION

Before starting machine, check, adjust and lock the operator's seat for maximum comfort and control of the machine.

**DO NOT START OR OPERATE AN UNSAFE MACHINE.** Before working the machine, be sure that any unsafe condition has been satisfactorily remedied. Check brakes, steering and attachment controls before moving. Advise the proper maintenance authority of any malfunctioning part or system. Be sure all protective guards or panels are in place, and all safety devices provided are in place and in good operating condition.

Check instruments at start-up and frequently during operation.

Do not run the engine of this machine in closed areas without proper ventilation to remove deadly exhaust gases.

Be sure exposed personnel in the area of operation are clear of the machine before moving the machine or its attachments. **WALK COMPLETELY AROUND** the machine before mounting. Sound horn. Obey flag man, safety signals and signs.

Know the principles of cross steering of crawler tractors. Read section in Operation and Maintenance Instruction Manual on cross steering.

Keep engine exhaust system and exhaust manifolds clear of combustible material. Equip machine with screens and guards when working under conditions of flying combustible material.

If engine has a tendency to stall for any reason under load or idle, report this for adjustment to a proper maintenance authority immediately. Do not continue to operate machine until condition has been corrected.

Never use bucket as a man-lift.

Use recommended bucket for machine and material load ability and heaping characteristics of material, terrain, and other pertinent job conditions.

Avoid abrupt starts and stops when transporting a loaded bucket.

Inspect your seat belt webbing and hardware at least twice a year for signs of fraying, wear or other weakness that could lead to failure.

Use only designated towing or pulling attachment points. Use care in making attachment. Be sure pins and locks as provided are secure before pulling. Stay clear of draw bars, cables or chains under load.

When pulling or towing through a cable or chain, do not start suddenly at full throttle. Take up slack carefully. Guard against kinking chains or cables. Inspect carefully for flaws before using. Do not pull through a kinked chain or cable due to the high stresses and possibility of failure of the kinked area. Always wear heavy gloves when handling chain or cable.

Be sure cables are anchored and the anchor point is strong enough to handle the expected load. Keep exposed personnel clear of anchor point and cable or chain. **DO NOT PULL OR TOW UNLESS OPERATOR'S COMPARTMENT OF MACHINES INVOLVED ARE PROPERLY GUARDED AGAINST POTENTIAL CABLE OR CHAIN BACKLASH.**

During operation always carry ripper in full raised position when not in use and lowered to ground when parked.

When counterweights have been provided, do not work machine if they have been removed unless their equivalent weight has been replaced. See the Operation and Maintenance Instruction Manual.

When operating a machine know what clearances will be encountered, overhead doors, wires, pipes, aisles, roadways; also the weight limitations of ground, floor, and ramps.

Know bridge and culvert load limits and do not exceed them. Know machine's height, width, and weight. Use a signal person when clearance is close.

Be sure that the exact location of gas lines, utility lines, sewers, overhead and buried power lines, and other obstructions or hazards are known. Such locations should be precisely marked by the proper authorities to reduce the risk of accidents. Obtain shut-down or relocation of any such facilities before starting work, if necessary.

Be certain to comply with all local, state, and federal regulations regarding working in the vicinity of power lines.

When roading find out what conditions are likely to be met - clearances, congestion, type of surface, etc. Be aware of fog, smoke or dust element that obscure visibility.

When backing, always look to where the machine is to be moved. Be alert to the position of exposed personnel. **DO NOT OPERATE** if exposed personnel enter the immediate work area.

## SAFETY RULES

Never travel a machine on a job site, in a congested area, or around people without a signal person to guide the operator.

In darkness, check area of operation carefully before moving in with machine. Use all lights provided. Do not move into area of restricted visibility.

Maintain clear vision of all areas of travel or work. Keep cab windows clean and repaired. Carry blade low for maximum visibility while traveling. Obtain and use fan blast deflectors where tractors are used a pusher tractors in tandem.

Transport a loaded bucket with the bucket as far tipped back and in as low a position as possible for maximum visibility, stability, and safest transport of the machine. Carry it at a proper speed for the load and ground conditions.

Carry the bucket low when traveling with a load.

Maintain a safe distance from other machines. Provide sufficient clearance for ground and visibility conditions. Yield right-of-way to loaded machines.

Avoid going over obstacles such as rough terrain, rocks, logs, curbs, ditches ridges, and railroad tracks whenever possible. When obstructions must be crossed, do so with extreme care at an angle if possible. Reduce speed - down-shift. Ease up to the break over point - pass the balance point slowly on the obstruction and ease down on the other side.

Cross gullies or ditches at an angle with reduced speed after insuring ground conditions will permit a safe traverse.

Be alert to soft ground conditions close to newly constructed walls. The fill material and weight of machine may cause the wall to collapse under the machine.

Operate at speeds slow enough to insure complete control at all times. Travel slowly over rough ground, on slopes or near drop offs, in congested areas or on ice or slippery surfaces.

Be alert to avoid changes in traction conditions that could cause loss of control. **DO NOT** drive on ice or frozen ground conditions when working the machine on steep slopes or near drop offs.

Keep the machine well back from the edge of an excavation.

Be especially careful when traveling up or down slopes. Position the bucket in such a way as to provide a possible anchorage on the ground in case of a slide.

When proceeding across a hill side proceed slowly. Never turn sharply up hill or down hill.

Avoid side hill travel whenever possible. Drive up and down the slope. Should the machine start slipping sideways on a grade, turn it immediately downhill.

In steep down hill operation, do not allow engine to over speed. Select proper gear before starting down grade.

There is no substitute for good judgement when working on slopes.

The grade of slope you should attempt will be limited by such factors as condition of the ground, load being handled, the type of machine, speed of machine and visibility.

**NEVER COAST** the machine down grades and slopes with the transmission in neutral on power shift machines, or clutch disengaged on manually shifted machines.

To reduce the danger of uncontrolled machine, choose a gear speed before proceeding down grade that will hold machine to proper speeds for conditions.

Operating in virgin rough terrain that includes previously mentioned hazards is called pioneering. Be sure you know how this is done. Danger from falling branches and upturning roots is acute in these areas.

When pushing over trees, the machine must be equipped with proper over head guarding. Never allow a machine to climb up on the root structure particularly while the tree is being felled. Use extreme care when pushing over any tree with dead branches.

Avoid brush piles, logs or rocks. **DO NOT DRIVE THE MACHINE ONTO BRUSH PILES, LOGS, LARGE ROCKS** or other surface irregularities that break traction with the ground especially when on slopes or near drop offs.

Avoid operating equipment too close to an over hang or high wall either above or below the machine. Be on the look out for caving edges, falling objects and slides. Beware of concealment by brush and under growth of these dangers.

Park in a non-operating and non-traffic area or as instructed. Park on firm level ground if possible. Where not possible, position machine at a right angle to the slope, making sure there is no danger of uncontrolled sliding movement. Set the parking brake.

Never park on an incline without carefully blocking the machine to prevent movement.

If parking in traffic lanes cannot be avoided, provide appropriate flags, barriers, flares and warning signals as required. Also provide advance warning signals in the traffic lane of approaching traffic.

Move the machine away from pits, trenches, overhangs and over head power lines before shutting down for the day.

When stopping operation of the machine for any reason, always return the transmission or hydrostatic drive control to neutral and engage the control lock to secure the machine for a safe start up. Set parking brake, if so equipped.

Never lower attachments or tools from any position other than seated in operator's seat. Sound the horn. Make sure the area near the attachment is clear. Lower the attachment slowly. **DO NOT USE** float position to lower hydraulic equipment.

## SAFETY RULES

Always before leaving the operator's seat and after making certain all people are clear of the machine, slowly lower the attachments or tools flat to the ground in a positive ground support position. Move any multi purpose tool to positive closed position. Return the controls to hold. Place transmission control in neutral and move engine controls to off position. Engage all control locks, set parking brake, and open and lock the master (key, if so equipped) switch. Consult Operation and Maintenance Instruction Manual.

Always follow the shut down instructions as outlined in the Operation and Maintenance Instruction Manual.

### MAINTENANCE

Do not perform any work on equipment that is not authorized. Follow the Maintenance or Service Manual procedures.

Machine should not be serviced with anyone in the operator's seat unless they are qualified to operate the machine and are assisting in the servicing.

Shut off engine and disengage the Power Take Off lever if so equipped before attempting adjustments or service.

Always turn the master switch (key switch if so equipped) to the OFF position before cleaning, repairing, or servicing and when parking machine to forestall unintended or unauthorized starting.

Disconnect batteries and TAG all controls according to local or national requirements to warn that work is in progress. Block the machine and all attachments that must be raised per local or national requirements.

Never lubricate, service or adjust a machine with the engine running, except as called for in the Operation and Maintenance Instruction Manual. Do not wear loose clothing or jewelry near moving parts.

Do not run engine when refueling and use care if engine is hot due to the increased possibility of a fire if fuel is spilled.

Do not smoke or permit any open flame or spark near when refueling, or handling highly flammable materials.

Always place the fuel nozzle against the side of the filler opening before starting and during fuel flow. To reduce the chance of a static electricity spark, keep contact until after fuel flow is shut off.

Do not adjust engine fuel pump when the machine is in motion.

Never attempt to check or adjust fan belts when engine is running.

When making equipment checks that require running of the engine, have an operator in the operator's seat at all times with the mechanic in sight. Place the transmission in neutral and set the brakes and lock. **KEEP HANDS AND CLOTHING AWAY FROM MOVING PARTS.**

Avoid running engine with open unprotected air inlets. If such running is unavoidable for service reasons, place protective screens over all inlet openings before servicing engine.

Do not place head, body, limbs, feet, fingers, or hands near rotating fan or belts. Be especially alert around a pusher fan.

Keep head, body, limbs, feet, fingers, or hands away from bucket, blade or ripper when in raised position.

If movement of an attachment by means of machine's hydraulic system or winches is required for service or maintenance, do not raise or lower attachments from any position other than when seated in the operator's seat. Before starting machine or moving attachments or tools, set brakes, sound horn and call for an all clear. Raise attachments slowly.

Never place head, body, limbs, feet, fingers, or hands into an exposed portion between uncontrolled or unguarded scissor points of machine without first providing secure blocking.

Never align holes with fingers or hands - Use the proper aligning tool.

Disconnect batteries before working on electrical system or repair work of any kind.

Check for fuel or battery electrolyte leaks before starting service or maintenance work. Eliminate leaks before proceeding.

**BATTERY GAS IS HIGHLY FLAMMABLE.** Leave battery box open to improve ventilation when charging batteries. Never check charge by placing metal objects across the posts. Keep sparks or open flame away from batteries. Do not smoke near battery to guard against the possibility of an accidental explosion.

Do not charge batteries in a closed area. Provide proper ventilation to guard against an accidental explosion from an accumulation of explosive gases given off in the charging process.

Be sure to connect the booster cables to the proper terminals (+ to +) and (- to -) at both ends. Avoid shorting clamps. Follow the Operation and Maintenance Instruction Manual procedure.

Due to the presence of flammable fluid, never check or fill fuel tanks, storage batteries or use starter fluid near lighted smoking materials or open flame or sparks.

Rust inhibitors are volatile and flammable. Prepare parts in well ventilated place. Keep open flame away - **DO NOT SMOKE.** Store containers in a cool well ventilated place secured against unauthorized personnel.

Do not use an open flame as a light source to look for leaks or for inspection anywhere on the machine.

**DO NOT** pile oily or greasy rags - they are a fire hazard. Store in a closed metal container.

## SAFETY RULES

Never use gasoline or solvent or other flammable fluid to clean parts. Use authorized commercial, non-flammable, non-toxic solvents.

Never place gasoline or diesel fuel in an open pan.

Shut off engine and be sure all pressure in system has been relieved before removing panels, housings, covers, and caps. See Operation and Maintenance Instruction Manual.

Do not remove hoses or check valves in the hydraulic system without first removing load and relieving pressure on the supporting cylinders. Turn radiator cap slowly to relieve pressure before removing. Add coolant only with engine stopped or idling if hot. See Operation and Maintenance Instruction Manual.

Fluid escaping under pressure from a very small hole can almost be invisible and can have sufficient force to penetrate the skin. Use a piece of card board or wood to search for suspected pressure leaks. **DO NOT USE HANDS.** If injured by escaping fluid, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.

Never use any gas other than dry nitrogen to charge accumulators. See Operation and Maintenance Instruction Manual.

When making pressure checks use the correct gauge for expected pressure. See the Operation and Maintenance Instruction Manual or Service Manual for guidance.

For field service, move machine to level ground if possible and block machine. If work is absolutely necessary on an incline, block machine and its attachments securely. Move the machine to level ground as soon as possible.

Brakes are inoperative when manually released for servicing. Provision must be made to maintain control of the machine by blocking or other means.

Block all wheels before bleeding or disconnecting any brake system lines and cylinders.

Never use make shift jacks when adjusting track tension. Follow the Undercarriage Service Manual.

Know your jacking equipment and its capacity. Be sure the jacking point used on the machine is appropriate for the load to be applied. Be sure the support of the jack at the machine and under the jack is appropriate and stable. Any equipment up on a jack is dangerous. Transfer load to appropriate blocking as a safety measure before proceeding with service or maintenance work according to local or national requirements.

Always block with external support any linkage or part on machine that requires work under the raised linkage, parts, or machine per local or national requirements. Never allow anyone to walk under or be near unblocked raised equipment. Avoid working or walking under raised blocked equipment unless you are assured of your safety.

When servicing or maintenance requires access to areas that cannot be reached from the ground, use a ladder or step platform that meets local or national requirements to reach the service point. If such ladders or platforms are not available, use the machine hand holds and steps as provided. Perform all service or maintenance carefully.

Shop or field service platforms and ladders used to maintain or service machinery should be constructed and maintained according to local or national requirements.

Lift and handle all heavy parts with a lifting device of proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.

In lifting and handling heavy parts, slings must be of adequate strength for the purpose intended and must be in good condition.

Handle all parts with extreme care. Keep hands and fingers from between parts. Wear authorized protective equipment such as safety glasses, heavy gloves, safety shoes.

When using compressed air for cleaning parts use safety glasses with side shields or goggles. Limit the pressure to 207 kPa (30 psi) according to local or national requirements.

Wear welders protective equipment such as dark safety glasses, helmets, protective clothing, gloves and safety shoes when welding or burning. Wear dark safety glasses near welding. **DO NOT LOOK AT ARC WITHOUT PROPER EYE PROTECTION.**

Replace seat belts every two years on open canopy units and every three years on machines with cabs or at change of ownership.

Wear proper protective equipment such as safety goggles or safety glasses with side shields, hard hat, safety shoes, heavy gloves when metal or other particles are apt to fly or fall.

Use only grounded auxiliary power source for heaters, chargers, pumps and similar equipment to reduce the hazards of electrical shock.

Keep maintenance area **CLEAN** and **DRY**. Remove water or oil slicks immediately.

Remove sharp edges and burrs from reworked parts.

Be sure all mechanics tools are in good condition. **DO NOT** use tools with mushroomed heads. Always wear safety glasses with side shields.

Do not strike hardened steel parts with anything other than a soft iron or non-ferrous hammer.

Do not rush. Walk, do not run.

Know and use the hand signals used on particular jobs and know who has the responsibility for signaling.

## SAFETY RULES

Face the access system when climbing up and down.

Apply the parking device and place the transmission in neutral before starting the machine.

Do not bypass the starter safety switch. Repair the starter safety controls if they malfunction.

Fasten seat belt before operating.

Steering should be checked to both right and left. Brakes should be tested against engine power. Clutch and transmission controls should be moved through or to neutral positions to assure disengagement. Operate all controls to insure proper operation. If any malfunctions are found, park machine, shut off engine, report and repair before using machine.

If the power steering or the engine ceases operating, stop the machine motion as quickly as possible. Lower equipment, set parking device and keep machine securely parked until the malfunction is corrected or the machine can be safely towed. Never lift loads in excess of capacity.

Should the machine become stuck or frozen to the ground, back out to avoid roll over.

Know and understand the job site traffic flow patterns.

Keep the machine in the same gear going down hill as used for going up hill.

When roading a machine, know and use the signaling devices required on the machine. Provide an escort for roading where required.

Always use the recommended transport devices when roading the machine.

Do not attempt repairs unless proper training has been provided.

Use extreme caution when removing radiator caps, drain plugs, grease fittings or pressure taps. Park the machine and let it cool down before opening a pressurized compartment.

Release all pressure before working on systems which have an accumulator.

When necessary to tow the machine, do not exceed the recommended towing speed, be sure the towing machine has sufficient braking capacity to stop the towed load. If the towed machine cannot be braked, a tow bar must be used or two towing machines must be used - one in front pulling and one in the rear to retard. Avoid towing over long distances.

Observe proper maintenance and repair of all pivot pins, hydraulic cylinders, hoses, snap rings and main attaching bolts.

Always keep the brakes and steering systems in good operating condition.

Replace all missing, illegible or damaged safety signs. Keep all safety signs clean.

Do not fill the fuel tank to capacity. Allow room for expansion.

Wipe up spilled fuel immediately.

Always tighten the fuel tank cap securely. Should the fuel cap be lost, replace it only with the original manufacturers approved cap. Use of a non-approved cap may result in over-pressurization of the tank.

Never drive the machine near open fires.

Use the correct fuel grade for the operating season.

## **FOREWORD**

**Always furnish serial number if making an inquiry to dealer or factory about this machine.**

**Many equipment owners employ the Dealer Service Department for all work other than routine lubrication and minor service. This practice is encouraged, as our Dealers are well informed and equipped to render efficient service by factory trained mechanics.**

**This manual may not be reprinted or reproduced, either in whole or in part, without written permission of Fiatallis ®.**

**Illustrations show standard and optional items.**

## **IMPORTANT**

**The information in this manual was current at the time of publication. It is our policy to constantly improve our product and to make available additional items. These changes may affect procedures outlined in this manual. If variances are observed, verify the information through your Dealer.**

**Fiatallis is not responsible for any liability arising from any damage resulting from defects caused by parts and/or components not approved by Fiatallis for use in maintaining and/or repairing products manufactured or merchandized by Fiatallis.**

**In any case, no warranty of any kind is made or shall be imposed with respect to products manufactured or merchandized by Fiatallis when failures are caused by the use of parts and/or components not approved by Fiatallis.**



# SECTION 1 - DESCRIPTION AND SPECIFICATIONS

TOPIC NO.	TITLE	PAGE
1.	DESCRIPTION	
	A. General . . . . .	1-1
	B. Principles of Operation . . . . .	1-1
2.	SPECIFICATIONS	
	A. Engine Data and Characteristics . . . . .	1-2
	B. Fuel Injection (American Bosch (PSB) Fuel Injection Pump) . . . . .	1-2
	C. Fuel Injection (Roosa Master Fuel Injection Pump without Automatic Timing Advance) . . . . .	1-2
	D. Fuel Injection (Roosa Master Fuel Injection Pump with Automatic Timing Advance) . . . . .	1-2
	E. Valve Timing . . . . .	1-2
	F. Lubrication . . . . .	1-2
	G. Engine Speeds . . . . .	1-2

## TOPIC 1 - DESCRIPTION

### A. GENERAL

The Model 10000, 11000, 11000 MKII, and 685T engines covered in this manual are both six cylinder, vertical in-line, four cycle, water cooled, open combustion chamber, direct injection, full diesel engines. The main difference between the models is that the 10000 engine is naturally aspirated, and the 11000, 11000 MKII, and 685T are turbocharged.

Fuel is supplied to the cylinders by a fuel injection pump. The pump delivers accurately metered quantities of fuel, under high pressure, through fuel injection nozzles, into the cylinders at a definite timing in relation to the engine firing cycle. The fuel is ignited by heat generated by compression of the air in the cylinders.

A combustion chamber is located in the head of each piston and the fuel injection nozzles are mounted in the cylinder head. The orifices in the tip of the nozzle are drilled at a slight angle so that the fuel is sprayed directly into the combustion chamber which is slightly offset toward the camshaft side of the engine. The shape of the combustion chamber, angle of fuel injection, and the shrouded intake valves, causes extreme turbulence of the air within the cylinders and results in the fuel and air being thoroughly mixed for complete combustion.

The engines are full pressure lubricated by a gear type oil pump driven by the crankshaft gear. Engine cooling is accomplished by coolant, forced through the engine cooling and radiator system by a centrifugal type water pump. The water pump is belt driven.

### B. PRINCIPLES OF OPERATION

In a four cycle diesel engine, a power stroke is made by each piston for every two complete revolutions of the crankshaft. The sequence of the strokes is as follows: Intake, compression, power, and exhaust.

#### 1. INTAKE STROKE

As the piston moves downward on the first, or intake stroke, air enters the cylinder through the air intake manifold, and the intake valve which starts to open a few degrees before the piston reaches top dead center. The intake charge consists of air only, with no fuel mixture.

#### 2. COMPRESSION STROKE

Shortly after the piston starts to move upward on the second, or compression stroke, the intake valve closes. The air is compressed in the cylinder and compression of the air raises the temperature in the cylinder to approximately 1000°F. At the proper moment during the compression stroke, a metered quantity of fuel is injected into the combustion chamber under extremely high pressure. The finely atomized fuel is ignited by heat of the compressed air and starts to burn immediately.

#### 3. POWER STROKE

Expansion of the burning gases forces the piston downward on its third, or power stroke. Near the bottom of the power stroke, the exhaust valve starts to open.

#### 4. EXHAUST STROKE

As the piston moves upward on the fourth, or exhaust stroke, the exhaust valve is open and burned gases are forced out of the cylinder by the upward travel of the piston. A few degrees before the piston reaches top dead center, the intake valve starts to open to admit a fresh charge of air to the cylinder. A few degrees after top dead center, the exhaust valve completely closes and the cycle is repeated.

## TOPIC 2 - SPECIFICATIONS

### A. ENGINE DATA AND CHARACTERISTICS

Number of Cylinders .....	6
Bore .....	4.4375 in (112.71 mm)
Stroke .....	5.5625 in (141.29 mm)
Total Displacement .....	516 in <sup>3</sup> (8.4 lit)
Crankshaft Rotation (Viewed from Fan End) .....	Clockwise
Number of Main Bearings .....	7
Compression Ratio (Nominal) .....	16.2:1
Compression Pressure (Minimum) at Sea Level 600 rpm hot .....	445 psi (31.3 kg/cm <sup>2</sup> )
Firing Order .....	1-5-3-6-2-4
Minimum Stabilized Water Temp: .....	170 °F. (76.7 °C)
Maximum Air Intake Restriction: 30 in (762 mm) H <sub>2</sub> O	
Maximum Permissible Exhaust Restriction	
Naturally Aspirated .....	3 in Hg (10.2 kPa)
Turbocharged .....	1 in Hg (3.4 kPa)

### B. FUEL INJECTION PUMP (AMERICAN BOSCH (PSB)

Nozzle Opening Pressure: 3800-3850 psi (267.2-270.7 kg/cm<sup>2</sup>)

#### Fuel Injection Timing:

Track-Type Tractors without Torque Converter and Motor Graders .....	30°
Track-Type Tractors with Torque Converter .....	32°
Tractor Loaders and Tractor Dozers TL20D .....	32°
D30 .....	33°
TL30D .....	34°
Fuel Injection Pump Speed (Ratio to Crankshaft) .....	1:1

### C. FUEL INJECTION PUMP (ROOSA MASTER WITHOUT AUTOMATIC TIMING ADVANCE)

Nozzle Opening Pressure .....	2825 psi (198.6 kg/cm <sup>2</sup> )
Fuel Injection Timing:	
Naturally Aspirated Engines (10000) .....	30°
Turbocharged Engines (11000) .....	36°
Fuel Injection Pump Speed (Ratio to Crankshaft) .....	1:2

### D. FUEL INJECTION PUMP (ROOSA MASTER WITH AUTOMATIC TIMING ADVANCE)

Nozzle Opening Pressure (First type) .. 2800-2850 psi (196.9-100.4 kg/cm<sup>2</sup>)

Nozzle Opening Pressure ..  
(Second Type) 3800-3850 psi (267.2-270.7 kg/cm<sup>2</sup>)

Fuel Injection Pump Timing:	
11000	24° BTDC (Static), 36° BTDC (Running)
11000 MKII (DB, DC):	18° BTDC (Static) 36° BTDC (Running)
11000 MKII (DM):	14° BTDC (Static), 36° BTDC (Running)
Fuel Injection Pump Speed (Ratio to Crankshaft) .....	1:2

### E. FUEL INJECTION PUMP (BOSCH-GERMANY)

Nozzle Opening Pressure .....	3800-3850 psi (267.2-270.7 kg/cm <sup>2</sup> )
Fuel Injection Timing BTDC	
HD-11, 11-B Crawler Tractor .....	32°
12G, 12G-B Crawler Loader .....	34°
100-C, 150-C, 200-C Motor Graders .....	32°
745, 745H, 745B, 745H-B Wheel Loaders .....	34°
Fuel Injection Pump Speed (Ratio to Crankshaft) .....	1:2

### F. VALVE TIMING

#### NOTE

Early model engines used camshaft part no. 4336274 and later model engines use camshaft part no. 4337723. The part no. is stamped on the camshaft near the front end. The valve timing for each camshaft is as follows:

	Camshaft no. 4337723 With Tappets Set at 0.024 in (0.61mm)	Camshaft no. 4336274 With Tappets Set at 0.018 in (0.46 mm)
Intake Valve Opens BTDC	21°	40°
Intake Valve Closes ABDC	55°	70°
Duration	256°	290°
Exhaust Valve Opens BBDC	53°	70°
Exhaust Valve Closes ATDC	23°	40°
Duration	256°	290°
Overlap	44°	80°
Running Clearance for Valve	0.018 in (0.46 mm) HOT	
Tappets (Intake and Exhaust)	0.020 in (0.51 mm) COLD	

### G. LUBRICATION

Type .....	Full Pressure
Lubricating Oil Filter .....	Full Flow
Lubricating Oil Specifications .....	CD, MIL-L-45199B or MIL-L-2104C
Oil Pump Speed Ratio to Crankshaft .....	0.682:1

### H. ENGINE SPEEDS

For specified high and low idle engine speeds, which vary depending upon the unit in which the engine is used, refer to the OPERATION AND MAINTENANCE INSTRUCTION MANUAL furnished with the unit.

**Study SAFETY RULES, pages I thru III, thoroughly for the protection of personal and machine safety.**

## TOPIC 2 SPECIFICATIONS

### MACHINE LIST, FUEL INJECTION PUMP TYPE, PUMP PART NUMBER, ENGINE TIMING

NOTE: ALL TIMING STATIC

**PUMP TYPE:**

- (1) Roosa-Master
- (2) Robert Bosch

<u>MACHINE LIST</u>	<u>PUMP TYPE</u>	<u>PUMP PART NO.</u>	<u>ENGINE TIMING DEGREES B.T.D.C.</u>
<b>CRAWLER TRACTOR</b>			
11-B(D.D.)	(2)	74320816	32
	(2)	74320940	32
	(2)	74321357	32
	(2)	74359826	32
	(1)	74321202	18
	(1)	74321477	18
11-B (P.S. w/ converter)	(2)	74320754	32
	(2)	74320941	32
	(2)	74321351	32
	(2)	74359830	32
	(1)	74321203	18
	(1)	74321477	18
<b>CRAWLER LOADER</b>			
12G-B	(1)	74321201	24
	(1)	74321337	18
	(1)	74321743	18
	(2)	74320793	32
	(2)	74321071	32
	(2)	74321352	32
	(2)	74321364	32
	(2)	74329832	32
<b>WHEEL LOADER</b>			
745-B	(1)	74321204	24
	(1)	74321338	18
	(1)	74359238	24
	(1)	74321696	18
	(1)	74359855	24
	(2)	74320817	34
	(2)	74359828	34
	(1)	74357415	24
	(1)	74321474	18
745H-B	(2)	74321350	34
	(2)	74320817	34
	(1)	74321204	24
	(1)	74321338	18
	(2)	74359828	34
	(1)	74321474	18

(Added April 1986)

## TOPIC 2 SPECIFICATIONS

<u>MACHINE LIST</u>	<u>PUMP TYPE</u>	<u>PUMP PART NO.</u>	<u>ENGINE TIMING DEGREES B.T.D.C.</u>
745-C	(1)	74321924	14
	(1)	74322021	14
<b>MOTOR GRADER</b>			
100-C	(1)	74321756	14
	(2)	74320815	32
	(2)	74320939	32
	(2)	74321356	32
	(2)	74359816	32
	(1)	74321478	18
	(1)	74321205	18
150-C	(1)	74321205	18
	(2)	74321356	32
	(1)	74321206	18
	(2)	74320939	32
	(1)	74321478	18
	(1)	74321479	18
	(2)	74320815	32
	(2)	74320939	32
	(2)	74359816	32
	(1)	74321756	14
200-C	(1)	74321206	18
	(1)	74321479	18
	(1)	74321882	14
	(2)	74320835	32
	(2)	74321354	32
<b>TRACTOR SCRAPER</b>			
262-B (front)	(2)	74394877	34
(rear)	(1)	74321973	14
263-B (front)	(2)	74396184	37
(rear)	(1)	74321973	14

(Added April 1986)

## SECTION 2 - COOLING SYSTEM

<b>TOPIC NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
1.	GENERAL . . . . .	2-2
2.	RADIATOR (EXCEPT 12G CRAWLER LOADER)	
	A. General . . . . .	2-2
	B. Radiator Removal and Installation . . . . .	2-2
	C. Radiator Inspection . . . . .	2-4
3.	RADIATOR (12G CRAWLER LOADER)	
	A. General . . . . .	2-4
	B. Radiator Removal and Installation . . . . .	2-4
	C. Radiator Inspection . . . . .	2-4
4.	FAN, FAN BELTS, FAN HUB, FAN BELT TIGHTENER, AND FAN DRIVE (EXCEPT 12G CRAWLER LOADER)	
	A. Description . . . . .	2-4
	B. Fan Belt Adjustment . . . . .	2-4
	C. Fan Removal, Inspection, and Installation . . . . .	2-6
	D. Fan Belt Removal, Inspection, and Installation . . . . .	2-6
	E. Fan Hub Removal, Disassembly, and Inspection . . . . .	2-6
	F. Fan Hub Assembly and Installation . . . . .	2-6
	G. Fan Belt Tightener Removal, Disassembly, and Inspection . . . . .	2-9
	H. Fan Belt Tightener Assembly and Installation . . . . .	2-10
	I. Fan Drive Removal, Disassembly, and Inspection (Track-Type Tractor Engines w/American Bosch Fuel Injection Pump) . . . . .	2-10
	J. Fan Drive Assembly and Installation (Track-Type Tractor Engines w/American Bosch Fuel Injection Pump) . . . . .	2-11
	K. Fan Drive Removal, Disassembly, and Inspection (Crawler Tractor Engines w/Roosa Master or Bosch (Germany) Fuel Injection Pump) . . . . .	2-12
	L. Fan Drive Assembly and Installation (Crawler Tractor Engines w/Roosa Master or Bosch (Germany) Fuel Injection Pump) . . . . .	2-12
5.	FAN, FAN BELTS, AND FAN DRIVE (12G CRAWLER LOADER)	
	A. Description . . . . .	2-13
	B. Fan Belt Adjustment . . . . .	2-13
	C. Fan Removal, Inspection, and Installation . . . . .	2-13
	D. Fan Belt Removal, Inspection, and Installation . . . . .	2-13
	E. Fan Hub Removal, Disassembly, Inspection, Assembly, and Installation . . . . .	2-15
	F. Fan Drive Removal, Disassembly, Inspection, Assembly, and Installation . . . . .	2-15
6.	THERMOSTATS	
	A. General . . . . .	2-17
	B. Thermostat Removal, Testing, and Installation . . . . .	2-18
7.	OIL COOLERS	
	A. General . . . . .	2-18
	B. Oil Cooler Removal . . . . .	2-18
	C. Oil Cooler Cleaning . . . . .	2-20
	D. Oil Cooler Testing . . . . .	2-23
	E. Oil Cooler Installation . . . . .	2-23
8.	WATER PUMP	
	A. Description . . . . .	2-24
	B. Water Pump Removal . . . . .	2-24
	C. Water Pump Disassembly, Inspection, and Assembly . . . . .	2-25
	D. Water Pump Installation . . . . .	2-27
9.	COOLANT FILTER	
	A. General . . . . .	2-27
	B. Coolant Filter Service . . . . .	2-28
	C. Coolant Filter Removal and Installation . . . . .	2-28

*Study SAFETY RULES, pages 1 thru III, thoroughly for the protection of personal and machine safety.*

## TOPIC 1 - GENERAL

Refer to FIG. 1A. The engine cooling system includes radiator, water pump, oil cooler, water inlet and water outlet manifolds, thermostats, coolant temperature gauge, and water passages in cylinder block and cylinder head.

All units, using engines covered in this manual, with the exception of early model motor graders, have a pressurized cooling system. A double acting pressure relief valve is provided in the radiator filler cap. The valve is set to open at approximately 7 psi. Early model motor graders have an open type vented cooling system.

The water pump draws water from the bottom of the radiator and forces it through the oil cooler and the cored water passages in the engine. The coolant is discharged from the cylinder head into the water outlet manifold, through the thermostat and upper radiator hose and into the upper part of the radiator. The coolant dissipates its heat as it passes from the top to the bottom of the radiator through the cooling cores. The fan helps dissipate the heat as it forces air through the radiator. The thermostats, located in the thermostat housing at the front end of the water outlet manifold, operate automatically to maintain a minimum coolant temperature of 170°F.

## TOPIC 2 - RADIATOR (EXCEPT 12G CRAWLER LOADER)

### A. GENERAL

The radiator used on motor graders, tractor loaders, and tractor dozers is a one piece welded assembly. The radiator used on track-type tractors consists of a top and bottom tank, core, and side members bolted together and serviced separately.

On track-type tractors, the radiator is mounted on a radiator support, Fig. 1, which is bolted to the tractor main frame.

On motor graders, the radiator is bolted to the radiator grill, Fig. 2, which is bolted to the grader main frame.

On tractor loaders, and tractor dozers the radiator is bolted to the radiator support, Fig. 3, which is bolted to the loader main frame.

### B. RADIATOR REMOVAL AND INSTALLATION

#### 1. TRACK-TYPE TRACTORS (Fig. 1)

- Drain cooling system.
- Remove or tilt radiator guard forward.
- Disconnect radiator inlet and outlet hoses. Disconnect any wires which may be attached to radiator.
- The radiator (1) and radiator support (2) may now be removed as an assembly by removing fan guard (if so equipped), support mounting capscrews (9), and capscrews (6); or the radiator may be removed from the support by removing capscrews (13) and lockwashers.

- If Radiator support was removed from tractor, install by direct reversal of removal procedure.
- Install radiator on radiator support and secure with capscrews (13) and lockwashers.




Fig. 1-Typical Radiator Mounting  
(Track-Type Tractors)  
(T-16315)

1. Radiator Assembly	8. Nut
2. Radiator Support	9. Capscrew
3. Nut	10. Plain Washer
4. Lock Nut	11. Lockwasher
5. Brace	12. Nut
6. Capscrew	13. Capscrews
7. Lockwasher	




FIG. 1A COOLANT FLOW SCHEMATIC

1. Drain cock	8. Water pump
2. Thermostat	9. Coolant filter
3. Bypass pipe	10. Engine oil cooler
4. Thermostat housing cover	11. Torque converter fluid cooler
5. Pressure cap (7 psi) (0.49 kg/cm <sup>2</sup> )	12. Immersion heater thermostat
6. Vent cocks	13. Immersion heater
7. Radiator	14. Water outlet manifold

Optional

Study SAFETY RULES, pages I thru III, thoroughly for the protection of personal and machine safety.

Product: Fiatallis 745/745H Wheel Loader Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/fiatallis-745-745h-wheel-loader-service-repair-manual/>

Sample of manual. Download All 808 pages at:

<https://www.arepairmanual.com/downloads/fiatallis-745-745h-wheel-loader-service-repair-manual/>