


# EPSON TERMINAL PRINTER **EPL-9000**

---

# **SERVICE MANUAL**

---



# EPSON

4003603

## NOTICE

All rights reserved. Reproduction of any part of this manual in any form whatsoever without SEIKO EPSON's express written permission is forbidden.

The contents of this manual are **subjects** to change without notice.

All efforts have been made to ensure the accuracy of the contents of this manual. However, should any errors be detected, SEIKO EPSON would greatly appreciate being informed of them.

The above notwithstanding SEIKO EPSON can assume no responsibility for any errors in this manual or the consequence thereof.

Epson and Epson ESCP are registered trademarks and Epson **ESCP2** is a trademark of Seiko Epson Corporation.

**Speedo**, Fontware, FaceLift, Swiss, and Dutch are trademarks of BitStream Inc.

**CG Times** and **CG Omega** are registered trademarks of Miles, Inc.

Univers is a registered trademark of Linotype AG and / or its subsidiaries.

Antique Olive is a trademark of Fonderie Olive.

Albertus is a trademark of Monotype Corporation **plc**.

Coronet is a trademark of Ludlow Industries (UK) Ltd.

Arial and Times New Roman are registered trademarks of Monotype Corporation **plc**.

**General Notice:** Other product **names** used herein are for identification purposes only and maybe trademarks of their respective **companies**.

**Copyright © 1994 by SEIKO EPSON CORPORATION Nagano, Japan**

# PRECAUTIONS

Precautionary notations throughout the text are categorized relative to 1) personal injury and 2) damage to equipment.

**DANGER** Signals a precaution which, if ignored, could result in serious or fatal personal injury. Great caution should be exercised in performing procedures preceded by DANGER Headings.

**WARNING** Signals a precaution which, if ignored, could result in damage to equipment.

The precautionary measures itemized below should always be observed when performing repair/maintenance procedures.

## **DANGER**

1. ALWAYS DISCONNECT THE PRODUCT FROM BOTH THE POWER SOURCE AND PERIPHERAL DEVICES PERFORMING ANY MAINTENANCE OR REPAIR PROCEDURE.
2. NO WORK SHOULD BE PERFORMED ON THE UNIT BY PERSONS UNFAMILIAR WITH BASIC SAFETY MEASURES AS DICTATED FOR ALL ELECTRONICS TECHNICIANS IN THEIR LINE OF WORK.
3. WHEN PERFORMING TESTING AS DICTATED WITHIN THIS MANUAL, DO NOT CONNECT THE UNIT TO A POWER SOURCE UNTIL INSTRUCTED TO DO SO. WHEN THE POWER SUPPLY CABLE MUST BE CONNECTED, USE EXTREME CAUTION IN WORKING ON POWER SUPPLY AND OTHER ELECTRONIC COMPONENTS.

## **WARNING**

1. REPAIRS ON EPSON PRODUCT SHOULD BE PERFORMED ONLY BY AN EPSON CERTIFIED REPAIR TECHNICIAN.
2. MAKE CERTAIN THAT THE SOURCE VOLTAGE IS THE SAME AS THE RATED VOLTAGE, LISTED ON THE SERIAL NUMBER/RATING PLATE. IF THE EPSON PRODUCT HAS A PRIMARY AC RATING DIFFERENT FROM AVAILABLE POWER SOURCE, DO NOT CONNECT IT TO THE POWER SOURCE.
3. ALWAYS VERIFY THAT THE EPSON PRODUCT HAS BEEN DISCONNECTED FROM THE POWER SOURCE BEFORE REMOVING OR REPLACING PRINTED CIRCUIT BOARDS AND/OR INDIVIDUAL CHIPS.
4. IN ORDER TO PROTECT SENSITIVE MICROPROCESSORS AND CIRCUITRY, USE STATIC DISCHARGE EQUIPMENT, SUCH AS ANTI-STATIC WRIST STRAPS, WHEN ACCESSING INTERNAL COMPONENTS.
5. REPLACE MALFUNCTIONING COMPONENTS ONLY WITH THOSE COMPONENTS BY THE MANUFACTURE; INTRODUCTION OF SECOND-SOURCE ICs OR OTHER NONAPPROVED COMPONENTS MAY DAMAGE THE PRODUCT AND VOID ANY APPLICABLE EPSON WARRANTY.

# SAFETY INFORMATION

This printer is a page printer which operates by means of a laser. There is no possibility of danger from the laser, provided the printer is operated **according** to the instructions in this manual provided.

Since radiation emitted by the **laser** is completely confined within protective housings, the laser beam cannot escape from the machine during any phase of user operation.

## For Europe Users;

**WARNING:** Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous laser radiation exposure.

This is a semiconductor laser. The maximum power of the laser diode is 5 mW and the wavelength is 780 nm.

## For Denmark Users;

ADVARSEL  
Usynlig laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion.  
Undgå udsættelse for stråling.

Klasse 1 laser produkt der opfylder IEC825 sikkerheds kravene.

## For Finland, Sweden Users;

**VAROITUS**  
Laitteen käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteivlle.

**VARNING**  
Om apparaten används på annat sätt än i denna bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laser klass 1.

## For Finland, Sweden Service People

**VAROITUS**  
Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle laser säteivlle. Älä katso säteeseen.

**VARNING**  
Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.

**For Norway Users:**

**ADVARSEL**

Dersom apparatet brukes på annen måte enn spesifisert i denne bruksanvisning, kan brukeren utsettes for usynlig laserstråling som overskrider grensen for laser klasse 1.



Dette er en halvleder laser. Maksimal effekt til laserdiode er 5 mW og bølgelengde er 780 nm.

**Laser Safety Labels**

[Label on rear printer case]

A laser safety labels is attached on the outside of the printer shown below.


**For Europe**




[Label inside printer]

The following laser safety label will be attached inside the printer as shown **below**.

**For Denmark, Finland, Sweden, and Norway**

 <p>CLASS 3B 780nm 5mWmax</p>	危険	開いたインターロックを無効にすると不可視のレーザー放射を受けます。直接放射や散乱放射に目や皮膚が曝されることがあります。
	DANGER	INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.
	CAUTION	INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.
	PRECAUCIÓN	RADIACIÓN LASÉRICA INVISIBLE CUANDO SE ABRE Y ANULA EL INTERBLOQUEO. EVITE LA EXPOSICIÓN DIRECTA AL HAZ.
	VARNING	OSYNLIG LASERSTRÅLNING NÄR DENNA DEL ÄR ÖPPNAD OCH SPÄRRAR ÄR URKOPPLADE. STRÅLEN ÄR FÄRLIG.
	ADVARSEL	USYNLIG LASERSTRÅLING NÄR DEKSEL ÅPNES OG SIKKERHETSLÅS BRYTES, UNNGÅ EKSPONERING FOR STRÅLEN.
	ADVARSEL	USYNLIG LASERSTRÅLING VED ÅBNING, NÅR SIKKERHEDSÅFBRYDERER UD AF FUNKTION. UNDGÅ UDSÆTTELSE FOR STRÅLING.
	VARO!	NÄKYMÄTÖN AVATTAESSA JÄSULOJALUKITUS OHITETTAESSA OLET ALTTIINA LASERSÄTEILYLLE ÄLÄ KATSO SÄTEESÄN.
	VORSICHT!	UNSIHTBARE LASERSTRÄHLUNG, WENN ABDECKUNG GEÖFFNET UND SICHERHEITSVERRIEGELUNG ÜBERBRÜCKT. NICHT IN DER STRAHL BÜCKEN.
ATTENTION	EMISSION DE RADIATION LASER INVISIBLE QUAND L'APPAREIL EST OUVERT ET LORSQUE LA SÉCURITÉ EST NEUTRALISÉE. ÉVITER D'ÊTRE EXPOSÉ AU RAYON LASER.	



# PREFACE

This manual describes functions, theory of electrical and mechanical operations, maintenance, and repair of EPL-9000.

The instructions and procedures included herein are intended for the experience repair technician, and attention should be given to the precautions on the preceding page. The chapters are organized as follows:

## **CHAPTER 1. GENERAL DESCRIPTION**

Provides a general product overview, lists specifications, and illustrates the main components of the printer.

## **CHAPTER 2. OPERATING PRINCIPLES**

Describes the theory of printer operation.

## **CHAPTER 3. DISASSEMBLY AND ASSEMBLY**

Includes a step-by-step guide for product disassembly and assembly.

## **CHAPTER 4. ADJUSTMENTS**

Includes a step-by-step guide for adjustment.

## **CHAPTER 5. TROUBLESHOOTING**

Provides Epson-approved techniques for adjustment.

## **CHAPTER 6. MAINTENANCE**

Describes preventive maintenance techniques to service the equipment.

## **APPENDIX**

Describes connector pin assignments, circuit diagrams, circuit board component layout.

*The contents of this manual are subject to change without notice.*

# REVISION SHEET

<b>Revision</b>	<b>Issue Date</b>	<b>Revision Page</b>
Rev. A	August 5, 1994	1st issue

# TABLE OF CONTENTS

<b>CHAPTER 1.</b>	<b>GENERAL DESCRIPTION</b>
<b>CHAPTER 2.</b>	<b>OPERATING PRINCIPLES</b>
<b>CHAPTER 3.</b>	<b>DISASSEMBLY AND ASSEMBLY</b>
<b>CHAPTER 4.</b>	<b>ADJUSTMENTS</b>
<b>CHAPTER 5.</b>	<b>TROUBLESHOOTING</b>
<b>CHAPTER 6.</b>	<b>MAINTENANCE</b>
<b>APPENDIX</b>	

# Chapter 1 General Description

---

## Table of Contents

<b>1.1 FEATURES</b>	<b>1-1</b>
<b>1.2 SPECIFICATIONS</b>	<b>1-3</b>
1.2.1 Basic Specifications. . . . .	1-3
1.2.2 Electrical Specifications. . . . .	1-5
1.2.3 Reliability Specifications . . . . .	1-5
1.2.4 Environmental Conditions for Operation (Including Imaging Cartridge). . .	1-6
1.2.5 Environmental Conditions for Storage and Transportation . . . . .	1-6
1.2.6 Applicable Standards. . . . .	1-6
1.2.7 Specification for Consumable (Imaging Cartridge) . . . . .	1-7
1.2.8 Physical Specifications . . . . .	1-7
1.2.9 Software Specifications. . . . .	1-8
<b>1.3 INTERFACE SPECIFICATIONS</b>	<b>1-11</b>
<b>1.3.1 Parallel interface. . . . .</b>	<b>1-11</b>
1.3.1.1 Compatibility Mode of Parallel Interface. . . . .	1-11
1.3.1.2 Reverse Mode. . . . .	1-13
1.3.2 Serial Interface . . . . .	1-17
1.3.3 Optional LocalTalk Interface . . . . .	1-19
<b>1.4 OPERATING INSTRUCTIONS</b>	<b>1-20</b>
<b>1.4.1 Control Panel. . . . .</b>	<b>1-20</b>
<b>1.4.2 SelecType Functions. . . . .</b>	<b>1-22</b>
<b>1.4.3 Service Mode. . . . .</b>	<b>1-25</b>
1.4.3.1 Hexadecimal Dump Mode. . . . .	1-25
1.4.3.2 Language Setting Mode . . . . .	1-25
1.4.3.3 Factory Service Mode. . . . .	1-26
1.4.3.4 EEPROM Format Mode . . . . .	1-26
<b>1.4.4 Display of Messages. . . . .</b>	<b>1-27</b>
1.4.4.1 Status Messages. . . . .	1-27
1.4.4.2 Error Messages. . . . .	1-27
1.4.4.3 Warning Messages. . . . .	1-28
<b>1.4.5 Printer Sharing. . . . .</b>	<b>1-29</b>
1.4.5.1 Port Fixed Mode. . . . .	1-29
1.4.5.2 AutoSense Mode. . . . .	1-30
<b>1.4.6 Emulation Mode Switch Functions. . . . .</b>	<b>1-31</b>
1.4.6.1 Emulation Switch by SPL . . . . .	1-31
1.4.6.2 Intelligent Emulation Switch . . . . .	1-31
1.4.7 Bi Resolution Improvement Technology . . . . .	1-32
1.4.8 Optional Memory. . . . .	1-33
<b>1.5 MAIN COMPONENTS</b>	<b>1-34</b>
1.5.1 C135 MAIN Board. . . . .	1-35
1.5.2 C82326* I/F Board (Optional LocalTalk Module). . . . .	1-36
1.5.3 Control panel. . . . .	1-36
1.5.4 MCU PWB Board. . . . .	1-37
1.5.5 LVPS Unit . . . . .	1-37
1.5.6 HVPS Board . . . . .	1-38
1.5.7 ROS Unit. . . . .	1-38

1.5.8 Fusing Unit. . . . .	1-39
1.5.9 Drive Unit. . . . .	1-39
1.5.10 Imaging Cartridge. . . . .	1-39

## List of Figures

Figure 1-1. Exterior View of the <b>EPL-9000</b> . . . . .	1-1
Figure 1-2. Printable Area. . . . .	1-5
Figure 1-3. Compatibility Mode Signal Timing. . . . .	1-11
Figure 1-4. <b>Parallel</b> interface State Switch Diagram . . . . .	1-14
Figure 1-5. Negotiation Timing Chart . . . . .	1-15
Figure 1-6. Data Transfer Timing Chart. . . . .	1-15
Figure 1-7. Termination Timing Chart. . . . .	1-16
Figure 1-8. Interrupt Timing Chart. . . . .	1-16
Figure 1-9. Control Panel . . . . .	1-20
Figure 1-10. Port Fixed Mode . . . . .	1-29
Figure 1-11. Auto Sense Mode. . . . .	1-30
Figure 1-12. Emulation Switch by SPL . . . . .	1-31
Figure 1-13. Intelligent Emulation Switch . . . . .	1-31
Figure 1-14. Effect of <b>BiRITech</b> . . . . .	1-32
Figure 1-15. <b>RITech</b> Adjustment. . . . .	1-32
Figure 1-16. Component Layout . . . . .	1-34
Figure 1-17. C135 MAIN Board. . . . .	1-35
Figure 1-18. <b>C82326*</b> I/F Board. . . . .	1-36
Figure 1-19. Control Panel . . . . .	1-36
Figure 1-20. MCU PWB Board . . . . .	1-37
Figure 1-21. LVPS Unit. . . . .	1-37
Figure 1-22. HVPS Drive. . . . .	1-38
Figure 1-23. ROS Unit. . . . .	1-38
Figure 1-24. Fusing Unit . . . . .	1-39
Figure 1-25. Drive Unit . . . . .	1-39
Figure 1-26. Imaging Cartridge. . . . .	1-39

## List of Tables

Table 1-1. Options for <b>EPL-9000</b> . . . . .	1-2
Table 1-2. Paper Feed Methods . . . . .	1-3
Table 1-3. Paper Types. . . . .	1-4
Table 1-4. Usability of Special Paper . . . . .	1-4
Table 1-5. Electrical Specifications . . . . .	1-5
Table 1-6. Differences between EPSON GU2 and <b>GL/2</b> in the HP LaserJet 4 Emulation. . . . .	1-8
Table 1-7. <b>Built-in</b> Fonts . . . . .	1-8
Table 1-8. Parallel Interface Pin Assignments . . . . .	1-12
Table 1-9. Parallel Interface Pin Assignments. . . . .	1-13
Table 1-10. Serial Interface Pin Assignments . . . . .	1-17
Table 1-11. LocalTalk Interface Pin Assignments. . . . .	1-19
Table 1-12. <b>SelectType</b> Functions . . . . .	1-22
Table 1-13. Factory Service Mode . . . . .	1-26
Table 1-14. Status Messages . . . . .	1-27
Table 1-15. Error Messages . . . . .	1-27
Table 1-16. Warning Messages. . . . .	1-28

## 1.1 FEATURES

The EPSON® EPL-9000 is a non-impact page printer that combines a semi-conductor laser with electro-photographic technology. This printer is small and light, and features high-speed, high-resolution printing. Maintenance is very easy as a result of various built-in diagnostic functions. The main features are:

- l1 No ozone
- ❑ Printing speed — 8 ppm (pages per minute) (A4 or letter size)
- ❑ Resolution — 600/300 dpi (dots per inch)
- ❑ Small footprint
- ❑ Easy maintenance
- ❑ HP® LaserJet® 4 emulation mode
- ❑ 45 built-in scalable fonts (35 Intellifonts and 10 TrueType fonts)
- ❑ ESC/P2™ emulation
- ❑ High-performance controller (the controller's CPU is a 19.2 MHz SPARKlite (MB86930))
- ❑ Bi Resolution Improvement Technology (**BiRITech**) refines the print quality by eliminating jagged edges from images and characters on 600 dpi and 300 dpi printing.
- ❑ Optional EPSONScript Level 2 (PostScript® compatible) module
- ❑ EPSON Micro Gray Technology (**EMGTech**), which is available when using EPSONScript Level 2 mode, refines gray scale printing to be comparable to printing on a 1200-dpi printer
- ❑ Small and low-cost optional LocalTalk™ interface module
- ❑ 2 MB standard RAM and up to 64 MB RAM with the addition of optional SIMMs
- ❑ Bidirectional parallel interface
- ❑ High-speed serial communication rate of 57.6K bps
- ❑ High-speed parallel communication rate of approximately 400 KB/second
- ❑ A multi-user, multi-emulation mode
- ❑ IES (Intelligent Emulation Switch) allows switching between EPSONScript mode and another mode
- ❑ SPL (Shared Printer Language) enables switching of the printer mode by command

Figure 1-1 shows an exterior view of the EPL-9000.




Figure 1-1. Exterior View of the EPL-9000

Table 1-1 lists the optional units available for the EPL-9000.

**Table 1-1. Options for EPL-9000**

Cat. No.	Description	Note	Machine Type
			EPL-9000
X3209*	EPSONScript Level 2 Module	Supports EPSONScript Level 2 mode (PostScript Level 2 compatible) fonts and commands	Yes
—	Local language ROM	Supports local language fonts	Yes
81242*	250 sheet universal paper tray (A4/Letter size)	A4/Letter size paper tray	Yes
81243*	250 sheet universal paper tray (A3/Double-Letter size)	A3/Double-Letter size paper tray	Yes
81241*	Lower paper cassette unit	Lower paper cassette unit (No include paper cassette)	Yes
3051022	Imaging cartridge	Toner cartridge	Yes
82326*	LocalTalk I/F Module	—	Yes
82307*/ 82308*	32 KB serial interface card	—	Yes
82310*/ 82311*	32 KB parallel interface card	—	Yes
82312*	LocalTalk card	—	Yes
82314*	COAX interface card	—	Yes
82315*	TWINAX interface card	—	Yes
82324*	Ethernet interface card for NetWare®	—	Yes

Note: LocalTalk card (C82312\*) cannot be used with LocalTalk I/F module (C82326\*).

## 1.2 SPECIFICATIONS

This section provides statistical data for the EPL-9000.

### 1.2.1 Basic Specifications

Printing method:	Laser beam scanning and dry electro-photography
Resolution:	600/300 dpi
Printing speed:	8 ppm (letter/A4), 5 ppm (B4), 4.3 ppm (A3) by cassette feed
First printing time:	18.9 seconds (A4 cassette feed) 19.1 seconds (Letter cassette feed) 25.0 seconds (A3 cassette feed)
Warm-up time:	Less than 120 seconds (at rated current and 20° C (68° F) temperature)
Paper supply:	See Table 1-2.

**Table 1-2. Paper Feed Methods**

Paper Supply		Capacity <sup>2</sup> (17 lb. (64 g/m <sup>2</sup> ) paper)	Paper Size	Usage Thickness (Ream Weight)
Standard built-in paper tray or optional lower paper cassette unit	A3/Double- letter paper cassette	250	A3, A4, A5, B4, B5, LT, HLT, LGL, EXE, GLG, B, F4	16 to 24 lb. (60 to 90 g/m <sup>2</sup> )
	A4/Letter paper cassette	250	A4, A5, B5, LT, HLT, EXE	
Manual feeder (MSI)		50	A4, A5, B5, LT, HLT, EXE, GLG, GLT, B, F4	16 to 24 lb. (60 to 135 g/m <sup>2</sup> )
		30	A4, A5, B5, LT, HLT, EXE	Special paper (label, OHP)
		5	International-B5, MON, C10, DL, C5	Envelopes made of 16 to 28 lb. (60 to 105 g/m <sup>2</sup> )

#### Notes:

1. The weight in pounds (lb) is determined by how much 500 sheets cut to 17x 22 inches would weigh; 1 g/m<sup>2</sup> = 0.2659763 lb.
2. The printer can use manual feed for A3, B4, LGL, GLG, B and F4 size paper, if user supports paper by hand.
3. When inserting A4, A5, B5, LT, HLT, EXE, and GLT size papers, keep the longer side horizontal.

Paper types:

See Table 1-3.

**Table 1-3. Paper Types**

Standard paper	Xerox® 4024 DP paper 20 lb. (75 g/m <sup>2</sup> )
Normal paper	Regular photocopier paper <b>Bond paper</b> Recycled paper 16 to 24 lb. (60 to 90 g/m <sup>2</sup> )
Special paper	Card stock (90 to 135 g/m <sup>2</sup> ) <b>Envelopes</b> Labels Letterhead Transparency (OHP) sheets Colored paper

Usability of special papers:

See Table 1-4.

**Table 1-4. Usability of Special Paper**

Input	Standard paper	Normal paper	OHP	Envelopes	Labels	Card Stock
Paper tray	R	R	P	N	P	N
Manual feed (MSI)	R	R	P	P	P	P
Envelope cassette	N	N	N	P	N	N

R: Reliable feeding and good image quality.

P: Possible, but better avoided.

N: Not supported.

Paper size range:

**98 mm (3.87 inches) to 297 mm (11.7 inches)** (Width)  
140 mm (5.5 inches) to 432 mm (17 inches) (Length)

Paper feed alignment and direction:

Center alignment for **all** sizes


Paper ejection:

Face down

Output tray capacity:

250 sheets (standard paper)

Printable area (standard paper): See Figure 1-2.



**Figure 1-2. Printable Area**

**Note:** The actual printable area depends on the printer mode.

Noise: Less than 35 dB(A) (standby)  
Less than 48 dB(A) (operating)

Ozone density: 0.05 ppm (typical)

Toxicity: No toxicity exists in organic photo conductor (OPC), toner, or plastic materials

## 1.2.2 Electrical Specifications

**Table 1-5. Electrical Specifications**

Description	100 V Version	200 V Version
Rated voltage	115 VAC	220-240 VAC
Input voltage range	104-127 VAC	198-264 VAC
Rated frequency range	50-60 Hz	
Input frequency range	47-63 Hz	
Power consumption	Less than 500 W	Less than 600 W

## 1.2.3 Reliability Specifications

MPBF (Mean Prints Between Failures): Over 12,000 sheets

**Note:** MPBF indicates average number of pages printed before occurrence of problem requiring replacement or service.

Jam rate: 1 out of 3,000 sheets or less (Standard paper)  
1 out of 2,000 sheets or less (Normal paper)  
1 out of 25 sheets or less (Label, Envelope, OHP)

Multiple paper feeds: 1 out of 800 sheets or less (Standard paper)  
1 out of 500 sheets or less (Normal paper)  
1 out of 25 sheets or less (Label, Envelope, OHP)

Paper curl height: 30 mm (1.2 inches) or less

MTTR (Mean Time To Repair): 30 minutes or less

Durability: 5 years or 300,000 sheets

### 1.2.4 Environmental Conditions for Operation (Including Imaging Cartridge)

Temperature:	10 to 32° C (50 to 90° F)
Humidity:	20 to <b>80% RH</b>
Altitude:	<b>2,500 m (8,200 feet)</b> or lower
Levelness:	Printer should <b>be</b> installed on a <b>level</b> plane.
<b>Illuminance:</b>	<b>3,000 IUX</b> or less (Must not be exposed to direct sunlight.)

### 1.2.5 Environmental Conditions for Storage and Transportation

Temperature:	0 to 35° C (32 to 95° F) over <b>full</b> storage term -20 to <b>40° C (-4 to 104° F)</b> under extreme conditions (Extremes are allowable for up to <b>1/30 of full</b> storage term) Temperature variation must be 10° C (18° F)/hour or less
Humidity:	20 to <b>80%<sub>RH</sub></b> over full storage term 5 to <b>95%RH</b> under extreme conditions (Extremes are allowable for up to <b>1/30 of full</b> storage term)
Drop test:	Height 52 cm
Vibration:	Vibration frequency <b>5 to 55 Hz and 55 to 5 Hz</b> Acceleration <b>1 G</b> Acceleration direction <b>3 direction</b>
Resistance to atmospheric pressure:	More than <b>740 hecto pascal</b>
Storage term:	12 months (following date of manufacture)

### 1.2.6 Applicable Standards

#### Safety Standards

120 VAC model:	None
220/240 VAC model:	EN 60950 (IEC950), NEMKO (IEC950), SETI (IEC950), SEMKO (IEC950), DEMKO (IEC950)

#### Safety Regulations (Laser radiation)

120 VAC model:	None
220/240 VAC model:	VDE 0837 (Laser <b>Class 1</b> )(IEC825), SETI (IEC825), SEMKO(IEC825), DEMKO (IEC825)

#### EMI

120 VAC model:	None
220/240 VAC model:	DOC Class B Vfg 243 (VDE 0878 Part 3,30) EN55022 class B (CISPR Pub.22 class B)

#### Others

Toner:	No effect on human health (OSHA-TSCA, EINECS)
OPC:	No <b>effect</b> on human health (OSHA)
Ozone:	<b>UL478</b> (5th edition)
Materials:	SWISS Environmental Law (No <b>CdS</b> must be contained)

### 1.2.7 Specification for Consumable (Imaging Cartridge)

Life: 6,500 pages

Note: In continuous printing mode with **A4/letter** paper at a **5%** image ratio (black/white ratio). The life varies, depending on the printing mode (continuous or intermittent) and/or the image ratio.

#### ***Environmental Conditions for Storage and Transportation***

Temperature: 0 to 35° C (32 to 95° F) over full storage term  
-20 to 40° C (-4 to 104° F) under extreme conditions  
(Extremes are allowable for up to 1/30 of full storage term)  
Temperature variations must be 10° C (18° F)/hour or less.

Humidity: 20 to 80% RH over full storage term  
5 to 95% RH under extreme conditions  
(Extremes are allowable for up to 1/30 of full storage term)

Drop test: Height 76 cm (30.4 inches)

Vibration: Same as printer

Resistance to atmospheric pressure: More than 740 **hecto pascal**

Storage term: 24 months (following date of manufacture)

### 1.2.8 Physical Specifications

Dimensions (Width x Depth x Height):

Printer: 437 x 473 x 270 mm (17.2 x 18.6x 10.6 inches)

Weight: Approx. 17 Kg (37.5 lb.) (consumable, excluding all options)

### 1.2.9 Software Specifications

Built-in modes: HP LaserJet 4 emulation (PCL<sup>®</sup> 5e)  
 EPSON GL/2 mode (LJ4-GL/2 mode and GL-like mode)  
 FX @\$70/1170, LX-100) emulation mode  
 ESC/P 2 (LQ-570/1070) mode

Note: The EPSON GL/2 mode is similar to the GL/2 mode included in the HP LaserJet 4 emulation. Table 1-6 shows the differences between EPSON GL/2 mode and the GL/2 mode in the HP LaserJet 4 emulation. While in EPSON GL/2 mode, the operator can enter GL/2 mode without sending the ESC %B (Enter GL/2 mode) command. If the operator's application software cannot send the ESC %B command, then use this mode.

**Table 1-6. Differences between EPSON GL/2 and GL/2 in the HP LaserJet 4 Emulation**

	EPSON GL/2 Mode	GL/2 for HP LaserJet 4 Emulation Mode
PCL mode	Does not exist	Exists as the initial mode
Paper eject	Supports PG, AF commands	Supported in PCL
Auto eject	SelectType setting	Not available
Reduced printing	SelectType setting	Available in PCL
Switch to PCL (ESC %A)	Not supported	supported
Reset (ESC E)	Ejects paper and then initialize	Ejects paper, switches to PCL, and then initialize
PJL, EJL, and ES	supported	supported
Advance Full Page (PG, AF)	supported	Not supported

**Notes:** EPSON GL/2 mode has two operational modes. One is LJ4-GL/2 mode; the other is the GL-like mode.

LJ4-GL2 mode emulates the GL/2 mode in the HP LaserJet 4 emulation. The user can print with software that supports the HP 7600 series plotter.

The GL-like mode features all the commands of the LJ4-GL/2 mode, plus a few additional commands. The GL-like mode emulates some of the HP-GL<sup>®</sup> plotter (HP 7475A, etc.) commands. If the application software uses unsupported commands for the GL-like mode, print cannot be assured.

Optional modes: EPSONScript Level 2 (PostScript Level 2 emulation) mode

Auxiliary software: Hex dump  
 Status sheet  
 Font sample

Built-in fonts: See Table 1-7

**Table 1-7. Built-in Fonts**

Resident Fonts		Applicable Mode		
		HP LJ4 GL/2	ESC/P 2	FX
<b>Bitmap fonts</b>				
Line Printer	16.66 cpi (Portrait)	s	NS	NS
Prestige	12 cpi (Portrait)	NS	s	s
Prestige	20 cpi (Portrait)	NS	s	s

S: Supported, NS: Not Supported

Table 1-7. Built-in Fonts (Continued)

Resident Fonts		Applicable Mode		
		HP LJ4 GL/2	ESC/P 2	FX
<b>Scalable fonts</b>				
Dutch™ 801	Roman <b>SWC</b>	s	NS	NS
Dutch 801	Bold <b>SWC</b>	s	NS	NS
Dutch 801	Italic <b>SWC</b>	s	NS	NS
Dutch 801	Bold Italic <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Zapf Humanist 601	Demi <b>SWC</b>	s	NS	NS
Zapf Humanist 601	Bold <b>SWC</b>	s	NS	NS
Zapf Humanist 601	Demi Italic <b>SWC</b>	s	NS	NS
Zapf Humanist 601	Bold Italic <b>SWC</b>	s	NS	NS
Ribbon 131	<b>SWC</b>	s	NS	NS
Clarendon	Condensed <b>SWC</b>	s	NS	NS
Swiss™ 742	<b>SWC</b>	s	NS	NS
Swiss 742	Bold <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Swiss 742	Medium Italic <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Swiss 742	Bold Italic <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Swiss 742	Condensed <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Swiss 742	Bold Condensed <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Swiss 742	Condensed Italic <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Swiss 742	Bold Italic Condensed <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Incised 901	<b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Incised 901	Black <b>SWC</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Incised 901	Italic <b>SWC</b>	s	NS	NS
Original Garamond	<b>SWC</b>	s	NS	NS
Original Garamond	Bold <b>SWC</b>	s	NS	NS
Original Garamond	Italic <b>SWC</b>	s	NS	NS
Original Garamond	Bold Italic <b>SWC</b>	s	NS	NS
Audrey Two	<b>SWC</b>	s	NS	NS
Flareserif 821	<b>SWC</b>	s	NS	NS
Flareserif 821	Extra Bold	s	NS	NS
Swiss 721	Roman <b>SWM</b>	s	s	NS
Swiss 721	Bold <b>SWM</b>	s	s	NS
Swiss 721	Oblique <b>SWM</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Swiss 721	Bold Oblique <b>SWM</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Dutch 801	Roman <b>SWM</b>	<b>s</b>	<b>s</b>	<b>NS</b>
Dutch 801	Bold <b>SWM</b>	<b>s</b>	<b>s</b>	<b>NS</b>
Dutch 801	Italic <b>SWM</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Dutch 801	Bold Italic <b>SWM</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
Symbol Set	<b>SWA</b>	<b>s</b>	<b>NS</b>	<b>NS</b>
More WingBats	<b>SWM</b>	s	NS	NS
Courier	<b>SWC</b>	s	s	s
Courier	Bold <b>SWC</b>	s	s	s
Courier	Italic <b>SWC</b>	s	NS	NS
Courier	Bold italic <b>SWC</b>	s	NS	NS
Letter Gothic	Roman <b>SWC</b>	<b>s</b>	<b>s</b>	<b>s</b>
Letter Gothic	Bold <b>SWC</b>	<b>s</b>	<b>s</b>	<b>s</b>
Letter Gothic	Italic <b>SWC</b>	<b>s</b>	<b>s</b>	<b>s</b>

S: Supported, NS: Not Supported

**Font Symbol Sets**

**HP LaserJet 4 Mode (bitmap fonts): 15 symbol sets**

Roman-8	<b>Norweg1</b>
Roman Extension	Italian
<b>ECM94-1</b>	<b>Swedis2</b>
ANSI ASCII	UK
<b>French2</b>	German
Legal	Spanish
<b>IBM®-US</b>	<b>IBM-DN</b>
<b>PcMultilingual</b>	

**HP LaserJet4 Mode (scalable fonts) : 34 symbol sets**

Roman-8	<b>Norweg1</b>
Italian	<b>ECM94-1</b>
<b>Swedis2</b>	ANSI ASCII
UK	<b>French2</b>
German	<b>Legal</b>
8859-2 ISO	Spanish
<b>PsMath</b>	8859-9 ISO
<b>WiTurkish</b>	<b>MsPublishing</b>
VeMath	DeskTop
Math-8	<b>WiE.Europe</b>
PcTk437	windows
<b>PsText</b>	IBM-US
<b>IBM-DN</b>	<b>McText</b>
<b>PcMultilingual</b>	<b>VeInternational</b>
VeUS	PiFont
<b>PcE.Europe</b>	<b>symbol</b>
<b>WiAnsi</b>	Wingdings

**ESC/P 2 Mode: 15 International characters and 9 code tables**

USA	<b>SPAIN1</b>
<b>FRANCE</b>	JAPAN
GERMANY	NORWAY
UK	DENMARK2
<b>DENMARK1</b>	<b>SPAIN2</b>
<b>SWEDENT</b>	<b>L.AMERICA</b>
ITALY	KOREAR
LEGAL	

<b>PcUSA(437)</b>	<b>PcMultilingual(850)</b>
<b>PcPortuguese(860)T</b>	<b>TPcCanFrench(863)</b>
<b>PcNordic(865)</b>	<b>PcTurk2(857)</b>
<b>PcE.Europe(852)</b>	<b>BpBRASCII</b>
<b>BpAbicomp</b>	

**FX Mode: 13 International characters and 9 code tables**

USA	<b>SPAIN1</b>
FRANCE	JAPAN
GERMANY	NORWAY
UK	DENMARK2
<b>DENMARK1</b>	<b>SPAIN2</b>
<b>SWEDENT</b>	<b>L.AMERICA</b>
ITALY	

<b>PcUSA(437)</b>	<b>PcMultilingual(850)</b>
<b>PcPortuguese(860)T</b>	<b>PcCanFrench(863)</b>
<b>PcNordic(865)</b>	<b>PcTurk2(857)</b>
<b>PcE.Europe(852)</b>	<b>BpBRASCII</b>
<b>BpAbicomp</b>	

## 1.3 INTERFACE SPECIFICATIONS

The EPL-9000 is equipped with the following external interfaces:

- Parallel interface
- RS-232C/RS-422 interface
- Optional LocalTalk interface
- Optional Type B interface

### 1.3.1 Parallel Interface

The parallel interface has two modes as follows:

- Compatibility mode (same as parallel interface of EPSON's current page printer)
- Reverse mode

#### 1.3.1.1 Compatibility Mode of Parallel Interface

System:	$\overline{\text{STROBE}}$ synchronization, 8-bit parallel data transfer
Handshaking:	$\overline{\text{BUSY}}$ and $\overline{\text{ACKNLG}}$ signals
Connector type:	P90-25027-1 (Amphenol) receptacle
Applicable plug:	57-30360 (Amphenol or equivalent)
Transfer speed:	Approximately 400,000 bytes/second (max.)
Signal timing:	See Figure 1-3.
Signal description:	See Table 1-8.




Figure 1-3. Compatibility Mode Signal Timing

Table 1-8. Parallel Interface Pin Assignments

Pin No.	Signal Name	IO	Description
1	<u>STROBE</u>	IN	<u>STROBE</u> is a strobe <b>pulse</b> used to read data from the host computer. The pulse width must be more than 0.5 $\mu$ s. Normally it is HIGH, and data is latched at the trailing edge of this <b>signal</b> .
2-9	DATA 1-8	IN	DATA 1 to 8 are parallel data bits. When the signal is HIGH, the data bit is 1, and when it is LOW, the data bit is 0. The most significant bit ( <b>MSB</b> ) is DATA8. The signal state <u>must be maintained</u> for 0.5 $\mu$ sec. on either side of the <u>STROBE</u> signal active edge.
10	<u>ACKNLG</u>	OUT	<u>ACKNLG</u> is an acknowledge <b>pulse</b> with an approximate width of 1 or 10 $\mu$ sec. This signal goes LOW when the data reception is completed, which indicates that the printer can accept new data. <b>Timing with the BUSY signal is specified through SelectType.</b>
11	BUSY	OUT	The <b>BUSY</b> signal informs the host computer of the printer state. When the <b>signal</b> is HIGH, the printer cannot <b>accept data</b> .
12	PE	OUT	The PE signal indicates paper <b>empty</b> for the standard tray selected through <b>SelectType</b> or command, or for the optional paper <b>cassette</b> . Paper empty is indicated by HIGH.
13	<u>SLCT</u>	OUT	Use in reverse mode.
14	<u>AUTO-FEED</u>	IN	<b>Not</b> used.
15	<u>NC</u>		<b>Not</b> used.
16	<u>GND</u>	-	<b>Logic</b> around level.
17	<u>CHASSIS GND</u>	-	connected to the printer chassis. The printer chassis <b>GND</b> and the signal <b>GND</b> are connected to each other.
18	<u>NC</u>	-	Not connected.
19-30	<u>GND</u>	-	Ground level for the twisted pair return signal.
31	<u>INIT</u>	IN	The <u>STROBE</u> <b>signal</b> is <b>ignored</b> when this <b>signal</b> is LOW.
32	<u>ERROR</u>	OUT	This level goes LOW when the printer is: <ul style="list-style-type: none"> <li>• out of paper</li> <li>• in paper jam state</li> <li>• in error state</li> <li>• off line</li> </ul>
33	<u>GND</u>		Same as for pins 19 to 30.
34	<u>NC</u>	-	<b>Not</b> used.
35	<u>+5</u>	-	Pulled <b>up</b> to <b>+5V</b> through 1.0 <b>Kohm</b> resistance.
36	<u>SLCT IN</u>	-	Use the reverse mode.

### 1.3.1.2 Reverse Mode

The reverse mode for EPL-9000 supports the nibble mode of IEEE-P1284. This printer can run in reverse mode, in which the printer can inform the computer of its status by EIJ and PJJ commands.

System: IEEE-P1284 nibble mode  
 Connector type: P90-25027-1 (Amphenol) receptacle  
 Applicable plug: 57-30360 (Amphenol or equivalent)  
 Signal description: See Table 1-9.

**Table 1-9. Parallel Interface Pin Assignments**

Pin No.	Signal Name	I/O	Description
1	$\overline{\text{STROBE}}$	IN	<b>HostClk:</b> This signal is a strobe pulse used to read extension request values from the host computer during negotiation.
2-9	DATA 1-8	IN	The signals are data bits of extension request values during negotiation. This printer supports following values: 0000 0100: Request Device ID (by nibble mode sending) 0000 0000: Request nibble mode
10	$\overline{\text{ACKNLG}}$	OUT	<b>PtrClk:</b> Printer data sending clock.
11	BUSY	OUT	<b>PtrBusy:</b> Printer sending data bits 3 and 7 during data transfer to host computer.
12	PE	OUT	<b>AckDataReq:</b> Printer sending data bits 2 and 6 during data transfer to host computer.
13	SLCT	OUT	<b>Xflag:</b> Printer sending data bits 2 and 6 during data transfer to host computer.
14	$\overline{\text{AUTO-FEED}}$	IN	<b>HostBusy:</b> This signal informs the printer of the host computer state. When the signal is HIGH, the host computer cannot accept data.
15	NC		Not used.
16	GND		Logic ground level.
17	CHASSIS GND	-	Connected to the printer chassis. The printer chassis <b>GND</b> and the signal <b>GND</b> are connected to each other.
18	NC		Not connected.
19-30	GND	-	Ground level for the twisted pair return signal.
31	INIT	IN	<b>nInit:</b> High level fixed
32	$\overline{\text{ERROR}}$	OUT	<b>nDataAvail:</b> Printer sending data bits 0 and 4 during data transfer to host computer.
33	GND	-	Same as for pins 19 to 30.
34	NC		Not used.
35	+5		Pulled up to +5V through 1.0 Kohm resistance.
36	$\overline{\text{SLCT IN}}$	IN	<b>1284Active:</b> If this signal is set to HIGH, this printer active <b>P1284</b> (reverse mode).

Figure 1-4 shows the parallel interface state switch diagram.





Figure 1-4. Parallel Interface State Switch Diagram

Figure 1-5 shows the negotiation timing chart.



**Figure 1-5. Negotiation Timing Chart**

Note 1: The signal is set to HIGH when not sending data.


The signal is set to LOW when sending data.

Note 2: The signal is set to HIGH, if extension request value was 04h.

Note 3: HB DA: Host Busy Data Available

HB DNA: Host Busy Data Not Available

Figure 1-6 shows the data transfer timing chart.



**Figure 1-6. Data Transfer Timing Chart**

Note 1: The signal is set to HIGH when not sending data.


The signal is set to LOW when sending data.

Note 2: The signal is set to HIGH if the extension request value is 04h.

Note 3: HB DA: Host Busy Data Available

HB DNA: Host Busy Data Not Available

Figure 1-7 shows the termination timing chart.




**Figure 1-7. Termination Timing chart**

Note 1: The signal is HIGH when **HB DNA**.  
The signal is LOW when **HB DA**.

Note 2: The signal is set to HIGH if the extension request value is **04h**.

Note 3: Idle= LOW

Figure 1-8 shows the interrupt timing chart.



**Figure 1-8. Interrupt Timing Chart**

Note 1: The signal is set to HIGH, if extension request value was **04h**.

### 1.3.2 Serial Interface

Type:	RS-232C/RS-422		
Transfer system:	Full duplex		
Synchronization:	Asynchronous start-stop system		
	Start-bit:	1 bit	
	Stop-bit:	1 or 2 bits	
	Data length:	7 or 8 bits	
	Parity:	Odd, even, or none	
Protocol:	X-ON/X-OFF (can be combined with DTR control) DTR control (can be combined with X-ON/X-OFF)		
Transfer speed:	300,600, 1200, 2400,4800,9600,19200,38400, or 57600 bps		
Error:	Overrun error:	Processed as missing data and replaced by "***"	
	Parity error:	Replaced by "***"	
	Framing error:	Replaced by "***"	
	Breaking Character:	Ignored	
Signal description:	See Table 1-10.		

**Table 1-10. Serial Interface Pin Assignments**

Pin No.	Signal Name	I/O	Description
1	CHASSIS-GND	-	Connected to the printer chassis. The printer chassis <b>GND</b> and the signal <b>GND</b> are connected to each other.
2	TXD	OUT	Serial ASCII data output by the printer. It maintains "MARK" state (LOW level) between transmitted character codes. Logic 0 is at HIGH level ("SPACE") and logic 1 is at LOW level ("MARK").
3	RXD (RXD+)	IN	Serial ASCII <b>data</b> input to the printer. It maintains "MARK" state (LOW level) between received character codes.
4	RTS	OUT	Transmission request signal output from the printer. It is always at HIGH level during power ON.
5	CTS	IN	Always ignored.
6	DSR	IN	Signal input to the printer. The printer can transmit data through TXD while DSR is at HIGH level. X-ON/X-OFF, however, can be transmitted regardless of DSR state. It can always be ignored by setting <b>SelectType</b> (factory setting).
7	SIGNAL-GND	-	Ground.
8	DCD	IN	Always ignored.
9	(SD+)	OUT	See Note 4.
10	(SD-)	OUT	See Note 4.
11 to 17	NC		Not connected.
18	(RD-)	IN	See Note 4.
19	NC		Not connected.
20	DTR	OUT	Signal output by printer. When the <b>DTR</b> signals HIGH, the <b>RXD</b> signal can be received by the printer. The <b>SelectType</b> settings do not specify <b>DTR</b> control, the signal level is HIGH while the printer power is on. When <b>SelectType</b> setting is used for <b>DTR</b> control, <b>DTR</b> goes LOW in case of any error conditions. The data ( <b>RXD</b> ) from host computer must be stopped within 128 characters after <b>DTR</b> goes LOW.
21-25	NC		Not connected.

Note 1: ( ) indicates an **RS-422** signal, which is **SelectType**.

Note 2: "US", "DSR", and "DTR" states can be selected through **SelectType**.

Note3: Although the signals **RTS**, **CTS**, **DSR**, **DTR**, and **DCD** are **RS-232C** level, they can be used for **RS-422** mode if selected through **SelectType**.

Note4: **SD+**, **SD-**:

Serial ASCII data output from the printer.

HIGH level; when **SD+** voltage is higher than **SD-** voltage.

LOW level; when **SD+** voltage is less than **SD-** voltage.

Logic 0 is "SPACE" and logic 1 is "MARK" state must be maintained between transmitted character codes.

**RD+**, **RD-**:

Serial ASCII data input from the computer.

HIGH level; when **RD+** voltage is higher than **RD-** voltage.

LOW level; when **RD+** voltage is less than **RD-** voltage.

Logic 0 is "SPACE" and logic 1 is "MARK" state must be maintained between transmitted character codes.

## Handshaking

When the vacant area for data in the input buffer drops to 256 bytes, the printer outputs an **X-OFF** code or sets the **DTR** signal level to **LOW**, indicating that the printer cannot receive more data. Once the vacant area for data in the buffer recovers to 512 bytes, the printer outputs an **X-ON** code or sets the **DTR** flag to **HIGH**, indicating that the printer is again ready to receive data.

## Protocol

There are two types of protocols, as listed below, and each of them can be designated by **SelectType** independently.

### ■ DTR/DSR protocol

**SelectType** is used to execute the **DTR/DSR** control protocol. The **DTR** signal is set to **HIGH** when the printer is ready to receive data, and to **LOW** when conditions indicate an error or that the receiving buffer is full.

When the error is cleared and the printer returns to on-line mode, the signal returns to **HIGH**. When **SelectType** is used to set the **DTR** control **OFF**, **DTR** is always set **HIGH**. The printer transmits **TXD** only when **DSR** is at the **HIGH** level (**DSR** is always considered **HIGH** when the **SelectType** setting for **DSR** is **OFF**). **X-ON/X-OFF** transmission is independent of the **DSR** state.

### ■ X-ON/X-OFF (DC1/DC3) protocol

**SelectType** is used to execute the **X-ON/X-OFF** protocol. The **X-OFF (DC3)** code is output if status indicates an error, and the printer warns the host to stop data transmission within 128 characters. No further **X-OFF** codes are sent in response to additional data received from the host after the **X-OFF** code has been sent once. The **X-ON (DC1)** code is output after all renditions given in the error are cleared.

When the remaining capacity of the receive buffer reaches 256 characters, **X-OFF (DC3)** is output once. It is sent only once, even if there are multiple errors. The printer goes on line automatically at power on, and outputs an **X-ON** code. Transmission of **X-ON/X-OFF** codes can be defined by **SelectType**.

**1.3.3. Optional LocalTalk Interface**

This printer can use the optional LocalTalk interface module.

Type:	LocalTalk
Signal level:	Same as RS-422 signal level
Protocol:	X-ON/X-OFF (cannot be combined with DTR control) DTR control (cannot be combined with X-ON/X-OFF)
Transfer speed:	230.4 K bps
Signal description:	See Table 1-11.

**Table 1-11. LocalTalk Interface Pin Assignments**

Pin No.	Signal Name	I/O	Description
1	DTR	OUT	Signal output by the printer. When the DTR signals HIGH, the RXD signal can be received by the printer.
2	CTS	IN	The printer transmits the data through TXD while CTS is HIGH.
3	TXD-	OUT	Serial ASCII data output from the printer. HIGH level; when SD+ voltage is higher than SD- voltage. LOW level; when SD+ voltage is less than SD- voltage. Logic 0 is "SPACE" and logic 1 is "MARK" state must be maintained between transmitted character codes.
4	GND		Ground.
5	RXD-	IN	Serial ASCII data input from computer. HIGH level; when RD+ voltage is higher than RD- voltage. LOW level; when RD+ voltage is less than RD- voltage. Logic 0 is "SPACE" and logic 1 is "MARK" state must be maintained between transmitted character codes.
6	TXD+	OUT	Refer to TXD-.
7	NC		Not connected.
8	RXD+	IN	Refer to RXD-.