

Product: 1989 EPSON LX-810/850 Terminal Printer Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/1989-epson-lx-810850-terminal-printer-service-repair-workshop-manual/>

# LX - 810 / 850

# TECHNICAL MANUAL

## EPSON

Sample of manual. Download All 176 pages at:  
<https://www.arepairmanual.com/downloads/1989-epson-lx-810850-terminal-printer-service-repair-workshop-manual/>

#### NOTICE

- “ All rights reserved. Reproduction of any part of this manual in any from whatsoever without SEIKO EPSON's express written permission is forbidden.
- The contents of this manual are subject to change without notice.
- \* All efforts have been made to ensure the accuracy of the contents of this manual. However, should any errors be detected, SEIKO EPSON would greatly appreciate being informed of them.
- “ The above notwithstanding SEIKO EPSON can assume no responsibility for any errors in this manual or the consequences thereof.

© Copyright 1989 by SEIKO EPSON CORPORATION  
Nagano, Japan

## PRECAUTIONS

Precautionary notations throughout the text are categorized relative to 1) personal injury, and 2) damage to equipment:

**DANGER** Signals a precaution which, if ignored, could result in serious or fatal personal injury. Great caution should be exercised in performing procedures preceded by a **DANGER** headings.

**WARNING** Signals a precaution which, if ignored, could result in damage to equipment.

The precautionary measures itemized below should always be observed when performing repair/maintenance procedures.

### DANGER

- 1. ALWAYS DISCONNECT THE PRODUCT FROM BOTH THE POWER SOURCE AND THE HOST COMPUTER BEFORE PERFORMING ANY MAINTENANCE OR REPAIR PROCEDURE.**
- 2. NO WORK SHOULD BE PERFORMED ON THE UNIT BY PERSONS UNFAMILIAR WITH BASIC SAFETY MEASURES AS DICTATED FOR ALL ELECTRONICS TECHNICIANS IN THEIR LINE OF WORK.**
- 3. WHEN PERFORMING TESTING AS DICTATED WITHIN THIS MANUAL, DO NOT CONNECT THE UNIT TO A POWER SOURCE UNTIL INSTRUCTED TO DO SO. WHEN THE POWER SUPPLY CABLE MUST BE CONNECTED, USE EXTREME CAUTION IN WORKING ON POWER SUPPLY AND OTHER ELECTRONIC COMPONENTS.**

### WARNING

- 1. REPAIRS ON EPSON PRODUCT SHOULD BE PERFORMED ONLY BY AN EPSON CERTIFIED REPAIR TECHNICIAN.**
- 2. MAKE CERTAIN THAT THE SOURCE VOLTAGE IS THE SAME AS THE RATED VOLTAGE, LISTED ON THE SERIAL NUMBER/RATING PLATE. IF THE EPSON PRODUCT HAS A PRIMARY-AC RATING DIFFERENT FROM THE AVAILABLE POWER SOURCE, DO NOT CONNECT IT TO THE POWER SOURCE.**
- 3. ALWAYS VERIFY THAT THE EPSON PRODUCT HAS BEEN DISCONNECTED FROM THE POWER SOURCE BEFORE REMOVING OR REPLACING PRINTED CIRCUIT BOARDS AND/OR INDIVIDUAL CHIPS.**
- 4. IN ORDER TO PROTECT SENSITIVE  $\mu$ P CHIPS AND CIRCUITRY, USE STATIC DISCHARGE EQUIPMENT, SUCH AS ANTI-STATIC WRIST STRAPS, WHEN ACCESSING INTERNAL COMPONENTS.**
- 5. REPLACE MALFUNCTIONING COMPONENTS ONLY WITH THOSE COMPONENTS RECOMMENDED BY THE MANUFACTURER; INTRODUCTION OF SECOND-SOURCE ICs OR OTHER NONAPPROVED COMPONENTS MAY DAMAGE THE PRODUCT AND VOID ANY APPLICABLE EPSON WARRANTY.**

# PREFACE

**This manual describes functions, theory of electrical and mechanical operations, maintenance, and repair of the LX-8 10/850.**

**The instructions and procedures included herein are intended for the experienced repair technician, and attention should be given to the precautions on the preceding page. The chapters are organized as follows:**

**Chapter 1 - Provides a general product overview, lists specifications, and illustrates the main components of the printer.**

**Chapter 2 - Describes the theory of printer operation.**

**Chapter 3 - Discusses the options**

**Chapter 4 - Includes a step-by-step guide for product disassembly, assembly, and adjustment.**

**Chapter 5 - Provides Epson-approved techniques for troubleshooting.**

**Chapter 6 - Describes preventive maintenance techniques and lists lubricants and adhesives required to service the equipment.**

**•The contents of this manual are subject to change without notice.**

REV.-A

REVISION TABLE

REVISION	DATE ISSUED	CHANGE DOCUMENT
A	Mar 27, 1989	1st issue

# TABLE OF CONTENTS

<b>CHAPTER 1.</b>	<b>GENERAL DESCRIPTION</b>
<b>CHAPTER 2.</b>	<b>OPERATING PRINCIPLES</b>
<b>CHAPTER 3.</b>	<b>OPTIONAL EQUIPMENTS</b>
<b>CHAPTER 4.</b>	<b>DISASSEMBLY, ASSEMBLY, AND ADJUSTMENT</b>
<b>CHAPTER 5.</b>	<b>TROUBLESHOOTING</b>
<b>CHAPTER 6.</b>	<b>MAINTENANCE</b>
<b>APPENDIX</b>	

# CHAPTER 1

## GENERAL DESCRIPTION

<b>1.1</b>	<b>FEATURES</b> .....	1-1
<b>1.2</b>	<b>SPECIFICATIONS</b> .....	1-3
	<b>1.2.1 Hardware Specifications</b> .....	1-3
	<b>1.2.2 Firmware Specifications (ESC/P)</b> .....	1-10
<b>1.3</b>	<b>INTERFACE OVERVIEW</b> .....	1-12
<b>1.4</b>	<b>DIP SWITCH AND JUMPER SETTINGS</b> .....	1-15
	1.4.1 DIP Switch Settings .....	1-15
	1.4.2 Jumper Setting .....	1-15
<b>1.5</b>	<b>SELECTYPE FUNCTION</b> .....	1-16
<b>1.6</b>	<b>SHEET LOADING AND SHEET EJECTION</b> .....	1-16
<b>1.7</b>	<b>TEAR-OFF FUNCTION</b> .....	1-17
<b>1.8</b>	<b>OPERATING INSTRUCTIONS</b> .....	1-18
	<b>1.8.1 Self-Test</b> .....	1-18
	1.8.2 Hexadecimal Dump Function .....	1-19
	1.8.3 Buzzer Operation .....	1-20
	1.8.4 Printer Initialization .....	1-21
	1.8.5 Adjust Lever Operation .....	1-21
<b>1.6</b>	<b>MAIN COMPONENTS</b> .....	1-22
	1.6.1 TAMA Board .....	1-23
	1.6.2 TAPNL-W Control Panel .....	1-23
	1.6.3 TA Filter Unit .....	1-24
	1.6.4 Printer Mechanism (M-3D10) .....	1-24
	1.6.5 Housing .....	1-25

## LIST OF FIGURES

Figure 1-1.	Exterior View of the LX-810/850 .....	1-2
Figure 1-2.	Pin Configuration .....	1-3
Figure 1-3.	Cut-Sheet Printing Area .....	1-6
Figure 1-4.	Printing Area for Continuous Paper .....	1-7
Figure 1-5.	Roll Paper Printing Area .....	1-8
Figure 1-6.	Data Transmission Timing .....	1-12
Figure 1-7.	Self-Test Printout .....	1-18
Figure 1-8.	Hexadecimal Dump Function .....	1-19

**Figure 1-9. Lever Position** .....1-21

**Figure 1-10. LX-810/850 Component Layout** ..... 1-22

**Figure 1-11. TAMA Main Control Board** ..... 1-23

**Figure 1-12. TAPNL-W Control Panel** .....1-23

**Figure 1-13. TA Filter Unit** .....1-24

**Figure 1-14. Model-3D1 O Printer Mechanism** .....1-24

**Figure 1-15. Housing** .....1-24

## LIST OF TABLES

**Table 1-1. interface Options** ..... 1-1

**Table 1-2. Optional Unit** .....1-1

**Table 1-3. Cut-Sheet Specifications** .....1-4

**Table 1-4. Continuous Paper Specifications** .....1-4

**Table 1-5. Roll Paper Specifications** .....1-4

**Table 1-6. Envelope Specifications** .....1-5

**Table 1-7. Label Specifications** .....1-5

**Table 1-8. printing Speed** .....1-10

**Table 1-9. Character Size** .....1-10

**Table 1-10. Column Width (maximum characters/line)** ..... 1-11

**Table 1-11. Connector Pin Assignments and Signal Functions** ..... 1-12

**Table 1-12. Printer Select/Deselect Control** ..... 1-14

**Table 1-13. Settings for DIP Switch 1 (SW 1)** .....1-15

**Table 1-14. Settings for DIP Switch 2 (SW 2)** ..... 1-15

**Table 1-15. International Character Set Selection** ..... 1-15

**Table 1-16. Lever Position** ..... 1-21

## 1.1 FEATURES

The LX-8 10/850 is a small, light-weight, low-cost, advanced paper handling printer comparable to the LX-800. Its main features are:

1. **Advanced paper handling:** Auto backout and cut sheet loading
2. **Expanded ESC/P-code printing,** implemented as a standard feature
3. **Printing speeds:**
  - 200 cps (high speed draft)
  - 150 cps (draft 10 cpi)
  - 180 cps (draft 12 cpi)
4. **Optional 8100 series interface**
5. **Clear, easy-to-read printing with a standard EPSON font**
6. **Two built-in NLQ (Near Letter Quality) fonts (Roman and Saris Serif)**
7. **Control panel switch selection of Draft, Roman, or Saris Serif font**
8. **Control panel switch selection of normal or condensed printing**
9. **Control panel mode settings are saved in non-volatile memory**
10. **Easy handling of cut sheets with the optional cut-sheet feeder (CSF)**

The LX-8 10/850 is equipped with the standard EPSON 8-bit parallel interface. Various interface options enable users to print data from a variety of computers. Table 1-1 lists the interface options, Table 1-2 lists the optional units available for the LX-8 10/850, and Figure 1-1 shows an exterior view of the LX-8 10/850.


**Table 1-1.** Interface Options

Model	Description
8143	New serial interface board
8148	Intelligent serial interface board
8165	Intelligent IEEE-488 interface board

**NOTE:** Refer to the "Optional Interface Technical Manual" for details.

Table 1-2. Optional Units

Model	Description
C8061 2*	Single bin cut sheet feeder
C80006*	Pull tractor unit
8310	Roll paper holder
8750	Ribbon cartridge (Black)



**Figure 1-1. Exterior View of the LX-81 O/850**

## 1.2 SPECIFICATIONS

This section describes LX-8 10/850 printer specifications.

### 1.2.1 Hardware Specifications

Printing Method	Serial, impact, dot matrix
Pin Configuration	9 wires (diameter 0.29mm)




Figure 1-2. Pin Configuration

Feeding Method	Friction feed, tractor feed (push tractor: standard, pull tractor: optional)
----------------	--

When handling paper, note the following precautions described below

#### Friction Feed Precautions:

1. Do not use continuous paper.
2. Do not use a single sheet shorter than 182mm or longer than 364mm.
3. Do not perform any reverse paper feed within 8.5mm from the top, or 22mm from the bottom.
4. Do not perform reverse feed greater than 1/6 inch after the paper end is detected.
5. Use the pull-out unit.
6. Do not use multi-part single sheet forms.

#### Tractor Feed Precautions:

1. Release the friction feed mechanism.
2. Joining of copying paper must be by line or dotted pasting.
3. Copy paper must be a carbon-less, multi-part paper.

**a. Push Tractor Feed**

1. Use the pull-out unit.
2. Do not perform reverse feeding greater than 1/6 inch.
3. After paper end detection, accuracy of paper feed cannot be assured and reverse feeding cannot be performed.

**b. Push Pull Feed**

1. Remove the pull-out unit and attach the pull tractor unit.
2. Do not loosen the paper between the platen and pull tractor unit.
3. Adjust precisely the horizontal position of the pull and push tractor.
4. Do not perform reverse feeding greater than 1/6 inch.
5. Do not perform reverse feeding after the paper end is detected.

**c. Pull Tractor Feed**

1. Remove the pull-out unit and attach the pull tractor unit.

Line Spacing                      1/6 inch, 1/8 inch, or programmable in units of 1/216 inch  
 Paper Insertion                From rear  
 Paper-Feed Speed              Approximately 95 ins/line (1/6 inch line feeding)  
     Approximately 75 ins/line (1/6 inch in page feed)

**Paper Specifications See Table 1-3 through 1-6**

**Table 1-3. Cut-Sheet Specifications**

Width	182 mm to 257 mm (7.15 in. to 10.1 in.)
Length	182 mm to 364 mm ( 7.15 in. to 14.3 in.)
Thickness	0.065 mm to 0.14 mm (0.0025 in. to 0.0055 in.)
Weight	14 lb. to 24 lb. (52.3 g/m <sup>2</sup> to 90 g/m <sup>2</sup> )
Quality	Plain paper
Copies	Not available

**Table 1-4. Continuous Paper Specifications**

Width	101 mm to 254 mm (4.0 in. to 10.0 in.)
Copies	3 sheets (1 original and 2 copies)
Quality	Plain paper
Total Thickness	0.065 mm to 0.25 mm (0.0025 in. to 0.01 in.)
Weight	1 sheet - 14 lb. to 22 lb., (52.3 g/m <sup>2</sup> to 82 g/m <sup>2</sup> ) 3 sheets -- 12 lb. to 15 lb., (40 g/m <sup>2</sup> to 58.2 g/m <sup>2</sup> ) each

**Table 1-5. Roll Paper Specifications**

Width	216 mm ± 3 mm (8.5 in. ± 0.12 in.)
Weight	14 lb. to 17 lb. (45 kg to 55 kg)
Quality	Plain paper
Thickness	0.07 mm to 0.09 mm ( 0.0028 in. to 0.0035 in.)

Table 1-6. Envelope Specifications

<b>Size</b>	<b>No.6 (166 mm x 92 mm), No. 10 (240 mm x 104 mm)</b>
<b>Quality</b>	<b>Bond paper, Plain paper, Air mail</b>
<b>Thickness</b>	<b>0.16 mm to 0.52 mm (0.0063 in. to 0.0197 in.) Difference of thickness within printing area must be less than 0.25 mm (0.0098 in.).</b>
<b>Weight</b>	<b>12 lb. to 24 lb. (45 g/m<sup>2</sup> to 91 g/m<sup>2</sup>)</b>

- NOTES:** “ Envelope printing is only available at normal temperature.  
 \* Keep the *long* side of the envelope horizontal at setting.  
 \* Set the left of a No.6 envelope at the setting mark of the sheet guide.


Table 1-7. Label Specifications

<b>Size</b>	<b>2 1/2 in. X 15/16 in. (63.5 mm X 23.8 mm)</b>
<b>Weight</b>	<b>55Kg (68 g/m<sup>2</sup>)</b>
<b>Thickness</b>	<b>0.19 mm (0.0075 in.) max. Thickness excluding the base paper must be equal to or less than 0.12 mm (0.0075 in.).</b>

- NOTES:** \* Label printing is only available at normal temperature.  
 •Labels must be a fanfold type.  
 •For printing labels on pressure sensitive paper, the following conditions must be met: (1) jointed by dotted or line pasting. (2) total thickness is equal to or less than 0.3mm (0.01 18 inch). (3) 5 degree C to 35 degree C and 10% to 80% RH.

Printing Area

The figures below show the printing area for cut sheets.



- \*1 ) At least 3.0 mm (0.12 in.) when the paper width is less than 229 mm (9 in.); at least 24 mm (0.9 in.) when the paper width is 257 mm ( 10.1 in.)
- Printing is possible approx. 28 mm from the paper's detected bottom edge; the 13.5 mm value (lowest print position) is for reference only. Paper feed accuracy can not be assured within 22 mm (0.87 in.) of either the top or bottom edge.

Figure 1 -3. Cut-Sheet Printing Area






Figure 1-5. Roll Paper Printing Area

**Ink Ribbon**

Type: 8750 Ribbon Cartridge  
 Color: Black  
 Reliability: 3 million characters at 14 dots/character

**Reliability**

Mean Cycles Between Failure (MCBF): 3 million lines (excluding printhead)  
 Mean Time Between Failure (MTBF): 4000 POH (25% duty)

**Life of Printhead**

200 million strokes/wire

**Safety Approval**

Safety Standards: UL478 (U.S. version)  
 CSA22.2 #220 (Canada version)  
 VDE0806 (TUV) (European version)  
 Radio Frequency Interference (RFI): FCC class B (U.S. version)  
 VDE 0871 (Self-certification)(European version)

**Electrical Specifications**

<b>Power Conditions</b>	<b>120 VAC <math>\pm</math> 10% (120V version)</b> <b>220/240 VAC <math>\pm</math> 10% (220/240V version)</b>
<b>Frequency Range</b>	<b>49.5 to 60.5 Hz</b>
<b>Power Consumption</b>	<b>28W (Draft self-test)</b>
<b>insulation Resistance</b>	<b>10 Mgohms min. (Between AC Line and Chassis)</b>
<b>Dielectric Strength</b>	<b>(At 50 or 60 Hz, between the AC line and chassis)</b>
<b>120V Version</b>	<b>1 KV AC (rms/minute) or 1250V AC (rms/second)</b>
<b>220/240V Version</b>	<b>1.5KV AC (rms/10 minutes) or 1250V AC (rms/second)</b>

**Environmental Conditions**

<b>Temperature</b>	<b>5 to 35 degrees C (41 to 95 degrees F) -operating</b> <b>-30 to 60 degrees C (-22 to 149 degrees F) -storage</b>
<b>Humidity</b>	<b>10 to 80 % RH (no condensation) -operating</b> <b>5 to 85 % RH (no condensation) -storage</b>
<b>Resistance to Shock</b>	<b>1 G, within 1 mS -operating</b> <b>2 G, within 1 mS -storage</b>
<b>Resistance to Vibration</b>	<b>0.25 G, 55 Hz max. -operating</b> <b>0.50 G, 55 Hz max. -storage</b>

**Physical Specifications**

<b>Weight</b>	<b>5.75 Kg</b>
<b>Dimensions</b>	<b>418 mm (Width) X 339 mm (Depth) X 141 mm(Height),</b> <b>excluding knobs and paper guides</b>

**1.2.2 Firmware Specifications (ESC/P)**

<b>Control Code</b>	ESC/PTMlevel ESC/P-81 (EPSON Standard Code for Printers)
<b>Printing Direction</b>	Bi-directional printing with logic seeking (text) Uni-directional (left to right) printing (Bit-image)
<b>Input data buffer</b>	4 K bytes
<b>Character Set</b>	96 ASCII characters 96 Italic characters 32 International characters (13 countries) 32 International Italic characters 96 IBM Graphics characters
<b>Font</b>	EPSON NLQ Roman EPSON NLQ Saris Serif EPSON Draft
<b>Printing Speed</b>	See Table 1-8

**Table 1-8. Printing Speed**

Type of Letters	Print Speed (cps)
High Speed Draft	200
Pica	150
Elite	180
Double-Width	75
Emphasized	75
Double-Width Emphasized	37
Condensed	128
Double-Width condensed	64
Double-Width Elite	90
<b>Condensed Elite</b>	<b>150</b>
NLQ Pica	25
NLQ Elite	30

<b>Dot-matrix Format</b>	9×9 Text mode (Draft) 18 X 20 Text mode (NLQ)
<b>Character Size</b>	See Table 1-9

**Table 1-9. Character Size**

Type of Letters	Width (mm)	Height (mm)
Pica	2.1	3.1
Elite	1.7	3.1
Condensed	1.05	3.1
Double-Width Pica	4.2	3.1
Double-Width Elite	3.4	3.1
Double-Width Condensed	2.1	3.1
Condensed Elite	0.85	3.1
Emphasized	2.1	3.1
Double-Width Emphasized	4.2	3.1
Super/Subscript	Depends On Pitch	1.6

Printing Columns

See Table 1-10

Table 1-10. Column Width (maximum characters/line)

Type of Letters	Column Width (CPL)	Column/inch (cpi)
Pica	80	10
Elite	96	12
Condensed	137	17
Double-Width Pica	40	5
Double-Width emphasized	40	5
Double-Width Elite	48	6
Double-Width Condensed	68	8.5
Condensed Elite	160	20
Emphasized	80	10

### 1.3 INTERFACE OVERVIEW

The standard 8-bit parallel interface provided with this printer meets the specifications described below.

Data Format	8-bit parallel
Synchronization	By <u>STROBE</u> pulse
Handshaking	By <u>BUSY</u> and <u>ACKNLG</u> signal
Signal Level	TTL-compatible
Adaptable Connector	57-30360 (amphanol) or equivalent
Data Transmission Timing	See Figure 1-6




Figure 1-6. Data Transmission Timing

Table 1-11 shows the connector pin assignments and signal functions of the 8-bit parallel interface.

Table 1-11. Connector Pin Assignments and Signal Functions

Pin No.	Signal Name	Return Pin No.	DIR	Functional Description
1	<u>STROBE</u>	19	In	Strobe pulse to read the input data. Pulse width must be more than 0.5 μs. Input data is latched at falling edge of this signal.
2	DATA 1	20	In	Parallel input data to the printer. "HIGH" level means data "1". "LOW" level means data "0".
3	DATA 2	21	In	
4	DATA 3	22	In	
5	DATA 4	23	In	
6	DATA 5	24	In	
7	DATA 6	25	In	
8	DATA 7	26	In	
9	DATA 8	27	In	
10	<u>ACKNLG</u>	28	out	This pulse indicates data is received and ready to accept next data. Pulse width is 12 μs approx.
11	BUSY	29	out	"HIGH" indicates printer cannot accept next data.
12	PE	30	out	"HIGH" indicates paper-out. This signal is effective only when <u>ERROR</u> signal is "LOW".
13	SLCT	—	Out	Always "HIGH" output. (Pulled up to +5V through 3.3kohms register.)

Table 1-11. Connector Pin Assignments and Signal Functions (Cont.)

Pin No.	Signal Name	Return Pin No.	DIR	Functional Description
14	$\overline{\text{AUTOFEED-XT}}$	—	In	if "LOW" when the printer is initialized, a line feed is automatically performed by input of "CR" code. (Auto LF)
15				Not used
16	GND			Ground for twisted-pair grounding
17	Chassis GND	—	—	Chassis ground level of printer
18				Not used
9 to 30	GND			Grounds for twisted-pair grounding
31	I NIT	16	In	Pulse (Width: $50\mu\text{s}$ min., active "LOW") input for printer initialization.
32	$\overline{\text{ERROR}}$		out	"LOW" indicates some error is occurred in the printer.
33	GND	—	—	Ground for twisted-pair grounding
34		—	—	Not used
35		—	Out	Always "HIGH". (Pulled up to +5V through 3.3 Kohms register.)
36	$\overline{\text{SLCT-IN}}$	—	In	If "LOW" when printer is initialized, the DC1/DC3 control is disabled.

- NOTES:**
1. "DIR" refers to the direction of the signal flow as viewed from the printer.
  2. "Return" denotes a twisted-pair return line.
  3. The cable used must be shielded to prevent noise.
  4. All interface conditions are based on TTL levels. Both the rise and fall times of all signals must be less than 0.2 us.
  5. The  $\overline{\text{AUTO FEED-XT}}$  signal can be set LOW by DIP switch 2-4.
  6. The  $\overline{\text{SELECT-IN}}$  signal can be set LOW by jumper 1.
  7. Printing tests, including interface circuit tests, can be performed without using external equipment by setting DATA 1-8 of the interface connector to certain codes and connecting the  $\overline{\text{ACKNLG}}$  signal to the  $\overline{\text{STROBE}}$  signal.

Table 1-12 shows Printer Select/Deselect (DC1/DC3) control, including relations among ON-LINE, SELECT-IN input, DC 1/DC3 and interface signals.

Table 1-12. Printer Select/Deselect Control

ON-LINE SW	SLCT-IN	DC1/DC3	ERROR	BUSY	ACKNLG	DATA ENTRY
OFF-LINE	HIGH/LOW	DC 1/DC3	LOW	HIGH	No pulse	Disable
ON-LINE	HIGH	DC 1	HIGH	LOW/HIGH (During data entry)	Pulse output after entry	Enable(Normal Process)
		DC3	HIGH	LOW/HIGH (During data entry)	Pulse output after entry	Enable (Waits DC 1. See Note 2)
	LOW	DC 1	HIGH	LOW/HIGH (During data entry)	Pulse output after entry	Enable (Normal process)
		DC3	HIGH	LOW/HIGH (During data entry)	Pulse output after entry	

- NOTES: 1. In Table 1-12, it is assumed that no ERROR status exists other than that attributable to the OFF-LINE mode.
2. Once the printer has been put in the deselected state by the DC3 code, the printer will not revert to the selected state unless the DC 1 code is input again. (In the deselected state, the printer ignores input data until the DC 1 code is received.)
  3. The DC 1 and DC3 codes are enabled only when the SLCT-IN signal (Input Connector No.36 for the parallel interface unit) is HIGH and printer power is initialized.
  4. If the SLCT-IN signal is LOW when the printer is initialized, DC1/DC3 printer select/deselect control is invalidated, and these control codes are ignored.
  5. If the SLCT-IN signal is HIGH and is not set to LOW by jumper 1 when the printer is initialized, the printer starts from the selected (DC 1 ) state.

## 1.4 DIP SWITCH AND JUNIPER SETTINGS

This section describes DIP switch settings for the LX-8 10/850 printer.

### 1.4.1 DIP Switch Settings

The two DIP switches are located on the side of the printer and function as shown in Tables 1-13 through 1-15. Note that the status of the DIP switches is read only at power on or upon receipt of the I NIT signal.

Table 1-13. Settings for **DIP** Switch 1 (**SW1**)

No.	Description	ON	OFF	Factory Setting
1	Character Pitch	12 cpi	10 cpi	OFF
2	Shape of Zero	0	0	OFF
3	Table Selection (note)	Graphics	Italics	OFF
4	Tear Off	Invalid	Valid	OFF
5	Draft Mode	Normal	High	OFF
6	International	See Table 1-15		ON
7	Character Set			ON
8	Selection			ON

**NOTE:** When the DIP switch is set for the Italic table, at power on printer defaults to ESC 7 table. When the switch is set for the Graphic table, at power on it defaults to ESC 6 table.

Table 1-14. Settings for DIP Switch 2 (**SW2**)

No.	Description	ON	OFF	Factory Setting
1	Page length	12 in.	11 in.	OFF
2	Cut-Sheet Feeder (CSF) Mode	On	off	OFF
3	1-inch skip	On	off	OFF
4	AUTO FEED XT Signal Internally Fixed or Not	Fixed to LOW	Depends On External Signal	OFF

Table 1-15. International Character Set Selection

1-6	1-7	1-8	Country	1-6	1-7	1-8	Country
On	On	On	U.S.A	Off	On	On	Denmark 1
On	On	Off	France	Off	On	Off	Sweden
On	Off	On	Germany	Off	Off	On	Italy
On	Off	Off	U.K.	Off	Off	Off	Spain 1

### 1.4.2 Jumper Setting

Jumper 1 (user-selectable) is located on the TAMA board. If the jumper is connected, the  $\overline{\text{SLCT-IN}}$  signal is fixed to LOW, and DC 1 /DC3 printer select control is ignored.

## 1.5 SELECTYPE FUNCTION

SelectType allows the user to choose fonts and the printing mode easily. This function provides for selection of Draft, Roman, or Saris Serif fonts and selection of normal printing or condensed printing modes. SelectType is effective only when the printer is ON LINE and not printing.

To select Roman or Saris Serif, press the NLQ button. A buzzer sounds when the NLQ button is pressed. When it sounds twice, the Roman font is selected. When it sounds three times, the Saris Serif font is selected.

To select the Draft font, press the DRAFT button. The buzzer will sound once, indicating that the DRAFT font is selected.

To set for condensed printing when the printer is in the print mode, press the CONDENSED button once (the buzzer will sound once), and the printer will enter the condensed print mode.

To cancel condensed printing, press the CONDENSED button again. After you press the button, the buzzer sounds twice to tell you that condensed printing is cancelled.

## 1.6 SHEET LOADING AND SHEET EJECTION

The release lever enables disengaging of the push tractor unit drive mechanism. The printer therefore provides some improved paper-handling functions through combination of the release-lever and LOAD/EJECT control panel switch.

### Cut Sheet Loading And Ejection

To load a sheet of paper, position the paper release lever back, place the sheet along the paper guide, and press the LOAD/EJECT switch. This loads the paper to the top-of-form position. Pressing the LOAD/EJECT switch after the paper has been loaded will cause the paper to be ejected.

### Continuous Paper Loading And Ejection (Back-out)

To load fanfold paper, move the paper release lever forward, and insert the paper into the push tractor. Pressing the LOAD/EJECT switch will then cause paper to be automatically loaded to the top-of-form position. Pressing the LOAD/EJECT switch after the fanfold paper has been loaded will cause the printer to eject the paper backward from the push tractor. To back out several pages, press the LOAD/EJECT switch several times (reverse feed is performed on a page-by-page basis).

The ON-LINE LED will flash only when the paper is loaded and the ON-LINE switch pressed. This indicates that the printer has entered "Top-of-form adjust" mode, and that the user may adjust the top-of-form position, as well as the loading positions for subsequent forms. Adjustment is made using the FORM FEED button,

which will increment the paper forward, and the LINE FEED switch, which will increment the paper in reverse. (The minimum feed amount is 2/216 inch).

When cut sheet is used, the adjusted Top-of-form position will be lost when the printer is re-initialized, and the Top-of-form will be reset to the default value. When continuous paper is used, however, the memory of the adjusted Top-of-form position will be retained even after printer initialization.

## 1.7 TEAR-OFF FUNCTION

The Tear-Off function can be enabled by making the appropriate DIP switch setting, and will operate when the release-lever is set to the tractor position. In such a case, if the input data buffer is empty and the printer is *ON-LINE*, the paper will automatically be fed to the tear-off position, and the *ON-LINE* LED will flash to indicate that the *FORM FEED* and *LINE FEED* switches are now available to perform micro-adjustment. The user may then adjust the paper to the tear-off position. This position becomes the new tear-off position default, and will remain valid even if the printer is reset and reinitialized, and regardless of whether the main power has been interrupted. When new data are input to the printer, the paper will automatically be returned to its original position, and printing will then start. Paper having been advanced to the tear-off position will also be returned to its original position if the *ON-LINE* switch is pressed (switching the printer from *ON-LINE* to *OFF-LINE*).



## 1.8.2 Hexadecimal Dump Function

The printer enters the HEX-DUMP mode when it is powered on while the LINE-FEED and FORM-FEED buttons are pressed down.

In the HEX-DUMP mode, the hexadecimal representation of the input data is printed out, along with corresponding ASCII characters. This function is valuable for checking the data the printer has received from the host. If input data is a control code rather than a character code, a period (.) is printed in the ASCII column.

```
Data Dump Mode
0000 1E 40 0D 1B 55 00 1B 33 1F 00 0D 0A 0D 0A 0A 0A .@..U..T.....
0010 12 1B 70 00 1B 78 01 1B 57 00 1B 4D 20 20 20 20 ..p...x..W..M
0020 43 49 41 50 54 45 52 20 31 0D 0A 20 20 20 20 47 CHAPTER 1 . G
0030 45 4E 45 52 41 4C 20 44 45 53 43 52 49 50 54 49 ENERAL DESCRIPTI
0040 4F 4E 0D 0A 0D 0A 20 20 20 20 31 2E 31 20 46 45 ON.... 1.1 FE
0050 41 54 55 52 45 0D 0A 20 20 20 20 31 2E 32 20 53 ATURE.. 1.2 S
0060 50 45 43 49 46 49 43 41 54 49 4F 4E 53 0D 0A 20 PECIFICATIONS..
0070 20 20 20 20 20 20 31 2E 32 2E 31 20 48 61 72 1.2.1 Har
0080 64 77 61 72 65 20 53 70 65 63 69 66 69 63 61 74 dware Specificat
0090 49 6F 6E 73 0D 0A 20 20 20 20 20 20 20 20 20 20 ions.. 1.
00A0 32 2E 32 20 46 49 72 6D 77 61 72 65 20 53 70 65 2.2 Firmware Spe
00B0 63 69 66 69 63 61 74 69 6F 6E 73 20 2B 45 53 43 cifications (ESC
00C0 2F 50 29 0D 0A 20 20 20 20 31 2E 33 20 49 4E 54 /F).. 1.3 INT
00D0 45 52 46 41 43 43 20 4F 56 45 52 56 49 45 57 0D ERFACE OVERVIEW..
00E0 0A 20 20 20 31 2E 34 20 44 49 50 20 41 4E 44 . 1.4 DIP AND
00F0 20 4A 55 4D 50 45 52 20 53 45 54 54 49 4E 47 53 JUMPER SETTINGS
0100 0D 0A 20 20 20 20 20 20 20 20 31 2E 34 2E 31 20 .. 1.4.1
0110 44 49 50 20 53 77 69 74 63 68 20 53 65 74 74 69 DIP Switch Setti
0120 6E 67 73 0D 0A 20 20 20 20 20 20 20 20 20 20 20 20 31 2E 34 ngs.. 1.4
0130 2E 32 20 4A 75 6E 70 65 72 20 53 65 74 74 69 6E .2 Jumper Settin
0140 67 0D 0A 20 20 20 20 31 2E 35 20 53 45 4C 45 43 g... 1.5 SELEC
0150 54 59 50 45 20 46 55 4E 43 54 49 4F 4E 0D 0A 20 TYPE FUNC1 [ON].
0160 20 20 20 31 2E 36 20 53 48 45 45 54 20 4C 4F 41 1.6 SHEET LOA
0170 44 49 4E 47 20 41 4E 44 20 53 49 45 45 54 20 45 DING AND SHEET E
0180 4A 45 43 54 49 4F 4E 0D 0A 20 20 20 31 2E 37 JECT1[ ]1.. 1.7
0190 20 54 45 41 52 2E 4F 46 44 20 46 55 4E 43 54 49 TEAR-OFF FUNC1
01A0 4F 4E 0D 0A 20 20 20 31 2E 38 20 4F 50 45 52 ON.. 1.8 OPER
01B0 41 54 49 4E 47 20 49 4E 53 54 52 55 43 54 49 4F ATING INSTRUCTIO
01C0 4E 55 0D 0A 20 20 20 20 20 20 20 31 2E 38 2E .. 1.8.
01D0 31 20 53 65 6C 66 2D 54 65 73 74 0D 0A 20 20 20 1 Self-Test..
01E0 20 20 20 20 31 2E 38 2E 32 20 48 65 78 61 64 . 1.8.2 Hexad
01F0 65 63 69 6D 61 6C 20 44 75 6D 70 20 46 75 6E 63 ecimal Dump Func
0200 74 69 6F 6E 0D 0A 20 20 20 20 20 20 20 20 20 20 31 2E tion.. 1.
0210 39 2E 33 20 42 75 74 74 65 72 20 4F 70 65 72 61 8.3 Buzzer Opera
0220 74 69 6F 6E 0D 0A 20 20 20 20 20 20 20 20 20 20 31 2E tion..
0230 38 2E 34 20 50 72 69 6E 74 65 72 20 49 6E 69 74 8.4 1', Printer Init
0240 69 61 6C 69 74 61 74 69 6F 6F 0D 0A 20 20 20 20 20 20 31 2E ization..
0250 20 20 20 20 31 2E 38 2E 35 20 41 64 6A 75 73 74 . 1.8.5 Adjust
0260 20 4C 65 76 65 72 20 4F 70 65 72 61 74 69 6F 6E Lever Operation
0270 0D 0A 20 20 20 31 2E 36 20 4D 41 49 4E 20 43 .. 1.6 MAIN C
0280 4F 4D 50 4F 4E 45 4E 54 53 0D 0A 20 20 20 20 20 20 31 2E 36 MPONENTS..
0290 20 20 20 31 2E 36 2E 31 20 54 41 4D 41 20 42 6F 1.6.1 TAMA Be
02A0 61 72 64 0D 0A 20 20 20 20 20 20 20 20 20 20 31 2E 36 ard.. 1.6
02B0 2F 32 20 54 41 5C 4E 4C 2D 57 20 43 6F 6E 74 72 .2 TAPNL-W Contr
02C0 6F 6C 20 50 61 6E 65 6C 0D 0A 20 20 20 20 20 20 20 20 20 20 31 2E 36 ol Panel..
02D0 20 20 31 2E 36 2E 33 20 54 41 20 46 69 6C 74 65 1.6.3 TA Filte
02E0 72 20 55 6F 69 74 0D 0A 20 20 20 20 20 20 20 20 20 20 31 2E 36 r Unit..
02F0 31 2E 36 2E 35 20 50 72 69 6E 74 65 72 20 4D 65 1.6.5 Printer Me
0300 63 68 61 6E 69 73 6D 20 2B 4D 2D 33 44 31 30 29 chanism (M-3D10)
0310 0D 0A 20 20 20 20 20 20 20 31 2E 36 2E 36 20 .. 1.6.6
0320 4B 6F 75 73 69 6E 67 0D 0A 0D 0A 20 20 20 20 31 Housing.... 1
0330 2E 31 20 46 45 41 54 55 52 45 53 0D 0A 0D 0A 20 .1 FEATURES....
0340 20 20 20 54 68 65 20 4C 5B 2D 3B 31 30 2F 3B 35 The LX-B10/B5
0350 30 20 69 73 20 61 20 73 6D 61 6C 6C 2C 20 6C 69 0 is a small, li
0360 67 68 74 2D 77 65 69 67 68 74 1' 20 6C 6F 77 2D ght-weight, low-
0370 63 6F 73 74 2C 20 61 64 76 61 6E 63 65 64 0D 0A cost, advanced..
0380 20 20 20 20 70 61 70 65 72 20 6B 61 6E 64 6C 69 paper handli
0390 6E 67 20 70 72 69 6E 74 65 72 20 63 6F 6D 70 61 ng printer compa
03A0 72 61 62 6C 65 20 74 6F 20 74 68 65 20 4C 5B 2D rable to the LX-
03B0 3B 30 30 2E 20 49 74 73 20 6D 61 69 6E 0D 0A 20 800. Its main..
03C0 20 20 20 64 65 61 74 75 72 65 73 20 61 72 65 3A features are:
03D0 0D 0A 0D 0A 20 20 20 31 2E 20 20 20 41 64 76 .... 1. Adv
03E0 41 6E 63 65 64 20 70 61 70 65 72 20 68 61 6E 64 anced paper hand
03F0 6C 69 6E 67 3A 20 41 75 74 6F 20 62 61 63 6B 6F ling: Auto backo
0400 75 74 20 61 6E 64 20 63 75 74 20 73 6B 65 65 74 ut and cut sheet
```

Figure 1-8. Hexadecimal Dump Function

### 1.8.3 Buzzer Operation

The buzzer sounds under the following conditions:

**BEL code:** The buzzer sounds for 0.1 second when a BEL code is input.  
**Carriage trouble:** Beeps 6 times, pausing briefly after 3rd beep.  
**Paper-out:** Beeps 20 times, pausing briefly after every 4 beeps.  
**Abnormal voltage:** Beeps 5 times, pausing after every beep.  
**Incorrect RAM:** (SRAM) Beeps 8 times, pausing briefly after every 2 beeps. (Inside CPU)  
Beeps indefinitely until power OFF.

**Recognition of panel operation:**

Beeps 1 or 2 or 3 times in setting print mode.

**Factory setting:** Beeps once when the value under micro-adjusting is equal to the factory-set value.

**Sheet ejection failure (in CSF mode):**

Beeps 20 times, pausing briefly after every 4 beeps.

**Illegal paper release/unrelease:**

Beeps continuously when the paper release lever is changed when the paper is in the paper path. Beeps until the lever is changed again or the paper is completely out of the path.

### 1.8.4 Printer Initialization

The printer is initialized when:

- 1 ) AC power is turned on
- 2) The INIT signal is input

Here is a brief summary of the initialization sequence.

- a) Return the printhead to the leftmost position.
- b) Set ON LINE mode.
- c) Clear the print buffer and input buffer.
- d) Set the line spacing to 1/6 inches.
- e) Set the page length to 11 or 12 inches according to the DIP switch setting.
- f) Clear all vertical tab positions.
- g) Set the horizontal tab position at 13-column intervals.
- h) Set the print mode according to the DIP switch setting and the non-volatile memory setting of the control panel.

### 1.8.5 Adjust Lever Operation

The adjust lever must be set to the proper position according to the paper of paper you are using. Refer to Table 1-16 and Figure 1-9 below.

Table 1-16. Lever Position

Lever Position	Paper
2nd step	Cut sheet, continuous paper (non copy, 1 + 1 copy)
3rd step	Continuous paper (1 +2 copies)
4th step	Label
4th to 7th step	Envelope

•If printing density becomes lighter, set the adjust lever position one step narrower.




Figure 1-9. Lever Position

## 1.6 MAIN COMPONENTS

The main components of the LX-8 10/850 printer are designed for easy removal and replacement to maintain/repair the printer.

The main components are:

- 1 ) TAMA board: Main control board. The CPU on this board controls all main functions.
- 2) TAPNL-W control panel: Control panel.
- 3) TA filter unit: Transformer and filter board.
- 4) M-3D 10: Printer mechanism.




Figure 1-10. 1.X-81 0/850 Component Layout