

Product: 2000 TEREX TA30 Articulated Dumptruck Workshop Maintenance Manual

Full Download: <https://www.repairmanual.com/downloads/2000-terex-ta30-articulated-dumptruck-workshop-maintenance-manual/>

[CLICK HERE FOR
TABLE OF
CONTENTS](#)



TA30 Articulated Dumptruck Maintenance Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND ML1 5RY
REF. NO. SM 799

Sample of manual. Download All 406 pages at:

<https://www.repairmanual.com/downloads/2000-terex-ta30-articulated-dumptruck-workshop-maintenance-manual/>

Product: 2000 TEREX TA30 Articulated Dumptruck Workshop Maintenance Manual
Full Download: <https://www.arepairmanual.com/downloads/2000-terex-ta30-articulated-dumptruck-workshop-maintenance-manual/>

THIS PAGE IS INTENTIONALLY LEFT BLANK

The information contained within this Alert must not be made available to third parties not authorised to receive it.

Service Information Alert

DATE: April 1994

B168

MODEL: General

SUBJECT: VITON 'O' RINGS AND SEALS (FLUORO-ELASTOMERS) - SAFETY HAZARDS

PURPOSE:

To advise potentially hazardous condition.

DETAIL:

It has been brought to our attention that 'Viton' material used in manufacture of oil seals and 'O' rings, produces a highly corrosive acid (Hydrofluoric) when subjected to temperatures above 315° C.

The resulting contamination can have extreme consequences on human tissue since it is almost impossible to remove after contact.

We therefore recommend the following procedure when it is necessary to inspect any equipment that has been subjected to a high temperature i.e. fire.

- a. Visually inspect for any gaskets or seals which have suffered from heat; they will appear black and sticky.
- b. If this is affirmed - **Do Not Touch**
- c. Make enquiries to ascertain the material composition. Any Fluoro-elastomer (Viton, Fluorel or Tecnoflon) should be considered dangerous but natural rubber and nitrile are non-hazardous.
- d. If Fluoro-elastomer seals have been used, then the affected area **MUST** be decontaminated before undertaking further work.
- e. Disposable Heavy Duty Gloves (Neoprene) **MUST** be worn and the affected area decontaminated by washing thoroughly with Limewater (Calcium Hydroxide solution).
- f. Any cloths, residue and gloves used **MUST** be safely discarded after use.

Note: Burning of the discarded items is **NOT RECOMMENDED**, except in an approved incineration process where the gaseous products are treated by alkaline scrubbing.

TEREX SERVICE DEPARTMENT

THIS PAGE IS INTENTIONALLY LEFT BLANK

NOTICE DE SÉCURITÉ IMPORTANTE

Un entretien et des réparations adéquats sont importants pour la sécurité, un fonctionnement fiable de tous les véhicules à moteur. Les procédures d'entretien recommandées et décrites dans cette publication sont des méthodes efficaces permettant l'exécution d'opérations d'entretien. Certaines de ces opérations d'entretien nécessitent l'utilisation d'outils conçus tout particulièrement à cette fin. Les outils spéciaux doivent être utilisés lorsqu'ils sont recommandés.

Il est important de remarquer que cette publication comprend différents AVERTISSEMENTS et NOTES qui doivent être lus avec précaution afin de minimiser le risque de blessures du personnel ou de mise en pratique de méthodes de service inadéquates risquant d'endommager le véhicule ou de le rendre peu sûr. Il est également important de comprendre que ces AVERTISSEMENTS et NOTES ne sont pas exhaustifs. Il n'est pas possible de connaître, d'évaluer et de faire part au personnel de TOUTES les méthodes imaginables en fonction desquelles l'entretien peut être effectué ou de tous les risques possibles en résultant. Par conséquent, une évaluation aussi large n'a pas été prise en considération. Donc, quiconque utilise une procédure d'entretien ou un outil qui n'est pas recommandé doit tout d'abord s'assurer que ni sa sécurité et ni la sécurité du véhicule ne sera remise en cause par la méthode d'entretien qu'il/elle sélectionne.

Deux types d'en-tête sont utilisées dans ce manuel pour attirer votre attention.

1.  **AVERTISSEMENT** - Ce symbole est utilisé lorsqu'une procédure de fonctionnement, pratique, etc., qui, si elle n'est pas observée correctement, risque d'entraîner des blessures corporelles voire la mort. Recherche ce symbole pour indiquer les précautions de sécurité importantes. Il signifie - **ATTENTION! SOYEZ PRUDENT! VOTRE SECURITE EST EN JEU!**
2. **Note** - Ce symbole est utilisé lorsqu'une procédure de fonctionnement, méthode, etc., qui, si elle n'est pas observée strictement, risque d'entraîner des dommages ou une destruction de l'équipement.



AVERTISSEMENT

N'utilisez jamais des pièces qui sont altérées, modifiées ou affaiblies lors du fonctionnement. Ceci peut sérieusement remettre en cause l'intégrité de la machine et provoquer des dommages de l'équipement ou de graves blessures corporelles.

THIS PAGE IS INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

Section No.	Description	SM No.
000	GENERAL INFORMATION	
0000	Technical Data - TA30	1937 Rev 1
100	CHASSIS	
0010	Frames	1960
0020	Articulation and Oscillation Pivot - Pre May 2000 Production	1975
0020	Articulation and Oscillation Pivot - From May 2000 Production	1988 Rev 1
0040	Hood and Mounting	1984 Rev 1
0070	Fenders and Mounting	1963
110	ENGINE	
0030	Engine and Mounting	1964
0040	Kysor DST Fan	1974
0050	Air Cleaner	1958
120	TRANSMISSION	
0010	Transmission and Mounting	1965
130	DRIVELINES	
0010	Front and Rear Drivelines	1534 Rev 1
140	FRONT AXLE GROUP	
0020	Axle Group (Hub) (Refer to Section 160-0030)	-
0040	Wheel Rim and Tyre (Refer to Section 160-0050)	-
0060	Differential Drive Head (Refer to Section 160-0020)	-
150	CENTRE AXLE	
0020	Differential Drive Head	1971
160	REAR AXLE GROUP	
0020	Differential Drive Head	1969
0030	Axle Group (Hub)	1968
0050	Wheel Rim and Tyre	1970
165	BRAKE PARTS	
0010	Brake Parts - Rear	1962
0020	Brake Parts - Front	1961
170	PARKING BRAKE	
0010	Parking Brake and Mounting	1967
180	SUSPENSION SYSTEM	
0020	Front Suspension	1979
0021	Air Spring	1480
0022	Levelling Valve	1481
0040	Rear Suspension	1978
190	ELECTRICAL SYSTEM	
0000	Circuit Diagrams	1946 Rev 1
0270	Switches and Sensors	1959 Rev 1
200	FUEL SYSTEM	
0040	Fuel Tank, Lines and Mounting	1942

TABLE OF CONTENTS

Section No.	Description	SM No.
210	COOLING SYSTEM	
0000	Cooling System	1983
0040	Radiator, Header Tank and Mounting	1987
0060	Transmission Oil Cooler	1977
0100	Hydraulic Oil Cooler	1976
220	STEERING SYSTEM	
0000	Steering System Schematic	1943
0050	Steering Pump	-
0090	Steering Valve	1986 Rev 1
0105	Priority Valve	1947
0120	Steering Cylinder	1955
0140	Emergency Valve	1944
	(Refer to Section 230-0050)	
230	BODY SYSTEM	
0000	Body System Schematic	1949 Rev 1
0040	Hydraulic Tank	1950
0050	Main Hydraulic Pump	1951
0060	Body Control Valve	1952
0081	Body Control Joystick	1953 Rev 1
0121	Pilot Supply Valve	1954
0130	Body Cylinder	1956
250	BRAKING SYSTEM	
0000	Air Braking System Schematic	1948
0000	Hydraulic Braking System Schematic	1982
0070	Treadle Valve	1939
0170	Air Tanks and Mounting	1941
0190	Park Emergency Control Valve	1940
0200	Air Drier	1985 Rev 1
0260	Pressure Converter	1508
0270	Air Breather	1509
0280	Relay Emergency Valve	1945
0290	Pressure Protection Valve (4 way)	1938
260	OPERATORS COMPARTMENT	
0010	Cab and Mounting	1957
0090	Driver Seat and Mounting	1981
0130	Air Conditioning	1966
270	BODY	
0010	Body and Mounting	1980
300	MISCELLANEOUS	
0020	Lubrication System	1972
0070	Service Tools	1973
0080	Axle Bolt and Nut Torque Specifications	1521
0080	Standard Bolt and Nut Torque Specifications	1238
0090	Unit Storage	1239

* * * *

GENERAL INFORMATION - Technical Data

Section 000-0000

SM - 2476




Fig. 1 - Machine Dimensions

ENGINE

Make/Model Cummins MTA11-C300
 Type Four cycle, low emission, direct injection diesel, water-cooled, turbocharged and aftercooled.
 Gross power at 2 100 rev/min 224 kW (300 hp, 304 PS)
 Net power at 2 100 rev/min 214 kW (287 hp, 291 PS)

Note: Gross power rated to SAE J1995 Jun 90. Engine emission meets USA EPA/CARB MOH 40 CFR 89 and EU NRMM (non-road mobile machinery) directive.

Maximum Torque ... 1 376 Nm (1 015 lbf ft) at 1 300 rev/min
 Number of cylinders/configuration 6, in line
 Bore x Stroke 125 x 147 mm (4.92 x 5.79 in)
 Total Displacement 10.8 litres (660 in³)
 Air cleaner Dry type, double element
 Starting Electric
 Maximum Speed (No load) 2 450 rev/min
 Maximum Speed (Full load) 2 100 rev/min
 Idle Speed 675/750 rev/min
 Safe Operating Angle 43°/94% Grade

TRANSMISSION

Make/Model ZF 6WG 260 II Automatic with manual override. The transmission assembly consists of a torque converter close-coupled to a countershaft-type gearbox with integral output transfer gearing. Automatic shifting throughout the range, with kickdown feature. Lockup action in all forward gears. A torque proportioning output differential transmits drive permanently to front and rear axles. This differential may be locked by the driver for use in difficult traction conditions. Standard integral hydraulic retarder which is automatically operated should the engine

overspeed. Blocked filter indicator and filter bypass system provide valve block with additional protection from unfiltered oil.

Pressures:

Main 16 + 2 bar (232 + 30 lbf/in²)
 Lockup (Wk) 14 ± 1 bar (190 ± 15 lbf/in²)
 Converter 'IN' 7.6 bar (110 lbf/in²) at 2 300 rev/min
 Converter 'OUT' 4.8 bar (70 lbf/in²) at 2 300 rev/min
 Converter Relief Valve 8.5 bar (123 lbf/in²)
 Retarder 5.5 bar (80 lbf/in²)

Temperatures:

Normal 80° - 110° C (176° - 230° F)
 Maximum 120° C (248° F)

Stall Speed 1 655 ± 50 rev/min

Ratios:

Torque Converter 1.84:1
 Transmission Refer to table

Forward						
Gear	1	2	3	4	5	6
Ratio	5.35	3.45	2.21	1.42	0.97	0.62
km/h	5.0	8.0	12.5	19.5	29.0	45.0
mile/h	3.0	5.0	8.0	12.0	18.0	28.0
Reverse						
Gear	1	2	3			
Ratio	5.35	2.21	0.97			
km/h	5.0	12.5	29.0			
mile/h	3.0	8.0	18.0			

General Information - Technical Data

Section 000-0000

AXLES

Three axles in permanent all-wheel drive with differential coupling between each axle to prevent driveline wind-up. Heavy duty axles with fully-floating axle shafts and outboard planetary reduction gearing.

Automatic limited slip differentials in each axle. Centre axle incorporates a through-drive differential to transmit drive to the rear axle. Locking of this differential is actuated simultaneously with the transmission output differential lock.

Ratios:
Differential 3.44:1
Planetary 6.35:1
Total Reduction 21.85:1

SUSPENSION

Front: Axle is carried on the leading arms of a sub-frame pivoting on the main frame. Suspension is by flexible air bellows with four heavy duty hydraulic dampers.

Axle Vertical Travel 127 mm (5 in)

Rear: Each axle is coupled to the frame by three rubber-bushed links with lateral restraint by transverse link. Pivoting inter-axle balance beams equalise load on each axle. Suspension movement is cushioned by rubber/metal laminated compression units between each axle and underside of balance beam ends.

Axle Vertical Travel ± 130 mm (5.12 in)
Axle Oscillation $\pm 12^\circ$

BRAKES

Air assisted hydraulic dry disc on each wheel with two heavy-duty callipers per disc at the front and a single heavy-duty calliper per disc at the rear. Independent circuits for front and rear brake systems. Overstroke actuates warning light. Brake system meets ISO 3450, SAE J1473.

Air System Pressure 7.6 bar (110 lbf/in²)
Total Air Reservoir Capacity 55 litres (3 356 in³)
Hydraulic Brake Fluid Capacity 2.64 litres (0.68 US gal)

Parking: Spring-applied, air-released disc on rear driveline.

Emergency: Emergency brake control actuates the service brakes. Automatic application of service brakes should pressure fall in the brake air system.

Retardation: Hydraulic retarder integral with transmission.

WHEELS AND TYRES

Wheels: 5-piece earthmover rims with 12 stud fixing
Size:

Standard 25 x 19.50 in for 23.5 R25** tyres
Optional 25 x 22.00 in for 30/65 R25** tyres

Tyres:

Standard 23.5 R25**
Optional 30/65 R25**

Inflation Pressures (Bridgestone):

	Front	Rear
23.5 R25**	4.0 bar (58 lbf/in ²)	4.8 bar (69 lbf/in ²)
30/65 R25**	4.3 bar (62 lbf/in ²)	4.3 bar (62 lbf/in ²)

Note: Tyre pressures should be regarded as nominal only. It is recommended that for tyres both listed and unlisted, the user should consult the tyre manufacturer and evaluate all job conditions in order to make the proper selection.

HYDRAULIC SYSTEM

Steering and Body Hoist

The steering and body hoist systems are supplied with oil from a common tank by the main hydraulic pump. Gear pump driven from power takeoff on transmission. System components are protected by full flow filtration on the return line.

Pump:

Type Gear
Capacity at 2 300 rev/min 4.49 litre/s (71 US gal/min)

Steering System

Hydrostatic power steering by two single-stage, double-acting, cushioned steering cylinders. Emergency steering pressure is provided by a ground driven pump mounted on the rear of the transmission. An audible alarm and warning light indicates should the emergency system activate. Conforms to ISO 5010, SAE J53.

System Pressure 241 bar (3 500 lbf/in²)
Steering Angle to either side 45°
Lock to Lock Turns, steering wheel 4
Vehicle Clearance Circle (SAE) 17.6 m (58 ft)

Body Hoist System

Two single-stage, double-acting hoist rams, cushioned at both ends of stroke. Electro servo assisted hoist control.

System Pressure 221 bar (3 200 lbf/in²)
Control Valve Pilot Operated, Open Centre
Body Raise Time (loaded) 12 sec
Body Lower Time (power down) 7.5 sec

General Information - Technical Data

Section 000-0000

ELECTRICAL SYSTEM

Type 24 volt, Negative Ground
 Battery Two, 12 Volt, 143 Ah each
 Accessories 24 Volt
 Alternator 70 Amp

BODY

Of all welded construction, fabricated from high hardness (min. 360 BHN) 1 000 MPa (145 000 lbf/in²) yield strength steel. 25° tail chute angle provides good load retention without tailgate.

Plate Thicknesses:

Floor and Tailchute 15 mm (0.59 in)
 Sides 12 mm (0.47 in)
 Front 8 mm (0.31 in)

Volume:

Struck (SAE) 13.0 m³ (17.0 yd³)
 Heaped 2:1 (SAE) 16.0 m³ (21.0 yd³)

SERVICE CAPACITIES

Fuel tank 330 litres (87 US gal)
 Hydraulic System
 (steering & body) 200 litres (52.8 US gal)
 Engine Crankcase 40 litres (10.5 US gal)
 Cooling System 59 litres (15.6 US gal)
 Transmission & filters (dry fill) 52 litres (13.8 US gal)
 Transmission & filters (wet fill) 26 litres (6.9 US gal)
 Differentials - Front & Rear (each) 11 litres (2.9 US gal)
 Differential - Centre 14 litres (3.7 US gal)
 Planetaries (each) 3.5 litres (0.9 US gal)
 Service Brakes 3 litres (0.79 US gal)
 Air Conditioning Compressor 0.125 litres (0.033 US gal)

TYPICAL NOISE LEVELS

Operator Ear (ISO 6394) 79 dbA

*Exterior Sound Rating (SAE J88 JUN 86) TBA dbA

*- The above result is for the mode giving the highest exterior sound level when measured and operated as per the prescribed procedures of the standard. Results shown are for the vehicle in base configuration.

Note: Noise Level Exposure to the operator and bystander personnel may be higher depending upon proximity to buildings, rock piles, machinery, etc.. The actual job site Noise Level Exposure must be measured and applicable regulations complied with in respect to Employee Hearing Protection.

Vehicle Weights		
Standard Vehicle	kg	lb
Net Distribution		
Front Axle	10 585	23 335
Centre Axle	5 000	11 025
Rear Axle	4 970	10 955
Vehicle, Net	20 555	45 315
Payload	27 000	59 525
Gross Distribution		
Front Axle	14 450	31 860
Bogie Axle, leading	16 545	36 470
Bogie Axle, rear	16 560	36 510
Vehicle, Gross	47 555	104 840
Bare Chassis	16 025	35 330
Body	4 000	8 820
Body Hoists (Pair)	530	1 170

* * * *

THIS PAGE IS INTENTIONALLY LEFT BLANK

SM - 2475




Fig. 1 - General Arrangement of Frame Assemblies

DESCRIPTION

The chassis consists of two separate frame assemblies which provide the articulation of the unit. The front and rear frames are constructed of all welded high-grade steel fabrications with rectangular box section beams forming main, side and cross members. The frames are coupled to provide 45° articulation to each side as well as oscillation.

The front frame is fabricated to form a rigid structure which carries the cab, power train and suspension system.

The rear frame is fabricated to form a rigid structure which carries the body, body hydraulics, suspension and rear drive axles.

Oscillation between the front and rear frames is provided by a large diameter cylindrical coupling carried on nylon bushes located in the rear frame. Longitudinal shocks are absorbed by the thrust faces of the nylon bushes. A large thrust nut, which is threaded to the end of the coupling and locked to the

frame, secures the coupling in position. Wear on the thrust faces of the bushes is compensated by tightening this thrust nut.

INSPECTION AND MAINTENANCE

Inspection

Inspect the frames and attached parts at intervals not exceeding 250 hours for cracked or broken welds and bending of the frame. Any defects found should be repaired before they progress into major failures.

Straightening

Hydraulic straightening or aligning equipment should be used to straighten bent or twisted frames whenever possible. However, if heat must be applied, never heat the metal beyond a dull, cherry red colour, as too much heat will weaken the metal. When it is necessary to heat the metal, apply heat uniformly over the area to be straightened and protect the heated surface from sudden cooling. Frame parts that cannot be straightened should be renewed.

Chassis - Frames

Section 100-0010

Welding

Electric arc welding is recommended for all welded frame repairs. Since the nature and extent of damage to the frame cannot be predetermined, no definite repair procedure can be established. As a general rule however, if parts are twisted, bent or pulled apart or a frame is bent or out of alignment, no welding should be done until the parts are straightened or realigned.

Successfully welded repairs will depend to a great extent upon the use of the proper equipment, materials and the ability of the welder. The Service Department can be consulted regarding the feasibility of, welding repairs.



WARNING

Welding and flame cutting cadmium plated metals produce odourless fumes which are toxic. Recommended industrial hygiene practice for protection of the welding operator from the cadmium fumes and metallic oxides requires enclosure ventilation specifically designed for the welding process. A respiratory protective device such as the M.S.A. 'Gasfoe' respirator with G.M.A. cartridge will provide protection against cadmium, fumes and metallic oxides. The 'Gasfoe' respirator has been approved by the U.S. Bureau of Mines: Approval number 23B-10, and is designed to protect against gases, vapours, and/or metal fumes.

Note: Disconnect the battery and alternator cables before performing any welding on the frames. Failure to do so may seriously damage the machines electrical equipment. Always fasten the welding machines ground cable to the piece/frame being welded if possible.

Note: The current from the welding rod always follows the path of least resistance. If, for example, the ground

clamp is attached to the rear frame when welding is performed on the front frame, the current must pass a frame connection to return to the welding machine. Since the pivot coupling offers the least resistance but not a sound electrical connection, small electric arcs may be set up across the moving parts which may cause welding blotches on their wearing surfaces and increase the wear rate of these components.

Reinforcement

Frame reinforcement can be made with channel or angle or flat structural stock. Whenever possible, the reinforcement should extend well beyond the bent, broken or cracked area. The reinforcement stock thickness should not exceed that of the frame stock and the material should be of the same tensile strength.

Painting

A check of the condition of the paint should be made approximately twice a year and chassis repainted if necessary.



WARNING

Welding, burning, heating or dressing surfaces previously painted using polyurethane paint produces fumes which are toxic. Surfaces must be prepared using paint stripper prior to area being reworked. Recommended Industrial Hygiene and Safety Rules should be followed for protection of the welding operator from the fumes.

To keep rust and corrosion to a minimum, periodic painting of abrasions and other exposed metal areas on the frames is highly recommended.

If painting of a frame is required, thoroughly clean the areas to be painted. Apply a primer coat of red oxide and then a finish coat of polyurethane enamel.

* * * *

CHASSIS - Articulation and Oscillation Pivot

Section 100-0020

SM - 2483




Fig. 1 - Articulation and Oscillation Pivot

DESCRIPTION AND OPERATION

The articulation and oscillation pivot allows the front and rear frames to rotate horizontally (articulation) and tilt laterally (oscillation) with respect to each other. It is also the main load bearing coupling between the two frames. The pivot assembly houses the driveshaft connecting the drive between the front and rear frames.

Articulation bearings, oscillation bushes, pivot driveshaft bearings and associated parts can be removed, inspected and replaced or renewed by following the procedures outlined in this section.

Chassis - Articulation and Oscillation Pivot

Section 100-0020

PIVOT DRIVESHAFT BEARINGS

Removal

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

Note: It is not necessary to separate the frames in order to remove the pivot driveshaft assembly.



WARNING

To prevent personal injury and property damage, make sure blocking or lifting equipment is properly secured and of adequate capacity to do the job safely.

1. Position the vehicle in a level work area, apply the parking brake and switch off the engine.

2. Block all road wheels and place the battery master switch in the 'Off' position.

3. Open drain cocks on air tanks to drain air pressure from the tanks. Close air tank drain cocks when air has exhausted from the air tanks.

Note: Take extra care when handling drivelines as any deformity on a rotating mass creates vibration and excessive wear during any operation.

4. Match mark yokes and mating surfaces of transmission - pivot driveline (Fig. 2) to aid in 'Installation'. Remove bolts, lockwashers and caps and remove driveline from the machine.

Note: Take care to avoid damaging pipe (3) when performing Step 5.

5. Remove locknut (25) and washers (26) from front

yoke (27). Remove yoke (27) from shaft (37).

6. Remove bolts (1, Fig. 3), lockwashers (2, Fig. 3), nuts (3, Fig. 3) and protective guard (4, Fig. 3), if fitted, from beneath rear of pivot housing.



WARNING

Tensioned spring on adjuster.

7. Slacken adjuster (14, Fig. 3) until brake pads (13, Fig. 3) are sufficiently clear of parking brake disc (5, Fig. 3) to permit removal of calliper (7, Fig. 3).

8. Note positions of front and rear wedge plates (8 & 9, Fig. 3) to aid in 'Installation'. Remove bolts (6, Fig. 3), washers (11, Fig. 3), nuts (12, Fig. 3), front and rear wedge plates (8 & 9, Fig. 3) and left hand torque plate (10, Fig. 3).


9. Move and secure calliper (7, Fig. 3) clear of parking brake disc (5, Fig. 3).


Note: Take extra care when handling drivelines since any deformity on a rotating mass creates vibration and excessive wear during any operation.

10. Match mark brake yoke (16) and mating surface of pivot - centre axle driveline (Fig. 2) to aid in 'Installation'. Remove bolts, lockwashers and caps and remove driveline from the machine.

11. Remove bolts (57) and lockwashers (14) from rear housing (31).

Note: Take extra care when handling driveshafts as any deformity on a rotating mass creates vibration and excessive wear during any operation.





12. Withdraw pivot driveshaft assembly from pivot by pulling rearwards on brake yoke/disc assembly and place in suitable location for further work.

13. Remove front locknut (25) then position front yoke (27) fully on to front of shaft (37) and suitably restrain to resist rotation. Remove rear locknut (25), washers (26) and rear yoke brake/disc assembly (16). Tag front and rear ends of shaft (37) and install locknuts (25) on the shaft to protect the threads.

14. Tag and remove housing (31). Note position of seal (40) to aid in 'Installation'. Remove and discard seal (40).

15. Remove washer (39), rear bearing (30) and spacer (19) from rear of shaft (37).

16. Remove bolt (56), lockwasher (57) and bracket

(58) securing pipe (3) to pivot (1) assembly.

Note: Take care to avoid damaging pipe (3) when performing Steps 17 through 18.

17. Remove bolts (20) and lockwashers (14) from front housing (28).

18. Tag and remove front housing (28). Note position of seal (12) in front housing (28) to aid in 'Installation'. Remove and discard seal (12).

! WARNING
When necessary to drive out components, use a soft drift to avoid injury and damage from flying chips.

19. Using a suitable puller/drift, remove bearing (30).

Chassis - Articulation and Oscillation Pivot

Section 100-0020

20. Remove spacer (19). Note position of seals (29) in pivot (1) housing to aid in 'Installation'. Remove and discard seals (29).

Inspection

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

1. Clean parts with a suitable solvent and let dry. DO NOT spin bearings with compressed air. Place bearings on clean surface, cover with lint free cloth and allow to dry.

2. Check pivot driveshaft bearings (30) for wear or damage, replace if required.

3. Inspect bushes (38) for wear. Replace if badly scored.

Installation

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

Note: Tighten all fasteners without special torques specified, to standard torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.

Note: If bushes (38) are to be renewed, then proceed with Steps 1 thru 5, if the bushes (38) are satisfactory, proceed from Step 6.

! WARNINGS

To prevent personal injury and property damage, make sure blocking or lifting equipment is properly secured and of adequate capacity to do the job safely.


!

When necessary to drive out components, use a soft drift to avoid injury and damage from flying chips.

1. Apply suitable heat to bushes (38) to break bond of retaining compound. Remove locknuts (25) from their protective position on shaft (37), then remove bushes (38) with a suitable drift.

2. Allow shaft (37) to cool. Thoroughly clean shaft (37) and new bushes (38) with a suitable solvent. Wash mating faces of shaft (37) and new bushes (38) with chlorethane and allow to dry.

3. Apply LOCTITE primer to mating faces of shaft (37)



and new bushes (38) and allow to dry. Refer to Fig. 4.

4. Apply LOCTITE Fugeteile 35 to shaft (37) mating faces and install new bushes (38), with the recesses in bushes (38) against shoulder on driveshaft (37). Make sure that bushes (38) are fully home against the shoulders. Refer to Fig. 4.

5. Allow 15 minutes for retaining compound to cure to handling strength.

6. Degrease front bearing (30) housing in pivot (1) with a suitable solvent and allow to dry.

Note: Do not use retaining compound on the housing for the rear pivot shaft bearing.

Note: Front bearing (30) of shaft (37) is secured with retaining compound as well as normal hardware. Cleaning the bearing housing ensures a good bond. THE REAR BEARING IS SECURED BY NORMAL HARDWARE ONLY.

7. Apply coat of grease to new seals (29) and install seals in pivot housing. Make sure seal lips are facing outwards as shown on Fig. 5.

8. Make sure that pivot shaft bearing (30) is pre-packed with grease then position spacer (19), bearing (30) and washer (39) on rear of shaft (37).

9. Apply bead of grease to fill inner rim of new seal (40) and position new seal in rear housing (31). Refer to Fig. 6. Fill lube fitting (24) assembly on rear housing with grease and make sure that nipple (22) does not protrude into grease slot in rear face of housing (31).

Note: Take extra care when handling driveshafts as any deformity on a rotating mass creates vibration and excessive wear during any operation.




Fig. 5 - Pivot Housing Inner Seals




Fig. 6 - Typical Outer Seal Installation

10. Assemble rear housing (31) and brake yoke/disc assembly (16) onto rear of shaft (37). Secure with locknut (25) and both washers (26) but only fingertight at this stage.

11. Insert shaft (37) assembly fully into pivot (1) from the rear. Take care not to dislodge internal seals (29).

12. Partially withdraw shaft (37) assembly to enable housing of rear pivot driveline bearing (30) to be filled with grease from 1/3 to 1/2 of capacity.

13. Reposition shaft (37) assembly fully in pivot (1).

14. Align housing (31) with lube fitting (24) uppermost and secure with lockwashers (14) and bolts (20). Torque tighten bolts (20) to 106 Nm (78 lbf ft).

15. Apply a bead of grease to fill inner rim of new seal (12) and position seal in front housing (28). Refer to Fig. 6. Fill pipe (3), through lube fitting (50), with grease. Make sure that pipe (3) does not protrude into grease slot in rear face of housing (28).

16. Install spacer (19) onto front of shaft (37).

17. Pre-pack bearing (30) with grease taking care not to place any grease on outer curved surface. Clean this surface with a suitable solvent where necessary and allow to dry.

Note: Make sure that Steps 18 through 22 are performed within the hardening time of the retaining compound in use.

18. Make sure mating surfaces of housing (28) are still clean then apply coating of retaining compound to mating surfaces of bearing (30) and housing (28). Install bearing (30) on to front of shaft (37).

19. Pack housing (28) of with grease from 1/3 to 1/2 of capacity.

20. Install front housing (28), front yoke (27), both washers (26) and locknut (25).

Note: Take care to avoid damaging the pipe (3) when performing Steps 21 through 22.

21. Lock brake yoke/disc (16) assembly with a suitable tool and install locknut (25) on front yoke (27). Torque tighten locknut (25) to 678 Nm (500 lbf ft).

22. Lock front yoke (27) and torque tighten locknut (25) on brake yoke assembly to 678 Nm (500 lbf ft).

23. Align front housing (28) with pipe (3) uppermost and secure in place with bolts (20) and lockwashers (14). Torque tighten bolts (20) to 106 Nm (78 lbf ft).

24. Install bracket (58), and secure with lockwasher (57) and bolt (56).

25. Check that no end float exists by pulling and pushing on the brake yoke/disc assembly.

Note: Take extra care when handling drivelines as chips, dents, burrs or deformity on any rotating mass creates vibration and excessive wear during any operation. (Steps 26 & 28).

Chassis - Articulation and Oscillation Pivot

Section 100-0020

26. Connect pivot - centre axle driveline (Fig. 2) to brake yoke/disc assembly as noted on 'Removal'. Install caps and secure with lockwashers and bolts.

27. Position parking brake calliper (7, Fig. 3) in position and install left hand torque plate (10, Fig. 3), front and rear wedge plates (8 & 9, Fig. 3) and secure in place with bolts (6, Fig. 3), washers (11, Fig. 3) and locknuts (12, Fig. 3).

28. Install transmission - pivot driveline (Fig. 2) with caps, lockwashers and bolts as noted on 'Removal'.

29. Position guard (4, Fig. 3), if fitted, and secure to frame using bolts (1, Fig. 3), lockwashers (2, Fig. 3) and nuts (3, Fig. 3).

30. Place the battery master switch in the on position, start the engine and allow air pressure in the tanks to build up to correct operating pressure.

31. Adjust parking brake as shown in Section 170-0010, PARKING BRAKE AND MOUNTING.

32. Remove all blocking from the road wheels.

ARTICULATION BEARINGS

Removal

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

Note: The lengths of the electrical, hydraulic and air connections between the two frames are designed to permit articulation. As a result, the frames can be separated sufficiently to permit removal of the articulation bearings without disconnecting these connections.



WARNING

To prevent personal injury and property damage, make sure blocking or lifting equipment is properly secured and of adequate capacity to do the job safely.

1. Position the vehicle in a level work area, apply the parking brake and switch off the engine.

2. Block all road wheels and place the battery master switch in the 'Off' position.

3. Open drain cocks on air tanks to drain air pressure from the tanks. Close air tank drain cocks when air

has exhausted from the air tanks.

4. Position levelling jack under centre front portion of the front frame. Raise jack and block frame to remain level after removal of the articulation pins. Check that front wheels are still effectively blocked.

Note: Make sure that front frame is correctly supported and prevented from tilting on the axle, or damage to coupling etc. could result.

5. Disconnect steering cylinders by removing bolts (36), lockwashers (14), washers (45) and pins (44) from attachment points on pivot (1) housing. Move steering cylinders clear of pivot (1) housing and secure.

Note: Take extra care when handling drivelines as chips, dents, burrs or deformity on any rotating mass creates vibration and excessive wear during any operation.

6. Match mark yokes and mating surfaces of transmission - pivot driveline (Fig. 2) to aid in 'Installation'. Remove bolts, lockwashers and caps and remove driveline from the machine.

7. Remove bolt (53) and hardened washer (54) securing pin (55) to pivot (1) housing. Remove nut (51) and withdraw pin (55), tapping pin downwards to ease removal. Take care not to damage the threads on pin (55).

Note: It may be necessary to adjust the frame levelling jack to relieve binding between pin (55) and pin bores during removal.

8. Remove bolt (46), lockwasher (14) and washer (47) securing pin (32) to pivot (1) housing.

9. Remove pin (32), tapping pin upwards to ease removal. Take care not to damage the threads on pin (32).

Note: It may be necessary to adjust the frame levelling jack to relieve binding between pin (32) and pin bores during removal.

10. Attach suitable lifting equipment to the rear frame and take up slack.

Note: Only separate the frames sufficiently to permit removal of the articulation bearings or damage to electrical, hydraulic and air connections could result.

11. Remove blocking from the rear frame and wheels

Chassis - Articulation and Oscillation Pivot

Section 100-0020

and use lifting equipment to pull the rear frame away from the front frame. After moving, block the rear frame and wheels securely.

12. Mark all bearing retainers (5, 11, 17 & 21) to aid in 'Installation'.

Note: Retainers (5, 11, 17 & 21) are not interchangeable.

13. Remove bolts (13), lockwashers (14), retainers (5, 11, 17 & 21) and upper and lower shims (7, 8 & 9).

14. Remove and discard 'O' rings (4, 10 & 18). Remove spacer (52) noting orientation to aid in 'Installation'.

15. Remove and tag all bearings (6) to aid in 'Installation', where appropriate.

Note: Never interchange cups or cones between bearings.

Inspection

Numbers in parentheses refer to Fig. 1.

1. Clean parts with a suitable solvent and let dry. DO NOT spin bearings with compressed air. Place bearings on clean surface, cover with lint free cloth and allow to dry.

2. Check articulation bearings (6) and pins (32 & 55) for wear or damage. Renew if required.

Installation

Numbers in parentheses refer to Fig. 1, unless otherwise specified.



WARNING

To prevent personal injury and property damage, make sure blocking or lifting equipment is properly secured and of adequate capacity to do the job safely.

Note: Two bearings are installed on EACH articulation point. Each bearing comprises a cup and a cone and are installed into the articulation point with the cones 'back to back'. Refer to Fig. 7.

Note: Never interchange cups or cones between bearings.

1. Insert both bearing cups and cones into housing so




Fig. 7 - Section Through Articulation Bearing

that bearing cones are back to back and position retainer (11), for top articulation bearing, and retainer (21), for bottom articulation bearing on underside of bearing housing. Make sure that bearings are pre-packed with grease including end faces and faces on bearing cups.

2. Install top retainer (5), for top articulation bearing, and retainer (21), for bottom articulation bearing.

3. Lubricate bolts (13 for top and 33 for bottom) and install along with washers (14). Torque tighten bolts (13 & 33) to 27 Nm (20 lbf ft).

4. Use feeler gauges to measure end float and record value. Refer to Fig. 8.

Note: End float is equal to the sum of the clearances between both retainers and the lug.

5. Select shims to total value of -0.07 to $+0.02$ mm (-0.003 to $+0.001$ in) of that recorded at Step 4.




Fig. 8 - Measuring End Float

Chassis - Articulation and Oscillation Pivot

Section 100-0020

6. Remove bolts (13 & 33), lubricate and coat with anti-seize compound then install shims (7, 8 & 9) beneath appropriate upper retainer (5 for upper articulation bearing, 17 for lower articulation bearing).

7. Re-install bolts (13 & 33) and washers (14) and torque tighten to 106 Nm (78 lbf ft).

8. Install spacer (52) in upper bearing as noted on removal. Install upper 'O' ring (4) and lower 'O' ring (10) for top bearing (6).

Note: The lower bearing is NOT fitted with a spacer.

9. Install 'O' rings (18) for lower bearing (6).

10. Attach suitable lifting equipment to the rear frame and take up slack.

11. Remove blocking from rear frame and wheels. Move rear frame with lifting equipment to align the articulation pin bores. Block the rear frame and wheels to remain level and stationary.

12. Clean articulation pins (32 & 55) with suitable solvent, allow to dry then coat them with anti-seize compound including threads on upper pin (55).

13. Insert articulation pin (32).

Note: It may be necessary to adjust the levelling jack beneath front frame to permit entry of articulation pin (32). Pin (32) may be tapped in to place taking care that it is not misaligned and does not cause damage to the pin, bearings or pivot housing lugs.

14. Secure pin (32) with washer (47), lockwasher (14) and bolt (36).

15. Insert upper articulation pin (55).

16. Install nut (51) on pin (55). Torque tighten nut (51) to 1 424 Nm (1 050 lbf ft).

Note: Take extra care when handling drivelines as chips, dents, burrs or deformity on any rotating mass creates vibration and excessive wear during any operation.

17. Install transmission - centre driveline (Fig. 2) with caps, lockwashers and bolts as noted on 'Removal'.

18. Position steering cylinders in place on pivot (1) and install pins (44). Secure pins (44) with bolts (36), washers (45) and lockwashers (14).

19. Place the battery master switch in the on position, start the engine and allow air pressure in the tanks to build up to correct operating pressure.

20. Lower and remove jack and all blocking equipment.

OSCILLATION BUSHES

Removal

Numbers in parentheses refer to Fig. 1, unless otherwise specified.



WARNING

To prevent personal injury and property damage, make sure blocking or lifting equipment is properly secured and of adequate capacity to do the job safely.

1. Position the vehicle in a level work area, apply the parking brake and switch off the engine.

2. Block all road wheels and place the battery master switch in the 'Off' position.

3. Open drain cocks on air tanks to drain air pressure from the tanks. Close air tank drain cocks when air has exhausted from the air tanks.

4. Remove hydraulic oil tank remote drain plug and drain hydraulic oil into a suitable container. Re-install drain plug in hydraulic tank remote drain fitting.

5. Tag all air and hydraulic lines between front and rear frames to aid in 'Installation. Disconnect all air and hydraulic lines. Cap line fittings and plug lines to prevent ingress of dirt.

6. Disconnect electrical wiring and any other attachments that would be damaged on separation of front and rear frames.

7. Position levelling jack under centre front portion of the front frame. Raise the jack and block the front frame, front and rear, so it will remain level after separation. Check that both front wheels are still securely blocked.

Note: Make sure that the front frame is correctly supported and prevented from tilting on the axle or damage to coupling etc. could result.

Note: Take extra care when handling drivelines as chips, dents, burrs or deformity on any rotating mass creates vibration and excessive wear during any operation.

8. Remove bolts (1, Fig. 3), lockwashers (2, Fig. 3), nuts (3, Fig. 3) and protective guard (4, Fig. 3), if fitted, from beneath rear of pivot housing.



WARNING

Tensioned spring on adjuster.

9. Slacken adjuster (14, Fig. 3) until brake pads (13, Fig. 3) are sufficiently clear of parking brake disc (5, Fig. 3) to permit removal of calliper (7, Fig. 3).

10. Note positions of front and rear wedge plates (8 & 9, Fig. 3) to aid in 'Installation'. Remove bolts (6, Fig. 3), washers (11, Fig. 3), nuts (12, Fig. 3), front and rear wedge plates (8 & 9, Fig. 3) and left hand torque plate (10, Fig. 3).

11. Move and secure calliper (7, Fig. 3) clear of parking brake disc (5, Fig. 3).

Note: Take extra care when handling drivelines since any deformity on a rotating mass creates vibration and excessive wear during any operation.

12. Match mark brake yoke (16) and mating surface of pivot - centre axle driveline (Fig. 2) to aid in 'Installation'. Remove bolts, lockwashers and caps and remove driveline from the machine.

13. Mark disc (5, Fig. 3) assembly to aid in 'Installation' then remove bolts (15, Fig. 3) washers (16, Fig. 3) and disc (5, Fig. 3).

14. Remove bolts (36), lockwashers (14) and lockplate (35).

15. Using special tool, which can be fabricated as shown in Fig. 11, remove thrust nut (34) from pivot (1). Note position of rear 'V' ring (41) to aid in 'Installation'. Remove and discard 'V' ring (41).

16. Attach suitable lifting equipment to the front of the rear frame and take up slack.

17. Remove all blocking from rear frame and wheels and using suitable lifting equipment draw the rear frame from pivot (1) assembly. When clear, block the rear frame and wheels.

Note: Use care when separating rear frame and pivot

assembly to avoid damage to end threads.

18. Replace thrust nut (34) on pivot (1) to protect threads.

19. Note position of front 'V' ring (41) to aid in 'Installation'. Remove and discard 'V' ring (41).

20. Inspect oscillation bushes (43) as described in 'Inspection'. If bushes are to be renewed, proceed with Step 20.

21. Remove oscillation bush/es (43) with hammer and chisel.

Note: The suggested method is to make an axial cut along the bush then to lever the bush in order to collapse it upon itself.

Inspection

Numbers in parentheses refer to Fig. 1.

1. Clean oscillation bushes (43) with a suitable solvent and allow to dry.

2. Inspect oscillation bushes (43) for wear, scoring, erosion and 'out of round'. Pay particular attention to the thrust faces of the bushes which should also be inspected for cracking/splitting. Renew if required.

Installation

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

Note: Tighten all fasteners without special torques specified, to standard torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



WARNING

To prevent personal injury and property damage, make sure blocking or lifting equipment is properly secured and of adequate capacity to do the job safely.

1. Wipe bush housing clean using suitable solvent and allow to dry.

2. Apply LOCQUIC primer to housing and allow to dry for 10 minutes. Apply LOCTITE RC-35 to housing.

3. Align new bushes to housing with grease holes aligned vertically and identification 'PAINT DOT' at Top Dead

Chassis - Articulation and Oscillation Pivot

Section 100-0020

Centre. Refer to Fig. 9. Drift bushes into housing using hammer with soft packing for protection.

4. Using special tool, which can be fabricated as shown in Fig. 11, remove thrust nut (34) from pivot (1). Clean grease from pivot exterior using a suitable solvent where necessary and allow to dry.

Note: Use care on inserting the pivot housing assembly or damage to the thread could occur.

5. Install new pre-greased front 'V' ring (41). Refer to Fig. 10. Apply liberal coat of grease to external surface of pivot (1) and mating faces of bushes (43).

6. Attach suitable lifting equipment to the front of the rear frame and take up slack.

7. Remove all blocking from rear frame and wheels and use lifting equipment to line-up and draw the rear frame onto pivot (1) assembly.

8. Install new pre-greased rear 'V' ring (41). Refer to Fig. 10. Using special tool, as shown in Fig. 11, install and tighten thrust nut (34) until there is no end float/clearance at thrust face of either bush (43). Slacken thrust nut (34) until pin of lockplate (35) can be inserted in first available hole in thrust nut (34).

9. Secure lockplate (35) with bolts (36) and



lockwashers (14). Torque tighten bolts (36) to 75 Nm (55 lbf ft).

10. Grease oscillation bushes (43) through lube fittings (59) until excess lubrication is seen.

11. Check that no end float exists at oscillation bushes by pushing and pulling on brake yoke assembly.

12. Position brake disc (5, Fig. 3) onto brake yoke (16) as noted at 'Removal'. Secure in place with bolts (15, Fig. 3) and washers (16, Fig. 3).

Note: Take extra care when handling drivelines as



chips, dents, burrs or deformity on any rotating mass creates vibration and excessive wear during any operation.

13. Connect pivot - centre axle driveline (Fig. 2) at brake yoke using bolts, lockwashers and caps as noted at 'Removal'.

14. Position parking brake calliper (7, Fig. 3) in position and install left hand torque plate (10, Fig. 3), front and rear wedge plates (8 & 9, Fig. 3) and secure in place with bolts (6, Fig. 3), washers (11, Fig. 3) and locknuts (12, Fig. 3).

15. Position guard (4, Fig. 3), if fitted, and secure to frame using bolts (1, Fig. 3), lockwashers (2, Fig. 3) and nuts (3, Fig. 3).

16. Remove all protective plugs and connect all air and hydraulic lines and other attachments disconnected in preparation for separation of front and rear frames.

17. Fill hydraulic oil tank with hydraulic oil, as specified in Section 300-0020, LUBRICATION SYSTEM.

18. Place the battery master switch in the on position, start the engine and allow air pressure in the tanks to build up to correct operating pressure. Check air and hydraulic lines for leaks. Tighten line fittings as required.

19. Adjust parking brake as shown in Section 170-0010, PARKING BRAKE AND MOUNTING.

20. Remove all blocking from the road wheels.

THRUST NUT ADJUSTMENT

1. Position the vehicle in a level work area, apply the parking brake and switch off the engine.

2. Block all road wheels and place the battery master switch in the 'Off' position.

3. Open drain cocks on air tanks to drain air pressure from the tanks. Close air tank drain cocks when air has exhausted from the air tanks.

4. Position levelling jack under centre front portion of the front frame and raise the jack to ensure both frames are parallel.

5. Remove bolts and lockwashers securing lockplate at the thrust nut and remove the lockplate.

6. Using special tool, which can be manufactured as shown in Fig. 11, tighten thrust nut until there is no end float/clearance at thrust face of either bush. Slacken thrust nut until pin of the lockplate can be inserted in the first available hole in the thrust nut.

7. Secure lockplate with bolts and lockwashers. Torque tighten bolts to 75 Nm (55 lbf ft).

8. Lower jack and remove all blocking from the front wheels.

MAINTENANCE

The end float/clearance at the thrust face of the oscillation bushes should be checked every 250 hours. Any clearance found must be removed by adjustment of the thrust nut, as described under 'Thrust Nut Adjustment'.

Note: A practical method of establishing the effective adjustment of the thrust nut is to use movement of the machines body in the raised position. Move the body from fully raised to almost fully raised while watching the effect of this action on the frame and pivot arrangement. Any slackness between the thrust nut and thrust faces will be clearly visible movement of the frame.

Very little other maintenance of the articulation and oscillation pivot is required other than to stress the importance of correct lubrication of the assembly.

Lubricate the oscillation bushes, articulation bearings/pins and the pivot driveshaft bearings in accordance with Section 300-0020, LUBRICATION SYSTEM but note the following precautions:-

Note: The oscillation bushes are lubricated every 10 to 15 hours.

Note: DO NOT exceed the lubrication schedule for the pivot driveshaft bearings i.e. 4 shots of a hand grease gun every 250 hours.


SPECIAL TOOL

The special tool required for removal and installation of the thrust nut, can be manufactured, as shown in Fig. 11.

Chassis - Articulation and Oscillation Pivot

Section 100-0020

SM - 844



Dimensions in mm (in)

Fig. 11 - Fabrication Details of Thrust Nut Removal and Installation Tool

SPECIAL TORQUE SPECIFICATIONS

			TORQUE	
FIG. NO.	ITEM NO.	ITEM NAME	Nm	lbf ft
1	13	Bolt	106	78
1	20	Bolt	106	78
1	25	Nut	678	500
1	33	Bolt	106	78
1	36	Bolt	75	55
1	51	Nut	1 425	1 050

ARTICULATION AND OSCILLATION PIVOT DIAGNOSIS

Noise and vibration caused by the pivot driveshaft assembly appear only at certain speeds and generally come and go as these speeds are approached and passed. When the driveshaft assembly noise becomes excessive, it takes the form of a vibration which can be

felt throughout the frame.

Noise from the articulation and oscillation points must be investigated.

An 'Articulation and Oscillation Pivot Diagnosis' table is shown below.

ARTICULATION AND OSCILLATION PIVOT DIAGNOSIS		
CONDITION	REASON	REMEDY
Noise (Pivot Driveshaft)	Insufficient lubricant	Check seals. Install proper grade of lubricant.
	Out of balance driveshaft assembly	Check alignment.
Vibration (Pivot Driveshaft)	Backlash due to worn bearings, housings, yokes and trunnions	Renew worn parts.
	Yoke not in line	Renew driveshaft assembly or assemble correctly.
	Driveshaft out of balance	Renew driveshaft assembly.
Noise (Articulation/Oscillation Points)	Excessive run out or distorted yokes	Dismantle and correct, or renew, damaged part.
	Loose nut on yoke	Check splines, if worn. Renew shaft. Torque tighten nut to value in 'Special Torque Specifications' in this section.
	Insufficient lubricant	Lubricate. Investigate/revise lubrication schedules. Refer to Section 300-0020, LUBRICATION SYSTEM. Check seals for lubricant loss/contamination. Renew as necessary.
	Worn bearings/bushes	Inspect/renew as necessary.

* * * *

THIS PAGE IS INTENTIONALLY LEFT BLANK

CHASSIS - Articulation and Oscillation Pivot

Section 100-0020

SM - 2495




Fig. 1 - Articulation and Oscillation Pivot

DESCRIPTION AND OPERATION

The articulation and oscillation pivot allows the front and rear frames to rotate horizontally (articulation) and tilt laterally (oscillation) with respect to each other. It is also the main load bearing coupling between the two frames. The pivot assembly houses the driveshaft connecting the drive between the front and rear frames.

Articulation bearings, oscillation bushes, pivot driveshaft bearings and associated parts can be removed, inspected and replaced or renewed by following the procedures outlined in this section.

Chassis - Articulation and Oscillation Pivot

Section 100-0020

PIVOT DRIVESHAFT BEARINGS

Removal

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

Note: It is not necessary to separate the frames in order to remove the pivot driveshaft assembly.



WARNING
To prevent personal injury and property damage, make sure blocking or lifting equipment is properly secured and of adequate capacity to do the job safely.

1. Position the vehicle in a level work area, apply the parking brake and switch off the engine.

2. Block all road wheels and place the battery master switch in the 'Off' position.

3. Open drain cocks on air tanks to drain air pressure from the tanks. Close air tank drain cocks when air has exhausted from the air tanks.

Note: Take extra care when handling drivelines as any deformity on a rotating mass creates vibration and excessive wear during any operation.

4. Match mark yokes and mating surfaces of transmission - pivot driveline (Fig. 2) to aid in 'Installation'. Remove bolts, lockwashers and caps and remove driveline from the machine.

Note: Take care to avoid damaging pipe (3) when performing Step 5.

5. Remove locknut (25) and washers (26) from front

yoke (27). Remove yoke (27) from shaft (37).

6. Remove bolts (1, Fig. 3), lockwashers (2, Fig. 3), nuts (3, Fig. 3) and protective guard (4, Fig. 3), if fitted, from beneath rear of pivot housing.



WARNING
Tensioned spring on adjuster.

7. Slacken adjuster (14, Fig. 3) until brake pads (13, Fig. 3) are sufficiently clear of parking brake disc (5, Fig. 3) to permit removal of calliper (7, Fig. 3).

8. Note positions of front and rear wedge plates (8 & 9, Fig. 3) to aid in 'Installation'. Remove bolts (6, Fig. 3), washers (11, Fig. 3), nuts (12, Fig. 3), front and rear wedge plates (8 & 9, Fig. 3) and left hand torque plate (10, Fig. 3).

9. Move and secure calliper (7, Fig. 3) clear of parking brake disc (5, Fig. 3).

Note: Take extra care when handling drivelines since any deformity on a rotating mass creates vibration and excessive wear during any operation.

10. Match mark brake yoke (16) and mating surface of pivot - centre axle driveline (Fig. 2) to aid in 'Installation'. Remove bolts, lockwashers and caps and remove driveline from the machine.

11. Remove bolts (57) and lockwashers (14) from rear housing (31).

Note: Take extra care when handling driveshafts as any deformity on a rotating mass creates vibration and excessive wear during any operation.

