


[CLICK HERE FOR TABLE OF CONTENTS](#)



**TEREX**

# TR100 Mining Truck Maintenance Manual



[CLICK HERE TO RETURN TO MAIN LIBRARY INDEX](#)

PART No. 15272903

TECHNICAL PUBLICATIONS DEPARTMENT  
TEREX EQUIPMENT LIMITED,  
MOTHERWELL, SCOTLAND, ML1 5RY  
REF. NO. SM755/783

Product: 2008 TEREX TR100 Mining Truck Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/2008-terex-tr100-mining-truck-service-repair-workshop-manual/>

Sample of manual. Download All 574 pages at:  
<https://www.arepairmanual.com/downloads/2008-terex-tr100-mining-truck-service-repair-workshop-manual/>



## IMPORTANT SAFETY NOTICE

Proper service and repair is important to the safe, reliable operation of all motor vehicles. The service procedures recommended and described in this publication, are effective methods for performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when, and as recommended.

It is important to note that this publication contains various WARNINGS and NOTES which should be carefully read in order to minimize the risk of personal injury to personnel, or the possibility that improper service methods will be followed which may damage the vehicle or render it unsafe. It is also important to understand these WARNINGS and NOTES are not exhaustive. It is not possible to know, evaluate and advise the service trade of ALL conceivable ways in which service might be carried out, or, of the possible hazardous consequences of each way. Consequently, no such broad evaluation has been undertaken. Accordingly, anyone who uses a service procedure, or tool, which is not recommended, must first satisfy themselves thoroughly that neither their safety, nor vehicle safety, will be jeopardized by the service method he/she selects.

Two types of heading are used in this manual to attract your attention.

1.  **WARNING** - This symbol is used when an operating procedure, practice, etc., which, if not correctly followed could result in personal injury or loss of life. Look for this symbol to point out important safety precautions. It means - **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

2. **Note** - This is used when an operating procedure, practice, etc., which, if not strictly observed, could result in damage to or destruction of equipment.



### **WARNING**

**Never use parts which are altered, modified, or weakened in operation. This can seriously jeopardize the integrity of the machine and could result in property damage or serious personal injury.**

THIS PAGE IS INTENTIONALLY LEFT BLANK

The information contained within this Alert must not be made available to third parties not authorised to receive it.

# Service Information Alert

**DATE:** April 1994

**B168**

**MODEL:** General

**SUBJECT:** VITON 'O' RINGS AND SEALS (FLUORO-ELASTOMERS) - SAFETY HAZARDS

**PURPOSE:**

To advise potentially hazardous condition.

**DETAIL:**

It has been brought to our attention that 'Viton' material used in manufacture of oil seals and 'O' rings, produces a highly corrosive acid (Hydrofluoric) when subjected to temperatures above 315° C.

The resulting contamination can have extreme consequences on human tissue since it is almost impossible to remove after contact.

We therefore recommend the following procedure when it is necessary to inspect any equipment that has been subjected to a high temperature i.e. fire.

- a. Visually inspect for any gaskets or seals which have suffered from heat; they will appear black and sticky.
- b. If this is affirmed - **Do Not Touch**
- c. Make enquiries to ascertain the material composition. Any Fluoro-elastomer (Viton, Fluorel or Tecmoflon) should be considered dangerous but natural rubber and nitrile are non-hazardous.
- d. If Fluoro-elastomer seals have been used, then the affected area **MUST** be decontaminated before undertaking further work.
- e. Disposable Heavy Duty Gloves (Neoprene) **MUST** be worn and the affected area decontaminated by washing thoroughly with Limewater (Calcium Hydroxide solution).
- f. Any cloths, residue and gloves used **MUST** be safely discarded after use.

**Note:** Burning of the discarded items is **NOT RECOMMENDED**, except in an approved incineration process where the gaseous products are treated by alkaline scrubbing.

## TEREX SERVICE DEPARTMENT

THIS PAGE IS INTENTIONALLY LEFT BLANK

## TABLE OF CONTENTS

Section No.	Description	SM No.
<b>000</b> 0000 0010	<b>GENERAL INFORMATION</b> TR100 Off-Highway Truck Welding Procedure	1618 Rev 3 2172
<b>100</b> 0010 0010	<b>CHASSIS</b> Chassis, Hood and Fenders - Pre January 2000 Production Chassis, Hood and Fenders - From January 2000 Production	1622 1898
<b>110</b> 0030 0050 0130	<b>ENGINE</b> Engine and Mounting Air Cleaner Power Takeoff	1655 Rev 1 1246 1656
<b>120</b> 0010 0010 0070 0070 0090 0100	<b>TRANSMISSION</b> Transmission and Mounting - Pre March 1999 Production Transmission and Mounting - From March 1999 Production Commercial Electronic Control (CEC) Shift System Commercial Electronic Control 2 (CEC2) Power Takeoff Transmission Oil Filter	1623 1899 1619 Rev 1 2314 Rev 2 1178 1624
<b>130</b> 0010 0020	<b>DRIVELINE</b> Front Driveline Rear Driveline	1657 1658
<b>140</b> 0040	<b>FRONT AXLE</b> Wheel, Rim and Tyre	1625 Rev 2
<b>160</b> 0020 0020 0030 0050	<b>REAR AXLE</b> Differential Differential (Optional) Axle Group Wheel, Rim and Tyre	1626 Rev 1 1907 1627 Rev 2 1628 Rev 3
<b>165</b> 0020 0030	<b>BRAKE PARTS</b> Brake Parts - Front Axle Brake Parts - Rear Axle	1629 1630 Rev 1
<b>180</b> 0030 0050	<b>SUSPENSION SYSTEM</b> Ride Cylinder - Front Ride Cylinder - Rear	1631 Rev 1 1632 Rev 2
<b>190</b> 0000 0000 0270 0270	<b>CIRCUIT DIAGRAMS</b> Circuit Diagrams Circuit Diagrams (C.E.C 2) Switches and Sensors - Pre March 2000 Production Switches and Sensors - From March 2000 Production	1585 2313 1633 Rev 1 2046 Rev 2
<b>200</b> 0010	<b>FUEL SYSTEM</b> Fuel Tank and Mounting	1634
<b>210</b> 0000 0040 0040 0050 0060	<b>COOLING SYSTEM</b> Cooling System Radiator, Header Tank and Mounting - Pre September 1999 Production Radiator, Header Tank and Mounting - From September 1999 Production Disc Brake Oil Cooler Transmission Oil Cooler	1263 1635 1900 1636 1637

## TABLE OF CONTENTS

Section No.	Description	SM No.
<b>220</b>	<b>STEERING SYSTEM</b>	
0000	Steering System Schematic	1661 Rev1
0040	Steering and Brake Control Tank	1638
0050	Steering Pump	2356
0050	Steering Pump (new style)	2575 Rev 1
0080	Accumulator	1205
0090	Steering Valve	1640 Rev 1
0110	Double Relief Valve	1208
0120	Steering Cylinder and Linkage - Pre August 2000 Production	1641 Rev 1
0120	Steering Cylinder and Linkage - From August 2000 Production	2047
0130	Accumulator Valve	1642
0150	Steering Filter	1593
<b>230</b>	<b>BODY SYSTEM</b>	
0000	Body System Schematic	1646 Rev 1
0040	Body and Disc Brake Cooling Tank	1643
0050	Main Hydraulic Pump	1644
0060	Body Control Valve	1659 Rev 4
0081	Body Control Joystick	1277
0100	Manifold Relief Valve	1645
0121	Pilot Supply Valve	1599
0130	Body Cylinder	1279
<b>250</b>	<b>BRAKING SYSTEM</b>	
0000	Braking System Schematic	1660 Rev 1
0050	Brake Manifold Valve	1647
0055	Tandem Pump	1648
0060	Accumulator	1600
0070	Treadle Valve	1649
0090	Directional Control Valve	1226
0100	Monoblock Brake Valve	1227 Rev 2
0110	Pressure Reducing Valve	2045
0130	Retarder Control Valve	1650 Rev 1
0140	Shuttle Valve	1229
0151	Parking Brake Valve	1651
0152	Brake Dump Valve	1652
<b>260</b>	<b>OPERATOR'S COMPARTMENT</b>	
0010	Cab and Mounting	1602 Rev 1
0090	Driver Seat and Mounting	1901 Rev 1
0110	Passenger Seat and Mounting - Pre November 1999 Production	1603
0110	Passenger Seat and Mounting - From November 1999 Production	1902
0130	Air Conditioning	1903
<b>270</b>	<b>BODY</b>	
0010	Body and Mounting	1653 Rev 1
<b>300</b>	<b>MISCELLANEOUS</b>	
0020	Lubrication System	1654 Rev 9
0070	Service Tools	1662 Rev 2
0080	Standard Bolt and Nut Torque Specifications	1238 Rev 1
0090	Unit Storage	1239

\* \* \* \*

# GENERAL INFORMATION - TR100 Mining Truck

Section 000-0000

SM - 2034




Fig. 1 - Machine Dimensions

## ENGINE

Make/Model ..... Cummins KTA-38-C1050  
 Type ..... 4 Cycle, Turbocharged/Aftercooled  
 Gross Power  
 at 2 100 rev/min ..... 783 kW (1 050 hp, 1 094 PS)  
 Net Power at 2 100 rev/min ..... 727 kW (975 hp, 988 PS)

**Note:** Power ratings to SAE J1995 June 1990. Net Power is after deductions for fan and alternator. Engine requires no derating up to 3 050 m (10 000 ft) altitude.

Maximum Torque ..... 4631 Nm (3415 lbf ft)  
 at 1300 rev/min  
 Number of Cylinders/Configuration ..... 12V  
 Bore x Stroke ..... 159 x 159 mm (6.25 x 6.25 in)  
 Total Displacement ..... 37.7 litres (2300 in<sup>3</sup>)  
 Starting ..... Electric  
 Maximum Speed, Full Load ..... 2100 rev/min  
 Maximum Speed, No Load ..... 2400 rev/min  
 Idle Speed ..... 750 rev/min

## TRANSMISSION

Make/Model ..... Allison H 8610 AR CEC 2  
 Automatic electronic control with soft shift feature.  
 Remote mounted in the frame with integral TC 890 torque converter and planetary gearing. Six speeds forward, one reverse. Automatic converter lockup action in all speed ranges. Downshift inhibitor. Hydraulic retarder.

### Speeds With Standard Planetary

Forward						
Gear	1	2	3	4	5	6
Ratio	4.24	2.32	1.69	1.31	1.00	0.73
km/h	8.2	15.0	20.6	26.5	34.8	47.6
mile/h	5.1	9.3	12.8	16.5	21.6	29.6
Reverse						
Ratio	5.75					
km/h	6.0					
mile/h	3.8					

# General Information - TR100 Mining Truck

Section 000-0000

## DRIVE AXLE

Heavy duty axle with full floating axle shafts, single reduction spiral bevel gear differential and planetary reduction at each wheel.

Ratios:	Standard	Optional
Differential .....	2.16:1	2.16:1
Planetary .....	13.75:1	10.50:1
Total Reduction .....	29.70:1	22.68:1

## SUSPENSION

**Front:** King pin strut type independent front wheel suspension by self-contained, variable rate, nitrogen/oil cylinders.

**Rear:** Variable rate nitrogen/oil cylinders with A-frame linkage and lateral stabilizer bar.

Maximum Strut Stroke	
Front .....	229 mm (9.0 in)
Rear .....	175 mm (6.9 in)
Maximum Rear Axle Oscillation .....	± 7.0 Degrees

## WHEELS AND TYRES

Wheel Rim Width .....	19.5 in
Tyres (Front & Rear)	
Standard .....	27.00 R 49** Radial
Optional .....	27.00-49 (48 PR) E-4

**Note:** It is recommended that for tyres both listed and unlisted, the user should consult the tyre manufacturer and evaluate all job conditions in order to make the proper selection.

## BRAKES

### Service

All hydraulic brake system. Transmission mounted pressure compensating pump provides hydraulic pressure for brakes and steering. Independent circuits front and rear. Each circuit incorporates a nitrogen accumulator which stores energy to provide consistent braking response.

Front Brake Circuit Pressure .....	159 bar (2300 lbf/in <sup>2</sup> )
Rear Brake Circuit Pressure .....	52 bar (750 lbf/in <sup>2</sup> )
Accumulators:	
Nitrogen Precharge Pressure .....	55 bar (800 lbf/in <sup>2</sup> )

### Front:

Type .....	Dry Disc with 1 calliper per wheel
Disc Diameter .....	965 mm (38 in)
Pad Area, Total .....	2015 cm <sup>2</sup> (320 in <sup>2</sup> )

### Rear:

Type .....	Oil cooled, multiple friction discs, completely sealed from dirt and water.
Braking Surface, Total .....	87567 cm <sup>2</sup> (13573 in <sup>2</sup> )

## Parking

Application of rear brakes by springs in brake disc pack. Hydraulically released.  
Hold-off Pressure ..... 83 bar (1200 lbf/in<sup>2</sup>) |

## Retardation

Modulated lever control of rear disc pack.  
Retarder Actuation Pressure ..... up to 33 bar (480 lbf/in<sup>2</sup>) |

## Emergency

Push button solenoid control applies service and parking brakes. Automatically applies when engine is switched off. Parking brake applies should system pressure fall below a predetermined level.

Brakes conform to ISO 3450, SAE J1473 OCT 90.

## STEERING SYSTEM

Independent hydrostatic steering with closed-centre steering valve, accumulator and pressure compensating piston pump.

Accumulator provides uniform steering regardless of engine speed. In the event of loss of engine power it provides steering of approximately two lock-to-lock turns.

A low pressure indicator light warns of system pressure below 83 bar (1200 lbf/in<sup>2</sup>). Steering conforms to ISO 5010, SAE J53.

System Pressure .....	159 bar (2300 lbf/in <sup>2</sup> )
Relief Pressure .....	207 bar (3000 lbf/in <sup>2</sup> )
Steering Cylinders .....	Double Acting, Single Stage
Accumulator:	
Oil Capacity .....	16.4 litres (4.33 US gal)
Nitrogen Precharge Pressure .....	55 bar (800 lbf/in <sup>2</sup> )
Steering Angle (Left and Right) .....	39°
Pump:	
Type .....	Piston
Capacity at 2100 rev/min .....	2.0 litres/s (32 US gal/min)

## BODY HYDRAULICS

Two body hoist cylinders are mounted between the frame rails. Cylinders are two-stage with power down in the second stage.

System Relief Pressure .....	190 bar (2750 lbf/in <sup>2</sup> )
Pump:	
Type .....	Gear
Capacity at 2100 rev/min .....	6.1 l/s (97 US gal/min)
Control Valve .....	Servo Controlled, Open Centre
Body Raise Time .....	16.3 Seconds
Body Lower Time .....	18 Seconds

## ELECTRICAL

Type .....	24 V, Negative Ground
Battery .....	Four, 12 V, 210 Ah each, Maintenance Free
Accessories .....	24 V
Alternator .....	70 Amp
Starter .....	Two, 8.9 kW

# General Information - TR100 Mining Truck

Section 000-0000

## BODY

Longitudinal 'V' type floor with integral transverse box-section stiffeners. The body is exhaust heated and rests on resilient impact absorption pads.

Body wear surfaces are high hardness (360-440 BHN) abrasion resistant steel. Yield strength of plates 1000 MPa (145000 lbf/in<sup>2</sup>).

### Plate Thicknesses:

Floor .....	19 mm (0.75 in)
Side .....	10 mm (0.39 in)
Front, lower .....	10 mm (0.39 in)

ROPS Cabguard SAE J1040 Feb 86. ISO 3471

### Volumes:

Struck (SAE) .....	41.6 m <sup>3</sup> (54.4 yd <sup>3</sup> )
Heaped 2:1 (SAE) .....	57.0 m <sup>3</sup> (74.5 yd <sup>3</sup> )

## TYPICAL NOISE LEVELS

OPERATOR EAR (ISO 6394) ..... 83 dbA

\*EXTERIOR SOUND RATING  
(SAE J88 JUN 86) ..... 93 dbA

\*The above result is for the mode giving the highest exterior sound level when measured and operated as per the prescribed procedures of the standard. Results shown are for the unit in base configuration.

**Note:** Noise Level Exposure to the operator and bystander personnel may be higher depending upon proximity to buildings, rock piles, machinery etc.. The actual job site Noise Level Exposure must be measured and applicable regulations complied with in respect to Employee Hearing Protection.

## SERVICE CAPACITIES

Engine Crankcase and Filters .....	134 litres (35.4 US gal)
Transmission and Filters .....	100 litres (26 US gal)
Cooling System .....	304 litres (80.3 US gal)
Fuel Tank .....	1090 litres (288 US gal)
Steering Hydraulic Tank .....	61 litres (16.1 US gal)
Steering System .....	72 litres (19 US gal)
Body and Brake Cooling Tank .....	297 litres (78.5 US gal)
Body and Brake Cooling System .....	564 litres (149 US gal)
Planetaries (Total) .....	57 litres (15.1 US gal)
Differential .....	61 litres (16.1 US gal)
Front Ride Strut (Each) .....	27 litres (7.1 US gal)
Rear Ride Strut (Each) .....	18 litres (4.8 US gal)
Power Takeoff .....	1.5 litres (0.4 US gal)
Air Conditioning Compressor .....	0.135 litres (0.036 US gal)

VEHICLE WEIGHTS (MASS)		
	kg	lb
Chassis, with hoists	53240	117380
Body, standard	15380	33900
Net Weight	68620	151280
<b>PAYLOAD, maximum</b>	<b>90720</b>	<b>200000</b>
Maximum Gross Weight*	159340	351280
FOR UNIT EQUIPPED WITH OPTIONAL BODY LINER PLATES:		
Chassis, with hoists	53240	117380
Body, with wear plates	20910	46100
Net Weight	74150	163480
<b>PAYLOAD, maximum</b>	<b>85190</b>	<b>187800</b>
Maximum Gross Weight*	159340	351280
* Maximum permissible gross vehicle weight with options, attachments, full fuel tank and payload.		
WEIGHT DISTRIBUTION		
	Front Axle	Rear Axle
Empty %	49	51
Loaded %	34	66

\* \* \* \*

# General Information - TR100 Mining Truck

---

Section 000-0000

THIS PAGE IS INTENTIONALLY BLANK

## Welding



### WARNINGS

Before any welding is done on a machine equipped with any electronic systems, disconnect the following (if applicable) in this order: Battery earth cable, battery supply cable, alternator earth cables, alternator supply cables and electrical connections at the engine ECM, transmission ECU, body control lever, hydraulics ECU and cab bulkhead to avoid damage to electrical components. Turn off battery master switch to isolate the batteries before disconnecting any components. After welding connect all of the above in the reverse order.



Before any welding is done ensure all paint has been removed from the area to be welded. Failure to do so may result in hazardous fumes being given off from the paint.

**Note:** Always fasten the welding machines ground cable to the piece/frame being welded if possible.

Electric arc welding is recommended for all welded frame repairs. Since the nature and extent of damage to the frame cannot be predetermined, no definite repair procedure can be established. As a general rule however, if parts are twisted, bent or pulled apart, or a frame is bent or out of alignment, no welding should be done until the parts are straightened or realigned.

Successfully welded repairs will depend to a great extent upon the use of the proper equipment, materials and the ability of the welder. The Customer Support Department can be consulted regarding the feasibility of welding repairs.



### WARNING

Welding and flame cutting cadmium plated metals produce odourless fumes which are toxic. Recommended industrial hygiene practice for protection of the welding operator from the cadmium fumes and metallic oxides requires enclosure ventilation specifically designed for the welding process. A respiratory protective device such as the M.S.A. 'Gasfoe' respirator with G.M.A. cartridge will provide protection against cadmium, fumes and metallic oxides. The 'Gasfoe' respirator has been approved by the U.S. Bureau of Mines: Approval number 23B-10, and is designed to protect against gases, vapours, and/or metal fumes.

**Note:** The current from the welding rod always follows the path of least resistance. If, for example, the ground clamp is attached to the rear frame when welding is performed on the front frame, the current must pass a frame connection to return to the welding machine. Since the pivot coupling offers the least resistance but not a sound electrical connection, small electric arcs may be set up across the moving parts which may cause welding blotches on their wearing surfaces and increase the wear rate of these components.

## General Welding Procedure

The following general procedure should be used for the repair of defects outwith the vicinity of alloy steel castings.

1. Completely ARC-AIR gouge or grind out the crack until sound metal is reached. If ARC-AIR method is employed, pre-heat area to 100° C (212° F), measure 3 - 4" either side of repair prior to gouging. On completion of gouging grind to remove thin carbon layer.
2. Apply dye-penetrant check to ensure crack has been completely removed.

## General Information - Welding Procedure

---

Section 000-0010

3. Pre-heat area to 100° C (212° F), measured 3 - 4" either side of repair. Avoid local overheating.

4. Weld completely using E-7016 electrodes. Care must be taken to ensure electrodes are protected from moisture pick-ups at all times.

5. Allow repair weld to cool slowly.

6. Grind and blend repair to original contour. Paint heat damaged areas.

The following general procedure should be used for the repair of defects in alloy steel castings and in the welds joining steel castings.

1. Completely ARC-AIR gouge or grind out the crack until sound metal is reached. If ARC-AIR method is employed, pre-heat area to 200° C (392° F), measure

3 - 4" either side of repair prior to gouging. On completion of gouging grind to remove thin carbon layer.

2. Apply dye-penetrant check to ensure crack has been completely removed.


3. Pre-heat area to 200° C (392° F), measured 3 - 4" either side of repair. Avoid local overheating.

4. Weld completely using E-7016 electrodes. Care must be taken to ensure electrodes are protected from moisture pick-ups at all times.

5. On completion of welding, post-heat repair area to 400° C (752° F), measure 3 - 4" either side of repair.

6. If welding has to be interrupted for any reason, e.g. overnight, post-heat immediately as in Step 5.

\* \* \* \*



## REMOVAL



### WARNING

To prevent personal injury and property damage, be sure wheel chocks, blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.

To remove any of the components shown in Figs. 1 through 6 (or similar components) the following procedures should be carried out.

1. Position the vehicle in a level work area, apply the parking brake and switch off the engine.
2. Turn steering wheel several times to relieve pressure in the steering circuit. Block all road wheels.

3. Attach a suitable lifting device to the component and remove mounting hardware. Remove the component from the vehicle.

## INSTALLATION

**Note:** Tighten all fasteners to standard torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



### WARNING


To prevent personal injury and property damage, be sure wheel chocks, blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.

Using a suitable lifting device, align the component to be installed in position on the chassis. Secure the component securely to the chassis with mounting hardware removed during removal.

# Chassis - Chassis, Hood and Fenders

Section 100-00100

SM - 1586



## MAINTENANCE

### Inspection

Inspect the frame and attached parts at intervals not exceeding 250 hours for cracked or broken welds and bending/twisting of the frame. Any defects found should be repaired before they progress into major failures. Contact your dealer for recommended weld and repair instructions.

### Welding

**Note:** It is important that the electrical connections are disconnected in the following order to prevent damage to the electrical components:

- Disconnect battery equalizer ground cables.
- Disconnect battery cables from terminal posts (ground cable first).
- Disconnect battery equalizer positive cables.
- Disconnect electrical connections at the ECU.

After welding, reconnect all of the above in the reverse order.

### WARNING

**Welding and flame cutting cadmium plated metals produce odourless fumes which are toxic. Recommended industrial hygiene practice for protection of the welding operator from the cadmium fumes and metallic oxides requires enclosure ventilation specifically designed for the welding process. A respiratory protective device such as the M.S.A. 'Gasfoe' respirator with G.M.A. cartridge will provide protection against cadmium, fumes and metallic oxides. The 'Gasfoe' respirator has been approved by the U.S. Bureau of Mines: Approval number 23B-10, and is designed to protect against gases, vapours, and/or metal fumes.**

Electric arc welding is recommended for all chassis welding. Since the nature and extent of damage to the frame cannot be predetermined, no definite repair procedure can be established. As a general rule however, if parts are twisted, bent or pulled apart, or a frame is bent or twisted, no welding should be done




Fig. 3 - Exploded View of Fenders and Mounting

until the parts are straightened or realigned.

Successfully welded repairs will depend to a great extent upon the use of the proper equipment, materials and the ability of the welder. The Service Department can be consulted regarding the feasibility of welding repairs.

## Painting

A check of the condition of the paint should be made approximately twice a year and chassis repainted if necessary.

If painting of the actual frame of the unit is required,

thoroughly clean the areas to be painted. Apply a primer coat of red oxide and then a finish coat of polyurethane enamel.

To keep rust and corrosion to a minimum, periodic painting of abrasions and other exposed metal areas on the frame is highly recommended.

## SPECIAL TOOLS

There are no special tools required for procedures outlined in this section. Refer to Section 300-0070, SERVICE TOOLS for part numbers of general service tools required. These tools are available from your dealer.

# Chassis - Chassis, Hood and Fenders

Section 100-00100

SM - 2036






Fig. 4 - Exploded View of Ladders and Handrails




# Chassis - Chassis, Hood and Fenders

Section 100-00100

SM - 2037



\* \* \* \*



## REMOVAL



### WARNING

To prevent personal injury and property damage, be sure wheel chocks, blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.

To remove any of the components shown in Figs. 1 through 6 (or similar components) the following procedures should be carried out.

1. Position the vehicle in a level work area, apply the parking brake and switch off the engine.
2. Turn steering wheel several times to relieve pressure in the steering circuit. Block all road wheels.

3. Attach a suitable lifting device to the component and remove mounting hardware. Remove the component from the vehicle.

## INSTALLATION

**Note:** Tighten all fasteners to standard torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



### WARNING


To prevent personal injury and property damage, be sure wheel chocks, blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.

Using a suitable lifting device, align the component to be installed in position on the chassis. Secure the component securely to the chassis with mounting hardware removed during removal.

# Chassis - Chassis, Hood and Fenders

Section 100-00100

SM - 1586



## MAINTENANCE

### Inspection

Inspect the frame and attached parts at intervals not exceeding 250 hours for cracked or broken welds and bending/twisting of the frame. Any defects found should be repaired before they progress into major failures. Contact your dealer for recommended weld and repair instructions.

### Welding

**Note:** It is important that the electrical connections are disconnected in the following order to prevent damage to the electrical components:

- Disconnect battery equalizer ground cables.
- Disconnect battery cables from terminal posts (ground cable first).
- Disconnect battery equalizer positive cables.
- Disconnect electrical connections at the ECU.

After welding, reconnect all of the above in the reverse order.



### WARNING

Welding and flame cutting cadmium plated metals produce odourless fumes which are toxic. Recommended industrial hygiene practice for protection of the welding operator from the cadmium fumes and metallic oxides requires enclosure ventilation specifically designed for the welding process. A respiratory protective device such as the M.S.A. 'Gasfoe' respirator with G.M.A. cartridge will provide protection against cadmium, fumes and metallic oxides. The 'Gasfoe' respirator has been approved by the U.S. Bureau of Mines: Approval number 23B-10, and is designed to protect against gases, vapours, and/or metal fumes.

Electric arc welding is recommended for all chassis welding. Since the nature and extent of damage to the frame cannot be predetermined, no definite repair procedure can be established. As a general rule however, if parts are twisted, bent or pulled apart, or a frame is bent or twisted, no welding should be done




Fig. 3 - Exploded View of Fenders and Mounting

until the parts are straightened or realigned.

Successfully welded repairs will depend to a great extent upon the use of the proper equipment, materials and the ability of the welder. The Service Department can be consulted regarding the feasibility of welding repairs.

### Painting

A check of the condition of the paint should be made approximately twice a year and chassis repainted if necessary.

If painting of the actual frame of the unit is required,

thoroughly clean the areas to be painted. Apply a primer coat of red oxide and then a finish coat of polyurethane enamel.

To keep rust and corrosion to a minimum, periodic painting of abrasions and other exposed metal areas on the frame is highly recommended.


### SPECIAL TOOLS


There are no special tools required for procedures outlined in this section. Refer to Section 300-0070, SERVICE TOOLS for part numbers of general service tools required. These tools are available from your dealer.

# Chassis - Chassis, Hood and Fenders

Section 100-00100

SM - 2386





# Chassis - Chassis, Hood and Fenders

Section 100-00100

SM - 2388




Fig. 6 - Mudguards

\* \* \* \*




Fig. 1 - Exploded View of Engine Mounting

## DESCRIPTION

Numbers in parentheses refer to Fig. 1.

For engine make, model and specification, refer to Section 000-0000, GENERAL INFORMATION. For detailed engine servicing and repair data refer to the engine manufacturers service manual.

There are four full flow lube oil filters (30), two lube oil bypass filters (27) two fuel filters (28) and four coolant filters (29) installed on engine (1). Mounted at the front left hand side of the engine is the fuel pump and at the front right hand side of the engine is the alternator. There are two starter motors mounted at the rear right hand side of the engine, one of which is a prelube starter motor.

# Engine - Engine and Mounting

Section 110-0030

## REMOVAL

Numbers in parentheses refer to Fig. 1.



### WARNINGS

To prevent personal injury and property damage, ensure wheel blocks, blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.



High electrical current. Disconnect battery equalizer and battery cables at the batteries before removing engine attachments. High electrical current can cause sparks and personal injury from burns.

**Note:** Tag and identify all lines, hoses, cables and linkages disconnected to remove the engine.

1. Position the vehicle in a level work area, ensure the body is fully lowered, apply the parking brake and switch off the engine.

2. Turn steering wheel several times to relieve pressure in the steering circuit. Block all road wheels.

3. Disconnect electrical connections as follows:  
a. Disconnect battery equalizer ground cables.  
b. Disconnect battery cables from terminal posts (ground cable first).  
c. Disconnect battery equalizer positive cables.  
d. Disconnect electrical connections at the ECU.

4. Remove mounting hardware securing the hood and hood sides on the vehicle. Remove hood and hood side assemblies from the vehicle. Refer to Section 100-0010, CHASSIS, HOOD AND FENDERS.

5. Disconnect electrical connections from the radiator guard and remove mounting hardware securing the radiator guard on the vehicle. Remove radiator guard from the vehicle. Refer to Section 100-0010, CHASSIS, HOOD AND FENDERS.



### WARNING

Harmful gas. Before disconnecting any air conditioner lines refer to Section 260-0130, AIR CONDITIONING. Refrigerant will rapidly freeze all objects with which it comes into contact, and it can cause serious damage to the skin and eyes.

6. If the vehicle is equipped with an air conditioning system, evacuate refrigerant from the system and disconnect lines at the compressor. Refer to Section 260-0130, AIR CONDITIONING.

7. Place a suitable container under the engine drain port, remove drain plug and drain the oil. After draining, reinstall drain plug in the engine sump and tighten securely.

8. With suitable containers in position, open drain cocks and drain coolant from the radiator assembly and engine (1) assembly. Close all drain cocks after draining.

9. Identify all cooling lines for ease of installation and with suitable containers in position, disconnect all cooling lines from engine (1).

10. Using suitable lifting equipment, carefully remove the radiator, shroud and screen assemblies from the vehicle. Refer to Section 210-0040, RADIATOR, HEADER TANK AND MOUNTING.

11. Disconnect and remove air cleaner intake pipes from the engine turbochargers and air cleaner plenum chamber. Refer to Section 110-0050, AIR CLEANER.

12. Disconnect and remove exhaust tubes from the engine turbochargers.

13. Disconnect throttle control linkage from engine (1).

14. Identify heater lines for ease of installation and, with a suitable container in position, disconnect heater lines from engine (1).

15. Close fuel shutoff valve at filter head, identify fuel lines for ease of installation and, with a suitable container in position, disconnect fuel lines from engine (1).

16. Slacken T-bar clamp (38) and clamp (35) securing filler hose (37) and dipstick hose (36) respectively to hand hole cover (31) on left hand side of engine (1). Remove hose assemblies (36 & 37) from hand hole cover (31) and cover hose ends and fittings to prevent entry of dirt.

17. Remove bolt (40), nut (41) and clips (42 & 43) from twisted bracket (39). Tie hose assemblies (36 & 37) away from engine (1) to prevent fouling during engine removal.

18. Identify all electrical harnesses and cables attached to engine (1) assembly for ease of installation and disconnect from engine (1) assembly.

19. Disconnect front driveline from engine coupling and secure clear of engine (1). Refer to Section 130-0010, FRONT DRIVELINE.

20. Using suitable lifting equipment, remove tandem pump assembly from the left hand side of the engine power takeoff. Refer to Section 250-0055, TANDEM PUMP. The hydraulic lines can be left attached to the tandem pump.

21. Using suitable lifting equipment, remove main hydraulic pump assembly from the right hand side of the engine power takeoff. Refer to Section 230-0050, MAIN HYDRAULIC PUMP. The hydraulic lines can be left attached to the main hydraulic pump.



## WARNING

**Heavy assembly. To prevent personal injury and property damage, be sure lifting device is properly secured and of adequate capacity to do the job safely.**

22. Attach suitable lifting equipment to engine (1) lifting brackets and raise lifting equipment to take up the slack.

23. Remove bolts (7) and hardened washers (8) securing support (5) assembly to crossmember (6). Remove locknuts (13), bolts (7) and hardened washers (8) securing rear mounts (15) to the chassis.

24. Check to make certain that all necessary line and electrical disconnections have been made before lifting engine (1) assembly.

25. Carefully lift engine (1) assembly clear of the chassis and move to a clean work area. Securely mount engine (1) assembly to a work stand.

26. If necessary, remove shock mounts (9) from support (5) assembly and rear mounts (15). Rear mounts (15) can be removed from engine (1) by removing bolts (14 & 23) and hardened washers (12). Support (5) assembly can be removed by removing bolts (4).

27. If it is necessary to remove crossmember (6) from

the chassis, remove disc brake oil cooler and transmission oil cooler from crossmember (6) first. Refer to Section 210-0050, DISC BRAKE OIL COOLER, and, Section 210-0060, TRANSMISSION OIL COOLER.

28. With oil coolers removed, remove locknuts (13), hardened washers (12), bolts (10) and hardened washers (11). Remove front crossmember (6) from chassis mounts.

29. If necessary, adaptor (50) can be removed from the flywheel housing after the power takeoff and yoke assembly is removed. Refer to Section 110-0130, POWER TAKEOFF.

30. With the power takeoff and yoke assembly removed, remove bolts (49) and adapter (50) from the flywheel housing.

31. Remove bolts (51), hardened washers (52) and drive coupling (53) assembly from the flywheel.

32. Remove bolts (54) securing flange coupling (55) in drive coupling (53) and remove flange coupling (55) from drive coupling (53).

33. If necessary, support fan (48) assembly with suitable lifting equipment and remove bolts (45) and lockwashers (46) securing fan (48) and spacer (47) on engine (1) fan hub. Remove fan (48) and spacer (47).

## INSPECTION

Numbers in parentheses refer to Fig. 1.

1. Inspect shock mounts (9) for damage and replace if damaged.

2. Check all mounting components for cracks and excessive wear. Repair or replace as required.

3. Inspect drive coupling (53) and flange coupling (55) for wear or damage and replace if necessary.

4. Replace all filters (27, 28, 29 & 30). Check all drive belts for tension and wear, as described under 'Maintenance'.

5. Refer to the Engine Service Manual for additional engine disassembly/assembly, repair, adjustment and tune-up procedures.

## Engine - Engine and Mounting

Section 110-0030

### INSTALLATION

Numbers in parentheses refer to Fig. 1.

**Note:** Tighten all fasteners without special torques specified to standard torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



#### WARNING

To prevent personal injury and property damage, be sure lifting device is properly secured and of adequate capacity to do the job safely.

1. Position spacer (47) and fan (48) on engine (1) fan hub and secure with bolts (45) and lockwashers (46).
2. Thoroughly clean and dry threads on bolts (54) and drive coupling (53) and apply Loctite Activator 'T' to the threads. Apply Loctite 638 to the threads of bolts (54) and drive coupling (53). Position flange coupling (55) to drive coupling (53) and secure with bolts (54).

**Note:** The flange coupling must be installed on the drive coupling side opposite the side that has the part number on it. See Fig. 2.

3. Thoroughly clean and dry threads on bolts (51) and engine flywheel and apply Loctite Activator 'T' to the threads. Apply Loctite 638 to the threads of bolts (51) and engine flywheel. Position drive coupling (53) assembly to engine flywheel and secure with bolts (51) and hardened washers (52). The part number must be facing out. See Fig. 2.

**Note:** Incorrect assembly of drive coupling (53) assembly to the engine flywheel can cause engine and/or power takeoff damage.

4. Position adaptor (50) to the engine flywheel housing and secure with bolts (49). Install the power takeoff and yoke assembly to adaptor (50). Refer to Section 110-0130, POWER TAKEOFF.
5. Install new shock mounts (9) in support (5) assembly and rear mounts (15). Lubricate shock mounts (9) with water and press in using a driver of same diameter as internal metal sleeve in the shock mount to protect the rubber from damage.
6. Secure support (5) assembly to engine (1) with bolts (4). Secure rear mounts (15) to engine (1) with bolts (14 & 23) and hardened washers (12).




Fig. 2 - Sectional View of Engine Coupling Installation

7. Install front crossmember (6) on the chassis mounts and secure with bolts (10), hardened washers (11 & 12) and locknuts (13).

8. Install disc brake oil cooler and transmission oil cooler on front crossmember (6). Refer to Section 210-0050, DISC BRAKE OIL COOLER and, Section 210-0060, TRANSMISSION OIL COOLER.



#### WARNING

Heavy assembly. To prevent personal injury and property damage, be sure lifting device is properly secured and of adequate capacity to do the job safely.

9. Attach suitable lifting equipment to engine (1) lifting brackets and carefully position engine (1) assembly in the frame.