




**TEREX**

# TA30 (Tier 3) Articulated Dumptruck Maintenance Manual



[CLICK HERE TO RETURN TO MAIN LIBRARY INDEX](#)

Part No. 15501359

Sample of manual. Download All 376 pages at:

<http://www.terexrepairmanual.com/downloads/2005-terex-ta30tier-3-dump-truck-service-repair-workshop-manual/>

CUSTOMER SUPPORT DEPARTMENT  
TEREX EQUIPMENT LIMITED  
MOTHERWELL, SCOTLAND ML1 5RY  
REF. NO. SM859

Product: 2005 TEREX TA30(Tier 3) Dump Truck Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/2005-terex-ta30tier-3-dump-truck-service-repair-workshop-manual/>

Sample of manual. Download All 376 pages at:  
<https://www.arepairmanual.com/downloads/2005-terex-ta30tier-3-dump-truck-service-repair-workshop-manual/>

## TABLE OF CONTENTS

Section No.	Description	SM No.
<b>000</b>	<b>GENERAL INFORMATION</b>	
0000	Technical Data - TA30 Tier 3	2329 Rev 2
0010	Welding Procedure	2172
<b>100</b>	<b>CHASSIS</b>	
0010	Frames	2170
0020	Articulation and Oscillation Pivot	2273
0040	Hood and Mounting	2173
<b>110</b>	<b>ENGINE</b>	
0030	Engine and Mounting	2324 Rev 2
0040	Cooling Fan	2175
0050	Air Cleaner	2176
<b>120</b>	<b>TRANSMISSION</b>	
0010	Transmission and Mounting	2177
<b>130</b>	<b>DRIVELINES</b>	
0010	Front and Rear Drivelines	2178
<b>140</b>	<b>FRONT AXLE GROUP</b>	
0020	Axle Group (Hub)	(Refer to Section 160-0030)
0040	Wheel Rim and Tyre	(Refer to Section 160-0050)
0060	Differential Drive Head	(Refer to Section 160-0020)
<b>150</b>	<b>CENTRE AXLE</b>	
0020	Differential Drive Head	2337
<b>160</b>	<b>REAR AXLE GROUP</b>	
0020	Differential Drive Head	1969
0030	Axle Group (Hub)	2194 Rev 1
0050	Wheel Rim and Tyre	2179 Rev 2
<b>165</b>	<b>BRAKE PARTS</b>	
0010	Brake Parts - Rear	2180 Rev 1
0020	Brake Parts - Front	(Refer to Section 165-0010)
<b>170</b>	<b>PARKING BRAKE</b>	
0010	Parking Brake and Mounting	2181
0040	Parking Brake and Mounting	From A8591132 2409
<b>180</b>	<b>SUSPENSION SYSTEM</b>	
0020	Front Suspension	2182
0040	Rear Suspension	2183 Rev 1
<b>190</b>	<b>ELECTRICAL SYSTEM</b>	
0000	Circuit Diagrams	2184 Rev 2
0085	Hydraulic System ECU	2200
0270	Switches and Sensors	2335
<b>200</b>	<b>FUEL SYSTEM</b>	
0040	Fuel System	2186
0051	Electronic Foot Pedal	2187


## TABLE OF CONTENTS

Section No.	Description	SM No.
<b>210</b>	<b>COOLING SYSTEM</b>	
0000	Cooling System	2328 Rev 1
0040	Radiator and Mounting	2325
0060	Transmission Oil Cooler	2190 Rev 1
0100	Hydraulic Oil Cooler	2191 Rev 1
<b>215</b>	<b>MAIN HYDRAULIC VALVE</b>	
0050	Main Hydraulic Valve Assembly	2192 Rev 2
<b>220</b>	<b>STEERING SYSTEM</b>	
0000	Steering System Schematic	2197
0090	Steering Valve	2193
0120	Steering Cylinder	2195 Rev 1
<b>230</b>	<b>BODY SYSTEM</b>	
0000	Body System Schematic	2199 Rev 1
0040	Hydraulic Tank	2350
0050	Main Hydraulic Pump	2196
0081	Body Control Lever	2202
0130	Body Cylinder	2207
<b>250</b>	<b>BRAKING SYSTEM</b>	
0000	Braking System Schematic	2198
0060	Accumulators	2326
0070	Treadle Valve	2208
<b>260</b>	<b>OPERATORS COMPARTMENT</b>	
0010	Cab and Mounting	2209
0090	Driver Seat and Mounting	2210
0130	Air Conditioning	2211
<b>270</b>	<b>BODY</b>	
0010	Body and Mounting	2212
<b>300</b>	<b>MISCELLANEOUS</b>	
0020	Lubrication System	2204 Rev 5
0070	Service Tools	2206 Rev 2
0080	Axle Bolt and Nut Torque Specifications	1521
0080	Standard Bolt and Nut Torque Specifications	1238
0090	Unit Storage	1239

\* \* \* \*

# GENERAL INFORMATION - Technical Data

Section 000-0000



## ENGINE

Make/Model ..... Cummins QSM11  
Type ..... Four cycle diesel, turbocharged with air-to-air charge cooling, water-cooled. Electronic management.

Gross power at 2 100 rev/min ..... 261 kW (350 hp, 355 PS)  
Net power at 2 100 rev/min ..... 248 kW (333 hp, 338 PS)

**Note:** Gross power rated to SAE J1995 Jun 90. Engine emission meets USA EPA/CARB Tier III and EU NRMM (non-road mobile machinery) Tier III directive.

Maximum Torque .... 1 776 Nm (1 310 lbf ft) at 1 400 rev/min  
Number of cylinders/configuration ..... 6, in line  
Bore x Stroke ..... 125 x 147 mm (4.92 x 5.79 in)  
Piston Displacement ..... 10.8 litres (661 in<sup>3</sup>)  
Air cleaner ..... Dry type, double element  
Starting ..... Electric  
Maximum Speed (No load) ..... 2 350 rev/min  
Maximum Speed (Full load) ..... 2 100 rev/min  
Idle Speed ..... 750 rev/min  
Safe Operating Angle ..... 39°/81% Grade

## TRANSMISSION

Make/Model ..... ZF 6WG 310 RPC Automatic with manual override. The transmission assembly consists of a torque converter close-coupled to a countershaft-type gearbox with integral output transfer gearing. Automatic shifting throughout the range, with kickdown feature. Lockup action in all forward gears. A torque proportioning output differential transmits drive permanently to front and rear axles. This differential may be locked by the driver for use in difficult traction conditions. Standard integral hydraulic retarder which automatically operates should the engine

overspeed. Blocked filter indicator and filter bypass system provide valve block with additional protection from unfiltered oil.

### Pressures:

Main ..... 16 + 2 bar (232 + 30 lbf/in<sup>2</sup>)  
Lockup (Wk) ..... 12 ± 2 bar (174 ± 30 lbf/in<sup>2</sup>)  
Converter 'IN' ..... 10.5 bar (152 lbf/in<sup>2</sup>) at 2 300 rev/min  
Converter 'OUT' ..... 4.8 bar (70 lbf/in<sup>2</sup>) at 2 300 rev/min  
Converter Relief Valve ..... 8.5 bar (123 lbf/in<sup>2</sup>)  
Retarder ..... 5.5 bar (80 lbf/in<sup>2</sup>)

### Temperatures:

Normal ..... 80° - 110° C (176° - 230° F)  
Maximum (Retarder Mode) ..... 145° C (293° F)

Stall Speed ..... 1 805 ± 50 rev/min

### Ratios:

Torque Converter ..... 1.84:1  
Transmission ..... Refer to table below

Forward						
Gear	1	2	3	4	5	6
km/h	5.6	8.7	13.6	21.1	31.0	51.0
mile/h	3.5	5.4	8.5	13.1	19.3	31.7
Reverse						
Gear	1	2	3			
km/h	5.6	13.6	31.0			
mile/h	3.5	8.5	19.3			

# General Information - Technical Data

Section 000-0000

## AXLES

Three axles in permanent all-wheel drive with differential coupling between each axle to prevent driveline wind-up. Heavy duty axles with fully-floating axle shafts and outboard planetary reduction gearing.

Automatic limited slip differentials in each axle. Centre axle incorporates a through-drive differential to transmit drive to the rear axle. Locking of this differential is actuated simultaneously with the transmission output differential lock.

Ratios:

Differential .....	3.44:1
Planetary .....	6.35:1
Total Reduction .....	21.85:1

## SUSPENSION

**Front:** Axle is carried on the leading arms of a sub-frame which pivots on the main frame. Suspension is by rubber elements with four heavy duty hydraulic dampers.

**Rear:** Each axle is coupled to the frame by three rubber-bushed links with lateral restraint by a transverse link. Pivoting inter-axle balance beams equalise load on each axle. Suspension movement is cushioned by rubber/metal laminated compression units between each axle and underside of balance beam ends. Pivot points on rear suspension linkages are rubber-bushed and maintenance-free.

## WHEELS AND TYRES

Wheels: ..... 5-piece earthmover rims with 12 stud fixing Size:

Standard .....	25 x 19.50 in for 23.5 R25** tyres
Optional .....	25 x 22.00 in for 750/65 R25** tyres

Tyres:

Standard .....	23.5 R25**
Optional .....	750/65 R25**

Inflation Pressures (Bridgestone):

	Front	Rear
23.5 R25** .....	4.75 bar (69 lbf/in <sup>2</sup> )	4.75 bar (69 lbf/in <sup>2</sup> )
750/65 R25** ..	3.25 bar (47 lbf/in <sup>2</sup> )	3.25 bar (47 lbf/in <sup>2</sup> )

Inflation Pressures (Michelin):

	Front	Rear
23.5 R25** .....	4.0 bar (58 lbf/in <sup>2</sup> )	4.0 bar (58 lbf/in <sup>2</sup> )
750/65 R25** ....	3.0 bar (44 lbf/in <sup>2</sup> )	3.0 bar (44 lbf/in <sup>2</sup> )

Inflation Pressures (Pirelli):

	Front	Rear
23.5 R25** .....	4.8 bar (70 lbf/in <sup>2</sup> )	4.8 bar (70 lbf/in <sup>2</sup> )

Inflation Pressures (Continental):

	Front	Rear
23.5 R25** .....	5.0 bar (73 lbf/in <sup>2</sup> )	5.0 bar (73 lbf/in <sup>2</sup> )

Inflation Pressures (Marangoni):

	Front	Rear
750/65 R25** ....	3.0 bar (43 lbf/in <sup>2</sup> )	3.0 bar (43 lbf/in <sup>2</sup> )

**Note:** Tyre pressures should be regarded as nominal only. It is recommended that for tyres both listed and unlisted, the user should consult the tyre manufacturer and evaluate all job conditions in order to make the proper selection.

## HYDRAULIC SYSTEM

Braking, steering and body hoist systems are controlled by a main hydraulic valve mounted on frame. Systems are supplied with oil from a common tank by the main hydraulic pump, driven from power takeoff on transmission. System components are protected by full flow filtration on the return line.

Pump:

Type .....	Piston
Capacity at 2 100 rev/min .....	4.9 litre/s (77.4 US gal/min)

## Brakes

All hydraulic braking system with dry disc on each wheel with two heavy-duty callipers per disc. Independent circuits for front and rear brake systems. Warning lights and audible alarm indicate low brake system pressure. Brake system conforms to ISO 3450, SAE J1473.

Actuating Pressure ..... 103 bar (1 500 lbf/in<sup>2</sup>)

Discs:

Diameter .....	477 mm (18.8 in)
Thickness .....	16 mm (0.63 in)

Parking: Spring-applied, hydraulic-released disc on rear driveline.

Emergency: Automatic application of driveline brake should pressure fall in main brake hydraulic system. Service brakes may also be applied using the parking-emergency brake control.

Retardation: Hydraulic retarder integral with transmission, or optional engine brake.

## Steering

Hydrostatic power steering by two single-stage, double-acting, cushioned steering cylinders. Emergency steering pressure is provided by a ground driven pump mounted on the rear of the transmission. An audible alarm and warning light indicates should the emergency system activate. Conforms to ISO 5010, SAE J53.

System Pressure ..... 241 bar (3 500 lbf/in<sup>2</sup>)

Steering Angle to either side ..... 45°

Lock to Lock Turns, steering wheel ..... 4

## Body Hoist

Two single-stage, double-acting hoist rams, cushioned at both ends of stroke. Electro servo assisted hoist control.

System Pressure ..... 220 bar (3 200 lbf/in<sup>2</sup>)

Control Valve ..... Pilot Operated, Closed Centre

Body Raise Time (loaded) ..... 12 sec

Body Lower Time (power down) ..... 7.5 sec

## ELECTRICAL SYSTEM

Type ..... 24 volt, Negative Ground

Battery ..... Two, 12 Volt, 143 Ah each

Accessories ..... 24 Volt

Alternator ..... 70 Amp

# General Information - Technical Data

Section 000-0000

## BODY

Of all welded construction, fabricated from high hardness (min. 360 BHN) 1 000 MPa (145 000 lbf/in<sup>2</sup>) yield strength steel. 25° tail chute angle provides good load retention without tailgate.

### Plate Thicknesses:

Floor and Tailchute ..... 14 mm (0.55 in)  
 Sides ..... 12 mm (0.47 in)  
 Front ..... 8 mm (0.31 in)

### Volume:

Struck (SAE) ..... 13.8 m<sup>3</sup> (18.0 yd<sup>3</sup>)  
 Heaped 2:1 (SAE) ..... 17.5 m<sup>3</sup> (22.9 yd<sup>3</sup>)

## SERVICE CAPACITIES

Fuel tank ..... 398 litres (103 US gal)  
 Hydraulic System ..... 202 litres (53.4 US gal)  
 Engine Crankcase and filters ..... 34 litres (9.0 US gal)  
 Cooling System ..... 54 litres (14.3 US gal)  
 Transmission (including cooler) ..... 63 litres (16.6 US gal)  
 Differentials - Front & Rear (each) ..... 17 litres (4.5 US gal)  
 Differential - Centre ..... 18.5 litres (4.9 US gal)  
 Planetaries (each) ..... 3 litres (0.8 US gal)  
 Hand Pump Tank ..... 1 litres (0.26 US gal)  
 Air Conditioning Compressor ..... 0.125 litres (0.033 US gal)

## TYPICAL NOISE LEVELS

Operator Ear (ISO 6394) ..... 78 dbA

\*Exterior Sound Rating (ISO 6395) ..... 110 dbA

\* - The above result is for the mode giving the highest exterior sound level when measured and operated as per the prescribed procedures of the standard. Results shown are for the vehicle in base configuration.

**Note:** Noise Level Exposure to the operator and bystander personnel may be higher depending upon proximity to buildings, rock piles, machinery etc.. The actual job site Noise Level Exposure must be measured and applicable regulations complied with in respect to Employee Hearing Protection.

\* \* \* \*

Vehicle Weights		23.5 R25 Tyres	
Standard Vehicle	kg	lb	
<b>Net Distribution</b>			
Front Axle	11 720	25 840	
Centre Axle	5 300	11 685	
Rear Axle	5 400	11 905	
<b>Vehicle, Net</b>	<b>22 420</b>	<b>49 430</b>	
<b>Payload</b>	<b>28 000</b>	<b>61 730</b>	
<b>Gross Distribution</b>			
Front Axle	16 800	37 040	
Centre Axle	16 720	36 860	
Rear Axle	16 900	37 360	
<b>Vehicle, Gross</b>	<b>50 420</b>	<b>111 260</b>	
Bare Chassis	17 490	38 560	
Body	4 400	9 700	
Body Hoists (Pair)	530	1 170	

Ground Pressures		
At 15% sinkage of unloaded radius and specified weights		
23,5 R25	Net	Loaded
Front	115 kPa (16.7 psi)	165 kPa (23.9 psi)
Rear	52 kPa (7.5 psi)	165 kPa (23.9 psi)
750/65 R25	Net	Loaded
Front	90 kPa (13.1 psi)	128 kPa (18.6 psi)
Rear	41 kPa (5.9 psi)	111 kPa (18.6 psi)



## Welding



### WARNINGS

Before any welding is done on a machine equipped with any electronic systems, disconnect the following (if applicable) in this order: Battery earth cable, battery supply cable, alternator earth cables, alternator supply cables and electrical connections at the engine ECM, transmission ECU, body control lever, hydraulics ECU and cab bulkhead to avoid damage to electrical components. Turn off battery master switch to isolate the batteries before disconnecting any components. After welding connect all of the above in the reverse order.



Before any welding is done ensure all paint has been removed from the area to be welded. Failure to do so may result in hazardous fumes being given off from the paint.

**Note:** Always fasten the welding machines ground cable to the piece/frame being welded if possible.

Electric arc welding is recommended for all welded frame repairs. Since the nature and extent of damage to the frame cannot be predetermined, no definite repair procedure can be established. As a general rule however, if parts are twisted, bent or pulled apart, or a frame is bent or out of alignment, no welding should be done until the parts are straightened or realigned.

Successfully welded repairs will depend to a great extent upon the use of the proper equipment, materials and the ability of the welder. The Customer Support Department can be consulted regarding the feasibility of welding repairs.



### WARNING

Welding and flame cutting cadmium plated metals produce odourless fumes which are toxic. Recommended industrial hygiene practice for protection of the welding operator from the cadmium fumes and metallic oxides requires enclosure ventilation specifically designed for the welding process. A respiratory protective device such as the M.S.A. 'Gasfoe' respirator with G.M.A. cartridge will provide protection against cadmium, fumes and metallic oxides. The 'Gasfoe' respirator has been approved by the U.S. Bureau of Mines: Approval number 23B-10, and is designed to protect against gases, vapours, and/or metal fumes.

**Note:** The current from the welding rod always follows the path of least resistance. If, for example, the ground clamp is attached to the rear frame when welding is performed on the front frame, the current must pass a frame connection to return to the welding machine. Since the pivot coupling offers the least resistance but not a sound electrical connection, small electric arcs may be set up across the moving parts which may cause welding blotches on their wearing surfaces and increase the wear rate of these components.

## General Welding Procedure

The following general procedure should be used for the repair of defects outwith the vicinity of alloy steel castings.

1. Completely ARC-AIR gouge or grind out the crack until sound metal is reached. If ARC-AIR method is employed, pre-heat area to 100° C (212° F), measure 3 - 4" either side of repair prior to gouging. On completion of gouging grind to remove thin carbon layer.
2. Apply dye-penetrant check to ensure crack has been completely removed.

# General Information - Welding Procedure

---

Section 000-0010

3. Pre-heat area to 100° C (212° F), measured 3 - 4" either side of repair. Avoid local overheating.

4. Weld completely using E-7016 electrodes. Care must be taken to ensure electrodes are protected from moisture pick-ups at all times.

5. Allow repair weld to cool slowly.

6. Grind and blend repair to original contour. Paint heat damaged areas.

The following general procedure should be used for the repair of defects in alloy steel castings and in the welds joining steel castings.

1. Completely ARC-AIR gouge or grind out the crack until sound metal is reached. If ARC-AIR method is employed, pre-heat area to 200° C (392° F), measure

3 - 4" either side of repair prior to gouging. On completion of gouging grind to remove thin carbon layer.

2. Apply dye-penetrant check to ensure crack has been completely removed.

3. Pre-heat area to 200° C (392° F), measured 3 - 4" either side of repair. Avoid local overheating.

4. Weld completely using E-7016 electrodes. Care must be taken to ensure electrodes are protected from moisture pick-ups at all times.

5. On completion of welding, post-heat repair area to 400° C (752° F), measure 3 - 4" either side of repair.

6. If welding has to be interrupted for any reason, e.g. overnight, post-heat immediately as in Step 5.

\* \* \* \*

SM - 2783




Fig. 1 - General Arrangement of Frame Assemblies

## DESCRIPTION

The chassis consists of two separate frame assemblies which provide the articulation of the unit. The front and rear frames are constructed of all welded high-grade steel fabrications with rectangular box section beams forming main, side and cross members.

The front frame is fabricated to form a rigid structure which carries the cab, power train and suspension system.

The rear frame is fabricated to form a rigid structure which carries the body, body hydraulics, suspension and rear drive axles.

Steering is by frame articulation to 45° either side by two widely spaced vertical pivot pins in taper roller bearings. Oscillation between the front and rear frames is provided by a large diameter cylindrical coupling carried on nylon bushes located in the rear frame. Longitudinal shocks are absorbed by the thrust faces of the nylon bushes. A large thrust nut, which is threaded to the end of the coupling and locked to the frame, secures the coupling in position. Wear on the

thrust faces of the bushes is compensated by tightening this thrust nut.

## INSPECTION AND MAINTENANCE

### Inspection

Inspect the frames and attached parts at intervals not exceeding 250 hours for cracked or broken welds and bending of the frame. Any defects found should be repaired before they progress into major failures.

### Straightening

Hydraulic straightening or aligning equipment should be used to straighten bent or twisted frames whenever possible. However, if heat must be applied, never heat the metal beyond a dull, cherry red colour, as too much heat will weaken the metal. When it is necessary to heat the metal, apply heat uniformly over the area to be straightened and protect the heated surface from sudden cooling. Frame parts that cannot be straightened should be renewed.

# Chassis - Frames

Section 100-0010

## Welding



### WARNINGS

Before any welding is done on a machine equipped with the Quantum Electronic Fuel System, disconnect the following in this order: Battery earth cable, battery supply cable, alternator earth cables, alternator supply cables, body hydraulics joystick and electrical connections at the engine ECM, transmission ECU and hydraulics ECU to avoid damage to electrical components. Turn off battery master switch to isolate the batteries before disconnecting any components. After welding connect all of the above in the reverse order.



Before any welding is done ensure all paint has been removed from the area to be welded. Failure to do so may result in hazardous fumes being given off from the paint.

**Note:** Always fasten the welding machines ground cable to the piece/frame being welded if possible.

Electric arc welding is recommended for all welded frame repairs. Since the nature and extent of damage to the frame cannot be predetermined, no definite repair procedure can be established. As a general rule however, if parts are twisted, bent or pulled apart, or a frame is bent or out of alignment, no welding should be done until the parts are straightened or realigned.

Successfully welded repairs will depend to a great extent upon the use of the proper equipment, materials and the ability of the welder. The Customer Support Department can be consulted regarding the feasibility of welding repairs.



### WARNING

Welding and flame cutting cadmium plated metals produce odourless fumes which are toxic. Recommended industrial hygiene practice for protection of the welding operator from the cadmium fumes and metallic oxides requires enclosure ventilation specifically designed for the welding process. A respiratory protective device such as the M.S.A. 'Gasfoe' respirator with G.M.A. cartridge will provide protection against cadmium, fumes and metallic oxides. The 'Gasfoe' respirator has been approved by the U.S. Bureau of Mines: Approval number 23B-10, and is designed to protect against gases, vapours, and/or metal fumes.

**Note:** The current from the welding rod always follows the path of least resistance. If, for example, the ground clamp is attached to the rear frame when welding is performed on the front frame, the current must pass a frame connection to return to the welding machine. Since the pivot coupling offers the least resistance but not a sound electrical connection, small electric arcs may be set up across the moving parts which may cause welding blotches on their wearing surfaces and increase the wear rate of these components.

## Reinforcement

Frame reinforcement can be made with channel or angle or flat structural stock. Whenever possible, the reinforcement should extend well beyond the bent, broken or cracked area. The reinforcement stock thickness should not exceed that of the frame stock and the material should be of the same tensile strength.

## Painting

A check of the condition of the paint should be made approximately twice a year and chassis repainted if necessary.



**WARNING**

**Welding, burning, heating or dressing surfaces previously painted using polyurethane paint produces fumes which are toxic. Surfaces must be prepared using paint stripper prior to area being reworked. Recommended Industrial Hygiene and Safety Rules should be followed for protection of the welding operator from the fumes.**

To keep rust and corrosion to a minimum, periodic painting of abrasions and other exposed metal areas on the frames is highly recommended.

If painting of a frame is required, thoroughly clean the areas to be painted. Apply a primer coat of polyurethane red oxide and then a finish coat of polyurethane enamel.


\* \* \* \*



# CHASSIS - Articulation and Oscillation Pivot

Section 100-0020

SM-3109



- |                         |                       |                     |                         |                         |
|-------------------------|-----------------------|---------------------|-------------------------|-------------------------|
| 1 - Pivot Assembly      | 16 - Lockplate        | 27 - Lube Fitting   | 41 - Washer             | 55 - Lube Fitting       |
| 2 - Nylon Bush          | 17 - Front Yoke       | 28 - Plug           | 42 - Nut                | 56 - Elbow              |
| 3 - Loctite 648         | 18 - Brake Yoke       | 29 - 'O' Ring       | 43 - Lower Pin          | 57 - Adaptor            |
| 4 - Loc Quick Primer    | 19 - Bolt             | 30 - Bearing Assy   | 44 - Hardened Washer    | 58 - Connector          |
| 5 - Gasket              | 20 - Washer           | 31 - Retaining Ring | 45 - Washer             | 59 - Elbow              |
| 6 - Cover Plate         | 21 - Lockwasher       | 32 - Seal Housing   | 46 - Bolt               | 60 - Pipe Assembly      |
| 7 - Bolt                | 22 - Bolt             | 33 - Seal Housing   | 47 - Bolt               | 61 - Washer             |
| 8 - Bearing Assy - Cup  | 23 - Extreme Pressure | 34 - Seal Housing   | 48 - Bolt               | 62 - Bolt               |
| 9 - Bearing Assy - Cone | Lithium No.2 Grease   | 35 - Seal Housing   | 49 - Loctite 243        | 63 - Thrust collar-Rear |
| 10 - 'V' Ring Seal      | 24 - SAE 80W-90 EP    | 36 - Seal           | 50 - Thrustcollar-Front | 64 - Shim               |
| 11 - Thrust Nut         | Gear Oil              | 37 - Seal           | 51 - 'O' Ring           | 65 - Shim               |
| 12 - Locking Plate      | 25 - Plug             | 38 - Shim           | 52 - Hose Assembly      | 66 - Shim               |
| 13 - Antiseize Comp     | 26 - Extreme Pressure | 39 - Spacer         | 53 - Hose Assembly      | 67 - Shim               |
| 14 - Driveshaft         | Multipurpose Grease   | 40 - Upper Pin      | 54 - Connector          | 68 - Shim               |
| 15 - Seal               |                       |                     |                         |                         |

Fig. 1 - Articulation and Oscillation Pivot

## DESCRIPTION AND OPERATION

The articulation and oscillation pivot allows the front and rear frames to rotate horizontally (articulation) and tilt laterally (oscillation) with respect to each other. It is also the main load bearing coupling between the two frames. The pivot assembly houses the driveshaft

connecting the drive between the front and rear frames.

Articulation bearings, oscillation bushes, pivot driveshaft bearing and associated parts can be removed, inspected and replaced or renewed by following the procedures outlined in this section.

# Chassis - Articulation and Oscillation Pivot

Section 100-0020

## THRU-DRIVE DRIVESHAFT

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

**Note:** The following procedures assume that only thru-drive components require repair.

**Note:** Tighten all fasteners without special torques specified to torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



### WARNINGS

To prevent personal injury and property damage, be sure wheel blocks are properly secured and of adequate capacity to do the job safely.



When necessary to drive out or drive on components during disassembly/assembly, be sure to use a soft drift to prevent property damage and personal injury.

## Removal and Disassembly

1. Position the vehicle on a level work area and apply parking brake.
2. Raise body and install body safety prop to secure body in partially raised position.
3. Shut down engine and block all wheels securely.
4. Identify the relationship of the driveline caps to the transmission yoke and front yoke (17). Remove capscrews and remove driveline from vehicle.  
**Note:** Take extra care when handling drivelines as any deformity on a rotating mass creates vibration and excessive wear during any operation.
5. Remove wheel blocks, start engine and steer vehicle into a full left-hand lock. Shut down engine and block all wheels securely.
6. Remove Lockplate (16) , 2 Off Front bolts (19) & Front thrust collar (50).
7. Remove and discard 'O' rings (29 & 51) from Thrust collar (50).
8. Place a suitable container under the front of the pivot and pull front yoke (17) from driveshaft (14).

9. Disconnect mounting hardware securing protective guard (if fitted), from beneath the parking brake disc, to the rear frame.

10. Release the parking brake by turning the hex-head on the parking brake actuator fully anticlockwise.



### WARNING

Tensioned spring on adjuster.

11. Remove mounting hardware securing parking brake assembly to mounting bracket on frame, then secure parking brake assembly clear of brake disc.

12. Identify the relationship of the driveline caps to brake yoke (18). Remove capscrews, disconnect driveline and secure clear of brake yoke.

13. Withdraw driveshaft assembly (14) from housing by pulling rearwards on parking brake disc/brake yoke assembly (18). If necessary, tap front end of driveshaft (14) to ease removal, take care to avoid damaging threads. Place driveshaft (14) assembly on work bench for further disassembly.

14. Prise out and discard seal (15) from front of the housing.

15. Lift out front bearing assembly cup (8) from front of the housing.

16. If bearing replacement is required, use a suitable puller to remove front and rear bearing assembly cups (8) from the housing.

**Note:** If either bearing assembly cup or cone (8 or 9) need replacing, they must be replaced as a set.

17. If retaining rings (31) need replacing, use a suitable drift or puller to remove them from the housing.

18. Temporarily install front yoke (17) fully onto front of driveshaft (14) and suitably restrain to resist rotation.

19. Remove mounting hardware securing parking brake disc to brake yoke (18) and remove brake disc.

20. Remove Lockplate (16) , 2 off Rear bolts (19) , Rear Thrust collar (63) & Brake yoke (18) from driveshaft (14). Identify front and rear ends of driveshaft (14).

21. Remove and discard 'O' rings (29 & 51) from Rear Thrust collar (63).

22. Remove and discard seal (15) from driveshaft (14).

23. If bearing replacement is required, use a suitable puller or drift to remove rear bearing assembly cone (9) from driveshaft (14).

## Inspection

1. Clean all parts with a suitable solvent and let dry. DO NOT spin bearings with compressed air. Place bearings on a clean surface, cover with a lint free cloth and allow to dry.

2. Check bearing assemblies cups and cones (8 & 9) for wear or damage. Renew as necessary.

**Note:** If either bearing assembly cup or cone (8 or 9) need replacing, they must be replaced as a set.

3. Inspect splines of driveshaft (14) and yokes (17 & 18) for nicks, burrs or excessive wear. Replace if wear is excessive or splines are nicked. Burrs may be removed with a fine file or medium India stone.

4. Check yokes (17 & 18) for damage in region polished by oil seal lip; even slight damage in this area can cause leakage. Very slight marks may be polished out with fine emery cloth but it is essential that polishing marks are parallel to the seal lip.

5. Replace all seals and 'O' rings with new parts.

## Assembly and Installation


1. If removed, use a suitable driver and install retaining rings (31) into housing, ensuring that they butt hard against abutment shoulders.

2. Using a suitable driver, install front bearing cup (8) into tractor end of pivot casing. Ensure it is firmly seated & that a 0.05mm (0.002") feeler gauge **cannot** be inserted between cup and mating face.

3. Check rear bearing cup (8) is firmly seated in the body end of the pivot casing, again ensuring 0.05mm (0.002") feeler gauge **cannot** be inserted between cup and mating face.

4. Lightly oil both bearing assembly cones (9) with SAE 80W - 90 E. P. gear oil (24).

5. Support driveshaft (14) in a suitable fixture & tap one Bearing assembly cone (9) onto driveshaft (14) using a tubular mandrel.



6. Refer to Fig. 2, Maintain end face of cone approximately 55mm from end of spline face.

7. Insert driveshaft (14) into truck end of pivot casing until bearing assembly cone (9) seats firmly in the bearing assembly cup (8).

8. Apply loctite (3) to new seal (15) and fit over the driveshaft (14) with seal 'Lip' to bearing side. Press seal home using a mandrel.

9. Apply grease to splines of Front yoke (17) and slide onto the drive shaft (14).

10. Fit new 'O'-rings (29 & 51) to Front thrust collar (50) and fit collar over stub end of driveshaft (14) (align mating holes). Fit 2 off front bolts (19).

11. Tighten Front bolts (19) ; alternately 1/4 - 1/2 turns, drawing driveshaft (14) hard against the inner face of Front thrust collar (50). Shaft will be visible through inspection hole on the collar.

12. Lock Front yoke (17) from rotation by a suitable method / bar acting on the ground. Torque front bolts (19) to 54Nm/39 lbf ft.

13. Using special mandrel (15270104) home locking plate (16) onto Bolts (19). Remove the clamping bar.

14. Slide Rear bearing assembly cone (9) onto rear end of drive shaft (14) until it seats in bearing assembly cup (8).

15. Position clamping bar assembly and screw central bolt hard against bolts (19) of front thrust collar (50), enabling body end bearing to be fully seated home.

16. Using mandrel and heavy hammer, drive Rear bearing assembly cone, fully into cup. Now remove clamp bar assembly from front end.

# Chassis - Articulation and Oscillation Pivot

Section 100-0020

Sm 3144




Fig. 3 - Measurements / various

17. Take remaining seal (15), apply loctite (3) and fit over drive shaft with seal 'Lip' to bearing side. Press seal home using a mandrel.

18. Apply grease to splines of brake yoke (18) and slide onto drive shaft (14). Ensure milled slots of driving flanges are aligned with those of brake yoke.

**Note :** For Measurement letters- refer to fig. 3, unless otherwise stated.

19. Before fitting of Rear Thrust collar (63) record Measurements as stated:

- i) Measure total width 'A' of Rear thrust collar (63)
- ii) Using Depth micrometer, measure inner bore depth 'B' of collar (63) and record value.
- iii) Subtract 'B' from 'A' to determine recess dimension 'C'.

20. Fit Rear thrust collar (63) without 'O'-rings onto Drive shaft (14) and tighten Rear bolts (19) to a nominal torque of 15Nm/11lbf ft.

**Note :** a gap should be visible between end of shaft and inner face of collar.

21. Using a Depth micrometer, measure distance 'D' from collar (63) outer face to end face of drive shaft (14) via the hole in the collar and record the value.

22. The actual free air space 'E' to be shimmed between end of drive shaft (14) and compression face of Thrust collar (63) equals:

$$E = D - C.$$

23. Now add 0.6mm (0.024") to dimension 'E' to allow for oversize shims. This value is dimension 'F' (End float will be determined by subtraction).

24. Remove Rear bolts (19) and Rear thrust collar (63) from pivot body end and chap drive shaft (14) to free bearing.

25. Calculate the nominal combination of minimum number of shims (64) to achieve the size nearest to dimension 'F'. Record the appropriate part numbers and total nominal thickness value.

26. Select the shims (64) and measure the total actual thickness of the combination. Record this value.

27. Place the shim pack (64) in the rear thrust collar (63), lock off the Brake yoke (18) from rotation by suitable method / bar on ground. Torque bolts (19) to full torque.

28. Remove the clamp and spin the yoke (18) to ensure driveshaft (14) free rotation.

29. Take a magnetic clock gauge located on the flange of pivot casing, needle acting on rear thrust collar (63)

end face. Check Brake yoke (18) float movement.

30. Take reading obtained and subtract a figure sufficient to give an end float in the range 0.05mm - 0.15mm (0.002" - 0.006"), reduce shim pack (64) accordingly.

31. Remove Rear thrust collar (63) and shims (64) and re-assemble with the appropriate shims. Ensure 'O'-rings (29 & 51) are now fitted.

32. Lock Brake yoke (18) flange as before ,applying alternate 1/4 -1/2 turns on bolts (19). Torque to 54 Nm (39 lbf ft).

33. Remove the locking bar and confirm that the driveshaft (14) end float is in the range 0.05mm - 0.15mm (0.002" - 0.006") by moving the brake yoke (18) for and aft against the clock gauge.

34. Adjust and refit the shim pack (63) as necessary.

35. Float set correctly; Drive home locking plate (16) using a mandrel (15270104) . Re-check the end float.

36. Install parking brake disc on brake yoke (18) and secure with bolts and washers. Tighten bolts to a torque of 73 Nm (54 lbf ft).

37. Install parking brake assembly to mounting brackets and secure with bolts, washers and nuts. Refer to Section 170-0010, PARKING BRAKE AND MOUNTING.

38. Apply parking brake by turning the hex-head on the parking brake actuator fully clockwise.

39. Apply Loctite 638 to the threads of capscrews used to mount driveline to brake yoke (18). Align match marks and install driveline. Tighten capscrews to a torque of 153 Nm (113 lbf ft).

40. Apply Loctite 638 to the threads of capscrews used to mount driveline between transmission yoke and front yoke (17). Align match marks and install driveline. Tighten capscrews to a torque of 153 Nm (113 lbf ft).

41. Remove bolts (7), washers (20), gasket (5) and cover plate (6) from side of oscillation hub to gain access to filler/level hole plug (25) on pivot assembly (1). Remove filler/level plug (25).

42. Add SAE 80W - 90 E. P. gear oil (24) through filler/level hole in pivot assembly (1) until the oil is level with the bottom of filler/level hole.

43. Remove plug (25) from underside of oscillation hub to drain the cavity between the oscillation hub and pivot assembly (1) of any oil that entered while filling the driveshaft bearing housing.

44. Install plug (25) into filler/level hole on pivot assembly (1). Install gasket (5) and cover plate (6) on side of oscillation hub, secure with bolts (7) and washers (20).

45. Install plug (25) into cavity drain port on underside of oscillation hub.

46. Install parking brake disc protective guard (if fitted) and secure with bolts, washers and nuts. Tighten nuts to a torque of 73 Nm (54 lbf ft).

47. Start engine, raise body, lower body safety prop and lower body.

48. Remove wheel blocks.

## ARTICULATION COMPONENTS

Numbers in parentheses refer to Fig. 1, unless otherwise specified.

**Note:** The following procedures assume that only components associated with articulation require repair.

**Note:** It is essential that the grease used for articulation components is Extreme Pressure Lithium Complex No. 2 (23), as specified in Section 300-0020, LUBRICATION SYSTEM.

**Note:** Tighten all fasteners without special torques specified to torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



### WARNINGS


**To prevent personal injury and property damage, be sure wheel blocks, blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.**



**When necessary to drive out or drive on components during disassembly/assembly, be sure to use a soft drift to prevent property damage and personal injury.**

# Chassis - Articulation and Oscillation Pivot

Section 100-0020



## Disconnecting Front and Rear Frames

**Note:** The front and rear frames can be separated sufficiently to permit disassembly/assembly of the articulation components without disconnecting hydraulic lines or electrical wiring.

1. Position the vehicle on a level work area and apply parking brake.
2. Raise body and install body safety prop to secure body in partially raised position.
3. Shut down engine and block all wheels securely.
4. Identify the relationship of the driveline caps to the transmission yoke and front yoke (17). Remove capscrews and remove driveline from vehicle.
5. Support tractor frame at front and rear with suitably placed stands or timbers so the frame will remain level during and after pin removal.
6. Remove bolts, washers and pins securing steering cylinders to pivot. Secure steering cylinders clear of pivot.
7. Release the parking brake by turning the hex-head on the parking brake actuator fully anticlockwise.



### WARNING

Tensioned spring on adjuster.

8. Attach suitable lifting equipment to pivot/rear frame assembly. Lifting equipment must prevent pivot from oscillating after separation, and, be capable of pulling pivot/rear frame assembly clear of front frame. Raise lifting equipment to support pivot/rear frame assembly.

9. Remove bolt (62), washer (61), large nut (42) and washer (41) securing upper pin (40).

10. Remove upper pin (40). If necessary tap upper pin (40) to ease removal taking care to avoid damaging the threads.

**Note:** It may be necessary to relieve binding between the pin and pin bores by raising or lowering the pivot/rear frame assembly.

11. Remove bolt (48) and hardened washer (44) securing lower pin (43).

12. Remove lower pin (43). If necessary tap lower pin (43) to ease removal taking care to avoid damaging the pin.

**Note:** Only separate the frames sufficiently to permit removal of the articulation bearings or damage to hydraulic and electrical connections could result.

13. Remove blocks from rear wheels and use lifting equipment to pull pivot/rear frame assembly clear of the front frame. After moving, block pivot/rear frame assembly and block the wheels.

14. Remove spacer (39) noting orientation to ensure correct installation.

## Disassembly

1. Identify seal housings (32, 33, 34 & 35) to ensure correct location on assembly/installation.

**Note:** Seal housings (32, 33, 34 & 35) are not interchangeable.

2. Remove bolts (46 & 47), washers (45), seal housings (32, 33, 34 & 35) and upper and lower shims (38).

3. Prise out and discard seals (36 & 37) from the housings.

4. Remove and tag all bearing assemblies (30) with spacers to ensure correct assembly/installation.

**Note:** Bearing assemblies (30) and spacers are a matched set, never interchange cups, cones or spacers between sets.

## Inspection

1. Clean all parts with a suitable solvent and let dry. DO NOT spin bearings with compressed air. Place bearings on a clean surface, cover with a lint free cloth

and allow to dry.

2. Check bearing assemblies (30) and spacers, and pins (40 & 43) for wear or damage. Renew as necessary.

**Note:** Bearing assemblies (30) and spacers must be renewed as a matched set.

3. Replace all seals with new parts.

## Assembly

1. Apply Loctite 243 (49) sparingly to bore of seal housings (32, 33, 34 & 35).

2. Using a suitable driver, install seals (36 & 37) into seal housings (32, 33, 34 & 35) ensuring that the metal ring on inside of the seals are not disturbed, and, that they are located towards the inside of seal housing.

3. Apply Loctite 243 (49) to threads of outer seal housing bolts (46).

4. Place outer seal housings (32 & 34) in position ensuring that grease relief hole in seal housings are directly opposite bearing grease port on pivot. Secure with bolts (46) and washers (45). Tighten bolts (46) to a torque of 94 Nm (68 lbf ft).

**Note:** Bearing assemblies (30) and spacers are a matched set, never interchange cups, cones or spacers between sets.

5. Using Extreme Pressure Lithium Complex No. 2 grease (23), pack bearing assemblies (30), including end faces, and install bearings.

6. Place inner seal housings (33 & 35) temporarily in position and secure with bolts (47) and washers (45). Tighten bolts (47) to a torque of 16 Nm (12 lbf ft).

7. Using feeler gauges, as shown in Fig. 4, measure the dimension between the inner pivot faces and seal housings (33 & 35). Measure at 3 positions equally spaced around seal housings and determine average dimension, this is the size of shims (38) required.

8. Remove bolts (47), washers (45) and inner seal housings (33 & 35).

9. Install shims (38) as calculated at Step 7, reinstall inner seal housings (33 & 35) and secure with bolts (47) and washers (45). Tighten bolts (47) to a torque of 94 Nm (68 lbf ft).

## Connecting Front and Rear Frames

1. Install spacer (39) in upper outer seal housing (32), as noted on removal.

2. Smear bearing and pin bores with Extreme Pressure Lithium Complex No. 2 grease (23).

3. Attach suitable lifting equipment to pivot/rear frame assembly. Lifting equipment must prevent pivot from oscillating and be capable of pulling pivot/rear frame assembly to align pivot bearing bores and front frame pin bores. Raise lifting equipment to support pivot/rear frame assembly.

4. Remove blocks from rear wheels and blocking from pivot/rear frame assembly. Using lifting equipment, pull pivot/rear frame assembly to align pivot bearing bores and front frame pin bores. Block wheels and block pivot/rear frame assembly to remain level and stationary.

5. Freeze upper and lower pins (40 & 43) to ease installation.

6. Smear lower pin (43) with Extreme Pressure Lithium Complex No. 2 grease (23) and install through front frame and bearing bores.

**Note:** It may be necessary to relieve binding between the pin and pin bores by raising or lowering pivot/rear frame assembly.

7. Apply Loctite 243 (49) to threads of bolt (48) and secure lower pin (43) with bolt (48) and hardened washer (44). Tighten bolt (48) to a torque of 73 Nm (54 lbf ft).

8. Smear upper pin (40) with Extreme Pressure Lithium Complex No. 2 grease (23) and install through front frame and bearing bores.

9. Apply Loctite 243 (49) to threads of bolt (62). Secure upper pin (40) with bolt (62), washer (61), large nut (42) and washer (41). Tighten nut (42) to a torque of 1 425 Nm (1 050 lbf ft).

## Final Assembly

1. Apply parking brake by turning the hex-head on the parking brake actuator fully clockwise.

2. Remove lifting equipment from pivot/rear frame assembly.

3. Remove stands or timbers from front frame.

# Chassis - Articulation and Oscillation Pivot

Section 100-0020

4. Apply Loctite 270 to the threads of capscrews used to mount driveline between transmission yoke and front yoke (17). Align match marks and install driveline. Tighten capscrews to a torque of 153 Nm (113 lbf ft).

5. Align steering cylinder bores and mounting pin bores on pivot, install pins and secure with bolts and washers. Tighten bolts to a torque of 73 Nm (54 lbf ft).

6. Remove plugs (28) from articulation bearing, grease ports and replace with lube fittings (27).


**Note:** Lube fittings (27) are stored on pad on side of pivot assembly (1).

7. Fill bearing housings with Extreme Pressure Lithium Complex No. 2 grease (23), through lube fittings (27), until excess grease starts to escape from seal housings (32 & 34).

8. Remove lube fittings (27) and reinstall plugs (28). Store lube fittings (27) on pad on side of pivot assembly (1).

9. Start engine, raise body, lower body safety prop and lower body.

10. Remove wheel blocks.



**lifting equipment are properly secured and of adequate capacity to do the job safely.**

**⚠ When necessary to drive out or drive on components during disassembly/assembly, be sure to use a soft drift to prevent property damage and personal injury.**

**⚠ Hydraulic fluid pressure will remain within the braking system after engine shut down. Operate the treadle pedal continuously until the pressure has dissipated before carrying out any work on the braking system or serious injury could result.**

## OSCILLATION COMPONENTS

Numbers in parentheses refer to Fig. 1.

**Note:** The following procedure assumes that only components associated with oscillation require repair.

**Note:** It is necessary to disconnect the front and rear frames at the articulation point to service the oscillation components.

**Note:** It is essential that the grease used for oscillation components is Extreme Pressure Multipurpose Grease (26), as specified in Section 300-0020, LUBRICATION SYSTEM.

**Note:** Tighten all fasteners without special torques specified to torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.

### **⚠ WARNINGS**

**To prevent personal injury and property damage, be sure wheel blocks, blocking materials and**

## Disconnecting Front and Rear Frames

1. Position the vehicle on a level work area and apply parking brake.
2. Raise body and install body safety prop to secure body in partially raised position.
3. Shut down engine and block all wheels securely.
4. Depress and release brake pedal continuously to relieve the pressure in the braking system.
5. Carefully loosen brake lines at base of both accumulators to check that the pressure has released. Re-tighten brake lines.
6. Tag all hydraulic lines and electrical wiring between front and rear frames to ensure correct assembly/installation. Disconnect all hydraulic lines and plug openings to prevent ingress of dirt. Disconnect electrical wiring and any other attachments which could be damaged on separation of front and rear frames.

7. Identify the relationship of the driveline caps to the transmission yoke and front yoke (17). Remove capscrews and remove driveline from the vehicle.

8. Support tractor frame at front and rear with suitably placed stands or timbers to keep the frame level during and after pin removal.

9. Remove bolts, washers and pins securing steering cylinders to pivot. Secure steering cylinders clear of pivot.

10. Release the parking brake by turning the hex-head on the parking brake actuator fully anticlockwise.



**WARNING**  
Tensioned spring on adjuster.

11. Attach suitable lifting equipment to pivot/rear frame assembly. Lifting equipment must prevent pivot from oscillating after separation, and, be capable of pulling pivot/rear assembly clear of front frame. Raise lifting equipment to support pivot/rear frame assembly.

12. Remove bolt, washer, large nut (42) and washer (41) securing upper pin (40).

13. Remove upper pin (40). If necessary tap upper pin (40) to ease removal taking care to avoid damaging the threads.

**Note:** It may be necessary to relieve binding between the pin and pin bores by raising or lowering the pivot/rear frame assembly.

14. Remove bolt (48) and hardened washer (44) securing lower pin (43).

15. Remove lower pin (43). If necessary tap lower pin (43) to ease removal taking care to avoid damaging the pin.

16. Remove blocks from rear wheels and use lifting equipment to pull pivot/rear frame assembly clear of the front frame. After moving, block pivot/rear frame assembly and block the wheels.

17. Remove spacer (39) noting orientation to ensure correct installation. Cover articulation bearings to prevent ingress of dirt.

## Disassembly

1. Remove protective guard (if fitted) from beneath parking brake disc by removing mounting hardware

securing guard to the rear frame. Refer to Section 170-0010, PARKING BRAKE AND MOUNTING.

2. Remove mounting hardware securing parking brake assembly to mounting bracket on frame. Remove and secure parking brake assembly clear of brake disc.

3. Identify the relationship of the driveline caps to brake yoke (18). Remove capscrews, disconnect driveline and secure clear of brake yoke (18).

4. Remove mounting hardware securing parking brake disc to brake yoke (18) and remove brake disc.

5. Place a suitable container under rear brake yoke (18) to catch oil released when pulling brake yoke (18) from driveshaft (14).

6. Remove Rear bolts (19), Lockplate (16) & Rear thrust collar (63). Pull brake yoke (18) from driveshaft (14).

7. Remove adaptor (57), connector (58), elbow (59) and pipe assembly (60) from oscillation hub.

8. Remove bolts (22) and washers (21) securing locking plate (12). Remove locking plate (12).

9. Restrain pivot assembly (1) to prevent it oscillating, by placing a heavy bar between the steering cylinder mountings. Lock the bar in position using suitable trestles or stands. See Fig. 5.

10. Using a suitable tool, remove thrust nut (11). If wear area of thrust nut (11) is damaged, replace thrust nut (11).

11. Insert an M20 eyebolt into tapped pad provided on top of pivot assembly (1) and attach suitable lifting equipment.

12. Remove pivot restraining bar.

13. Using lifting equipment, carefully pull pivot assembly (1) clear of oscillation hub. Place pivot assembly (1) in a suitable work area for further disassembly.


14. Note position of front 'V' ring (10) to aid in 'Installation'. Remove and discard 'V' ring (10).

15. Inspect nylon oscillation bushes (2) as described in 'Inspection'. If bushes are to be renewed, proceed with step 16.

16. Remove nylon oscillation bushes (2) with hammer and chisel.

# Chassis - Articulation and Oscillation Pivot

Section 100-0020



**Note:** The suggested method is to make an axial cut along the bush then to lever the bush in order to collapse it upon itself.

## Inspection

1. Clean nylon oscillation bushes with a suitable solvent and allow to dry.
2. Inspect nylon oscillation bushes for wear, scoring, erosion and 'out of round'. Pay particular attention to the thrust faces of the bushes which should also be inspected for cracking/splitting. Renew if required.
3. Replace all seals with new parts.

## Assembly

Numbers in parentheses refer to Fig. 1.

**Note:** Tighten all fasteners without special torques specified to torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



### WARNING

To prevent personal injury and property damage, be sure wheel blocks are properly secured and of adequate capacity to do the job safely.

1. Wipe bush housing clean using a suitable solvent and allow to dry.
2. Apply Loctite 648 (3) and Loc Quick Primer (4) and align new bushes (2) to housing with grease holes aligned vertically and identification 'PAINT DOT' at Top Dead Centre. Refer to Fig. 6. Drift bushes (2) into housing using hammer with soft packing for protection.

3. Install plug (25) in filler/level hole on pivot assembly (1). Install gasket (5) and cover plate (6) on side of oscillation hub and secure with bolts (7) and washers (20).

4. Install plug (25) in cavity drain port on underside of oscillation hub.

5. Install plugs (28) into oscillation bearing grease ports.

6. Lightly coat 'V' ring (10) and machined surfaces of pivot with Extreme Pressure Multipurpose Grease (26) and, install 'V' ring (10), with lip towards rear, on front of oscillation hub.

7. Using suitable lifting equipment, and taking care to prevent damaging bushes (2) or pivot threads, install pivot assembly (1) into rear frame.

8. Lightly coat 'V' ring (10) and machined surfaces of pivot with Extreme Pressure Multipurpose Grease (26) and, install 'V' ring (10), with lip towards front, on rear of oscillation hub.

9. a) Restrain pivot assembly (1) to prevent it oscillating, by placing a heavy bar between the steering cylinder mountings. Lock the bar in position using suitable trestles or stands. See Fig. 5.

b) Secure a suitable tool to pivot thrust nut (11) and tighten thrust nut (11) until there is no end float/clearance at thrust face of either bush. Slacken thrust nut (11) until pin of the locking plate (12) can be inserted in the first available hole in the thrust nut (11).

c) Secure locking plate (12) with bolts (22) and lockwashers (21). Torque tighten bolts (22) to 94 Nm (69 lbf ft).

10. Install adaptor (57), connector (58), elbow (59) and pipe assembly (60) to oscillation hub.

11. Install brake yoke (18) on driveshaft (14) until it butts against bearing assembly cup and cone (8 & 9).

12. Install parking brake disc on brake yoke (18) and secure with bolts, washers and nuts. Tighten bolts to a torque of 73 Nm (54 lbf ft).

13. Install rear of driveshaft (14).

14. install Brake yoke (18) , Rear thrust collar (63) ensuring 'O'-rings (29& 51) are in place , shim pack (64) and bolts (19).

15. Lock off Brake yoke flange as before (18) with suitable clamping method. Torque bolts (19) to 73 Nm (lbf ft)

16. Take a magnetic clock gauge located on the flange of pivot casing, needle acting on Rear thrust collar (63) end face. Check Brake yoke (18) float movement. Ensure still within range 0.05mm - 0.15mm (0.002" - 0.006").

17. If float is incorrect, alter arrangement of shim pack (64) to bring within size.

18. Using special mandrel (15270104) home locking plate (16) onto bolts (19). Remove clamping bar.

## Connecting Front and Rear Frames

1. Install spacer (39) in upper bearing assembly (30) as noted on removal.

2. Smear bearing assembly (30) and pin bores with Extreme Pressure Lithium Complex No. 2 grease (23).

3. Attach suitable lifting equipment to pivot/rear frame assembly. Lifting equipment must prevent pivot from oscillating and be capable of pulling pivot/rear frame assembly to align pivot bearing bores and front frame pin bores. Raise lifting equipment to support pivot/rear frame assembly.

4. Remove blocks from rear wheels and blocking from pivot/rear frame assembly. Using lifting equipment, pull pivot/rear frame assembly to align pivot bearing bores and front frame pin bores. Block wheels and block pivot/rear frame assembly to remain level and stationary.

5. Freeze upper and lower pins (40 & 43) to ease installation.

**Note:** It may be necessary to relieve binding between the pin and pin bores by raising or lowering pivot/rear frame assembly.

6. Smear lower pin (43) with Extreme Pressure Lithium Complex No. 2 grease (23) and install through front frame and bearing bores.

7. Apply Loctite 243 (49) to threads of bolt (48). Secure lower pin (43) with bolt (48) and hardened washer (44). Tighten bolt (48) to a torque of 73 Nm (54 lbf ft).

8. Smear upper pin (40) with Extreme Pressure Lithium Complex No. 2 grease (23) and install through front frame and bearing bores.

9. Apply Loctite 243 (49) to threads of bolt (62). Secure upper pin (40) with bolt (62), washer (61), washer (41) and large nut (42). Tighten nut (42) to a torque of 1 425 Nm (1 050 lbf ft).

## Final Assembly

1. Install parking brake assembly to mounting brackets and secure with bolts, washers and nuts. Refer to Section 170-0010, PARKING BRAKE AND MOUNTING.

2. Apply parking brake by turning the hex-head on the parking brake actuator fully clockwise.



### WARNING

Tensioned spring on adjuster.

3. Remove lifting equipment from pivot/rear frame assembly.

4. Remove stands or timbers from front frame.

5. Apply Loctite 270 to threads of capscrews used to mount driveline between transmission yoke and front yoke (17). Align match marks and install driveline. Tighten capscrews to a torque of 153 Nm (113 lbf ft).

6. Align match marks and reconnect driveline to brake yoke (18). Tighten capscrews to a torque of 153 Nm (113 lbf ft).

**Note:** Take extra care when handling drivelines as chips, dents, burrs or deformity on any rotating mass creates vibration and excessive wear during any operation.

7. Align steering cylinder bores and mounting pin bores on pivot. Install pins and secure with bolts and washers. Tighten bolts to a torque of 73 Nm (54 lbf ft).

8. Connect hydraulic lines and electrical wiring as noted on disassembly.

9. Remove bolts (7), washers (20), gasket (5) and cover plate (6) from side of oscillation hub to gain access to filler/level plug (25) on pivot assembly (1). Remove filler/level plug (25).

# Chassis - Articulation and Oscillation Pivot

Section 100-0020

10. Add SAE 80W - 90 E. P. gear oil (24) through filler/level hole in pivot assembly (1) until the oil is level with the bottom of filler/level hole.

11. Remove plug (25) from underside of oscillation hub to drain the cavity between the oscillation hub and pivot assembly (1) of any oil that entered while filling the driveshaft bearing housing.

12. Install plug (25) in filler/level hole on pivot assembly (1). Install gasket (5) and cover plate (6) on side of oscillation hub, secure with bolts (7) and washers (20).

13. Install plug (25) in cavity drain port on underside of oscillation hub.

14. Remove plugs (28) from articulation bearing grease ports and replace with lube fittings (27).

**Note:** Lube fittings (27) are stored on pad on side of pivot assembly (1).

15. Fill bearing housings with Extreme Pressure Lithium Complex No. 2 grease (23) through lube fittings (27) until excess grease starts to escape from seal housings (32 & 34).

16. Remove lube fittings (27) and reinstall plugs (28). Store grease fittings (27) on pad on side of pivot assembly (1).

17. Add Extreme Pressure Multipurpose grease (26) to oscillation bushing lube fittings (55) on top of oscillation hub. Lube until excess grease is seen.

18. Install parking brake disc protective guard (if fitted) and secure with bolts, washers and nuts. Tighten nuts to a torque of 73 Nm (54 lbf ft).

19. Start engine to charge hydraulic systems, raise body, lower body safety prop and lower the body.

20. Bleed the braking system as described in Section 165-0010, BRAKE PARTS.

21. Remove wheel blocks.

## MAINTENANCE

Numbers in parentheses refer to Fig. 1.

Every 250 hours, oscillation bushes must be lubricated. Add Extreme Pressure Multipurpose grease

(26) to oscillation bushing lube fittings (55) on top of oscillation hub. Lube until excess grease is seen.



### WARNING

**To prevent personal injury and property damage, be sure wheel blocks are properly secured and of adequate capacity to do the job safely.**

Every 250 hours, check the end float/clearance at the thrust face of the oscillation bushes. Any clearance found must be removed by adjustment of the thrust nut, as described in step 9 of 'Assembly' procedure.

**Note:** A practical method of establishing the effective adjustment of the thrust nut is to use movement of the machine's body in the raised position. Move the body from fully raised to almost fully raised while watching the effect of this action on the frame and pivot arrangement. Any slackness between the thrust nut and thrust faces will be clearly visible movement of the frame.

Every 1 000 hours (6 months), follow the procedure given below to check the oil level in the driveshaft bearing housing, and, lubricate the articulation and oscillation bearings.

**Note:** It is essential that the grease used for articulation components is Extreme Pressure Lithium Complex No. 2 grease (23), as specified in Section 300-0020, LUBRICATION SYSTEM.

1. Position the vehicle on a level work area and apply parking brake.

2. Raise body and install body safety prop to secure body in partially raised position.

3. Shut down engine and block all wheels securely.

4. Remove protective guard (if fitted) from beneath parking brake disc by removing nuts, washers and bolts securing guard to rear frame.

5. Remove bolts (7), washers (20), gasket (5) and cover plate (6) from side of oscillation hub to gain access to filler/level plug (25) on pivot assembly (1). Remove filler/level plug (25).

6. Add SAE 80W - 90 E. P. gear oil (24) through filler/level hole in pivot assembly (1) until the oil is level with the bottom of filler/level hole.

7. Remove plug (25) from underside of oscillation hub to drain the cavity between the oscillation hub and pivot assembly (1) of any oil that entered while filling the driveshaft bearing housing.
  8. Install plug (25) into filler/level hole on pivot assembly (1). Install gasket (5) and cover plate (6) on side of oscillation hub, secure with bolts (7) and washers (20).
  9. Install plug (25) into cavity drain port on underside of oscillation hub.
  10. Remove plugs (28) from articulation bearing grease ports and replace with lube fittings (27).
- Note:** Lube fittings (27) are stored on pad on side of pivot assembly (1).
11. Fill bearing housings with Extreme Pressure Lithium Complex No. 2 grease (23) through lube fittings (27) until excess grease starts to escape from seal housings (32 & 34).
  12. Remove lube fittings (27) and reinstall plugs (28). Store grease fittings (27) on pad on side of pivot assembly (1).
  13. Add Extreme Pressure Multipurpose grease (26) to oscillation bushing lube fittings (55) on top of oscillation hub. Lube until excess grease is seen.
  14. Install parking brake disc protective guard (if fitted) and secure with bolts, washers and nuts. Torque tighten nuts to 73 Nm (54 lbf ft).
  15. Start engine, raise body, lower body safety prop and lower body.
  16. Remove wheel blocks.

## SPECIAL TOOLS


Refer to Section 300-0070, SERVICE TOOLS, for part numbers of the thrust nut tool and general service tools and adhesives required for procedures outlined in this section. These tools and adhesives are available from your dealer.

# Chassis - Articulation and Oscillation Pivot

Section 100-0020

SPECIAL TORQUE SPECIFICATIONS				
FIG. No.	ITEM No.	ITEM NAME	TORQUE	
			Nm	lbf ft
1	19	Nut (to seat bearing only)	250	180
1	22	Bolt	94	69
1	42	Nut	1 425	1 050
1	46 & 47	Bolt	94	68
1	48	Bolt	73	54
-	-	Parking Brake Disc Bolts	73	54
-	-	Parking Brake Brkt Mounting Nuts	680	490
-	-	Driveline Mounting Capscrews	153	113
-	-	Protective Guard Mounting Nuts	73	54
-	-	Steering Cylinder Pin Bolts	73	54

\* \* \* \*



## HOOD

### Removal

Numbers in parentheses refer to Fig. 1.



#### WARNING

**To prevent personal injury and property damage, be sure blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.**

1. Position the machine on a level surface, apply the parking brake and switch off the engine.

2. Block all road wheels and place the battery master switch in the 'Off' position.

3. Remove bolts, washers, lockwashers and nuts securing grille (27) to grille subframe. Secure grille (27) clear of hood (1).

4. Pull cable assembly (16), handle inside battery box, to release hood catch and lift up hood (1). Secure hood (1) in raised position using suitable lifting equipment.

5. Carefully remove bolts, washers and nuts securing hood retaining straps (14) and gas struts (15).

Remove fasteners, hood retaining straps (14) and gas struts (15) from hood (1).

6. Remove bolts (39), washers (13) and nuts (17) securing hinge assemblies (2) to frame. Carefully lift hood (1) assembly from the machine.

7. If required, remove mounting hardware securing grille subframe to hood (1). Secure grille subframe clear of hood (1).

8. If required, remove bolts (10) and washers (11) securing handles (9) to hood (1). Secure handles (9) clear of hood (1).

## Installation

Numbers in parentheses refer to Fig. 1.

**Note:** Tighten all fasteners to torques listed in Section 300-0080, STANDARD BOLT AND NUT TORQUE SPECIFICATIONS.



### WARNING

To prevent personal injury and property damage, be sure blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.

1. If removed, secure handles (9) to hood (1) using bolts (10) and washers (11).

2. If removed, secure grille subframe to hood (1) using mounting hardware as removed at 'Removal'.

3. Using suitable lifting equipment, lift and position hood (1) on the machine and align holes in hinge assemblies (2) with mounting holes on frame. Secure hood (1) using bolts (39), washers (13) and nuts (17).

4. Carefully install hood straps (14) and gas struts (15) using mounting hardware as removed at 'Removal'.

5. With lifting equipment still in place, lower hood (1) to match with goalpost support assembly (18). Remove lifting equipment.

6. If required, adjust fitment of hood (1) to frame at hinge assemblies (2) and adjustment rod (6).

7. Install grille (27) to hood (1) and secure using bolts, washers, lockwashers and nuts.

8. Remove wheel blocks.

## GOALPOST SUPPORT ASSEMBLY

### Removal

Numbers in parentheses refer to Fig. 1.



### WARNING

To prevent personal injury and property damage, be sure blocking materials and lifting equipment are properly secured and of adequate capacity to do the job safely.

1. Position the machine on a level surface, apply the parking brake and switch off the engine.

2. Block all road wheels and place the battery master switch in the off position.

3. Pull cable assembly (16), handle inside battery box, to release hood catch and lift up hood (1). Secure hood (1) in raised position.

4. Remove mounting hardware securing washer bottle to mounting bracket on the left hand side of goalpost support assembly (18). Secure washer bottle clear of goalpost support assembly (18).

5. Remove plate and mounting hardware securing transmission oil cooler to goalpost support assembly (18). If required, disconnect transmission oil cooler hoses.

6. Remove mounting hardware securing air cleaner intake tube to goalpost support assembly (18).

7. With a suitable container available to catch leakage, remove drain plug from radiator header tank and drain coolant. Apply Loctite 225 to drain plug and reinstall in header tank.

8. Ensure all cooling lines connected to header tank are identified for ease of installation and with suitable containers available to catch leakage, disconnect cooling lines. Fit blanking caps to all open lines.

9. Disconnect electrical harness from coolant level sensor in header tank. Note routing of all hoses and harnesses attached to and through goalpost support assembly (18) and disconnect.

10. Disconnect hood cable (16) ball joint from cam plate assembly (33) and secure cable (16) clear of hood catch mechanism.

11. Check to make certain that all necessary line and