

TECHNICAL MANUAL

**OPERATOR' S, UNIT, INTERMEDIATE
(DS) AND INTERMEDIATE (GS)
MAINTENANCE MANUAL**

FOR

**ENGINE, DIESEL,
CATERPILLAR, MODEL 3508
NSN 2815-01-216-0938**

HEADQUARTERS, DEPARTMENT OF THE ARMY

25 JULY 1986



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of this product. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for a untrained mechanic and there is no way to label the product against all such hazards. These warnings in the Service Manual and on the product are identified by this symbol:



Operations that may result only in mechanical damage are identified by labels on the product and in the Service Manual by the word CAUTION or NOTICE.

Caterpillar can not anticipate every possible circumstance that might involve a potential hazard. The warnings in this Manual are therefore not all inclusive. If a procedure, tool device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torque, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can affect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REG1139F.

WARNING

SAFETY

WARNING

Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the lubrication and maintenance procedures, recommended by Caterpillar, that are outlined in the OPERATION GUIDE and/or OWNER'S MANUAL for this product before performing any lubrication or maintenance.

Do not operate this product unless you have read and understood the instructions. Improper operation is dangerous and could result in injury or death.

The servicemen or mechanic may be unfamiliar with many of the components and systems of this product. This makes it important to use caution when performing service work. A knowledge of the system and/or components is important before the removal or disassembly of any component.

Because of the size of some components, the serviceman or mechanic should check the weights noted in this Manual. Use proper lifting procedures when removing any components.

Following is a list of basic precautions that should always be observed.

1. Read and understand all Warning plates and decals before operating, lubricating or repairing this product.
2. Make sure the work area around the product is made safe and be aware of hazardous conditions that may exist.
3. Always wear protective glasses and protective shoes when working. In particular, wear protective glasses when a hammer or sledge is used for pounding to make repairs. Use welders gloves, hood/goggles, apron and other protective clothing appropriate to the welding job being performed. Do not wear loose-fitting or torn clothing. Remove all rings from fingers when working on machinery.

4. If an engine must be started to make pressure or speed checks, be sure all guards and shields are installed. To help prevent an accident caused by parts in rotation, work carefully around machinery that has been put into operation.
5. If an engine has been running and the coolant is hot, loosen the filler cap slowly and let the pressure out of the cooling system, before any caps, plugs or lines are removed or disconnected.
6. Corrosion inhibitor contains alkali. Avoid contact with eyes. Avoid prolonged or repeated contact with skin. Do not take internally. In case of contact, immediately wash skin with soap and water. For eyes, flush with large amounts of water for at least 15 minutes. **CALL PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
7. Do not smoke when an inspection of the battery electrolyte level is made. Never disconnect any charging unit circuit or battery circuit cable from the battery when the charging unit is operating. A spark can cause an explosion from the flammable vapor mixture of hydrogen and oxygen that is released from the electrolyte through the battery outlets. Do not let electrolyte solution make contact with skin or eyes. Electrolyte solution is an acid. In case of contact, immediately wash skin with soap and water. For eyes, flush with large amounts of water for at least 15 minutes. **CALL PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
8. Disconnect battery and discharge any capacitors before starting any repair work. Hang "Do Not Operate" tag in the Operator's compartment or on the controls.
9. Do not work on anything that is supported only by lift jacks or a hoist. Always use blocks or proper stands to support the product before performing any service work.
10. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do not check for pressure leaks with your hand. High pressure oil or fuel can pierce the skin.

 **WARNING**

11. Never bend a fuel injection line, or install a line which has been bent. Keep the fuel injection lines and connections clean. Be sure to install caps and covers anytime a line is removed or disconnected.
12. During service work, do not hit the fuel injection lines with wrenches or other tools. When lines are installed, use the correct torque to tighten connections and be sure all clamps and dampers are correctly installed.
13. Make sure all fuel injection lines and pressure oil lines have enough clearance to prevent contact with any other component. Do not put any fuel or oil lines close to a hot component.
14. To avoid back injury use a hoist or get help when lifting components which weigh 50 lb. (23 kg) or more. Make sure all chains, hooks, slings, etc., are in good condition and are of the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
15. To avoid burns, be alert for hot parts on products which have just been stopped and hot fluids in lines, tubes and compartments.
16. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and pry cover loose to relieve any spring or other pressure, before removing them completely.
17. Be careful when removing filler caps, breathers and plugs on the product. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the product has recently been stopped because fluids can be hot.
18. Always use tools that are in good condition and be sure you understand how to use them before performing any service work. Use only Caterpillar replacement parts.
19. Reinstall all fasteners with same part number. Do not use a lesser quality fastener if replacements are necessary.
20. Repairs which require welding should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Make reference to "Techniques of Structural Repair Course" form number JEG03719. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of parent metal.
21. Before doing electrical work, disconnect battery. Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will it be damaged in operation by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing fluid.
22. Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution. After the repair is completed, reinstall any guard or shield that was removed.

A83266X2



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of this product. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for a untrained mechanic and there is no way to label the product against all such hazards. These warnings in the Service Manual and on the product are identified by this symbol:



Operations that may result only in mechanical damage are identified by labels on the product and in the Service Manual by the word **NOTICE**.

Caterpillar can not anticipate every possible circumstance that might involve a potential hazard. The warnings in this Manual are therefore not all inclusive. If a procedure, tool device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torque, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can affect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REGI 139F.

A83264X2



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of this product. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for a untrained mechanic and there is no way to label the product against all such hazards. These warnings in the Service Manual and on the product are identified by this symbol:



Operations that may result only in mechanical damage are identified by labels on the product and in the Service Manual by the word **NOTICE**.

Caterpillar can not anticipate every possible circumstance that might involve a potential hazard. The warnings in this Manual are therefore not all inclusive. If a procedure, tool device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torque, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can affect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REG1 139F.

A83264 X2



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of this product. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for a untrained mechanic and there is no way to label the product against all such hazards. These warnings in the Service Manual and on the product are identified by this symbol:



Operations that may result only in mechanical damage are identified by labels on the product and in the Service Manual by the word **NOTICE**.

Caterpillar can not anticipate every possible circumstance that might involve a potential hazard. The warnings in this Manual are therefore not all inclusive. If a procedure, tool device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torque, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can affect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REGI 139F.

A83264 X2



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of a machine. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS ON THIS MACHINE

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on the machine to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for an untrained mechanic and there is no way to label the machine against all such hazards. These warnings in the Service Manual and on the machine are identified by this symbol:



Operations that may result only in machine damage are identified by labels on the machine and in the Service Manual by the word **NOTICE**.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings, in this Manual are therefore not all inclusive. If a procedure, tool, device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the machine will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torques, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can effect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information which is available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REG1 139F.

67200-1 X1



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of a machine. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS ON THIS MACHINE

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on the machine to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for an untrained mechanic and there is no way to label the machine against all such hazards. These warnings in the Service Manual and on the machine are identified by this symbol:



Operations that may result only in machine damage are identified by labels on the machine and in the Service Manual by the word **NOTICE**.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings, in this Manual are therefore not all inclusive. If a procedure, tool, device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the machine will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torques, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can effect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information which is available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REG1139F.

67200-1 X1

 **WARNING**
SAFETY
 **WARNING**

Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the lubrication and maintenance procedures, recommended by Caterpillar, that are outlined in the OPERATION GUIDE and/or OWNER'S MANUAL for this product before performing any lubrication or maintenance.

Do not operate this product unless you have read and understood the instructions. Improper operation is dangerous and could result in injury or death.

The servicemen or mechanic may be unfamiliar with many of the components and systems of this product. This makes it important to use caution when performing service work. A knowledge of the system and/or components is important before the removal or disassembly of any component.

Because of the size of some components, the serviceman or mechanic should check the weights noted in this Manual. Use proper lifting procedures when removing any components.

Following is a list of basic precautions that should always be observed.

1. Read and understand all Warning plates and decals before operating, lubricating or repairing this product.
2. Make sure the work area around the product is made safe and be aware of hazardous conditions that may exist.
3. Always wear protective glasses and protective shoes when working. In particular, wear protective glasses when a hammer or sledge is used for pounding to make repairs. Use welders gloves, hood/goggles, apron and other protective clothing appropriate to the welding job being performed. Do not wear loose-fitting or torn clothing. Remove all rings from fingers when working on machinery.
4. If an engine must be started to make pressure or speed checks, be sure all guards and shields are installed. To help prevent an accident caused by parts in rotation, work carefully around

machinery that has been put into operation.

5. If an engine has been running and the coolant is hot, loosen the filler cap slowly and let the pressure out of the cooling system, before any caps, plugs or lines are removed or disconnected.
6. Corrosion inhibitor contains alkali. Avoid contact with eyes. Avoid prolonged or repeated contact with skin. Do not take internally. In case of contact, immediately wash skin with soap and water. For eyes, flush with large amounts of water for at least 15 minutes. **CALL PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
7. Do not smoke when an inspection of the battery electrolyte level is made. Never disconnect any charging unit circuit or battery circuit cable from the battery when the charging unit is operating. A spark can cause an explosion from the flammable vapor mixture of hydrogen and oxygen that is released from the electrolyte through the battery outlets. Do not let electrolyte solution make contact with skin or eyes. Electrolyte solution is an acid. In case of contact, immediately wash skin with soap and water. For eyes, flush with large amounts of water for at least 15 minutes. **CALL PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
8. Disconnect battery and discharge any capacitors before starting any repair work. Hang "Do Not Operate" tag in the Operator's compartment or on the controls.
9. Do not work on anything that is supported only by lift jacks or a hoist. Always use blocks or proper stands to support the product before performing any service work.
10. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do not check for pressure leaks with your hand. High pressure oil or fuel can pierce the skin.

 **WARNING**

11. Never bend a fuel injection line, or install a line which has been bent. Keep the fuel injection lines and connections clean. Be sure to install caps and covers anytime a line is removed or disconnected.
12. During service work, do not hit the fuel injection lines with wrenches or other tools. When lines are installed, use the correct torque to tighten connections and be sure all clamps and dampers are correctly installed.
13. Make sure all fuel injection lines and pressure oil lines have enough clearance to prevent contact with any other component. Do not put any fuel or oil lines close to a hot component.
14. To avoid back injury use a hoist or get help when lifting components which weigh 50 lb. (23 kg) or more. Make sure all chains, hooks, slings, etc., are in good condition and are of the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
15. To avoid burns, be alert for hot parts on products which have just been stopped and hot fluids in lines, tubes and compartments.
16. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and pry cover loose to relieve any spring or other pressure, before removing them completely.
17. Be careful when removing filler caps, breathers and plugs on the product. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the product has recently been stopped because fluids can be hot.
18. Always use tools that are in good condition and be sure you understand how to use them before performing any service work. Use only Caterpillar, replacement parts.
19. Reinstall all fasteners with same part number. Do not use a lesser quality fastener if replacements are necessary.
20. Repairs which require welding should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Make reference to "Techniques of Structural Repair Course" form number JEG03719. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of parent metal.
21. Before doing electrical work, disconnect battery. Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will it be damaged in operation by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing, fluid.
22. Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution. After the repair is completed, reinstall any guard or shield that was removed.

A83266X2



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of this product. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for a untrained mechanic and there is no way to label the product against all such hazards. These warnings in the Service Manual and on the product are identified by this symbol:



Operations that may result only in mechanical damage are identified by labels on the product and in the Service Manual by the word **NOTICE**.

Caterpillar can not anticipate every possible circumstance that might involve a potential hazard. The warnings in this Manual are therefore not all inclusive. If a procedure, tool device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torque, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can affect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REG1 139F.



IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of this product. This Service Manual outlines basic recommended procedures, some of which require special tools, devices or work methods. Although not necessarily all inclusive, a list of additional skills, precautions and knowledge required to safely perform repairs is provided in the SAFETY section of this Manual.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS

Basic safety precautions, skills and knowledge are listed in the SAFETY section of this Manual and in the descriptions of operations where hazards exist. Warning labels have also been put on to provide instructions and identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards during repair for a untrained mechanic and there is no way to label the product against all such hazards. These warnings in the Service Manual and on the product are identified by this symbol:



Operations that may result only in mechanical damage are identified by labels on the product and in the Service Manual by the word **NOTICE**.

Caterpillar can not anticipate every possible circumstance that might involve a potential hazard. The warnings in this Manual are therefore not all inclusive. If a procedure, tool device or work method not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the procedures you choose.

IMPORTANT

The information, specifications and illustrations in this book are on the basis of information available at the time it was written. The specifications, torque, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can affect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REG 139F.

A83264 X2

IMPORTANT SAFETY INFORMATION

Most accidents involving engine operation and maintenance are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs.

Read and understand all safety precautions and warnings before operating or performing lubrication and maintenance on this engine.

Basic safety precautions are outlined in the "Safety" section of this guide and in the description of operations where hazards exist. WARNING labels have also been put on the engine to provide instructions and to identify specific hazards which if not heeded could cause bodily injury or death to you or other persons. These warnings in the guide and on the engine labels are identified by the symbol



Operations that may cause only engine damage are identified by NOTICE labels on the engine and in the guide.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this guide and on the engine are therefore not all inclusive. If a procedure, tool or work method or operating technique not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the engine will not be damaged or made unsafe by the method of operation or maintenance procedures you choose.



Improper operation, lubrication or maintenance of this engine can be dangerous and could result in injury or death.

Do not operate this engine until you read and understand the instructions in the "Operation" section of the Operation and Maintenance Guide or the Owner's Manual.

Do not perform any lubrication and maintenance on this engine until you read and understand the instructions in the "Maintenance" section of the Operation and Maintenance Guide or the Owner's Manual.

Table of Contents

WHERE TITLE SHOWS DELETED TEXT DOES NOT PERTAIN TO THE 3508 ENGINE.

	Page		Page
Specifications for Engine Attachments, 3500 Industrial	1	Cooling System	
General Tightening Torque for Bolts, Nuts, and Taperlock Studs	3	Water Pump	31
Torque for Flared and O-Ring Fittings 4		Aftercooler	32
Engine Design	5	Water Connection Group - Outlet	32
Fuel System		Water Temperature Regulators	33
Fuel Injection	8	V-Belt Tension Chart.....	33
Fuel Pressure Regulator (Earlier).....	8	Basic Engine Components	
Fuel Pressure Regulator (Later).....	9	Cylinder Block	34
Manual Shutoff Group	9	Cylinder Liners	35
Fuel Injection Control Group	10	Cylinder Liner Projection.....	35
Governor Fastener Group	11	Pistons and Rings	36
Governor Drive	11	Connecting Rods	37
Air Induction and Exhaust System		Connecting Rod and Main Bearing Journals	38
Camshafts	12	Crankshaft	39
Valves	14	Crankshaft Wear Sleeves and Seals	40
Valve Covers	15	Front Balancer Group (3508)	41
Valve Rocker Arms, Lifters and Bridges	15	Lower Front Gear Group	42
Cylinder Heads.....	16	Upper Front Gear Group (7N4871).....	44
Turbocharger Impeller Installation.....	17	Rear Gear Group	45
Turbochargers	18	Flywheel	47
Exhaust Manifolds	22	Flywheel Runout	48
Air Intake Shutoff.....	23	Flywheel Housing.....	50
Lubrication System		Flywheel Housing Bore	52
Oil Pump	26	Flywheel Housing Runout.....	53
Oil Filter Bypass Valve (Earlier).....	28	Alternators and Regulators	Deleted
Oil Filter Bypass Valve (Later).....	29	Electrical System	
Oil Cooler Bypass and Cooling Jet Sequence Valves.....	30	Electric Starter Motors	Deleted
		Starter Solenoids	Deleted

Table of Contents (Continued)

	Page		Page
Air Starter Motors	Deleted	Troubleshooting	91
Pressure Regulating Valve for Air Starter Motor	Deleted	Fuel System	107
Systems Operation, 3500 Industrial Engines	61	Fuel System Inspection.....	107
Engine Design	63	Checking Engine Cylinders Separately.....	107
Fuel System	65	Fuel Injector Testing	107
Fuel Injection Control Linkage.....	67	Injector Tester Preparation	108
Fuel Injector.....	68	Operation of the Tester.....	108
Woodward UG8 Lever Governors	71	Leak Test for Injector Tester.....	109
Air Fuel Ratio Control.....	73	Injector Test Sequence	110
Air Inlet and Exhaust System	75	Fuel Pressure	116
Aftercooler	77	Engine Rotation	117
Turbochargers.....	78	Finding Top Center Position for No. 1 Piston	117
Valve System Components	78	Camshaft Timing.....	118
Lubrication System	80	Startup Procedure.....	120
Cooling System	82	Crankshaft Positions for Fuel Timing.....	121
Basic Block	84	Fuel Timing	122
Cylinder Block, Liners and Heads	84	Injector Synchronization.....	123
Pistons, Rings and Connecting Rods..	84	Fuel Setting	125
Crankshaft	84	Fuel Setting Adjustment.....	126
Camshafts	85	Engine Speed Measurement	127
Air Starting System	86	Woodward UG8 Lever Governor	128
Electrical System.....	88	Compensating Adjustment.....	128
Alternator	88	Low and High Idle Speed Adjustment.....	129
Starter Motor	88	Speed Droop Adjustment.....	129
Starter Solenoid.....	89	Air Fuel Ratio Control	132
Circuit Breaker.....	89	Air Inlet and Exhaust System.....	133
Contactor Switch (Water Temperature)	90	Restriction of Air Inlet and Exhaust.....	133
Testing and Adjusting	91	Measurement of Pressure in Inlet Manifold	133

Table of Contents (Continued)

	Page		Page
Exhaust Temperature.....	134	Projection of Cylinder Liners.....	145
Crankcase (Crankshaft Compartment)		Flywheel and Flywheel Housing.....	146
Pressure	134	Checking Crankshaft Deflection (Bend)....	148
Compression	134	Vibration Damper	149
Cylinder Heads.....	134	Electrical System	150
Valves	134	Test Tools for Electrical System	150
Bridge Adjustment.....	135	Battery	151
Crankshaft Positions for Valve		Charging System	151
Clearance Setting	136	Starting System.....	152
Valve Clearance.....	137	Air Starting System	Deleted
Lubrication System	139	Caterpillar, 3161 Governor.....	155
Too Much Oil Consumption.....	139	Governor Types	157
Measuring Engine Oil Pressure.....	139	Basic Governor	159
Oil Pressure is Low	140	Governor Components	159
Oil Pressure is High.....	140	Operation of the 3161 Governor	161
Too Much Bearing Wear	140	Auxiliary Controls	164
Increased Oil Temperature	140	Manual Shutdown	164
Cooling System	141	Pressure Shutdown.....	164
Visual Inspection of the Cooling System..	141	Electric Shutdown	164
Testing the Cooling System	141	Manual Mechanical Speed Control	164
Test Tools for Cooling System	141	Pneumatic Speed Control	165
Pressure Cap Test	142	Air Fuel Ratio Control.....	167
Radiator and Cooling System Leak Tests	143	Speed Adjusting Motor Governor Head....	169
Water Temperature Gauge Test	143	Manual Speed Setting Control	169
Water Temperature Regulator Test	144	Pneumatic Mid Speed Control	170
Basic Block	145	Troubleshooting	172
Connecting Rod Bearings	145	Governor Troubleshooting	172
Main Bearings	145	Air Fuel Ratio Control Troubleshooting.....	176
Cylinder Block	145		

Table of Contents (Continued)

	Page		Page
Pneumatic Speed Setting		System Checks	243
Control Troubleshooting	178	System Tests	245
Testing and Adjusting	180	Shutoff Speed Setting Adjustment	245
Governor Oil Pump	180	Wiring Diagrams	247
Governor Preparation	181		
Governor Installation	182	3500 Industrial Engines	253
Governor Adjustments	187	Disassembly and Assembly	
Auxiliary Controls	192	Manual Shutoff	257
Hydramechanical Protective System, 3500 Series Engines	197	Gauge Panel	259
Specifications		Air Intake Shutoff	262
Shutoff Control Group	199	Tachometer Drive	269
Thermostatic Pilot Valve	202	Crankcase Breather	270
Accessory (Shutoff) Drive Group	202	Water Temperature Regulators	272
Air Intake Shutoff	206	Water Pump	275
Tachometer and Service Meter Drive	209	Fuel Filter Housing	279
Remote Shutoff Valve Group	209	Fuel Priming Pump, Fuel Transfer Pump ..	283
Electrical Switches	210	Oil Pump	288
Systems Operation		Oil Filter Housing	293
Overspeed	211	Oil Pan	300
Low Engine Oil Pressure	211	Oil Sequence Valves	304
High Coolant Temperature	211	Oil Cooler	305
System Components	211	Turbochargers	312
System Hydraulics	214	Exhaust Manifolds	321
Hydraulic Circuits (Earlier)	214	Aftercooler	322
Hydraulic Circuits (Later)	228	Governor	326
Hydraulic Circuits, Later with an Alarm System	232	Governor Drive	328
Testing and Adjusting		Hydramechanical Shutoff Control	332
Troubleshooting	239	Hydramechanical Shutoff Drive	345
		Accessory Drive (Front)	347

Table of Contents (Continued)

	Page		Page
Oil and Water Pump Drive	350	Oil Pans	421
Crankshaft Vibration Damper	353	Oil Filter Bypass Valve	422
Crankshaft Front Seal and Wear Sleeve .	354	Duplex Oil Filter	423
Crankshaft Rear Seal and Wear Sleeve ..	356	Oil Scavenge Pump	424
Front Drive Housing	358	Exhaust Manifolds	426
Flywheel	362	Turbochargers	427
Flywheel Housing	363	Air Intake Shutoff	436
Valve Covers	365	Front Gear Groups	437
Rocker Shafts and Push Rods	366	Auxiliary Drive	440
Fuel Injectors.....	369	Tachometer Drive	441
Fuel Injection Control Linkage	371	Trunnion (Front)	443
Cylinder Heads.....	377	Engine Front Support Group (Wide)	443
Valves	381	Vibration Damper Group	444
Bridge Dowels	382	Front Mounting Group	447
Connecting Rod Bearings	384	Stub Shafts	447
Front Balancer Group.....	385	Time Delay Relay	449
Rear Gear Group	387	Heaters, Jacket Water	449
Spacer Plates	391	Magnetic Pickup	449
Crankshaft Main Bearings.....	393	Tachometer, Digital	450
Pistons	396	Contactors	451
Cylinder Liners	398	Pressure Switches	452
Camshafts	400	Temperature Switches	453
Crankshaft	407	Sending Units, Oil Pressure	454
Specifications for Engine Attachments 49Y1-UP, 95Y1-UP, 27Z1-UP, 65Z1-UP, 68Z1-UP, 71Z1-UP	411	Tachometer, Electric	454
Ether Starting Aid	416	Gauges, Ammeter/Oil Pressure/ Water Temperature	455
Primary Fuel Filter	416	Air Shutoff Solenoids	456
Fuel Filter Change Indicator Group	416	Air Compressor Group	457
Governor	417	Air Control Valve Group	458


Table of Contents (Continued)

	Page		Page
Electric Protective System for Engines Equipped with Reversal Protection	459	Step Oil Pressure, Chart C	492
Components	460	Reversal Detection, Chart D	494
Individual Circuit Description	462	Troubleshooting Procedures	496
Engine Stopped	462	Overspeed Setting Calibration,	
Starting Engine	Deleted	Procedure A	496
Engine Starts to Run: No Faults	Deleted	Crank Terminate, Speed Adjustment,	
Engine Runs at Rated Speed:		Procedure B	497
No Faults	Deleted	Oil Step Calibration, Procedure C	498
Pressure (At Engine Speeds above Oil Step		Overspeed Verify Test, Procedure D	499
Speed Setting)	Deleted	Reversal Detection, Procedure E	500
Engine Shutdown Due to Fault:		Sensor Assembly Verify, Procedure F	501
Loss of Engine Oil	Deleted	On/Off Time Delay (Relay), Procedure G .	503
Engine Running Below Oil Step		Wiring Diagrams	504
Speed Setting: No Faults (or Just		Electric Protective System Schematic	505
Accelerating through Step Speed)	Deleted	Engine Wiring Diagram	506
Engine Shutdown Due to Fault: Low Oil		Typical Junction Box Wiring Diagram	507
Pressure (At Engine Speeds Below Oil		Customer Wiring with Electric	
Step Speed Setting)	Deleted	Protective System	510
Engine Shutdown Due to Fault:		Electrical Protective System for Generator Set,	
Coolant Overheating	Deleted	Industrial and Marine Engines	513
Engine Shutdown Due to Fault:		Components	514
Engine Overspeed	Deleted	Individual Circuit Description	516
Engine Shutdown Due to Fault:		Engine Stopped	516
Engine Reversal	Deleted	Starting Engine	518
Shutdown System with 2301 Electric		Engine Starts to Run: No Faults	520
Governor Control: No Faults	Deleted	Engine Runs at Rated Speed: No Faults	522
Troubleshooting	484	Engine Shutdown Due to Fault:	
Functional Test	485	Loss of Engine Oil Pressure (At Engine	
System Problem Index	486	Speeds Above Oil Step Speed Setting)	524
System Troubleshooting Charts,		Engine Shutdown Due to Fault: Low Oil	
Preliminary Checks	487	Pressure (At Engine Speeds Below Oil	
Overspeed, Chart A	488	Step Speed Setting)	528
Crank Terminate, Chart B	490		

Table of Contents (Continued)

	Page		Page
Engine Shutdown Due to Fault: Coolant Overheating	530	Operation and Maintenance, 3508 Industrial Engine	
Engine Shutdown Due to Fault: Engine Overspeed	532	Safety	565
Shutdown System with 2301 Electric Governor Control: No Faults	534	Operation Section	568
Electric Protective System Functional Tests	536	Model Views.....	569
Speed Specification Chart	537	Gauges	571
Troubleshooting	538	Shutoff and Alarm System Components...	573
Problem Identification Index	539	Engine Controls	575
System Troubleshooting Charts, Preliminary Checks	540	Before Starting the Engine	578
System Arming, Chart A.....	541	Starting the Engine	579
Overspeed, Chart B.....	542	After Starting the Engine.....	582
Crank Terminate, Chart C	544	Stopping the Engine.....	583
Step Oil Pressure, Chart D.....	546	After Stopping the Engine	584
Troubleshooting Procedures		Lifting Engine and Attachment.....	584
Overspeed Setting Calibration, Procedure A	548	Engine Storage	585
Crank Terminate Speed Adjustment, Procedure B	549	Maintenance Section	586
Oil Step Calibration, Procedure C	550	Serial Number Location	587
Overspeed Verify Test, Procedure D	551	Maintenance Recommendations	587
Magnetic Pickup Verify, Procedure E.....	552	Fuel, Coolant and Lubricant Specifications	590
On/Off Delay (Relay), Procedure F	553	Refill Capacities	592
Wiring Diagrams	554	Engine Specifications.....	592
Electric Protective System Schematic.....	555	Recommended Lubricant Viscosities.....	593
Engine Wiring Diagram	556	Lubrication and Maintenance Chart	594
Typical Junction Box Wiring Diagram	557	When Required	596
Customer Wiring with Electric Protective System	560	Every 10 Service Hours or Daily	597
		Every 50 Service Hours or Weekly	609
		Every 100 Service Hours or 2 Weeks	611
		Every 250 Service Hours or Monthly.....	612
		Every 500 Service Hours or 3 Months	617
		Every 1000 Service Hours or 6 Months	618
		Every 2000 Service Hours or 1 Year.....	624
		Troubleshooting Section	628

FOR USE IN SERVICE MANUALS:
3500 INDUSTRIAL ENGINES,
SEN2573
VOLUME I SPECIFICATIONS,
REGO1312




SPECIFICATIONS

FOR

**3500 INDUSTRIAL
ENGINE ATTACHMENTS**

49Y1-UP	65Z1-UP
95Y1-UP	68Z1-UP
27Z1-UP	71Z1-UP

GENERAL TIGHTENING TORQUE FOR BOLTS, NUTS AND TAPERLOCK STUDS			
THREAD DIAMETER		STANDARD TORQUE	
inches	millimeters	lb. ft.	N·m*
 <p>Standard thread</p>		<p>Use these torques for bolts and nuts with standard threads (conversions are approximate).</p>	
1/4	6.35	9 ± 3	12 ± 4
5/16	7.94	18 ± 5	25 ± 7
3/8	9.53	32 ± 5	45 ± 7
7/16	11.11	50 ± 10	70 ± 15
1/2	12.70	75 ± 10	100 ± 15
9/16	14.29	110 ± 15	150 ± 20
5/8	15.88	150 ± 20	200 ± 25
3/4	19.05	265 ± 35	360 ± 50
7/8	22.23	420 ± 60	570 ± 80
1	25.40	640 ± 80	875 ± 100
1 1/8	28.58	800 ± 100	1100 ± 150
1 1/4	31.75	1000 ± 120	1350 ± 175
1 3/8	34.93	1200 ± 150	1600 ± 200
1 1/2	38.10	1500 ± 200	2000 ± 275
<p>Use these torques for bolts and nuts on hydraulic valve bodies.</p>			
5/16	7.94	13 ± 2	20 ± 3
3/8	9.53	24 ± 2	35 ± 3
7/16	11.11	39 ± 2	50 ± 3
1/2	12.70	60 ± 3	80 ± 4
5/8	15.88	118 ± 4	160 ± 6
 <p>Taperlock stud</p>		<p>Use these torques for studs with Taperlock threads.</p>	
1/4	6.35	5 ± 2	7 ± 3
5/16	7.94	10 ± 3	15 ± 5
3/8	9.53	20 ± 3	30 ± 5
7/16	11.11	30 ± 5	40 ± 10
1/2	12.70	40 ± 5	55 ± 10
9/16	14.29	60 ± 10	80 ± 15
5/8	15.88	75 ± 10	100 ± 15
3/4	19.05	110 ± 15	150 ± 20
7/8	22.23	170 ± 20	230 ± 30
1	25.40	260 ± 30	350 ± 40
1 1/8	28.58	320 ± 30	400 ± 40
1 1/4	31.75	400 ± 40	550 ± 50
1 3/8	34.93	480 ± 40	650 ± 50
1 1/2	38.10	550 ± 50	750 ± 70

*1 newton meter (N·m) is approximately the same as 0.1 mkg.


TORQUE FOR FLARED AND O-RING FITTINGS

The torques shown in the chart that follows are to be used on the part of 37° Flared, 45° Flared and Inverted Flared fittings (when used with steel tubing), O-ring plugs and O-ring fittings.

		INVERTED 45° FLARED					37° FLARED					45° FLARED					O-RING FITTING - PLUG		SWIVEL NUTS							
TUBE SIZE (O.D.)	mm	3.18	4.78	6.35	7.92	9.52	TUBE SIZE (O.D.)	mm	12.70	15.88	19.05	22.22	25.40	31.75	38.10	50.80	mm	12.70	15.88	19.05	22.22	25.40	31.75	38.10	50.80	
	in.	.125	.188	.250	.312	.375		in.	.500	.625	.750	.875	1.000	1.250	1.500	2.000		in.	.500	.625	.750	.875	1.000	1.250	1.500	2.000
THREAD SIZE (in.)		5/16	3/8	7/16	1/2	9/16 5/8	THREAD SIZE (in.)		3/4	7/8	1 1/16	1 3/16 1 1/4	1 5/16	1 5/8	1 7/8	2 1/2	THREAD SIZE (in.)		3/4	7/8	1 1/16	1 3/16 1 1/4	1 5/16	1 5/8	1 7/8	2 1/2
TORQUE N-m		5 ±1	11 ±1	16 ±2	20 ±2	25 ±3	TORQUE N-m		50 ±5	75 ±5	100 ±5	120 ±5	135 ±10	180 ±10	225 ±10	320 ±15	TORQUE N-m		50 ±5	75 ±5	100 ±5	120 ±5	135 ±10	180 ±10	225 ±10	320 ±15
TORQUE lb.in.		45 ±10	100 ±10	145 ±20	175 ±20	225 ±25	TORQUE lb.ft.		35 ± 4	55 ± 4	75 ± 4	90 ± 4	100 ± 7	135 ± 7	165 ± 7	235 ± 10	TORQUE lb.ft.		35 ± 4	55 ± 4	75 ± 4	90 ± 4	100 ± 7	135 ± 7	165 ± 7	235 ± 10

ASSEMBLY OF FITTINGS WITH STRAIGHT THREADS AND O-RING SEALS

- Put locknut (3), backup washer (4) and O-ring seal (5) as far back on fitting body (2) as possible. Hold these components in this position. Turn the fitting into the part it is used on, until backup washer (4) just makes contact with the face of the part it is used on.



ELBOW BODY ASSEMBLY

NOTE: If the fitting is a connector (straight fitting) or plug, the hex on the body takes the place of the locknut. To install this type fitting tighten the hex against the face of the part it goes into.


- To put the fitting assembly in its correct position turn the fitting body (2) out (counterclockwise) a maximum of 359°. Tighten locknut (3) to the torque shown in the chart.

- End of fitting body (connects to tube).
- Fitting body.
- Locknut.
- Backup washer.
- O-ring seal.
- End of fitting that goes into other part.

A71009X3

ENGINE DESIGN


CYLINDER AND VALVE LOCATION




○ INTAKE
0.38mm
(.015 in.)

● EXHAUST
0.76mm
(.030 in.)

3508



3512



3516

B62374X1

ENGINE DESIGN

SPECIFICATIONS	ENGINE		
	3508	3512	3516
NUMBER AND ARRANGEMENT OF CYLINDERS	60° V-8	60° V-12	60° V-16
VALVES PER CYLINDER	4	4	4
DISPLACEMENT	34.5 LITER (2105 cu. in.)	51.8 LITER (3158 cu. in.)	69.1 LITER (4210 cu. in.)
BORE		170mm (6.7 in.)	
STROKE	190mm (7.5 in.)		
COMPRESSION RATIO	13:1		
TYPE OF COMBUSTION	Direct Injection		
VALVE SETTING	Intake	0.38mm (.015 in.)	
	Exhaust	0.76mm (.030 in.)	

FIRING ORDER (INJECTION SEQUENCE)		
ENGINE	SAE STANDARD ROTATION*	SAE OPPOSITE ROTATION*
3508	1-2-7-3-4-5-6-8	1-8-7-2-6-5-4-3
3512	1-12-9-4-5-8-11-2-3-10-7-6	14-9-8-5-2-11 -10-3-6-7-12
3516	1-2-5-6-3-4-9-10-15-16-11-12-13-14-7-8	1-6-5-4-3-10-9-16-15-12-11-14-13-8-7-2

- * Direction of Rotation (as viewed from flywheel end):
 SAE Standard Rotation -----Counterclockwise
 SAE Opposite Rotation -----Clockwise

NOTE: Front end of engine is opposite the flywheel end.
 Left side and right side of engine are as seen from flywheel end.
 No. 1 cylinder is the front cylinder on the right side.
 No. 2 cylinder is the front cylinder on the left side.

B62375X1

INTRODUCTION

The specifications given in this book are on the basis of information available at the time it was written. The specifications torques, pressures of operation, measurements, adjustments and other items can change at any time. These changes can effect the service given to the product. Get the complete and most current information before you start any job. Caterpillar Dealers have the most current information which is available. For a list of the most current modules and form numbers available for each Service Manual, see the SERVICE MANUAL CONTENTS MICROFICHE REG 1139F.

When the words "use again" are in the description, the specification given can be used to determine if a part

can be used again. If the part is equal to or within the specification given, use the part again.

When the word "permissible" is in the description, the specification given is the "maximum or minimum" tolerance permitted before adjustment, repair and/or new parts are needed.


A comparison can be made between the measurements of a worn part, and the specifications of a new part to find the amount of wear. A part that is worn can be safe to use if an estimate of the remainder of its service life is good. If a short service life is expected, replace the part.

77200X2

NOTE: For Systems Operation and Testing and Adjusting, make reference to 3500 INDUSTRIAL ENGINES, Form No. SENR2352.

FUEL INJECTION


- (1) Torque for locknut for rocker arm adjustment screw 70 + 15 N•m (50 ± 11 lb. ft.)
 - (2) Diameter of rocker arm shaft..... 37.084 ± 0.013 mm (1.4600 + .0005 in.)
Bore in bearing for rocker arm shaft 37.140 ± 0.015 mm (1.4622 ± .0006 in.)
 - (3) Injector installation:
 - a. Put multipurpose type grease in bore of cylinder head for lubrication of the O-ring seals.
 - b. Put injector in bore. Use bolt and clamp to push injector into the correct position.
- NOTE: Do not tap (hit) surface "Y" to install injector.
- c. Tighten bolt that holds fuel injector clamp to..... 65 ± 7 N-m (48 ± 5 lb. ft.)
 - d. After clamp is tightened, injector rack "X" must move freely.
- (4) Fuel timing dimension set by gauge. See FUEL SETTING AND RELATED INFORMATION FICHE for the correct dimension to use.
 - (5) Guide springs must not be used again. Always install new guide springs.
 - (6) Diameter of valve lifter (new)..... 29.937 ± 0.010 mm (1.1786 ± .0004 in.)
Bore in head for valve lifter..... 30.000 ± 0.025 mm (1.1811 ± .0010 in.)



A98681X2

**FUEL PRESSURE REGULATOR
(Earlier)**


- (1) Fuel manifold adapter on right hand front fuel manifold
- (2) 9N4053 Spring for fuel pressure regulator valve plunger
Length under test force 28 5 mm (1.12 in.)
Test force 40 8 ± 2 1 N (9 17 ± 46 lb)
Free length after test 57 2 mm (2 25 in)
Outside diameter 15 24 mm (600 in)
- (3) Regulator valve plunger. Regulator valve to hold fuel manifold pressure at 415 to 620 kPa (60 to 90 psi)



B38805X1

**FUEL PRESSURE REGULATOR
(Later)**


- (1) Fuel manifold adapter on right hand front fuel manifold.
- (2) 9N4053 Spring for fuel pressure regulator valve plunger
 Length under test force 28.5 mm (1.12 in.)
 Test force 40.8 ± 2.1 N ($9.17 \pm .46$ lb.)
 Free length after test 57.2 mm (2.25 in.)
 Outside diameter 15.24 mm (.600 in.)
- (3) Regulator valve plunger. Regulator valve to hold fuel manifold pressure at
 415 to 450 kPa (60 to 65 psi)



MANUAL SHUTOFF GROUP


NOTE: The shutoff group must be installed on the same side of the engine that the governor is installed.

- (1) When right hand mounted, "RH FRONT" should be visible from front of engine. When left hand mounted, "LH FRONT" should be visible from front of engine.
- (2) Put clean engine oil on the O-ring seal and lip-type seal at assembly.
- (3) Pull shutoff lever until governor linkage stops against internal stop. Turn adjustment screw until it makes contact with lever. Turn adjustment screw one complete turn more and tighten locknut.



NOTE: FOR TORQUE VALUES NOT GIVEN, SEE THE FIRST PAGE OF SPECIFICATIONS FOR GENERAL TIGHTENING TORQUES

FUEL INJECTION CONTROL GROUP



A98684X2

- | | |
|--|---|
| <p>(1) Bore of the bearings in the bracket assemblies (after assembly)
 21.925 ± 0.015 mm (.8632 ± .0006 in.)</p> <p>(2) Diameter of the surfaces for the bearings and rod assemblies on the shafts
 21.850 ± 0.015 mm (.8602 ± .0006 in.)</p> <p>(3) Bore of the bearings in the two support assemblies (after assembly)
 21.925 ± 0.015 mm (.8632 ± .0006 in.)</p> | <p>(4) Clearance between the lever assemblies on the front cross shaft and the side shafts
 0.80 ± 0.10 mm (.031 ± .004 in.)</p> <p>(5) Tighten locknuts at each end of bellcrank to a torque of..... 8 ± 2 N-m (6 ± 1 lb. ft.)</p> |
|--|---|