



Document ID

Order number: FF11 FGG
Issued: 2014-10
Version: 02
Author: LBH / Technical Documentation Department

Product ID

Manufacturer: Liebherr-Werk Bischofshofen GmbH
Valid for: L 528-1267

Conformity: 

Contact Liebherr-Werk Bischofshofen GmbH
Dr. Hans Liebherr-Straße 4
Bischofshofen - A – 5500

Product: 2014 Liebherr L 528-1267 Wheel Loader Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/2014-liebherr-l-528-1267-wheel-loader-service-repair-workshop-manual/>

LBH/in.a./02/211-20141016.0934/en

Sample of manual. Download All 722 pages at:

<https://www.arepairmanual.com/downloads/2014-liebherr-l-528-1267-wheel-loader-service-repair-workshop-manual/>

Notes for the user

This service handbook is designed for trained specialists of the Liebherr organisation and their dealers.

This service handbook contains special knowledge for repairing Liebherr construction machines. Basic specialist knowledge on electronics, hydraulics, mechanics and engine technology is not contained in this service handbook. Therefore specialized training and qualifications are necessary. Liebherr recommends participation in the Liebherr training program for construction machines.

In this service handbook you will find information on:

- Special tools
- Technical data
- Maintenance intervals and maintenance tasks
- Testing and adjustment tasks
- Structure and function descriptions
- Removal and installation tasks
- Circuit diagrams, hydraulic plans and technical drawings

You will find information on controls and operation in the operating instructions. Information on spare parts are in the spare parts catalogue. Please observe the local accident prevention laws.

This document may only be duplicated, even in part, with the permission of Liebherr.

Technical changes are reserved.

Warning symbols

	This is the warning symbol. It warns you of potential injuries. To prevent injury or death, carry out all the measures identified by this warning symbol.
---	---

The warning symbol always appears together with the signal words

DANGER
WARNING
CAUTION

	DANGER	Indicates a hazardous situation that will immediately lead to serious or fatal injury if it is not avoided.
	WARNING	Indicates a hazardous situation that may lead to serious or fatal injury if it is not avoided.

	CAUTION	Indicates a hazardous situation that may lead to minor or moderate injury if it is not avoided.
	ATTENTION	Indicates a hazardous situation that may lead to damage if it is not avoided.

Structure of warnings

Warnings in this document are structured as follows:



WARNING

Here you will find information about the type and source of danger. Here you will be informed about possible consequences of not paying attention to the warning.

▶ Here you will be called on to take measures to avoid the dangerous situation.

Other designations

Symbol	Meaning
	Note Indicates useful tips and information.
	This symbol means: Carry out a task.
	This symbol means: Requirements must be fulfilled.
	This symbol means: Results of a task.
-	This symbol indicates a list.

Symbols

Contents

010	Introduction	010-1
010.1	Safety instructions	010-3
010.1.1	General safety instructions	010-3
010.1.2	Instructions on preventing crushing injuries and burns	010-4
010.1.3	Instructions on preventing fires and explosions	010-4
010.1.4	Safety instructions for start-up	010-5
010.1.5	Safety precautions during start-up	010-5
010.1.6	Instructions for safe working	010-6
010.1.7	Safety instructions for driving on slopes	010-7
010.1.8	Parking safely	010-7
010.1.9	Transporting the machine safely	010-7
010.1.10	Towing the machine safely	010-8
010.1.11	Measures for ensuring safe maintenance	010-8
010.1.12	Safety instructions for maintenance work on machines with hydro accumulators	010-11
010.1.13	Safety instructions for welding work on the machine	010-11
010.1.14	Instructions for working safely on the working attachment	010-11
010.1.15	Safety instructions for transporting the machine by crane	010-12
010.1.16	Safe maintenance of hydraulic hoses and hose lines	010-12
010.1.17	Roll-over protection structure (ROPS) and falling object protection structure (FOPS)	010-13
010.1.17.1	Preventing accidents	010-13
010.1.17.2	Preventing injuries	010-13
010.1.18	Attachments and accessories	010-14
010.1.19	Protection against vibrations	010-14
010.1.20	See and be seen	010-15
010.1.20.1	Field of view	010-15
010.1.20.2	Measures before and during operation	010-15
010.2	Special tools for maintenance and repair work	010-16
010.2.1	Special tools in general	010-16

010.2.2	Special tools for the diesel engine	010-17
010.2.3	Special tools for the electrical system	010-17
010.2.4	Special tools for the air conditioning system	010-18
010.2.5	Special tools for cab glazing	010-18
010.2.6	Special tools for the central lubrication system (Liebherr)	010-19
010.2.7	Special tools for the central lubrication system (Groeneveld)	010-19
010.3	Standards and regulations	010-20
010.3.1	Prestressing forces and tightening torques for bolts with metric standard and fine threads	010-20
010.3.2	Assembly instructions for the piston and piston nut of the hydraulic cylinder (WN 4121)	010-24
010.3.2.1	Range of application and purpose	010-24
010.3.2.2	Requirements and description	010-24
010.3.2.3	Amendments	010-29
010.3.2.4	Other applicable documents	010-29
010.3.2.5	Maximum permissible adapter operating pressure	010-34
010.4	Preservation guidelines	010-35
010.4.1	General information	010-35
010.4.2	Putting the machine out of service – unknown duration	010-35
010.4.3	Putting the machine out of service	010-36
010.4.3.1	Out of service for up to 2 months	010-36
010.4.3.2	Out of service for up to 12 months	010-37
010.4.3.3	Out of service for longer than 12 months	010-38
010.4.4	Putting back into service	010-38
010.4.4.1	After being out of service for 2 months	010-38
010.4.4.2	After being out of service for 12 months	010-39
010.4.4.3	After being out of service for longer than 12 months	010-39
020	Technical data	020-1
020.1	Drive group	020-5
020.1.1	Engine <i>L528-1267/25345-;</i>	020-5
020.1.2	Fuel tank <i>L528-1267/25345-;</i>	020-6
020.1.2	Steel fuel tank (optional) <i>L528-1267/25345-;</i>	020-6
020.1.3	Fuel level sensor <i>L528-1267/25345-;</i>	020-6

020.1.4	Fuel pre-filter <i>L528-1267/25345-;</i>	020-7
020.1.5	Fuel fine filter <i>L528-1267/25345-;</i>	020-7
020.1.6	Air mass sensor vacuum switching point <i>L528-1267/25345-;</i>	020-7
020.1.7	Clutch <i>L528-1267/25345-;</i>	020-7
020.2	Cooling system	020-8
020.2.1	Water cooler <i>L528-1267/25345-;</i>	020-8
020.2.2	Fan gear pump <i>L528-1267/25345-;</i>	020-8
020.2.3	Fan gear motor <i>L528-1267/25345-;</i>	020-8
020.3	Working hydraulics	020-9
020.3.1	Working hydraulics pump <i>L528-1267/25345-;</i>	020-9
020.3.2	Z kinematics control valve block <i>L528-1267/25345-;</i>	020-9
020.3.3	P kinematics control valve block <i>L528-1267/25345-;</i>	020-9
020.3.4	Pilot control hydro accumulator <i>L528-1267/25345-;</i>	020-10
020.3.5	Stabilisation module (optional) <i>L528-1267/25345-;</i>	020-10
020.3.6	Ride control hydro accumulator (optional) <i>L528-1267/25345-;</i>	020-10
020.3.7	Z kinematics lift cylinder <i>L528-1267/25345-;</i>	020-11
020.3.8	Z kinematics tilt cylinder <i>L528-1267/25345-;</i>	020-11
020.3.9	P kinematics lift cylinder <i>L528-1267/25345-;</i>	020-11
020.3.10	P kinematics tilt cylinder <i>L528-1267/25345-;</i>	020-12
020.4	Travel hydraulics	020-13
020.4.1	Travel pump <i>L528-1267/25345-;</i>	020-13
020.4.2	Travel motor 1 <i>L528-1267/25345-;</i>	020-13
020.4.3	Travel motor 2 <i>L528-1267/25345-;</i>	020-14
020.5	Hydraulic components	020-15

020.5.1	Filter unit <i>L528-1267/25345-;</i>	020-15
020.5.2	Breather filter <i>L528-1267/25345-;</i>	020-15
020.6	Steering system	020-16
020.6.1	Servostat <i>L528-1267/25345-;</i>	020-16
020.6.2	Steering cylinder <i>L528-1267/25345-;</i>	020-16
020.6.3	Emergency steering pump <i>L528-1267/25345-;</i>	020-16
020.6.4	Emergency steering pressure switch B3 <i>L528-1267/25345-;</i>	020-17
020.6.5	Emergency steering check pressure switch B3a <i>L528-1267/25345-;</i>	020-17
020.7	Brake system	020-18
020.7.1	Brake system gear pump <i>L528-1267/25345-;</i>	020-18
020.7.2	Compact brake valve <i>L528-1267/25345-;</i>	020-18
020.7.3	Service brake hydro accumulator <i>L528-1267/25345-;</i>	020-18
020.7.4	Brake light pressure switch B12 <i>L528-1267/25345-;</i>	020-18
020.7.5	Accumulator charge pressure switch B19 <i>L528-1267/25345-;</i>	020-19
020.7.6	Disc brake <i>L528-1267/25345-;</i>	020-19
020.7.7	Parking brake hydro accumulator <i>L528-1267/25345-;</i>	020-19
020.8	Electrical system	020-20
020.8.1	Central control unit (Master 4) <i>L528-1267/25345-;</i>	020-20
020.8.2	Input module <i>L528-1267/25345-;</i>	020-20
020.8.3	Output module <i>L528-1267/25345-;</i>	020-20
020.8.4	Battery <i>L528-1267/25345-;</i>	020-21
020.9	Transmission	020-22
020.9.1	Transmission <i>L528-1267/25345-;</i>	020-22
020.9.2	Output speed sensor B1 and travel motor 2 speed sensor B2 <i>L528-1267/25345-;</i>	020-22

020.10	Axles and cardan shafts	020-23
020.10.1	Front axle <i>L528-1267/25345-;</i>	020-23
020.10.2	Rear axle <i>L528-1267/25345-;</i>	020-23
020.10.3	Cardan shaft <i>L528-1267/25345-;</i>	020-24
020.11	Steel components of the basic machine	020-25
020.11.1	Ballast weight <i>L528-1267/25345-;</i>	020-25
020.12	Cab, heating and air conditioning	020-26
020.12.1.1	Air conditioning compressor	020-26
020.12.2	Dryer <i>L528-1267/25345-;</i>	020-26
020.12.3	Pressure switches <i>L528-1267/25345-;</i>	020-26
020.12.4	Anti-icing temperature sensor <i>L528-1267/25345-;</i>	020-26
020.13	Lubrication system	020-28
020.13.1	Central lubrication system (Liebherr) <i>L528-1267/25345-;</i>	020-28
020.13.1.1	Central lubrication pump	020-28
020.13.2	Progressive distributor <i>L528-1267/25345-;</i>	020-28
020.13.2.1	MX-F	020-28
020.13.2.2	MX-F 25	020-28
020.13.2.3	MX-F 45	020-29
020.13.2.4	MX-F 75	020-29
020.13.2.5	MX-F105	020-29
030	Maintenance	030-1
030.1	Maintenance and inspection schedule	030-9
030.2	Filling quantities and lubrication chart	030-13
030.2.1	Recommended lubricants <i>L528-1267/25345-;</i>	030-13
030.2.2	Recommended operating fluids <i>L528-1267/25345-;</i>	030-14
030.3	Lubricants and fuels	030-15
030.3.1	General information on changing lubricants and fuels	030-15

030.3.2	Converting the hydraulic system from mineral oils to environmentally harmless hydraulic fluids	030-15
030.3.3	Diesel fuels <i>L528-1267/25345-;</i>	030-16
030.3.3.1	Specification	030-16
030.3.3.2	Sulphur content of the diesel fuel, lubricity	030-16
030.3.3.3	Diesel fuel at low temperatures (winter operation)	030-16
030.3.3.4	Flow improvers at low temperatures	030-17
030.3.4	Lubricating oils for diesel engines <i>L528-1267/25345-;</i>	030-17
030.3.4.1	Lubricating oil quality	030-17
030.3.4.2	Lubricating oil viscosity	030-17
030.3.4.3	Complicating factors affect the oil change	030-18
030.3.5	Coolants for diesel engines <i>L528-1267/25345-;</i>	030-19
030.3.5.1	General recommendations	030-19
030.3.5.2	Water (fresh water)	030-19
030.3.5.3	Coolant mixing ratio	030-19
030.3.5.4	Permissible antifreeze and corrosion inhibitors	030-20
030.3.5.5	Corrosion inhibitors without antifreeze	030-20
030.3.6	Hydraulic oil <i>L528-1267/25345-;</i>	030-21
030.3.6.1	Liebherr hydraulic oil	030-21
030.3.6.2	Using engine oil as hydraulic oil	030-21
030.3.6.3	Warming up	030-22
030.3.6.4	Biodegradable hydraulic oils	030-22
030.3.6.5	Changing the oil, analysing the oil, changing filters	030-23
030.3.7	Lubricating oils for transmissions <i>L528-1267/25345-;</i>	030-24
030.3.8	Lubricating oils for axles <i>L528-1267/25345-;</i>	030-25
030.3.9	Lubrication grease and other lubricants <i>L528-1267/25345-;</i>	030-26
030.3.9.1	Minimum quality requirements	030-26
030.3.9.2	Liebherr lubrication grease	030-26
030.4	Maintenance tasks	030-28
030.4.1	Safety precautions <i>L528-1267/25345-;</i>	030-28
030.4.2	Preparatory tasks for maintenance	030-29

030.4.2.1	Maintenance positions <i>L528-1267/25345-;</i>	030-29
030.4.2.2	Opening the service accesses <i>L528-1267/25345-;</i>	030-30
030.4.2.3	Turning off the battery main switch <i>L528-1267/25345-;</i>	030-32
030.4.3	Overall machine	030-33
030.4.3.1	Checking the machine for external damage <i>L528-1267/25345-;</i>	030-33
030.4.3.2	Removing loose parts, dirt, ice and snow from the machine <i>L528-1267/25345-;</i>	030-33
030.4.3.3	Cleaning the machine <i>L528-1267/25345-;</i>	030-33
030.4.3.4	Shutting down the machine for a lengthy period <i>L528-1267;</i>	030-35
030.4.3.5	Checking the machine for leaks <i>L528-1267/25345-;</i>	030-35
030.4.3.6	Making sure the bolted connections are tight <i>L528-1267/25345-;</i>	030-36
030.4.3.7	Corrosion protection on machines that work with salt and artificial fertilisers and exchanging VCI capsules <i>L528-1267/25345-;</i>	030-36
030.4.3.8	Oil analyses <i>L528-1267/25345-;</i>	030-36
030.4.4	Drive group	030-42
030.4.4.1	Checking the engine oil level <i>L528-1267/25345-;</i>	030-42
030.4.4.2	Changing the engine oil <i>L528-1267/25345-;</i>	030-43
030.4.4.3	Changing the engine oil filter <i>L528-1267/25345-;</i>	030-45
030.4.4.4	Checking the V-ribbed belt on the engine <i>L528-1267/25345-;</i>	030-45
030.4.4.5	Changing the V-ribbed belt on the engine <i>L528-1267/25345-;</i>	030-47
030.4.4.6	Checking the engine valve clearance <i>L528-1267/25345-;</i>	030-48
030.4.4.7	Changing the engine oil separator filter insert <i>L528-1267/25345-;</i>	030-51
030.4.4.8	Checking the bleeder filter of the crankcase <i>L528-1267/25345-;</i>	030-52
030.4.4.9	Checking the glow plugs <i>L528-1267/25345-;</i>	030-53

030.4.4.10	Draining off condensate and sediment from the fuel tank <i>L528-1267/25345-;</i>	030-55
030.4.4.11	Draining off condensate from the fuel pre-filter <i>L528-1267/25345-;</i>	030-56
030.4.4.12	Changing the fuel pre-filter <i>L528-1267/25345-;</i>	030-57
030.4.4.13	Changing the fuel fine filter <i>L528-1267/25345-;</i>	030-58
030.4.4.14	Bleeding the fuel system <i>L528-1267/25345-;</i>	030-59
030.4.4.15	Cleaning the air filter service cover and dust discharge valve <i>L528-1267/25345-;</i>	030-60
030.4.4.16	Checking the air intake hose for leaks and tight fitting <i>L528-1267/25345-;</i>	030-62
030.4.4.17	Changing the air filter main element <i>L528-1267/25345-;</i>	030-63
030.4.4.18	Changing the air filter safety element <i>L528-1267/25345-;</i>	030-64
030.4.4.19	Checking the exhaust system for leaks and tight fitting <i>L528-1267/25345-;</i>	030-64
030.4.4.20	Cleaning or changing the diesel particulate filter <i>L528-1267/25345-;</i>	030-65
030.4.5	Cooling system	030-69
030.4.5.1	Checking the coolant level <i>L528-1267/25345-;</i>	030-69
030.4.5.2	Checking the coolant antifreeze and corrosion inhibitor concentration <i>L528-1267/25345-;</i>	030-70
030.4.5.3	Cleaning the cooling system <i>L528-1267/25345-;</i>	030-75
030.4.5.4	Changing the coolant <i>L528-1267/25345-;</i>	030-76
030.4.6	Working hydraulics	030-78
030.4.6.1	Checking the oil level in the hydraulic tank <i>L528-1267/25345-;</i>	030-78
030.4.6.2	Checking and cleaning the magnetic rod on the hydraulic tank <i>L528-1267/25345-35974;</i>	030-79
030.4.6.3	Draining off condensate and sediment from the hydraulic tank <i>L528-1267/25345-;</i>	030-80
030.4.6.4	Changing the hydraulic tank return suction filter <i>L528-1267/25345-35974;</i>	030-81

030.4.6.5	Changing the hydraulic tank return suction filter <i>L528-1267/35975-;</i>	030-82
030.4.6.6	Changing the hydraulic tank breather filter <i>L528-1267/25345-;</i>	030-83
030.4.6.7	Changing the oil in the hydraulic system in accordance with oil quality and oil analysis <i>L528-1267/25345-;</i>	030-84
030.4.6.8	Lubricating the solenoids, universal joints and tappets on the pilot control unit <i>L528-1267/25345-;</i>	030-86
030.4.7	Steering system	030-86
030.4.7.1	Testing the steering <i>L528-1267/25345-;</i>	030-86
030.4.7.2	Lubricating the bearing points on the steering cylinders <i>L528-1267/25345-;</i>	030-87
030.4.8	Brake system	030-87
030.4.8.1	Testing the service brake and parking brake <i>L528-1267/25345-;</i>	030-87
030.4.8.2	Checking the service brake discs for wear <i>L528-1267/25345-;</i>	030-88
030.4.8.3	Checking the gap and wear on the parking brake linings <i>L528-1267/25345-;</i>	030-90
030.4.9	Electrical system	030-93
030.4.9.1	Checking the lights <i>L528-1267/25345-;</i>	030-93
030.4.9.2	Checking the batteries, fluid level and terminals <i>L528-1267/25345-;</i>	030-94
030.4.9.3	Changing the travel direction rocker switch and cap (optional) on the control lever <i>L528-1267/25345-;</i>	030-96
030.4.10	Transmission	030-99
030.4.10.1	Checking the transmission oil level <i>L528-1267/25345-;</i>	030-99
030.4.10.2	Changing the transmission oil <i>L528-1267/25345-;</i>	030-99
030.4.11	Axles and cardan shafts	030-100
030.4.11.1	Checking the axle oil levels <i>L528-1267/25345-;</i>	030-100
030.4.11.2	Changing the axle oil <i>L528-1267/25345-;</i>	030-101
030.4.11.3	Checking the tightening torque of the front axle fastening bolts <i>L528-1267/25345-;</i>	030-103

030.4.11.4	Checking the cardan shafts <i>L528-1267/25345-;</i>	030-103
030.4.11.5	Checking the tyre pressure <i>L528-1267/25345-;</i>	030-104
030.4.11.6	Checking the wheel tightness (once after 50, 100 and 250 h) <i>L528-1267/25345-;</i>	030-105
030.4.12	Steel components of the basic machine	030-105
030.4.12.1	Lubricating the articulated bearing and the rear oscillating bedding <i>L528-1267/25345-;</i>	030-105
030.4.12.2	Covering - lubricating locks and hinges <i>L528-1267/25345-;</i>	030-106
030.4.13	Working attachment	030-107
030.4.13.1	Lubricating the lift arms and attachment <i>L528-1267/25345-;</i>	030-107
030.4.13.2	Checking the lift arm bearing bushings <i>L528-1267/25345-;</i>	030-108
030.4.13.3	Checking the lift arm bucket stops (Z kinematics) <i>L528-1267/25345-;</i>	030-109
030.4.13.4	Lubricating and testing the quick-change device <i>L528-1267/25345-;</i>	030-109
030.4.14	Cab, heating and air conditioning	030-110
030.4.14.1	Lubricating the elongated hole on the accelerator pedal and checking the bearing <i>L528-1267/25345-;</i>	030-110
030.4.14.2	Cleaning the fresh and recirculated air filters <i>L528-1267/25345-;</i>	030-111
030.4.14.3	Changing the fresh and recirculated air filters <i>L528-1267/25345-;</i>	030-113
030.4.14.4	Checking the condition and function of the safety belt <i>L528-1267/25345-;</i>	030-114
030.4.14.5	Checking and topping up the windscreen washer reservoir <i>L528-1267/25345-;</i>	030-114
030.4.14.6	Checking the rubber seals on the driver's cab <i>L528-1267/25345-;</i>	030-115
030.4.14.7	Checking the indicator and filling level beads in the dryer-collector unit (optional) <i>L528-1267/25345-;</i>	030-115
030.4.14.8	Testing the air conditioning unit <i>L528-1267/25345-;</i>	030-116
030.4.15	Lubrication system	030-117

030.4.15.1	Checking the lubrication system grease reservoir level <i>L528-1267/25345-;</i>	030-117
030.4.15.2	Checking the pipes, hoses and lubrication points of the lubrication system <i>L528-1267/25345-;</i>	030-118
030.4.15.3	Checking whether metered quantities are adequate at the bearing points (grease collars) of the lubrication system <i>L528-1267/25345-;</i>	030-118
030.5	Testing and adjustment checklist <i>L528-1267/25345-;</i>	030-119
030.6	Testing and adjustment tasks	030-123
030.6.1	Safety precautions <i>L528-1267/25345-;</i>	030-123
030.6.2	Overall machine	030-124
030.6.2.1	Preparatory tasks for testing and adjustment <i>L528-1267/25345-;</i>	030-124
030.6.2.2	Bringing the machine up to operating temperature <i>L528-1267/25345-;</i>	030-125
030.6.3	Drive group	030-126
030.6.3.1	Calibrating the pedals <i>L528-1267/25345-;</i>	030-126
030.6.3.2	Checking the engine speed <i>L528-1267/25345-;</i>	030-127
030.6.4	Cooling system	030-127
030.6.4.1	Pressure relief and proportional valve of fan gear motor <i>L528-1267/25345-;</i>	030-127
030.6.5	Working hydraulics	030-129
030.6.5.1	Working hydraulics pump flow regulator (standby pressure) <i>L528-1267/25345-;</i>	030-129
030.6.5.2	Z-bar kinematics control block for secondary pressure relief valves <i>L528-1267/25345-;</i>	030-131
030.6.5.3	P-kinematics control block for secondary pressure relief valves <i>L528-1267/25345-;</i>	030-132
030.6.5.4	Working hydraulics LS pressure cut-off <i>L528-1267/25345-;</i>	030-134
030.6.5.5	Stabilisation module (optional), cut-off function <i>L528-1267/25345-;</i>	030-135
030.6.5.6	Ride control hydro accumulator (optional), nitrogen filling <i>L528-1267/25345-;</i>	030-136

	030.6.5.7	Testing the control valve block for leakage <i>L528-1267/25345-;</i>	030-138
030.6.6	Travel hydraulics		030-142
	030.6.6.1	Travel pump replenishing pressure relief valve <i>L528-1267/25345-;</i>	030-142
	030.6.6.2	Travel pump high pressure relief valves <i>L528-1267/25345-;</i>	030-143
	030.6.6.3	Travel pump pressure cut-off <i>L528-1267/25345-;</i>	030-145
	030.6.6.4	Travel pump block curve calibration <i>L528-1267/25345-;</i>	030-147
	030.6.6.5	Start of regulation of travel motor 1 <i>L528-1267/25345-;</i>	030-149
	030.6.6.6	Automatic calibration of travel motor 2 <i>L528-1267/25345-;</i>	030-150
	030.6.6.7	Engine output <i>L528-1267/25345-;</i>	030-151
030.6.7	Steering system		030-152
	030.6.7.1	Steering system LS pressure cut-off <i>L528-1267/25345-;</i>	030-152
030.6.8	Brake system		030-154
	030.6.8.1	Compact brake valve, hydro accumulator charging function <i>L528-1267/25345-;</i>	030-154
	030.6.8.2	Service brake pressure <i>L528-1267/25345-;</i>	030-155
	030.6.8.3	Service brake hydro accumulator capacity <i>L528-1267/25345-;</i>	030-155
	030.6.8.4	Accumulator charge pressure switch shift pressure <i>L528-1267/25345-;</i>	030-157
030.6.9	Electrical system		030-158
	030.6.9.1	Setting the IP addresses of the central control unit (Master4) <i>L528-1267/25345-;</i>	030-158
	030.6.9.2	Central control unit (Master4) - Performing a reset <i>L528-1267/25345-;</i>	030-160
	030.6.9.3	Testing the CAN line <i>L528-1267/25345-;</i>	030-162
	030.6.9.4	Addressing the CAN module and checking the system information <i>L528-1267/25345-;</i>	030-165
030.6.10	Transmission		030-169

	030.6.10.1	Automatic calibration of clutch proportional solenoid valve <i>L528-1267/25345-;</i>	030-169
	030.6.10.2	Hydraulic control system – hydraulic oil adjustment <i>L528-1267/25345-;</i>	030-170
030.6.11	Cab, heating and air conditioning		030-170
	030.6.11.1	Adjusting the heating circuit pressure relief valve <i>L528-1267/25345-;</i>	030-170
	030.6.11.2	Calibrating the display unit <i>L528-1267/25345-;</i>	030-171
	030.6.11.3	Formatting the display unit and reinstalling the software <i>L528-1267/25345-;</i>	030-172
030.6.12	Options		030-174
	030.6.12.1	LiDAT on the machine - Checking connecting link <i>L528-1267/25345-;</i>	030-174
040	Drive group		040-1
040.1	Engine		040-2
	040.1.1	Diesel engine overview <i>L528-1267/25345-;</i>	040-2
	040.1.2	Fuel system	040-5
	040.1.2.1	Overview of the fuel system <i>L528-1267/25345-;</i>	040-6
	040.1.2.2	Fuel level sensor <i>L528-1267/25345-;</i>	040-7
	040.1.2.3	Fuel pre-filter <i>L528-1267/25345-;</i>	040-9
	040.1.2.4	Fuel fine filter <i>L528-1267/25345-;</i>	040-10
	040.1.3	Air filter system	040-10
	040.1.3.1	Overview of the air filter unit <i>L528-1267/25345-;</i>	040-11
	040.1.3.2	Air filter <i>L528-1267/25345-;</i>	040-12
	040.1.4	Exhaust system	040-12
	040.1.4.1	Overview of the exhaust system <i>L528-1267/25345-;</i>	040-13
	040.1.4.2	Overview of the diesel particulate filter <i>L528-1267/25345-;</i>	040-15
040.2	Coupling <i>L528-1267/25345-;</i>		040-20

050	Cooling system	050-1
050.1	Overview of the cooling system <i>L528-1267/25345-;</i>	050-2
050.2	Hydraulic control unit	050-4
050.2.1	Overview of the hydraulics cooling system <i>L528-1267/25345-;</i>	050-4
050.2.2	Fan gear pump <i>L528-1267/25345-;</i>	050-6
050.2.3	Fan gear motor <i>L528-1267/25345-;</i>	050-7
050.3	Electronic control unit	050-11
050.3.1	Overview of the electronic control system <i>L528-1267/25345-;</i>	050-11
050.3.2	Coolant temperature sensor <i>L528-1267/25345-;</i>	050-12
050.3.3	Hydraulic oil temperature sensor <i>L528-1267/25345-;</i>	050-13
050.3.4	Charge air temperature sensor <i>L528-1267/25345-;</i>	050-15
050.4	Cooler	050-17
050.4.1	Water cooler <i>L528-1267/25345-;</i>	050-17
050.4.2	Hydraulic oil cooler <i>L528-1267/25345-;</i>	050-18
050.4.3	Intercooler <i>L528-1267/25345-;</i>	050-20
050.4.4	Fuel cooler <i>L528-1267/25345-;</i>	050-21
060	Working hydraulics	060-1
060.1	Overview of working hydraulics for z-bar kinematics <i>L528-1267/25345-;</i>	060-3
060.2	Overview of working hydraulics for p kinematics <i>L528-1267/25345-;</i>	060-8
060.3	Working hydraulics pump <i>L528-1267/25345-;</i>	060-12
060.4	Control valve block for Z-bar kinematics <i>L528-1267/25345-;</i>	060-16
060.5	Control valve block for P kinematics <i>L528-1267/25345-;</i>	060-22
060.6	Pilot control	060-27
060.6.1	Overview of the pilot control unit <i>L528-1267/25345-;</i>	060-27

060.6.2	Pilot control unit <i>L528-1267/25345-;</i>	060-28
060.6.3	Working hydraulics lockout solenoid valve <i>L528-1267/25345-;</i>	060-33
060.6.4	Pilot control hydro accumulator <i>L528-1267/25345-;</i>	060-34
060.7	Ride control	060-35
060.7.1	Ride control overview <i>L528-1267/25345-;</i>	060-35
060.7.2	Stabilisation module <i>L528-1267/25345-;</i>	060-36
060.7.3	Ride control hydro accumulator <i>L528-1267/25345-;</i>	060-41
060.8	Working hydraulics cylinder	060-42
060.8.1	Hydraulic cylinders for Z kinematics	060-42
060.8.1.1	Z kinematics lift cylinder <i>L528-1267/25345-;</i>	060-42
060.8.1.2	Z kinematics tilt cylinder <i>L528-1267/25345-;</i>	060-44
060.8.2	Hydraulic cylinders for P kinematics	060-45
060.8.2.1	P kinematics lift cylinder <i>L528-1267/25345-;</i>	060-46
060.8.2.2	P kinematics tilt cylinder <i>L528-1267/25345-;</i>	060-47
070	Travel hydraulics	070-1
070.1	Travel hydraulics overview <i>L528-1267/25345-36291;</i>	070-2
070.2	Travel hydraulics overview <i>L528-1267/36292-;</i>	070-7
070.3	Travel pump <i>L528-1267/25345-36291;</i>	070-12
070.4	Travel pump <i>L528-1267/36292-;</i>	070-26
070.5	Travel motors	070-41
070.5.1	Overview of the travel motors <i>L528-1267/25345-;</i>	070-41
070.5.2	Travel motor 1 <i>L528-1267/25345-;</i>	070-43
070.5.3	Travel motor 2 <i>L528-1267/25345-;</i>	070-50

080	Hydraulic components	080-1
080.1	Hydraulic tank	080-2
080.1.1	Overview of the hydraulic tank <i>L528-1267/25345-;</i>	080-2
080.1.2	Filter unit <i>L528-1267/25345-;</i>	080-4
080.1.3	Breather filter <i>L528-1267/25345-;</i>	080-9
090	Steering system	090-1
090.1	Steering system overview <i>L528-1267/25345-35802;</i>	090-2
090.2	Steering system overview <i>L528-1267/35803-;</i>	090-6
090.3	Servostat <i>L528-1267/25345-;</i>	090-10
090.4	Steering cylinder	090-14
090.4.1	Steering cylinder overview <i>L528-1267/25345-35802;</i>	090-14
090.4.2	Steering cylinder overview <i>L528-1267/35803-;</i>	090-16
090.4.3	Steering damper hydro accumulator <i>L528-1267/35803-;</i>	090-18
090.5	Emergency steering	090-19
090.5.1	Emergency steering overview <i>L528-1267/25345-;</i>	090-19
090.5.2	Emergency steering pump <i>L528-1267/25345-;</i>	090-20
090.5.3	Electronic control unit	090-22
090.5.3.1	Overview of the electronic control system <i>L528-1267/25345-;</i>	090-22
090.5.3.2	Emergency steering pressure switch <i>L528-1267/25345-;</i>	090-23
090.5.3.3	Emergency steering check pressure switch <i>L528-1267/25345-;</i>	090-24
090.5.4	Valve block <i>L528-1267/25345-;</i>	090-25
100	Brake system	100-1
100.1	Overview of the brake system <i>L528-1267/25345-;</i>	100-2
100.2	Parking and service brake	100-4

100.2.1	Brake system gear pump <i>L528-1267/25345-;</i>	100-4
100.2.2	Compact brake valve <i>L528-1267/25345-;</i>	100-5
100.3	Service brake	100-12
100.3.1	Overview of the service brake <i>L528-1267/25345-;</i>	100-12
100.3.2	Service brake hydro accumulator <i>L528-1267/25345-;</i>	100-15
100.3.3	Brake light pressure switch <i>L528-1267/25345-;</i>	100-16
100.3.4	Accumulator charge pressure switch <i>L528-1267/25345-;</i>	100-17
100.4	Parking brake	100-18
100.4.1	Overview of the parking brake <i>L528-1267/25345-;</i>	100-18
100.4.2	Disc brake <i>L528-1267/25345-;</i>	100-21
100.4.3	Parking brake hydro accumulator <i>L528-1267/25345-;</i>	100-22
110	Electrical system	110-1
110.1	Overview of the electrical system <i>L528-1267/25345-;</i>	110-2
110.2	Lighting <i>L528-1267/25345-;</i>	110-7
110.3	Circuit diagrams <i>L528-1267/25345-;</i>	110-9
110.4	Electronic control unit	110-11
110.4.1	Overview of the electronic control system <i>L528-1267/25345-;</i>	110-11
110.4.2	Central control unit (Master4) <i>L528-1267/25345-;</i>	110-13
110.4.3	Modules	110-18
110.4.3.1	Overview of the module <i>L528-1267/25345-;</i>	110-18
110.4.3.2	Input modules <i>L528-1267/25345-;</i>	110-20
110.4.3.3	Output modules <i>L528-1267/25345-;</i>	110-22
110.5	Electrical components of the driver's cab	110-25
110.5.1	Overview of electrical components in the driver's cab <i>L528-1267/25345-;</i>	110-25

110.5.2	Fuse and relay board <i>L528-1267/25345-;</i>	110-26
110.6	Electrical components in the rear section	110-30
110.6.1	Battery installation <i>L528-1267/25345-;</i>	110-30
120	Transmission	120-1
120.1	Overview of the transmission <i>L528-1267/25345-;</i>	120-2
120.2	Mechanical transmission <i>L528-1267/25345-;</i>	120-3
120.3	Electronic control unit	120-9
120.3.1	Overview of the electronic control system <i>L528-1267/25345-;</i>	120-9
120.3.2	Output speed sensor and travel motor 2 speed sensor <i>L528-1267/25345-;</i>	120-10
120.4	Hydraulic control unit	120-11
120.4.1	Overview of the hydraulic control system <i>L528-1267/25345-;</i>	120-11
130	Axles and cardan shafts	130-1
130.1	Axles	130-2
130.1.1	Front axle <i>L528-1267/25345-;</i>	130-2
130.1.2	Rear axle <i>L528-1267/25345-;</i>	130-6
130.2	Cardan shafts	130-7
130.2.1	Cardan shaft <i>L528-1267/25345-;</i>	130-7
140	Steel components of the basic machine	140-1
140.1	Vehicle frame	140-2
140.1.1	Articulation bearing <i>L528-1267/25345-;</i>	140-2
140.1.2	Articulation lock <i>L528-1267/25345-;</i>	140-3
150	Working attachment	150-1
150.1	Lift arms with Z kinematics	150-2
150.1.1	Z kinematics lift arm <i>L528-1267/25345-;</i>	150-2
150.2	Lift arms with P kinematics	150-3

150.2.1	P kinematics lift arm <i>L528-1267/25345-;</i>	150-3
150.3	Z kinematics quick coupler <i>L528-1267/25345-;</i>	150-4
150.4	P kinematics quick coupler <i>L528-1267/25345-;</i>	150-8
160	Cab, heating and air conditioning	160-1
160.1	Overview of the cab, heating and air conditioning unit <i>L528-1267/25345-;</i>	160-3
160.2	Display and control elements	160-5
160.2.1	Electrical components in the control panel	160-5
160.2.1.1	Overview of electrical components in the control panel <i>L528-1267/25345-;</i>	160-5
160.2.1.2	Control unit for main functions <i>L528-1267/25345-;</i>	160-5
160.2.1.3	Starter switch <i>L528-1267/25345-;</i>	160-8
160.2.2	Display <i>L528-1267/25345-;</i>	160-9
160.2.3	Touch screen display <i>L528-1267/25345-;</i>	160-11
160.2.4	Control lever <i>L528-1267/25345-;</i>	160-13
160.3	Heating, ventilation, air conditioning	160-16
160.3.1	Overview of the heating, ventilation and air conditioning system <i>L528-1267/25345-;</i>	160-16
160.3.2	Heating and air conditioning unit	160-21
160.3.2.1	Heating and air conditioning unit <i>L528-1267/25345-;</i>	160-22
160.3.2.2	Blower <i>L528-1267/25345-;</i>	160-24
160.3.3	Heater/air conditioning control electronics <i>L528-1267/25345-;</i>	160-25
160.3.4	Heating circuit pressure relief valve <i>L528-1267/25345-;</i>	160-26
160.4	Air conditioning	160-28
160.4.1	Basic function of the air conditioning unit <i>L528-1267/25345-;</i>	160-28
160.4.2	Air conditioning compressor <i>L528-1267/25345-;</i>	160-29

160.4.3	Condenser <i>L528-1267/25345-;</i>	160-30
160.4.4	Dryer <i>L528-1267/25345-;</i>	160-31
160.4.5	Air conditioning pressure switch <i>L528-1267/25345-;</i>	160-32
160.4.6	Evaporator <i>L528-1267/25349-;</i>	160-34
160.4.7	Anti-icing temperature sensor <i>L528-1267/25345-;</i>	160-35
160.4.8	Automatic air conditioning	160-35
160.4.8.1	Overview of the automatic air conditioning <i>L528-1267/25345-;</i>	160-36
160.4.8.2	Interior temperature sensor and air flow temperature sensor <i>L528-1267/25345-;</i>	160-37
160.4.8.3	Outside temperature sensor <i>L528-1267/25345-;</i>	160-37
160.4.8.4	Sun sensor <i>L528-1267/25345-;</i>	160-38
170	Lubrication system	170-1
170.1	Liebherr automatic central lubrication system	170-2
170.1.1	Overview of Liebherr automatic central lubrication system <i>L528-1267/25345-;</i>	170-2
170.1.2	Liebherr central lubrication pump <i>L528-1267/25345-;</i>	170-6
170.1.3	Progressive distributor MX-F <i>L528-1267/25345-;</i>	170-10
190	Options	190-1
190.1	Reversible fan drive <i>L528-1267/25345-;</i>	190-2
190.2	LiDAT	190-4
190.2.1	LiDat - Overall system <i>L528-1267/25345-;</i>	190-4
190.2.2	LiDAT on the machine <i>L528-1267/25345-;</i>	190-6
190.3	Weighing device (Liebherr) <i>L528-1267/25345-;</i>	190-10
200	Service codes, diagnosis	200-1
200.1	Malfunctions	200-2

200.1.1	Warning symbols	200-2
200.1.2	Service code indicator in the display	200-3
200.1.3	C service codes displayed in the LCD	200-4
200.2	Troubleshooting	200-6
200.2.1	Replacing fuses	200-6
200.2.1.1	Fuses in the battery compartment	200-6
200.2.1.2	Plug-in fuses on the relay and fuse board	200-7
200.2.1.3	Plug-in fuses for LiDAT	200-10

LBH/n.a./02/211-2014/1016.0934/en

010 Introduction

Contents

010.1	Safety instructions	010-3
010.1.1	General safety instructions	010-3
010.1.2	Instructions on preventing crushing injuries and burns	010-4
010.1.3	Instructions on preventing fires and explosions	010-4
010.1.4	Safety instructions for start-up	010-5
010.1.5	Safety precautions during start-up	010-5
010.1.6	Instructions for safe working	010-6
010.1.7	Safety instructions for driving on slopes	010-7
010.1.8	Parking safely	010-7
010.1.9	Transporting the machine safely	010-7
010.1.10	Towing the machine safely	010-8
010.1.11	Measures for ensuring safe maintenance	010-8
010.1.12	Safety instructions for maintenance work on machines with hydro accumulators	010-11
010.1.13	Safety instructions for welding work on the machine	010-11
010.1.14	Instructions for working safely on the working attachment	010-11
010.1.15	Safety instructions for transporting the machine by crane	010-12
010.1.16	Safe maintenance of hydraulic hoses and hose lines	010-12
010.1.17	Roll-over protection structure (ROPS) and falling object protection structure (FOPS)	010-13
010.1.17.1	Preventing accidents	010-13
010.1.17.2	Preventing injuries	010-13
010.1.18	Attachments and accessories	010-14
010.1.19	Protection against vibrations	010-14
010.1.20	See and be seen	010-15
010.1.20.1	Field of view	010-15
010.1.20.2	Measures before and during operation	010-15
010.2	Special tools for maintenance and repair work	010-16

010.2.1	Special tools in general	010-16
010.2.2	Special tools for the diesel engine	010-17
010.2.3	Special tools for the electrical system	010-17
010.2.4	Special tools for the air conditioning system	010-18
010.2.5	Special tools for cab glazing	010-18
010.2.6	Special tools for the central lubrication system (Liebherr)	010-19
010.2.7	Special tools for the central lubrication system (Groeneveld)	010-19
010.3	Standards and regulations	010-20
010.3.1	Prestressing forces and tightening torques for bolts with metric standard and fine threads	010-20
010.3.2	Assembly instructions for the piston and piston nut of the hydraulic cylinder (WN 4121)	010-24
010.3.2.1	Range of application and purpose	010-24
010.3.2.2	Requirements and description	010-24
010.3.2.3	Amendments	010-29
010.3.2.4	Other applicable documents	010-29
010.3.2.5	Maximum permissible adapter operating pressure	010-34
010.4	Preservation guidelines	010-35
010.4.1	General information	010-35
010.4.2	Putting the machine out of service – unknown duration	010-35
010.4.3	Putting the machine out of service	010-36
010.4.3.1	Out of service for up to 2 months	010-36
010.4.3.2	Out of service for up to 12 months	010-37
010.4.3.3	Out of service for longer than 12 months	010-38
010.4.4	Putting back into service	010-38
010.4.4.1	After being out of service for 2 months	010-38
010.4.4.2	After being out of service for 12 months	010-39
010.4.4.3	After being out of service for longer than 12 months	010-39

010.1 Safety instructions

010.1.1 General safety instructions

1. Familiarise yourself with the “**operating manual**” before starting up the machine.
Make sure that you are in possession of and have read and understood additional instructions applicable to any special equipment installed on your machine.
2. Only expressly authorised personnel may operate, service or repair the machine.
Observe the legal minimum ages.
3. Only trained or instructed personnel may operate the machine. Clearly assign responsibility for operation, rigging, maintenance and repair work.
4. Clearly establish the driver’s responsibilities (also with respect to traffic regulations) and authorise him to refuse to carry out unsafe instructions from third parties.
5. Personnel undergoing training, instruction or who are not yet fully qualified may only be allowed to work on the machine under constant supervision by an experienced person.
6. Now and again check that your personnel are working safely and are aware of possible dangers in observance of the “**operating manual**” .
7. Wear safe working clothes when working on the machine.
Do not wear rings, wristwatches, ties, scarves, unbuttoned jackets, loose clothing or similar garments, as they can become caught in the machinery and cause injury.
Certain tasks require safety goggles, safety boots, hard hats, gloves, reflective vests, ear protection etc.
8. Ask the site manager about any special safety regulations in force on the site.
9. Do not hold onto the steering column, the control panel or the control levers when getting on or off the machine.
You might inadvertently trigger movements which could lead to accidents.
10. Never jump down from the machine. Use the steps, ladders and platforms provided for getting on and off.
11. Keep all handles, steps, rails, gangways, platforms and ladders free from oil, grease, mud snow and ice. This reduces the risk of slipping, tripping up or falling.
12. Familiarise yourself with the emergency exit through the right cab door and/or the rear window.
13. Unless there are other instructions, perform maintenance and repair work as follows:
Procedure:
 - Park the machine on firm, level ground and lower the working attachment to the ground.
 - Move all control levers to neutral.
 - Shut down the engine and take out the ignition key.
14. Before starting any work on the hydraulic circuit, you must also press the working hydraulics lockout button and actuate all pilot control units (joystick and pedals) in both directions in order to reduce the control pressure and accumulated pressure in the operating circuits. You must then reduce the internal tank pressure.
15. Lock the working hydraulics to prevent accidental actuation before leaving the driver’s cab.
Lock the working hydraulics in accordance with the instructions in the “**operating manual**”.

16. Secure all loose parts of the machine.
17. Never start up a machine without first making a thorough tour of inspection and checking if any warning signs are missing or illegible.
18. Observe all signs with warnings or safety instructions.
19. Special safety apparatus must be fitted to the machine for certain applications. If this is the case, only work with this apparatus fitted and in working order.
20. Do not make any modifications, extensions or conversions to the machine with possible safety implications without the approval of the supplier. This also applies to installing and adjusting safety apparatus and valves, as well as to welding load-bearing components.
21. Avoid standing near the diesel engine while it is running. People that have a pacemaker must not stand next to the diesel engine while it is running (minimum distance 50 cm).
22. Do not touch live components of the solenoid controlled unit pumps on their electrical connections.

010.1.2 Instructions on preventing crushing injuries and burns

1. Do not work under the attachment if it is not resting on the ground or supported.
2. Do not use any ropes or chains which are damaged or which have insufficient load bearing capacity.
Wear protective gloves when handling wire ropes.
3. When working with the attachment, never align the boreholes with your fingers, instead, use a suitable mandrel for this purpose.
4. Make sure no objects come into contact with the fan when the engine is running.
Objects which fall or project into the fan will be thrown back out or destroyed and could damage the fan.
5. When the machine is near operating temperature, the engine cooler system is hot and pressurised.
Do not touch parts carrying cooling water.
This can lead to burns.
6. Only check the coolant level once the cap on the expansion tank has cooled down enough to touch.
Carefully open the cap to let out excess pressure.
7. When running at or near the operating temperature, the engine oil and hydraulic oil are hot.
Avoid touching hot oil or parts which carry oil.
8. Wear goggles and safety gloves when working on the battery.
Avoid sparks and naked lights.
9. Never let anyone move the bucket or other working attachments into position by hand.
10. Any time you open the engine compartment, prevent the compartment doors from falling shut using the struts provided.
11. Before starting up the machine, close and lock the engine compartment doors and the battery compartment cover.
12. Never lie under the machine when it is raised using the working attachment, unless the undercarriage is securely supported using wooden beams.
13. Avoid touching hot surfaces and liquids. This can lead to burns.

010.1.3 Instructions on preventing fires and explosions

1. When refuelling, the engine must be turned off. Switch off the auxiliary heater, if installed.