

Product: Kubota WSM B21,TL421,BT751 Tractor,Front Loader,Backhoe Service Repair Workshop Manual

Full Download: <https://www.arepairmanual.com/downloads/1996-kubota-wsm-b21t>

l421bt751-tractorfront-loaderbackhoe-service-repair-workshop

-manual/

WSM

WORKSHOP MANUAL
**TRACTOR, FRONT LOADER,
BACKHOE**

B21, TL421, BT751

Kubota

Sample of manual. Download All 437 pages at:

<https://www.arepairmanual.com/downloads/1996-kubota-wsm-b21tl421bt751-tractorfront-loaderbackhoe-service-repair-workshop>

Product: Kubota WSM B21,TL421,BT751 Tractor,Front Loader,Backhoe Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1996-kubota-wsm-b21tl421bt751-tractorfront-loaderbackhoe-service-repair-workshop-manual/>

TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA Tractor B21, KUBOTA Front Loader TL421 and KUBOTA Backhoe BT751. It is divided into two parts, "Mechanism" and "Servicing" for each section.

■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

■ Servicing

Under the heading "General" section comes general precautions, check and maintenance and special tools. Other section, there are troubleshooting, servicing specification lists, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information, illustrations and specifications contained in this manual are based on the latest production information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

December '96

© KUBOTA Corporation 1996

12010Z00010

Sample of manual. Download All 437 pages at:

<https://www.arepairmanual.com/downloads/1996-kubota-wsm-b21tl421bt751-tractorfront-loaderbackhoe-service-repair-workshop-manual/>

⚠ SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and decals on the machine itself to warn of the possibility of personal injury. Read these instructions carefully.

It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.

⚠ DANGER :Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING:Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION :Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.


■ IMPORTANT :Indicates that equipment or property damage could result if instructions are not followed.

■ NOTE :Gives helpful information.

00000Z00010

BEFORE SERVICING AND REPAIRING

- (1) Read all instructions and safety instructions in this manual and on your machine safety decals.
- (2) Clean the work area and machine.
- (3) Park the machine on a firm and level ground, and set the parking brake.
- (4) Lower the implement to the ground.
- (5) Stop the engine, and remove the key.
- (6) Disconnect the battery negative cable.
- (7) Hang a "DO NOT OPERATE" tag in operator station.



00000Z00020




00000F00020

SAFETY STARTING

- (1) Do not start the engine by shorting across starter terminals or bypassing the safety start switch.
- (2) Do not alter or remove any part of machine safety system.
- (3) Before starting the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- (4) Never start the engine while standing on ground. Start the engine only from operator's seat.

00000Z00030




00000F00030


SAFETY WORKING

- (1) Do not work on the machine while under the influence of alcohol, medication, or other substances or while fatigued.
- (2) Wear close fitting clothing and safety equipment appropriate to the job.
- (3) Use tools appropriate to the work. Makeshift tools, parts, and procedures are not recommended.
- (4) When servicing is performed together by two or more persons, take care to perform all work safely.
- (5) Do not work under the machine that is supported solely by a jack. Always support the machine by safety stands.
- (6) Do not touch the rotating or hot parts while the engine is running.
- (7) Never remove the radiator cap while the engine is running, or immediately after stopping. Otherwise, hot water will spout out from radiator. Only remove radiator cap when cool enough to touch with bare hands. Slowly loosen the cap to first stop to relieve pressure before removing completely.
- (8) Escaping fluid (fuel or hydraulic oil) under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or fuel lines. Tighten all connections before applying pressure.

00000Z00040



00000F00040




00000F00050

AVOID FIRES

- (1) Fuel is extremely flammable and explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.
- (2) To avoid sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- (3) Battery gas can explode. Keep sparks and open flame away from the top of battery, especially when charging the battery.
- (4) Make sure that no fuel has been spilled on the engine.


00000Z00050



VENTILATE WORK AREA

- (1) If the engine must be running to do same work, make sure the area is well ventilated. Never run the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.

00000Z00060



PREVENT ACID BURNS

- (1) Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, clothing and cause blindness if splashed into eyes. Keep electrolyte away from eyes, hands and clothing. If you spill electrolyte on yourself, flush with water, and get medical attention immediately.


00000Z00070



DISPOSE OF FLUIDS PROPERLY

- (1) Do not pour fluids into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, electrolyte and other harmful waste.

00000Z00080



PREPARE FOR EMERGENCIES

- (1) Keep a first aid kit and fire extinguisher handy at all times.
- (2) Keep emergency numbers for doctors, ambulance service, hospital and fire department near your telephone.

00000Z00090

SAFETY DECALS

- The following safety decals are installed on the machine. If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

(1) Part No. TA040-4965-2



! DANGER

TO AVOID POSSIBLE INJURY OR DEATH FROM A MACHINE RUNAWAY.

1. Do not start engine by shorting across starter terminals or bypassing the safety start switch. Machine may start in gear and move if normal starting circuitry is bypassed.
2. Start engine only from operator's seat with transmission and PTO OFF. Never start engine while standing on the ground.

(2) Part No. 32751-4921-2

! WARNING

TO AVOID SERIOUS PERSONAL INJURY OR DEATH:

1. Keep tractor seat in forward position except when operating backhoe.
2. Using seat in reversed position while operating attachments other than backhoe may result in entanglement with PTO shaft or 3-point hitch.

(3) Part No. TA040-4959-3



! WARNING

TO AVOID PERSONAL INJURY.

1. Keep PTO shield in place at all times.
2. Do not operate the PTO at speeds faster than the speed recommended by the implement manufacturer.
3. For trailing PTO-driven implements, set drawbar at towing position. (see operator's manual)

(4) Part No. TA040-4935-1

! WARNING

TO AVOID PERSONAL INJURY:

1. Attach pulled or towed loads to the drawbar only.
2. Use the 3-point hitch only with equipment designed for 3-point hitch usage.

(5) Part No. TA040-4958-1

Do not touch hot surface like muffler, etc.





(6) Part No. 6C150-4743-1 (HST type)

WARNING



BEFORE DISMOUNTING TRACTOR:

1. ALWAYS SET PARKING BRAKE. Leaving transmission in gear with the engine stopped will not prevent tractor from rolling.
2. PARK ON LEVEL GROUND WHENEVER POSSIBLE. If parking on a slope, position tractor across the slope.
3. LOWER ALL IMPLEMENTS TO THE GROUND.
4. STOP THE ENGINE.


(7) Part No. 6C040-4741-2
No fire

T12011ZZ00100

12010Z00150

KiSC issued 04, 2006 A

(8) Part No. 32771-4925-1

WARNING**TO AVOID PERSONAL INJURY OR DEATH FROM ROLL-OVER :**

1. Kubota recommends the use of a Roll-Over Protective structures (ROPS) and seat belt in almost all applications.
2. To ensure ROPS protection, do not operate tractor without loader mainframe.
3. Never use just the seat belt or just the ROPS. They must be used together. For further details, consult your Operator's Manual or your local dealer.

(9) Part No. 32751-4958-1
Stay clear of engine fan and fanbelt.

(10) Part No. 6C040-4742-2

CAUTION**TO AVOID PERSONAL INJURY:**

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Lock the two brake pedals together before driving on the road.
8. Slow down for turns, or rough roads, or when applying individual brakes.
9. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
10. Pull only from the drawbar.
11. Before dismounting, lower the implement to the ground, set the parking brake, stop the engine and remove the key.
12. Securely support tractor and implements before working underneath.

(11) Part No. 6C140-4746-1

WARNING**TO AVOID PERSONAL INJURY:**

Do not modify or repair a ROPS because welding, grinding, drilling or cutting any portion may weaken the structure.



(12) Part No. 6C040-5559-1

DANGER EXPLOSIVE GASES

Cigarettes, flames or sparks could cause battery to explode. Always shield eyes and face from battery. Do not charge or use booster cables or adjust post connections without proper instruction and training.

KEEP VENT CAPS TIGHT AND LEVEL**POISON CAUSES SEVERE BURNS**

Contains sulfuric acid. Avoid contact with skin, eyes or clothing. In event of accident flush with water and call a physician immediately.

KEEP OUT OF REACH OF CHILDREN**CARE OF DANGER, WARNING AND CAUTION LABELS**

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels from your local KUBOTA Distributor.
4. If a component with danger, warning or caution label (s) affixed is replaced with new part, make sure new label (s) is (are) attached in the same location (s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

T12011ZZ00200

12010Z00160

SPECIFICATIONS

Model	B21	
PTO power	10.0 kW (13.5 HP)	
Engine	Maker	KUBOTA
	Model	D1005-ETLB
	Type	Indirect Injection. Vertical, water-cooled, 4-cycle diesel
	Number of cylinders	3
	Bore and stroke	76 x 73.6 mm (2.99 x 2.90 in.)
	Total displacement	1001 cm ³ (61.1 cu.in.)
	Engine net power (DIN)	15.7 kW (21.0 HP)
	Rated revolution (min ⁻¹)	43.3 r/s (2600 rpm)
	Maximum torque	59 N·m (44 ft-lbs)
	Battery	12 V, RC : 79 min, CCA : 433 A
Capacities	Starting system	Electric starting with cell starter 12 V, 1.0 kW
	Lubricating system	Forced lubrication by trochoidal pump
	Cooling system	Pressurized radiator, forced circulation with water pump
	Fuel	Diesel fuel No. 2-D [above -10 °C (14 °F)], Diesel fuel No. 1 [below -10 °C (14 °F)]
	Fuel tank	24 L (6.3 U.S.gals, 5.3 Imp.gals)
Dimensions	Engine crankcase (with filter)	3.0 L (3.2 U.S.qts, 2.6 Imp.qts)
	Engine coolant	3.4 L (3.6 U.S.qts, 2.6 Imp.qts)
	Transmission case	27.5 L (7.26 U.S.gals, 6.05 Imp.gals)
	Front axle case	3.7 L (3.9 U.S.qts, 3.3 Imp.qts)
	Overall length (without 3P)	2495 mm (98.2 in.)
Travelling system	Overall width	1365 mm (53.7 in.)
	Overall height (with ROPS / FOPS)	2260 mm (89.0 in.)
	Overall height (top of steering wheel)	1370 mm (53.9 in.)
	Wheel base	1535 mm (60.4 in.)
	Minimum ground clearance	305 mm (12.0 in.)
	Tread	Front
		Rear
Hydraulic system	Weight (with ROPS, FOPS, main frame and front loader)	1296 kg (2858 lbs)
	Clutch	Dry single plate
PTO system	Tires	Front
		Rear
	Steering	Integral type power steering
	Transmission	Main-hydrostatic transmission, range-gear shift (3 forward and 3 reverse)
	Brake	Wet disk type
	Min. turning radius (without brake)	2.85 m (9.4 feet)
	Differential	Bevel gear
PTO system	Hydraulic control system	Position Control
	Pump capacity	32 L/min (8.5 U.S.GPM, 7.0 Imp.GPM)
	Three point hitch	SAE Category I
	Max. lift force (24 in, behind lift points)	460 kg (1014 lbs)
PTO system	PTO shaft	SAE 1-3/8, 6 splines
	Revolution	540 min ⁻¹ (rpm) at 2584 engine min ⁻¹ (rpm)

Note : * Manufacturer's estimate the company reserves the right to change the specifications without notice.

12010Z00020


TRAVELLING SPEED

(At rated engine rpm)

Model		B21	
Tire size (Rear)		12.4-16 R4	
Range gear shift lever		km/h	mph
Forward	Low	0 to 4.7	0 to 2.9
	Middle	0 to 8.0	0 to 5.0
	High	0 to 17.8	0 to 11.1
Reverse	Low	0 to 4.0	0 to 2.5
	Middle	0 to 6.8	0 to 4.2
	High	0 to 15.1	0 to 9.4

12010Z00030

DIMENSIONS




G GENERAL

GENERAL

CONTENTS

[1] FEATURES	G-1
[2] TRACTOR IDENTIFICATION	G-2
[3] GENERAL PRECAUTIONS	G-3
[4] HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING.....	G-3
(1) Wiring.....	G-4
(2) Battery	G-5
(3) Fuse.....	G-6
(4) Connector	G-6
(5) Handling of Circuit Tester	G-7
[5] LUBRICANTS, FUEL AND COOLING WATER	G-8
[6] TIGHTENING TORQUES.....	G-9
(1) General Use Screws, Bolts and Nuts	G-9
(2) Stud Bolts	G-10
(3) Hydraulic Hoses Fitting.....	G-10
[7] MAINTENANCE	G-11
[8] CHECK AND MAINTENANCE.....	G-12
(1) Daily Check.....	G-12
(2) Check Points of Initial 50 Hours.....	G-13
(3) Check Points of Every 50 Hours.....	G-17
(4) Check Points of Every 100 Hours.....	G-20
(5) Check Points of Every 200 Hours.....	G-23
(6) Check Points of Every 300 Hours.....	G-24
(7) Check Point of Every 400 Hours.....	G-25
(8) Check Point of Every 800 Hours.....	G-25
(9) Check Point of Every 1 Year.....	G-26
(10) Check Point of Every 2 Years.....	G-26
(11) Others.....	G-27
[9] SPECIAL TOOLS	G-29
(1) Special Tools for Engine	G-29
(2) Special Tools for Tractor	G-36
[10] TIRES	G-41
(1) Tire Pressure	G-41
(2) Tread	G-41
(3) Tire Liquid Injection.....	G-42
[11] IMPLEMENT LIMITATIONS.....	G-45

[1] FEATURES




12010P00010

- (1) Integral Power Steering
- (2) E-TVCS (Three Vortex Combustion System) Diesel Engine
- (3) Engine Key Shut-Off System
- (4) Hydrostatic Transmission (HST)
- (5) Wet Disc Brake
- (6) The Strong Integrated Frame
- (7) The Hard-Nose Slanted Hood and Front Guard
- (8) Single-Lever Reversible High-Back Seat
- (9) The Backhoe Quickly Attached or Detached
- (10) The Automatic Self-Leveling Loader and Single Lever Operation
- (11) The 3-Point Hitch and the PTO Fitted as Standard Features
- (12) Industrial Tire
- (13) 4 Post ROPS

12010G00010


[2] TRACTOR IDENTIFICATION



When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.


(1) Tractor Identification Plate
(2) Tractor Serial Number

(3) Engine Serial Number
(4) Hour Meter



12010G00020

[3] GENERAL PRECAUTIONS




11790F00050

11790G00030

- During disassembly, carefully arrange removed parts in a clean area to prevent confusion later. Bolts and nuts should be installed in their original position to prevent reassembly errors.
- When special tools are required, use KUBOTA genuine special tools. Special tools which are not frequently used should be made according to the drawings provided.
- Before disassembling or servicing electrical wires, always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before measuring.
- Use only KUBOTA genuine parts for parts replacement to maintain tractor performance and to assure safety.
- Gaskets and O-rings must be replaced during reassembly. Apply grease to new O-rings or oil seals before assembling. See the figure left side.
- When reassembling external snap rings or internal snap rings, they must be positioned so that sharp edge faces against the direction from which a force is applied. See the figure left side.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.

(1) Grease
 (2) Force
 (3) Sharp Edge
 (4) Axial Force
 (5) Rotating Movement

(A) External Snap Ring
 (B) Internal Snap Ring



11790F00060

To ensure safety and prevent damage to the machine and surrounding equipment, heed the following precautions in handling electrical parts and wiring.

■ IMPORTANT


- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not attempt to modify or remodel any electrical parts and wiring.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.

(1) Negative Terminal

(2) Positive Terminal

11790G00041

(1) Wiring




11790F00070

- Securely tighten wiring terminals.

(1) Correct
(Securely Tighten)

(2) Incorrect
(Loosening Leads to Faulty Contact)




11790F00080

- Do not let wiring contact dangerous part.

(1) Wiring (Correct)
(2) Wiring (Incorrect)

(3) Dangerous Part
(4) Dangerous Part

11790G00050




11790F00100

- Securely insert grommet.

(1) Grommet

(A) Correct
(B) Incorrect

11790G00060



11790F00110


- Securely clamp, being careful not to damage wiring.

(1) Clamp
• Wind Clamp Spirally
(2) Wire Harness

(3) Clamp
(4) Welding Dent

11790G00080


11790G00090



- Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag be required.

(1) Wiring
(2) Clamp


(A) Correct
(B) Incorrect



- In installing a part, take care not to get wiring caught by it.

(1) Wiring

(A) Incorrect




- After installing wiring, check protection of terminals and clamped condition of wiring, only then connect battery.

(1) Cover
• Securely Install Cover

11790G00110

11790G00120

(2) Battery




- Take care not to confuse positive and negative terminal posts.
- When removing battery cables, disconnect negative cable first. When installing battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After connecting cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.

CAUTION

- Take care not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before recharging the battery, remove it from the machine.
- Before recharging, remove cell caps.
- Do recharging in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.

11790G00131


(3) Fuse

- Use fuses with specified capacity.
Neither too large or small capacity fuse is acceptable.
- Never use steel or copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse

(2) Fusible Link


11790G00140

(4) Connector

- For connector with lock, push lock to separate.

(A) Push

11790G00150




- In separating connectors, do not pull wire harnesses.
- Hold connector bodies to separate.

(A) Correct

(B) Incorrect


11790G00160



- Use sandpaper to remove rust from terminals.
- Repair deformed terminal. Make certain there is no terminal being exposed or displaced.

(1) Exposed Terminal
(2) Bend Terminal(3) Sandpaper
(4) Rust


11790G00170



- Make certain that there is no female connector being too open.

(A) Correct

(B) Incorrect




- Make certain plastic cover is large enough to cover whole connector.

(1) Cover

(A) Correct

(B) Incorrect



- Use tester correctly following manual provided with tester.
- Check for polarity and range.

11790F00210

11790G00200

[5] LUBRICANTS, FUEL AND COOLING WATER

No.	Place	Capacity	Lubricants, fuel and cooling water
1	Fuel tank	24 L 6.3 U.S.gals. 5.3 Imp.gals.	No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below - 10 °C (14 °F)
2	Cooling system	3.2 L 3.4 U.S.qts. 3.0 Imp.qts.	Fresh clean water with anti-freeze
3	Engine crankcase	3.0 L 3.2 U.S.qts. 2.6 Imp.qts	Engine oil : API Service CC or CD Below 0 °C (32 °F) SAE10W, 10W-30 or 10W-40 0 to 25 °C (32 to 77 °F) SAE20, 10W-30 or 10W-40 Above 25 °C (77 °F) SAE30, 10W-30 or 10W-40
4	Transmission case	27.5 L 7.26 U.S.qts. 6.05 Imp.qts.	KUBOTA SUPER UDT fluid *
5	Front axle case	3.7 L 3.9 U.S.qts. 3.3 Imp.qts	KUBOTA SUPER UDT fluid * or SAE80, 90 gear oil

Greasing

No.	Place	No. of greasing point	Capacity	Type of grease
6	Speed control pedal (HST pedal)	1	Until grease overflows	Multipurpose type grease
	Battery terminal	2	Moderate amount	
	Lift rod	1		
	Seat adjuster	—		
	Seat lock pin	—		

* KUBOTA original transmission hydraulic fluid.

12010G00030

[6] TIGHTENING TORQUES

(1) General Use Screws, Bolts and Nuts

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to the table below.

Indication on top of bolt	No-grade or 4T						7T						9T		
Material of bolt	SS400, S20C						S43C, S48C						SCr435, SCM435		
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Unit Diameter	N·m	kgf·m	ft-lbs												
M6 (6 mm, 0.24 in.)	7.85 to 9.31	0.80 to 0.95	5.79 to 6.87	7.85 to 8.82	0.80 to 0.90	5.79 to 6.50	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31	7.85 to 8.82	0.80 to 0.90	5.79 to 6.50	12.3 to 14.2	1.25 to 1.45	9.05 to 10.4
M8 (8 mm, 0.31 in.)	17.7 to 20.5	1.8 to 2.1	13.1 to 15.1	16.7 to 19.6	1.7 to 2.0	12.3 to 14.4	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2	17.7 to 20.5	1.8 to 2.1	13.1 to 15.1	29.5 to 34.3	3.0 to 3.5	21.7 to 25.3
M10 (10 mm, 0.39 in.)	39.3 to 45.1	4.0 to 4.6	29.0 to 33.2	31.4 to 34.3	3.2 to 3.5	23.2 to 25.3	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5	60.9 to 70.6	6.2 to 7.2	44.9 to 52.0
M12 (12 mm, 0.47 in.)	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5				77.5 to 90.2	7.9 to 9.2	57.2 to 66.5	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5	103 to 117	10.5 to 12.0	76.0 to 86.7
M14 (14 mm, 0.55 in.)	108 to 125	11.0 to 12.8	79.6 to 92.5				124 to 147	12.6 to 15.0	91.2 to 108				167 to 196	17.0 to 20.0	123 to 144
M16 (16 mm, 0.63 in.)	167 to 191	17.0 to 19.5	123 to 141				197 to 225	20.0 to 23.0	145 to 166				260 to 304	26.5 to 31.0	192 to 224
M18 (18 mm, 0.71 in.)	246 to 284	25.0 to 29.0	181 to 209				275 to 318	28.0 to 32.5	203 to 235				344 to 402	35.0 to 41.0	254 to 296
M20 (20 mm, 0.79 in.)	334 to 392	34.0 to 40.0	246 to 289				368 to 431	37.5 to 44.0	272 to 318				491 to 568	50.0 to 58.0	362 to 419

11790G00761

American standard cap screws with UNC or UNF threads.

Grade	SAE grade 5 or 8		
Unit Size	N·m	kgf·m	ft-lbs
1/4	9.8 to 11.7	1.0 to 1.2	7.2 to 8.6
5/16	19.0 to 23.1	1.9 to 2.4	14 to 17
3/8	33.9 to 40.7	3.5 to 4.2	25 to 30
1/2	88.1 to 105.8	9.0 to 10.8	65 to 78
9/16	122.0 to 146.4	12.4 to 14.9	90 to 108
5/8	176.3 to 211.5	18.0 to 21.6	130 to 156

12010G00040

(2) Stud Bolts

Material of opponent part	Ordinariness			Aluminum		
	N·m	kgf·m	ft-lbs	N·m	kgf·m	ft-lbs
M8 (8 mm, 0.31 in.)	11.8 to 15.6	1.2 to 1.6	8.68 to 11.5	8.82 to 11.8	0.90 to 1.2	6.51 to 8.67
M10 (10 mm, 0.39 in.)	24.6 to 31.3	2.5 to 3.2	18.1 to 23.1	19.7 to 25.4	2.0 to 2.6	14.5 to 18.8
M12 (12 mm, 0.47 in.)	29.5 to 49.0	3.0 to 5.0	21.7 to 36.1	31.4	3.2	23.1

11790G00762

(3) Hydraulic Hoses Fitting

Item	Thread size	Tightening torque		
		N·m	kgf·m	ft-lbs
Adjustable elbow	9/16	37 to 44	3.7 to 4.6	27 to 33
	3/4	47 to 54	4.8 to 5.5	35 to 40
Hose fitting and flare nut	9/16	22 to 25	2.2 to 2.6	16 to 19
	3/4	35 to 41	3.6 to 4.1	26 to 30
Adaptor (NPT)	3/8	39 to 44	3.9 to 4.4	28 to 32
	1/2	49 to 58	5.0 to 5.9	36 to 43

NOTE : When connecting a hose with flare nut, after tightening the nut with specified torque, return it approximetary 45 degrees and re-tighten it to specified torque.

12010G00050

[7] MAINTENANCE

No.	Item	Period	Indication on hour meter																After purchase		Reference page	
			50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	1 year	2 years		
1	Engine oil	Change	★	☆		☆		☆		☆		☆		☆		☆		☆			G-13	
2	Engine oil filter	Replace	★			☆			☆				☆				☆				G-13	
3	Transmission fluid	Change	★					☆					☆								G-15	
4	Hydraulic oil filter	Replace	★			☆			☆			☆			☆			☆			G-14	
5	Hydraulic oil filter for HST	Replace	★			☆			☆			☆			☆			☆			G-14	
6	Oil strainer for HST	Clean	★					☆					☆			☆					G-15	
7	Front axle case oil	Change						☆					☆			☆					G-25	
8	Front axle pivot	Adjust							☆										☆		G-25	
9	Engine start system	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆			G-18	
10	Greasing	—	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆			G-17	
11	Wheel bolt torque	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆			G-19	
12	Battery condition	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆			G-19	
13	Air cleaner element [Double type]	Primary element	Clean		☆		☆		☆		☆		☆		☆		☆		☆			G-21
		Replace																		☆		G-21
		Secondary element	Replace																	☆		G-21
14	Fuel filter element	Clean		☆		☆		☆		☆		☆		☆		☆		☆		☆		G-21
		Replace								☆									☆			G-25
15	Fan belt	Adjust		☆		☆		☆		☆		☆		☆		☆		☆		☆		G-22
16	Clutch	Adjust	★	☆		☆		☆		☆		☆		☆		☆		☆		☆		G-16
17	Brake	Adjust		☆		☆		☆		☆		☆		☆		☆		☆		☆		G-22
18	Fuel line	Check		☆		☆		☆		☆		☆		☆		☆		☆		☆		G-23
		Replace																		☆		G-23
19	Radistor hose and clamp	Check			☆			☆				☆			☆			☆			G-24	
		Replace																		☆		G-24
20	Toe-in	Adjust			☆			☆			☆			☆			☆			☆		G-24
21	Engine valve clearance	Adjust																	☆			G-25
22	Cooling system	Flush																		☆		G-26
23	Coolant	Change																		☆		G-26
24	Fuel system	Bleed																				G-27
25	Fuse	Replace																				G-28
26	Light bulb	Replace																				G-28

IMPORTANT :

The jobs indicated by ★ must be done after the first 50 hours of operation.

* Air cleaner should be cleaned more often in dusty conditions than in normal conditions.

** Consult your local KUBOTA dealer for this service.

12010G00060

[8] CHECK AND MAINTENANCE

CAUTION

- Be sure to check and service the tractor on a flat place with engine shut off, the parking brake on and chock the wheels.

11790G00210

(1) Daily Check

To prevent trouble from occurring, it is important to know the condition of the tractor. Check the following items before starting.

Checking

- Check areas where previous trouble was experienced.
- Walk around the tractor.

- 1) Check the tire pressure, and check for wear and damage.
- 2) Check for oil and water leaks.
- 3) Check the engine oil level.
- 4) Check the transmission fluid level.
- 5) Check the coolant level.
- 6) Check the condition of seat belt and ROPS/FOPS attaching hardware..
- 7) Check and clean the radiator screen and grill.
- 8) Check the bolts and nuts of the tires are tight.
- 9) Check the number plate or SMV emblem for damage and cleaner replace as necessary if equipped.
- 10) Care of danger, warning and caution labels.
- 11) Clean around the exhaust manifold and the muffler of the engine.

- While sitting in the operator's seat.

- 1) Check the HST pedal, brake pedals and clutch pedal.
- 2) Check the parking brake.
- 3) Check the steering wheel.

- Turning the key switch.



- 1) Check the performance of the easy checker lights.
- 2) Check head lights, tail lights and hazard lights. Clean if necessary.
- 3) Check the performance of the meters and gauges.

- Starting the engine.

- 1) Check to see that the lights on the Easy Checker go off.
- 2) Check the color of the exhaust gas.
- 3) Check the brakes for proper operation.

12010G00070

(2) Check Points of Initial 50 Hours



Changing Engine Oil

CAUTION

- Before changing oil, be sure to stop the engine.

1. Start and warm up the engine for approx. 5 minutes.
2. Place an oil pan underneath the engine.
3. To drain the used oil, remove the drain plug (1) at the bottom of the engine and drain the oil completely.
4. Screw in the drain plug (1).
5. Fill new oil up to upper line on the dipstick (2).

IMPORTANT

- When using an oil of different manufacture or viscosity from the previous one, remove all of the old oil.
- Never mix two different types of oil.
- Use the proper SAE Engine Oil according to ambient temperatures.
- Refer to "LUBRICANTS, FUEL AND COOLING WATER". (See page G-8.)

Engine oil capacity	3.0 L 3.2 U.S.qts 2.6 Imp.qts
---------------------	-------------------------------------

(1) Drain Plug
(2) Dipstick
(3) Oil Inlet

(A) Oil level is acceptable within this range.

12010G00080

Replacing Engine Oil Filter Cartridge

CAUTION

- Be sure to stop the engine before changing oil filter cartridge.


1. Remove the oil filter cartridge with the filter wrench.
2. Apply a slight coat of oil onto the cartridge gasket.
3. To install the new cartridge, screw it in by hand. Over tightening may cause deformation of rubber gasket.
4. After the new cartridge has been replaced, the engine oil normally decrease a little. Thus see that the engine oil does not leak through the seal and be sure to read the oil level on the dipstick. Then, replenish the engine oil up to the specified level.


IMPORTANT

- To prevent serious damage to the engine, replacement element must be highly efficient. Use only a KUBOTA genuine filter or its equivalent.

(1) Engine Oil Filter

12010G00090





Replacing Hydraulic Oil Filter Cartridge


CAUTION

- **Be sure to stop the engine before changing the oil filters.**
- 1. Drain the transmission fluid.
- 2. Remove the protect cover (2) of hydraulic oil filter.
(Filter for main hydraulic circuit)
- 2. Remove the seat under cover.
(Filter for HST circuit)
- 3. Remove the oil filter cartridge by using a filter wrench.
- 4. Apply a slight coat of oil onto the cartridge gasket.
- 5. To install the new cartridge, screw it in by hand. Over tightening may cause deformation of rubber gasket.
- 6. After the new cartridge has been replaced, the transmission fluid level will normally decrease slightly. Make sure that the transmission fluid does not leak through the seal. Check the fluid level.


IMPORTANT

- **To prevent serious damage to the hydraulic system, the replacement filter must be a highly efficient, 60 μm filter for main filter and 10 μm filter for HST. Use only a genuine KUBOTA filter or its equivalents.**
- **When using the auxiliary hydraulics, replace the transmission oil filter cartridge after initial 50 service hours.**


(1) Hydraulic Oil Filter (for Main Circuit) (3) Wing Bolt
 (2) Protect Cover (4) Hydraulic Oil Filter (for HST Circuit)




12010G00100



12010F10100



12010F40020



12010F10110P

Changing Transmission Fluid

CAUTION

- Be sure to stop the engine checking and changing the transmission fluid.
- 1. Place an oil pan under the tractor.
- 2. Remove the drain plugs (1) at the bottom of the rear axle cases and oil tank.
- 3. Drain the transmission fluid.
- 4. After draining, screw in the three drain plugs.
- 5. Fill new oil from filling port after removing the filling plug (2) up to the upper notch on the dipstick.
- 6. After running the engine for a few minutes, stop it and check the oil level again, if low, add oil prescribed level.

IMPORTANT

- Use only multi-grade transmission oil. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS AND FLUID" (See page G-8).
- Never work the tractor immediately after changing the transmission oil. Keeping the engine at medium speed for a few minutes to prevents damage to the transmission.
- Do not mix different blends oil together.

Transmission fluid capacity	27.5 L 7.26 U.S.gals. 6.05 Imp.gals.
-----------------------------	--

(1) Drain Plug
(2) Filling Plug
(3) Dipstick

(A) Oil level acceptable within this range.

12010G00110


Cleaning Oil Strainer for HST Charge Pump

1. Disconnect the suction hose (1) from strainer (3).
2. Remove the lock plate (2) and then pull out the strainer from oil tank.
3. Clean the strainer with nonflammable solvent.


NOTE

- When changing the transmission fluid, disassemble and rinse the strainer with nonflammable solvent to completely clean off fillings. When reassembling, be careful not to damage the parts.
- Since the fine fillings in the oil could impair the component parts of the hydraulic system precision built to withstand high pressure, the suction line end is provided with an oil strainer.

(1) Suction Hose
(2) Lock Plate
(3) Strainer
(4) O-ring




12010F00100



12010F00110

12010G00120



Checking Clutch Pedal Free Travel


CAUTION

- When checking, park the tractor on flat ground, apply the parking brake, stop the engine and remove the key.

1. Slightly depress the clutch pedal (3) and measure free travel at top of pedal stroke.
2. If the measurement is not within the factory specifications, loosen the lock nut (2) and adjust the clutch rod (1) length.
3. After adjusting it, be sure to keep the following distance for clutch pedal stopper bolt (4).
4. After adjusting them, try to start engine. If no start, check the safety switch setting position.


Clutch pedal free travel	Factory spec.	20 to 30 mm 0.8 to 1.2 in.
Stopper bolt distance : "A"	Factory spec.	8.5 mm 0.3 in.

(1) Clutch Rod
 (2) Lock Nut
 (3) Clutch Pedal
 (4) Clutch Pedal Stopper Bolt
 (5) Clutch Housing



12010G00130




(3) Check Points of Every 50 Hours





Greasing

1. Apply a grease to the following position as figures.

(1) Grease Fitting (HST Pedal)	(4) Seat Lock Pin
(2) Battery Terminals	(5) Seat Adjuster
(3) Grease Fitting (Lifting Rod RH)	



12010G00140



Checking Engine Start System Tractor

(Serial No.60970 and below)

CAUTION

- Do not allow anyone near the tractor while testing.
- If the tractor does not pass the test do not operate the tractor.

■ Preparation before testing

1. Sit on operator's seat.
2. Set the parking brake and stop the engine.
3. Shift the range gear shift lever in "NEUTRAL" position.
4. Shift the PTO gear shift lever to "OFF" position.
5. Fully depress the clutch pedal.

■ Test 1 : for safety switch on the clutch linkage

1. Release the clutch pedal.
2. Turn the key to "START" position.
3. The engine must not crank.

■ Test 2 : for safety switch on the range gear shift linkage

1. Fully depress the clutch pedal again.
2. Shift the range gear shift lever to "Desired" position.
3. Turn the key to "START" position.
4. The engine must not crank.

■ Test 3 : for safety switch on the PTO gear shift linkage

1. Shift the range gear shift lever to "NEUTRAL" position.
2. Shift the PTO gear shift lever to "ON" position.
3. Turn the key to "START" position.
4. The engine must not crank.

■ After testing :If crank any test of the above, adjust or replace the required safety switch.

When adjusting the safety switches keep the each linkage at condition indicated below.

1. Clutch pedal linkage → Fully depress the clutch pedal.
2. Range gear shift linkage → Shift the range gear shift lever to "NEUTRAL" position.
3. PTO gear shift linkage → Shift PTO gear shift lever to "OFF" position.

Safety switch distance "A"	Factory spec.	19 to 21 mm 0.75 to 0.83 in.
-------------------------------	---------------	---------------------------------

Tightening torque	Safety switch mounting nut	15 to 18 N·m 1.5 to 1.8 kgf·m 11.1 to 13.3 ft-lbs
-------------------	----------------------------	---

(1) Range Gear Shift Levere
(2) PTO Gear Shift Lever

(3) Clutch Pedal

12010G00150