

Product: Kubota WSM KX91-3,KX101-3 Excavator Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/kubota-wsm-kx91-3kx101-3-excavator-service-repair-workshop-manual/>

WSM

WORKSHOP MANUAL KUBOTA EXCAVATOR

KX91-3 KX101-3

The Kubota logo is rendered in a bold, black, stylized font. The letters are thick and blocky, with a distinctive shape for the 'u' and 'o' characters.

Sample of manual. Download All 610 pages at:
<https://www.arepairmanual.com/downloads/kubota-wsm-kx91-3kx101-3-excavator-service-repair-workshop-manual/>

Code No.97899-60520

Product: Kubota WSM KX91-3,KX101-3 Excavator Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/kubota-wsm-kx91-3kx101-3-excavator-service-repair-workshop-manual/>

Sample of manual. Download All 610 pages at:
<https://www.arepairmanual.com/downloads/kubota-wsm-kx91-3kx101-3-excavator-service-repair-workshop-manual/>

CONTENTS

I General

II Machine body

- Mechanism Section II-M-1
- Service Section II-S-1

III Engine

- Mechanism Section III-M-1
- Engine WSM (Addition)

IV Hydraulic System

- Mechanism Section IV-M-1
- Service Section IV-S-1


V Electrical System

- Mechanism Section V-M-1
- Service Section V-S-1

VI Optional Units


I. General

A. Body and engine identification marks	I-S-3
B. Safety precautions for servicing, disassembly and reassembly.	I-S-4
a. Safety measures before starting work	I-S-4
b. Safety measures during work.	I-S-4
c. Preparation for disassembly.	I-S-5
d. Precautions for disassembly and reassembly	I-S-5
C. IMPORTANT SAFETY PROCESS AND CRITICAL FUNCTIONAL PROCESS	I-S-6
a. Essential Adhesives	I-S-6
b. Important Safety Process	I-S-6
c. Important Critical Functional Process	I-S-6
D. IMPORTANT INSPECTION ITEMS AFTER REASSEMBLING.	I-S-6
E. SERVICING FUNDAMENTALS.	I-S-7
a. Items for Servicing	I-S-7
b. O-ring, Oil seal, Circlip and Roll Pin.	I-S-9
c. Piping	I-S-11



A. Body and engine identification marks

If trouble should occur during use, or if servicing is necessary, contact the dealer who handles the machine. At the time please inform the dealer of
(1) Model of machine and serial number



KE, KDG, KUK Version


KUBOTA CORP.		CE
2-47 SHIKITSU HIGASHI 1-CHOME NANIWAKU OSAKA JAPAN		
MODEL <input type="text"/>	SERIAL NO <input type="text"/>	
MASS <input type="text"/> Kg	MAX. DRAW BAR PULL <input type="text"/> KN	
POWER <input type="text"/> KW	MAX. VERT. LOAD <input type="text"/> KN	
MANUFACTURED YEAR <input type="text"/>	MADE IN JAPAN	

L-3338


KTC, KCL, KTA Version

EXCAVATOR	
MODEL	<input type="text"/>
SERIAL No.	<input type="text"/>
ENGINE No.	<input type="text"/>
KUBOTA Corporation JAPAN	

2) Machine serial number



(3) Engine serial number



B. Safty precautions for servicing, disassembly and reassembly

Safty precautions for servicing

Most accidents during servicing arise from carelessness. Please remember that safty involves both the welfare of the employees and improved work efficiency.

Safty precautions for Disassembly and reassembly

Machines must be diassembled and assembled efficiently and safty.

It is very important to thoroughly understand the construction and function of the machine, to make all appropriate preparations, and start operations according to the specified working procedures.

a. Safty measures before starting work

(1) Work clothes

1. Wear specified work cap and clothed. (Under no circumstances may workers wear undershirts only.)
Cuffs must be kept buttoned, and any tears must be mended.)
2. Wear safety shoes.
3. Do not wear cotton gloves when working on the internal section of engine, reduction gears or hydraulic units for repair or others, or when using a hammer. Wear leather gloves, however, when hoisting wires.

(2) Inspecting equipment and tools

1. Prepare equipment (cranes, fork lifts, tool, etc.) required for servicing and inspect for any problems before starting work.
2. Hammer heads (metal parts) must be firmly secured to their handles.
3. Check hosting tools (wire ropes, hoisting chains, etc.) before use.

(3) Keep workshop in order

1. Secure appropriate space needed for disassembly to the job.
2. Secure a clean, safe place for arranging disassembled parts.
3. Store volatile substances (gasoline, light oil, thinner, oily articles, etc.) in appropriate containers at selected locations to prevent fire hazards.

b. Safty measures during work

(1) Protectors

1. Wear goggles when using chisels for chipping.
2. Use appropriate protectors during welding.
3. Wear a helmet when working with a crane or at elevated locations.

(2) Team work

1. When working with two or more people, divide the work and maintain close communication.
2. Crane work must be carried out using predetermined signals.

(3) Disassembly and assembly

1. Do not wear gloves when using hammers.
2. Use rods of the specified soft material for removing pins. Do not use a hammer as a pad.
3. Do not place fingers in holes when centering.
4. Heavy parts must be adequately supported before removing bolts.

(4) Cranes

1. In principle, use a crane for objects heavier than 44lb (20kg).
2. Crane operation and hoisting must be performed only by qualified personal.
3. Pay careful attention to the center of gravity when hoisting, and do not stand under the lifted objects.

(5) Others

1. To work under a jacked-up carrier, be sure to place wood pieces under it.
2. When charging batteries, make sure there are no open flames in the immediate vicinity.
3. All electric tools must be grounded.
4. Before welding the machine, remove the battery.
 - When removing the battery, be sure to disconnect negative (-) cord first.
 - When mounting the battery, be sure to connect the positive (+) cord first.

c. Preparation for disassembly

(1) Cleaning

Remove mud and dirt from the body before disassembly.

(2) Acceptance inspection

The machine must be checked before it is disassembled to record existing conditions, such as those listed below.

Model, serial number, and hourmeter reading

- Reason for repair and repair history
- Element stains
- Fuel and oil condition
- Parts damage *(Take photographs if necessary.)

(3) Equipment and tools

prepare equipment, tools, cranes and parts storage racks as required.

d. Precautions for disassembly and reassembly

(1) Disassembly

1. Follow the specified disassembly procedures.
2. Make alignment marks to insure correct reassembly.
3. Arrange disassembled parts in an orderly way, and attach identification tags or put marks if needed.

(2) Reassembly

1. Clean all parts before assembly. Repair any scratches or dents. Take special precautions against dirt and dust.
2. Parts with rust-preventive coatings must be assembled only after removing the coating.
3. Separated parts must be correctly reassembled using alignment marks.
4. As a rule, use a press to reassemble bearings, bushing and oil seals. Use pads when using a hammer.

C.IMPORTANT SAFTY PROCESS AND CRITICAL FUNCTIONAL PROCESS

The following instructions are related to essential adhesives, important safety process **S** and critical functional process **A** .Pay special attention in servicing these process. (Pay also close attention in reconnecting the electrical cables.)

a. Essential Adhesives

Type of screw adhesive

- Unless otherwise specified, use Three-Bond 1324 adhesive (medium-duty type).

Keep the screw threads free of oil and water.

Type of instantaneous adhesive

- Use Three-Bond 1733 or Three-Bond 1741E adhesive.

Keep the bond areas free of oil and water.

b. Important Safety Process **S** .

1. Reconnecting the fuel hose (clearance, hose routes, clamps, etc.)
2. Electrical cabling (engine, instrument panal, controls, etc.) (wiring routes, clamps and couplers)

c. Important Critical Functional Process **A** .

1. Setting up the travel wheel motor (tightening torque)
2. Reassembling the rotary joints (joint direction and shaft set-up)
3. Installing the swivel base bearing and the swivel motor (tightening torque)
4. Fitting the pump couplings (tightening torque)

D.IMPORTANT INSPECTION ITEMS AFTER REASSEMBLING

a Operate the Machine and check for Unusual Noise and Vibrations.


b Make Sure the Safety decals and Wireharness Clamps are in their Specified Positions.

c With the Machine Front in a Specified Posture, Check the Amount of Hydrauric Oil

Checking the oil level (For further details, refere to the Operation Manual of each model.)




- 1) Park the machine on a level ground.
- 2) Make sure the hydrauric oil temprature is in the range of 10-30°C (50-86°F) and see if the oil level is within the specified zone of the oil level gauge.
- 3) Keep the machine front as shown as following posture.

Posture: Extend the rods of the arm and bucket cylindrs nealy half. Place the bucket on the ground, the offset swing at the center, and the dozer also on the ground.



E.SERVICING FUNDAMENTALS

Locking adhesive




a.Items for Servicing

- 1) Tighten bolts, nuts, adapters, and similar parts to their specified torques which are given in the list of tightening torques and adhesive as well as in this manual. Be sure to observe the specified torques for important tightened parts and components.
- 2) Wipe out water, oil and grease off the screws on which loctite adhesive is to be applied. Be sure to apply the adhesive to specified locations.


Liquid color	Feature
Red	Heavy-duty
Blue	Medium-duty

The word "LOCTITE" in this manual denotes the red-color type.


- 3) Precautions in disassembling the hydraulic equipment
 - Use a vacuum pump, pulgs, oil pans, waste cloth and the like to prevent oil from running out or splashing.
 - Wipe out leaking oil completely first and then add oil as required.
 - Protect the openings with plugs, covers or the like to keep off foreign matters. Most of hydraulic system troubles are caused by the entry of foreign matters.
 - Before reassembling, clean up the parts and components and apply hydraulic oil on them.
 - The system consists of precision parts. Be careful not to scratch them and apply excessive force on them.




- 4) Precautions in tightening hoses and pipes.
- Flexible hoses have a slight natural bend of their own. Utilize the natural bend. Be also careful not to twist them.
 - Be careful not to confuse the routes of the hoses.
 - Do not hold the hoses in tight contact with their adjacent parts and surfaces.



- Tightening steps
 1. First tighten the nut to its specified torque.
 2. Then loosen the nut by about 45° to fit the seat of the joint to the connection.



- 5) The quantities of oil, fuel, water and others, except for the oil to be filled in the track rollers and idlers, are listed just as reference. Fill up the fluid up to the specified center level of a level gauge if it is provided.




- 6) Security support the machine with a jack and a supporting jig when it is jacked up for servicing.
- 7) Be sure to use a crane in disassembling and reassembling heavy parts and components (frame, front attachment, crawler, etc.).

b.O-ring, Oil seal, Circlip and Roll Pin



(1) General precautions

- Make sure the O-ring and the oil seal are free of anything unusual (uneven surface, scratches, chipping, etc.).
- Check the O-ring groove for burrs. Correct, if any, using an oil stone or the like.
- When putting a part past a sharp edge into position, protect such edge with a cover or get the part chamfered.




(2) O-ring



- Clean up the O-ring groove and deburr its edge as required.
- Before installing the ring, be sure to apply lubricant (grease) over it. (Do not do this to the floating seal.)
- Fit the O-ring into its groove without twist. With your fingertip, push the ring gently and evenly into the final position. Otherwise the ring would easily get twisted in contact with the inner edge of the groove.



(3) Floating seal

- Be sure to wipe oil off the O-ring and the O-ring contact surface. (Note, however, that oil must be applied thinly over those of the wheel motor.)
- In fitting the O-ring into the floating seal, be careful not to twist the O-ring.
- Before installing the floating seal together with the O-ring, apply sealing oil thinly over the sliding surface. Be careful to keep the sliding surface and O-ring in alignment with the housing.
- Finally turn the floating seal 2 or 3 times by hand in order to form an oil film over the sliding surface as well as to get the sealing surface well it.






(4) Oil seal

- Do not confuse the orientation of the oil seal lips. Direct the main lip toward the oil chamber; in other word, toward what is to be sealed.


- | | |
|-------------------------|-------------------------|
| a. Packing | f. Dustproof lip |
| b. Metal ring | g. Atmosphere (outside) |
| c. Spring | h. Grease |
| d. Main lip | |
| e. Oil chamber (inside) | |

- If in dry state, the oil seal may wear out when running in the machine. To prevent this, be sure to apply lubricant (grease) over the lip sliding surface. If provided also with a dustproof lip, fill the space between this lip and the main lip with grease.
- As a rule, use a press to press-fit the oil seal. If not available, apply a suitable tool and tap it evenly without allowing any tilt. Press-fit the oil seal deep down to the bottom of the oil seal fitting boss.



(5) Mounting the circlip

- Place the circlip with its sharp edge facing outward (in the locking direction).
- Fit the circlip securely in the groove. For the hole circlip in particular, install and turn it slightly to make sure it fits well.



(6) Tapping the roll pin (spring pin)

- Place the roll pin (spring pin) with its opening perpendicular to the load.
- Place the roll pin (spring pin) with its opening in the turning direction.
- Evenly tap the roll pin (spring pin) into position.

c. Piping

(1) General precautions

- Tightening the pipe socket to the specified torque. If too tight, the socket itself or a hydraulic component may get damaged. If too loose, an oil leak may result.
- In connecting a new hose or pipe, tighten its nut first to the specified torque and then turn it back (about 45°). Then tighten it again to the specified torque. (Do not do this to the sealing tape-applied hose or pipe.)
- When disconnecting a vertical hose or pipe, separate its bottom connection first.
- In disconnecting and reconnecting the hose and pipe, be sure to use two wrenches. With one wrench, restrain the mating part to allow no twist.
- Check the mating connector's sleeve and the hose's taper for dust deposits and scratches.
- When the pipe socket has been tightened up, wipe the joint clean. Apply the maximum operating pressure 2 or 3 times to make sure there is no oil leak.

(2) Hydraulic hose

Check the hydraulic hose for too tight a connect or twist.


* Excessively tight contact

Let's suppose that a hose is in contact with another hose or other part. If the hose is pulled away by a force of 2 kg but still in contact, it means the contact is too tight.


(3) Precautions in tightening the bolts and nuts

- Use bolts of specified length.
- Do not over tighten the bolts: Its threads may get deformed or the fixed part may get damaged. Do not undertighten the bolt either: It may get loose.
- In other words, tighten the bolt to the specified torque.
- Tighten the bolts and nuts diagonally for even tightness.



Top and bottom alternately



Diagonally



Diagonally starting from center



(4) Hose screw

Thread size (piping screw)	Tightening torque N·m kgf·m ft·lbf		Wrench size (reference)
	Union nut section	Taper thread section	
1/8"	7.8 ~ 11.8 N·m 0.8 ~ 1.2 kgf·m 5.8 ~ 8.7 ft·lbf	14.71 ~ 19.61 N·m 1.5 ~ 20 kgf·m 10.85 ~ 14.47 ft·lbf	17 mm 0.67 in
1/4"	24.5 ~ 29.4 2.5 ~ 3.0 18.1 ~ 21.7	36.3 ~ 44.1 3.7 ~ 4.5 26.8 ~ 32.5	19 mm 0.75 in
3/8"	49.0 ~ 53.9 5.0 ~ 5.5 36.2 ~ 39.8	49.0 ~ 68.6 5.0 ~ 7.0 36.2 ~ 50.6	22 mm 0.87 in
1/2"	58.8 ~ 63.7 6.0 ~ 6.5 43.4 ~ 47.0	83.4 ~ 88.3 8.5 ~ 9.0 61.5 ~ 65.1	27 mm 1.06 in
3/4"	117.7 ~ 127.5 12.0 ~ 13.0 86.8 ~ 94.0	127.5 ~ 147.1 13.0 ~ 15.0 94.0 ~ 108.5	36 mm 1.42 in
1"	137.3 ~ 147.1 14.0 ~ 15.0 101.3 ~ 108.5	147.1 ~ 166.7 15.0 ~ 17.0 108.5 ~ 123.0	41 mm 1.61 in

Metric Size Hose

Thread size (piping screw)	Torque N·m kgf·m ft·lbf
M12 × 1.5	20 ~ 30 2.0 ~ 3.1 14.75 ~ 22.13
M14 × 1.5	20 ~ 30 2.0 ~ 3.1 14.75 ~ 22.13
M16 × 1.5	30 ~ 50 3.1 ~ 5.1 22.13 ~ 36.9
M18 × 1.5	30 ~ 50 3.1 ~ 5.1 22.13 ~ 36.9
M22 × 1.5	40 ~ 60 4.1 ~ 6.1 29.5 ~ 44.25

(5) Joint bodies

Thread size (piping screw)	Tightening torque N·m kgf·m ft·lbf		Spanner size (reference)	Remarks Steel pipe (OD)	
	R (tapered thread)	G (straight thread)			
1/8"	19.6 ~ 29.4 N·m 2.0 ~ 3.0 kgf·m 14.5 ~ 21.7 ft·lbf	-	17 mm 0.67 in	When in steel pipe is in use.	8 mm 0.31 in
1/4"	36.3 ~ 44.1 3.7 ~ 4.5 26.8 ~ 32.5	W/O-ring Joint Torque 58.8 ~ 78.5 6 ~ 8 43.4 ~ 57.9	19 mm 0.75 in		12 mm 0.47 in
3/8"	39.2 ~ 49.0 4.0 ~ 5.0 28.9 ~ 36.2	W/O-ring Joint Torque 78.5 ~ 98.1 8 ~ 10 57.9 ~ 72.3	23 mm 0.91 in		15 mm 0.59 in
1/2"	49.0 ~ 68.6 5.0 ~ 7.0 36.2 ~ 50.6	W/O-ring Joint Torque 117.7 ~ 137.3 12 ~ 14 86.8 ~ 101.3	26 mm 1.02 in		16 mm 0.63 in

(6) Tightening torque table for hose clamp (Screw type)

No.	Dia. (mm)	Code No.	Tightening torque N·m kgf·m ft·lbf
1	Ø12 ~ 16	09318-89016	2.5 ~ 3.4 25 ~ 35 1.84 ~ 2.51
2	Ø31 ~ 40	09318-89039	2.5 ~ 3.4 25 ~ 35 1.84 ~ 2.51
3	Ø36 ~ 46	15108-72870	2.5 ~ 3.4 25 ~ 35 1.84 ~ 2.51
4	Ø15 ~ 25	RC101-64580	4.9 ~ 5.9 50 ~ 60 3.61 ~ 4.35
5	Ø26 ~ 38	68311-72820	4.9 ~ 5.9 50 ~ 60 3.61 ~ 4.35
6	Ø13 ~ 20	RB101-63630	3.4 ~ 4.4 35 ~ 45 2.58 ~ 3.31
7	Ø40 ~ 55	35820-15180	4.9 ~ 5.9 50 ~ 60 3.61 ~ 4.35

(7) Nuts for piping

Steel pipe size (O.D. × I.D. × Thickness)	Tightening torque N·m kgf·m ft·lbf	Spanner size (reference)	Remarks
8 × 6 × 1 mm 0.31 × 0.24 × 0.04 in	29.4 ~ 39.2 3.0 ~ 4.0 21.7 ~ 28.9	17 mm 0.67 in	When sleeve nut is in use.
10 × 7 × 1.5 mm 0.39 × 0.28 × 0.06 in	39.2 ~ 44.1 4.0 ~ 4.5 28.9 ~ 32.5	19 mm 0.75 in	
12 × 9 × 1.5 mm 0.47 × 0.35 × 0.06 in	53.9 ~ 63.7 5.5 ~ 6.5 39.7 ~ 47.0	21 mm 0.83 in	
16 × 12 × 2 mm 0.63 × 0.47 × 0.08 in	88.3 ~ 98.1 9.0 ~ 10.0 65.1 ~ 72.3	29 mm 1.14 in	
18 × 14 × 2 mm 0.71 × 0.55 × 0.08 in	127.5 ~ 137.3 13.0 ~ 14.0 94.0 ~ 101.3	32 mm 1.26 in	
27.2 × 21.6 × 2.8 mm 1.07 × 0.85 × 0.11 in	235.4 ~ 254.97 24.0 ~ 16.0 173.6 ~ 188.1	41 mm 1.61 in	

(8) Tightening torque of bolts and nuts

Refer to the tightness torque table below.

Nomial Dia.	Bolts, Nuts	4T 	7T 	9T 
		SS41	S40C, S45C	SCr4
M6		7.8 ~ 9.3 N·m 0.80 ~ 0.95 kgf·m 5.8 ~ 6.9 ft·lbf	9.8 ~ 11.3 N·m 1.00 ~ 1.15 kgf·m 7.2 ~ 8.3 ft·lbf	12.3 ~ 14.2 N·m 1.25 ~ 1.45 kgf·m 9.0 ~ 10.5 ft·lbf
M8		17.7 ~ 20.6 N·m 1.80 ~ 2.10 kgf·m 13.0 ~ 15.2 ft·lbf	23.5 ~ 27.5 N·m 2.40 ~ 2.80 kgf·m 17.4 ~ 20.3 ft·lbf	29.4 ~ 34.3 N·m 3.00 ~ 3.50 kgf·m 21.7 ~ 25.3 ft·lbf
M10		39.2 ~ 45.1 N·m 4.00 ~ 4.60 kgf·m 28.9 ~ 33.3 ft·lbf	48.0 ~ 55.9 N·m 4.90 ~ 5.70 kgf·m 35.4 ~ 41.2 ft·lbf	60.8 ~ 70.6 N·m 6.20 ~ 7.20 kgf·m 44.8 ~ 52.1 ft·lbf
M12		62.8 ~ 72.6 N·m 6.40 ~ 7.40 kgf·m 46.3 ~ 53.5 ft·lbf	77.5 ~ 90.2 N·m 7.90 ~ 9.20 kgf·m 57.1 ~ 66.5 ft·lbf	103.0 ~ 117.7 N·m 10.50 ~ 12.00 kgf·m 75.9 ~ 86.8 ft·lbf
M14		107.9 ~ 125.5 N·m 11.00 ~ 12.80 kgf·m 79.6 ~ 92.6 ft·lbf	123.6 ~ 147.1 N·m 12.60 ~ 15.0 kgf·m 91.1 ~ 108.5 ft·lbf	166.7 ~ 196.1 N·m 17.00 ~ 20.00 kgf·m 123.0 ~ 144.7 ft·lbf
M16		166.7 ~ 191.2 N·m 17.00 ~ 19.50 kgf·m 123.0 ~ 141.0 ft·lbf	196.1 ~ 225.6 N·m 20.00 ~ 23.00 kgf·m 144.7 ~ 166.4 ft·lbf	259.9 ~ 304.0 N·m 26.50 ~ 31.00 kgf·m 191.7 ~ 224.2 ft·lbf
M18		245.2 ~ 284.4 N·m 25.00 ~ 29.0 kgf·m 180.8 ~ 209.7 ft·lbf	274.6 ~ 318.7 N·m 28.00 ~ 32.50 kgf·m 202.5 ~ 235.1 ft·lbf	343.2 ~ 402.1 N·m 35.00 ~ 41.00 kgf·m 253.2 ~ 296.5 ft·lbf
M20		333.4 ~ 392.2 N·m 34.00 ~ 40.00 kgf·m 245.9 ~ 389.3 ft·lbf	367.7 ~ 431.5 N·m 37.50 ~ 44.0 kgf·m 271.2 ~ 318.2 ft·lbf	519.8 ~ 568.8 N·m 53.00 ~ 58.00 kgf·m 383.3 ~ 419.5 ft·lbf


(9) Types and materials of bolts and nuts

[ex. bolts]

Types	Material	Tensile strength	Hardness	Bolt head marking	
4T	SS41	Over 392 MPa 4000 kgf/cm ² 56892 lbf/in ²	H _{RB} 62 ~ 98		No mark or marked 4
7T	S40C S45C	Over 686 MPa 7000 kgf/cm ² 99561 lbf/in ²	H _{RC} 20 ~ 28		Marked 7
9T	SCr4	Over 882 MPa 9000 kgf/cm ² 128007 lbf/in ²	H _{RC} 28 ~ 34		Marked 9

II. Machine body(Mechanism section)





A. Front attachment	II-M-3
a. Greasing points	II-M-3
b. Bucket interchangeability	II-M-4
B. Swivel frame and components	II-M-5
a. Accel lever (Standard-version)	II-M-6
b. Auto idle-version	II-M-7
c. Accel cable	II-M-9
d. Swivel bearing	II-M-10
C. Track frame and components	II-M-11
a. Tension spring pre-set length	II-M-11
b. Additional parts to change from rubber track to iron track	II-M-11
c. Track tension adjustment	II-M-12
d. Grease tension cylinder, L	II-M-13
e. Drive sprocket	II-M-14
f. Rubber track	II-M-15
g. Iron track	II-M-16



A. Front attachment


a. Greasing points

- (1) Keep applying grease until it comes out of the circumference at the other end surface of each rotating part.
- (2) Apply grease to the end surfaces of all the rotating parts and their related shims.



b. Bucket interchangeability

1. The bucket support is the same in dimensions for the three types (KX91-3, 101-3 and U35-3). This means the bucket is interchangeable among the five types.
2. The KX series bucket can be readily installed on the machine. (The KX-3 series pins should be employed.)
3. The bucket shims (for the arms and bucket link couplings) are not used if an old-type bucket is installed. For the KX-3 series bucket, however, be sure to apply these shims.






- (1) Shim(0.5, 1.0mm-outer dia75mm, Inner dia41mm)
- (2) Shim(0.5, 1.0mm-outer dia64mm, Inner dia41mm)
- (3) O-ring ϕ 80mm

KX-3 series bucket	U-35 bucket	KX91-2 bucket	KX-91,101 series bucket
With KX-3 series pins, arms and bucket links			



Attachable		○	○	○	○
Problems when attached	Pin	-	Short in length. Pin stopper bolt position out of alignment → Use the old-type pins.	Same as left	KX-3 series pin.
	O-ring	-	Boss diameter out of spec (L series: 80 mm dia., old type: 90 mm dia.) → Use the specific O-rings.	Boss diameter out of spec (L series: 80 mm dia., old type: 90 mm dia.) → Use the specific O-rings.	Same as left
	Interference between bucket, arm and boom	-	-	-	-

B.Swivel frame and components

KX91-3, 101-3



a. Accel lever (Standard-version)



(1) Engine RPM



Idling
1000~1100 rpm

(2) Accel lever operating force



No load Max. RPM
 KX91-3: 2300~2450 rpm
 KX101-3: 2400~2550 rpm
 Idling to Max., 3.5 kgf
 Max. to idling, 3.5 kgf

b. Auto idle-version


(1) Accel lever side




(2) AI motor side



(3) Engine side




d. Swivel bearing




(NOTE)

1. GREASE : ALVANIA EP-2
2. CLEARANCE - AXIAL : 0.05 ~ 0.12
RADIAL : 0.05 ~ 0.12
3. ROTATING SURFACE HARDNESS : HRC 55~62
4. TOOTH SURFACE HARDNESS : Hs 70~80



5. ROLLING HEAT TREATMENT
QUENCHING & TEMPERING



GEAR DATA	
GEAR PROFILE	STANDARD
MODULE	5.5
PRESSURE ANGLE	20°
NUMBER OF TEETH	80
P.C.D	φ440
ADDENDUM	5.5
DEDENDUM	7.15
WHOLE DEPTH	12.65
OVER PIN SIZE	+1.18 +0.29
dp=φ8.5	4.30, 3.73
GLASS	JIS 7


- | | | |
|----------------|---------------------|-------------------------|
| (1) Outer race | (4) Filler plug φ22 | (7) Seal |
| (2) Inner race | (5) Ball φ19.05 | (8) Grease Nipple PT1/8 |
| (3) Pin φ8 | (6) Support | |

C.Track frame and components

a. Tension spring pre-set length


* Set to the cotter pin closest to the following dimension.

Rubber track




No	Part
(1)	Idler assy
(2)	Plate
(3)	Bolt
(4)	Cylinder assy R
(*)	Cylinder assy L
(5)	Spring assy

Iron track




b. Additional parts to change from rubber track to iron track



No	Part	Code No.	Q'ty
(1)	Guide	RC411-2182-0	4
(2)	Hollar bolt	68541-2118-0	12
(3)	Plate	RC411-2181-0	4
(4)	Bolt	01135-61225	8


* Reposition the nut to change the spring's pre-set length.



Full Download: <https://www.aresairmanual.com/downloads/kubota-wsm-kx91-3kx101-3-excavator-service-repair-workshop-manual/>

Rubber track

Run the rubber track so that its seam marking (∞) should come at the top center with the track idler roller between adjacent links.



Iron track

