

Product: Takeuchi TB175 Mini Compact Excavator Service Repair Workshop Manual(Book No.CL7E001)
Full Download: <https://www.arepairmanual.com/downloads/takeuchi-tb175-mini-compact-excavator-service-repair-workshop-manualbook-no-cl7e001/>

TB175

Hydraulic Excavator

BOOK No. **CL7E001**

WORKSHOP MANUAL

Serial No. **17530001~**

TAKEUCHI

Sample of manual. Download All 474 pages at

<https://www.arepairmanual.com/downloads/takeuchi-tb175-mini-compact-excavator-service-repair-workshop-manualbook-n>

FOREWORD

This manual is intended for persons who engage in maintenance operations, and explains procedures for disassembly and reassembly of the machine, check and maintenance procedures, maintenance reference values, troubleshooting and outline specifications, etc. Please use this manual as a reference in service activities to improve maintenance techniques.

Further, please be advised that items contained in this manual are subject to change without notice due to design modifications, etc.

MACHINE FRONT AND REAR, LEFT AND RIGHT

The end where the dozer blade is mounted is the front and the end with the travel motors is the rear. Also the right and left sides of the operator when he is seated in the operator's seat are the right and left sides of the machine.

MACHINE SERIAL NUMBER

The machine serial number is stamped on the identification plate. When sending reports and inquiries, and when ordering parts, etc., be sure to include this number.

MANUAL CONTROL

Information on those to whom this manual is distributed is recorded in the ledger in the section in charge at this company, so please decide on a person to be in charge of it and control it. When there are updates or additions, etc., we will notify the person in charge.

SYMBOLS

 means "Please refer to the section quoted."

 Indicates the tightening torque at the specific section that requires special attention in designing.

 Indicates the mass of a part or device.

- I . GENERAL**
- II . SPECIFICATIONS**
- III. MACHINE CONFIGURATION**
- IV. HYDRAULIC UNITS**
- V . TROUBLESHOOTING**
- VI. ENGINE**

I . GENERAL

CONTENTS

Safety Precautions 3
Cautions during Disassembly and Assembly 9
Cautions during Removal and Installation of the Hydraulic Units 9
Cautions during Removal and Installation of Piping 10
Handling of Seals 10
Tightening Torques 11

SAFETY PRECAUTIONS



SAFETY ALERT SYMBOL

This symbol means Attention! Be Alert! Your Safety Is Involved.

The message that follows the symbol contains important information about safety.

Read and understand the message to avoid personal injury or death.

■ SIGNAL WORDS

Safety messages appearing in this manual and on machine decals are identified by the words “DANGER”, “WARNING” and “CAUTION”. These signal words mean the following:

 DANGER
The word “DANGER” indicates an imminently hazardous situation which, if not avoided, can result in serious injury or death.

 WARNING
The word “WARNING” indicates a potentially hazardous situation which, if not avoided, could result in serious injury or death.

 CAUTION
The word “CAUTION” indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

IMPORTANT: The word “IMPORTANT” is used to alert against operators and maintenance personnel about situations which can result in possible damage to the machine and its components.

This manual is intended for trained and qualified personnel only. Warnings or cautions described in this manual do not necessarily cover all safety measures. For maintenance work, each person must take adequate safety precautions against possible hazards present in the respective working environment.

Observe all safety rules

- Operation, inspection and maintenance of this machine must be performed only by a trained and qualified person.
- All rules, regulations, precautions and safety procedures must be understood and followed when performing operation, inspection and maintenance of this machine.
- Do not perform any operation, inspection and maintenance of this machine when under the adverse influence of alcohol, drugs, medication, fatigue, or insufficient sleep.

Wear appropriate clothing and personal protective equipment

- Do not wear loose clothing or any accessory that can catch on controls or in moving parts.
- Do not wear oily or fuel stained clothing that can catch fire.
- Wear a hard hat, safety shoes, safety glasses, filter mask, heavy gloves, ear protection and other protective equipment as required by job conditions. Wear required appropriate equipment such as safety glasses and filter mask when using grinders, hammers or compressed air, as metal fragments or other objects can fly and cause serious personal injury.
- Use hearing protection when operating the machine. Loud prolonged noise can cause hearing impairments, even the total loss of hearing.

Provide a fire extinguisher and first aid kit

- Know where a fire extinguisher and first aid kit are located and understand how to use them.
- Know how to contact emergency assistance and first aid help.

Attach a “DO NOT OPERATE” tag

Severe injury could result if an unauthorized person should start the engine or touch controls during inspection or maintenance.

- Stop the engine and remove the key before performing maintenance.
- Attach a “DO NOT OPERATE” tag to the starter switch or control lever.

Use the correct tools

Do not use damaged or weakened tools or tools designed for other purposes. Use tools suited for the operation at hand.

Replace important safety parts periodically

- Replace fuel hoses periodically. Fuel hoses become weaker over time, even if they appear to be in good shape.
- Replace important safety parts whenever an irregularity is found, even if it is before the normal time for replacement.

Anti-explosive lighting

Use anti-explosive electrical fixtures and lights when inspecting fuel, oil, coolant, battery fluid, etc. If lighting that is not anti-explosive should break, the substance could ignite, resulting in serious injury or death.

Do not allow unauthorized personnel in the work area

Do not allow unauthorized personnel in the work area. Chips or other debris can fly off machine parts when grinding, welding or using a hammer.

Prepare the work area

- Select a firm, level work area. Make sure there is adequate light and, if indoors, ventilation.
- Clear obstacles and dangerous objects. Eliminate slippery areas.

Always clean the machine

- Clean the machine before performing maintenance.
- Cover electrical parts when washing the machine. Water on electrical parts could cause short-circuits or malfunctions.
Do not use water or steam to wash the battery, sensors, connectors or the operator's seat area.

Stop the engine before performing maintenance

- Avoid lubrication or mechanical adjustments with the machine in motion or with the engine running while stationary.
- If maintenance must be performed with the engine running, always work as a 2-person team with one person sitting in the operator's seat while the other works on the machine.
 - When performing maintenance, be sure to keep your body and clothing away from moving parts.

Stay clear of moving parts

- Stay clear of all rotating and moving parts. Wrapping or entanglement may result in serious injury or death.
- Keep hands, clothing and tools away from the rotating fan and running fan belts.

Securely block the machine or any component that may fall

- Before performing maintenance or repairs under the machine, set all working equipment against the ground or in the lowermost position.
- Securely block the tracks.
- If you must work beneath the raised machine or equipment, always use wood blocks, jack-stands or other rigid and stable supports. Never get under the machine or working equipment if they are not sufficiently supported. This procedure is especially important when working on hydraulic cylinders.

Securely block the working equipment

To prevent unexpected movement, securely block the working equipment when repairing or replacing the cutting edges or bucket teeth.

Secure the engine hood or cover when opened

Be sure to secure the engine hood or cover when opening it. Do not open the engine hood or cover on slopes or in strong wind.

Place heavy objects in a stable position

When removing or installing the hoe attachment, place it in a stable position so that it does not tip over.

Cautions on working on the machine



L3A005

- When performing maintenance on the machine, clean up the foot area and strictly observe the following so as not to fall:
 - Do not spill oil or grease.
 - Do not leave tools laying around.
 - When walking, watch your step.
- Never jump off the machine. Use the steps and handrails when climbing on and off the machine, and always support your body at three points with your hands and feet.
- Use protective equipment as required by job conditions.

Use caution when fueling

- Do not smoke or permit open flames while fueling or near fueling operations.
- Never remove the fuel cap or refuel with the engine running or hot. Never allow fuel to spill on hot machine components.
- Maintain control of the fuel filler nozzle when filling the tank.
- Do not fill the fuel tank to capacity. Allow room for expansion.
- Clean up spilled fuel immediately.
- Tighten the fuel tank cap securely. Should the fuel cap be lost, replace it only with the original manufacturer's approved cap. Use of a non-approved cap without proper venting may result in pressurization of the tank.
- Never use fuel for cleaning purposes.
- Use the correct fuel grade for the operating season.

Handling of hoses

Fuel, oil or hydraulic fluid leaks can cause a fire.

- Do not twist, bend or hit the hoses.
- Never use twisted, bent or cracked hoses, tubes and pipes. They may burst.
- Retighten loose connections.

Be careful with hot and pressurized components

Stop the engine and allow the machine to cool down before performing inspection and maintenance.

- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot directly after the engine is stopped. Touching these parts will cause burns.
- The engine coolant, oil and hydraulic fluid are also hot and under high pressure. Be careful when loosening caps and plugs. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurted out.

Be careful with hot cooling systems

Do not remove the radiator cap or drain plugs when the coolant is hot. Stop the engine, let the engine and radiator cool and loosen the radiator cap or drain plugs slowly.

Be careful with fluids under pressure

Pressure can be maintained in the hydraulic circuit long after the engine has been shut down.

- Release all pressure before working on the hydraulic system.
- Hydraulic fluid under pressure can penetrate the skin or eyes and cause injury, blindness or death. Fluid escaping from a small hole can be almost invisible. Wear a safety goggles and heavy gloves and use a piece of cardboard or wood to search for suspected leaks.

If fluid is injected into the skin, it must be removed within a few hours by a doctor familiar with this type of injury.

Release all pressure before working on the hydraulic system

Oil may spurt out if caps or filters are removed or pipes disconnected before releasing the pressure in the hydraulic system.

- Gradually loosen the vent plug to relieve tank pressure.
- Move all the control levers and pedals several times in all directions to release the pressure from the working equipment circuitry. (For link type controls)
- When removing plugs or screws or disconnecting hoses, stand to the side and loosen slowly to gradually release the internal pressure before removing.

Handling of the Accumulator

N0A005

High pressure nitrogen gas is enclosed in the accumulator and incorrect handling could possibly bring about serious injury due to explosion. The following matters should be strictly observed:

- Do not disassemble.
- Do not bring close to fire or throw into a fire.
- Do not make hole, weld, or fuse.
- Do not subject to shock such as hitting or rolling.
- At time of disposal, it will be necessary to release the enclosed gas. Please contact a Takeuchi sales or service agent.

Be careful with grease under pressure

The track adjuster contains highly pressurized grease. If the tension is adjusted without following the prescribed procedure, the grease discharge valve may fly off, resulting in injury.

- Loosen the grease discharge valve slowly. Do not unfasten it more than one full turn.
- Do not put your face, arms, legs or body in front of the grease discharge valve.

Disconnect the battery

Disconnect the battery before working on the electrical system or doing any welding. Remove the negative (-) battery cable first. When reconnecting the battery, connect the negative (-) battery cable last.

Avoid battery hazards

- Batteries contain sulfuric acid which will damage eyes or skin on contact.
 - If acid contacts eyes, flush immediately with clean water and get prompt medical attention.
 - If acid is accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
 - If acid contacts skin or clothing, wash off immediately with clean water.
- Wear safety glasses and gloves when working with batteries.
- Batteries generate flammable and explosive gases. Keep arcs, sparks, flames and lighted tobacco away.
- Use a flashlight to check battery electrolyte level.
- Stop the engine and shut off electrical equipment while inspecting or handling the battery.
- Do not short circuit the battery posts with metal items.
- Always unfasten the negative (–) battery cable first when disconnecting the battery cable. Always connect the negative (–) battery cable last when fastening the battery cable.
- Loose battery terminals may result in sparks. Be sure to fasten terminals tightly.
- Make sure the vent caps are tightened securely.
- Do not charge a battery or jump-start the engine if the battery is frozen. Warm to 15°C (60°F) or the battery may explode.

Have a Takeuchi service agent repair welding cracks or other damage

Ask a Takeuchi service agent to repair any welding problems which are detected. If not feasible, make sure the welding is done by a qualified person in a properly equipped workplace.

Safety signs

- Keep all safety signs clean and legible.
- Replace all missing, illegible or damaged safety and warning signs.

Checks after maintenance

- Gradually raise the engine speed from a low idle to maximum speed and check that no oil or air is leaking from serviced parts.
- Move the controls and check that the machine is operating properly.

Disposing of wastes

- Funnel spent fluids from the machine into containers. Disposing of fluids improperly destroys the environment.
- Follow the prescribed regulations when disposing of oil, fuel, engine coolant, refrigerant, solvents, filters, batteries or other harmful substances.

CAUTIONS DURING DISASSEMBLY AND ASSEMBLY

1. Clean the machine before disassembly operation.
2. Before disassembly, check the machine conditions and record them.
 - Model, Machine Serial Number, Hourmeter
 - Reason for Repairs, Repair History
 - Dirtiness of Filters
 - Fuel and Oil Conditions
 - Damage to each parts, etc.
3. To make reassembly operations easy, make matching marks at the necessary points.
4. Clean all disassembled parts and new parts, then arrange them in the proper sequence.
5. Be sure to replace all seals and cotter pins, etc., with new parts.
6. Keep parts which should not come in contact with oil and water separate from parts with oil on them.
 - Electrical Parts, Rubber, V-Belts, etc.
7. When installing bearings, bushings and oil seals, as a rule, use a press. When a hammer, etc., is used, it leaves bruises.
8. Wipe all joining surfaces clean so that there is no dirt or dust adhering to them.
9. Wrap seal tape from the front end, Wrapping it tight and leaving 1 or 2 threads bare, Overlap the tape by about 10 mm.

SEALING TAPE

LEAVE 1 OR 2 THREAD MARGIN

Y2-A102E

10. When fitting the snap rings, the bigger, rounder side of their circumferences should face the mating surfaces.

CAUTIONS DURING REMOVAL AND INSTALLATION OF THE HYDRAULIC UNITS

1. Make sure that the temperature of the hydraulic oil has dropped.
2. To prevent a loss of flow of the hydraulic oil, the residual pressure in the piping and the internal pressure in the hydraulic tank should be released.
3. Be sure to install caps or plugs on all openings in the hydraulic unit to prevent dirt from getting into the unit through the openings.

PLUG

PLUG

Y2-A103E

4. It is easy to mistake hydraulic oil adhering to the hydraulic unit for an oil leak, so wipe the unit off thoroughly.
5. Be sure that no damage is done to the plating on the rod in the hydraulic cylinder.
6. As a rule, removal and installation of the hydraulic cylinder should be done with the rod fully retracted.
7. Be sure to bleed the air after replacing the hydraulic oil or removing any of the hydraulic devices.
 - ☞ “III. Machine Configuration, Hydraulic System”

CAUTIONS DURING REMOVAL AND INSTALLATION OF PIPING

1. When hydraulic hoses are installed, tighten them once to the prescribed torque, then loosen them slightly and retighten them to the prescribed torque.
 - Tighten the fittings after the installation surfaces fit snugly together.
 - Pieces wrapped with seal tape are excluded.
2. Use 2 spanners, each on an opposite side, to remove and tighten fittings so that the hoses or steel pipes are not twisted.
3. After installation of hydraulic hoses or steel pipes, apply the maximum working pressure 5 or 6 times and confirm that there is no leakage.

HANDLING OF SEALS

1. Clean the grooves for O-rings and if there is any burr, etc., remove it.

BURR

DIRT

Y2-A105E

2. Be careful not to twist O-rings. If an O-ring is twisted, remove the twist with the fingertips.
3. During insertion, be careful not to damage the seal.
4. Handling of Floating Seals
 - Wipe all oil off the O-ring and housing of the floating seal.
 - When assembling, apply a thin coating of gear oil to the contact surface of the housing.
 - After assembly, turn the seal 2 or 3 times to get it to fit snugly.
5. Apply grease to the lip of the oil seal.
 - This is to prevent wear when it is first started up after assembly.

GREASE

Y2-A106E

TIGHTENING TORQUES**Hydraulic Hoses**

Hose Fitting Size	Torque			
	Union Nut (G)		Taper Thread (R)	
	N·m	ft-lb	N·m	ft-lb
1/8	9.8 $^{+4.9}_0$	7.3 $^{+3.5}_0$	11.8 ±1.2	8.7 ±0.8
1/4	24.5 $^{+4.9}_0$	18.1 $^{+3.5}_0$	29.4 ±2.9	21.7 ±2.1
3/8	49 $^{+4.9}_0$	36.2 $^{+3.5}_0$	53.9 ±5.4	39.8 ±3.9
1/2	58.8 $^{+4.9}_0$	43.4 $^{+3.5}_0$	88.3 ±8.8	65.1 ±6.4
3/4	117.7 $^{+4.9}_0$	86.8 $^{+3.5}_0$	147.1 ±14.7	108.5 ±10.7
1	137.3 $^{+4.9}_0$	101.3 $^{+3.5}_0$	196.1 ±19.6	144.7 ±14.3

UNION NUT

TAPER THREAD

Y2-A107E

Bite Type Pipe Fitting for Steel Pipe

Pipe Outer Diameter (mm)	Torque	
	N·m	ft-lb
8	34.3 ±4.9	25.3 ±3.5
10	41.7 ±2.5	30.7 ±1.7
12	58.8 ±4.9	43.4 ±3.5
15	88.3 ±4.9	65.1 ±3.5
16	93.2 ±4.9	68.7 ±3.5
18	132.4 ±4.9	97.6 ±3.5
22	205.9 ±9.8	151.8 ±7.2
27.2	245.2 ±9.8	181.0 ±7.2
28	313.8 ±19.6	231.4 ±14.3
32	313.8 ±19.6	231.4 ±14.3
35	411.9 ±19.6	303.7 ±14.3

Joints for Piping

Nominal Thread Diameter (R)	Torque			
	Steel		Cast Steel	
	N·m	ft-lb	N·m	ft-lb
1/8	11.8 ±1.2	8.7 ±0.8	10.8 ±1.1	8.0 ±0.7
1/4	29.4 ±2.9	21.7 ±2.1	24.5 ±2.5	18.1 ±1.7
3/8	53.9 ±5.4	39.8 ±3.9	49 ±4.9	36.2 ±3.5
1/2	88.3 ±8.8	65.1 ±6.4	73.5 ±7.4	54.3 ±5.3
3/4	147.1 ±14.7	108.5 ±10.7	127.5 ±12.7	94.1 ±9.3
1	196.1 ±19.2	144.7 ±14.3	171.6 ±17.2	126.6 ±12.5

Joints for Piping (O-ring Seal Type)

Nominal Thread Diameter (G)	Torque	
	N·m	ft-lb
1/8	19.6 ±2.0	14.5 ±1.4
1/4	34.3 ±4.9	25.3 ±3.5
3/8	53.9 ±4.9	39.8 ±3.5
1/2	63.7 ±4.9	47.0 ±3.5
3/4	93.2 ±4.9	68.7 ±3.5
1	107.9 ±9.8	79.5 ±7.2
1-1/4	117.7 ±9.8	86.8 ±7.2
1-1/2	137.3 ±9.8	101.2 ±7.2

O-RING

Nominal Thread Diameter (UNF)	Torque	
	N·m	ft-lb
7/16-20	16.7 ±2.0	12.3 ±1.4
1/2-20	22.6 ±2.0	16.6 ±1.4
9/16-18	31.4 ±2.9	23.1 ±2.1
3/4-16	59.8 ±4.9	44.1 ±3.5
1-1/16-12	102.0 ±5.9	75.2 ±4.4
1-5/16-12	135.3 ±7.8	99.8 ±5.8
1-5/8-12	181.4 ±9.8	133.8 ±7.2

Y2-A110

Bolts and Nuts (for ISO Strength Category 10.9)

Thread	Size × Pitch	Torque					
		General Tightening Points			Special Tightening Points		
		N·m	kgf·m	ft·lb	N·m	kgf·m	ft·lb
Coarse	M 6 × 1.0	9.8 ±0.5	1.0 ±0.05	7.2 ±0.4	11.8 ±0.6	1.2 ±0.06	8.7 ±0.4
	M 8 × 1.25	22.6 ±1.1	2.3 ±0.11	16.6 ±0.8	26.5 ±1.3	2.7 ±0.13	19.5 ±0.9
	M10 × 1.5	47.1 ±2.4	4.8 ±0.24	34.7 ±1.7	54.9 ±2.7	5.6 ±0.28	40.5 ±2.0
	M12 × 1.75	83.4 ±4.1	8.5 ±0.42	61.5 ±3.0	97.1 ±4.8	9.9 ±0.49	71.6 ±3.5
	M14 × 2.0	134.4 ±6.7	13.7 ±0.68	99.1 ±4.9	155.9 ±7.7	15.9 ±0.79	115.0 ±5.7
	M16 × 2.0	207.9 ±10.4	21.2 ±1.06	153.3 ±7.7	241.2 ±12.1	24.6 ±1.23	177.9 ±8.9
	M20 × 2.5	410.9 ±20.5	41.9 ±2.09	303.1 ±15.1	475.6 ±23.7	48.5 ±2.42	350.8 ±17.5
Fine	M 8 × 1.0	24.5 ±1.2	2.5 ±0.12	18.1 ±0.9	28.4 ±1.4	2.9 ±0.14	21.0 ±1.0
	M10 × 1.25	50.0 ±2.5	5.1 ±0.25	36.9 ±1.8	58.8 ±2.9	6.0 ±0.30	43.4 ±2.2
	M12 × 1.5	87.3 ±4.3	8.9 ±0.44	64.4 ±3.2	102.0 ±5.1	10.4 ±0.52	75.2 ±3.8
	M14 × 1.5	135.3 ±6.8	13.8 ±0.69	99.9 ±5.0	157.9 ±7.8	16.1 ±0.80	116.5 ±5.8
	M16 × 1.5	220.6 ±11.0	22.5 ±1.12	162.7 ±8.1	256.0 ±12.7	26.1 ±1.30	188.8 ±9.4
	M20 × 1.5	452.1 ±22.6	46.1 ±2.30	333.4 ±16.6	524.7 ±26.1	53.5 ±2.66	387.0 ±19.2

- General Tightening Points (Non-lubricated)
 - All securing points other than the special tightening points.
- Special Tightening Points (Grease with molybdenum disulfide applied.)
 - Points where particularly necessary due to function.
Special tightening positions and associated instructions are given in the text.
- Points where thread-locking compound is used (Three Bond #1324 is applied.)
Thread-locking compound positions and associated instructions are given in the text.
- If tightening torque values are provided in this manual, then tightening should be done according to those values.
(This indicates that the tightening torque differs from the values given in this table.)
- In order to tighten bolts and nuts evenly, they should be tightened alternately top, bottom, left, right.

II . SPECIFICATIONS

CONTENTS

Names of Components.....3

Dimensions4

Specifications Tables.....8

Mass Tables.....14

Recommended Lubricants15

Types of Crawler Belts.....17

Types of Attachments.....18

Servicing Standards19

Standards for Judging Performance29

 Reference Value Table29

 Methods for Inspecting Performance33

In regard to Standard Values and Allowable Values


The terms used in the items “Servicing Standards” and “Standards for Judging Performance” have the following meanings.

Standard Value This indicates the standard value for the new machine at the time of shipping from the factory. It should be used as the target value for maintenance work after operation.

Allowable Value..... The dimensions of parts change during use because of wear and deformation. Also, the performance of pumps, motors, and other hydraulic equipment drops, and this is the estimated value indicating the use limit for the respective part. It is decided under reference to the standard at the time of shipping, the results of various tests, etc. As the use conditions, the degree of repairs, etc., differ for each machine, these should be combined and used as reference for servicing standards and standards for judging performance.

* Do not use the standard values and the allowable values as standards for customer claims.

NAMES OF COMPONENTS




L3B000

- | | | |
|-------------------------------|--------------------------|--------------------------|
| 1. Cab | 12. Crawler Belt | 23. Arm |
| 2. Engine Hood | 13. Idler | 24. Arm Cylinder |
| 3. Fuel Tank | 14. Track Roller | 25. Boom |
| 4. Hydraulic Tank | 15. Carrier Roller | 26. Boom Cylinder |
| 5. Hydraulic Pump | 16. Travel Motor | 27. Swing Bracket |
| 6. Slew Motor | 17. Slew Bearing | 28. Swing Cylinder |
| 7. Pilot Valve | 18. Track Adjuster | 29. Dozer Blade |
| 8. Battery | 19. Pilot Valve (Travel) | 30. Dozer Blade Cylinder |
| 9. Control Valve (Mono Block) | 20. Swivel Joint | 31. Pilot Valve (Swing) |
| 10. Control Valve (3-Section) | 21. Bucket | |
| 11. Engine | 22. Bucket Cylinder | |

DIMENSIONS

Mono-Boom



L3B001

DIMENSIONS

SPECIFICATIONS

Machine Dimensions

Unit: mm

	Standard Arm		Middle Arm	Long Arm	Telescopic Arm*
	Rubber Crawler	Steel Crawler	Rubber Crawler	Rubber Crawler	Rubber Crawler
A	6555	←	6590	←	←
B	2245	←	←	←	←
C	2570/2615**	2565	2570	←	←
D	1720	←	←	←	←
E	785	760	785	←	←
F	2210	2180	2210	←	←
G	2855	2830	2855	←	←
H	2150	←	←	←	←
J	450	←	←	←	←
K	385	360	385	←	←
L	2180	←	2285	2430	2320
M	1635	←	1745	1870	1735
N	2060	←	2170	2310	2180
P	695	←	←	←	←
Q	735	←	←	←	←
R	2150	←	←	←	←
S	500	←	←	←	←
T	4840	4845	4875	4975	4925
U	2000	1995	2000	←	←
V	80°	←	←	←	←
W	50°	←	←	←	←

*: Telescopic arm fully retracted.


** : Equipped with roof guard.

Machine Dimensions

Unit: mm

	Standard Arm		Middle Arm	Long Arm	Telescopic Arm	
	Rubber Crawler	Steel Crawler	Rubber Crawler	Rubber Crawler	Arm Fully Retracted	Arm Fully Extended
					Rubber Crawler	Rubber Crawler
A	7055	←	7225	7385	7065	8125
B	6905	6910	7080	7245	6915	7995
C	4240	4260	4420	4590	4245	5445
D	3475	3500	3655	3830	3155	4365
E	7025	7005	7160	7290	7025	7715
F	4995	4970	5125	5255	5005	5695
G	1935	1915	1775	1630	1935	—
H	4630	←	4655	4700	5075	5235
J	525	505	525	525	←	←
K	410	435	410	410	←	←

2-Piece Boom



L3B002

Machine Dimensions

Unit: mm

	Rubber Crawler
A	6560
B	2245
C	2570/2615*
D	1720
E	785
F	2210
G	2855
H	2150
J	450
K	385
L	2505
M	1955
N	2385
P	690
Q	730
R	2150
S	500
T	4845
U	2000
V	80°
W	50°

**: Equipped with roof guard.

Machine Dimensions

Unit: mm

	Rubber Crawler
A	7650
B	7510
C	4440
D	3955
E	7970
F	6000
G	2310
H	4360
J	525
K	410

SPECIFICATIONS TABLES**SPECIFICATIONS**

Machine Type		Mono-Boom	2-Pice Boom
Machine Mass (not including operator)			
Rubber Crawler	kg	7280	7940
Steel Crawler	kg	7405	8145
Engine Rated Output	kW/min ⁻¹	42.8/2100	←
Bucket Capacity (Standard Bucket)			
Rated Capacity	m ³	0.245	←
Struck Capacity	m ³	0.185	←
Performance			
Slew Speed	min ⁻¹	8.0/11.5	←
Travel Speed: Rubber Crawler	1st / 2nd km/h	3.0/5.5	←
Steel Crawler	1st / 2nd km/h	2.9/5.5	←
Gradeability	% (degree)	35	←
Ground Pressure: Rubber Crawler	kPa	32.9	35.9
Steel Crawler	kPa	33.9	36.9
Noise Level: Sound-power level	dB (A)	LWA 99	←
Sound-pressure level	dB (A)	LPA 75	←
Auxiliary Hydraulic Flow Rate	1st / 2nd L/min	69.3 (82*)/53.1	69.3/53.1
Dimensions			
Overall Length in Transport Position	mm	6555	6560
Overall Width	mm	2245	←
Overall Height: Rubber Crawler	mm	2570	2570 (2610**)
Steel Crawler	mm	2565	2565 (2605**)
Dimensions of Base Machine			
Tail Swing Radius	mm	1720	←
Distance of Rearmost Upper Structure from Axis of Rotation	mm	1715	←
Clearance Height under Upperstructure:			
Rubber Crawler	mm	785	←
Steel Crawler	mm	760	←
Distance between Centerlines of Drive Sprockets and Idlers:			
Rubber Crawler	mm	2210	←
Steel Crawler	mm	2180	←
Crawler			
Overall Length: Rubber Crawler	mm	2855	←
Steel Crawler	mm	2830	←
Overall Width	mm	2150	←
Crawler Shoe Width	mm	450	←
Minimum Ground Clearance:			
Rubber Crawler	mm	385	←
Steel Crawler	mm	360	←

*: High flow

**: Equipped with roof guard

Machine Type		Mono-Boom	2-Pice Boom
Working Equipment (Hoe Attachment)			
Boom Swing Angle: L.H.	degree	80	←
R.H.	degree	50	←
Maximum Reach	mm	7055	7650
Maximum Reach at GRP	mm	6905	7510
Minimum Level Cut Radius with Bucket Flat on GRP	mm	2140	1810
Maximum Digging Depth	mm	4240	4440
Radius at Maximum Digging Depth	mm	3030	2665
Vertical Digging Depth	mm	3475	3955
Maximum Digging Height	mm	7025	7970
Radius at Maximum Digging Height	mm	3015	1355
Maximum Dumping Height	mm	4995	6000
Radius at Maximum Dumping Height	mm	2835	2090
Minimum Dumping Height	mm	1935	2310
Minimum Front Swing Radius	mm	2180	2505
Minimum Front Swing Radius at Boom Offset	mm	1635	1955
Overall Height at Minimum Front Swing Radius	mm	5255	4825
Overall Height at Minimum Front Swing Radius at Boom Offset	mm	5255	4825
Maximum Bucket Offset Volume: Left	mm	695	690
Right	mm	735	730
Digging Force: Bucket	kN	52.7	←
Arm	kN	36.7	36.0
Working Equipment (Dozer Blade)			
Dozer Blade: Width	mm	2150	←
Height	mm	500	←
Dozer Blade:			
Maximum Lifting Range above Ground Level	mm	525	←
Maximum Lowering Range below Ground Level	mm	410	←

SPECIFICATIONS OF DEVIDES

Engine				
Model		Yanmar 4TNV98-ZQTB		
Type		4-cycle, vertical, water-cooled, in-line, 4-cylinder diesel engine		
Number of Cylinders – Bore × Stroke		mm	4-98 × 110	
Maximum Torque		N·m	232.3	
Total Displacement		mL	3319	
Compression Ratio			18.5	
Specific Fuel Consumption (at rated output)		g/kW·h	246	
Maximum No-load R.P.M.		min ⁻¹	2330 ±25	
Minimum No-load R.P.M.		min ⁻¹	1100	
Starter	Output	V – kW	12 – 3.0	
Alternator	Output	V – kW	12 – 0.86	
Battery				
	Type		115D31	
	Capacity	V – A·h	12 – 72	
Hydraulic Pump (Piston)				
Model		K3SP36C-1CFR-9002-1		
Type		Variable displacement type double axial piston		
Delivery:	P1	L/min	72.5	
	P2	L/min	72.5	
Rated Pressure:	P1	MPa	27.5	
	P2	MPa	27.5	
Hydraulic Pump (Gear)				
Model		SDYA255F1H1-R338		
Type		Tandem gear		
Delivery:	P3	L/min	58.2	
	P4	L/min	11.7	
Rated Pressure:	P3	MPa	24.0	
	P4	MPa	3.4	
Control Valve (Mono-Block)				
Model		KVMM-80-TB		
Number of Circuits		Mono-Block		
Main Relief Valve Pressure Setting		MPa	27.5	
Port Relief Valve Pressure Setting		MPa	33.3	
		MPa	20.6	
Control Valve				
Model		KVSE31-4		
Number of Circuits		4		
Main Relief Valve Pressure Setting		MPa	24.0	
Port Relief Valve Pressure Setting		MPa	26.9	
		MPa	20.6	

Solenoid Valve			
Use	Speed Shift (Slow), Speed Shift (Travel) and Lever Lock, A/C		
Model	16521-00010		
Number of Solenoids	4		
Solenoid Rated Voltage	V	12	
Relief Valve Set Pressure	MPa	3.4	
Solenoid Valve			
Use	2-Piece boom		
Model	16321-00000		
Number of Solenoids	1		
Solenoid Rated Voltage	V	12	
Proportional Control Valve			
Use	1st/2nd Auxiliary Hydraulics		
Model	2KWE5A-30/G12R-269		
Pilot Valve			
Model	PV48M2		
Secondary Side Pressure	(Ports 1, 3)	MPa	0.54 to 2.06
	(Ports 2, 4)	MPa	0.64 to 1.86
Operating Angle: Single	(Ports 1, 3)	degree	19
Single	(Ports 2, 4)	degree	25

Pilot Valve (Travel, With Damper)			
Model			RCVD8CC4118
Secondary Side Pressure	MPa		0.44~2.11
Pilot Valve (Travel)			
Model			RCVD8C4131
Secondary Side Pressure	MPa		0.44~2.11
Pilot Valve (Swing)			
Model			PV6P1013A
Secondary Side Pressure	MPa		0.49~2.06
Reducing Valve			
Model			V4030-001
Set Pressure	MPa		1.96
Boom Cylinder			
Bore Diameter × Rod Diameter	mm		80 × 55
Stroke	mm		815
Fully Retracted Length (Pitch)	mm		1410
Cushion Mechanism			Rod End
Boom Cylinder (2-Piece Boom)			
Bore Diameter × Rod Diameter	mm		120 × 75
Stroke	mm		725
Fully Retracted Length (Pitch)	mm		1207
Cushion Mechanism			Rod End
Arm Cylinder			
Bore Diameter × Rod Diameter	mm		95 × 65
Stroke	mm		910
Fully Retracted Length (Pitch)	mm		1340
Cushion Mechanism			Both Ends
Arm Cylinder (2-Piece Boom, Emergency Shut-off Valve)			
Bore Diameter × Rod Diameter	mm		100 × 65
Stroke	mm		875
Fully Retracted Length (Pitch)	mm		1327
Cushion Mechanism			Both Ends
Bucket Cylinder			
Bore Diameter × Rod Diameter	mm		85 × 55
Stroke	mm		660
Fully Retracted Length (Pitch)	mm		1035
Cushion Mechanism			—
Swing Cylinder			
Bore Diameter × Rod Diameter	mm		120 × 75
Stroke	mm		690
Fully Retracted Length (Pitch)	mm		1180
Cushion Mechanism			Both Ends