

Product: Takeuchi TB260 Mini Compact Excavator Service Repair Workshop Manual(Book No.CQ1E001)

Full Download: <https://www.aresairmanual.com/downloads/takeuchi-tb260-mini-compact-excavator-service-repair-workshop-manualbook-no-cq1e001/>

# WORKSHOP MANUAL

# **TB260**

Serial No.126100001~

Book No. CQ1E001

WETB260-BB

**MINI EXCAVATOR**

Sample of manual. Download All 702 pages at:

<https://www.aresairmanual.com/downloads/takeuchi-tb260-mini-compact-excavator-service-repair-workshop-manualbook-no-cq1e001/>

**TAKEUCHI**

## FOREWORD

This manual, which is written for engineers who service the machine, describes procedures for disassembly and assembly, inspection and maintenance, and troubleshooting, as well as maintenance reference values and an outline of the specifications. Refer to this manual during daily work to improve your services. Note that the information is subject to change without notice due to design modifications made to the machine from time to time by the manufacturer.

### Directional terms: front, rear, left, right

In this manual, the “front” refers to the end of the machine where the dozer blade is mounted, while the “rear” refers to the other end where the travel motor is mounted. The “right” or “left” refers to the side viewed by a person sitting in the operator’s seat.

### Machine serial number

The machine serial number is stamped on the identification plate. Be sure to include this number when sending a report or inquiry or when ordering parts.

### Control of manual

Appoint a person in charge of keeping the manuals up to date in your company and inform us of the person’s name for our records. Any revisions or additions to this manual will be sent to the person.

### Symbols used in this manual

The symbols used in this manual have the following meanings.

-  Indicates the machine serial number.
-  Means “Refer to the section quoted.”
-  Indicates the mass of the equipment or machine.
-  Means “Tighten to the torque specified here.”
-  Indicates the use of thread-locking compound.
-  Indicates the use of grease.

### Manual structure

This manual consists of the following parts.

1. Safety
2. Service data
3. Function
4. Disassembly and assembly
5. Troubleshooting
6. Other

# SAFETY **1**

Safety alert symbol .....	1-2
Safety precautions .....	1-3
Cautions when working.....	1-9

## SAFETY ALERT SYMBOL



This symbol represents the safety alert.

The message that follows the symbol contains important information regarding human safety.

Read and understand the message to avoid personal injury or death.

### Safety label

Safety labels are used to alert operators or other people exposed to the risks of injury or damage. There are the following three types of labels.

Read the labels carefully as they are important for your safety.



#### **DANGER**

The word “DANGER” indicates an imminently hazardous situation which, if not avoided, is likely to result in serious injury or death.



#### **WARNING**

The word “WARNING” indicates a potentially hazardous situation which, if not avoided, could result in serious injury or death.



#### **CAUTION**

The word “CAUTION” indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**IMPORTANT:** The word “IMPORTANT” is used to alert operators and maintenance personnel about situations which could result in damage to the machine and its components.


This manual is intended for trained and qualified personnel only. Warnings or cautions described in this manual do not necessarily cover all safety measures. It is also impossible to cover all hazards and risks which may be associated with the maintenance of the machine in every environment. For maintenance work, each person must take adequate safety precautions against possible hazards in the respective working environment.

## SAFETY PRECAUTIONS

### Observe all safety rules


- Operation, inspection and maintenance of this machine must be performed only by a trained and qualified person.
- All rules, regulations, precautions and safety procedures must be understood and followed when performing operation, inspection and maintenance of this machine.
- Do not perform any operation, inspection or maintenance of this machine when under the influence of alcohol, drugs, medication, fatigue or insufficient sleep.

### Wear safe clothing and protective gear



- Do not wear loose clothing or any accessory that can catch on the controls or the moving parts of the machine.
- Do not wear clothing stained with oil or grease that can easily catch fire.
- Wear protective gear such as helmet, safety shoes, protective goggles, respirator, gloves and earmuffs, as appropriate, depending on the work involved. Especially make sure to wear protective eye-wear and mask when working with a grinding/polishing/sanding machine, hammer or compressed air, as metal fragments or other objects could scatter in such an environment.
- Wear hearing protectors when operating the machine. Loud and prolonged noise can damage or destroy your hearing.

### Install an extinguisher and a first aid kit



- Install an extinguisher to fight a fire, and learn how to use it.
- Prepare a first aid kit and keep it at a designated place.
- Decide on the procedures to be used in case of fire or other hazards.
- Decide on and take note of the contact(s) in case of emergency.

### Place a “Do not operate” alert sign

Serious injury or death may result if an unauthorized person starts the engine or touches the controls during inspection or maintenance.

- Before performing maintenance, stop the engine, remove the key and store it in a safe place.
- Prominently display a “Do not operate” alert sign on places such as the starter switch and the control lever. Place another sign outside of the machine as necessary.

### Use the correct tools



Do not use damaged or weakened tools or tools designed for other purposes. Use only the correct tools for the work involved.

### Regularly replace the safety-critical parts

- Regularly replace fuel hoses to prevent a fire hazard. Hoses wear out over time, even if they do not show any symptom of wear.
- Regardless of the replacement schedule, replace immediately if a symptom of wear is found.


### Explosionproof lighting



1BAA04Z

To prevent an ignition or explosion, use explosion-proof lights when inspecting fuel, oil, coolant or battery fluid.

### Prohibit access by unauthorized persons



1BAA05Z

Do not allow unauthorized personnel in the work area while working. Take particular care that no unauthorized person is present when grinding, welding or using a hammer.


### Prepare the work area

- Select a level and firm ground on which to perform maintenance work. Make sure that the work area is light enough and well ventilated.
- Straighten any obstacle or dangerous object, remove any spill of oil or grease and clean the work area.

### When the canopy is tilted up

- If the canopy is raised or lowered while the engine is moving, the machine may accidentally start moving, resulting in severe injury to the maintenance personnel. Make sure that the working equipment has been lowered to the ground and the engine has been turned off before raising/lowering the canopy.
- When the canopy is tilted up, firmly secure the canopy with a stopper to prevent it from falling.

### Keep the machine clean



1BAA06Z


- Clean the machine before performing maintenance and try to keep it clean.
- Before washing, cover the electrical parts with vinyl to prevent water from entering, as this could cause a short-circuit or malfunction. Do not use water or steam to wash the battery, sensors, connectors or the operator's seat area.

### Stop the engine before performing maintenance

Make sure the engine is stopped before starting inspection or maintenance. If maintenance must be performed with the engine running, always work as a 2-person team, communicating with each other.

- One of them must sit at the operator's seat and stop the engine whenever necessary. He/she must take care not to touch the lever or pedal unless necessary.
- The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.

### Keep clear of the moving fan and belt



1BAA07Z

- Any object that can be easily caught in moving parts must be kept away.
- If a hand or tool becomes trapped in the fan or fan belt, you could lose your finger. Do not touch the fan or belt while they are moving.

### When working under the machine



1BAA08Z

- Before performing maintenance or repairs under the machine, set all movable equipment against the ground or in the lowermost position.
- Place chocks under the crawler tracks to secure the machine.
- If it is unavoidably necessary to work under the raised machine or working equipment, be sure to firmly support it by using an arm stopper, wooden block, stand or safety brace. Never go under the raised machine or working equipment without such protection measures.

### When working on the machine



1BAA09Z

- To prevent slipping/falling from machine, clear the footing and observe the following:
  - a. Do not spill oil or grease on the machine.
  - b. Keep the machine tidy and clean.
  - c. Be careful when walking around the machine.
- Never jump down from the machine. Climb up/down the ladder (steps) holding the handrail to support your weight in a three point secure stance (hand and feet).
- Wear protective gear according to the work involved.

### Securing the working equipment

When replacing/repairing the bucket teeth or side cutter, secure the relevant equipment to prevent any accidental movement.

### Secure the engine hood and guard when they are open

Firmly secure the machine when the engine hood or guard is left open. Do not keep the hood or guard open on a windy day or if the machine is parked on a slope.

### Place heavy components in a stable position



1BAA10Z

When it is necessary to temporarily place a heavy component, such as the hoe attachment, on the ground during removal or installation, be sure to place it in a stable position.

### Caution when filling with fuel or oil



1BAA11Z


- Keep away from heat, sparks and flame while filling with fuel or oil.
- Never remove the fuel cap or try to fuel when the engine is running or still hot.
- Maintain control of the fuel filler nozzle when filling the tank.
- Refill with fuel or oil outdoors or in a well ventilated place, with the engine turned off.
- Clean up spilled fuel or oil immediately.
- Do not overfill the tank.
- Firmly tighten the fuel cap or oil cap. If the fuel cap is lost, replace it only with the original manufacturer's approved cap. Use of a non-approved cap without proper venting may result in pressurization of the tank.
- Never use fuel for cleaning.
- Use the correct grade of fuel for the operating season.

### Handling of hoses

Oil leak or fuel leak can cause a fire.

- Do not twist, bend or hit the hoses.
- Never use twisted, bent or cracked pipes, tubes or hoses; otherwise, they may burst.
- Retighten loose connections.

### Be careful with hot and pressurized components



1BAA12Z

Before performing inspection and maintenance, stop the engine and allow the machine to cool down.

- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Wait until it cools before making any inspection or adjustments.
- The engine coolant, hydraulic oil and other oils are also hot and under high pressure. Touching these liquids will cause burns.


### Handling of radiator



1BAA13Z

Do not remove the radiator cap when the coolant is hot. Wait until it cools down, and then remove the radiator cap by loosening it slowly to release the internal pressure.

### Be careful with oils under pressure



1BAA14Z

Pressure is maintained in the hydraulic circuit long after the engine has been shut down.

- Do not fill with, dispose of fuel/oil, or perform the inspection and maintenance until the internal pressure is completely released.
- The hydraulic oil escaping from a small hole can be hazardous if contacted. It is under high enough pressure to penetrate the skin or eyes and cause serious injury. If leak is suspected, protect your eyes and skin by wearing protective glasses and thick gloves to search for a leak. Also use a paperboard or plywood to keep your skin from oil spurting. If oil penetrates the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury.

### Release internal pressure before working on the hydraulic system

Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- Gradually loosen the vent plug to release the internal pressure of the hydraulic oil tank.
- Move all the control levers and pedals several times in all directions to release the pressure from the circuit of the working equipment (for link type controls).
- When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.

### Be careful with grease under pressure



1BAA15Z

In the track adjuster, the grease has been injected under high pressure. If the tension is adjusted without following the prescribed procedure, the grease discharge valve may fly off, resulting in injury.

- Loosen the grease discharge valve slowly.
- Do not put your face, arms, legs or body in front of the grease discharge valve.

### Handling of the accumulator



1BAA16Z

Be sure to handle the high-pressure nitrogen gas enclosed in the accumulator with care according to procedure. If handled incorrectly, it could explode and cause serious injury. Strictly observe the following precautions:

- Do not disassemble.
- Do not allow flame near it or throw it into a fire.
- Do not drill, weld or fuse.
- Do not subject it to physical shock such as hitting, rolling or dropping.
- Before disposing of the unit, the sealed gas must be drained. Contact your sales or service dealer for help with this.

### Disconnect the battery

Disconnect the wiring from the both terminals (+ and -) on the battery before working on the electrical system or doing electric welding. Otherwise, short-circuit and explosion of the battery can result.

## Use caution when handling batteries



1BAA17Z

- Batteries contain sulfuric acid which will damage eyes or skin if contacted.
  - If eye contact occurs, flush immediately with clean water and get prompt medical attention.
  - If accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
  - If acid contacts skin or clothing, wash off immediately with a lot of water.
- Wear protective glasses and gloves when working with batteries.
- Batteries generate flammable hydrogen gas which may explode. Keep away from flame and sparks.
- Do not use or charge the battery when the electrolyte level is lower than the lower limit: otherwise, it could cause an explosion.
- Be sure to stop the engine by turning off the starter switch before inspecting or handling the battery.
- Be careful not to let metal tools (or any metal objects) such as a hammer or spanner come into contact with the battery terminals.
- When disconnecting the battery wiring, always disconnect it from the earth side (-). When connecting, connect the earth side last.
- Loose battery terminals may result in sparks. Be sure to fasten terminals tightly.
- Make sure the battery caps are tightened securely.
- Do not charge a battery or jump-start the engine if the battery is frozen; otherwise it may explode. Warm the frozen battery to 15°C (59°F) before use.


## Have a service agent repair welding cracks or other damage

Ask a service agent to make any repairs that require welding. If the agent is unavailable, make sure the welding is done by a qualified person in a properly equipped workplace.

## Checks after maintenance

- Gradually raise the engine speed from low idle to maximum and check that no oil or water is leaking from the parts serviced.
- Move the controls and check that the machine is operating properly.

## Disposing of wastes




1BAA18Z

- Always collect oil that is drained from the machine in containers. Improperly disposed waste oil can cause environmental harm.
- Follow appropriate laws and regulations when disposing of harmful objects such as oil, fuel, coolant, solvent, filters and batteries.

## CAUTIONS WHEN WORKING


### When disassembling or assembling

- Clean the machine before disassembly.
- Check the following items and record the results:
  - a. Model, machine serial number, hour meter.
  - b. Reason for repair, repair history.
  - c. Are the filters dirty?
  - d. The conditions of the fuel and oil.
  - e. Any damage or looseness to any part?
- Where necessary, draw alignment indicators to avoid assembly errors. To avoid misconnection, place indicators such as reference tags on pipes.
- Clean all disassembled parts and new parts, arrange them neatly, and place indicators as necessary.
- Be sure to replace all seals and cotter pins with new ones.
- Keep those parts that should not come in contact with water or oil away from those with oil on the surface.
- When installing bearings, bushings and oil seals, a press tool should be used. If a hammer is used, use a cushioning material to avoid damage.
- Wipe all joining surfaces clean until there is no dirt or dust adhering to them.
- Wrap the thread tight with seal tape starting 1 or 2 threads away from the thread end. The tape should be overlapped by about 10 mm (0.39 in).



### When removing/installing the hydraulic unit


- Make sure that the temperature of the hydraulic oil has dropped and is cool enough to work with.
- To prevent the hydraulic oil from escaping under pressure, release the residual pressure in the piping.
- Be sure to install caps or plugs on all openings in the hydraulic unit to prevent dirt from getting into the unit through them.



- The hydraulic oil adhering to the unit is often mistaken for an oil leak, so wipe off the unit thoroughly.
- Be sure that no damage is caused to the plating on the rod in the hydraulic cylinder.
- Removal and installation of the hydraulic cylinder should be done with the rod fully retracted.
- Be sure to bleed the air after installing the hydraulic cylinder. (☞ "4. Disassembly and assembly: Cylinder")
- Always bleed the air when hydraulic oil is changed or a hydraulic device is replaced. (☞ "4. Disassembly and assembly: Drive system")


## When connecting/disconnecting the hoses or pipes

- When hydraulic hoses or pipes are connected, tighten them once to the prescribed torque, then loosen them slightly and retighten them to the prescribed torque.
  - a. Tighten the fittings after the installation surfaces fit snugly together.
  - b. The above procedures do not apply to fittings with seal tape.
- Use two spanners, one to tighten/loosen and the other to secure the mating hose/pipe to ensure that the hose is not twisted.



1CAA03Z

- After connecting the hydraulic hoses or pipes, apply the maximum working pressure five or six times to check for leakage.
- If high pressure, vibration or shock is applied to a twisted hose, oil leak, hose breakage or damage to the hose fitting can result.
- Be sure that the hydraulic hoses are not contacting sharp objects or each other. This could cause surface flaws on the hoses, resulting in breakage.



1CAA04Z


## Handling of seals

- Clean the grooves for O-rings and remove any burrs.



1CAA05Z

- Be careful not to twist the O-rings. If twisted, remove it with your fingertips.
- When inserting, be careful not to damage the seal.
- Handling of the floating seal
  - a. After removal, wipe all oil off the O-ring and housing of the floating seal.
  - b. When assembling, apply a thin coating of gear oil to the contact surface of the housing,
  - c. After assembly, turn the seal two or three times to get it to fit snugly.
- Apply grease to the lip of the oil seal.
  - a. This is to prevent wear from occurring upon first start up after assembly.




1CAA06Z

# SERVICE DATA **2**

Dimensional drawing  
Specification tables  
Table of masses  
Lubricant and fuel chart  
Performance criteria  
Tightening torque  
Hydraulic circuit diagram  
Electrical circuit diagram  
Wire harness diagram

# DIMENSIONAL DRAWING

## Machine dimensions



2A0AV01


Unit: mm (in.)

	Standard arm		Middle arm		Long arm	
	Rubber crawler	Steel crawler	Rubber crawler	Steel crawler	Rubber crawler	Steel crawler
A	–	–	5540 (218.0)	←	5550 (218.5)	←
B	–	–	1870 (73.6)	←	←	←
C	–	–	2600 (102.4)	2590 (102.0)	2600 (102.4)	2590 (102.0)
C'	–	–	–	–	–	–
D	–	–	1300 (51.2)	←	←	←
E	–	–	635 (25.0)	625 (24.6)	635 (25.0)	625 (24.6)
F	–	–	2050 (80.7)	2035 (80.2)	2050 (80.7)	2035 (80.2)
G	–	–	2575 (101.3)	2560 (100.8)	2575 (101.3)	2560 (100.8)
H	–	–	2000 (78.7)	←	←	←
J	–	–	400 (15.7)	←	←	←
K	–	–	330 (13.1)	325 (12.7)	330 (13.1)	325 (12.7)
L	–	–	2390 (94.0)	←	2420 (95.4)	←
M	–	–	1945 (76.6)	←	1975 (77.8)	←
P	–	–	655 (25.8)	←	←	←
Q	–	–	785 (31.0)	←	←	←
R	–	–	2000 (78.7)	←	←	←
S	–	–	430 (16.9)	←	←	←
T	–	–	4240 (166.9)	←	4255 (167.5)	←
U	–	–	1870 (73.6)	←	←	←
U'	–	–	1930 (76.0)	←	←	←
V	–	–	78	←	←	←
W	–	–	55	←	←	←

C': When canopy used

U': Angle blade specifications

Operating range



2A0AV02

Unit: mm (in.)

	Standard arm		Middle arm		Long arm	
	Rubber crawler	Steel crawler	Rubber crawler	Steel crawler	Rubber crawler	Steel crawler
A	–	–	6120 (240.9)	←	6270 (246.9)	←
B	–	–	5975 (235.3)	←	6130 (241.4)	←
C	–	–	3735 (147.1)	3745 (147.4)	3895 (153.4)	3905 (153.7)
D	–	–	2830 (111.3)	2835 (111.7)	2980 (117.4)	2990 (117.7)
E	–	–	4175 (164.3)	←	4220 (166.1)	←
F	–	–	5835 (229.7)	5825 (229.4)	5940 (233.9)	5930 (233.5)
G	–	–	4115 (162.0)	4105 (161.6)	4220 (166.1)	4210 (165.8)
H	–	–	1465 (57.6)	1455 (57.3)	1305 (51.5)	1300 (51.5)
J	–	–	430 (16.9)	420 (16.5)	430 (16.9)	420 (16.5)
J'	–	–	445 (17.5)	435 (17.2)	445 (17.5)	435 (17.2)
K	–	–	430 (16.9)	440 (17.2)	430 (16.9)	440 (17.2)
K'	–	–	450 (17.7)	455 (18.0)	450 (17.7)	455 (18.0)

J', K': Angle blade specifications

## SPECIFICATION TABLES

Operating mass	Rubber crawler	Canopy	kg (lb)	–
		Cab	kg (lb)	5660 (12480)
	Steel crawler	Canopy	kg (lb)	–
		Cab	kg (lb)	5850 (12895)
Rated horse power			kW (hp)	33.6 (45.1)
			min <sup>-1</sup> (rpm)	2400 (2400)
Bucket capacity	Heaped capacity		m <sup>3</sup> (ft. <sup>3</sup> )	0.168 (5.93)
	Struck capacity		m <sup>3</sup> (ft. <sup>3</sup> )	0.127 (4.48)

### Performance

Standard loading mass			kg (lb)	230 (505)
Slew speed			min <sup>-1</sup> (rpm)	–
Travel speed	Rubber crawler	1st	km/h (mph)	–
		2nd	km/h (mph)	–
	Steel crawler	1st	km/h (mph)	–
		2nd	km/h (mph)	–
Maximum tractive force			kN (lbf)	62.3 (14000)
Gradeability			%	58
			deg.	30
Ground pressure	Rubber crawler	Canopy	kPa (psi)	–
		Cab	kPa (psi)	31.1 (4.51)
	Steel crawler	Canopy	kPa (psi)	–
		Cab	kPa (psi)	32.3 (4.68)
Noise level	Sound-power level		dB (A)	–
	Sound-pressure level*		dB (A)	–

\*: At the operator location as stipulated by ISO 6396: 2008.

### Dimensions of completed machine

Overall length	Standard arm		mm (in.)	–
	Middle arm		mm (in.)	5540 (218)
	Long arm		mm (in.)	5550 (218.5)
Overall width	During normal operation		mm (in.)	2000 (78.7)
	Track retracted		mm (in.)	–
Overall height	Rubber crawler	Canopy	mm (in.)	–
		Cab	mm (in.)	2600 (102.4)
	Steel crawler	Canopy	mm (in.)	–
		Cab	mm (in.)	2590(102.0)

### Dimensions of base machine

Overall length of base machine			mm (in.)	3155 (124.1)
Overall width of base machine	During normal operation		mm (in.)	2000 (78.7)
	Track retracted		mm (in.)	–
Upper structure overall width			mm (in.)	1870 (73.6)
Upper structure overall width	Left		mm (in.)	950 (37.5)
	Right		mm (in.)	920 (36.1)
Cab overall width			mm (in.)	1040 (40.9)

Overall height of base machine	Rubber crawler	Canopy	mm (in.)	-
		Cab	mm (in.)	-
	Steel crawler	Canopy	mm (in.)	-
		Cab	mm (in.)	-
Swing radius			mm (in.)	1300 (51.2)
Upper structure rearmost distance from axis of rotation			mm (in.)	1295 (51.0)
Clearance height under upper structure	Rubber crawler		mm (in.)	635 (25.0)
	Steel crawler		mm (in.)	625 (24.6)
Crawler base	Rubber crawler		mm (in.)	2050 (80.7)
	Steel crawler		mm (in.)	2035 (80.2)
Crawler overall length	Rubber crawler		mm (in.)	2575 (101.3)
	Steel crawler		mm (in.)	2560 (100.8)
Undercarriage overall width	During normal operation		mm (in.)	2000 (78.7)
	Track retracted		mm (in.)	-
Track gauge	During normal operation		mm (in.)	1600 (63.0)
	Track retracted		mm (in.)	-
Track shoe width			mm (in.)	400 (15.7)
Ground clearance of undercarriage	Rubber crawler		mm (in.)	330 (13.1)
	Steel crawler		mm (in.)	325 (12.7)

### Engine

Model			Yanmar 4TNV86CT
Type			4-cycle, vertical, water-cooled, in-line diesel engine (direct-injection)
Cylinders	Number of cylinders	Quantity	4
	Bore	mm (in.)	86 (3.36)
	Stroke	mm (in.)	90 (3.54)
Total displacement		mL (cu. in.)	2091 (127.6)
Maximum torque		N·m (ft.-lb.)	162 to 177 (119.5 to 130.5)
		min <sup>-1</sup> (rpm)	1560 (1560)
Specific fuel consumption (at rated output)		g/(kW·h) (lb./hp-hr.)	238 (0.391)
Fuel/air cleaner			Centrifugal, filter paper-type
Cooling system	Fan		Suction
	Radiator		Pressure sealed-type
Starting system	Voltage	V	12
	Output	kW	2.3
Generator	Voltage	V	12
	Output	kW	0.66
Battery	Voltage	V	12
	Capacity	A·h	90
	Quantity		1

**Hydraulic system**

Hydraulic pump drive system			Engine direct coupling	
Hydraulic pump	Type		Variable displacement type double axial piston + double gear	
	Quantity		1	
	Delivery	P1	L/min. (US gal./min.)	58.3 (15.4)
		P2	L/min. (US gal./min.)	58.3 (15.4)
		P3	L/min. (US gal./min.)	43.9 (11.6)
		P4	L/min. (US gal./min.)	10.8 (2.9)
Hydraulic pump control system			All horsepower control	
Main relief valve pressure setting			MPa (psi)	24.0 (3480)
			MPa (psi)	24.0 (3480)
			MPa (psi)	20.6 (2990)
			MPa (psi)	3.3 (480)
Hydraulic tank pressure			Pressure tank	
Control valve	Type		Directional control valve, 12 valves in series (standard spec)	
	Operation type		-	
Hydraulic oil filter	Type		Glass fiber filter type	
	Filter precision		BETA10 = 6	
	Installation position		Return circuit (in hydraulic tank)	
Hydraulic oil cooler	Cooling system		Air cooling	
	Radiation surface area	m <sup>2</sup> (ft. <sup>2</sup> )	-	

**Operating device**

Cab	Position		Left side
	Construction		Suspension seat, adjustable
Cab or canopy	Construction		Steel-enclosed cab with fully reinforced glass windows, canopy with steel support columns
Control levers and pedals	Shifting operation		Variable travel speed switch (with right joystick grip controller) and accelerator adjuster (with dial knob)
	Travel operation		Hydraulic pilot-operated, 2 levers
	Slew operation		Hydraulic pilot-operated
	Arm operation		Hydraulic pilot-operated
	Bucket operation		Hydraulic pilot-operated
	Boom operation		Hydraulic pilot-operated
	Boom swing operation		Hydraulic pilot-operated, pedal-operated system
Other			Auxiliary line piping operation: Hydraulic, pilot-operated pedal system
Instruments, switches			Cluster gauge (5.7-in. LCD panel), light, Power mode, high-altitude mode, auto-deceleration function, 1st auxiliary line piping detent, lift alarm, and beacon light.
Lighting device			Headlight, boom light (12 V-55 W H3 halogen), side light (12 V-20 W)

Warning, safety devices	Horn (12 V, 108 dB), Travel alarm(12 V, 112dB)
Others	Cab specifications: Wiper, air conditioner, and radio included

**Slew equipment**

Slew bearing	Type	Ball bearing-type
Slew motor	Type	Constant-volume piston motor
	Quantity	1
Reduction gears	Type	Epicycle reduction gear (2-stage)
Slew brake	Type	Brake valve with a shockless relief
	Quantity	1
Slew parking brake	Type	Wet friction plate type
Slew lock	Type	-

**Lower machinery**

Power transmission device			
Travel motor	Type		Variable displacement type double axial piston motor, With counterbalance valve
	Quantity		2
Reduction gears	Type		Epicycle reduction gear
Travel brake	Type		Operation delay with a counter balance valve
Parking brake	Type		Wet friction plate type
Undercarriage			
Track shoe	Type		Rubber crawler
	Number of shoes (on one side)	Quantity	76
	Shoe width	mm (in.)	400 (15.75)
	Lug height	mm (in.)	25 (0.98)
	Type		Steel crawler with triple grouser
	Number of shoes (on one side)	Quantity	40
	Shoe width	mm (in.)	400 (15.75)
	Grouser height	mm (in.)	15 (0.55)
Roller	Carrier roller (on one side)	Quantity	1
	Track roller (on one side)	Quantity	5
Track adjuster	Type		Grease cylinder type (with cushion spring)
Track gauge extension mechanism			-

**Working equipment**

Backhoe attachment			
Bucket capacity	Heaped capacity	m <sup>3</sup> (ft. <sup>3</sup> )	0.168 (5.93)
	Struck capacity	m <sup>3</sup> (ft. <sup>3</sup> )	0.127 (4.48)
Bucket width	Standard	mm (in.)	620 (24.3)
	With side cutter	mm (in.)	640 (25.3)
Bucket mass		kg (lb)	133.8 (295)
Boom length		mm (in.)	2850 (112.2)

Arm length	Standard	mm (in.)	–
	Middle	mm (in.)	1620 (63.8)
	Long	mm (in.)	1780 (70.1)
Bucket wrist radius		mm (in.)	880 (34.6)
Bucket wrist angle		deg.	185
Boom swing angle	Left	deg.	80
	Right	deg.	55
Eccentricity of boom swing pivot		mm (in.)	85 (3.3)

### Working dimensions (Middle arm)

Maximum reach		mm (in.)	6120 (240.9)
Maximum reach at ground reference plane		mm (in.)	5975 (235.3)
Minimum radius of ground level finishing		mm (in.)	1920 (75.7)
Maximum digging depth		mm (in.)	3735 (147.1)
Reach at maximum digging depth		mm (in.)	2360 (93.0)
Maximum vertical digging depth		mm (in.)	2830 (111.3)
Maximum height of cutting edge		mm (in.)	5835 (229.7)
Reach at maximum height		mm (in.)	3270 (128.7)
Maximum dumping height		mm (in.)	4115 (162.0)
Reach at maximum dumping height		mm (in.)	3020 (118.9)
Minimum dumping height		mm (in.)	1465 (57.6)
Minimum radius of equipment and attachment		mm (in.)	2390 (94)
Minimum radius of equipment at maximum front offset		mm (in.)	1645 (64.8)
Overall height at minimum radius of equipment and attachment		mm (in.)	4400 (173.2)
Overall height of equipment at maximum front offset		mm (in.)	4400 (173.2)
Max. bucket offset distance	Left	mm (in.)	655 (25.8)
	Right	mm (in.)	785 (31.0)

### Main structure

Boom		Vertical rotation angle expansion type, with attached boom link	
Arm		–	
Bucket	Type	–	
	Number of teeth	Quantity	4

### Hydraulic cylinder

Boom cylinder	Number of cylinders	Quantity	1
	Bore	mm (in.)	100 (3.9)
	Stroke	mm (in.)	710 (28.0)
Arm cylinder	Number of cylinders	Quantity	1
	Bore	mm (in.)	90 (3.5)
	Stroke	mm (in.)	740 (29.1)
Bucket cylinder	Number of cylinders	Quantity	1
	Bore	mm (in.)	80 (3.1)
	Stroke	mm (in.)	625 (24.6)
Swing cylinder	Number of cylinders	Quantity	1
	Bore	mm (in.)	90 (3.5)
	Stroke	mm (in.)	685 (27.0)

**Digging force**

Maximum digging force	Bucket cylinder	kN (lbf)	43.2 (9710)
	Arm cylinder	kN (lbf)	27.3 (6140)
Maximum lifting force	Boom cylinder	kN (lbf)	30.4 (6830)
Attachment (optional)			–

**Dozer blade**

Type		Straight type	
Operation type		Hydraulic hoisting type	
Dozer blade cylinder	Number of cylinders	Quantity	1
	Bore	mm (in.)	110 (4.3)
	Stroke	mm (in.)	175 (6.9)
Dimensions			
Dozer blade dimensions	Width	mm (in.)	2000 (78.7)
	Height	mm (in.)	430 (16.9)
Cutting angle		deg.	70
Distance between the front end of the dozer blade and the axis of rotation		mm (in.)	1870 (73.6)
Dozer blade maximum lifting		mm (in.)	430 (16.9)
Dozer blade maximum lowering		mm (in.)	430 (16.9)
Dozer blade approach angle		deg.	28

## TABLE OF MASSES

### Upper structure

kg (lb.)

Engine	170 (375)
Radiator assembly	45 (99)
Main pump	36 (79)
Gear pump	–
Hydraulic tank assembly	57 (126)
Fuel tank assembly	7 (15)
Control valve assembly	75 (165)
Pilot valve	2 (4)
Slew motor	50 (110)
Cab	238 (525)
Canopy	–
Counterweight	626 (1379)
Counterweight (with added weight)	–
Boom bracket	143 (314)
Swing cylinder	55 (120)

### Lower structure

kg (lb.)

Swivel joint	22 (49)
Slew bearing	84 (185)
Rubber crawler (One side)	231 (509)
Steel crawler (One side)	318 (701)
Steel crawler	–
Steel crawler	–
Segmented rubber crawler	–
Travel motor	54 (119)
Carrier roller	4 (9)
Track roller	11 (25)
Front idler assembly	51 (112)
Track adjuster	29 (65)
Dozer blade	236 (521)
Dozer blade	–
Dozer blade	–
Dozer blade cylinder	43 (95)

### Hoe attachment

kg (lb.)

Boom	223 (491)
Arm	–
Arm (middle model)	120 (265)
Arm (long model)	133 (293)
Bucket (Standard model)	–
Boom cylinder	68 (149)
Arm cylinder	58 (128)
Bucket cylinder	37 (82)

# LUBRICANT AND FUEL CHART

Select the appropriate fuel, lubricant, and grease according to temperature by referring to the table below.

- Regardless of the specified time, change the oil if it becomes too dirty or degraded.
- When refilling, never mix oils of different brands. If a brand is to be changed, replace all of the fuel/oil.

Part	Type	Selection by air temperature							When to change/ replenish	Capacity	
		-4 -20	14 -10	32 0	50 10	68 20	86 30	104°F 40°C			
Engine oil pan	Diesel engine oil API: CD class ACEA: E3/E4/E5 class JASO: DH1 class	<div style="text-align: center;"> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc; margin-bottom: 5px;">SAE 10W-30</div> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc;">SAE 15W-40</div> </div>							Every 250 hrs. after the first 50 hrs.	Upper limit: 7.4 L (7.8 US qt.) Lower limit: 4.0 L (4.2 US qt.)	
	Hydraulic tank	Takeuchi genuine hydraulic oil 46	<div style="text-align: center;"> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc;">ISO VG46</div> </div>								Every 4000 hrs.***
	Anti-wear hydraulic oil	<div style="text-align: center;"> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc; margin-bottom: 5px;">ISO VG32</div> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc; margin-bottom: 5px;">ISO VG46</div> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc;">ISO VG68</div> </div>							Every 2000 hrs.***		
Engine cooling system	Cooling water (water + coolant)** SAE-J814C, J1941, J1034, or J2036 ASTM-D6210 or D4985 (USA)	<div style="text-align: center;"> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc; margin-bottom: 5px;">Mixture of 50% coolant</div> <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #cccccc;">Mixture of 30% coolant</div> </div>							Every 1000 hrs.	11.0 L (11.6 US qt.)	
		Travel reduction gear	Gear oil API: GL-4	SAE 90							Every 1000 hrs. after the first 250 hrs.*
Carrier roller	Engine oil API: CD class	SAE 30							–	0.060 L (2.0 fl. oz.)	
Track roller	Gear oil API: GL-3	–							–	0.100 L (3.4 fl. oz.)	
Idler	Engine oil API: CD class	SAE 30							–	0.070 L (2.4 fl. oz.)	
Slew bearing	Lithium grease EP-2 NLGI No. 2								Every 50 hrs.	As required	
Working equipment									–		Daily or every 10 hrs.
Levers									–		When required

\* If the ratio of traveling time to total operating time is high, replace the gear oil earlier than the specified time.

\*\* For water, use tap water (soft). Do not use well or river water.

When the ambient temperature drops below 0°C (32°F), add coolant (antifreeze). Follow the coolant manufacturer's instructions to determine the mixture ratio.

\*\*\* The replacement interval for hydraulic oil depends on the type of oil being used. New machines are shipped from the factory with the Takeuchi genuine hydraulic oil 46. This manual describes when to replace the hydraulic oil assuming that this Takeuchi oil is used. When a conventional anti-wear hydraulic oil is used, replace it every 2000 hours.

API Standards: American Petroleum Institute

ACEA Standards: European Automobile Manufacturers' Association

JASO Standards: Japanese Automotive Standards Organization

**Diesel fuel standards**

Use a diesel fuel that is compliant with any of the standards listed below. The table below shows standards from various countries/regions.

Diesel fuel standards	Country/Region
ASTM D975 No. 1-D, S15 No. 2-D, S15	USA Canada
EN590:96	EU
ISO 8217 DMX	International standard
BS 2869-A1 (or A2)	UK
JIS K2204 Grade, 2-go	Japan
KSM-2610	Korea
GB252	China

Part	Type		Capacity
Fuel tank	Diesel fuel	<p>To maintain the performance and service life of the engine, always use clean and high-quality fuel.</p> <ul style="list-style-type: none"> <li>• To avoid freezing in cold climates, use a light oil that still functions when the temperature is at least 12°C (54°F) below the lowest expected ambient temperature.</li> <li>• Use a light oil with a cetane number of 45 or higher. When operating at a very low temperature or at a high altitude, a higher cetane number fuel will be required.</li> <li>• Use fuel with an overall sulfur content below 0.05% to 0.0015%. Be sure to use fuel with an ultra-low sulfur content for applications in the U.S. or Canada, in particular.</li> <li>• The use of fuel containing a high sulfur content may cause sulfuric acid corrosion to occur inside the cylinder.</li> <li>• Do not mix fuel with any kerosene, used engine oil, or left-over fuel.</li> <li>• Poor quality fuel can degrade engine performance. It can also damage the engine.</li> <li>• Refrain from adding additives to the fuel. Some fuel additives can degrade engine performance.</li> </ul>	81 L (21.3 US gal.)

# PERFORMANCE CRITERIA


## Standard values table

Item			Standard value	Allowable value	
Engine speed	Idling	min <sup>-1</sup> (rpm)	1150 <sup>+100</sup> / <sub>-100</sub> ( 1150 <sup>+100</sup> / <sub>-100</sub> )		
	Maximum R.P.M.	min <sup>-1</sup> (rpm)	2350 <sup>+50</sup> / <sub>-50</sub> ( 2350 <sup>+50</sup> / <sub>-50</sub> )		
Hydraulic oil pressure	Boom	MPa (psi)	24.0 <sup>+1.3</sup> / <sub>-0.4</sub> ( 3481 <sup>+189</sup> / <sub>-58</sub> )		
	Arm	MPa (psi)	24.0 <sup>+1.3</sup> / <sub>-0.4</sub> ( 3481 <sup>+189</sup> / <sub>-58</sub> )		
	Dozer blade	MPa (psi)	20.6 <sup>+2.0</sup> / <sub>-0.0</sub> ( 2988 <sup>+290</sup> / <sub>0</sub> )		
	Slew	MPa (psi)	18.6 <sup>+2.2</sup> / <sub>-0.0</sub> ( 2698 <sup>+319</sup> / <sub>0</sub> )		
	Pilot pressure	MPa (psi)	3.3 <sup>+0.3</sup> / <sub>-0.3</sub> ( 479 <sup>+44</sup> / <sub>-44</sub> )		
Cylinder speed	Boom cylinder	Retracted	s	2.5 <sup>+0.5</sup> / <sub>-0.5</sub>	3.3
		Extended	s	2.8 <sup>+0.5</sup> / <sub>-0.5</sub>	3.6
		Retracted	s		
		Extended	s		
	Arm cylinder	Retracted	s	2.1 <sup>+0.4</sup> / <sub>-0.4</sub>	2.7
		Extended	s	2.9 <sup>+0.4</sup> / <sub>-0.4</sub>	3.6
	Bucket cylinder	Retracted	s	1.9 <sup>+0.4</sup> / <sub>-0.4</sub>	2.5
		Extended	s	3.1 <sup>+0.4</sup> / <sub>-0.4</sub>	3.8
	Swing cylinder	Retracted	s	5.4 <sup>+0.8</sup> / <sub>-0.8</sub>	6.7
		Extended	s	5.4 <sup>+0.8</sup> / <sub>-0.8</sub>	6.7
		Retracted	s		
		Extended	s		
	Dozer blade cylinder	Retracted	s	2.1 <sup>+0.4</sup> / <sub>-0.4</sub>	2.7
		Extended	s	2.5 <sup>+0.4</sup> / <sub>-0.4</sub>	3.2
Dozer blade cylinder (with float function)	Retracted	s	1.7 <sup>+0.4</sup> / <sub>-0.4</sub>	2.3	
	Extended	s	2.5 <sup>+0.4</sup> / <sub>-0.4</sub>	3.2	
Slew time	Normal speed	s	12.8 <sup>+1.0</sup> / <sub>-1.0</sub>	15.1	
	Low speed	s			
Overrun when slewing stops		mm (in.)	120 <sup>+50</sup> / <sub>-50</sub> ( 4.7 <sup>+2.0</sup> / <sub>-2.0</sub> )	222 (8.7)	
Natural travel drop		mm (in.)	0.0 ( 0.0 )		
Natural slew drop	Slew bearing	mm (in.)	0.0 ( 0.0 )		
	Swing cylinder	mm (in.)	5.0 <sup>+0.0</sup> / <sub>-5.0</sub> ( 0.2 <sup>+0.0</sup> / <sub>-0.2</sub> )	10.0 (0.4)	
Travel speed 10 m (32.8 ft.)	1st	Rubber	s	12.4 <sup>+1.2</sup> / <sub>-1.2</sub>	14.8
		Steel	s	13.3 <sup>+2.0</sup> / <sub>-2.0</sub>	16.6
	2nd	Rubber	s	7.3 <sup>+1.5</sup> / <sub>-1.5</sub>	9.8
		Steel	s	7.8 <sup>+2.0</sup> / <sub>-2.0</sub>	10.9
Travel speed (5 revs.)	1st	Rubber	s	34.1 <sup>+1.5</sup> / <sub>-1.5</sub>	39.0
		Steel	s	35.9 <sup>+2.0</sup> / <sub>-2.0</sub>	41.5
	2nd	Rubber	s	19.8 <sup>+1.0</sup> / <sub>-1.0</sub>	23.6
		Steel	s	20.8 <sup>+0.0</sup> / <sub>-2.0</sub>	25.7
Straight-ahead traveling		mm (in.)	125.0 <sup>+0.0</sup> / <sub>-125.0</sub> ( 4.9 <sup>+0.0</sup> / <sub>-4.9</sub> )	500 (19.7)	

Straight travel function check	Bucket		To be moved forward using simultaneous operation	
	Arm			
	Boom			
	Dozer blade			
Bucket cylinder speed	Retracted	s	$6^{+1}_{-1}$	
Natural cylinder drop	Boom cylinder	mm (in.)	$4^{+0}_{-4}$ ( $0.2^{+0.0}_{-0.2}$ )	8 (0.3)
	Arm cylinder	mm (in.)	$6^{+0}_{-6}$ ( $0.2^{+0.0}_{-0.2}$ )	12 (0.5)
	Arm cylinder (with emergency shut-off valve)	mm (in.)	$3^{+0}_{-3}$ ( $0.1^{+0.0}_{-0.1}$ )	6 (0.2)
	Bucket cylinder	mm (in.)	$4^{+0}_{-4}$ ( $0.2^{+0.0}_{-0.2}$ )	8 (0.3)
	Dozer blade cylinder	mm (in.)	$4^{+0}_{-4}$ ( $0.2^{+0.0}_{-0.2}$ )	8 (0.3)
	Bucket tip	mm (in.)	$75^{+0}_{-75}$ ( $3.0^{+0.0}_{-3.0}$ )	150 (5.9)
	Bucket tip (with emergency shut-off valve)	mm (in.)	$55^{+0}_{-55}$ ( $2.2^{+0.0}_{-2.2}$ )	110 (4.3)
Backlash		mm (in.)	$18^{+10}_{-10}$ ( $0.7^{+0.4}_{-0.4}$ )	36 (1.4)
Lever play	Right control lever	mm (in.)	$4^{+0}_{-4}$ ( $0.2^{+0.0}_{-0.2}$ )	
	Left control lever	mm (in.)	$4^{+0}_{-4}$ ( $0.2^{+0.0}_{-0.2}$ )	
	Travel lever	mm (in.)	$4^{+0}_{-4}$ ( $0.2^{+0.0}_{-0.2}$ )	
	Dozer blade lever	mm (in.)	$4^{+0}_{-4}$ ( $0.2^{+0.0}_{-0.2}$ )	
Slew bearing play		mm (in.)	$0.5^{+0.4}_{-0.4}$ ( $0.02^{+0.02}_{-0.02}$ )	
Track tension	Rubber	mm (in.)	83 to 93 (3.4 to 3.8)	
	Rubber pads	mm (in.)		
	Steel	mm (in.)	150 to 170 (6.1 to 6.9)	

Remark: Measured with the air conditioner and power mode turned off.

## Hydraulic pump assignment table



2DAA01Z

P1	Right travel, bucket, boom	58.3 L/min. (15.4 US gal./min.)
P2	Left travel, boom swing, 1st auxiliary line piping, arm	58.3 L/min. (15.4 US gal./min.)
P3	Slew, blade, 2nd auxiliary line piping, first auxiliary line piping*, arm*	43.9 L/min. (11.6 US gal./min.)
P4	Pilot pressure, travel speed switching	10.8 L/min. (2.9 US gal./min.)

### Pump P1

Right travel	Pressure: 24.0 MPa (3480 PSI)	Test port A1
Bucket	Pressure: 24.0 MPa (3480 PSI)	Test port A1
Boom	Pressure: 24.0 MPa (3480 PSI)	Test port A1

### Pump P2

Left travel	Pressure: 24.0 MPa (3480 PSI)	Test port A2
Boom swing	Pressure: 24.0 MPa (3480 PSI)	Test port A2
1st auxiliary line piping	Pressure: 24.0 MPa (3480 PSI)	Test port A2
Arm	Pressure: 24.0 MPa (3480 PSI)	Test port A2

### Pump P3

Slew	Pressure: 18.6 MPa (2697 PSI)	Test port A3
Dozer blade	Pressure: 20.6 MPa (2987 PSI)	Test port A3
2nd auxiliary line piping	Pressure: 20.6 MPa (2987 PSI)	Test port A3
3rd auxiliary line piping	Pressure: 20.6 MPa (2987 PSI)	Test port A3

### Pump P4

Pilot pressure	Pressure: 3.3 MPa (479 PSI)	Test port PB
Travel speed switching	Pressure: 3.3 MPa (479 PSI)	Test port PA

\* During composite operation


**Methods for inspecting performance**

**Hydraulic oil pressure (Boom, arm, dozer blade)**


**Measurement method**

- Engine: Maximum R.P.M.
- Hydraulic oil temp.: 50°C to 60°C (122°F to 140°F)
- Install a pressure gauge on the pressure detection port. Operate the hydraulic circuit to be tested, and measure the relief pressure.


Circuit	Relief valve	Pressure detection port	
		Port	Size
Boom	R1	A1	G1/4
Arm	R2	A2	
Dozer blade	R3	A3	



2D0AV01




2D0AW01



2D0AW02

**Adjustment method**

1. Loosen the locknut (2), and turn the setscrew (1) to adjust the set pressure.
  - Turn the setscrew clockwise to increase the set pressure.
  - Turn the setscrew counterclockwise to decrease the set pressure.
2. In order to keep the setscrew (1) from turning after the pressure has been adjusted, tighten the locknut (2) while holding the setscrew (1) firmly in place.
  - Lock nut: 30 ± 2 N·m (22.1 ± 1.5 ft.-lb)
3. Operate the relief valve once more to confirm that the pressure that has been set is stabilized.



2DAG05Z

Sample of manual. Download All 702 pages at:

<https://www.aresairmanual.com/downloads/takeuchi-tb260-mini-compact-excavator-service-repair-workshop-manualbook-n>