

Product: Takeuchi TW60 Series Wheel Loader Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/takeuchi-tw60-series-wheel-loader-service-repair-workshop-manual/>

**TAKEUCHI**®

## Service manual

# WHEEL LOADER SERIES TW60



ISSUE:08-08-07

*It is not allowed to duplicate this service manual, to use it otherwise or to leave it to a third party for evaluation without our explicit consent.*

Sample of manual. Download All 246 pages at:

<https://www.arepairmanual.com/downloads/takeuchi-tw60-series-wheel-loader-service-repair-workshop-manual/>

Product: Takeuchi TW60 Series Wheel Loader Service Repair Workshop Manual

Full Download: [https://www.arepairmanual.com/downloads/takeuchi-tw60-series](https://www.arepairmanual.com/downloads/takeuchi-tw60-series-wheel-loader-service-repair-workshop-manual/)

-wheel-loader-service-repair-workshop-manual/

Sample of manual. Download All 246 pages at:

<https://www.arepairmanual.com/downloads/takeuchi-tw60-series-wheel-loader-service-repair-workshop-manual/>

# ATLAS WEYHAUSEN

F. Weyhausen AG & Co. KG, Maschinenfabrik  
27793 Wildeshausen, Visbeker Straße / 27784 Wildeshausen, Postfach 1763  
Telephon: (04431) 981-0  
Telefax: (04431) 981-0

## I. Preface

This machine has been manufactured in accordance with today's technical standards and all known safety regulations.

However, using it may still pose a danger.

To prevent such dangers and to avoid putting people at risk and damaging the machine, the user must know how the machine works and how it is operated.

It is therefore important to strictly adhere to the

**Safety regulations**

**and**

**Instructions**

for operating the machine.

As the components of the machine are undergoing continuous development, we reserve the right to make changes.

Please do not hesitate to contact us with any queries that you may have:

**Order No. 8015739**



## II. Table of Contents

I.	Preface .....	3
II.	Table of Contents .....	5
<b>0</b>	<b>Introduction .....</b>	<b>9</b>
0.1	User Information on the Service Manual .....	10
0.2	Breakdown of Assembly Groups and Chapter Overview .....	11
0.3	Technical Description of the Wheel Loader .....	12
0.4	Safety Regulations for Work on the Wheel Loader .....	13
0.5	Safety Regulations in the Service Manual .....	14
0.6	Securing the Wheel Loader Prior to Beginning Work .....	15
0.7	Site Where Repair Work is Completed .....	16
0.8	International Measuring Units .....	17
0.9	Tightening Torques .....	18
0.9.1	Hose connections .....	18
0.9.2	Metric headless screws with standard threads .....	19
0.9.3	Metric headless screws with fine threads .....	19
0.9.4	RIPP screws with cheese head and hexagon socket .....	20
0.9.5	RIPP screws and nuts with cheese head and hexagon head .....	20
0.9.6	Self-locking screws and nuts with hexagon head .....	21
0.10	Positioning of Hydraulic Hose .....	22
<b>1</b>	<b>Front and Rear Carriage .....</b>	<b>23</b>
1.1	General Data .....	23
1.2	Front Carriage .....	23
1.3	Repairing the Front Carriage .....	24
1.4	Checking the Articulated Pendulum Joint .....	24
1.4.1	Faults in the articulated pendulum joint .....	24
1.4.2	Checking the assembly dimensions .....	25
1.4.3	Disconnecting the front carriage from the rear carriage .....	26
1.4.4	Checking/Disassembling the pendulum joint and replacing components .....	31
1.4.5	Checking/Disassembling the articulated joint and replacing components .....	34
1.4.6	Joining the front carriage and rear carriage .....	37
1.5	Repairing the Rear Carriage .....	41
1.5.1	Disassembling the engine hood .....	41
1.6	Welding and Preservation Work on the Wheel Loader .....	42
1.6.1	Welding .....	42
1.6.2	Preservation .....	43
1.7	Table of Figures .....	45
<b>2</b>	<b>Hoisting Gear and Hoisting Gear Hydraulics .....</b>	<b>47</b>
2.1	General Data .....	47
2.2	Operating Faults and Solutions .....	48
2.3	Maintenance Work .....	49
2.3.1	Greasing the hoisting gear .....	49
2.4	Repairing the Hoisting Gear and Hoisting Gear Hydraulics .....	50
2.4.1	Checking the hoisting gear .....	50
2.4.2	Disassembling the hoisting gear .....	52
2.4.3	Replacing the hoisting gear components .....	53
2.4.4	Replacing the hoisting gear hydraulic cylinders .....	54
2.4.5	Assembling the hoisting gear .....	55
2.4.6	Completing the hoisting gear .....	56
2.5	Table of Figures .....	57

<b>3</b>	<b>Hydraulic System</b>	<b>59</b>
3.1	Breakdown of Assembly Groups	59
3.2	Technical data	59
3.3	Faults, Causes and Corrective Measures	60
3.4	Setting Instructions, Hydraulic System	65
3.4.1	Operating conditions for correct measurement results	66
3.4.2	Measuring and test instruments	67
3.4.3	Safety regulations, measurement and adjustment work	67
3.4.4	Environmental protection measures	67
3.5	Completing Adjustments	69
3.6	Completing Repairs	85
3.6.1	Completing repairs to the travel pump	85
3.6.2	Repairing the load pump	93
3.6.3	Repairs to the charge pump	96
3.6.4	Repairs to the pump set and travel pump	98
3.6.5	Repairing the travel motor	103
3.7	Repairing the Loading Circuit	109
3.7.1	Repairing the loading circuit control block	109
3.8	Repairing the Hydraulic Cylinders	119
3.8.1	Checking the steering cylinder	119
3.8.2	Checking the lifting and working cylinder	123
3.8.3	Checking the QDC hydraulic system	127
3.8.4	Venting the QDC hydraulic system	131
3.9	Repairing the Steering Circuit	133
3.9.1	Repairing the steering unit	133
3.10	Repairing the Hydraulic Components	137
3.10.1	Repairing the inching valve	137
3.10.2	Repairing the differential lock control block	140
3.10.3	Checking the hydraulic oil cooler (combined cooler)	142
3.11	Checking the Hydraulic Circuit	145
3.11.1	Checking the hydraulic oil	145
3.11.2	Venting the hydraulic circuit	147
3.11.3	Operating the vacuum pump	149
3.11.4	Rinsing the hydraulic circuit	150
3.11.5	Replacing the hydraulic oil sort (to biological oil)	152
3.12	Table of Figures	155
	<b>Appendix to Chapter 3: Hydraulic System Circuit Diagram</b>	<b>159</b>

<b>4</b>	<b>Electrical System</b>	<b>163</b>
4.1	General Data	163
4.1.1	Overview of fuses	164
4.1.2	Overview of relays	165
4.1.3	Overview of lighting	165
4.1.4	Overview of switches	166
4.2	Operating Faults and Solutions	167
4.3	Service and Maintenance Work	168
4.3.1	Service and maintenance work on the battery	168
4.3.2	Checking the electrical system	168
4.4	Setting Instructions	169
4.5	Completing Repairs	170
4.5.1	Before beginning work	170
4.5.2	Repairing the control board	171
4.5.3	Repair work on the cab electrical system	173
4.5.4	Repairing the lighting system	176
4.5.5	Replacing the relay in the engine compartment	177
4.5.6	Replacing the hand brake switch	177
4.5.7	Replacing the brake light switch	177
4.6	Table of Figures	179
<b>Appendix to Chapter 4: Electric System Circuit Diagrams</b>		<b>181</b>
<b>5</b>	<b>Diesel Engine</b>	<b>193</b>
5.1	General Data	193
5.2	Technical Data	194
5.2.1	Diesel engine	194
5.2.2	Fuel	194
5.2.3	Engine oil	194
5.3	Faults, Causes, Solutions	195
5.3.1	Faults, causes and solutions related to the diesel engine	195
5.4	Maintenance Work on the Diesel Engine	196
5.4.1	Securing the wheel loader	196
5.4.2	Maintenance table	197
5.4.3	Checking and changing the engine oil	198
5.4.4	Visual inspection of the engine and checking the unit for leaks	199
5.4.5	Cleaning the engine cooling system (water cooling)	199
5.4.6	Cleaning the air filter	200
5.4.7	Checking the engine mount	201
5.4.8	Checking the fuel system	201
5.4.9	Venting the fuel system	202
5.4.10	Changing the fuel prefilter	202
5.4.11	Changing the fuel filter	203
5.4.12	Changing the engine oil filter	203
5.5	Setting Instructions	204
5.5.1	Checking the engine speed	204
5.5.2	Checking the fan belt	205
5.6	Completing Repairs	206
5.6.1	Replacing the accelerator cable	206
5.6.2	Replacing the exhaust system	207
5.7	Table of Figures	209

<b>7</b>	<b>Axles and Brakes .....</b>	<b>211</b>
7.1	General Data .....	211
7.1.1	Technical data .....	211
7.2	Operating Faults and Solutions .....	212
7.3	Maintenance Work, Axles and Drum Brake .....	213
7.3.1	Lubricants and filling quantities .....	213
7.3.2	Checking the oil level axle .....	213
7.3.3	Checking and changing the brake fluid .....	216
7.4	Completing Repairs .....	218
7.4.1	Securing the wheel loader for work on the axles .....	218
7.4.2	Replacing the cardan shaft .....	218
7.4.3	Replacing the front axle .....	219
7.4.4	Replacing the rear axle .....	220
7.4.5	Repair work on the drum brake .....	221
7.4.6	Disassembling the hydraulic drum brake .....	222
7.4.7	Assembling the hydraulic drum brake .....	226
7.4.8	Replacing the hand brake cable .....	231
7.4.9	Checking and replacing the axle transfer box .....	232
7.5	Table of Figures .....	237
<b>8</b>	<b>Operator's Cab .....</b>	<b>239</b>
8.1	Breakdown of Assembly Groups .....	239
8.2	Cleaning and Maintenance Work .....	239
8.3	Replacing the operator's seat .....	240
8.4	Table of Figures .....	241
9.1	Table of Topics .....	243

## 0 INTRODUCTION

### Qualification of personnel

This manual has been written for service personnel trained by TAKEUCHI to complete maintenance and repair work on their wheel loaders.

### Product

This manual documents a TAKEUCHI production series product with construction status complying with the date of issue.

### Service

The maintenance and repair measures for machines may require different working procedures or setting and test data from that described here as a result of further technical developments to the product.

Therefore, we recommend you have your TAKEUCHI wheel loader inspected by service personnel whose practical and theoretic training is constantly brought up-to-date by our customer service personnel.

Repair work carried out by TAKEUCHI service stations is also covered by the warranty within the scope of the current contractual conditions.

Damage caused as a result of work being completed improperly and unprofessionally by personnel not authorized by the manufacturer, and any consequential costs, are excluded from any contractual liability.

This also applies to the failure to use original spare parts from TAKEUCHI.

– TAKEUCHI Service –

## USER INFORMATION ON THE SERVICE MANUAL

## 0.1 User Information on the Service Manual

**NOTE**

This Service Manual is intended for service personnel trained by us.

All the work described here may only be performed by this group of personnel.

### To all manual users

The use of this Service Manual should help you to localize sources of faults quicker and easier, and to eliminate them by performing the repair work described.

If your equipment becomes defect, localize the fault according to the procedures described here.


Years of experience gained by our service technicians in the repair of wheel loaders represent the basis of the contents of this Service Manual.

### Using the manual

The manual provides a basis for:

- A quick reference of possible faults and how to clear them.
- Clear descriptions of all the adjustment and setting values.
- Chronological descriptions of the various repair work, disassembly and assembly of components.
- Overview of the tools necessary.
- Simple, unambiguous identification of spare parts.
- Quick access to overviews and circuit diagrams concerning the hydraulic and electric systems.
- Basic information on the hydraulic system, electrical installations and vehicle construction.
- Details on consumables and emissions.
- Vehicle and technical data.

## 0.2 Breakdown of Assembly Groups and Chapter Overview



MAIN GROUPS	DESCRIPTION	PAGE
100	Front and Rear Carriage	23
200	Hoisting Gear and Hoisting Gear Hydraulics	43
300	Hydraulic System	59
400	Electrical System	163
500	Diesel Engine	193
600	not applicable for wheel loader models with standard electric	-
700	Axles and Brakes	211
800	Operator's Cab	239

## TECHNICAL DESCRIPTION OF THE WHEEL LOADER

## 0.3 Technical Description of the Wheel Loader

### Definition of a wheel loader

A wheel loader is a construction site machine for transporting loads close to the ground, predominantly bulk material.

A working cycle is comprised of filling, raising, transporting and depositing the material.

### Deployment options

The possibility of changing attachments quickly and easily by means of a hydraulic Quick Disconnect Coupler (QDC) means that a wheel loader, which has just been used to transport bulk material, can be converted to a transport vehicle for pallets loaded with bricks or other materials.

### Constructional design

The connection of the front carriage and rear carriage by means of an articulated pendulum joint ensures the wheel loader can be well maneuvered and steered on off-road terrain.

- The angular movement is  $\pm 12^\circ$ .
- The full lock of the steering wheel per side (jack-knifing) is  $40^\circ$ .

The hoisting gear for the loading movement is fitted on the front carriage.

The shovel size and the maximum load depend on the attachment selected.

The rear carriage contains the components for the drive, diesel engine, hydraulic system, electrical installations and operator's cab.

The front carriage consists of the front axle, hoisting gear and loading circuit.

### Hydraulic system

The diesel engine installed in the rear carriage drives a combined pump set directly.

This pump set supplies all the hydraulic circuits with the necessary quantity of hydraulic oil. All driving and loading movements of the wheel loader are generated and controlled hydraulically. The wheel loader is equipped with a central, hydrostatic drive which acts on all four wheels.

### Operator's workplace

The operator is provided with a generous sized operator's cab equipped with large windows and well-arranged operator controls.

The operator's cab is made of a welded steel frame construction and is a roll-over protected structure (ROPS) in compliance with DIN/ISO 3471.

The operator receives vehicle information via an operating and display console on the steering column.

## SAFETY REGULATIONS FOR WORK ON THE WHEEL LOADER

**Heating and ventilation**

The interior of the cab is provided with a multistage ventilation device which draws in fresh air, filtered, from outside.

The air for the interior of the cab can be heated by continuously variable thermoregulators. Heat is supplied by means of heated engine oil from the diesel engine.

**Operator's seat and joystick**

An adjustable, sprung, operator's seat, complying to safety requirements, protects the operator from vehicle jolting.

The joystick (control lever) is located in the adjustable armrest to the right of the operator's seat. The joystick is used to control the movements induced by the loading circuit.

Switches in the joystick switch the drive functions such as forwards/reverse, cross-country reduction gear and differential lock.

A further control lever beside the joystick controls the functions of the Quick Disconnect Coupler (QDC) or 4th section.

## 0.4 Safety Regulations for Work on the Wheel Loader

<b>NOTE</b>	All the safety precautions and operating instructions necessary to operate the wheel loader are provided in the relevant wheel loader operating manual.
<b>⚠ WARNING</b>	The safety and warning information provided in this Service Manual must be observed prior to starting the repair work and during its completion.
<b>NOTE</b>	It is essential to observe any overriding laws and directives applicable in your country concerning the deployment and use of construction site machines. Familiarize yourself with them and their content and check that they are observed.
<b>NOTE</b>	Apply warning and danger signs to the wheel loader on which repairs are to be carried out. Take applicable measures to ensure that the wheel loader <b>cannot</b> be started up.

## SAFETY REGULATIONS IN THE SERVICE MANUAL

## 0.5 Safety Regulations in the Service Manual


The Service Manual contains attention and warning symbols indicating risks.

These attention and warning symbols are intended to make you aware of situations which could lead to personal injury and property damage.

 <b>DANGER</b>	Sources of danger which could lead to fatal or severe personal injury.
 <b>CAUTION</b>	Activities or lack of concentration during work which could lead to fatal or severe personal injury.
 <b>WARNING</b>	Activities or lack of concentration during work which could lead to personal injury or property damage.
 <b>NOTE</b>	Indication of special technical features to be observed during disassembly or assembly of components to prevent machine damage.

## SECURING THE WHEEL LOADER PRIOR TO BEGINNING WORK

## 0.6 Securing the Wheel Loader Prior to Beginning Work



e-00-00000000000000000000000000000000

## Securing measures

- Lower the attachment to its home position.
- Stop the diesel engine and prevent it from being switched on again by removing the ignition key.
- Apply the hand brake.
- Place wheel chocks under the wheels to secure them.
- Check the hydraulic circuit is depressurized.
- Put the electrical system out of service by disconnecting the minus or plus pole of the battery.
- When working on the front carriage, front axle, brake system or steering, always install the articulation lock.

## Tools and aids

Always work using the tools and aids described in the repair instructions.


**WARNING**

Makeshift solutions and tools often lead to injuries to personnel and damage to the equipment.

**NOTE**

In the descriptions of the adjustment and repair work, pay attention to the measuring instruments and test devices prescribed and to any information on the use of special tools.

## 0.7 Site Where Repair Work is Completed



### Working on construction sites

If repair work must be completed at the construction site, find a safe working base:

- Pay attention the wheel loader is parked on solid ground.
- Apply the hand brake.
- Place wheel chocks under the wheels to secure them.
- Protect the working area from moisture and dirt.

### Working in workshops:

If the wheel loader can be repaired in a workshop, clean the wheel loader before starting the work.

#### DANGER

#### Risk of toxication!


Ensure sufficient ventilation if the diesel engine is run inside closed rooms.

- Ensure sufficient ventilation of the hall if the diesel engine is run for longer periods.
- If the diesel engine is run for longer periods in the hall, a gas extractor must be installed.
- If the wheel loader is driven over an inspection pit, pay attention the wheels are a safe distance from the edges of the pit.

### After completing the repair work

Restore the wheel loader to a safe operating condition.

- After starting up the wheel loader, check for leaks in the hydraulic system.
- Test the functions of the wheel loader.



## 0.8 International Measuring Units

EUROPE	USA
25,40 mm	1 in (inch)
1 kg (Kilogramm)	2,205 lb (pounds)
9,81 Nm (1 kpm)	7,233 lbf x ft (pound force foot)
1,356 Nm (0,138 kpm)	1 lbf x ft (pound force foot)
1 kg / cm	5,560 lb / in (pound per inch)
1 bar (1,02 kp/cm <sup>2</sup> )	14,233 psi (pound force per square inch lbf/in <sup>2</sup> )
0,070 bar (0,071 kp/cm <sup>2</sup> )	1 psi (lbf/in <sup>2</sup> )
1 Liter	0,264 Gallon (Imp.)
4,456 Liter	1 Gallon (Imp.)
1 Liter	0,220 Gallon (US)
3,785 Liter	1 Gallon (US)
1609,344 m	1 Mile (land mile)
0°C (Celsius)	32°F (Fahrenheit)
0°C (Celsius)	273,15 Kelvin

## 0.9 Tightening Torques

### 0.9.1 Hose connections

TIGHTENING TORQUES $M_A$ IN [Nm] FOR CONNECTIONS						
ROW	TUBE A. Ø	DN	THREAD	Test Pressure [bar] (1)	DKL (2)	DKOL (2)
L	6	5	M12x1.5	375	10-12	8-10
L	8	6	M14x1.5		12-15	10-13
L	10	8	M16x1.5		20-23	18-23
L	12	10	M18x1.5		30-35	27-32
L	15	13	M22x1.5		50-55	45-50
L	18	16	M26x1.5		75-85	70-80
L	22	20	M30x2.0		110-120	100-110
L	28	25	M36x2.0		160-180	150-160
L	35	32	M45x2.0		240-260	200-220
L	42	40	M52x2.0		320-350	300-320
					DKS (2)	DKOS (2)
S	8	5	M14x1.5	960	20-25	18-23
S	10	6	M16x1.5		30-35	27-32
S	12	8	M20x1.5		45-50	40-50
S	14	10	M22x1.5		60-70	50-60
S	16	13	M24x1.5	600	80-100	70-90
S	20	16	M30x2.0		130-150	120-140
S	25	20	M36x2.0		240-270	200-240
S	30	25	M42x2.0	375	360-400	320-360
S	38	32	M52x2.0		600-640	520-560
<b>Counterpart:</b> Screwed end DIN 3853 Bore form W DIN 3861 Row L+S				(1)Complies with EO nominal pressure + 50% (2)Union nuts complying with DIN 3870 Form A		

## 0.9.2 Metric headless screws with standard threads

DIMENSIONSx P	TIGHTENING TORQUE $M_A$ [Nm]				
	4.6	5.6	8.8	10.9	12.9
M 4 x 0.7	1,02	1,37	3,3	4,8	5,6
M 5 x 0.8	2,0	2,7	6,5	9,5	11,2
M 6 x 1.0	3,5	4,6	11,3	16,5	19,3
M 8 x 1.25	8,4	11	27,3	40,1	46,9
M 10 x 1.5	17	22	54	79	93
M 12 x 1.75	29	39	93	137	160
M 14 x 2.0	46	62	148	218	255
M 16 x 2.0	71	95	230	338	395
M 18 x 2.5	97	130	329	469	549
M 20 x 2.5	138	184	464	661	773
M 22 x 2.5	186	250	634	904	1057
M 24 x 3.0	235	315	798	1136	1329
M 27 x 3.0	350	470	1176	1674	1959
M 30 x 3.5	475	635	1597	2274	2662
M 33 x 3.5	645	865	2161	3078	3601
M 36 x 4.0	1080	1440	2778	5957	4631
M 39 x 4.0	1330	1780	3597	5123	5994

## 0.9.3 Metric headless screws with fine threads

DIMENSIONSx P	TIGHTENING TORQUE $M_A$ [Nm]		
	8.8	10.9	12.9
M 8 x 1	29,2	42,8	50,1
M 9 x 1	42,6	62,6	73,3
M 10 x 1	60	88	103
M 10 x 1.25	57	83	98
M 12 x 1.25	101	149	174
M 12 x 1.5	97	143	167
M 14 x 1.5	159	234	274
M 16 x 1.5	244	359	420
M 18 x 1.5	368	523	613
M 18 x 2	348	496	581
M 20 x 1.5	511	728	852
M 22 x 1.5	692	985	1153
M 24 x 1.5	899	1280	1498
M 24 x 2	865	1232	1442
M 27 x 1.5	1304	1858	2174
M 27 x 2	1262	1797	2103
M 30 x 2	1756	2502	2927
M 33 x 2	1352	3350	3921
M 36 x 2	3082	4390	5137
M 39 x 2	3953	5631	6589

## 0.9.4 RIPP screws with cheese head and hexagon socket

TERMINOLOGY		M5	M6	M8	M10	M12
Across flat dimension	S	4	5	6	8	10
Torque Figures M <sub>A</sub> / Nm	Fkl.	on connecting material steel R <sub>m</sub> < 800 / ≥ 800 N/mm <sup>2</sup>				
	90/80 RG	-	-	-	-	-
	100/10 RG	13/11	24/20	45/42	90/85	150/140
	100/10 FG	-	-	-	-	-
	12.9/12 RG	15/13	28/24	52/50	115/105	180/160
	12.9/12 FG	-	-	-	-	-
RG = Standard thread FG = Fine thread	Fkl.	on connecting material gray cast iron				
	90/80 RG	-	-	-	-	-
	100/10 RG	10	19	39	80	120
	100/10 FG	-	-	-	-	-
	12.9/12 RG	12	22	48	95	140
	12.9/12 FG	-	-	-	-	-


## 0.9.5 RIPP screws and nuts with cheese head and hexagon head

TERMINOLOGY		M5	M6	M8	M10	M12	M14	M16
Across flat dimension	S	8	10	13	15	17	19	22
Torque Figures M <sub>A</sub> / Nm	Fkl.	on connecting material Rm steel <800/ > 800 N/mm <sup>2</sup>						
	90/80 RG	-	-	-	-	-	-	-
	100/10 RG	11/10	19/18	42/37	85/80	130/120	230/215	330/310
	100/10 FG	-	-	45/40	95/90	145/138	250/240	370/350
	12.9/12 RG	13/12	22/20	50/45	100/90	165/155	275/255	410/390
	12.9/12 FG	-	-	55/50	110/ 105	175/165	300/290	440/420
RG = Standard thread FG = Fine thread	Fkl.	on connecting material gray cast iron						
	90/80 RG	-	-	-	-	-	-	-
	100/10 RG	9	16	35	75	115	200	300
	100/10 FG	-	-	38	85	130	230	335
	12.9/12 RG	11	18	43	85	150	240	380
	12.9/12 FG	-	-	48	100	160	275	400


## 0.9.6 Self-locking screws and nuts with hexagon head

TERMINOLOGY		M5	M6	M8	M10	M12	M14	M16
Across flat dimension	S	8	10	13	15	17	19	22
Torque Figures M <sub>A</sub> / Nm	Fkl.	on connecting material steel						
	90/80 RG	9	16	34	58	97	155	215
	100/10 RG	12	21	44	75	120	185	280
	100/10 FG	-	-	-	-	-	-	-
	12.9/12 RG	14	25	52	90	145	220	340
	12.9/12 FG	-	-	-	-	-	-	-
RG = Standard thread FG = Fine Thread	Fkl.	on connecting material gray cast iron						
	90/80 RG	7	13	28	49	83	130	195
	100/10 RG	9.5	16	36	64	105	170	260
	100/10 FG	-	-	-	-	-	-	-
	12.9/12 RG	11	19	43	72	125	200	320
	12.9/12 FG	-	-	-	-	-	-	-


## 0.10 Positioning of Hydraulic Hose




Torsion of hoses is to be avoided because the restoring torque under load may lead to detachment of the connection or cause a defect on the hose line.




Run hoses in elbows of sufficient diameters in order to prevent kinks or a tear-out under pressure. Narrow elbows flatten the hose and thus obstruct the free flow. In addition, the life expectancy of the hose is shortened considerably.




The installation of hose lines on moving parts is to be planned very carefully. Bending radius, torsional strain and a sufficient hose length are to be determined in such a way that none of them falls below the specified values.



The hose length can be kept shorter when using elbow fittings, adapters and hose clamps, which has the additional advantage of a clear arrangement and better appearance. Special attention has to be paid of course to the bending and change of length of the hose.




When fitting hose lines, a tensile load caused by the change of length of the hose is to be avoided in all operating conditions, this does not apply to the hose's own weight.



In case of high ambient temperatures hose lines must be installed in such a way that a safe distance is kept to hot components. Use a heat protection or a fire protecting hose.

# 1 FRONT AND REAR CARRIAGE

## 1.1 General Data




### Breakdown of assembly groups

The front and rear carriages of the wheel loader are comprised of 4 assembly groups:

- 1 Counterweight
- 2 Rear carriage (base frame)
- 3 Articulated pendulum joint
- 4 Front carriage

These four components form the wheel loader chassis.

## 1.2 Front Carriage



### Design

The front carriage (4) is made of a steel construction.

The front carriage forms the base for the hoisting gear (5) with hydraulic cylinders.

The front axle (6) is located below the front carriage.

The articulated pendulum joint (3) connects the front and rear carriages.

The articulation of the front carriage produces the corner steering of the wheel loader.

Articulation is produced by the steering cylinder (7) extending and retracting.

## 1.3 Repairing the Front Carriage

Check the screw fittings between the front axle and front carriage within the scope of a vehicle inspection or visit to the workshop.

### NOTE

Tighten the screw connections according to the prescribed torque.

The necessary torque is listed in the table **Tightening Torques for Screws**.

## 1.4 Checking the Articulated Pendulum Joint




Fig.1.3 Greasing the articulated pendulum joint

### Design

The articulated pendulum joint (3) is comprised of two individual joint components:

- articulated joint,
- pendulum joint.

The articulated joint enables the front carriage to be turned 40° to each side.

The pendulum joint enables an angular movement of  $\pm 12^\circ$  between the front and rear carriage.

### Maintenance work

The articulated pendulum joint must be greased at regular intervals.

- Check the greasing condition of the articulated pendulum joint.
- Use a grease gun to grease the three greasing points (3.3) of the articulated pendulum joint daily.
- At the same time, check the greasing condition of the steering cylinder.
- Grease the greasing points (7.3) of the steering cylinder once a month.

### 1.4.1 Faults in the articulated pendulum joint

#### Faults

- If noises occur during the full lock of the steering wheel which cannot be cleared through cleaning or greasing, check the articulated joint of the wheel loader.
- If noises occur during angular movements of the wheel loader or the angular movements are jerky, check the pendulum bearing.

## CHECKING THE ARTICULATED PENDULUM JOINT



## 1.4.2 Checking the assembly dimensions

The compensating disks in the articulated joint could be worn as a result of wear or deficient greasing.

If this happens, or the articulated joint causes noises when turning the steering wheel, check the assembly dimension.

## NOTE

Before checking and restoring the assembly dimensions of the articulated joint, park the wheel loader on a level surface and secure it.



## Checking the assembly dimension, left

Determine the dimension **X** = ##### between the top and bottom bore holes **B** in the front carriage.

- To determine the dimensions, articulate (steer) the front carriage fully to the right when on a level surface.
- Then secure the wheel loader.
- Clean the section around the articulated joint.
- First, determine dimension **X1** from the top edge of the top bore hole **B** to the bottom edge of the bottom bore hole **B** in the front carriage using applicable sliding calipers.
- Measure the material thickness **X2** of the top and bottom bore hole **B** in the front carriage mounting.
- From the previously measured total dimension **X1**, subtract the material thickness of the two bolt holes **X2**.
- Note down dimension **X** calculated in this way.

## Checking the assembly dimension, right

Carry out the same measurement on the opposite side of the articulated joint.

- To do this, start the wheel loader and articulate it fully to the left.
- Then secure the wheel loader again.
- Carry out the measurement as described previously and determine dimension **X** for this side.

## Determining assembly dimension deviation

Use the dimensions to determine the deviations, refer to example calculation:

- 1. Left dimension **X** = 287.7 minus 287 = 0.7 mm
- 2. Right dimension **X** = 287.5 minus 287 = 0.5 mm
- Add the two values calculated and divide the result by 2.
- The value established determines the thickness of the shim **A** to insert.
  - **A** from 0.1 to 0.5 mm = 0.5 mm shim.
  - **A** over 0.5 mm = 1.0 mm shim.

### 1.4.3 Disconnecting the front carriage from the rear carriage

#### NOTE

The repair work described here may only be carried out in the workshop.




Fig.1.6 Securing the wheel loader

#### Securing the wheel loader

To disassemble the articulated pendulum joint, the front carriage must be separated from the rear carriage; secure the wheel loader to do this.

- Lower the attachment to its home position, refer to the operating manual.
- Stop the diesel engine and prevent it from being switched on again by removing the ignition key.
- Apply the hand brake.
- Place wheel chocks under the wheels to secure them.
- Check the hydraulic circuit is depressurized; depressurize it, if necessary.

#### Disassembling the cardan shaft on the front axle

#### ⚠ WARNING

After disassembling the cardan shaft, the hand brake no longer affects the rear axle.

Place sufficient wheel chocks under the tires to secure the rear wheels.

Secure all four wheels of the wheel loader with wheel chocks.




Fig.1.7 Disassembling the cardan shaft on the front carriage

- In order to be able to reassemble the cardan shaft (1) in the correct position **M** following repair, mark the cardan shaft flange position and junction point.
- Loosen the nuts (2) on the flange connection cardan shaft-front axle and screw off the nuts.
- Slide the cardan shaft (1) together sufficiently far until the front axle is free.
- To ensure the front section of the cardan shaft does not fall off, fix the cardan shaft (1) to the base frame.
- Release the hand brake.

## CHECKING THE ARTICULATED PENDULUM JOINT

## Disassembling the hoisting gear's hydraulic connections

## NOTE



When hydraulic components, such as hydraulic hoses, hydraulic cylinders or valves are unscrewed, hydraulic oil escapes from the openings. Collect escaping hydraulic oil in suitable containers or clear up with cleaning cloths. Pay attention that hydraulic oil never escapes onto open ground.




Fig.1.8 Hoisting gear hydraulic connections

- Mark all the hydraulic hoses and cables to ensure easy reassembly later.
- Six hydraulic connections to the hydraulic cylinders (2 x lifting cylinders **6.10**, 2 x working cylinder **6.11** and 2 x for the QDC (Quick Disconnect Coupler) must be disassembled.
- Disassemble the cover plate (3) below the working cylinder in the front carriage.
- Unscrew the hose connections for the hoisting cylinder **6.10**.
- Seal the hoses and connections using seal plugs and caps.
- Clear up any escaping oil immediately with cleaning cloths.

## CHECKING THE ARTICULATED PENDULUM JOINT





Fig.1.9 Hydraulic connections steering cylinder and front axle




Fig.1.10 Disassembling the steering cylinder

### Disassembling the hydraulic connections to the steering cylinder and front axle

- Unscrew the hose connections (4) from the steering cylinder 4.4.
- Place oilpans under the front axle.
- Unscrew the differential lock connection (5) from the front axle.
- Seal the connection bore holes in the front axle and the hose line with seal plugs.
- Disassemble the brake line (6) from the drum brake (7) and seal it immediately.
- Identify the brake line (6) clearly.
- Disassemble the hand brake cable (8) from the drum brake (7).
- Seal the hoses and connections using seal plugs and caps.
- Clear up any escaping oil immediately with cleaning cloths.

### Disassembling the steering cylinder from the articulated pendulum joint

- If the articulated joint needs to be disassembled, disassemble the steering cylinder.
- Unscrew the safety screw (1.1) in the piston rod bolt (1) out of the piston rod.
- Press the piston rod bolt (1) out of the articulated pendulum joint.
- Support the steering cylinder 4.4 in the front carriage.

## CHECKING THE ARTICULATED PENDULUM JOINT

## Disconnecting the electrical connections

## NOTE

Before beginning work on the electrical installation, always remove the positive pole from the battery using an insulated wrench.



Fig.1.11 E connections, front carriage

- Mark the cables so that they can be correctly assigned again during reassembly.
- Disconnect the electrical connections from the headlights (10).
- Bundle the cables together, tie them and fix the bundle to the hose bundle.




Fig.1.12 Hydraulic hoses hose clamping device

## Removing the hydraulic hoses and cables

- Open the hose clamping devices and pull out the hoses with casing.
- Loosen the central hose clamping device (11) over the articulated joint.
- Pull the hydraulic hoses out of the front carriage.
- Bind the hoses together and fix the hose bundle to the cab side panel.

## CHECKING THE ARTICULATED PENDULUM JOINT

### Disconnecting the front carriage from the rear carriage

#### NOTE

This repair work can only be carried out in a workshop.




Fig.1.13 Disconnecting the front and rear carriages

- Ensure the crane or hoisting system has a sufficient lifting capacity.
- Support the front and rear carriages before separating them.
- Prop the rear carriage and place jacks or blocks under the rear carriage's counterweight **X**.
- If necessary, prop the front carriage underneath the front carriage mounting **Y**.

### Determining the separating point

Separation of the front carriage from the rear carriage is influenced by which bearing (pendulum bearing or articulated bearing) is to be replaced.

#### NOTE

The work is completed from underneath the wheel loader. Drive the wheel loader over an inspection pit. If no inspection pit is available, secure the wheel loader sufficiently with wheel chocks.

#### NOTE

If repairs are necessary on the articulated bearing or bolt, disconnect the front and rear carriages at the articulated joint, otherwise at the pendulum joint.