


ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
1	25/904700	Control Valve	2
2	25/904701	:Body	Upper	1
3	N.S.P.	:Body	Lower	1
4	25/904702	:Seal Kit	1
5	N.S.P.	::Dowel	2
6	N.S.P.	::'O' Ring	1
7	N.S.P.	::'O' Ring	1
8	N.S.P.	::'O' Ring	1
9	N.S.P.	::Capscrew	1
10	25/904703	:Seal Kit	1
11	N.S.P.	::Plunger Guide	4
12	N.S.P.	::Seal	4
13	N.S.P.	::Seal	4
14	N.S.P.	::Plunger	4
15	25/904704	:Disc	4
16	25/904705	:Retainer	4
17	25/904706	:Spring	4
18	25/904707	:Spring	4
19	25/904708	:Shim	A/R
20	25/904709	:Shim	A/R
21	25/904710	:Shim	A/R
22	N.S.P.	:Piston	4
23	25/904711	:Lever Kit	1
24	N.S.P.	::Lever Half	2
25	N.S.P.	::Cap	1
26	N.S.P.	::Screw	1
27	N.S.P.	::Nut	3
28	N.S.P.	::Screw	2
29	N.S.P.	::Washer	2
30	N.S.P.	::Washer	2
30	N.S.P.	::Blanking Plate	1
31	N.S.P.	::Screw	2
32	N.S.P.	::Adapter	1
33	25/904712	:Nut	1
34	25/904713	:Nut	1
35	25/904714	:Gaiter	1




ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
36	25/904715	:Switch Plate	1
37	25/904716	:Coupling	1
38	25/904717	:Retainer	1
39	25/904718	:Seal	1
40	1305/0002	Bolt	8



E 1-7-3 SERVO CONTROL CIRCUIT

5000M ISSUE




ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
37	611/21600	Hose	1
38	612/20900	Hose	1
39	816/50022	Tee Piece	1
40	612/20400	Hose	1
41	611/00800	Hose	1
42	1604/0002	Adapter	1
43	611/01100	Hose	1
44	816/00367	Tee Piece	1
45	1604/0002	Adapter	2
46	1406/0011	Dowty Seal	3
47	See Page E3-4-2		Track/Slew Valve	1
48	816/00367	Tee Piece	1
49	611/20800	Hose	1
50	208/30500	Shuttle Valve	1
	N.S.P.	:Body	1
	831/00069	:Roller	1
	816/60042	:Adapter	2
	1406/0011	:Dowty Seal	2
51	1612/0002	Adapter	1
52	611/20800	Hose	1
53	611/21600	Hose	1
54	612/20900	Hose	1
55	1604/0006	Adapter	1
56	1406/0021	Dowty Seal	1
57	816/00344	Tee Piece	1
58	615/21100	Hose	1
59	1604/0006	Adapter	1
60	See Index B1	Hydraulic Tank	1




E 1-7-3 SERVO CONTROL CIRCUIT

5000M ISSUE


1




ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
1	208/00703	Manifold	1
2	1406/0026	Dowty Seal	1
3	1604/0008	Adapter	1
4	617/20700	Hose	1
5	1606/0012	Adapter	1
6	1406/0021	Dowty Seal	1
7	See Page E2-1-1		Pump	1
8	1406/0018	Dowty Seal	1
9	1604/0004	Adapter	1
10	613/22300	Hose	1
11	658/00561	Pipe	1
12	1356/0004	Back Nut	2
13	613/23100	Hose	1
14	1604/0004	Adapter	1
15	1406/0018	Dowty Seal	1
16	See Page E3-14-1		Relief Valve	1
17	1406/0018	Dowty Seal	1
18	1604/0004	Adapter	1
19	816/50012	Tee Piece	1
20	612/20400	Hose	1
21	1606/0003	Adapter	4
22	1406/0011	Dowty Seal	12
23	See Page E3-6-3		Control Unit	2
24	1604/0002	Adapter	8
25	611/01100	Hose	1
26	1604/0002	Adapter	1
27	611/20300	Hose	1
28	1606/0003	Adapter	6
29	1406/0015	Dowty Seal	6
30	See Page E3-1-2		Excavator Valve	1
31	611/21600	Hose	1
32	611/01100	Hose	1
33	1604/0002	Adapter	1
34	611/20300	Hose	1
35	611/21600	Hose	1
36	611/20600	Hose	1



ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
1	208/46300	Cab-STD	1
1A	208/46600	Cab-With Roof Light	1
2	208/40500	:Door	1
3		::Hinge	1
4	208/43700	:Locking Handle	1
5	106/14503	::Key	2
6	1360/0208	:Bolt	3
7	208/38201	:Plate	1
8	110/40201	:Inner Handle	1
9	1360/0211	:Bolt	1
10	208/41800	:Slam Lock	1
11	826/00551	:Door Retainer	1
12	1370/0103	:Nut	2
13	1412/0001	:Washer	2
14	1315/0208	:Bolt	1
15	1315/0207	:Bolt	1
16	1420/0006	:Washer	1
17	1425/0006	:Spring Washer	1
18	208/41900	:Guard-Roof Light	1
19	1305/0103	:Bolt	6
20	1416/0005	:Spring Washer	6
21	257/19201	Grille	1
22	926/02300	Seal Strip	1460 Long	1
23	835/00020	Plug	1
24	2410/1003	Grommet	1
25	926/02200	Door Beading	855mm Long	1
26	1414/0011	Washer	2
27	1360/0204	Bolt	2
28	208/46202	Retainer	4
29	206/50422	Rubber Mounting	6
30	208/47300	Hose Bracket	3
31	1350/0103	Nut	12
32	1410/0002	Washer	24
33	1305/3116	Bolt	12
34	1340/0103	Nut	6
35	208/46203	Bulkhead	2
36	See Page C 1-3-1		Instrument Panel	1




ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
37	208/00204	Mounting	4
38	1305/3622	Bolt	4
39	1412/0007	Washer	8
40	1340/0603	Nut	4
41	1410/0007	Washer	2
42	819/00025	Shim-3mm.	A/R
43	819/00026	Shim-6mm.	A/R



ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
1	40/201200	Seat	1
2	208/47600	Bracket	2
3	208/47500	Bracket	1
4	1340/0001	Nut	8
5	1305/0003	Bolt	8
6	1416/0004	Spring Washer	8
7	1305/0205	Bolt	4
8	1411/0003	Washer	4
9	1305/0214	Bolt	4
10	1410/0003	Washer	4
11	208/46201	Gaiter	2
12	2201/0018	Clip	2
13	829/00063	Spacer	4



ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
1	208/48901	Control Lever	2
2	108/65101	Knob	2
3	910/18600	Track Control Assembly R.H.	1
4	910/18700	Track Control Assembly L.H.	1
5		:Boot	1
6		:Plate	1
7		:Cable Assembly R.H.	1
8		:Cable Assembly L.H.	1
9		::Plate	1
10		::Clevis Pin	1
11	1305/3118	Bolt	4
12	1410/0002	Washer	8
13	1340/0104	Nut	4
14	1305/1614	Bolt	4
15	920/00157	Washer	4
16	See Index E3	Track Valve Block	1





E 2-2-2 PUMP & PUMP DRIVE – SERVO CONTROLS

5000M ISSUE




ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
1	20/202100	Pump	1
2	20/202101	:Seal Kit	1
3	201/67504	Bracket	1
4	1305/3314	Bolt	4
5	1416/0007	Spring Washer	4
6	01/103501	Key	1
7	1305/3008	Bolt	4
8	1416/0004	Spring Washer	4
9	201/67501	Coupling	1
10	1381/3002	Capscrew	1
11	1305/3112	Bolt	6
12	1416/0005	Spring Washer	6
13	45/900700	Drive Coupling	1
14	201/67502	Coupling	Pump Drive End	1
15	20/202102	Key	1



E 3-1-2 EXCAVATOR VALVE

Sample of manual. Download All 19 pages at: <https://www.arespa.com/download/805b-servo-suppl-ment-parts-manual/>

5000M ISSUE 1



ITEM	PART No.	CHANGE No.	DESCRIPTION	REMARKS	QTY.
					m/c Assy.
1	919/50600	Valve	1
2	920/00089	:Plug	1
3	2401/0205	:Seal	1
4	920/00251	:Plug	1
5	920/01083	:Seal	1
6	920/01085	:Plug	1
7	920/01086	:Seal	1
8	920/01082	:Banjo	1
9	920/01083	:Seal	2
10	920/00368	:Adapter	2
11	920/01084	:Flexible Hose Assembly	1
12	920/00217	:Seal	2
13	920/01081	:Adapter	1
14	920/01104	:Cover	6
15	920/00446	:Bolt	12
16	920/00157	:Washer	12
17	920/00085	:Core Plug	2
18	2401/0103	: 'O' Ring	2
19	1305/3638	Bolt	3
20	208/00202	Mounting Rubber	3
21	1412/0007	Washer	6
22	1410/0007	Washer	3
23	1340/0603	Nut	3