

A - 1

HOW TO USE MICROFICHE PARTS CATALOGUE


The microfiche parts catalogue we have newly prepared (hereinafter referred to as MICROCATALOGUES) have the same contents as those contained in the usual book-type parts catalogues.

If you have a microfiche reader (hereinafter referred to as READERS), you can read the information contained on the microfiche film you have, but you will still be faced with the problem of how to find the wanted film CATALOGUES, the contents are arranged according to a certain rule, and if you learn this rule by heart, any frame of the microfiche film, containing the wanted information, can be found quickly, with the use of the index plate which is attached to the READER.

It is important that you always use the index plate when looking for a certain frame in the microfiche film.

A. Composition of the MICROCATALOGUES

Now, you are going to learn the arranging "rule" of information in the MICROCATALOGUES, the "rule" determining which kinds of information are located at which parts of the microfiche films in the MICROCATALOGUES with the help of the drawing below.



Let us explain Fig. 1

- 1) Our MICROCATALOGUES consist of microfiche films each having 208 frames arranged in 13 horizontal rows (columns A through M) by 16 vertical columns (row 1 through 16).
- 2) The top space above the horizontal row A is the title space where the model code, catalogue date, and other information are printed.
- 3) File Number
 Since each microfiche film contains only up to 416 pages of the book catalogues, two, three or more films are sometimes required to contain a complete catalogue. In these cases, each microfiche film composing a certain MICROCATALOGUE is identified by a consecutive file number printed at the upper right hand corner.
- 4) Date
 The date on which the MICROCATALOGUE is prepared is indicated.
- 5) "How to use this catalogue"
 The frames identified by the address Nos. A-1, A-2 and A-3 contains the explanation on how to use the MICROCATALOGUE.
- 6) Foreword
 The frames identified by the address Nos. A-4 and A-5 contain the same foreword as contained in the book-form catalogues.
- 7) Illust. index
 All the frames in the leftmost vertical column except the top one (B-1 through K-1) contain illustration indexes. Each index contains all the illustrations belonging to the respective blocks such as the engine block, electric block, and frame block, in reduced forms extracted from the MICROCATALOGUE proper, with the relevant titles and address Nos. shown.
- 8) Title index
 In the space below the array of reduced illustration pages in each of the illustration index frames, the titles and the related address Nos. of all the reduced illustration pages shown in the upper space of that frame are listed to serve as title indices. The same title indices are also listed in the lower space of each of the illustrated text frames.
- 9) Parts No. index
 All the frames in the bottom horizontal column (1. In only one sheet, it is recorded from indicator No. M1./2. In more than two sheet, it is recorded at the lower line of last sheet.) are for parts No. indices. All the parts Nos. contained in the MICRO CATALOGUE are arranged orderly together with the respective address Nos.

B. Indexing system

Along with information contained in microfiche films, the indexing system is a major factor. In our MICROCATALOGUES, the following three indexing systems are utilized:

B-1 Indexing systems

1) Illust. index

The illust. indices are for finding parts of which the shapes are known.

NOTE: Sometimes, small parts are difficult to indentify in the illustrations by their shaper. For these parts, you should look for some larger parts to which the parts in question are attached.

2) Title index

This index system is for finding parts when the name of the principal parts to which they are related is known.

NOTE:1 For the titles of the illustration pages, only the name of the most representative piece in the page is adopted (for example, the name of an assembly part).

This means that the names of most small parts cannot be found in the parts name index list. You must always look for a major part to which the wanted parts belong, when looking for these parts, using the part name index list.

NOTE:2 When there are more titles than the title index space of one frame can accept in one catalogue, the titles are divided into several blocks (ex., engine block, frame block, etc.).

3) Parts No. Index

This index system is for finding parts when the part Nos. are known.

B-2 Indexing procedures

Now, let us explain the procedure for finding wanted frames with the help of the three indexing systems.

a. Finding wanted parts in the MICROCATALOGUE

a-1 How to find the parts Nos. of parts of which the shapes are known.

Procedure 1

Shift the fiche carrier until the B-1 square on the index plate is brought directly under the carrier needle.

Procedure 2

Now, the illust. index printed in the frame B-1 is projected on to the screen. Try to find an illustration in which the wanted part is shown. Among the array of reduced illustrations projected.

Procedure 3

If you found an illustration in which the wanted part is shown, go on to Procedure 4. If the wanted part is not found in any of the illustrations in the frame B-1, shift the fiche carrier to C-1 and try to find an illustration in which the wanted part is shown among the arrayed reduced illustrations. If the wanted part is not found in any of the reduced illustrations, shift the fiche carrier to D-1, then to E-1 and so on to K-1.

Procedure 4

Make a note of the address No. of the illustration in which the wanted part is shown.

Procedure 5

Shift the fiche carrier until the square corresponding to the address No. found in the procedure 4 or 9 is brought under the carrier needle.

Procedure 6

Check the address No. of the projected square.

Procedure 7

Look for the wanted part in the illustration on the left half of the screen, and read the identification number of this part.

Procedure 8

Look for the obtained identification number in the text page in the right of the screen, and read the relevant information. This is how one part is found with the help of the illust. index system.

a-2 To find another part proceed as follows:

- 1) If the shape of the next wanted part is known, again project the frame B-1 and go through the procedures 2 through 9.
- 2) If the name of the next wanted part is known, try to find the address No. in the title index list shown in the lower portion of the screen, and carry out the procedures 5. (Title index)
- 3) If the part No. of the next wanted part is known, project the L-1 or M-1 frame and read the address No. corresponding to the known part No. Then, carry out the procedures 5. (Part No. index)

Make full use of the three index systems in each case as explained above.

NOTE: After reading the required information, you should switch off the READER and put the microfiche back in the file.

PREFACE

When it becomes necessary to replace parts on SUZUKI MOTORCYCLES, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI GSX-R750MN, GSX-R750MP, GSX-R750NR, GSX-R750NS.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.No.	: Engine number	OS	: Over size
F.No.	: Frame number	STD	: Standard
d	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length		
LH	: Left hand side		
RH	: Right hand side		
-100045	: Up to F.No.JS1GR7BA-100045		
100046-	: From F.No.JS1GR7BA-100046		

12 x 24 x 2.6 Figures in the description column show the dimensions of parts.
 | | |
 ID OD T(or W,L)

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

- 5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.
- 5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.
- 5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. SERIAL FRAME NUMBER

- GSX-R750MN : JS1GR7BA N2100001-
- GSX-R750MP : JS1GR7BA P2100001-
- GSX-R750NR : JS1GR7BA R2100001-
- GSX-R750NS : JS1GR7BA S2100001-

PREFACE

Quand il devient nécessaire de remplacer des pièces sur SUZUKI MOTOCYCLETES toujours utiliser les PIÈCES D'ORIGINE SUZUKI qui ont été soumises à des contrôles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI GSX-R750MN, GSX-R750MP, GSX-R750MR, GSX-R750WS.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E.No.	: Numéro du moteur	OS	: Sur-dimensionné
F.No.	: Numéro du châssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur

L : Longueur
LH : Côté gauche
RH : Côté droit

-100045 : Jusqu'à F.No. JS1GR7BA-100045

100046- : Depuis F.No. JS1GR7BA-100046

12 x 34 x 5.6 Les chiffres dans la colonne
| | | remarques montrent les dimensions
ID OD T(or W,L) des pièces comme suit.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

- 5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des raisons administratives et dont l'usage est commun avec celles d'autres modèles.
- 5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.
- 5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NUMERO DE SERIE DU CADRE









GSX-R750MN : JS1GR7BA N2100001-
GSX-R750MP : JS1GR7BA P2100001-
GSX-R750MR : JS1GR7BA R2100001-
GSX-R750WS : JS1GR7BA S2100001-

COLOR CHART
TABLEAU DES COULEURS
CUADRO DE COLORES
FARBTABELLE

COLOR NO. NO DE COULEUR NO. DE COLOR FARBCODE	COLOR DESCRIPTION DESCRIPTION DE COULEUR DESCRIPCIÓN DE COLOR FARBESCHREIBUNG	COLOR NO. NO DE COULEUR NO. DE COLOR FARBCODE	COLOR DESCRIPTION DESCRIPTION DE COULEUR DESCRIPCIÓN DE COLOR FARBESCHREIBUNG
AJ6	1UJ,1GG,1SZ,0FP	D6G	33J,Y22,20H,1UM
A5L	0JW,1MW	D6H	33J,Y22,1UM
A5S	0JW,1LE,0FP	L97	33J,1LV
A5T	0JW,1MW,14B	M04	1LV,1LY,39S
A5U	0JW,1LE,14B,1NG,1TW	M05	20G,0FP,1LW
A5V	0JW,1MW,14B,1TU,1SZ	M09	33J,0FP,764
A5W	0JW,1LE,14B,1TW	M18	0JW,1LE
A5Y	0JW,1MW,14B,1SZ	N59	0JW,1LE,1JG
A5Z	1TW,33J	N61	33J,1LV,1LD
A6A	1TW,33J,1TU,23S	N62	1LE,1PJ,1JG
A6B	1TW,33J,1TU	P55	DAHLIA PURPLE NO.3
A6C	1TW,33J,1TU,1NG,23S	Y09	OPAL GREEN METALLIC
A6D	1NG,1LE,14B	Y22	BOURGOGNE PURPLE METALLIC
A6E	1TU,1MW,14B	Y79	DECAL ZEKKEN
A7U	0JW,1TW,14B	Y81	BLACK / PINK DECAL
A7V	0JW,1SZ,14B	Y96	GREEN / SILVER GRADATION NO.2
C4P	0JW,1LE,1TC	Y97	GREEN / WHITE GRADATION NO.2
C4S	1UJ,1SZ,0FP	0FP	TRADITIONAL SILVER METALLIC
D4A	33J,Y22	0JW	PEARL STILL WHITE
D4G	0JW,1LE,Y09	0LX	PEARL STILL WHITE
D4H	0JW,1LE,Y09,1ZV	0MA	STILL WHITE
D6F	33J,Y22,20H	019	BLACK

COLOR CHART
TABLEAU DES COULEURS
CUADRO DE COLORES
FARBTABELLE

COLOR NO. NO DE COULEUR NO. DE COLOR FARBCODE	COLOR DESCRIPTION DESCRIPTION DE COULEUR DESCRIPCIÓN DE COLOR FARBESCHREIBUNG	COLOR NO. NO DE COULEUR NO. DE COLOR FARBCODE	COLOR DESCRIPTION DESCRIPTION DE COULEUR DESCRIPCIÓN DE COLOR FARBESCHREIBUNG
1DR	MARBLE ATOM PURPLE	1TU	LIGHT PURPLE METALLIC
1GG	TAPING COSMOS PINK NO.2	1TW	TAKE PURPLE
1JG	GOBUGALIDA PINK	1UJ	QUEST SILVER METALLIC
1LD	PEARL SUZUKI LIGHT BLUE	1UL	PURE RED
1LE	PEARL SUZUKI MEDIUM BLUE	1UM	LUMINOUS ORANGE NO.3 (TAPE)
1LS	SEMI LUMINOUS PINK NO.2	1MW	BLUE / WHITE
1LV	MB TYRIAN PINK	1NY	BLUE / WHITE GRADATION
1LW	OFF SIDE BLUE NO.2 (TAPE)	1YA	PINK / PURPLE GRADATION
1LX	PRL STILL WHITE	1YC	PINK / PURPLE GRADATION NO.2
1LY	LAVENDER (TAPE)	1ZV	CANDY TEAL BLUENISH GREEN
1LZ	GRADATION 750R NO.1	12R	TIGHT SILVER METALLIC
1MA	GRADATION 750R NO.2	14B	FANTASTIC COPPER GOLD METALLIC
1MC	GRADATION 750R NO.4	20G	CHARCOAL GRAY METALLIC
1MJ	SPECTRUM BLUE M/T	20H	WARM SILVER METALLIC
1MW	PRL PURE RED NO.2	23S	ATOMIC SILVER NO.2
1NG	TYRIAN PINK NO.2	291	BLACK (SEMI-GLOSS)
1PJ	T. PEACH PINK	3WC	0FP,33J
1PK	GRADATION 750R NO.6	33J	PEARL NOVELTY BLACK
1PL	GRADATION 750R NO.7	36X	PEARL NOVELTY BLACK
1PN	GRADATION 750R NO.8	39S	VENETIAN BLUE
1SZ	CAT PURPLE METALLIC	5FM	DYNAMIC BLUE
1TC	PHANTOM PINK METALLIC	58R	BLACK


<p>CYLINDER HEAD COVER</p> 	<p>B-02 CYLINDER HEAD</p> 	<p>B-03 CYLINDER</p> 	<p>B-05 CRANKCASE</p> 	<p>B-06 CRANKCASE COVER</p> 	<p>B-09 OIL PAN - OIL PUMP</p> 
<p>CRANKSHAFT</p> 	<p>B-11 STARTER CLUTCH</p> 	<p>B-12 CAM SHAFT - VALVE</p> 	<p>B-13 CAM CHAIN</p> 		

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.1

B - 2

FIG.1 (B- 2) CYLINDER HEAD COVER



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11171-17E00	COVER, cylinder head	1	model N/P
1-2	11171-17E10	COVER, cylinder head	1	model R
1-3	11171-17E11	COVER, cylinder head	1	model S
2	11173-17E00	GASKET, head cover No.1	1	
3	11178-17E00	GASKET, head cover No.2	4	
4	09106-07009	BOLT (L:5.5)	8	
5	09161-11008	WASHER	8	
6	09206-08001	PIN	2	
7-1	11176-26000	COVER, breather	1	model N/P
7-2	11176-31E00	COVER, breather	1	model R/S
8	11177-17E00	GASKET, breather cover	1	
9-1	01517-06257	BOLT	4	model N/P
9-2	01550-06253	BOLT	4	model R/S
10-1	11400-17870	GASKET SET	1	model N/P
10-2	11400-17874	GASKET SET	1	model R/S,+11400-17873


GSX-R750MS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-04	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	URNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPEP	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDE	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.2

B - 3

FIG.2 (B- 3) CYLINDER HEAD




REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11100-17E00	HEAD ASSY, cylinder	1	model N/P
1-2	11100-17E20	HEAD ASSY, cylinder	1	model R/S
2	11115-17E70	.GUIDE, valve	16	
3-1	09103-06013	.BOLT (6x45)	16	model N/P
3-2	09103-06165	.BOLT (6x45)	16	model R/S
4	09206-08001	.PIN	8	
5-1	11141-17E00	GASKET, cylinder head	1	model N/P
5-2	11141-17E01	GASKET, cylinder head	1	model R/S
6	04211-11189	PIN	2	
7-1	01517-06305	BOLT	1	model N/P
7-2	01550-06303	BOLT	1	model R/S
8	09103-10272	BOLT (10x160)	12	
9	09160-10082	WASHER	12	
10-1	09119-08079	BOLT, oil gallery IN	2	model N/P
10-2	07120-08163	BOLT, oil gallery IN	2	model R/S
11-1	07120-08165	BOLT, oil gallery EX	2	model N/P
11-2	07120-08163	BOLT, oil gallery EX	2	model R/S
12	09168-08015	GASKET	4	
13	11131-17E00	PIPE, oil	2	
14	09103-06026	BOLT (6x39)	4	
15-1	08322-21064	WASHER	4	model N/P
15-2	08322-01063	WASHER	4	model R/S
16-1	09482-00410	SPARK PLUG (NGK,CR9EK)	4	model N/P
16-2	09482-00411	SPARK PLUG (ND,U27ETR)	4	model N/P
16-3	09482-00458	SPARK PLUG (NGK,CR9E)	4	model R/S
16-4	09482-00459	SPARK PLUG (ND,U27ESR-N)	4	model R/S
16-5	09482-00412	SPARK PLUG (NGK,CR8EK)	4	OPT,model N/P
16-6	09482-00462	SPARK PLUG (NGK,CR10EK)	4	OPT,model N/P
16-7	09482-00413	SPARK PLUG (ND,U24ETR)	4	OPT,model N/P
16-8	09482-00463	SPARK PLUG (ND,U31ETR)	4	OPT,model N/P
16-9	09482-00456	SPARK PLUG (NGK,CR8E)	4	OPT,model R/S
16-10	09482-00460	SPARK PLUG (NGK,CR10E)	4	OPT,model R/S
16-11	09482-00457	SPARK PLUG (ND,U24ESR-N)	4	OPT,model R/S
16-12	09482-00461	SPARK PLUG (ND,U31ESR-N)	4	OPT,model R/S

GSX-R750MS E28

AIR CLEANER	C-05	COUPLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-04	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLIND	I-13	STEERING DAMPER	G-15		
COUPLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.2

B - 4



3

FIG.2 (B- 4) CYLINDER HEAD

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	13101-17E00	PIPE, intake No.1	2	
18	13103-17E00	PIPE, intake No.3	1	
19	13104-17E00	PIPE, intake No.4	1	
20	09280-44007	.O RING	4	+09280-44009
21	09402-56208	CLAMP	4	
22	09126-06014	SCREW (6x16)	8	
23	09354-50103-600	HOSE, fuel cook vacuum	1	L:600+200
24	01550-10403	BOLT, eng mtg head R & L	2	model S

GSX-R750MS E2B

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	O-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	URNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	O-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDE	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.3

B - 5




FIG.3 (B - 5) CYLINDER

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11210-17E01	CYLINDER	1	model N/P
1-2	11200-17E01	CYLINDER	1	model R/S
2	09280-75004	.0 RING	4	
3	11241-17E00	GASKET, cylinder	1	
4-1	01421-06205	STUD BOLT	1	model N/P
4-2	01421-06203	STUD BOLT	1	model R/S
5-1	08316-16064	NUT	1	model N/P
5-2	08316-10063	NUT	1	model R/S
6	04211-11189	PIN	2	
7	17415-14300	BOLT, cylinder drain	2	model N/P
8	09168-08008	GASKET	2	model N/P
9-1	11281-17E00	HOSE, oil RH	1	model N/P
9-2	11281-17E01	HOSE, oil RH	1	model R/S
10-1	11282-17E00	HOSE, oil LH	1	model N/P
10-2	11282-17E01	HOSE, oil LH	1	model R/S
11	11284-17E00	BOLT, oil hose union	2	
12	09168-08016	GASKET	4	
13	11285-32000	BOLT, oil hose union	1	
14	09161-10009	GASKET	3	

GSX-R750WS E28


AIR CLEANER	C-05	COYLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	E-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COYLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.4

B-6

5

FIG.4 (B-6) CRANKCASE



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11300-178A1	CRANKCASE SET	1	model N
1-2	11300-178A6	CRANKCASE SET	1	model P
1-3	11300-178A8	CRANKCASE SET	1	model R
1-4	11302-46874	CRANKCASE SET	1	model S
2	09206-13004	.PIN	4	
3	04211-09129	.PIN	2	
4	09103-06163	.BOLT (6x105)	2	
5	09103-09007	.BOLT (5x80)	4	
6	09103-09008	.BOLT (9x95)	2	
7	09103-09009	.BOLT (7x105)	1	
8	09103-09010	.BOLT (9x115)	3	
9	09106-09001	.BOLT (9x60)	2	
10-1	07110-06758	.BOLT	1	model N/P
10-2	07130-06753	.BOLT	1	model R/S
11-1	07110-08508	.BOLT	1	model N/P
11-2	07130-08503	.BOLT	1	model R/S
12-1	07110-08608	.BOLT	1	model N/P
12-2	07130-08603	.BOLT	1	model R/S
13-1	07130-08808	.BOLT	1	model N/P
13-2	07130-08803	.BOLT	1	model R/S
14-1	01517-08605	.BOLT	1	model N/P
14-2	01550-08603	.BOLT	1	model R/S
15-1	01517-06354	.BOLT	5	model N/P
15-2	01550-06353	.BOLT	5	model R/S
16-1	01517-06404	.BOLT	3	model N/P
16-2	01550-06403	.BOLT	3	model R/S
17-1	01517-06408	.BOLT	1	model N/P
17-2	01550-06403	.BOLT	1	model R/S
18-1	01517-06505	.BOLT	2	model N/P
18-2	01550-06503	.BOLT	2	model R/S
19-1	01517-06655	.BOLT	1	model N/P
19-2	01550-06653	.BOLT	1	model R/S
20-1	07110-06257	.BOLT	1	model N/P
20-2	07130-06253	.BOLT	1	model R/S
21-1	07110-06357	.BOLT	2	model N/P
21-2	07130-06353	.BOLT	2	model R/S


GSX-R750MS E28

AIR CLEANER	C-05	CONVING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	URNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
CONVING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	L-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.4

B-7

FIG.4 (B-7) CRANKCASE



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22-1	07110-06408	.BOLT	3	model N/P
22-2	07130-06403	.BOLT	3	model R/S
23-1	07110-06508	.BOLT	3	model N/P
23-2	07130-06503	.BOLT	3	model R/S
24-1	07110-06608	.BOLT	1	model N/P
24-2	07130-06603	.BOLT	1	model R/S
25	09103-06062	.BOLT (6x145)	1	
26	09168-06018	.GASKET	3	
27	09168-08016	.GASKET	1	
28	09280-04004	.O RING	4	
29	09248-18002	.PLUG, upper	1	
30	09493-24010	.JET, oil gallery mission LH	1	
30A	09493-28012	.JET, oil gallery mission RH	1	
31	09493-80008	.JET, oil gallery piston	4	
32	09168-10002	.GASKET	2	
33	09248-10007	.PLUG, oil gallery	2	
34	09168-16002	.GASKET	2	
35	09248-16010	.PLUG, oil gallery	2	
36	09168-06024	.GASKET	3	
37	09248-22002	.PLUG, LH	1	
38	09168-22002	.GASKET	1	
39	09248-14010	.PLUG, oil gallery	1	
40	09168-14002	.GASKET	1	
41	12228-17E00-000	.BEARING, thrust RH (Green)	1	SEE ILLUSTRATION ON FIG.7 (B-11)
42-1	12228-17E00-010	.BEARING, thrust LH (Red)	1	SEE ILLUSTRATION ON FIG.7 (B-11)
42-2	12228-17E00-080	.BEARING, thrust LH (Black)	1	
42-3	12228-17E00-0C0	.BEARING, thrust LH (Blue)	1	
42-4	12228-17E00-000	.BEARING, thrust LH (Green)	1	
42-5	12228-17E00-0E0	.BEARING, thrust LH (Yellow)	1	
42-6	12228-17E00-0F0	.BEARING, thrust LH (White)	1	
43	09241-37002	PLUG, crankcase LH	1	
44	09103-10139	BOLT (10x150)	1	
45-1	09100-12028	BOLT (12x185)	1	model N
45-2	09100-12043	BOLT (12x165)	1	model P/R/S


GSX-R750WS E28

AIR CLEANER	C-05	COUPLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	J-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COUPLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.4

B-8 7

FIG.4 (B-8) CRANKCASE



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
46-1	01987-10558	BOLT	2	model N/P
46-2	01580-10603	BOLT	2	model R
46-3	01580-10553	BOLT	2	model S
47-1	01517-10558	BOLT	2	model N/P
47-2	01550-10553	BOLT	2	model R/S
48	11613-33C00	NUT	2	
49	09159-10058	NUT	3	
50	11681-27A00	BUSH	2	
51-1	11611-40C01	SPACER (L:27)	1	model N
51-2	11611-19B11	SPACER (L:13)	1	model P
51-3	11611-17E00	SPACER (L:13)	1	model R/S
52	08319-31128	NUT	1	
53-1	08322-11128	WASHER	1	model N/P
53-2	08322-01123	WASHER	1	model R/S

GSX-R750MS E28


AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	Z-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-14	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDE	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.5

B-9

8

FIG.5 (B-9) CRANKCASE COVER



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11340-17E01	COVER, clutch	1	model N/P
1-2	11340-21E00	COVER, clutch	1	model R/S
2	11971-33210	.LENS, oil level	1	
3	11482-17E00	GASKET, clutch cover	1	
4	04211-09189	PIN	2	
5	09168-06024	GASKET	2	
6-1	07110-06255	BOLT	6	model N/P
6-2	07130-06253	BOLT	6	model R/S
7-1	07110-06305	BOLT	2	model N/P
7-2	07130-06303	BOLT	2	model R/S
8-1	07110-06355	BOLT	1	model N/P
8-2	07130-06353	BOLT	1	model R/S
9	09259-20012	PLUG, engine oil filler	1	
10	09280-17003	O RING	1	
11-1	11381-17E00	COVER, signal generator	1	model N/P
11-2	11381-31E00	COVER, signal generator	1	model R/S
12	11491-17E01	GASKET, signal generator cover	1	
13-1	09106-06059	BOLT (6x23)	5	model N/P
13-2	09106-06082	BOLT (6x23)	5	model R/S
14	09168-06024	GASKET	1	
15-1	11361-17E00	COVER, engine sprocket	1	model N/P
15-2	11361-17E10	COVER, engine sprocket	1	model R/S
16	04211-09129	PIN	2	
17-1	07110-06505	BOLT (6x50)	2	model N/P
17-2	09106-06083	BOLT (6x50)	2	model R/S
18-1	07110-06555	BOLT (6x55)	3	model N/P
18-2	09106-06083	BOLT (6x50)	3	model R/S


GSX-R750MS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.6

B-10

FIG.6 (B-10) OIL PAN - OIL PUMP




REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11511-17E00	PAN, oil	1	
2	11489-17E01	GASKET, oil pan	1	
3-1	01547-06257	BOLT	13	model N/P
3-2	01547-06253	BOLT	13	model R/S
4-1	01547-06307	BOLT	1	model N/P
4-2	01547-06303	BOLT	1	model R/S
5	09168-06024	GASKET	1	
6	09247-14001	PLUG, Oil drain	1	
7	09168-14002	GASKET	1	
8	09248-16010	PLUG, oil gallery	2	
9	09168-16002	GASKET	2	
10	16520-17E00	STRAINER, engine oil	1	
11	09128-06039	BOLT (6x16)	2	
12	09280-12012	O RING, oil gallery	2	
13	16529-27A01	GASKET, outlet	1	
14	09280-18009	O RING	2	
15	16440-17C00	VALVE ASSY, oil relief	1	
16	09168-16002	GASKET	1	
17	16400-17E00	PUMP ASSY, engine oil	1	
18	09280-26005	O RING	1	
19	09280-18009	O RING	1	
20-1	07110-06307	BOLT	1	model N/P
20-2	07130-06303	BOLT	1	model R/S
21-1	07110-06357	BOLT	2	model N/P
21-2	07130-06353	BOLT	2	model R/S
22	04211-09129	PIN	2	
23	16332-19C00	GEAR, oil pump driven	1	
24	08221-12205	WASHER	2	
25	09261-05006	PIN	1	
26	08331-31126	CIRCLIP	1	
27	37820-33000	SWITCH, oil pressure	1	

GSX-R750MS E28

AIR CLEANER	C-05	COOLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	L-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COOLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.7

B - 11



10

FIG.7 (B-11) CRANKSHAFT

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12160-17000	ROD ASSY, connecting	4	model N/P
1-2	12160-17E00	ROD ASSY, connecting	4	model R/S
2	12163-27A52	.BOLT	8	
3-1	12164-17E01-0A0	BEARING, crank pin (Green)	8	+12164-17E00-0A0
3-2	12164-17E01-0B0	BEARING, crank pin (Black)	8	+12164-17E00-0B0
3-3	12164-17E01-0C0	BEARING, crank pin (Brown)	8	+12164-17E00-0C0
3-4	12164-17E01-0D0	BEARING, crank pin (Yellow)	8	+12164-17E00-0D0
4	12000-17821	CRANKSHAFT SET	1	
5	04221-04089	.PIN	1	
6	12228-17E00-0D0	.BEARING, thrust RH (Green)	1	
7-1	12228-17E00-0A0	.BEARING, thrust LH (Red)	1	
7-2	12228-17E00-0B0	.BEARING, thrust LH (Black)	1	
7-3	12228-17E00-0C0	.BEARING, thrust LH (Blue)	1	
7-4	12228-17E00-0D0	.BEARING, thrust LH (Green)	1	
7-5	12228-17E00-0E0	.BEARING, thrust LH (Yellow)	1	
7-6	12228-17E00-0F0	.BEARING, thrust LH (White)	1	
8-1	12229-17E00-0A0	BEARING, crankshaft (Green)	6	LOWER
8-2	12229-17E00-0B0	BEARING, crankshaft (Black)	6	
8-3	12229-17E00-0C0	BEARING, crankshaft (Brown)	6	
8-4	12229-17E00-0D0	BEARING, crankshaft (Yellow)	6	
9-1	12229-17E10-0A0	BEARING, crankshaft (Green)	6	UPPER
9-2	12229-17E10-0B0	BEARING, crankshaft (Black)	6	
9-3	12229-17E10-0C0	BEARING, crankshaft (Brown)	6	
9-4	12229-17E10-0D0	BEARING, crankshaft (Yellow)	6	
10-1	12111-17E04-0F0	PISTON	4	model N/P
10-2	12111-17E20-0F0	PISTON	4	model R/S
11-1	12140-07D10	RING SET, piston	4	model N/P
11-2	12140-17E10	RING SET, piston	4	model R/S
12	12151-07D00	PIN, piston	4	
13	09381-18003	CIRCLIP	8	
14-1	12103-17820-050	PISTON SET (OS:0.5)	4	OPT,model N/P
14-2	12103-17820-100	PISTON SET (OS:1.0)	4	OPT,model N/P
14-3	12100-17E20-050	PISTON SET (OS:0.5)	4	OPT,model R/S
14-4	12100-17E20-100	PISTON SET (OS:1.0)	4	OPT,model R/S


GSX-R750MS E28

AIR CLEANER	C-05	COUPLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-07	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COUPLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG. 8

B - 12

FIG. 8 (B-12) STARTER CLUTCH



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12611-17E00	GEAR, starter idle (NT:12/56)	1	model N/P
1-2	12611-21E00	GEAR, starter idle (NT:12/56)	1	model R/S
2	12616-17E00	SHAFT, starter idle gear	1	
3	08221-12185	WASHER	2	
4	08331-31126	CIRCLIP	1	
5-1	12600-17820	CLUTCH SET, starter	1	model N/P
5-2	12600-21810	CLUTCH SET, starter	1	model R/S
6-1	07110-06166	BOLT	6	model N/P
6-2	07130-06163	BOLT	4	model R
6-3	07130-06123	BOLT	4	model S
7	09241-12006	PLUG, starter idle shaft	1	

GSX-R750WS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	URNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	B-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDE	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG. 9

B - 13




FIG. 9 (B-13) CAM SHAFT - VALVE

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12711-17E00	CAM SHAFT, intake	1	
2	12721-17E00	CAM SHAFT, exhaust	1	
3	12741-17E00	SPROCKET, cam shaft	2	
4	09103-07001	BOLT	4	
5	12891-17E00	TAPPET	16	
6	12911-17E00	VALVE, intake	8	
7	12912-17E00	VALVE, exhaust	8	
8	12921-17E00	SPRING, valve	16	
9-1	12931-17E00	RETAINER, valve spring	16	model N/P/R
9-2	12931-17E01	RETAINER, valve spring	16	model S
10	12933-17E00	SEAT, valve spring	16	
11	12932-32C00	COTTER, valve	32	
12	09289-04002	OIL SEAL	16	
13-1	12892-05C00-120	SHIM, tappet (T:1.20)	16	
13-2	12892-05C00-125	SHIM, tappet (T:1.25)	16	
13-3	12892-05C00-130	SHIM, tappet (T:1.30)	16	
13-4	12892-05C00-135	SHIM, tappet (T:1.35)	16	
13-5	12892-05C00-140	SHIM, tappet (T:1.40)	16	
13-6	12892-05C00-145	SHIM, tappet (T:1.45)	16	
13-7	12892-05C00-150	SHIM, tappet (T:1.50)	16	
13-8	12892-05C00-155	SHIM, tappet (T:1.55)	16	
13-9	12892-05C00-160	SHIM, tappet (T:1.60)	16	
13-10	12892-05C00-165	SHIM, tappet (T:1.65)	16	
13-11	12892-05C00-170	SHIM, tappet (T:1.70)	16	
13-12	12892-05C00-175	SHIM, tappet (T:1.75)	16	
13-13	12892-05C00-180	SHIM, tappet (T:1.80)	16	
13-14	12892-05C00-185	SHIM, tappet (T:1.85)	16	
13-15	12892-05C00-190	SHIM, tappet (T:1.90)	16	
13-16	12892-05C00-195	SHIM, tappet (T:1.95)	16	
13-17	12892-05C00-200	SHIM, tappet (T:2.00)	16	
13-18	12892-05C00-205	SHIM, tappet (T:2.05)	16	
13-19	12892-05C00-210	SHIM, tappet (T:2.10)	16	
13-20	12892-05C00-215	SHIM, tappet (T:2.15)	16	
13-21	12892-05C00-220	SHIM, tappet (T:2.20)	16	
14	12800-05820	SHIM SET, tappet Inc. Ref.No.13-1-13-21 (5pcs. each) & No.15	1	OPT Not shown
15	99000-69491	.CASE, tappet shim	1	OPT

GSX-R750MS E2B


AIR CLEANER	C-05	COMLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	BEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	O-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLIND	I-13	STEERING DAMPER	G-15		
COMLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG. 10

B - 14

13








FIG. 10 (B-14) CAM CHAIN



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12760-17E00	CHAIN, cam shaft drive	1	model N/P/R
1-2	12760-17E01	CHAIN, cam shaft drive	1	model S
2	12771-17E00	GUIDE, cam chain No.1	1	
3	12782-18E00	GUIDE, cam chain No.2	1	+12782-26B10
4-1	02112-05108	SCREW	2	model N/P
4-2	02112-05103	SCREW	2	model R/S
5-1	12810-17E00	TENSIONER, cam chain	1	model N/P
5-2	12810-17E01	TENSIONER, cam chain	1	model R/S
6	12814-34200	CUSHION	2	
7-1	12791-17E00	GUIDE, cam chain No.3	1	model N/P/R
7-2	12791-17E01	GUIDE, cam chain No.3	1	model S
8-1	01517-06125	BOLT	1	model N/P
8-2	01550-06123	BOLT	1	model R
8-3	01550-06163	BOLT	1	model S
9	09168-06023	WASHER	1	
10-1	12830-26D10	ADJUSTER ASSY, tensioner	1	model N/P
10-2	12830-26D12	ADJUSTER ASSY, tensioner	1	model R/S
11	12834-27A00	.PLUG	1	
12	12832-27A00	.GASKET	1	
13	12833-26D10	.SPRING	1	
14	12837-27A10	GASKET, adjuster	1	
15-1	09106-06059	BOLT (6x23)	2	model N/P
15-2	09106-06082	BOLT (6x23)	2	model R/S

GSX-R750MS E28

AIR CLEANER	C-05	COOLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COOLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-16		

CARBURETOR 	C-02 CARBURETOR FITTINGS 	C-04 AIR CLEANER 	C-05 MUFFLER 	C-06 OIL COOLER - OIL FILTER 	C-07 WATER PUMP 
RADIATOR 	C-09 RADIATOR HOSE 				


AIR CLEANER	C-05	COUPLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COUPLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG. 11

C - 2

14

FIG. 11 (C- 2) CARBURETOR



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	13201-17E00	CARBURETOR ASSY, LH	1	model N/P
1-2	13201-17EE0	CARBURETOR ASSY, LH	1	model R/S
2-1	13202-17E00	CARBURETOR ASSY, ML	1	model N/P
2-2	13202-17EE0	CARBURETOR ASSY, ML	1	model R/S
3-1	13203-17E00	CARBURETOR ASSY, MR	1	model N/P
3-2	13203-17EE0	CARBURETOR ASSY, MR	1	model R/S
4-1	13204-17E00	CARBURETOR ASSY, RH	1	model N/P
4-2	13204-17EE0	CARBURETOR ASSY, RH	1	model R/S
5-1	13507-07000	.DIAPHRAGM	4	model N/P/R
5-2	13507-07001	.DIAPHRAGM	4	model S
6	13501-17000	.VALVE, piston	4	
7	13394-31210	.E RING	4	
8	13331-12000	.RING	4	
9	13387-17000	.RING	4	
10	13417-07010	.SPRING	2	LH,RH
11-1	13417-17E00	.SPRING	2	model N/P,ML,MR
11-2	13417-17000	.SPRING	2	model R/S,ML,MR
12	13383-17E00	.NEEDLE, jet (6ZD16-3)	4	
13	13258-44B00	.GASKET, float chamber	4	
14	09492-35008	.JET, pilot (35)	4	
15	09494-00751	.JET, needle (0-8)	4	
16	13278-02340	.O RING	4	
17	09491-22015	.JET, main (112.5)	2	LH,RH
18	09491-23011	.JET, main (115)	2	ML,MR
19	13331-07000	.RING	4	
20	13370-07000	.VALVE ASSY, needle	4	
21	13240-17E00	.FLOAT ASSY	4	
22	13374-46710	.O RING	4	
23	13374-44080	.O RING	4	
24-1	13602-34390	.SCREW	8	model N/P
24-2	02112-75163	.SCREW	8	model R/S
25-1	02112-05166	.SCREW	8	model N/P
25-2	02112-05163	.SCREW	8	model R/S
26	13508-17C00	.CAP	4	
27	13671-33600	.CLIP	4	


GSX-R750WS E2B

AIR CLEANER	C-05	CONVING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-14	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	D-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLIND	I-13	STEERING DAMPER	G-15		
CONVING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG. 11

C - 3

FIG. 11 (C- 3) CARBURETOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	13247-13A00	.SCREW, drain	4	
29	13502-17D00	.COVER, diaphragm	4	
30	13418-17C00	.CAP, starter	4	
31	13418-17C10	.HOLDER	4	
32-1	13271-26D00	.SPRING	4	model N/P
32-2	13417-26D00	.SPRING	4	model R/S
33	13432-47090	.WASHER	4	
34	13411-05320	.PLUNGER ASSY	4	
35	09493-50004	.JET, main air (0.5)	4	
36	09493-25003	.JET, pilot air (1.25)	4	
37	13279-47070	.SCREW, air (1 1/4)	4	
38	13268-47070	.SPRING	4	
39	13291-29900	.WASHER	4	
40	13295-29900	.O RING	4	

GSX-R750MS E2B

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-1C	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.12

C - 4




FIG.12 (C- 4) CARBURETOR FITTINGS


REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13413-17E00	LEVER, starter	1	
2	13628-17E10	PLATE	1	
3-1	13602-05128	SCREW	16	model N/P
3-2	02112-05127	SCREW	16	model R/S
4	13628-17E00	PLATE	1	
5	13439-17C00	HOLDER	2	
6	13683-17E00	HOSE	1	
7	13683-17E10	HOSE	1	
8	13684-20C10	HOSE	2	
9	13680-17E10	HOSE ASSY	1	
10	13685-17E00	NIPPLE	1	
11	13375-60A00	SPRING	1	
12	13427-38300	WASHER	1	
13	13685-44B00	NIPPLE	2	
14	13673-44B00	SEAL	4	
15-1	13602-05108	SCREW	1	model M/P
15-2	02112-05107	SCREW	1	model R/S
16	13279-17E00	ADJUSTER ASSY	1	
17	13680-17E00	HOSE ASSY	1	
18	13267-44B00	SCREW	3	
19	13271-44B00	SPRING	3	
20	13268-17C10	SPRING	3	
21	13683-17E20	HOSE	1	

GSX-R750MS E28

AIR CLEANER	C-05	COUPLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLIND	I-13	STEERING DAMPER	G-15		
COUPLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG. 13

C-5



17

FIG. 13 (C- 5) AIR CLEANER

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	13700-17E00	CLEANER ASSY, air	1	model N/P
1-2	13700-17E01	CLEANER ASSY, air	1	model R/S
2	13780-17E00	.FILTER, air	1	
3-1	13740-17E00	.CAP, air cleaner	1	model N/P
3-2	13740-17E01	.CAP, air cleaner	1	model R
3-3	13740-17E02	.CAP, air cleaner	1	model S
4-1	02142-05124	.SCREW	2	model N/P/R
4-2	02142-05123	.SCREW	2	model S
5	13891-17E00	.TUBE, inlet	1	
6	13881-17E00	.TUBE, outlet	4	
7-1	09402-64208	.CLAMP	4	model N/P/R
7-2	09402-64203	.CLAMP	4	model S
8	13853-17E00	.TUBE, breather	1	
9-1	13824-48810	.CLIP	2	model N/P/R
9-2	09401-16401	.CLIP	2	model S
10	13870-21458	.TUBE, drain	1	
11-1	13824-18910	..CLIP	1	model N/P/R
11-2	09401-11101	..CLIP	1	model S
12	13877-38A00	..STOPPER, drain	1	
13-1	13825-43400	.CLIP	1	model N/P/R
13-2	09401-13413	.CLIP	1	model S
14	13760-17E00	BRACKET, air cleaner RH	1	
15	13770-17E00	BRACKET, air cleaner LH	1	
16-1	02142-06126	SCREW	2	model N/P
16-2	02142-06123	SCREW	2	model R/S
17-1	02142-06166	SCREW	4	model N/P
17-2	02142-06163	SCREW	4	model R/S
18	13800-17E00	CLEANER ASSY, air No.2	1	
19	13750-17E00	BRACKET, air cleaner No.2	1	
20-1	01517-06164	BOLT	1	model N/P
20-2	01550-06163	BOLT	1	model R/S
21	13841-17E00	CUSHION, air seal	1	

GSX-R750MS E28


AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLIND	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.14

C - 6

18

FIG.14 (C- 6) MUFFLER



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	14150-17E01	PIPE, exhaust RH	1	model N/P
1-2	14150-17EA0	PIPE, exhaust RH	1	model R/S
2	14160-17E01	PIPE, exhaust LH	1	model N/P
2A	14106-17EA0	PIPE, exhaust LH	1	model R/S
3	14181-17E00	GASKET, exhaust pipe	4	
4-1	07130-08255	BOLT	8	model N/P
4-2	07130-08253	BOLT	8	model R/S
5	14771-44800	CONNECTOR, muffler	2	
6-1	01517-08407	BOLT	2	model N/P
6-2	01550-08403	BOLT	2	model R/S
7-1	14305-17E11	BODY, muffler	1	model N
7-2	14305-17E12	BODY, muffler	1	model P
7-3	14305-17E14-H01	BODY, muffler	1	model R/S
8-1	01107-08408	BOLT	1	model N/P
8-2	01500-08403	BOLT	1	model R/S
9	09160-08002	WASHER (8.5x29x1.6)	1	
10-1	08321-21088	LOCK WASHER	1	model N/P
10-2	08321-01083	LOCK WASHER	1	model R/S
11	09320-12048	CUSHION	1	
12	09180-08152	SPACER	1	
13-1	14770-17E01	DAMPER	1	model N
13-2	14770-17E03	DAMPER	1	model P/R/S
14-1	01517-08205	BOLT	2	model N/P
14-2	09100-08240	BOLT	2	model R/S
15-1	01517-08407	BOLT	1	model N
15-2	01517-08457	BOLT	1	model P
15-3	01550-08457	BOLT	1	model R/S
16-1	08316-16080	NUT	1	model N
16-2	08361-25088	NUT	1	model P/R/S
17	09160-08106	WASHER (8.1x33x1.6)	1	
18	09320-12049	CUSHION	1	
19	09180-08156	SPACER	1	


GSX-R750MS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.15

C-7

FIG.15 (C-7) OIL COOLER - OIL FILTER



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16600-17E00	COOLER ASSY, oil	1	
2	09280-64003	O RING (D:3.1, ID:63.9)	1	
3	16591-33C00	BOLT, oil cooler union	1	
4	16461-17E00	HOSE, oil cooler, water in	1	
5-1	16471-17E00	HOSE, oil cooler, water out	1	model N/P
5-2	16471-17E02	HOSE, oil cooler, water out	1	model R
6-1	09181-22009	WASHER	1	model N/P
6-2	08221-22355	WASHER	1	model R/S
7	09402-15502	CLAMP	4	model N/P/R
7A	09401-13410	CLIP	4	model S
8	16510-06801	FILTER ASSY, engine oil	1	
9	09407-18402	CLAMP	1	
10-1	09404-06412	CLAMP	1	model N
10-2	09404-06402	CLAMP	1	model P/R
10-3	09404-06429	CLAMP	1	model S


GSX-R750NS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	C-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HAND BAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	C-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PART	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWING ARM	I-02	STEERING STEM	G-14		

FIG.16

C - 8

FIG.16 (C- 8) WATER PUMP




REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	17400-17E00	PUMP ASSY, water	1	model N/P/R
1-2	17400-17E01	PUMP ASSY, water	1	model S
2	17491-17E00	.IMPELLER, water pump	1	
3	09168-06025	.GASKET	1	
4	17470-46A00	.SEAL, mechanical	1	
5	17461-38A00	.OIL SEAL	1	
6-1	17511-17E00	.SHAFT, water pump	1	model N/P/R
6-2	17511-17E01	.SHAFT, water pump	1	model S
7-1	08113-69010	.BEARING	1	model N/P/R
7-2	09262-10014	.BEARING (10x26x8)	1	model S
8-1	09262-15008	.BEARING (15x28x7)	1	model N/P/R
8-2	09262-12001	.BEARING (12x28x8)	1	model S
9	17418-33400	.O RING	1	
10	17435-33400	.O RING	1	
11	08331-41286	.CIRCLIP	1	
12-1	02112-06166	.SCREW	2	model N/P
12-2	02112-06163	.SCREW	2	model F/S
13	09100-06099	.BOLT (6x13)	1	
14	09164-06006	.LOCK WASHER	1	
15-1	17854-17E00	HOSE, water pump outlet	1	model N/P
15-2	17854-17E01	HOSE, water pump outlet	1	model R/S
16-1	09402-30502	CLAMP	1	model N/P/R
16-2	09402-32511	CLAMP	1	model S
17-1	09402-33502	CLAMP	1	model N/P/R
17-2	09402-38511	CLAMP	1	model S
18	02112-06357	SCREW	3	model N/P
19	09108-06117	BOLT	1	model R/S
20	08316-10063	NUT	1	model R/S
21	02112-06353	SCREW	2	model R/S

GSX-R750MS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-04	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL PUMP	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.17

C - 9



21


FIG.17 (C- 9) RADIATOR

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17710-17E00	RADIATOR ASSY, water	1	
2-1	01517-06254	BOLT	2	model N/P
2-2	09116-06147	BOLT	2	model R/S
3	09160-06113	WASHER (6.5x24x1.2)	2	model N/P
4	09180-07004	SPACER (6.5x10.5x12)	2	
5	17787-19A00	CUSHION, radiator upper	2	
6	09320-12053	CUSHION, radiator lower	1	
7	17740-17E00	BRACKET, radiator upper	1	
8-1	01177-06125	BOLT	2	model N/P
8-2	01580-06123	BOLT	2	model R
8-3	01580-06163	BOLT	2	model S
9	17751-17E00	BRACKET, radiator lower	1	
10-1	01174-06165	BOLT	2	model N/P
10-2	01580-06163	BOLT	2	model R/S
11-1	17800-17E00	FAN ASSY, radiator	1	model N/P
11-2	17800-17E02	FAN ASSY, radiator	1	model R/S
12	17820-17E00	.FAN ASSY	1	
13-1	17801-05A00	.BOLT	3	model N/P
13-2	02112-04063	.SCREW	3	model R/S
14	17770-17E00	.SHROUD ASSY, fan	1	
15-1	17801-45C00	.SCREW	3	model N/P
15-2	02142-05083	.SCREW	3	model R/S
16-1	01517-06125	BOLT	2	model N/P
16-2	01550-06173	BOLT	2	model R/S
17-1	01517-06108	BOLT	1	model N/P
17-2	01550-06103	BOLT	1	model R/S
18-1	08316-16064	NUT	2	model N/P
18-2	08316-10063	NUT	2	model R/S
19	17762-39A00	NUT	1	

GSX-R750MS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	BEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURNSIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR FITTINGS	C-04	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLIND	H-14	LABEL	J-15	REAR FENDER	I-06	STARTING NOYOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDE	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FI	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		

FIG.18 (C-10) RADIATOR HOSE



REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	17730-20930	CAP, radiator,1.1	1	model N/P
1-2	17730-12C01	CAP, radiator,1.1	1	model R/S
2	17791-32C00	CONDUCTION, radiator	1	
3-1	01517-06167	BOLT	2	model N/P
3-2	G1550-06163	BOLT	2	model R/S
4	17792-32C01	BRACKET, conduction	1	
5-1	01517-06207	BOLT	2	model N/P
5-2	01550-06203	BOLT	2	model R/S
6	17793-17E00	BRACKET, conduction bracket	1	
7-1	01517-06167	BOLT	2	model N/P
7-2	01550-06163	BOLT	2	model R/S
8-1	09159-06017	NUT	2	model N/P
8-2	08316-10063	NUT	2	model R/S
	09280-44005	O RING (D:2.4, ID:43.2)	1	
10	17662-17E00	CONNECTOR, thermostat inlet	1	
11	17670-32C01	THERMOSTAT, water	1	
12-1	01517-06207	BOLT	2	model N/P
12-2	01550-06203	BOLT	2	model R/S
13-1	17857-17E00	HOSE, radiator inlet	1	model N/P
13-2	17857-17E01	HOSE, radiator inlet	1	model R/S
14	17852-17E00	HOSE, radiator outlet	1	
15-1	17855-17E00	HOSE, head inlet joint	1	model N/P
15-2	17855-17E02	HOSE, head inlet joint	1	model R
15-3	17856-17E50	HOSE, head inlet joint	1	model S
16-1	09402-30502	CLAMP, water hose	6	model N/P/R
16-2	09402-32511	CLAMP, water hose	6	model S
17-1	09402-33502	CLAMP, water hose	2	model N/P/R
17-2	09402-38511	CLAMP, water hose	2	model S
18	17853-17E00	HOSE, water pump inlet	1	
19	17856-17E00	HOSE, head outlet	1	
20	17880-17E00	PIPE, head outlet	2	
21-1	17840-17E00	PIPE, head outlet No.2	1	model N/P
21-2	17840-17E10	PIPE, head outlet No.2	1	model R/S
22-1	17859-17E00	HOSE, joint	2	model N/P/R
22-2	17853-28C20	HOSE, joint	2	model S

GSX-R750MS E28

AIR CLEANER	C-05	COWLING BODY PARTS	J-12	FRAME	F-02	FUEL TANK	F-07	OIL PAN - OIL PUMP	B-10	REAR WHEEL	I-08	TAIL LAMP	E-10
ALTERNATOR	D-10	CRANKCASE	B-06	FRAME COVER	G-02	GEAR SHIFTING	D-06	OPTIONAL	J-16	SEAT	F-13	TRANSMISSION	D-04
BATTERY	E-02	CRANKCASE COVER	B-09	FRONT BRAKE HOSE	H-12	HANDLE SWITCH	H-08	RADIATOR	C-09	SIGNAL GENERATOR	D-12	TURN SIGNAL LAMP	E-09
CAM CHAIN	B-14	CRANKSHAFT	B-11	FRONT CALIPERS	H-09	HANDLEBAR	H-06	RADIATOR HOSE	C-10	SPEEDOMETER	E-04	WATER PUMP	C-08
CAM SHAFT - VALVE	B-13	CYLINDER	B-05	FRONT DAMPER	G-10	HEADLAMP	E-07	REAR CALIPER	I-11	STAND	F-04	WIRING HARNESS	E-11
CARBURETOR	C-02	CYLINDER HEAD	B-03	FRONT FENDER	H-02	INSTALLATION PARTS	J-07	REAR CUSHION LEVER	I-04	STARTER CLUTCH	B-12		
CARBURETOR ADJUSTING SCREW	C-03	CYLINDER HEAD COVER	B-02	FRONT MASTER CYLINDER	H-11	LABEL	J-15	REAR FENDER	I-06	STARTING MOTOR	D-08		
CLUTCH	D-02	ELECTRICAL	E-03	FRONT WHEEL	H-04	MUFFLER	C-06	REAR MASTER CYLINDER	I-13	STEERING DAMPER	G-15		
COWLING BODY	J-03	FOOTREST	F-05	FUEL COCK	F-12	OIL COOLER - OIL FILTER	C-07	REAR SWINGING ARM	I-02	STEERING STEM	G-14		