




SHEET 2 - STARTING AND CHARGING SYSTEM, POWER DISTRIBUTION




SHEET 3 - POWER DISTRIBUTION




SHEET 4 - POWER DISTRIBUTION




SHEET 5 - GROUNDS




SHEET 6 - ENGINE



SHEET 7 - ENGINE



SHEET 8 - POWER TAKE-OFF (PTO) AND ENGINE




SHEET 9 - SAFETY CONTROLLER

WORKMASTER 33 / WORKMASTER 37 COMPACT TRACTOR 47951359 ELECTRICAL SCHEMATIC HYDROSTATIC TRANSMISSION 1ST EDITION

SCHEMATIC SHEET INDEX

Component	Sheet
SHEET NOT USED	1
STARTING AND CHARGING SYSTEM, POWER DISTRIBUTION	2
POWER DISTRIBUTION	3
POWER DISTRIBUTION	4
POWER DISTRIBUTION	5
ENGINE	6
ENGINE	7
ENGINE	8
SAFETY CONTROLLER	9
LIGHTING	10
LIGHTING AND TRAILER CONNECTOR	11
ANALOG/DIGITAL INSTRUMENT CLUSTER (ADIC)	12
DIAGNOSTIC CONNECTOR AND AUDIBLE DEVICES	13

SYMBOL LEGEND



COMPONENT LEGEND

Label Prefix	Component Type	Label Prefix	Component Type
A	Electronics	K	Relays
B	Sensors	M	Motors
D	Diodes	Q	Circuit Breakers
E	Lights	R	Resistive
F	Fuses	S	Switches
G	Generators	W	Splice Blocks
H	Audio	Y	Solenoids
J	Outlets		

CIRCUIT COLOR INDEX

