


Sample of manual. Download All 1 pages at: <https://www.aresairmanual.com/downloads/new-holland-t9-390-t9-450-t9-505-t9-560-t9-615-and-t9-670-tractor-series-hydraulic-schematic-manual/>



- 1. MOTOR DRAIN
- 2. SUPPLY
- 3. HIFLOW SUPPLY
- 4. PILOT DRAIN
- 5. REGULATED
- 6. SIGNAL
- 7. HIFLOW SIGNAL
- 8. TANK
- 9. AUXILIARY VALVE CENTER SECTION MEGAFLOW
- 9A. AUXILIARY VALVE CENTER SECTION STANDARD AND PARALLEL FLOW
- 10. NOT USED
- 11. NOT USED
- 12. SUPPLY ATTACHED TO INLET PORT ON TRAILER BRAKE VALVE OR UNITS WITH TRAILER BRAKE OTHERWISE ATTACHED TO INLET PORT ON CENTER MANIFOLD
- 13. AUXILIARY VALVE WITH TRAILER BRAKE AND TPH
- 14. HITCH CYLINDERS
- 15. MEGAFLOW PUMP
- 16. NOT USED
- 17. NOT USED
- 18. STANDARD SINGLE FILTER
- 19. OPTIONAL DUAL FILTER
- 20. 500 AND 600 SERIES REAR AXLE
- 21. PTO DROPBOX
- 22. 315, 425, AND 450 SERIES REAR AXLE
- 23. PARK BRAKE PRESSURE LINE
- 24. SERVICE BRAKE PRESSURE LINE
- 25. STEERING VALVE BLOCK
- 26. SHOCK VALVES
- 27. SUCTION VALVES
- 28. PILOT PRESSURE VALVE
- 29. PRESSURE REDUCING VALVE
- 30. PILOT STEERING UNIT
- 31. STEERING CYLINDERS
- 32. HYDRAULIC FAN DRIVE
- 33. COOLER
- 34. COOLER BYPASS VALVE
- 35. SERVICE BRAKE SUPPLY LINE
- 36. PARK BRAKE VALVE SUPPLY LINE
- 37. MAIN HYDRAULIC PUMP
- 38. CHARGE REGULATOR VALVE
- 39. HYDRAULIC TANK
- 40. SERVICE BRAKE VALVE
- 41. PARK BRAKE VALVE
- 42. 315, 425 AND 450 SERIES FRONT AXLE
- 43. 500 AND 600 SERIES FRONT AXLE

T9.390, T9.450, T9.505, T9.560, T9.615, AND T9.670 TRACTOR SERIES  
 HYDRAULIC SCHEMATIC  
 RAC 84416546

- LEGEND
- PFC PISTON PUMP SUPPLY (HIGH PRESSURE) █
  - PFC PISTON PUMP SUPPLY (REGULATED) █
  - CHARGE PUMP FLOW █
  - RETURN TO TANK / SUMP █
  - MEGAFLOW PFC PISTON PUMP SUPPLY █
  - AXLE LUBE SUPPLY █
  - FAN DRIVE PUMP SUPPLY █