


Color LaserJet™

8500, 8500 N, 8500 DN Printer

Service Manual



Product: 1998 HP Color LaserJet 8500, 8500N, 8500DN Printer Service Repair Workshop Manual
Full Download: <https://www.arepairmanual.com/downloads/1998-hp-color-laserjet-8500-8500n-8500dn-printer-service-repair-workshop-manual/>

Sample of manual. Download All 552 pages at:
<https://www.arepairmanual.com/downloads/1998-hp-color-laserjet-8500-8500n-8500dn-printer->

HP Color LaserJet 8500, 8500 N, 8500 DN Printer

Service Manual_____

Copyright Information

© 1998 Hewlett-Packard
Company

All Rights Reserved.

Reproduction, adaptations, or translation without prior written permission is prohibited except as allowed under copyright laws.

Part number C3983-90954

First edition, October 1998

Printed in USA

Warranty

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with respect to this information. HEWLETT-PACKARD SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Hewlett-Packard shall not be liable for any direct, indirect, incidental, consequential, or other damage alleged in connection with the furnishing or use of this information.

NOTICE TO U.S. GOVERNMENT USERS:
RESTRICTED RIGHTS
COMMERCIAL COMPUTER SOFTWARE: "Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1)(ii) of the Rights in Technical Data Clause at DFARS 52.227-7013.

Trademark Credits

CompuServe™ is a U.S. trademark of CompuServe, Inc.

MS-DOS® is a U.S. registered trademark of Microsoft Corporation.

Photoshop™ and PostScript® are registered trademarks of Adobe Systems Incorporated.

TrueType™ is a U.S. trademark of Apple Computer, Inc.

UNIX® is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

Safety Information

WARNING
Electrical Shock Hazard

To avoid electrical shock, use only supplied power cords and connect only to properly grounded (3-hole) wall outlets.

Contents

List of figures

List of tables

1 Product information

Chapter contents	17
Printer features	19
Specifications	21
Site requirements	24
Media requirements	26
Identification (model and serial numbers)	34
Product overview	35
Safety information	39

2 Service approach

Chapter contents	47
Introduction	49
Parts and supplies	49
Technical assistance	52
Warranty	55

3 Operational overview

Chapter contents	57
Verifying package contents	59
Verifying the cables are installed	60
Connecting the printer to the network	62
Changing the printer control panel overlay	65
Printer control panel layout	66
Menu maps	68
Selecting the display language	84
Installing the consumables	85
Configuring input trays	90
Verifying the printer is installed correctly	92
Verifying DIMM installation	93
Paper handling accessory status LEDs	94

4 Printer maintenance

Chapter contents97
Cleaning procedures99
Printer consumables104
Installing consumables106

5 Theory of operation

Chapter contents119
Introduction123
Color theory126
Image formation129
Consumable detection mechanisms142
Electrical systems152
Mechanical systems157
Paper path166
EPH controller board180
2,000-sheet input unit180
Multi-bin mailbox186
Duplexer192
Printer timing192

6 Removal and replacement

Chapter contents199
Introduction203
Maintenance units205
Doors and covers206
Top assemblies223
Front assemblies227
Left assemblies229
Right assemblies237
Rear assemblies246
2,000-sheet input unit271
Multi-bin mailbox286

7 Troubleshooting

Chapter contents	311
Pre-troubleshooting checklist	315
Printer message troubleshooting	316
Aids to troubleshooting	361
Paper path troubleshooting	378
Image formation troubleshooting	383
Image defects troubleshooting	386
Color balance adjustment	414
Repetitive defects troubleshooting	419
2,000-sheet input unit troubleshooting	426
Multi-bin mailbox troubleshooting	434
Communications troubleshooting	439
Diagrams	440

8 Parts and diagrams

Chapter contents	443
Overview	445
Ordering parts	445
Illustrations and parts lists	449
Numerical parts list	502
Alphabetical parts list	513

Index

List of figures

Figure 1.	Space requirements	25
Figure 2.	Example of printer model number and serial number label (110 V and 220 V)	34
Figure 3.	Front view	35
Figure 4.	Rear view	36
Figure 5.	Formatter assemblies	37
Figure 6.	Paper handling accessories and options	38
Figure 7.	Contents of printer box	59
Figure 8.	Power cord connection	60
Figure 9.	C-link and power cables connections	61
Figure 10.	Network connections	62
Figure 11.	Parallel cable connection	64
Figure 12.	Changing the printer control panel overlay	65
Figure 13.	Location of printer control panel features	66
Figure 14.	Consumable installation order	85
Figure 15.	DIMM slot configuration	93
Figure 16.	Paper handling accessory status LEDs	94
Figure 17.	Cleaning the post charger unit	99
Figure 18.	Cleaning the density sensor	100
Figure 19.	Cleaning the transfer charger	101
Figure 20.	Removing the waste toner tray cover	102
Figure 21.	Cleaning the waste toner tray	103
Figure 22.	Location of consumables in printer	104
Figure 23.	Contents of transfer kit	106
Figure 24.	Contents of drum kit	110
Figure 25.	Contents of fuser kit	113
Figure 26.	Cross-section view of internal components	124
Figure 27.	Image formation	129
Figure 28.	Electrostatic latent image formation block	130
Figure 29.	Preconditioning exposure	131
Figure 30.	Primary charging of imaging drum	132
Figure 31.	Black toner cartridge (left) and color toner cartridge (right) development	133
Figure 32.	Primary transfer	134
Figure 33.	Post charging	135
Figure 34.	Secondary transfer	136
Figure 35.	Separation	137
Figure 36.	Cleaning roller charging	138

Figure 37.	Transfer drum cleaning	139
Figure 38.	Imaging drum cleaning block	140
Figure 39.	Fusing the toner	141
Figure 40.	Waste toner level detection	143
Figure 41.	Color toner level detections	145
Figure 42.	Color toner lever detection	146
Figure 43.	Density sensor	148
Figure 44.	Transfer belt control	149
Figure 45.	Cleaning roller control	150
Figure 46.	Carousel control	151
Figure 47.	Power distribution circuit diagram	152
Figure 48.	Power Save circuit diagram	153
Figure 49.	High-voltage power supply circuit	156
Figure 50.	Laser/scanner	158
Figure 51.	Printer motors and heaters	159
Figure 52.	Carousel motor (M1)	160
Figure 53.	Drum motor (M2)	161
Figure 54.	Cartridge motor (M3)	162
Figure 55.	Main motor (M4)	163
Figure 56.	Pick-up motor (M5)	164
Figure 57.	Paper path	166
Figure 58.	Tray 2 and 3 pick-up	169
Figure 59.	Tray 1 pick-up	171
Figure 60.	Printer sensors	172
Figure 61.	Printer switches	174
Figure 62.	Printer clutches and solenoids	177
Figure 63.	Fusing and delivery unit	179
Figure 64.	2,000-sheet input unit sensors, switches, clutches, and motors	181
Figure 65.	2,000-sheet input unit paper path	185
Figure 66.	Multi-bin mailbox cabling	188
Figure 67.	Multi-bin mailbox sensors	189
Figure 68.	Multi-bin mailbox paper path	191
Figure 69.	Timing chart for WAIT period (1 of 2)	193
Figure 70.	Timing chart for WAIT period (2 of 2)	194
Figure 71.	Timing chart for printing full color letter-sized page (1 of 2)	195
Figure 72.	Timing chart for printing full color letter-sized page (2 of 2)	196
Figure 73.	Timing chart for printing full color 11-by-17-inch sized page (1 of 2)	197
Figure 74.	Timing chart for printing full color 11-by-17 inch sized page (2 of 2)	198

Figure 75.	Orientation of printer and accessories: top, front, and right	206
Figure 76.	Orientation of printer and accessories: rear and left	207
Figure 77.	Removing the front cover	208
Figure 78.	Front right cover	209
Figure 79.	Inside left panel	210
Figure 80.	Screws behind left door	211
Figure 81.	Screws behind right door	212
Figure 82.	Connector on top cover	212
Figure 83.	Left door and strap	213
Figure 84.	Screws on left rear cover	214
Figure 85.	Screws on upper left door	215
Figure 86.	Stopper hinges on lower left cover	216
Figure 87.	Connectors on the right upper door	217
Figure 88.	E-ring	218
Figure 89.	Spring on right cover subassembly	219
Figure 90.	Right rear cover	220
Figure 91.	Screws on the right lower cover	221
Figure 92.	Rear cover	222
Figure 93.	Bottom of the control panel	223
Figure 94.	Scanner unit	224
Figure 95.	Upper airflow vent	225
Figure 96.	Face-down exit sensor rail	225
Figure 97.	Face-down output assembly	226
Figure 98.	Toner lock sensor and color cartridge sensor	227
Figure 99.	Subrelay PCA	228
Figure 100.	Formatter board	230
Figure 101.	Connector on formatter board	232
Figure 102.	Back side of formatter board	232
Figure 103.	Feeder assembly	233
Figure 104.	Face-up solenoid	234
Figure 105.	Face-up solenoid	235
Figure 106.	Screws on the face-up exit assembly	236
Figure 107.	Tray 1	237
Figure 108.	Pick-up roller	238
Figure 109.	Registration roller assembly (front)	239
Figure 110.	Registration roller assembly (back)	240
Figure 111.	Connectors on registration roller assembly	241
Figure 112.	Density sensor	242
Figure 113.	Paper pick-up assembly	243
Figure 114.	Paper pick-up assembly	244
Figure 115.	Paper pick-up assembly	245

Figure 116.	Rear of printer with cover removed	246
Figure 117.	Rear of printer with formatter pan removed	247
Figure 118.	Formatter pan	248
Figure 119.	Formatter pan (left side)	249
Figure 120.	Fan 1	250
Figure 121.	Fan 2	251
Figure 122.	Power supply	252
Figure 123.	Controller board	253
Figure 124.	Cartridge motor	254
Figure 125.	Main motor	255
Figure 126.	Carousel motor PCA	256
Figure 127.	Fans 1 and 2 housing assemblies	257
Figure 128.	Carousel motor	258
Figure 129.	Lower air duct	259
Figure 130.	Screws on the delivery drive assembly	260
Figure 131.	Access to main gear assembly	261
Figure 132.	High-voltage converter 1 PCA	262
Figure 133.	High-voltage converter 1	263
Figure 134.	High-voltage converter 2 PCA	264
Figure 135.	High-voltage converter 2	265
Figure 136.	High-voltage converter 2	266
Figure 137.	Drum/cartridge drive assembly	267
Figure 138.	Separation discharge high-voltage converter	268
Figure 139.	Plate over media size sensing PCAs	269
Figure 140.	Media size sensing PCAs	270
Figure 141.	Front cover of the 2,000-sheet input unit	272
Figure 142.	Back cover removal	273
Figure 143.	Left cover removal	274
Figure 144.	Vertical transfer unit (VTU)	275
Figure 145.	Right cover with VTU removed	276
Figure 146.	Tray 4 removal	277
Figure 147.	Paper pick-up assembly	278
Figure 148.	Controller PCA	279
Figure 149.	Screw on front LED PCA assembly	280
Figure 150.	Front LED PCA	281
Figure 151.	Power supply	281
Figure 152.	Main drive assembly	282
Figure 153.	Paper quantity switch assembly	283
Figure 154.	Paper size switch assembly	284
Figure 155.	Tension springs	285
Figure 156.	Front and back covers	287
Figure 157.	Top cover	288
Figure 158.	Power supply	289
Figure 159.	Paper bins	290

Figure 160.	Flipper assembly (1 of 3)	291
Figure 161.	Flipper assembly (2 of 3)	292
Figure 162.	Flipper assembly (3 of 3)	292
Figure 163.	Delivery head motor	293
Figure 164.	Transport belt motor	294
Figure 165.	Input paper guide (1 of 2)	295
Figure 166.	Input paper guide (2 of 2)	296
Figure 167.	Metallic tape and housing assembly (1 of 2)	297
Figure 168.	Metallic tape and housing assembly (2 of 2)	298
Figure 169.	Controller PCA (1 of 2)	299
Figure 170.	Controller PCA (2 of 2)	300
Figure 171.	Anti-curl strings (1 of 2)	301
Figure 172.	Anti-curl strings (2 of 2)	302
Figure 173.	Delivery head assembly (1 of 4)	303
Figure 174.	Delivery head assembly (2 of 4)	304
Figure 175.	Delivery head assembly (3 of 4)	304
Figure 176.	Delivery head assembly (4 of 4)	305
Figure 177.	Interlock switch	306
Figure 178.	Diagnostic LED PCA	307
Figure 179.	User status LED PCA	308
Figure 180.	Attachment assembly	309
Figure 181.	Example of a configuration page	362
Figure 182.	Right upper cover detection interlock	370
Figure 183.	Drum cartridge detection interlock	370
Figure 184.	Black toner cartridge detection interlock	371
Figure 185.	Toner carousel door detection interlock	371
Figure 186.	Front cover/delivery cover detection interlocks	372
Figure 187.	Laser shutters	373
Figure 188.	Left upper cover detection	374
Figure 189.	Right lower cover detection	374
Figure 190.	Printer paper path	380
Figure 191.	Image orientation and direction of travel	386
Figure 192.	Incorrect registration (late and early print)	388
Figure 193.	Image skew	389
Figure 194.	Blank or partially blank page	390
Figure 195.	Horizontal lines (in one color)	391
Figure 196.	Horizontal lines (in all colors, CMYK)	392
Figure 197.	Rain or speckled print	393
Figure 198.	Black, brown, or orange bands	394
Figure 199.	Background toner scatter	395
Figure 200.	Mottled process colors or poor transfer	396
Figure 201.	Stray toner	397
Figure 202.	Dark yellow or contaminated print	398
Figure 203.	Color adjust page	415

Figure 204.	Repetitive defect ruler	420
Figure 205.	Cleaning the transfer drum	423
Figure 206.	Rear view of 2,000-sheet input unit	428
Figure 207.	Location of sensors in the 2,000-sheet input unit	432
Figure 208.	Multi-bin mailbox power supply test mode switch	434
Figure 209.	Connectors on the controller board	440
Figure 210.	General printer circuit diagram (1 of 2)	441
Figure 211.	General printer circuit diagram (2 of 2)	442
Figure 212.	Major assembly locations (1 of 2)	450
Figure 213.	Major assembly locations (2 of 2)	451
Figure 214.	Printer covers and doors (1 of 3)	452
Figure 215.	Printer covers and doors (2 of 3)	454
Figure 216.	Printer covers and doors (3 of 3)	456
Figure 217.	Internal cover assembly	458
Figure 218.	Internal components (1 of 6)	460
Figure 219.	Internal components (2 of 6)	462
Figure 220.	Internal components (3 of 6)	464
Figure 221.	Internal components (4 of 6)	466
Figure 222.	Internal components (5 of 6)	468
Figure 223.	Internal components (6 of 6)	470
Figure 224.	Drum/cartridge drive assembly	472
Figure 225.	Delivery drive assembly	473
Figure 226.	Tray 3 assembly	474
Figure 227.	Tray 2 assembly	475
Figure 228.	Paper pick-up assembly (1 of 3)	476
Figure 229.	Paper pick-up assembly (2 of 3)	477
Figure 230.	Paper pick-up assembly (3 of 3)	478
Figure 231.	Registration frame assembly	480
Figure 232.	Registration roller assembly	481
Figure 233.	Feeder assembly	482
Figure 234.	Tray 1 pick-up assembly	483
Figure 235.	Tray 1 assembly	484
Figure 236.	Delivery assembly	485
Figure 237.	Delivery cover assembly	486
Figure 238.	Transfer belt assembly	487
Figure 239.	Fuser assembly (1 of 2)	488
Figure 240.	Fuser assembly (2 of 2)	489
Figure 241.	PCA assembly location diagram	491
Figure 242.	2,000-sheet input unit covers and doors	492
Figure 243.	2,000-sheet input unit internal components	494
Figure 244.	Multi-bin mailbox components (1 of 3)	496
Figure 245.	Multi-bin mailbox components (2 of 3)	498
Figure 246.	Multi-bin mailbox components (3 of 3)	500

List of tables

Table 1.	Features and optional accessories by printer model.	19
Table 2.	Printer performance	20
Table 3.	Electrical specifications	21
Table 4.	Operating environment specifications	21
Table 5.	Acoustic emissions	22
Table 6.	Printer dimensions	22
Table 7.	Consumable storage specifications	23
Table 8.	Media capacity and sizes for input trays	28
Table 9.	Media capacity and sizes for the multi-bin mailbox	30
Table 10.	Ordering information	49
Table 11.	Technical support websites	50
Table 12.	Printer control panel menu map overview	69
Table 13.	Information Menu	71
Table 14.	Proof and Print Menu	72
Table 15.	Paper Handling Menu	72
Table 16.	Configuration Menu	75
Table 17.	Printing Menu	76
Table 18.	I/O Menu	78
Table 19.	Resets Menu	78
Table 20.	Color Adjust Menu	79
Table 21.	Service Mode Menu	80
Table 22.	Paper handling accessory status LEDs	95
Table 23.	Replacement frequencies for printer consumables	105
Table 24.	Subtractive color absorption	126
Table 25.	Subtractive color mixing	127
Table 26.	Additive color mixing	128
Table 27.	Fusing temperatures	154
Table 28.	Printer motor and heater names and descriptions	159
Table 29.	Fan operation	165
Table 30.	Feed speeds based on media type	167
Table 31.	Printer sensor names and descriptions	173
Table 32.	Printer switch names and descriptions	175
Table 33.	Tray 2 and Tray 3 paper size detection	176
Table 34.	Printer clutch and solenoid names and descriptions	177
Table 35.	2,000-sheet input unit sensors, switches, clutches, and motors	182
Table 36.	Paper quantity detection switches	183
Table 37.	Paper size detection switches	183

Table 38.	Multi-bin mailbox sensors, switches, motors, and controller board PCA	190
Table 39.	Numbered printer messages	316
Table 40.	Unnumbered printer messages	334
Table 41.	Sensor monitor test	369
Table 42.	Media jam detection	381
Table 43.	Streaking	401
Table 44.	Neutral axis adjustments	418
Table 45.	Status LED on the 2,000-sheet input unit	427
Table 46.	Patterns of LED flashing (2-second pause between each pattern)	429
Table 47.	DIP switch settings for troubleshooting test procedures	430
Table 48.	Status LEDs on the multi-bin mailbox	436
Table 49.	Options, accessories, and consumables	446
Table 50.	Miscellaneous parts	448
Table 51.	Printer doors and covers (1 of 3)	453
Table 52.	Printer doors and covers (2 of 3)	455
Table 53.	Printer covers and doors parts	457
Table 54.	Internal cover assembly parts	459
Table 55.	Internal components parts (1 of 6)	461
Table 56.	Internal components parts (2 of 6)	463
Table 57.	Internal components parts (3 of 6)	465
Table 58.	Internal components parts (4 of 6)	467
Table 59.	Internal components parts (5 of 6)	469
Table 60.	Internal components parts (6 of 6)	471
Table 61.	Drum/cartridge drive assembly parts	472
Table 62.	Delivery drive assembly parts	473
Table 63.	Tray 3 assembly parts	474
Table 64.	Tray 2 assembly	475
Table 65.	Paper pick-up assembly parts	479
Table 66.	Registration frame assembly parts	480
Table 67.	Registration roller assembly parts	481
Table 68.	Feeder assembly parts	482
Table 69.	Tray 1 pick-up assembly parts	483
Table 70.	Tray 1 assembly parts	484
Table 71.	Delivery assembly parts	485
Table 72.	Delivery cover assembly parts	486
Table 73.	Transfer belt assembly parts	487
Table 74.	Fuser assembly parts	490
Table 75.	PCA assembly parts	491
Table 76.	2,000-sheet input unit cover and door parts	493
Table 77.	2,000-sheet input unit internal component parts	495
Table 78.	Multi-bin mailbox component parts (1 of 3)	497

Table 79. Multi-bin mailbox component parts (2 of 3)	499
Table 80. Multi-bin mailbox component parts (3 of 3)	501
Table 81. Numerical parts list	502
Table 82. Alphabetical parts list	513

1

Product information

Chapter contents

Printer features	19
Specifications	21
Electrical specifications	21
Operating environment specifications	21
Acoustic emission specifications	22
Printer dimensions	22
Consumable storage specifications	23
Site requirements	24
General guidelines	24
Space requirements	25
Media requirements	26
Selecting media	26
Storing media	27
Media capacity and sizes for input trays	28
Media capacity and sizes for the multi-bin mailbox	30
Media weights and sizes for duplexer	31
Envelopes	31
Transparencies	31
Glossy media	32
Heavy paper stock	32
Colored media	32
Media to avoid	33

Identification (model and serial numbers)	34
Product overview	35
External views	35
Formatter assemblies	37
Paper handling accessories and options	38
Safety information	39
FCC regulations	39
Canadian DOC regulations	39
Declarations of conformity	40
VCCI statement (Japan)	43
EMI statement (Korea)	43
Laser safety statement	43
Laser statement for Finland	44
Product information sheet	45
Toner safety	45
Material Safety Data Sheet	45
Ozone safety	46

Printer features

Table 1. Features and optional accessories by printer model

	8500	8500 N	8500 DN
Features			
Standard DIMM memory	32 MB	32 MB	64 MB
Expandable to 512 MB of DIMM ¹ memory	X	X	X
Internal printer hard disk			X
2,000-sheet input unit			X
Duplexer			X
HP JetDirect 600N internal print server		X	X
Optional accessories			
External (EIO-compatible) printer hard disk	X	X	
ROM, or synchronous DRAM DIMMs	X	X	X
Duplexer	X	X	
HP JetDirect 600N internal print server	X		
Multi-bin mailbox			X
¹ To expand the DIMM memory to 512 MB, install 64-MB DIMMs in all eight DIMM slots.			

Table 2. Printer performance

Print speeds	<ul style="list-style-type: none">● 24 pages per minute (ppm) black and white (b/w)● 6 ppm color
Text and graphics resolution	<ul style="list-style-type: none">● 600 dpi resolution
Approximate print speeds	
Letter, A4-size	<ul style="list-style-type: none">● 24 ppm b/w; 6 ppm color
Legal, Executive, 11-by-17 inch size	<ul style="list-style-type: none">● 12 ppm b/w; 3 ppm color
Heavy paper	<ul style="list-style-type: none">● 3.2 ppm b/w; 2.2 ppm color
Transparencies	<ul style="list-style-type: none">● 2.6 ppm b/w; 2.0 ppm color
Fonts	<ul style="list-style-type: none">● HP LaserJet 45 TrueType™ font set● PostScript® fonts
Printer personality support	<ul style="list-style-type: none">● Automatic personality switching● PCL¹ and PostScript support
User interface and EIO	<ul style="list-style-type: none">● Standard ECP or bidirectional parallel cable interface (IEEE-1284 compliant)● 2 enhanced input/output (EIO) slots● Automatic I/O switching
¹ Not available at initial product introduction.	

The approximate print speeds offered by this printer might vary from those listed above because the following factors affect processing time:

- complexity and size of graphics
- I/O configuration
- computer configuration
- amount of printer memory
- network operating system
- network configuration
- printer color calibration

Specifications

Electrical specifications

Table 3. Electrical specifications

Item	110-volt models	220-volt models
Power requirements	100 to 127 V (+/- 10%) 50/60 Hz (+/- 2 Hz)	220 to 240 V (+/- 10%) 50/60 Hz (+/- 2 Hz)
Power consumption (typical)		
During printing (black and white)	750 W (average)	750 W (average)
During printing (color)	375 W (average)	375 W (average)
During standby	190 W (average)	190 W (average)
During Power Save mode	< 45 W	< 45 W
During Off mode	< 2 W	< 2 W
Minimum recommended circuit capacity for typical product	12.0 A at 120 V	6.0 A at 220 V

Operating environment specifications

Table 4. Operating environment specifications

Item	Operating	Storage
Temperature		
Recommended	20 to 26° C (68 to 79° F)	0 to 35° C (32 to 95° F)
Allowed	15 to 30° C (59 to 86° F)	-20 to 60° C (-4 to 140° F)
Humidity		
Recommended	20 to 50% RH	35 to 85% RH
Allowed	10 to 80% RH	10 to 95% RH
Altitude		
Allowed	0 to 3,048 m (0 to 10,000 ft)	0 to 3,048 m (0 to 10,000 ft)

Acoustic emission specifications

Table 5. Acoustic emissions

Operation position (per ISO 9296, DIN 45635, T.19)	
Printing	L _p A 54 dB(A)
Standby	L _p A 49 dB(A)
Bystander 1 meter (per ISO 7779, DIN 45635, T.19)	
Printing	L _p A 50 dB(A)
Standby	L _p A 45 dB(A)
Sound power (per ISO 9296)	
Printing	6.7 B (A)
Standby	6.1 B (A)

Printer dimensions

Table 6. Printer dimensions

	Printer	Printer with stand	Printer with 2,000-sheet input unit and multi-bin mailbox
Height	750 mm 30 in	1111 mm 44 in	1230 mm 48 in
Width	566 mm 22 in	566 mm 22 in	1056 mm 42 in
Depth	625 mm 25 in	625 mm 25 in	625 mm 25 in
Weight (with consumables)	87 kg 192 lb	100 kg 220 lb	118 kg 260 lb

Consumable storage specifications

The life of consumables is greatly affected by their storage environment. Use the following table to determine shelf life of stored consumables.

For consumable replacement specifications, see page 105.

Table 7. Consumable storage specifications

Temperature	Normal (maximum of 2.5 years)	0 to 35° C (32 to 95° F)
	Severe (maximum of 18 days)	High 35 to 40° C (95 to 104° F) Low 0 to -20° C (32 to -4° F)
Maximum temperature change rate	40 to 15° C (104 to 59° F) within 3 minutes -20 to 25° C (-4 to 77° F) within 3 minutes	
Humidity	Normal (maximum of 2.5 years)	35 to 85% RH
	Severe (maximum of 18 days)	High 85 to 95% RH Low 10 to 35% RH
Atmospheric pressure	460 to 760 mm Hg	

Site requirements

General guidelines

Locating and placing the printer correctly are important in maintaining the performance level that has been set at the factory. In particular, be sure to adhere to the environmental specifications listed in this chapter. The following are recommendations for locating and placing the printer:

- Install in a well-ventilated, dust-free area.
- Install on a hard, level surface.
- Install where the temperature and humidity do not change abruptly. Do not install near water sources, humidifiers, air conditioners, refrigerators, or other major appliances.
- Do not expose the printer to direct sunlight, dust, open flames, or ammonia fumes.
- Install the printer away from walls or other objects. There must be enough space around the printer for proper access and ventilation (see figure 1 on page 25).
- Install the printer away from the direct flow of exhaust from air ventilation systems.

Space requirements




Figure 1.

Space requirements

- 1 Top view (with optional multi-bin mailbox and 2,000-sheet input unit)
- 2 Front view (with optional multi-bin mailbox and 2,000-sheet input unit)

Media requirements

Selecting media

Many types of paper and other print media can be used with the printer, within certain specifications. Using media that does not meet the specifications outlined in this chapter can increase the incidence of media jams, contribute to repair and maintenance costs, and cause premature wear, print quality problems, and problems requiring service. This service might not be covered by the HP warranty or service agreements.

Before purchasing media or specialized forms, test a small quantity in the printer. Make sure your media supplier obtains and understands the media specifications in the *HP LaserJet Printer Family Paper Specification Guide*. For ordering information, see page 445.

Note

It is possible that media could meet all of the specifications in this chapter and still not print satisfactorily. This might be caused by abnormal characteristics of the printing environment, such as extremes in temperature and humidity.

- For complete media specifications, see the *HP LaserJet Printer Family Paper Specification Guide*.
- Use only print media that meet the specifications outlined in this chapter.
- Do not try to print unsupported sizes or weights of media or other unsupported media.
- Always handle transparencies and glossy media by their edges to avoid fingerprints in the image area.
- Adhesives on any type of media must be compatible with the printer's fusing temperatures (approximately 190° C or 374° F).
- Do not use media that have already passed through the printer or through a copy machine, even if there is no printing on the page.
- Recycled media can be used with this printer. Recycled media must meet the specifications described in this chapter.

Storing media

Follow these guidelines when stacking and storing media:

- Store paper in its ream wrapper until you are ready to use it.
- Rewrap partially used packages of media before storing.
- Stack each carton upright and squarely on top of each other.
- Store envelopes in a protective box to avoid damaging the envelope edges.
- Keep stored media away from temperature and humidity extremes.
- *Do not* store cartons or reams directly on the floor where they will absorb humidity. Instead, place cartons on a pallet or on shelves.
- *Do not* store individual reams in any manner that causes them to curl or warp along the edges.
- *Do not* stack more than six cartons on top of each other.
- *Do not* place anything on top of media, regardless of whether the media is packaged or unpackaged.
- *Do not* store printed documents in vinyl folders or expose the documents to petroleum-based solvents.

Media capacity and sizes for input trays

The following table lists the types and sizes of media supported by each input tray. For best results, use HP LaserJet paper or conventional white copier paper. The media should be of good quality and free of cuts, nicks, tears, spots, loose particles, dust, wrinkles, voids, perforations, and curled or bent edges. For a complete list of media specifications, see the *HP LaserJet Printer Family Paper Specification Guide*.

Table 8. Media capacity and sizes for input trays

Media type	Media size and orientation	Media weight	Maximum capacity
Tray 1			
Paper Plain Preprinted Letterhead Prepunched Bond Recycled Color Card stock Heavy (more than 28 lb, 105 g/m ²) Glossy	11 by 17 in (portrait) JIS B4 (portrait) A3 (portrait) A4 (portrait) A5 (portrait) Custom min. (99 by 190 mm, 3.90 by 7.49 in) (portrait) Custom max. (304 by 469 mm, 11.98 by 18.48 in) (portrait) Executive (portrait) ISO B5 (portrait) JIS B4 (portrait) JIS B5 (portrait) Letter (landscape) Legal (landscape)	16 to 58 lb (60 to 216 g/m ²) bond	100 sheets of 20 lb (75 g/m ²) bond Limit to media-fill mark on the media width guides
Envelopes	B5 (portrait) C5 (portrait) Commercial #10 (Com10) (portrait) DL (portrait) Double Post Card (JPOSTD) Monarch (portrait)	Maximum 24 lb (90 g/m ²) bond	Approximately 10 Limit to media-fill mark on the media width guides
Labels	A4 (landscape) Letter (landscape)	—	Limit to media-fill mark on the media width guides
Transparencies	A4 (landscape) Letter (landscape)	4 to 5 mils (0.10 to 0.13 mm) thick*	Limit to media-fill mark on the media width guides