

# hp LaserJet 8100 and 8150


print systems and paper  
handling devices

**service manual**



i n v e n t

Product: 2000 HP LaserJet 8150 and 8100 Series Print Systems and Paper Handling Devices Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/2000-hp-laserjet-8150-and-8100-series-print-systems-and-paper-handling-devices-service-repair-workshop-manual/>



Product: 2000 HP LaserJet 8150 and 8100 Series Print Systems and Paper Handling Devices  
Full Download: <https://www.arepairmanual.com/downloads/2000-hp-laserjet-8150-and-8100-series-print-systems-and-paper-handling-devices-service-repair-workshop-manual/>

Sample of manual. Download All 844 pages at:  
<https://www.arepairmanual.com/downloads/2000-hp-laserjet-8150-and-8100-series-print-systems-and-paper-handling-devices-service-repair-workshop-manual/>

HP LaserJet 8150 and 8100  
Series Print Systems and Paper  
Handling Devices

**Service Manual** \_\_\_\_\_

© Copyright Hewlett-Packard Company, 2000

All Rights Reserved.  
Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Part number: C4265-90907

First Edition, November 2000

## Warranty

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with respect to this information. HEWLETT-PACKARD SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Hewlett-Packard shall not be liable for any direct, indirect, incidental, consequential, or other damage alleged in connection with the furnishing or use of this information.

## Trademark Credits

Adobe is a trademark of Adobe Systems Incorporated which may be registered in certain jurisdictions.

Arial is a U.S. registered trademark of the Monotype Corporation.

CompuServe™ is a U.S. trademark of CompuServe, Inc.

ENERGY STAR is a U.S. registered service mark of the United States Environmental Protection Agency.

Microsoft® is a U.S. registered trademark of Microsoft Corporation.

PANTONE® Pantone, Inc.'s check-standard trademark for color.

PostScript is a trademark of Adobe Systems, Incorporated, which may be registered in certain jurisdictions.

TrueType is a U.S. trademark of Apple Computer, Inc.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

Windows, MS Windows, and Windows NT are U.S. registered trademarks of Microsoft Corporation.

# Conventions

This is a combined Service Manual for both the HP LaserJet 8100 series printer and the HP LaserJet 8150 series printer. The HP LaserJet 8150 series printer shares most characteristics of the HP LaserJet 8100 series printer, except where stated.

This manual uses the following conventions:

**Color** is used to emphasize items that are important to the material under discussion.

**Bold** is used for emphasis, particularly in situations where *italic* type would be confusing.

*Italic* type is used to indicate related documents or emphasis.

DISPLAY type indicates text as seen on the printer control panel display.

**Commands** you use on a computer keyboard or on the printer control panel are shown in **KEYCAP**. Two examples are **SELECT**, and **- VALUE +**.

COURIER type indicates text that you type on a computer keyboard exactly as shown.

---

**Hint** Hints are used to suggest an action that might simplify the process.

---

**Note** Notes contain important information set off from the text.

---

**CAUTION** Caution messages alert you to the possibility of damage to equipment or loss of data.

---

**WARNING!** Warning messages alert you to the possibility of personal injury.



# Table of Contents

## .1 Product Information

Printer Features	26
Features of the HP Digital Copier	29
Product Overview	31
External View of the Printer	31
External View of HP Digital Copier	34
Identification	37
Model and Serial Numbers	37
Paper-handling Devices, Accessories, and Options	38
Ordering Information	40
Hard Disk	47
Determining Memory Requirements	48
Paper Capacities and Sizes	50
Printer and Paper-handling Devices	50
Media Selection Guidelines	52
Printer Media Selection Guidelines	52
Copy Module Media Selection Guidelines	56
Service Approach	61
Ordering Parts	61
Exchange Program	62
Consumables	62
Toner Cartridge Life	62
Refilled Toner Cartridges and Non-HP Staple Cartridges	63
Recycling Toner Cartridges	63
Technical Assistance	64
HP FIRST (Fax Information Retrieval Support Technology)	64
Internet	64
World Wide Web	65
HP Reseller Sales and Service Support Line (US Only)	65
Other Areas	65
Regulatory Information	66
FCC Regulations	66
Environmental Product Stewardship	68
Material Safety Data Sheet	70
Environmental Conformity	71
Declarations of Conformity	72
Safety Statements	73
Warranty	77

## 2 Site Requirements

Operating Environment . . . . .	80
Space Requirements . . . . .	81
Environmental Requirements . . . . .	84
Specifications . . . . .	85
Printer and Paper-handling Devices . . . . .	85
Copy Module . . . . .	89

## 3 Operating Overview

Using the Printer Control Panel . . . . .	92
Control Panel Layout . . . . .	92
Indicator Lights . . . . .	93
Settings and Defaults . . . . .	94
Printer Driver Information . . . . .	94
Paper Source Default . . . . .	95
Performing a Cold Reset . . . . .	96
Setting the Display Language . . . . .	96
Printer Control Panel Menus . . . . .	100
HP LaserJet 8100 Series Quick Copy Jobs Menu . . . . .	101
HP LaserJet 8100 Series Private/Stored Jobs Menu . . . . .	101
HP LaserJet 8150 Series Quick Copy Menu . . . . .	102
HP LaserJet 8150 Series Private/Stored Jobs Menu . . . . .	102
Information Menu . . . . .	104
Paper Handling Menu . . . . .	105
Print Quality Menu . . . . .	108
Printing Menu . . . . .	110
Configuration Menu . . . . .	113
Configuration of MBM Menu . . . . .	118
I/O Menu . . . . .	119
EIO Menu . . . . .	121
Duplex Registration Menu . . . . .	123
Resets Menu . . . . .	125
Using the HP Digital Copier Front Panel . . . . .	126
HP Digital Copier Front Panel . . . . .	127
HP Digital Copier Settings . . . . .	136
Loading Documents into the ADF . . . . .	138
Loading Documents onto the Flatbed . . . . .	140
Printer Service Mode . . . . .	141
Setting Page Count, Maintenance Count, and Serial Number . . . . .	143
Setting the Cold Reset Default Paper Size . . . . .	144
HP Digital Copier Service Mode . . . . .	145
HP Digital Copier Administrator Mode . . . . .	147
Remote Upgrade of the Printer Firmware . . . . .	148
Upgrade HP Digital Copier Firmware . . . . .	150

Testing the Printer . . . . .	153
Paper Path Test . . . . .	153
Configuration Page . . . . .	153

## 4 Maintenance and Adjustments

Cleaning the Printer and Paper Handling Accessories . . . . .	158
Cleaning Spilled Toner . . . . .	160
Cleaning the HP Digital Copier . . . . .	161
Materials . . . . .	161
Vacuum Specifications . . . . .	161
Cleaning ADF and Glass . . . . .	162
Cleaning the Document Cover, Document Holder, and Flatbed Glass . . . . .	162
Cleaning the ADF . . . . .	163
Copy Module Optics Cleaning . . . . .	165
Cleaning the ADF Lamp and Mirrors . . . . .	165
Lubricating the ADF Gears . . . . .	165
Cleaning the Carrier Unit and Mechanical Assemblies . . . . .	166
Lubricating the Carrier Unit Shaft . . . . .	166
Lubricating the Top of the Carrier Guide Rail . . . . .	166
Lubricating the Flatbed Motor Gears . . . . .	166
Cleaning the Front Panel . . . . .	166
Maintaining the Printer . . . . .	167
Maintaining the Copy Module . . . . .	168
HP Digital Copier Maintenance Parts . . . . .	168
Adjusting Printer Input Trays . . . . .	169
Adjusting for Edge-to-Edge Printing . . . . .	169
Adjusting Input Trays for Normal Printing . . . . .	170
Adjusting the 2000-sheet Printer Input Tray . . . . .	172
Adjusting Duplex Registration of the Paper Trays . . . . .	174
Adjusting the Copy Module . . . . .	175
Types of Adjustment . . . . .	175
When to Calibrate or Adjust the Copy Module . . . . .	175
Calibration Target . . . . .	175
Entering the Calibration Menu in Service Mode . . . . .	176
How to Perform an Offset Adjustment Calibration . . . . .	177
How to Perform a Density Calibration Adjustment . . . . .	177
How to Perform an ADF Vertical Magnification Adjustment . . . . .	177

## 5 Functional Overview

Printer Functional Overview . . . . .	180
Power Distribution System . . . . .	181
AC Power Distribution . . . . .	182
Overcurrent/Overvoltage Protection . . . . .	182
High Voltage Power Distribution . . . . .	183
Formatter System . . . . .	184
DC Controller System . . . . .	187
Laser and Scanner Drive . . . . .	187
Paper Motion Monitoring and Control . . . . .	187
Clutches . . . . .	187
Engine Test Microswitch . . . . .	188
Motors . . . . .	188
Image Formation System . . . . .	189
Toner Cartridge . . . . .	190
Drum Cleaning . . . . .	192
Drum Conditioning . . . . .	193
Image Writing . . . . .	194
Image Developing . . . . .	196
Image Transferring and Media Separation . . . . .	198
Image Fusing . . . . .	199
Paper Paths and Components . . . . .	200
Printer, Duplexer, and Envelope Feeder . . . . .	200
Paper Size Switches (Trays 2 and 3) . . . . .	203
Printing from Tray 1 . . . . .	203
Printing from Trays 2 and 3 . . . . .	203
Printing from the Envelope Feeder . . . . .	204
Printing with the Duplexer . . . . .	204
2000-sheet Input Tray (Tray 4) Components . . . . .	205
2000-Sheet Input Tray Operation . . . . .	207
2 x 500-sheet Input Tray . . . . .	210
2 x 500-sheet Input Tray Operation . . . . .	212
7-bin Tabletop Mailbox Components . . . . .	214
7-bin Tabletop Mailbox Operation . . . . .	216
8-bin Mailbox Components . . . . .	220
8-bin Mailbox Operation . . . . .	223
Finisher Components . . . . .	225
Stapler Unit Operation . . . . .	227
Main Functional Cycles of the Stapler (Internal Paper Path) . . . . .	229
Communication Link (Daisy Chain) . . . . .	230
Paper Jam Detection . . . . .	232
Printer Timing . . . . .	232
IEEE 1284 Parallel Cable Information . . . . .	234
Copy Module Functional Overview . . . . .	235
Copy Module System . . . . .	235
Function and Layout of the Copy Processor . . . . .	237

Copy Module Power Up Process . . . . .	239
Copy Processor Board . . . . .	239
Copy Module. . . . .	241
Printer components of copy module power up process . . . . .	242
Notes About the MFP Printer Product ID . . . . .	242
ADF Simplex Operation. . . . .	243
ADF Duplex Operation . . . . .	244
Flatbed Operation . . . . .	244
Copy Module Image Path . . . . .	246
Communication with the Printer . . . . .	248
Communication Channels. . . . .	248
Print Job Interrupt . . . . .	248
Paper Path and Sensors. . . . .	249

## 6 Removal and Replacement

Removal and Replacement Strategy. . . . .	252
Electrostatic Discharge (ESD) Precautions . . . . .	252
Required Tools . . . . .	253
User Installable Accessories . . . . .	254
Hardware Table. . . . .	262
Printer Assembly Removal and Replacement. . . . .	264
Control Panel . . . . .	265
Covers . . . . .	267
Delivery Unit (for Face-down Bin). . . . .	276
Diverter Assembly. . . . .	279
Diverter Door Assembly . . . . .	280
Lower Right Door Assembly . . . . .	281
Fan 1, Laser/Scanner and Housing (Exhaust) . . . . .	284
Fan 2, Low Voltage Power Supply (Exhaust) . . . . .	286
Fan 3, Formatter Fan and Housing (Intake) . . . . .	287
Fan 4, Delivery Unit (Exhaust) . . . . .	288
Fan 5, Tray 1 (Intake) . . . . .	289
Tray 1 . . . . .	291
Tray 1 Pickup Assembly . . . . .	294
Feeder Assembly . . . . .	298
Formatter Assembly . . . . .	300
Fusing Assembly . . . . .	302
Laser/Scanner Assembly . . . . .	304
Main Gear Assembly . . . . .	306
Main Motor Assembly . . . . .	309
Paper Input Unit (PIU) . . . . .	310
PCA, DC Controller. . . . .	311
Output Paper Sensor PCA . . . . .	312
High Voltage Power Supply (HVPS). . . . .	319
Low Voltage Power Supply (LVPS) . . . . .	320
Registration Assembly . . . . .	321

Tray 1 Feed Roller and Separation Pad . . . . .	324
Tray 2 and 3 Pickup, Feed, and Separation Rollers . . . . .	326
Paper Input Unit Sensor (PS2) . . . . .	327
Registration Sensor (PS1) . . . . .	329
Face-up Solenoid Assembly (SL3) . . . . .	331
Transfer Roller Assembly . . . . .	332
Tray 2 and 3 Assemblies . . . . .	334
2000-sheet Input Tray Removal and Replacement . . . . .	335
Orientation . . . . .	336
Front Cover . . . . .	337
Back Cover . . . . .	338
Left Cover . . . . .	339
Right Cover . . . . .	340
Main Drive Assembly . . . . .	341
Paper Tray . . . . .	343
Main Cable Harness . . . . .	344
Controller PCA . . . . .	346
Front LED PCA Assembly . . . . .	348
Pickup Assembly . . . . .	350
Power Supply . . . . .	352
Pickup, Feed, and Separation Rollers . . . . .	354
Paper Quantity Switch Assembly . . . . .	356
Paper Size Switch Assembly . . . . .	356
Vertical Transfer Unit (VTU) . . . . .	358
Tension Springs . . . . .	360
Locating Pins . . . . .	361
Casters and Stabilizing Feet . . . . .	362
Adjustable Foot . . . . .	363
2 x 500-sheet Input Tray Removal and Replacement . . . . .	364
Orientation of the 2 x 500-sheet Input Tray . . . . .	365
Back Cover . . . . .	366
Left Cover . . . . .	367
Vertical Transfer Unit (VTU) . . . . .	368
Right Cover . . . . .	371
Front Top Cover . . . . .	374
Trays 4 and 5 . . . . .	377
Pickup Assembly . . . . .	379
Paper Deck Drive Assembly . . . . .	381
Pickup, Feed, and Separation Rollers . . . . .	383
Controller PCA . . . . .	384
Tray-Size Sensing PCA . . . . .	385
Power Supply . . . . .	387
Main Cable . . . . .	388
Storage Paper Tray . . . . .	390
Front Door (Storage Area) . . . . .	391
Casters . . . . .	392
Foot Tip and Adjustable Foot Tip (Stabilizing Feet) . . . . .	393

Locating Pins . . . . .	394
Front LED PCA . . . . .	395
Envelope Feeder . . . . .	396
7-bin Tabletop Mailbox Removal and Replacement . . . . .	397
Orientation of the 7-bin Tabletop Mailbox . . . . .	398
Front Cover . . . . .	399
Back Cover . . . . .	402
Top Cover . . . . .	404
Controller PCA . . . . .	408
Power Supply . . . . .	409
Right Door Assembly (Paper Path Cover) . . . . .	410
Face-down Bins . . . . .	414
Empty Bin Sensor PCA . . . . .	417
Full Bin and Interlock Sensor PCA . . . . .	419
LED PCA . . . . .	421
Face-up Sensors PCA . . . . .	422
Reversing Mechanism Motor . . . . .	423
Face-up/Diverter Assembly (Flipper) . . . . .	425
Short Tray 7 . . . . .	428
Solenoid Reversing Mechanism . . . . .	429
Flipper Solenoid . . . . .	430
Handle . . . . .	431
Latching Mechanism . . . . .	432
Cover Latch . . . . .	433
8-bin Mailbox Removal and Replacement . . . . .	434
Orientation . . . . .	435
Front and Back Covers . . . . .	436
Top Cover . . . . .	437
Power Supply . . . . .	438
Paper Bins and Blind Cover . . . . .	439
Flipper Assembly . . . . .	440
Delivery Head Motor . . . . .	443
Transport Belt Motor . . . . .	444
Input Paper Guide . . . . .	446
Metal Tape and Housing Assembly . . . . .	448
Controller PCA . . . . .	450
Anticurl Strings . . . . .	452
Delivery Head Assembly . . . . .	454
Interlock Switch . . . . .	459
Diagnostic LED PCA . . . . .	460
User Status LED PCA . . . . .	462
Adjustable and Fixed Casters . . . . .	464
Attachment Assembly . . . . .	465
Stapler Assembly Removal and Replacement . . . . .	466
Mailbox with Stapler, Stapler Removal or Installation . . . . .	467
Back Plate . . . . .	469
Stapler Controller PCA . . . . .	471

Top Cover Assembly . . . . .	474
Stapler Bed Assembly . . . . .	475
Hinges . . . . .	477
Duplexer . . . . .	478
HP Digital Copier Removal and Replacement . . . . .	479
Installing the HP Digital Copier . . . . .	480
Install the Optional Output Accessory . . . . .	483
Install the Copy Connect EIO Board into the Printer . . . . .	484
Install the Copy Connect Cable . . . . .	485
Hardware Table . . . . .	487
Orientation of the HP Digital Copier . . . . .	489
Copy Module Maintenance Parts . . . . .	490
Separation Pad Assembly . . . . .	490
Pick Roller Assembly . . . . .	491
Copy Module Skins . . . . .	495
Document Holding Pad . . . . .	495
Paper Chute Flip-out . . . . .	496
Output Tray Flip-out . . . . .	497
Output Tray . . . . .	497
Flatbed (FB) Cover Assembly . . . . .	498
ADF Latch Cap . . . . .	501
ADF Cover . . . . .	502
Front Panel . . . . .	504
Panel Cover . . . . .	509
Front Panel Brackets . . . . .	510
Upper Cover . . . . .	512
Copy Module Power Supply/Main Board Assemblies . . . . .	514
Copy Processor Board . . . . .	514
Power Supply and Main Board Tray . . . . .	515
RFI Cover . . . . .	517
Control PCA . . . . .	519
Fan . . . . .	522
Power Supply . . . . .	523
Back PCA . . . . .	524
Copy Module ADF Unit Assemblies . . . . .	525
Optical Unit . . . . .	525
ADF Lamp PCA . . . . .	527
ADF Lamp . . . . .	529
Sensor Unit Assembly . . . . .	530
ADF Motor Unit . . . . .	533
ADF Belt . . . . .	534
LED Assembly PCA . . . . .	536
ADF Unit . . . . .	537
Copy Module Flatbed Assemblies . . . . .	538
Front Panel Frame Ground Spring . . . . .	538
Output Tray Brackets . . . . .	539
Glass Plate Assembly . . . . .	540

Home Position Sensor . . . . .	542
Carrier Unit Lamp . . . . .	544
Carrier Unit . . . . .	547
Felt Pad . . . . .	551
Feet. . . . .	552
Frame Ground Spring . . . . .	553
Front Lamp PCA . . . . .	554
Junction PCA and Cover . . . . .	555
Front Panel Ribbon Cable . . . . .	557
Carrier Belt and Motor . . . . .	559

## 7 Troubleshooting

Troubleshooting Process . . . . .	562
Printer System Troubleshooting Process . . . . .	565
Printer/Paper-Handling Troubleshooting Process . . . . .	566
Copy Module Troubleshooting Process . . . . .	568
Troubleshooting the Print System . . . . .	570
Preliminary Operating Checks . . . . .	570
Communication . . . . .	571
Interface Troubleshooting . . . . .	571
Network Troubleshooting . . . . .	573
Verify Host System Operation . . . . .	575
Verify Network and Server Operation . . . . .	575
General Troubleshooting Information . . . . .	576
Miscellaneous Problems and Solutions . . . . .	576
Paper Curl . . . . .	581
Troubleshooting the Printer and Paper-handling Devices . . . . .	582
Engine Test . . . . .	585
Event Log Pages . . . . .	586
Printer Message Tables . . . . .	595
Engine Error Messages . . . . .	596
Input Device Messages . . . . .	608
Output Device Messages . . . . .	616
Finisher Devices Messages . . . . .	628
Paper Handling Controller Error Messages . . . . .	632
Paper Jams . . . . .	634
Paper Path Test . . . . .	636
Menu Map . . . . .	639
Configuration Pages . . . . .	641
File Directory Page . . . . .	644
Usage Page . . . . .	645
Check the Toner Cartridge . . . . .	650
Image Quality Tables . . . . .	651
Repetitive Defect Ruler . . . . .	664
Image System Troubleshooting . . . . .	666
High-Voltage Power Supply Check . . . . .	667

Self-Diagnostics on Paper-handling Devices . . . . .	669
2000-sheet Input Tray Standalone Diagnostics . . . . .	669
2 x 500-sheet Input Tray Standalone Diagnostics . . . . .	673
7-bin Tabletop Mailbox Standalone Diagnostics. . . . .	677
8-bin Mailbox Standalone Diagnostics . . . . .	682
Diagrams . . . . .	690
Troubleshooting the Copy Module . . . . .	703
Status Messages . . . . .	706
Testing the Copy Module . . . . .	716
Copy Processor LED Test . . . . .	716
Copy Module Boot Up Icon Conditions. . . . .	718
Copy Module Offline Test . . . . .	719
Other Tests . . . . .	721
Service Mode Tests . . . . .	723

## 8 Parts and Diagrams

How to Use the Part Lists and Diagrams . . . . .	726
Ordering Parts . . . . .	726
Common Hardware. . . . .	726
Illustrations and Parts Lists . . . . .	727
Printer and paper-handling components. . . . .	728
Printer Parts and Diagrams. . . . .	730
Paper-Handling Devices Parts and Diagrams. . . . .	744
Input Devices . . . . .	744
Output Devices. . . . .	751
HP Digital Copier Parts and Diagrams . . . . .	762
Alphabetical Parts List (Printer and Paper-handling Devices). . . . .	777
Alphabetical Parts List (Copy Module) . . . . .	787
Numerical Parts List (Printer and Paper-handling devices). . . . .	791
Numerical Parts List (Copy Module) . . . . .	801

## Index

# List of Tables

Table 1-1.	Common features of the HP LaserJet 8100 Series and the HP LaserJet 8150 Series - - - - -	26
Table 1-2.	Comparison of HP LaserJet 8100 Series Printer Features - - - -	27
Table 1-3.	Comparison of HP LaserJet 8150 Series Printer Features - - - -	28
Table 1-4.	Accessories and Options - - - - -	40
Table 1-5.	Minimum Memory Requirements - - - - -	49
Table 1-6.	Paper Capacities and Sizes - - - - -	50
Table 1-7.	Paper Weight Equivalence - - - - -	55
Table 1-8.	Declaration of Conformity (HP LaserJet 8100 series and HP LaserJet 8150 series) - - - - -	72
Table 2-1.	Printer and Toner Cartridge Environmental Conditions - - - - -	84
Table 2-2.	Dimensions of printer and Paper-handling Devices - - - - -	85
Table 2-3.	Dimensions of Output Devices - - - - -	86
Table 2-4.	Electrical Specifications - - - - -	87
Table 2-5.	Acoustic Emissions - - - - -	88
Table 2-6.	Specifications for Copy Module - - - - -	89
Table 3-1.	Control Panel Keys - - - - -	92
Table 3-2.	Indicator Lights - - - - -	93
Table 3-3.	Factory Default Settings- - - - -	97
Table 3-4.	HP LaserJet 8100 Series Quick Copy Jobs Menu - - - - -	101
Table 3-5.	HP LaserJet 8100 Series Private/Stored Jobs Menu - - - - -	101
Table 3-6.	HP LaserJet 8150 Series Job Retention Menu- - - - -	102
Table 3-7.	Information Menu - - - - -	104
Table 3-8.	Paper Handling Menu- - - - -	105
Table 3-9.	Print Quality Menu - - - - -	108
Table 3-10.	Printing Menu- - - - -	110
Table 3-11.	Configuration Menu - - - - -	113
Table 3-12.	MBM Menu - - - - -	118
Table 3-13.	I/O Menu - - - - -	119
Table 3-14.	EIO Menu - - - - -	121
Table 3-15.	Duplex Registration Menu- - - - -	123
Table 3-16.	Resets Menu - - - - -	125
Table 3-17.	Status Bar - - - - -	127
Table 3-18.	Menu Tabs - - - - -	128
Table 3-19.	Context-sensitive Help - - - - -	133
Table 3-20.	Default Configurations - - - - -	133
Table 3-21.	Functions of Buttons and LEDs - - - - -	134
Table 3-22.	Start Button LED States- - - - -	135
Table 3-23.	Default Settings- - - - -	136
Table 3-24.	Service Mode Menu Items - - - - -	141
Table 3-25.	Key to Figure 3-5 - - - - -	154

Table 3-26.	Key to Figure 3-6 - - - - -	155
Table 4-1.	Cleaning the Printer- - - - -	160
Table 4-2.	Cleaning the Document Cover, Document Holder, and Flatbed Glass- - - - -	162
Table 4-3.	Cleaning the ADF- - - - -	163
Table 5-1.	Printer Sensors, Solenoids, Clutches, Motors, and Fans - - - -	201
Table 5-2.	Paper Size Switches - - - - -	203
Table 5-3.	2000-sheet Input Tray Sensors, Switches, Clutches and Motors - - - - -	206
Table 5-4.	2000-sheet Input Tray Paper Quantity Switches - - - - -	208
Table 5-5.	2000-sheet Input Tray Paper Size Switches - - - - -	208
Table 5-6.	2 x 500-sheet Input Tray Sensors, Switches, and Motors- - - -	211
Table 5-7.	2 x 500-sheet Input Tray Switches- - - - -	212
Table 5-8.	7-bin Tabletop Mailbox Sensors, Switches, and Motors - - - -	215
Table 5-9.	8-bin Mailbox Sensors, Switches, Motors, and Controller PCA - - - - -	221
Table 5-10.	Stapler Motors, Sensors, and Switches - - - - -	227
Table 5-11.	Printer Timing- - - - -	232
Table 5-12.	Parallel Cable Pin Assignments - - - - -	234
Table 6-1.	Hardware Table- - - - -	262
Table 6-2.	Hardware Table- - - - -	487
Table 7-1.	Paper Curl - - - - -	581
Table 7-2.	Power On Defects or Blank Display - - - - -	582
Table 7-3.	Fans - - - - -	584
Table 7-4.	HP LaserJet 8150 Series Event Log Page 2 - - - - -	587
Table 7-5.	Engine Error Messages - - - - -	596
Table 7-6.	2000-sheet Input Tray Error Messages - - - - -	608
Table 7-7.	2 x 500-sheet Input Tray Error Messages - - - - -	612
Table 7-8.	Envelope Feeder Error Messages - - - - -	615
Table 7-9.	7-bin Tabletop Mailbox Error Messages - - - - -	617
Table 7-10.	8-bin Mailbox Error Messages- - - - -	622
Table 7-11.	Stapler Error Messages - - - - -	628
Table 7-12.	Duplexer Error Messages - - - - -	631
Table 7-13.	Paper Handling Controller Error Messages - - - - -	632
Table 7-14.	General Paper Path Troubleshooting Questions - - - - -	633
Table 7-15.	Key to Figure 7-16 - - - - -	640
Table 7-16.	Printer Devices Troubleshooting- - - - -	648
Table 7-17.	Image Quality- - - - -	649
Table 7-18.	Blank (White) Page - - - - -	651
Table 7-19.	Black Pages - - - - -	651
Table 7-20.	Fading Print - - - - -	652
Table 7-21.	Dropout- - - - -	654
Table 7-22.	Black Lines (parallel or perpendicular to path) - - - - -	654
Table 7-23.	Toner Smear - - - - -	655
Table 7-24.	Background Scatter- - - - -	656
Table 7-25.	Repetitive Defects - - - - -	657
Table 7-26.	Line at Edge of Paper- - - - -	658

Table 7-27.	Misshapen Characters, Voids - - - - -	659
Table 7-28.	Faulty Registration - - - - -	660
Table 7-29.	Image Skew - - - - -	660
Table 7-30.	Bubble Print - - - - -	661
Table 7-31.	White Stripes Parallel to Path - - - - -	662
Table 7-32.	Partial Blank Page - - - - -	662
Table 7-33.	Compressed Print- - - - -	663
Table 7-34.	Blank Portion in the Middle of the Page (Tray 4 Input only)- - - - -	663
Table 7-35.	DIP Switch Settings - - - - -	671
Table 7-36.	2000-sheet Input Tray LED Status Interpretation- - - - -	672
Table 7-37.	DIP Switch Settings for troubleshooting test procedures - - - - -	674
Table 7-38.	Patterns of LED flashing (2-second pause between each pattern) - - - - -	676
Table 7-39.	DIP switch settings for troubleshooting test - - - - -	677
Table 7-40.	Patterns of Flashing LEDs - - - - -	679
Table 7-41.	8-bin Mailbox LED Status Interpretation - - - - -	685
Table 7-42.	Power On Checks - - - - -	704
Table 7-43.	Display and Communication Checks - - - - -	705
Table 7-44.	Boot Errors - - - - -	707
Table 7-45.	Equipment Errors - - - - -	708
Table 7-46.	Temporary Errors- - - - -	710
Table 7-47.	Error Conditions - - - - -	713
Table 7-48.	Copy Processor LED Test Results - - - - -	717
Table 7-49.	Icon Conditions - - - - -	718
Table 7-50.	Other Tests- - - - -	721
Table 8-1.	Printer and Paper-Handling Components - - - - -	728
Table 8-2.	Printer Covers and Doors - - - - -	731
Table 8-3.	Printer Internal Components (1 of 4) - - - - -	733
Table 8-4.	Printer Internal Components (2 of 4)- - - - -	735
Table 8-5.	Printer internal Components (3 of 4)- - - - -	737
Table 8-6.	Printer Internal Components (4 of 4)- - - - -	739
Table 8-7.	Detail of Assemblies - - - - -	741
Table 8-8.	PCB Assembly Locations - - - - -	742
Table 8-9.	Face-up Solenoid Assembly- - - - -	743
Table 8-10.	2000-sheet Input Tray Components (1 of 2) - - - - -	745
Table 8-11.	2000-sheet Input Tray Components (2 of 2) - - - - -	747
Table 8-12.	2 x 500-sheet Input Tray Internal Components- - - - -	749
Table 8-13.	7-bin Tabletop Mailbox Internal Components - - - - -	752
Table 8-14.	8-bin Mailbox Components (1 of 3) - - - - -	755
Table 8-15.	8-bin Mailbox Components (2 of 3) - - - - -	757
Table 8-16.	8-bin Mailbox Components (3 of 3) - - - - -	759
Table 8-17.	Stapler Internal Components - - - - -	761
Table 8-18.	Covers - - - - -	764
Table 8-19.	Flatbed - - - - -	765
Table 8-20.	Glass Plate and PCA Assembly - - - - -	767
Table 8-21.	Carrier Unit - - - - -	769
Table 8-22.	ADF Unit - - - - -	770

Table 8-23.	Optical Unit - - - - -	773
Table 8-24.	Document Cover Assembly - - - - -	774
Table 8-25.	Screws (1 of 4) - - - - -	775
Table 8-26.	Screws (2 of 4) - - - - -	775
Table 8-27.	Screws (3 of 4) - - - - -	776
Table 8-28.	Screws (4 of 4) - - - - -	776
Table 8-29.	Alphabetical Parts List – Printer and Paper-handling Devices - -	777
Table 8-30.	Alphabetical Parts List – Copy Module- - - - -	787
Table 8-31.	Numerical Parts List – Printer and Paper-handling Devices - - -	791
Table 8-32.	Numerical Parts List – Copy Module- - - - -	801

# List of Figures

Figure 1-1	Copy System	29
Figure 1-2	Printer - Front and Right Side View with Tray 1 Open	31
Figure 1-3	Rear and Left Side View	33
Figure 1-4	Front view of HP Digital Copier	34
Figure 1-5	Rear view of HP Digital Copier	34
Figure 1-6	Preferred Configuration	35
Figure 1-7	Digital Copier Tabletop Configuration	36
Figure 1-8	Sample Model and Serial Number Label for the printer	37
Figure 1-9	Paper Handling Devices and Accessories	38
Figure 1-10	Paper size specification	56
Figure 1-11	Paper orientation	59
Figure 1-12	Areas of the Paper that Should Not Be Perforated	60
Figure 1-13	Sample 5% Page Coverage	62
Figure 2-1	Printer Space Requirements (Top view)	81
Figure 2-2	Printer Space Requirements (Side view)	81
Figure 2-3	Printer Space Requirements (with Mailbox and Input Device)	82
Figure 2-4	Printer and Copy Module Space requirements	83
Figure 2-5	Dimensions of Paper Handling Devices	87
Figure 3-1	Control Panel Layout	92
Figure 3-2	Front Panel Layout	127
Figure 3-3	Button/LED Functions	134
Figure 3-4	Copy Module Service Mode	145
Figure 3-5	Configuration Page (varies with installed options)	154
Figure 3-6	Menu Map Page (varies with printer models and installed options)	155
Figure 4-1	Cleaning the Document Cover, Document Holder, and Flatbed Glass	162
Figure 4-2	Parts of the ADF	163
Figure 4-3	Image Area Margins	170
Figure 4-4	Tray Position Adjustment	171
Figure 4-5	Tray 4 Position Adjustment	172
Figure 4-6	Creating an Offset Target	176
Figure 5-1	Printer Functional Block Diagram	180
Figure 5-2	Low Voltage Power Distribution System	181
Figure 5-3	Low Voltage Power Supply	182
Figure 5-4	High Voltage Power Supply Contacts	184
Figure 5-5	Normal Mode vs. EconoMode	187
Figure 5-6	Image Formation Block Diagram	190
Figure 5-7	Photosensitive Drum	192
Figure 5-8	Drum Cleaning	193
Figure 5-9	Primary Charging Roller	194

Figure 5-10	Image Writing	195
Figure 5-11	Image Development	198
Figure 5-12	Image Transferring and Media Separation	199
Figure 5-13	Image Fusing	200
Figure 5-14	Printer Paper Paths	201
Figure 5-15	Printer Sensors, Solenoids, Clutches, Motors, and Fans	204
Figure 5-16	2000-sheet Input Tray Paper Path	207
Figure 5-17	2000-sheet Input Tray Sensors, Switches, Clutches, and Motors	209
Figure 5-18	2 x 500-sheet Input Tray Paper Path	212
Figure 5-19	2 x 500-sheet input Tray Sensors and Switches	213
Figure 5-20	7-bin Tabletop Mailbox Components (1 of 2)	216
Figure 5-21	7-bin Tabletop Mailbox Components (2 of 2)	217
Figure 5-22	7-bin Tabletop Mailbox Block Diagram	221
Figure 5-23	8-bin Mailbox Paper Path	222
Figure 5-24	8-bin Mailbox Sensors, Switches, Motors, and Controller PCA	224
Figure 5-25	Finisher Paper Path	228
Figure 5-26	Stapler Motors, Sensors, and Switches	229
Figure 5-27	Stapler Cycles	232
Figure 5-28	Recommended C-link Configuration (Daisy Chain)	234
Figure 5-29	General Timing Diagram	236
Figure 5-30	Copy Module System Block Diagram	238
Figure 5-31	Copy Processor and key components	240
Figure 5-32	Image path (1 of 2)	249
Figure 5-33	Locations of ADF Sensors	252
Figure 5-34	ADF Sensors functional diagram	253
Figure 6-1	Phillips vs. Posidriv Screwdrivers	257
Figure 6-2	Disk Drive	259
Figure 6-3	Control Panel (1 of 2)	269
Figure 6-4	Control Panel (2 of 2)	270
Figure 6-5	AC Access Cover	272
Figure 6-6	Back Cover	273
Figure 6-7	Front Cover (1 of 2)	274
Figure 6-8	Front Cover (2 of 2)	275
Figure 6-9	Left Lower Cover	276
Figure 6-10	Top Cover (1 of 2)	277
Figure 6-11	Top Cover (2 of 2)	278
Figure 6-12	Delivery Unit (1 of 2)	280
Figure 6-13	Delivery Unit (2 of 2)	281
Figure 6-14	Diverter Assembly	283
Figure 6-15	Diverter Door Assembly	284
Figure 6-16	Lower Right Door Assembly (1 of 3)	285
Figure 6-17	Right Lower Door Assembly (2 of 3)	286
Figure 6-18	Right Lower Door Assembly (3 of 3)	287
Figure 6-19	Fan 1, Laser/Scanner (1 of 2)	288
Figure 6-20	Fan 1, Laser/Scanner (2 of 2)	289
Figure 6-21	Fan 2, Low Voltage Power Supply	290
Figure 6-22	Fan 3, Formatter Fan	291

Figure 6-23	Fan 4, Delivery Unit - - - - -	292
Figure 6-24	Fan 5 Removal (1 of 2) - - - - -	293
Figure 6-25	Fan 5 Removal (2 of 2) - - - - -	294
Figure 6-26	Tray 1 Removal (1 of 3) - - - - -	295
Figure 6-27	Tray 1 Removal (2 of 3) - - - - -	296
Figure 6-28	Tray 1 Removal (3 of 3) - - - - -	297
Figure 6-29	Tray 1 Pickup Unit Removal (1 of 4) - - - - -	298
Figure 6-30	Tray 1 Pickup Unit Removal (2 of 4) - - - - -	299
Figure 6-31	Tray 1 Pickup Unit Removal (3 of 4) - - - - -	300
Figure 6-32	Tray 1 Pickup Unit Removal (4 of 4) - - - - -	301
Figure 6-33	Feeder Assembly (1 of 2) - - - - -	302
Figure 6-34	Feeder Assembly (2 of 2) - - - - -	303
Figure 6-35	Formatter Assembly - - - - -	305
Figure 6-36	Fusing Assembly - - - - -	306
Figure 6-37	Laser/Scanner Assembly - - - - -	308
Figure 6-38	Main Gear Assembly (1 of 3) - - - - -	310
Figure 6-39	Main Gear Assembly (2 of 3) - - - - -	311
Figure 6-40	Main Gear Assembly (3 of 3) - - - - -	312
Figure 6-41	Main Motor - - - - -	313
Figure 6-42	Paper Input Unit - - - - -	314
Figure 6-43	DC Controller PCA - - - - -	315
Figure 6-44	Output Paper Sensor PCA (1 of 4) - - - - -	316
Figure 6-45	Output Paper Sensor PCA (2 of 4) - - - - -	317
Figure 6-46	Output Paper Sensor PCA (3 of 4) - - - - -	318
Figure 6-47	Output Paper Sensor PCA (4 of 4) - - - - -	319
Figure 6-48	Paper Size PCA (1 of 3) - - - - -	320
Figure 6-49	Paper Size PCA (2 of 3) - - - - -	321
Figure 6-50	Paper Size PCA (3 of 3) - - - - -	322
Figure 6-51	High Voltage Power Supply - - - - -	323
Figure 6-52	Low Voltage Power Supply - - - - -	324
Figure 6-53	Registration Assembly (1 of 3) - - - - -	325
Figure 6-54	Registration Assembly (2 of 3) - - - - -	326
Figure 6-55	Registration Assembly (3 of 3) - - - - -	327
Figure 6-56	Tray 1 Feed Roller - - - - -	328
Figure 6-57	Tray 1 Separation Pad - - - - -	329
Figure 6-58	Tray 2 and 3, Pickup, Feed, and Separation Rollers - - - - -	330
Figure 6-59	Paper Input Unit Sensor (PS2) - - - - -	333
Figure 6-60	Registration Sensor (PS1) - - - - -	335
Figure 6-61	Face-up Solenoid Assembly, SL3 - - - - -	336
Figure 6-62	Transfer Roller Assembly - - - - -	337
Figure 6-63	2000-sheet Input Tray Orientation - - - - -	342
Figure 6-64	2000-sheet Input Tray Front Cover - - - - -	343
Figure 6-65	2000-sheet Input Tray Back Cover - - - - -	344
Figure 6-66	2000-sheet Input Tray Left Cover - - - - -	345
Figure 6-67	2000-sheet Input Tray Right Cover - - - - -	346
Figure 6-68	2000-sheet Input Tray Main Drive Assembly - - - - -	347
Figure 6-69	2000-sheet Input Tray Paper Tray - - - - -	349

Figure 6-70	2000-sheet Input Tray Main Cable Harness	351
Figure 6-71	2000-sheet Input Tray Controller PCA	352
Figure 6-72	2000-sheet Input Tray Front LED PCA	355
Figure 6-73	2000-sheet Input Tray Pickup Assembly	356
Figure 6-74	2000-sheet Input Tray Power Supply	358
Figure 6-75	2000-sheet Input Tray Rollers: Pickup, Feed, and Separation	361
Figure 6-76	2000-sheet Input Tray Paper Size and Paper Quantity Switch (1 of 2)	364
Figure 6-77	2000-sheet Input Tray Paper Size and Paper Quantity Switch Assemblies (2 of 2)	365
Figure 6-78	2000-sheet Input Tray Vertical Transfer Unit (VTU)	366
Figure 6-79	2000-sheet Input Tray Tension Springs	368
Figure 6-80	2000-sheet Input Tray Locating Pins	369
Figure 6-81	2000-sheet Input Tray Casters	370
Figure 6-82	2000-sheet Input Tray Adjustable Foot	371
Figure 6-83	Orientation of the 2 x 500-sheet Input Tray	373
Figure 6-84	Back Cover	374
Figure 6-85	Left Cover	375
Figure 6-86	Vertical Transfer Unit (VTU) (1 of 3)	376
Figure 6-87	Vertical Transfer Unit (VTU) (2 of 3)	377
Figure 6-88	Vertical Transfer Unit (VTU) (3 of 3)	378
Figure 6-89	Right Cover (1 of 3)	379
Figure 6-90	Right Cover (2 of 3)	380
Figure 6-91	Right Cover (3 of 3)	381
Figure 6-92	Front Top Cover (1 of 3)	382
Figure 6-93	Front Top Cover (2 of 3)	383
Figure 6-94	Front Top Cover (3 of 3)	384
Figure 6-95	Trays 4 and 5 (1 of 2)	385
Figure 6-96	Trays 4 and 5 (2 of 2)	386
Figure 6-97	Pickup Assembly (1 of 2)	387
Figure 6-98	Pickup Assembly (2 of 2)	388
Figure 6-99	Paper Deck Drive Assembly (1 of 2)	389
Figure 6-100	Paper Deck Drive Assembly (2 of 2)	390
Figure 6-101	Pickup, Feed, and Separation Rollers	391
Figure 6-102	2 x 500-sheet Input Tray Controller PCA	392
Figure 6-103	Tray-Size Sensing PCA (1 of 2)	393
Figure 6-104	Tray-Size Sensing PCA (2 of 2)	394
Figure 6-105	Power Supply	395
Figure 6-106	Main Cable (1 of 2)	396
Figure 6-107	Main Cable (2 of 2)	397
Figure 6-108	Storage Paper Tray	398
Figure 6-109	Front Door (Storage Area)	399
Figure 6-110	Castors	400
Figure 6-111	Foot Tip and Adjustable Foot Tip	401
Figure 6-112	Locating Pins	402
Figure 6-113	Front LED PCA	403
Figure 6-114	Orientation of the 7-bin Tabletop Mailbox	406

Figure 6-115 Front Cover (1 of 3) - - - - -	407
Figure 6-116 Front Cover (2 of 3) - - - - -	408
Figure 6-117 Front Cover (3 of 3) - - - - -	409
Figure 6-118 Back Cover (1 of 2) - - - - -	410
Figure 6-119 Back Cover (2 of 2) - - - - -	411
Figure 6-120 Top Cover (1 of 4) - - - - -	412
Figure 6-121 Top Cover (2 of 4) - - - - -	413
Figure 6-122 Top Cover (3 of 4) - - - - -	414
Figure 6-123 Top Cover (4 of 4) - - - - -	415
Figure 6-124 Mailbox Controller PCA - - - - -	416
Figure 6-125 Mailbox Power Supply - - - - -	417
Figure 6-126 Right Door Assembly (Paper Path Cover) (1 of 5)- - - - -	418
Figure 6-127 Right Door Assembly (Paper Path Cover) (2 of 5)- - - - -	419
Figure 6-128 Right Door Assembly (Paper Path Cover) (3 of 5)- - - - -	420
Figure 6-129 Right Door Assembly (Paper Path Cover) (4 of 5)- - - - -	421
Figure 6-130 Right Door Assembly (Paper Path Cover) (5 of 5)- - - - -	422
Figure 6-131 Face-down Bins (1 of 3) - - - - -	423
Figure 6-132 Face-down Bins (2 of 3) - - - - -	424
Figure 6-133 Face-down Bins (3 of 3) - - - - -	425
Figure 6-134 Empty Bin Sensor PCA (1 of 2)- - - - -	426
Figure 6-135 Empty Bin Sensor PCA (2 of 2)- - - - -	427
Figure 6-136 Full Bin and Interlock Sensor PCA (1 of 2)- - - - -	428
Figure 6-137 Full Bin and Interlock Sensor PCA (2 of 2)- - - - -	429
Figure 6-138 LED PCA - - - - -	430
Figure 6-139 Face-up Sensors PCA - - - - -	431
Figure 6-140 Reversing Mechanism Motor (1 of 2)- - - - -	432
Figure 6-141 Reversing Mechanism Motor (2 of 2)- - - - -	433
Figure 6-142 Face-up/Diverter Assembly (Flipper) (1 of 3) - - - - -	434
Figure 6-143 Face-up/Diverter Assembly (Flipper) (2 of 3) - - - - -	435
Figure 6-144 Face-up/Diverter Assembly (Flipper) (3 of 3) - - - - -	436
Figure 6-145 Short Tray 7 - - - - -	437
Figure 6-146 Solenoid Reversing Mechanism - - - - -	438
Figure 6-147 Flipper Solenoid - - - - -	439
Figure 6-148 7-bin Tabletop Mailbox Handle - - - - -	440
Figure 6-149 Latching Mechanism - - - - -	441
Figure 6-150 Cover Latch - - - - -	442
Figure 6-151 Orientation of the 8-bin Mailbox - - - - -	444
Figure 6-152 8-bin Mailbox Covers (Front and Back) - - - - -	445
Figure 6-153 8-bin Mailbox Top Cover - - - - -	447
Figure 6-154 8-bin Mailbox Power Supply - - - - -	448
Figure 6-155 8-bin Mailbox Paper Bins and Blind Cover - - - - -	449
Figure 6-156 8-bin Mailbox Flipper Assembly (1 of 3)- - - - -	450
Figure 6-157 8-bin Mailbox Flipper Assembly (2 of 3)- - - - -	451
Figure 6-158 8-bin Mailbox Flipper Assembly (3 of 3)- - - - -	452
Figure 6-159 8-bin Mailbox Delivery Head Motor - - - - -	453
Figure 6-160 8-bin Mailbox Transport Belt Motor - - - - -	454
Figure 6-161 8-bin Mailbox Input Paper Guide (1 of 2) - - - - -	456

Figure 6-162 8-bin Mailbox Input Paper Guide (2 of 2) - - - - -	457
Figure 6-163 8-bin Mailbox Metal Tape and Housing Assembly (1 of 2) - - - - -	458
Figure 6-164 8-bin Mailbox Metal Tape and Housing Assembly (2 of 2) - - - - -	459
Figure 6-165 8-bin Mailbox Controller PCA (1 of 2) - - - - -	460
Figure 6-166 8-bin Mailbox Controller PCA (2 of 2) - - - - -	461
Figure 6-167 8-bin Mailbox Anticurl Strings (1 of 2) - - - - -	462
Figure 6-168 8-bin Mailbox Anticurl Strings (2 of 2) - - - - -	463
Figure 6-169 8-bin Mailbox Delivery Head Assembly (1 of 4) - - - - -	464
Figure 6-170 8-bin Mailbox Delivery Head Assembly (2 of 4) - - - - -	465
Figure 6-171 8-bin Mailbox Delivery Head Assembly (3 of 4) - - - - -	466
Figure 6-172 8-bin Mailbox Delivery Head Assembly (4 of 4) - - - - -	467
Figure 6-173 8-bin Mailbox Interlock Switch - - - - -	469
Figure 6-174 8-bin Mailbox Diagnostic LED PCA (1 of 2) - - - - -	470
Figure 6-175 8-bin Mailbox Diagnostic LED PCA (2 of 2) - - - - -	471
Figure 6-176 8-bin Mailbox User Status LED PCA (1 of 2) - - - - -	472
Figure 6-177 8-bin Mailbox User Status LED PCA (2 of 2) - - - - -	473
Figure 6-178 8-bin Mailbox Adjustable and Fixed Casters- - - - -	474
Figure 6-179 8-bin Mailbox Attachment Assembly - - - - -	475
Figure 6-180 Mailbox with Stapler, Stapler Removal or Installation - - - - -	477
Figure 6-181 C-link Cable on Mailbox with Stapler - - - - -	478
Figure 6-182 Back Plate (1 of 2)- - - - -	479
Figure 6-183 Back Plate (2 of 2)- - - - -	480
Figure 6-184 Stapler Controller PCA (1 of 3) - - - - -	481
Figure 6-185 Stapler Controller PCA (2 of 3) - - - - -	482
Figure 6-186 Stapler Controller PCA (3 of 3) - - - - -	483
Figure 6-187 Top Cover Assembly - - - - -	484
Figure 6-188 Stapler Bed Assembly - - - - -	485
Figure 6-189 Hinges - - - - -	487
Figure 6-190 Optional Output Accessory- - - - -	493
Figure 6-191 Copy Connect EIO Board (slot 3) - - - - -	494
Figure 6-192 View with HP Digital Copier Stand (preferred configuration) - - - -	495
Figure 6-193 View with HP Digital Copier on Tabletop - - - - -	495
Figure 6-194 Orientation of the HP Digital Copier- - - - -	499
Figure 6-195 Separation Pad Assembly - - - - -	500
Figure 6-196 Pick Roller Cover - - - - -	501
Figure 6-197 Pick Rollers (1 of 2) - - - - -	502
Figure 6-198 Pick Rollers (2 of 2) - - - - -	503
Figure 6-199 Document Holding Pad - - - - -	505
Figure 6-200 Paper Chute Flip-out - - - - -	506
Figure 6-201 Output Tray - - - - -	507
Figure 6-202 FB Cover Assembly- - - - -	508
Figure 6-203 Thumb Screw for Document Cover Assembly - - - - -	509
Figure 6-204 Removing the Cover from the Posts - - - - -	510
Figure 6-205 ADF Latch Cap - - - - -	511
Figure 6-206 ADF Cover (1 of 2) - - - - -	512
Figure 6-207 ADF Cover (2 of 2) - - - - -	513
Figure 6-208 Front Panel (1 of 2) - - - - -	514

Figure 6-209 Front Panel (2 of 2) - - - - -	515
Figure 6-210 Front Panel Cable Clamp and Front Panel Frame Ground Plate -	516
Figure 6-211 Front Panel Ribbon Cable - - - - -	517
Figure 6-212 Unplugging the Ribbon Cable - - - - -	518
Figure 6-213 Panel Cover (bottom view) - - - - -	519
Figure 6-214 Front Panel Brackets (1 of 2) - - - - -	520
Figure 6-215 Front Panel Brackets (2 of 2) - - - - -	521
Figure 6-216 Upper Cover (1 of 2) - - - - -	522
Figure 6-217 Upper Cover (2 of 2) - - - - -	523
Figure 6-218 Copy Processor Board - - - - -	524
Figure 6-219 Power Supply and Main Board Tray (1 of 2) - - - - -	525
Figure 6-220 Power Supply and Main Board Tray (2 of 2) - - - - -	526
Figure 6-221 RFI Cover (inside/rear view) - - - - -	527
Figure 6-222 RFI Cover (outside/front view) - - - - -	528
Figure 6-223 Control PCA - - - - -	529
Figure 6-224 Card Cage - - - - -	530
Figure 6-225 EEPROM - - - - -	531
Figure 6-226 Fan - - - - -	532
Figure 6-227 Power Supply - - - - -	533
Figure 6-228 Back PCA - - - - -	534
Figure 6-229 Optical Unit (1 of 2) - - - - -	535
Figure 6-230 Optical Unit (2 of 2) - - - - -	536
Figure 6-231 ADF Lamp PCA (1 of 2) - - - - -	537
Figure 6-232 ADF Lamp PCA (2 of 2) - - - - -	538
Figure 6-233 ADF Lamp - - - - -	539
Figure 6-234 Sensor Unit Assembly (1 of 3) - - - - -	540
Figure 6-235 Sensor Unit Assembly (2 of 3) - - - - -	541
Figure 6-236 Sensor Unit Assembly (3 of 3) - - - - -	542
Figure 6-237 ADF Motor Unit - - - - -	543
Figure 6-238 ADF Belt - - - - -	544
Figure 6-239 LED Assembly PCA - - - - -	546
Figure 6-240 ADF Unit (shown without Optical Unit) - - - - -	547
Figure 6-241 Front Panel Frame Ground Spring - - - - -	549
Figure 6-242 Output Tray Brackets - - - - -	550
Figure 6-243 Glass Plate Assembly - - - - -	551
Figure 6-244 Idle Roller Coil Spring - - - - -	552
Figure 6-245 Home Position Sensor (1 of 2) - - - - -	553
Figure 6-246 Home Position Sensor (2 of 2) - - - - -	554
Figure 6-247 Dust Cover - - - - -	555
Figure 6-248 Lamp (1 of 2) - - - - -	556
Figure 6-249 Lamp (2 of 2) - - - - -	557
Figure 6-250 Carrier Unit (1 of 2) - - - - -	558
Figure 6-251 Carrier Unit (2 of 2) - - - - -	559
Figure 6-252 Carrier Belt - - - - -	560
Figure 6-253 Unplugging the Ribbon Cable - - - - -	561
Figure 6-254 Felt Pad - - - - -	562
Figure 6-255 Feet - - - - -	563

Figure 6-256	Frame Ground Spring	564
Figure 6-257	Front Lamp PCA	565
Figure 6-258	Junction PCA Cover	566
Figure 6-259	Junction PCA	567
Figure 6-260	Front Panel Ribbon Cable	568
Figure 6-261	Unplugging the Ribbon Cable	569
Figure 6-262	Carrier Belt and Motor (1 of 2)	570
Figure 6-263	Carrier Belt and Motor (2 of 2)	571
Figure 7-1	Troubleshooting Process	575
Figure 7-2	Print System Troubleshooting Process	577
Figure 7-3	Printer and Paper-Handling Troubleshooting Process (1 of 2)	578
Figure 7-4	Printer and Paper-Handling Troubleshooting Process (2 of 2)	579
Figure 7-5	Copy Module Troubleshooting Process (1 of 2)	580
Figure 7-6	Copy Module Troubleshooting Process (2 of 2)	581
Figure 7-7	Communications Link (C-link) Cables, Supported Daisy Chain Connections	583
Figure 7-8	Sample JetDirect Configuration Page	586
Figure 7-9	Fan Location and Airflow	596
Figure 7-10	Engine Test Button	597
Figure 7-11	Sample Event Log, page one	600
Figure 7-12	HP LaserJet 8150 Series Sample Event Log, page two	601
Figure 7-13	Error Format for Paper Handling	606
Figure 7-14	Paper Path Jam Locations	648
Figure 7-15	Paper Path Test Source and Output Selection	650
Figure 7-16	Sample Menu Map	653
Figure 7-17	Sample printer Configuration Page (1 of 2)	655
Figure 7-18	Sample Copy Module Configuration Page	656
Figure 7-19	Sample File Directory Page	657
Figure 7-20	Sample Usage Page	659
Figure 7-21	Repetitive Defect Ruler	678
Figure 7-22	High Voltage Power Supply Contacts	681
Figure 7-23	8-bin Mailbox LEDs Description	695
Figure 7-24	8-bin Mailbox Power Supply Test Mode Switch	696
Figure 7-25	Printer Sensors and Switches	704
Figure 7-26	Printer Motor, Clutches, and Solenoids	705
Figure 7-27	DC Controller Inputs and Outputs (1 of 5)	706
Figure 7-28	DC Controller Inputs and Outputs (2 of 5)	707
Figure 7-29	DC Controller Inputs and Outputs (3 of 5)	708
Figure 7-30	DC Controller Inputs and Outputs (4 of 5)	709
Figure 7-31	DC Controller Inputs and Outputs (5 of 5)	710
Figure 7-32	Mailbox with Stapler Wiring Diagram	711
Figure 7-33	2000-sheet Input Tray Controller PCA Inputs	712
Figure 7-34	2000-sheet Input Tray Controller PCA Outputs	713
Figure 7-35	2000-sheet Input Tray Main Wiring Diagram	714
Figure 7-36	8-bin Mailbox Main Wiring Diagram	715
Figure 7-37	Copy Processor LEDs	730
Figure 7-38	Locations of ADF Sensors	733

Figure 8-1	HP LaserJet 8150 MFP Paper-Handling Components- - - - -	742
Figure 8-2	Printer Covers and Doors- - - - -	744
Figure 8-3	Printer Internal Components (1 of 4) - - - - -	746
Figure 8-4	Printer Internal Components (2 of 4) - - - - -	748
Figure 8-5	Printer Internal Components (3 of 4) - - - - -	750
Figure 8-6	Printer Internal Components (4 of 4) - - - - -	752
Figure 8-7	Detail of Assemblies - - - - -	754
Figure 8-8	PCB Assembly Location Diagram - - - - -	756
Figure 8-9	Face-up Solenoid Assembly - - - - -	757
Figure 8-10	2000-sheet Input Tray Components (1 of 2) - - - - -	758
Figure 8-11	2000-sheet Input Tray Components (2 of 2) - - - - -	760
Figure 8-12	2 x 500-sheet Input Tray Internal Components - - - - -	762
Figure 8-13	7-bin Tabletop Mailbox Internal Components - - - - -	765
Figure 8-14	8-bin Mailbox Components (1 of 3) - - - - -	768
Figure 8-15	8-bin Mailbox Components (2 of 3) - - - - -	770
Figure 8-16	8-bin Mailbox Components (3 of 3) - - - - -	772
Figure 8-17	Stapler Internal Components - - - - -	774
Figure 8-18	Assembly Location Diagram - - - - -	776
Figure 8-19	Covers - - - - -	777
Figure 8-20	Flatbed- - - - -	779
Figure 8-21	Glass Plate and PCA Assembly - - - - -	781
Figure 8-22	Carrier Unit - - - - -	783
Figure 8-23	ADF Unit - - - - -	784
Figure 8-24	Optical Unit- - - - -	787
Figure 8-25	Document Cover Assembly - - - - -	788
Figure 8-26	Screws (1 of 4) - - - - -	789
Figure 8-27	Screws (2 of 4) - - - - -	789
Figure 8-28	Screws (3 of 4) - - - - -	790
Figure 8-29	Screws (4 of 4) - - - - -	790

Product: 2000 HP LaserJet 8150 and 8100 Series Print Systems and Paper Handling Devices  
Full Download: <https://www.arepairmanual.com/downloads/2000-hp-laserjet-8150-and-8100-series-print-systems-and-paper-handling-devices-service-repair-workshop-manual/>

Sample of manual. Download All 844 pages at:  
<https://www.arepairmanual.com/downloads/2000-hp-laserjet-8150-and-8100-series-print-systems-and-paper-handling-devices-service-repair-workshop-manual/>