


Product: 1998-2000 Terex 3360B Off-Highway Truck Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/1998-2000-terex-3360-b-off-highway-truck-workshop-parts-manual/>

[CLICK HERE FOR
STANDARD
TABLE OF CONTENTS](#)

[CLICK HERE FOR
OPTIONAL
TABLE OF CONTENTS](#)

TEREX 

Parts Book

[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

**Part Number
15272025**

3360B Off-Highway Truck (Cummins QSK-19C Low Emissions Powered)

From Serial No. T7501001

Sample of manual. Download All 328 pages at:

<https://www.arepairmanual.com/downloads/1998-2000-terex-3360b-off-highway-truck-workshop-parts-manual/>

1 July 98
Revised Mar 00

PUBLISHED BY:
TECHNICAL PUBLICATIONS DEPARTMENT

TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND



Product: 1998-2000 Terex 3360B Off-Highway Truck Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/1998-2000-terex-3360b-off-highway-truck-workshop-parts-manual/>

THIS PAGE IS INTENTIONALLY LEFT BLANK

Sample of manual. Download All 328 pages at:
<https://www.arepairmanual.com/downloads/1998-2000-terex-3360b-off-highway-truck-workshop-parts-manual/>



WARRANTY ON PARTS AND ATTACHMENTS

Terex Equipment Limited warrants that for a period of six months after sale of new Terex replacement parts or attachments by an authorised Terex dealer it will repair, or at its option, replace any defective or malfunctioning part or attachment. This warranty covers only malfunctions resulting from defects in material or workmanship.

This warranty does not cover malfunctions resulting from negligence, alteration, accident or overloading; use for a purpose for which the part or attachment is not designed or approved by Terex; loss of time, inconvenience, loss of use of the vehicle or other consequential damages; or labour for removal or reinstallation of defective or malfunctioning parts or attachments.

Repairs or replacements qualifying under this warranty will be performed by any authorised Terex dealer within a reasonable time following delivery of the malfunctioning part or attachment to the dealer's place of business.

Defective or malfunctioning parts or attachments must be delivered to an authorised Terex dealer's place of business during regular business hours for warranty repairs or replacements. The dealer must be furnished with the purchaser's copy of the sales slip or repair order to validate date of purchase.

* * * * *

SOLE WARRANTY

This is the only express warranty applicable to new Terex parts and attachments sold by Terex dealers and Terex neither assumes nor authorises anyone to assume for it any other obligation or liability in connection with such parts or attachments.

THIS PAGE IS INTENTIONALLY LEFT BLANK



INSTRUCTIONS FOR USE OF TEREX PARTS BOOK

This Parts Book is divided into Major Sections which cover components corresponding to specific areas of the machine.

Printed at the top left hand corner of each Parts Page is an Index Code which includes three numbers - the first of these relates to a Major Section, the second indicates a Sub-section within a Major Section and the last the model PLI number. Certain Major Sections may not apply to the particular model covered in this Parts Book and, consequently, will be omitted.

An illustrated Index page shows all the Major Component Section numbers included in the book. For example -

SECTION 100 - CHASSIS

SECTION 140 - FRONT AXLE GROUP

SECTION 230 - BODY HOIST SYSTEM etc.

Major Component Sections are listed in the 'Table Of Contents' pages together with Sub-section headings. For example to locate the serviceable items of a Steering Cylinder -

1. The Table of Contents shows the steering components to be in Major Section 220.
2. The steering cylinder is listed in Major Section 220, Sub-section 0120
3. Select the Parts Page Code that applies to the unit Serial number for which parts are needed and locate the Page with reference number.
EXAMPLE - 220-0120.

SERIAL NUMBERS - Each Parts Book covers a particular range of unit Serial Numbers.

It is important that unit Serial Numbers are quoted on all orders for Parts.

PARTS LISTS - Parts Forms usually consist of detailed parts information listed on one page together with a parts illustration on the opposite page. The parts list is printed in the order of the reference numbers shown on the parts illustration. The first column lists Note Letters; the second lists the reference numbers; the third shows quantity required and the fourth gives the parts descriptions. Parts which are part of an assembly have their descriptions indented beneath the assembly description.

ILLUSTRATIONS - These show typical assemblies and individual piece parts. They are intended for general reference only and may not always show exact details of parts. Parts are identified on each illustration with an item number. Note the item number of the part required and locate it in the parts list. The part number opposite the item number is the part to order.

INDENTATIONS - Parts which are indented under another part are Sub-groups of a Major Assembly or Sub-assembly. Parts which are not indented are major assemblies or individual component parts which do not belong to a major assembly.


EXAMPLE - 1 9052564 Pump Assy.
 2 9058512 . Shaft
 3 9024169 . Ring
 4 9058132 . Control Assy.
 5 9058135 . . Spring
 6 9072162 Gasket

- If you order Item 1, you will receive Items 1 - 5.
- If you order Item 4, you will receive Items 4 and 5.
- If you order Item 6, you will receive only Item 6.

NOTES - Whenever there is an alphabetical symbol to the left of the item number, refer to the corresponding note at the bottom of the form for information regarding ordering or application of the particular part number(s) noted.

ABBREVIATIONS - The abbreviations in this book have the following meanings -

| | | | | | |
|----------------|----------------------------|-----------|-----------------|-------------|---------------------|
| Amps | Amperes | Hsg | Housing | N.I | Not Illustrated |
| As R | As Required | I.D | Inside Diameter | N.L.A | No Longer Available |
| Assy | Assembly | L.H | Left Hand | N.S.S | Not Sold Separately |
| Brkt | Bracket | L.W | Lockwasher | O.D | Outside Diameter |
| Cad-Pltd | Cadium Plated | Lg | Long | Pr | Pair |
| Comm | Commencement of production | Lkg | Linkage | P.T.O | Power-Take-Off |
| E.S.N | Elastic Stop Nut | Mtg | Mounting | R.H | Right Hand |
| Ftgs | Fittings | N.C | Note Code | Std | Standard |



Off-Highway Truck



STANDARD SECTIONS



CHASSIS

100



ENGINE

110



TRANSMISSION

120



DRIVELINE

130



FRONT AXLE

140



REAR AXLE

160



BRAKE PARTS

165



SUSPENSION SYSTEM

180



ELECTRICAL SYSTEM

190



FUEL SYSTEM

200



COOLING SYSTEM

210



STEERING SYSTEM

220



BODY HOIST SYSTEM

230



BRAKING SYSTEM

250



CAB

260



BODY

270



MISCELLANEOUS

300



TABLE OF CONTENTS FOR MODEL

3360B QSK19C

FROM SERIAL NO T7501001

02/03/00

SECT - PAGE - PLI DESCRIPTION

SECTION 100 CHASSIS

100-0010-7501 CHASSIS
 100-0040-7501 HOOD AND MOUNTING
 100-0070-7501 FENDERS AND MOUNTING R1/ 11-98
 100-0070-7501 FENDERS AND MOUNTING (FROM T7501037)
 100-0090-7501 LADDERS AND HANDRAILS R1/ 11-98
 100-0100-7501 RADIATOR GUARD AND MOUNTING
 100-0140-7501 MUDGUARDS

SECTION 110 ENGINE

110-0030-7501 ENGINE AND MOUNTING R1/ 11-98
 110-0030-7501 ENGINE AND MOUNTING R1 02/00
 110-0050-7501 AIR CLEANER
 110-0060-7501 AIR CLEANER PIPES AND HOSES
 110-0070-7501 EXHAUST AND MOUNTING R1/ 11-98
 110-0070-7501 EXHAUST AND MOUNTING (FROM T7501044)
 110-0130-7501 POWER TAKEOFF - ENG R1/ 11-98

SECTION 120 TRANSMISSION

120-0010-7501 TRANSMISSION AND MOUNTING R1/ 11-98
 120-0010-7501 TRANSMISSION AND MOUNTING (FROM T7501050)
 120-0020-7501 TRANSMISSION BREAKDOWN R1/ 11-98
 120-0020-7501 TRANSMISSION BREAKDOWN (FROM T7501031)
 120-0050-7501 CONTROL VALVE
 120-0070-7501 SHIFT CONTROL R2 02/00
 120-0090-7501 POWER TAKEOFF - TRANS
 120-0100-7501 FILTER
 120-0110-7501 OIL LINES-TRANSMISSION
 120-0200-7501 FRONT COVER & CONVERTER GROUP
 120-0210-7501 CONVERTER HOUSING GROUP
 120-0220-7501 OIL PUMP
 120-0230-7501 FILTER ADAPT/REGULATOR VALVES
 120-0240-7501 LOCKUP VALVE
 120-0250-7501 ATEC LOCKUP DROP OUT
 120-0260-7501 RETARDER GROUP
 120-0280-7501 SPLITTER GEARING AND CLUTCHES
 120-0290-7501 MAIN HOUSING GROUP
 120-0300-7501 HIGH RANGE GEARING & CLUTCHES
 120-0310-7501 INTER RANGE GEARING & CLUTCHES
 120-0320-7501 LOW RANGE GEARING & CLUTCHES
 120-0330-7501 REV RANGE GEARING & CLUTCHES

SECT - PAGE - PLI DESCRIPTION

SECTION 120 TRANSMISSION

120-0340-7501 REAR COVER GROUP
 120-0360-7501 THROTTLE SENSOR AND MOUNTING R1/ 11-98

SECTION 130 DRIVELINE

130-0010-7501 FRONT DRIVELINE R1/ 11-98
 130-0010-7501 FRONT DRIVELINE (FROM T7501031)
 130-0020-7501 REAR DRIVELINE R1/ 11-98
 130-0020-7501 REAR DRIVELINE (FROM T7501031)

SECTION 140 FRONT AXLE

140-0040-7501 WHEEL, RIM AND TYRE-FRONT

SECTION 160 REAR AXLE

160-0020-7501 DIFFERENTIAL-REAR R1/ 11-98
 160-0020-7501 DIFFERENTIAL-REAR (FROM T7501031)
 160-0030-7501 AXLE GROUP-REAR
 160-0040-7501 PLANETARY GEARING-REAR R1/ 11-98
 160-0050-7501 WHEEL, RIM AND TYRE-REAR

SECTION 165 BRAKE PARTS

165-0020-7501 BRAKE PARTS-FRONT WHEEL-RIGIDS
 165-0030-7501 BRAKE PARTS-REAR WHEEL-RIGIDS R1/ 11-98
 165-0030-7501 BRAKE PARTS-REAR WHEEL-RIGIDS (FROM T7501037)

SECTION 180 SUSPENSION SYSTEM

180-0030-7501 FRONT RIDE CYLINDER
 180-0050-7501 REAR RIDE CYLINDER

SECTION 190 ELECTRICAL SYSTEM

190-0010-7501 ELECTRICAL TERMINALS
 190-0011-7501 ELECTRICAL CONNECTORS
 190-0030-7501 CABLES/HARNESSES-CAB
 190-0040-7501 CABLES/HARNESSES-CHASS/ENG R1/ 11-98
 190-0040-7501 CABLES/HARNESSES-CHASS/ENG (FROM T7501051)
 190-0070-7501 BATTERY AND CABLES
 190-0080-7501 BATTERY MOUNTING
 190-0100-7501 ELECTRICAL LIGHTING SYSTEM
 190-0210-7501 REVERSE ALARM
 190-0270-7501 SWITCHES AND SENSORS
 190-0310-7501 ELECTRICAL HORN R1/ 11-98
 190-0310-7501 ELECTRICAL HORN (FROM T7501051)

TABLE OF CONTENTS FOR MODEL

3360B QSK19C

FROM SERIAL NO T7501001

02/03/00

SECT - PAGE - PLI DESCRIPTION

SECTION 200 FUEL SYSTEM

200-0010-7501 FUEL TANK AND MOUNTING
 200-0040-7501 FUEL LINES 01-99
 200-0050-7501 ACCELERATOR LINKAGE

SECTION 210 COOLING SYSTEM

210-0010-7501 RADIATOR ASSEMBLY
 210-0020-7501 RADIATOR MOUNTING
 210-0030-7501 RADIATOR PIPING
 210-0040-7501 RADIATOR HEADER TANK AND HOSES R2 03/00
 210-0050-7501 OIL COOLER-DISC BRAKES
 210-0051-7501 OIL COOLER PIPING-DISC BRAKES R1/ 11-98
 210-0060-7501 OIL COOLER AND PIPING-TRANS

SECTION 220 STEERING SYSTEM

220-0010-7501 STEERING LINES
 220-0015-7501 STEERING LINES FILTRATION R1 02/00
 220-0040-7501 TANK AND MOUNTING-STEERING
 220-0050-7501 PUMP-STEERING
 220-0060-7501 PUMP AND ACCUMULATOR MOUNTING
 220-0080-7501 ACCUMULATOR-STEERING
 220-0090-7501 STEERING VALVE
 220-0110-7501 DOUBLE RELIEF VALVE
 220-0120-7501 STEERING CYLINDER
 220-0130-7501 RELIEF VALVE-STEERING
 220-0150-7501 FILTER-STEERING 02/00
 220-0190-7501 STEERING LINKAGE
 220-0230-7501 STEERING COLUMN MOUNTING

SECTION 230 BODY HOIST SYSTEM

230-0020-7501 LINES AND FITTINGS-BODY HOIST R1/ 11-98
 230-0021-7501 SERVO CONTROL LINES-BODY
 230-0040-7501 TANK AND MOUNTING-BODY HOIST
 230-0041-7501 BREATHER LINE-HYDRAULIC TANKS
 230-0050-7501 PUMP-BODY HOIST
 230-0060-7501 CONTROL VALVE-BODY HOIST R1/ 11-98
 230-0070-7501 CONTROL VALVE MOUNTING
 230-0081-7501 JOYSTICK-BODY CONTROL R1/ 11-98
 230-0081-7501 JOYSTICK-BODY CONTROL (FROM T7501031)
 230-0090-7501 KICK-OVER VALVE
 230-0100-7501 KICK-OVER VALVE MOUNTING R1/ 11-98
 230-0100-7501 KICK-OVER VALVE MOUNTING (FROM T7501048)

SECT - PAGE - PLI DESCRIPTION

SECTION 230 BODY HOIST SYSTEM

230-0120-7501 RELIEF VALVE
 230-0121-7501 PILOT SUPPLY VALVE
 230-0130-7501 HOIST CYLINDERS R1 03/00

SECTION 250 BRAKING SYSTEM

250-0020-7501 BRAKE LINES-HYDRAULIC
 250-0050-7501 BRAKE MANIFOLD/PAS VALVE
 250-0060-7501 BRAKE ACCUMULATOR
 250-0070-7501 TREADLE VALVE
 250-0090-7501 DIRECTIONAL CONTROL VALVE
 250-0100-7501 MONOBLOCK BRAKE VALVE
 250-0130-7501 RETARDER CONTROL VALVE-BRAKES R1/ 11-98
 250-0240-7501 FILTER ASSEMBLY-DISC BRAKE

SECTION 260 CAB

260-0010-7501 CAB ASSEMBLY R1 02/00
 260-0015-7501 CAB MOUNTING R1/ 11-98
 260-0030-7501 CAB DOOR-LEFT HAND R1/ 11-98
 260-0040-7501 CAB DOOR-RIGHT HAND
 260-0080-7501 SWITCHES AND INSTRUMENTS
 260-0090-7501 SEAT-DRIVER
 260-0110-7501 SEAT-PASSENGER R1/ 11-98
 260-0120-7501 HEATER
 260-0140-7501 HEATER LINES AND WIRING
 260-0190-7501 WINDSCREEN WASHER

SECTION 270 BODY

270-0010-7501 BODY ASSEMBLY R1/ 11-98
 270-0010-7501 BODY ASSEMBLY (FROM T7501031)
 270-0080-7501 ROCK EJECTORS R1/ 11-98
 270-0080-7501 ROCK EJECTORS (FROM T7501048)

SECTION 300 MISCELLANEOUS

300-0040-7501 MULTI CLAMPS AND HARDWARE
 300-0060-7501 TEREX PROMOTIONAL ITEMS


THIS PAGE IS INTENTIONALLY LEFT BLANK

THIS PAGE IS INTENTIONALLY LEFT BLANK

100-0010-7501 CHASSIS
FROM SERIAL NO. T7501001

DRAWING NO. P9474

P9474




100-0010-7501 CHASSIS
FROM SERIAL NO. T7501001

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|-----|-----|-----|----------|------------------------|-----------------|---------------|
| 001 | 001 | | 15258827 | FRAME ASSEMBLY-COMPL | | |
| 002 | 002 | | 09015394 | .BUSHING | | |
| 003 | 001 | | 15232910 | GUARD ASSEMBLY | | |
| 004 | 001 | | 15258186 | CHANNEL ASSEMBLY | | |
| 005 | 003 | | 00271612 | BOLT | | |
| 006 | 007 | | 00220081 | NUT | | |
| 007 | 007 | | 00103332 | LOCKWASHER | | |
| 008 | 007 | | 00106268 | WASHER | | |
| 009 | 004 | | 00271619 | BOLT | | |
| 010 | 001 | | 15300145 | TRANSMISSION GUARD ASS | | |
| 011 | 008 | | 00271620 | BOLT | | |
| 012 | 008 | | 09176228 | WASHER-HARDENED | | |
| 013 | 008 | | 09419493 | LOCKNUT | | |
| 014 | 008 | | 15247567 | DISC-SPRING | | |
| 015 | 004 | | 09011226 | WASHER | | |

100-0040-7501 HOOD AND MOUNTING
FROM SERIAL NO. T7501001

DRAWING NO. P9481

P9481




100-0040-7501 HOOD AND MOUNTING
FROM SERIAL NO. T7501001

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|-----|-----|-----|----------|------------------|-----------------|---------------|
| 001 | 001 | | 15300329 | HOOD ASSEMBLY | | |
| 002 | 002 | | 15252142 | PLATE | | |
| 003 | 023 | | 00179885 | BOLT | | |
| 004 | 035 | | 09267949 | WASHER-HARDENED | | |
| 005 | 012 | | 00120378 | NUT | | |
| 006 | 001 | | 15300340 | BAFFLE ASSEMBLY | | |
| 007 | 001 | | 15257809 | BAFFLE ASSY-HOOD | | |
| 008 | ASR | | 09368561 | BEADING | | |

100-0070-7501 FENDERS AND MOUNTING
FROM SERIAL NO. T7501001 TO T7501036

DRAWING NO. P9475



**100-0070-7501 FENDERS AND MOUNTING
FROM SERIAL NO. T7501001 TO T7501036**

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|-----|-----|-----|----------|-----------------------|-----------------|---------------|
| 001 | 001 | | 15300480 | LH FENDER ASSEMBLY | | |
| 002 | 001 | | 15251926 | PLATFORM ASSY-LH | | |
| 003 | 001 | | 15300482 | RH FENDER ASSEMBLY | | |
| 004 | 001 | | 15300457 | PLATFORM ASS Y R.H.S. | | |
| 005 | 001 | | 15301205 | CAB REAR CROSSMEMBER | | |
| 006 | 001 | | 15247991 | SUPPORT-LH | | |
| 007 | 001 | | 15256827 | SUPPORT-RH | | |
| 008 | 003 | | 09262364 | BOLT | | |
| 009 | ASR | | 09113457 | LOCKWIRE | | |
| 010 | 022 | | 09270000 | WASHER-HARDENED | | |
| 011 | 004 | | 09009275 | BOLT | | |
| 012 | 004 | | 09008198 | WASHER | | |
| 013 | 001 | | 15257874 | COVER-ENGINE ACCESS | | |
| 014 | 006 | | 00271612 | BOLT | | |
| 015 | 004 | | 09355771 | NUT | | |
| 016 | 008 | | 09250715 | WASHER-HARDENED | | |
| 017 | 010 | | 00179887 | BOLT | | |
| 018 | 018 | | 00274209 | LOCKNUT | | |
| 019 | 032 | | 09267949 | WASHER-HARDENED | | |
| 020 | 002 | | 09077400 | MIRROR | | |
| 021 | 001 | | 15254899 | HANDRAIL ASSY-LH | | |
| 022 | 028 | | 00179885 | BOLT | | |
| 023 | 001 | | 15246087 | MIRROR-WIDE ANGLE | | |
| 024 | 004 | | 09355771 | NUT | | |
| 025 | 004 | | 00106268 | WASHER | | |
| 026 | 002 | | 00271612 | BOLT | | |
| 027 | 002 | | 00271614 | BOLT | | |
| 028 | 005 | | 00179889 | BOLT | | |
| 029 | 001 | | 15254780 | GUARD-MUD LH | | |
| 030 | 001 | | 15248043 | GUARD-MUD RH | | |
| 031 | 001 | | 00190270 | BOLT | | |
| 032 | 005 | | 00179880 | BOLT | | |
| 033 | 001 | | 15301189 | FENDER EXTENSION. | | |
| 034 | 001 | | 15254903 | HANDRAIL ASSY-RH | | |
| 035 | 001 | | 09077595 | .BAR MIRROR MTG | | |
| 036 | 002 | | 00179820 | .BOLT | | |
| 037 | 002 | | 00103320 | .LOCKWASHER | | |
| 038 | 002 | | 00103340 | .WASHER | | |



100-0070-7501 FENDERS AND MOUNTING
FROM SERIAL NO. T7501037

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO | NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|-----|-----|-----|----------|-----------------------|-----------------|---------------|-----|-----|-----|----------|---------------|-----------------|---------------|
| 001 | 001 | | 15300480 | LH FENDER ASSEMBLY | | | 041 | 004 | | 00179885 | BOLT | | |
| 002 | 001 | | 15251926 | PLATFORM ASSY-LH | | | 042 | 004 | | 09270000 | WASHER | | |
| 003 | 001 | | 15300482 | RH FENDER ASSEMBLY | | | 043 | 004 | | 00274209 | LOCKNUT | | |
| 004 | 001 | | 15300457 | PLATFORM ASS Y R.H.S. | | | 044 | 002 | | 06350625 | BOLT | | |
| 005 | 001 | | 15301205 | CAB REAR CROSSMEMBER | | | 045 | 004 | | 07150620 | WASHER | | |
| 006 | 001 | | 15247991 | SUPPORT-LH | | | 046 | 002 | | 06470601 | LOCKNUT | | |
| 007 | 001 | | 15256827 | SUPPORT-RH | | | 047 | 001 | | 15302637 | KICK STRIP LH | | |
| 008 | 003 | | 09262364 | BOLT | | | 048 | 001 | | 15302638 | KICK STRIP RH | | |
| 009 | ASR | | 09113457 | LOCKWIRE | | | 049 | 007 | | 00179885 | BOLT | | |
| 010 | 022 | | 09270000 | WASHER-HARDENED | | | 050 | 014 | | 09270000 | WASHER | | |
| 011 | 004 | | 09009275 | BOLT | | | 051 | 007 | | 00120378 | NUT | | |
| 012 | 004 | | 09008198 | WASHER | | | | | | | | | |
| 013 | 001 | | 15257874 | COVER-ENGINE ACCESS | | | | | | | | | |
| 014 | 006 | | 00271612 | BOLT | | | | | | | | | |
| 015 | 004 | | 09355771 | NUT | | | | | | | | | |
| 016 | 008 | | 09250715 | WASHER-HARDENED | | | | | | | | | |
| 017 | 010 | | 00179887 | BOLT | | | | | | | | | |
| 018 | 018 | | 00274209 | LOCKNUT | | | | | | | | | |
| 019 | 032 | | 09267949 | WASHER-HARDENED | | | | | | | | | |
| 020 | 002 | | 09077400 | MIRROR | | | | | | | | | |
| 021 | 001 | | 15302681 | HANDRAIL ASSY-LH | | | | | | | | | |
| 022 | 028 | | 00179885 | BOLT | | | | | | | | | |
| 023 | 001 | | 15246087 | MIRROR-WIDE ANGLE | | | | | | | | | |
| 024 | 004 | | 09355771 | NUT | | | | | | | | | |
| 025 | 004 | | 00106268 | WASHER | | | | | | | | | |
| 026 | 002 | | 00271612 | BOLT | | | | | | | | | |
| 027 | 002 | | 00271614 | BOLT | | | | | | | | | |
| 028 | 005 | | 00179889 | BOLT | | | | | | | | | |
| 029 | 001 | | 15254780 | GUARD-MUD LH | | | | | | | | | |
| 030 | 001 | | 15248043 | GUARD-MUD RH | | | | | | | | | |
| 031 | 001 | | 00190270 | BOLT | | | | | | | | | |
| 032 | 005 | | 00179880 | BOLT | | | | | | | | | |
| 033 | 001 | | 15301189 | FENDER EXTENSION. | | | | | | | | | |
| 034 | 001 | | 15302682 | HANDRAIL ASSY-RH | | | | | | | | | |
| 035 | 001 | | 09077595 | .BAR MIRROR MTG | | | | | | | | | |
| 036 | 002 | | 00179820 | .BOLT | | | | | | | | | |
| 037 | 002 | | 00103320 | .LOCKWASHER | | | | | | | | | |
| 038 | 002 | | 00103340 | .WASHER | | | | | | | | | |
| 039 | 001 | | 15302574 | PLATE BENT RH | | | | | | | | | |
| 040 | 001 | | 15302618 | PLATE BENT LH | | | | | | | | | |

100-0090-7501 LADDERS AND HANDRAILS
FROM SERIAL NO. T7501001

DRAWING NO. P9473

P9473




100-0090-7501 LADDERS AND HANDRAILS
 FROM SERIAL NO. T7501001

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|------------|------------|-----|-----------------|------------------|-----------------|---------------|
| 001 | 001 | | 15300256 | LH STEP ASSEMBLY | | |
| 002 | 001 | | 15300257 | RH STEP ASSEMBLY | | |
| 003 | 002 | | 15302981 | PLATE | | |
| 004 | 002 | | 15302982 | U-BOLT | | |
| 005 | 002 | | 15255698 | STEP ASSY | | |
| 006 | 002 | | 00179840 | BOLT | | |
| 007 | 008 | | 00106265 | WASHER | | |
| 008 | 004 | | 00179893 | BOLT | | |
| 009 | 004 | | 00274209 | LOCKNUT | | |
| 010 | 008 | | 00102637 | NUT | | |
| 011 | 008 | | 00179885 | BOLT | | |
| 012 | 016 | | 09267949 | WASHER-HARDENED | | |
| 013 | 004 | | 09417713 | NUT | | |
| 014 | 008 | | 09060202 | WASHER-HARDENED | | |

100-0100-7501 RADIATOR GUARD AND MOUNTING
FROM SERIAL NO. T7501001

DRAWING NO. P9480

P9480




100-0100-7501 RADIATOR GUARD AND MOUNTING
 FROM SERIAL NO. T7501001



| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|-----|-----|-----|----------|------------------------|-----------------|---------------|
| 001 | 001 | | 15301268 | RADIATOR GUARD ASSEMBL | | |
| 002 | 002 | | 15258135 | .COVER PLATE. | | |
| 003 | 004 | | 00106263 | .WASHER | | |
| 004 | 004 | | 00179839 | .BOLT | | |
| 005 | 004 | | 00179889 | BOLT | | |
| 006 | 012 | | 00120378 | NUT | | |
| 007 | 008 | | 00179885 | BOLT | | |
| 008 | 001 | | 15252767 | GRILLE | | |
| 009 | 008 | | 00179887 | BOLT | | |
| 010 | 001 | | 15252077 | BRACKET | | |
| 011 | 016 | | 00179881 | BOLT | | |
| 012 | 032 | | 09270000 | WASHER-HARDENED | | |
| 013 | 001 | | 15300546 | PLATE - BENT | | |

100-0140-7501 MUDGUARDS
FROM SERIAL NO. T7501001


DRAWING NO. P9502





R.H. REAR



R.H. FRONT



L.H. FRONT



L.H. REAR


100-0140-7501 MUDGUARDS
 FROM SERIAL NO. T7501001

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|-----|-----|-----|----------|----------------|-----------------|---------------|
| 001 | 001 | | 15249109 | MUDFLAP | | |
| 002 | 001 | | 15249123 | ANGLE-MOUNTING | | |
| 003 | 001 | | 15255372 | ANGLE-MOUNTING | | |
| 004 | 036 | | 00179885 | BOLT | | |
| 005 | 042 | | 00103329 | LOCKWASHER | | |
| 006 | 036 | | 00120378 | NUT | | |
| 007 | 001 | | 15255462 | MUD FLAP | | |
| 008 | 001 | | 15233492 | PLATE-MOUNTING | | |
| 009 | 001 | | 15255463 | PLATE-CLAMPING | | |
| 010 | 001 | | 15300760 | MUDFLAP | | |
| 011 | 001 | | 15300761 | ANGLE | | |
| 012 | 001 | | 15300756 | CLAMP PLATE | | |
| 013 | 002 | | 15300762 | MUDFLAP | | |
| 014 | 002 | | 15249115 | PLATE-CLAMPING | | |
| 015 | 002 | | 15300750 | MUDFLAP | | |
| 016 | 002 | | 15300753 | PLATE | | |
| 017 | 001 | | 15300755 | BRACKET | | |
| 018 | 006 | | 00179883 | BOLT | | |
| 019 | 001 | | 15300754 | CLAMP PLATE | | |
| 020 | 001 | | 15300757 | MUDFLAP | | |
| 021 | 001 | | 15300823 | CLAMP PLATE | | |
| 022 | 001 | | 15300824 | CLAMP PLATE | | |

110-0030-7501 ENGINE AND MOUNTING
FROM SERIAL NO. T7501001 TO T7501036

DRAWING NO. P8941

P8941



**110-0030-7501 ENGINE AND MOUNTING
FROM SERIAL NO. T7501001 TO T7501036**

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|----|------------|------------|-----------------|------------------------|-----------------|---------------|
| | 001 | 001 | 15255425 | ENGINE QSK19-C650 | | |
| | 002 | 004 | 00274098 | LOCKNUT | | |
| | 003 | 002 | 09210208 | BOLT | | |
| | 004 | 001 | 15258300 | ALTERNATOR GUARD ASSY. | | |
| | 005 | 002 | 15302001 | BRACKET ASSY | | |
| | 006 | 001 | 15256627 | MOUNTING-ENG FRONT | | |
| | 007 | 008 | 00271558 | BOLT | | |
| | 008 | 008 | 00103331 | LOCKWASHER | | |
| | 009 | 002 | 15258329 | PLATE-SUPPORT | | |
| | 010 | 002 | 15256879 | BOLT | | |
| | 011 | 008 | 15235607 | WASHER-SNUBBING | | |
| | 012 | 004 | 15235693 | MOUNT-ENG ISOLATION | | |
| | 013 | 002 | 00271621 | BOLT | | |
| | 014 | 002 | 09355771 | NUT | | |
| | 015 | 002 | 15258302 | PLATE-SUPPORT | | |
| | 016 | 001 | 15228210 | COUPLING-DRIVE | | |
| | 017 | 012 | 09060202 | WASHER-HARDENED | | |
| | 018 | 012 | 09423067 | BOLT | | |
| | 019 | 001 | 15252692 | FLANGE-COUPLING | | |
| | 020 | 008 | 09409907 | BOLT | | |
| | 021 | 003 | 09379664 | CLAMP | | |
| | 022 | 006 | 00179895 | BOLT | | |
| | 023 | 006 | 00103329 | LOCKWASHER | | |
| | 024 | 002 | 09270005 | WASHER-HARDENED | | |
| | 025 | 001 | 00179851 | BOLT | | |
| | 026 | 007 | 01967341 | WASHER | | |
| | 027 | 002 | 09268885 | LOCK | | |
| | 028 | 002 | 09268892 | KEY | | |
| | 029 | 006 | 00179838 | BOLT | | |
| | 030 | 004 | 09174339 | CLIP-RUBBERIZED | | |
| | 031 | 003 | 09181284 | CLIP-RUBBERIZED | | |
| | 032 | 001 | 09004271 | BRACKET | | |
| | 033 | 001 | 09072485 | KIT-SECURITY ENG OIL | | |
| | 034 | 001 | 09255477 | KIT-SECURITY D/STICK | | |
| | 035 | 002 | 00179795 | BOLT | | |
| | 036 | 002 | 15266844 | FILTER-LUBE OIL | | |
| | 037 | 002 | 15271319 | FILTER-FUEL | | |
| A | 038 | 001 | 15266845 | FILTER WF-15DCA4 | | |
| A | 038 | 001 | 15267515 | FILTER WF-23DCA4 | | |
| A | 038 | 001 | 15267311 | FILTER WF-4DCA4 | | |

**110-0030-7501 ENGINE AND MOUNTING
FROM SERIAL NO. T7501001 TO T7501036**

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|----|-----|-----|----------|-----------------|-----------------|---------------|
| A | 038 | 001 | 15268362 | FILTER WF-8DCA4 | | |
| | 039 | ASR | 07551826 | HOSE-BULK | | |
| | 040 | ASR | 09134207 | HOSE | | |
| | 041 | 002 | 09223731 | CLAMP | | |
| | 042 | 002 | 00103319 | LOCKWASHER | | |
| | 043 | 002 | 00109084 | NUT | | |
| | 044 | 002 | 15247923 | BRACKET | | |
| | 045 | 002 | 09152894 | CLIP-RUBBERIZED | | |
| | 046 | 002 | 00179816 | BOLT | | |
| | 047 | 002 | 00103320 | LOCKWASHER | | |
| | 048 | 002 | 00102634 | NUT | | |

NOTES:

A WATER FILTERS,REFER TO ENGINE MANUFACTURES RECOMMENDATIONS

110-0030-7501 ENGINE AND MOUNTING
FROM SERIAL NO. T7501037

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|----|-----|-----|----------|------------------------|-----------------|---------------|
| | 001 | 001 | 15255425 | ENGINE QSK19-C650 | | |
| | 002 | 004 | 00274098 | LOCKNUT | | |
| | 003 | 002 | 09210208 | BOLT | | |
| | 004 | 001 | 15258300 | ALTERNATOR GUARD ASSY. | | |
| | 005 | 002 | 15302001 | BRACKET ASSY | | |
| | 006 | 001 | 15256627 | MOUNTING-ENG FRONT | | |
| | 007 | 008 | 00271558 | BOLT | | |
| | 008 | 008 | 00103331 | LOCKWASHER | | |
| | 009 | 002 | 15258329 | PLATE-SUPPORT | | |
| | 010 | 002 | 15256879 | BOLT | | |
| | 011 | 008 | 15235607 | WASHER-SNUBBING | | |
| | 012 | 004 | 15235693 | MOUNT-ENG ISOLATION | | |
| | 013 | 002 | 00271621 | BOLT | | |
| | 014 | 002 | 09355771 | NUT | | |
| | 015 | 002 | 15258302 | PLATE-SUPPORT | | |
| | 016 | 001 | 15228210 | COUPLING-DRIVE | | |
| | 017 | 012 | 09060202 | WASHER-HARDENED | | |
| | 018 | 012 | 09423067 | BOLT | | |
| | 019 | 001 | 15252692 | FLANGE-COUPLING | | |
| | 020 | 008 | 09409907 | BOLT | | |
| | 021 | 003 | 09379664 | CLAMP | | |
| | 022 | 006 | 00179895 | BOLT | | |
| | 023 | 006 | 00103329 | LOCKWASHER | | |
| | 024 | 002 | 09270005 | WASHER-HARDENED | | |
| | 025 | 001 | 00179851 | BOLT | | |
| | 026 | 007 | 01967341 | WASHER | | |
| | 027 | 002 | 09268885 | LOCK | | |
| | 028 | 002 | 09268892 | KEY | | |
| | 029 | 006 | 00179838 | BOLT | | |
| | 030 | 004 | 09174339 | CLIP-RUBBERIZED | | |
| | 031 | 003 | 09181284 | CLIP-RUBBERIZED | | |
| | 032 | 001 | 09004271 | BRACKET | | |
| | 033 | 001 | 09072485 | KIT-SECURITY ENG OIL | | |
| | 034 | 001 | 09255477 | KIT-SECURITY D/STICK | | |
| | 035 | 002 | 00179795 | BOLT | | |
| | 036 | 002 | 15266844 | FILTER-LUBE OIL | | |
| | 037 | 002 | 15271319 | FILTER-FUEL | | |
| A | 038 | 001 | 15266845 | FILTER WF-15DCA4 | | |
| A | 038 | 001 | 15267515 | FILTER WF-23DCA4 | | |
| A | 038 | 001 | 15267311 | FILTER WF-4DCA4 | | |

110-0030-7501 ENGINE AND MOUNTING
FROM SERIAL NO. T7501037

| NC | REF | QTY | PART NO. | DESCRIPTION | SER.NO. FROM | SER.NO. TO |
|----|-----|-----|----------|-----------------|-----------------|---------------|
| A | 038 | 001 | 15268362 | FILTER WF-8DCA4 | | |
| | 039 | ASR | 07551826 | HOSE-BULK | | |
| | 040 | ASR | 09134207 | HOSE | | |
| | 041 | 002 | 09223731 | CLAMP | | |
| | 042 | 002 | 00103319 | LOCKWASHER | | |
| | 043 | 002 | 00109084 | NUT | | |
| | 044 | 002 | 15247923 | BRACKET | | |
| | 045 | 002 | 09152894 | CLIP-RUBBERIZED | | |
| | 046 | 002 | 00179816 | BOLT | | |
| | 047 | 002 | 00103320 | LOCKWASHER | | |
| | 048 | 002 | 00102634 | NUT | | |
| | 049 | 001 | 15303146 | TUBE ASSEMBLY | | |
| | 050 | 001 | 15303147 | PLATE BENT | | |
| | 051 | 001 | 00179839 | BOLT | | |
| | 052 | 002 | 00106263 | WASHER | | |
| | 053 | 001 | 00274208 | NUT | | |
| | 054 | 001 | 15273589 | FANBELT | | |

NOTES:

A WATER FILTERS,REFER TO ENGINE MANUFACTURES RECOMMENDATIONS

P8510

