

Product: 2010 TEREX 820 Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-820-backhoe-loader-workshop-parts-manual/>

SPARES

BACKHOE LOADER

820

Publication No. August 2010

Product: 2010 TEREX 820 Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-820-backhoe-loader-workshop-parts-manual/>

Sample of manual. Download All 2435 pages at:
<https://www.arepairmanual.com/downloads/2010-terex-820-backhoe-loader-workshop-parts-manual/>

Contents

Chassis - Sideshift Long	12
Digger Stabilisers - Sideshift Mechanical Installation	14
Digger Stabilisers - Sideshift Stabilizer Cylinder	16
Digger Stabilisers - Sideshift Stabilizer Cylinder	18
Chassis - Centremount Short	20
Chassis - Centremount Long	22
Chassis - Sideshift Long	24
Digger Stabilisers - Sideshift Mechanical Installation	26
Digger Stabilisers - Sideshift Stabilizer Cylinder	28
Digger Stabilisers - Sideshift Stabilizer Cylinder	30
Chassis - Centremount Short	32
Chassis - Centremount Long	34
Engine Cover Yellow	36
Engine Cover White	40
Front Axle - Installation 2 Wheel Drive/2 Wheel Steer	44
Front Axle - Housing 2 Wheel Drive/2 Wheel Steer	46
Front Axle - Steering Pivot 2 Wheel Drive/2 Wheel Steer	48
Front Axle - Wheel Hub 2 Wheel Drive/2 Wheel Steer	50
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	52
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	54
Front Axle - Installation	56
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	58
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	60
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	62
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	64
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	66
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	68
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	70
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	72
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	74
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	76
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	78
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	80
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	82
Steering System 2 Wheel Steer	84
Front Wheels	86
Rear Wheels	88
Front Wheels	90
Rear Wheels	92
Rear Wheels	94
Front Wheels	96
Front Wheels	98
Rear Wheels	100
Front Wheels	102
Rear Wheels	104
Front Wheels	106
Rear Wheels	108
Front Wheels	110
Rear Wheels	112
Front Wheels	114
Rear Wheels	116
Front Wheels	118

Rear Wheels	120	Engine - Glow Plugs Rg38043	238
Front Wheels	122	Engine - Engine Lifting Rg38043	240
Rear Wheels	124	Engine - Plug And Blank-Off Plug Rg38043	242
Hardnose And Grille	126	Engine - Joints And Gaskets Rg38043	244
Engine - Engine Installation Rg38100	128	Engine - Joints And Gaskets Rg38043	246
Engine - Cylinder Block Rg38100	130	Engine - Engine Installation Tier 3	248
Engine - Pistons And Crankshaft Rg38100	132	Engine - Cylinder Block Tier 3	250
Engine - Cylinder Head Rg38100	136	Engine - Pistons And Crankshaft Tier 3	252
Engine - Rockers Rg38100	138	Engine - Cylinder Head Tier 3	254
Engine - Camshaft Rg38100	140	Engine - Rockers And Camshaft Tier 3	256
Engine - Lubricating Oil Filler And Breather Rg38100	142	Engine - Timing Case Tier 3	258
Engine - Turbocharger Connections Rg38100	146	Engine - Lubricating Oil Filler And Breather Tier 3	260
Engine - Exhaust Manifold Rg38100	148	Engine - Turbocharger Connections Tier 3	264
Engine - Thermostat And Water Filter Rg38100	150	Engine - Exhaust Manifold Tier 3	266
Engine - Water Pump Rg38100	152	Engine - Thermostat And Water Pipes Tier 3	268
Engine - Crankshaft Pulley Rg38100	154	Engine - Water Pump Tier 3	270
Engine - Flywheel Rg38100	156	Engine - Crankshaft Pulley Tier 3	272
Engine - Flywheel Housing Rg38100	158	Engine - Flywheel Tier 3	274
Engine - Oil Pan Rg38100	160	Engine - Flywheel Housing Tier 3	276
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38100	162	Engine - Oil Pan Tier 3	278
Engine - Oil Pump Rg38100	164	Engine - Oil Filter And Integral Oil Cooler Tier 3	280
Engine - Fuel System Rg38100	166	Engine - Oil Pump Tier 3	282
Engine - Fuel Lift Pump Rg38100	170	Engine - Fuel System Tier 3	284
Engine - Filter With Fuel Separator Up To Serial Number Tba	172	Engine - Fuel Lift Pump Tier 3	288
Engine - Filter With Fuel Separator From Serial Number Tba	174	Engine - Fuel Pipes Tier 3	290
Engine - Alternator And Mounting Rg38100	176	Engine - Filter With Fuel Separator Tier 3	292
Engine - Glow Plugs Rg38100	178	Engine - Alternator And Mounting Tier 3	294
Engine - Engine Lifting Rg38100	180	Engine - Fan Drive Tier 3	296
Engine - Plug And Blank-Off Plug Rg38100	182	Engine - Glow Plugs Tier 3	298
Engine - Joints And Gaskets Rg38100	184	Engine - Starter Motor Tier 3	300
Engine - Joints And Gaskets Rg38100	186	Engine - Plugs And Mounts Tier 3	302
Engine - Engine Installation Rg38043	188	Engine - Cylinder Head Auxiliaries Tier 3	304
Engine - Cylinder Block Rg38043	190	Fuel System Tier 3	306
Engine - Pistons And Crankshaft Rg38043	192	Fuel System - Fuel Tank Tier 3	308
Engine - Cylinder Head Rg38043	196	Exhaust System From Serial Number H200 7 1093	310
Engine - Rockers Rg38043	198	Induction System - Air Filtration	312
Engine - Camshaft Rg38043	200	Induction System - Air Filter	314
Engine - Lubricating Oil Filler And Breather Rg38043	202	Induction System - Air Filtration With Pre Cleaner	316
Engine - Turbocharger Connections Rg38043	206	Induction System - Air Filter	318
Engine - Exhaust Manifold Rg38043	208	Cooling System ROPS	320
Engine - Thermostat And Water Filter Rg38043	210	Cooling System - Radiator Assembly ROPS	322
Engine - Water Pump Rg38043	212	Cooling System Without Air Conditioning	324
Engine - Crankshaft Pulley Rg38043	214	Cooling System - Radiator Assembly Without Air Conditioning	328
Engine - Flywheel Rg38043	216	Cooling System With Air Conditioning	330
Engine - Flywheel Housing Rg38043	218	Cooling System - Radiator Assembly With Air Conditioning	334
Engine - Oil Pan Rg38043	220	Cooling System ROPS	336
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38043	222	Cooling System - Radiator Assembly ROPS	340
Engine - Oil Pump Rg38043	224	Cooling System Without Air Conditioning	342
Engine - Fuel System Rg38043	226	Cooling System - Radiator Assembly Without Air Conditioning	346
Engine - Fuel Lift Pump Rg38043	230	Cooling System With Air Conditioning	348
Engine - Filter With Fuel Separator Up To Serial Number Tba	232	Cooling System - Radiator Assembly With Air Conditioning	352
Engine - Filter With Fuel Separator From Serial Number Tba	234	Torque Converter	354
Engine - Alternator And Mounting Rg38043	236	Drive Line Bolting	356

Drive Line Bolting	360	Rear Axle - Centre Housing 2 Wheel Steer	494
Drive Line Bolting	364	Rear Axle - Wheel Hub 2 Wheel Steer	496
Transmission - Oil Filler 2 Wheel Drive	368	Rear Axle - Epicyclic Reduction Gear 2 Wheel Steer	498
Transmission - Drive Shaft 2 Wheel Drive	370	Rear Axle - Brakes 2 Wheel Steer	500
Transmission - Housing 2 Wheel Drive	372	Rear Axle - Brake Caliper	502
Transmission - Input Shaft 2 Wheel Drive	378	Rear Axle - Brake Caliper	504
Transmission - Reverse Idler Shaft 2 Wheel Drive	382	Rear Axle - Differential Bevel Gear - 2 Wheel Steer	506
Transmission - Main Shaft 2 Wheel Drive	384	Rear Axle - Differential 2 Wheel Steer	508
Transmission - Output Shaft 2 Wheel Drive	386	Rear Axle - Differential Lock Mechanism 2 Wheel Steer	510
Transmission - Drive Shaft 4 Wheel Drive	390	Rear Axle 2 Wheel Steer	512
Transmission - Oil Filler 4 Wheel Drive	392	Rear Axle 2 Wheel Steer	514
Transmission - Oil Filler 4 Wheel Drive	394	Rear Axle 2 Wheel Steer	516
Transmission - Oil Filter 4 Wheel Drive	396	Rear Axle 2 Wheel Steer	518
Transmission - Charging Pump 4 Wheel Drive	398	Rear Axle 2 Wheel Steer	520
Transmission - Oil Strainer 4 Wheel Drive	400	Rear Axle 2 Wheel Steer	522
Transmission - Housing 4 Wheel Drive	402	Rear Axle 2 Wheel Steer	524
Transmission - Input Shaft 4 Wheel Drive	406	Rear Axle 2 Wheel Steer	526
Transmission - Reverse / First Shaft 4 Wheel Drive	410	Rear Axle 2 Wheel Steer	528
Transmission - Second Shaft 4 Wheel Drive	412	Rear Axle - Brake Caliper	530
Transmission - 4 Wheel Drive Shaft 4 Wheel Drive	416	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	532
Transmission - Fork And Gearshift Rails 4 Wheel Drive	418	Hydraulic Valve - Backhoe Control Inlet	534
Transmission - Control Valve 4 Wheel Drive	420	Hydraulic Valve - Backhoe Control Slew	538
Transmission - Control Valve 4 Wheel Drive	424	Hydraulic Valve - Backhoe Control Boom	544
Transmission - Solenoid Valve 4 Wheel Drive	428	Hydraulic Valve - Backhoe Control Dipper	550
Transmission - Drive Shaft 2 Wheel Drive	430	Hydraulic Valve - Backhoe Control Bucket	556
Transmission - Oil Filler 2 Wheel Drive	432	Hydraulic Valve - Backhoe Control Stabilizer	562
Transmission - Oil Filter 2 Wheel Drive	434	Hydraulic Valve - Backhoe Control Auxiliary	566
Transmission - Charging Pump 2 Wheel Drive	436	Hydraulic Valve - Backhoe Control Outlet	572
Transmission - Oil Strainer 2 Wheel Drive	438	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	574
Transmission - Housing 2 Wheel Drive	440	Hydraulic Valve - Backhoe Control Inlet	576
Transmission - Input Shaft 2 Wheel Drive	442	Hydraulic Valve - Backhoe Control Slew	580
Transmission - Reverse / First Shaft 2 Wheel Drive	444	Hydraulic Valve - Backhoe Control Boom	586
Transmission - Second Shaft 2 Wheel Drive	446	Hydraulic Valve - Backhoe Control Dipper	592
Transmission - Fork And Gearshift Rails 2 Wheel Drive	450	Hydraulic Valve - Backhoe Control Bucket	598
Transmission - Control Valve 2 Wheel Drive	452	Hydraulic Valve - Backhoe Control Stabilizer	604
Consumable	456	Hydraulic Valve - Backhoe Control Auxiliary	608
Consumables	458	Hydraulic Valve - Backhoe Control Outlet	614
Consumable	462	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	616
Consumable	464	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	620
Consumable	466	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	622
Consumable	468	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	624
Consumable	470	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	626
Consumable	472	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	628
Consumable	474	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	630
Consumable	476	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	632
Consumable	478	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	634
Consumable	480	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	636
Gear Change - Control Lever 4 Speed	482	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	638
Gear Change - Control Lever 3 Speed	484	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	640
Gear Change - Control Lever 4 Speed	486	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	642
Gear Change - Control Lever 3 Speed	488	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	644
Rear Axle 2 Wheel Steer	490	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	646
Rear Axle - Housing 2 Wheel Steer	492	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	648

Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	650	Cab Trim - Console RH	786
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	652	Cab Side Console - Fuse & Relay Board	788
Torque Converter - Hydraulic Lines	654	Cab Trim - Cab Mounting	792
Torque Converter - Hydraulic Lines	656	Cab Trim - Floorplate Cab	794
Main Hydraulics - Hydraulic Lines Synchro Shuttle	658	Cab Trim - Console	796
Main Hydraulics - Hydraulic Lines Synchro Shuttle	662	Cab Trim - Windscreen Wiper	798
Main Hydraulics - Oil Filter Synchro Shuttle	666	Cab Trim - Cab Mounting 4 Post ROPS	800
Main Hydraulics - Solenoid Valve Synchro Shuttle	668	Cab Trim - Floorplate 4 Post ROPS	802
Hydraulic Reservoir Synchro Shuttle	670	Cab Trim - Cab Mounting	804
Main Hydraulics - Tandem Pump Synchro Shuttle	672	Cab Trim - Floorplate & Digger Tower	806
Main Hydraulics - Hydraulic Lines Synchro Shuttle	674	Cab Trim - Mats	808
Main Hydraulics - Hydraulic Lines Synchro Shuttle	678	Cab Trim - Mats	810
Main Hydraulics - Oil Filter Synchro Shuttle	682	Not Serviced	812
Main Hydraulics - Solenoid Valve Synchro Shuttle	684	Cab Environment - Heater Installation Front	814
Hydraulic Reservoir Synchro Shuttle	686	Cab Environment - Heater Installation Rear	818
Main Hydraulics - Tandem Pump Synchro Shuttle	688	Cab Environment - Heater Unit	820
Control Box - Installation From Serial Number Tba	690	Cab Environment - Air Conditioning Installation	822
Control Box Control Pedals	692	Cab Environment - Heater Installation Front	826
Control Box Hydraulics	696	Cab Environment - Air Conditioning Installation Rear	830
Control Box Brake Cylinder	698	Cab Environment - Air Conditioning Unit	832
Control Box Steering	700	Cab Environment - Less Heater Unit ROPS	836
Throttle Controls	702	Front Console - Installation ROPS	838
Throttle Controls Lever, Control	704	Front Console ROPS	840
Tool Kit - Wheel Brace + Grease Gun	706	Front Console - Instrument Panel ROPS	842
Service Brake - Brake Circuit From Serial Number Tba	708	Front Console - Forward/Reverse Switch ROPS	844
Service Brake - Brake Circuit From Serial Number Tba	710	Front Console - Installation Cab	846
Service Brake - Brake Circuit From Serial Number Tba	712	Front Console Cab	848
Service Brake - Brake Circuit From Serial Number Tba	714	Front Console - Instrument Panel Cab	850
Differential Lock Synchro Shuttle	716	Front Console - Forward/Reverse Switch Cab	852
Differential Lock - Controls Solenoid Valve	718	Front Console - Installation ROPS	854
Differential Lock Synchro Shuttle	720	Front Console ROPS	856
Parking Brake	722	Front Console - Instrument Panel ROPS	858
Parking Brake 4 Post ROPS	724	Front Console - Forward/Reverse Switch ROPS	860
Cab - 4 Post ROPS	726	Front Console - Installation ROPS	862
Cab - Rear Worklight	728	Front Console ROPS	864
Cab - Relay Bracket	730	Front Console - Instrument Panel ROPS	866
Cab - Frame	732	Front Console - Forward/Reverse Switch ROPS	868
Cab - Door	736	Front Console - Installation Cab	870
Cab - Rear Window	742	Front Console Cab	872
Cab - Outer Roof	746	Front Console - Instrument Panel Cab	874
Cab - Front Worklight	750	Front Console - Forward/Reverse Switch Cab	876
Cab - Rear Worklight	752	Front Console - Installation Cab	878
Cab - Inner Roof	754	Front Console Cab	880
Cab - Frame	756	Front Console - Instrument Panel Cab	882
Cab - Door	760	Front Console - Forward/Reverse Switch Cab	884
Cab - Rear Window	766	Front Console - Installation ROPS	886
Cab - Outer Roof	770	Front Console ROPS	888
Cab - Inner Roof	774	Front Console - Instrument Panel ROPS	890
Cab Trim - Windscreen Wiper	776	Front Console - Forward/Reverse Switch ROPS	892
Cab - Front Worklight	778	Front Console - Installation ROPS	894
Cab - Rear Worklight	780	Front Console ROPS	896
Cab Trim - Heater	782	Front Console - Instrument Panel ROPS	898
Cab Trim - Console	784	Front Console - Forward/Reverse Switch ROPS	900

Front Console - Installation Cab	902	Seat - Weatherproof P.V.C. Trim 4 Post ROPS	1020
Front Console Cab	904	Seat - Weatherproof P.V.C. Trim Air Suspension	1022
Front Console - Instrument Panel Cab	906	Seat - Seat Installation Air Suspension	1024
Front Console - Forward/Reverse Switch Cab	908	Front Fenders 2 Wheel Steer	1030
Front Console - Installation ROPS	910	Ride Control - Hydraulic Circuit English	1032
Front Console ROPS	912	Ride Control - Hydraulic Circuit English	1034
Front Console - Instrument Panel ROPS	914	Ride Control - Hydraulic Circuit Less Ride Control	1036
Front Console - Forward/Reverse Switch ROPS	916	Ride Control - Hydraulic Circuit French	1038
Front Console - Installation Cab	918	Ride Control - Hydraulic Circuit French	1040
Front Console Cab	920	Ride Control - Hydraulic Circuit German	1042
Front Console - Instrument Panel Cab	922	Ride Control - Hydraulic Circuit German	1044
Front Console - Forward/Reverse Switch Cab	924	Ride Control - Hydraulic Circuit Italian	1046
Front Console - Installation Cab	926	Ride Control - Hydraulic Circuit Italian	1048
Front Console Cab	928	Ride Control - Hydraulic Circuit Spanish	1050
Front Console - Instrument Panel Cab	930	Ride Control - Hydraulic Circuit Spanish	1052
Front Console - Forward/Reverse Switch Cab	932	Ride Control - Hydraulic Circuit Dutch	1054
Side Console Switchpack	934	Ride Control - Hydraulic Circuit Dutch	1056
Side Console - Instrument Panel Switchpack	938	Ride Control - Hydraulic Circuit Danish	1058
Side Console - Fuse & Relay Board	940	Ride Control - Hydraulic Circuit Danish	1060
Side Console Switchpack	942	Ride Control - Hydraulic Circuit	1062
Side Console - Instrument Panel Switchpack	946	Ride Control - Hydraulic Circuit Solenoid Valve	1064
Side Console - Fuse & Relay Board	948	Ride Control - Hydraulic Circuit	1066
Side Console 4 Post ROPS	950	Ride Control - Hydraulic Circuit Solenoid Valve	1068
Side Console - Instrument Panel Rocker Switch	954	Ride Control - Hydraulic Circuit ROPS	1070
Side Console - Fuse & Relay Board	956	Ride Control - Hydraulic Circuit Solenoid Valve	1072
Side Console 4 Post ROPS	958	Ride Control - Hydraulic Circuit ROPS	1074
Side Console - Instrument Panel Rocker Switch	962	Ride Control - Hydraulic Circuit Solenoid Valve	1076
Side Console - Fuse & Relay Board	964	Loader - Arms Yellow	1078
Side Console Switchpack	966	Loader - Links Yellow	1082
Side Console - Instrument Panel Switchpack	968	Loader - Return To Dig Mechanical	1084
Side Console Switchpack	970	Loader - Return To Dig Mechanical	1088
Side Console - Instrument Panel Switchpack	972	Loader - Safety Strut	1092
Chassis Electrics	974	Loader - Arms White	1094
Chassis Electrics Synchro Shuttle - Carraro	978	Loader - Links White	1098
Battery - Single From Serial Number H200 4 2919	982	Loader - Return To Dig Mechanical	1100
Battery - Dual From Serial Number H200 4 2919	984	Loader - Return To Dig Mechanical	1104
Battery - Single Tier 3	986	Loader - Safety Strut	1108
Battery - Dual Tier 3	988	Loader Bucket - Standard For Use With Forks	1110
Rear Lighting - Sideshift	990	Loader Bucket - 7 In 1	1112
Rear Lighting - Centremount	992	Loader Bucket - 7 In 1 Bucket Pipework	1114
Rear Lighting - ROPS	994	Loader Bucket - 7 In 1 Cylinder	1116
Rear Lighting - ROPS 4 Post ROPS	996	Loader Bucket Less Bucket	1118
Front Lighting - Headlights Left Hand Dip	998	Loader Hydraulics - Lift Cylinder Standard Specification	1120
Front Lighting - Headlights Right Hand Dip	1000	Loader Hydraulics - Lift Cylinder Standard Specification	1124
Mirrors - Cab	1002	Loader Hydraulics - Lift Cylinder Standard Specification	1126
Mirrors - ROPS 4 Post ROPS	1004	Loader Hydraulics - Bucket Cylinder Standard Specification	1128
Seat - Seat Installation Fabric Trim - Cab Machines	1006	Loader Hydraulics - Bucket Cylinder Standard Specification	1132
Seat - Fabric Trim Cab	1008	Loader Hydraulics - Bucket Cylinder Standard Specification	1134
Seat - Seat Installation Air Suspension	1010	Loader Hydraulics - Lift Cylinder Standard Specification	1136
Seat - Fabric Trim Air Suspension	1012	Loader Hydraulics - Lift Cylinder Standard Specification	1140
Seat - Seat Installation Weatherproof P.V.C. Trim	1014	Loader Hydraulics - Lift Cylinder Standard Specification	1142
Seat - Weatherproof P.V.C. Trim 4 Post ROPS	1016	Loader Hydraulics - Bucket Cylinder Standard Specification	1144
Seat - Seat Installation Weatherproof P.V.C. Trim	1018	Loader Hydraulics - Bucket Cylinder Standard Specification	1148

Loader Hydraulics - Bucket Cylinder Standard Specification	1150	Loader Controls Upper Control Levers	1284
Loader Hydraulics - Lift Cylinder Standard Specification	1152	Loader Controls Lower Control Levers	1286
Loader Hydraulics - Lift Cylinder Standard Specification	1156	Loader Controls Control Valve	1290
Loader Hydraulics - Lift Cylinder Standard Specification	1158	Loader Controls - Hydraulic Valve Inlet	1292
Loader Hydraulics - Bucket Cylinder Standard Specification	1160	Loader Controls - Hydraulic Valve Loader Arm Section	1294
Loader Hydraulics - Bucket Cylinder Standard Specification	1162	Loader Controls - Hydraulic Valve Standard Bucket Section	1296
Loader Hydraulics - Bucket Cylinder Standard Specification	1164	Loader Controls - Hydraulic Valve Standard Bucket Section	1298
Loader Hydraulics - Lift Cylinder Standard Specification	1166	Loader Controls - Hydraulic Valve Standard Bucket Section	1300
Loader Hydraulics - Lift Cylinder Standard Specification	1170	Loader Controls - Upper Control Levers 7 In 1 Bucket	1302
Loader Hydraulics - Lift Cylinder Standard Specification	1172	Loader Controls - Lower Control Levers 7 In 1 Bucket	1306
Loader Hydraulics - Bucket Cylinder Standard Specification	1174	Loader Controls - Control Valve 7 In 1 Bucket	1310
Loader Hydraulics - Bucket Cylinder Standard Specification	1178	Loader Controls - Hydraulic Valve Inlet	1312
Loader Hydraulics - Bucket Cylinder Standard Specification	1180	Loader Controls - Hydraulic Valve Loader Arm Section	1314
Loader Hydraulics - Lift Cylinder Standard Specification	1182	Loader Controls - Hydraulic Valve Standard Bucket Section	1320
Loader Hydraulics - Lift Cylinder Standard Specification	1186	Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1326
Loader Hydraulics - Lift Cylinder Standard Specification	1188	Loader Controls - Hydraulic Valve Outlet	1332
Loader Hydraulics - Bucket Cylinder Standard Specification	1190	Loader Controls - Upper Control Levers	1334
Loader Hydraulics - Bucket Cylinder Standard Specification	1194	Loader Controls - Lower Control Levers	1336
Loader Hydraulics - Bucket Cylinder Standard Specification	1196	Loader Controls - Control Valve	1340
Loader Hydraulics - Lift Cylinder Standard Specification	1198	Loader Controls - Hydraulic Valve Inlet	1342
Loader Hydraulics - Lift Cylinder Standard Specification	1202	Loader Controls - Hydraulic Valve Loader Arm Section	1344
Loader Hydraulics - Lift Cylinder Standard Specification	1204	Loader Controls - Hydraulic Valve Standard Bucket Section	1350
Loader Hydraulics - Bucket Cylinder Standard Specification	1206	Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1356
Loader Hydraulics - Bucket Cylinder Standard Specification	1210	Loader Controls - Hydraulic Valve Outlet	1362
Loader Hydraulics - Bucket Cylinder Standard Specification	1212	Loader Controls Upper Control Levers	1364
Hose Burst Kit Loader Arm Cylinder	1214	Loader Controls Lower Control Levers	1366
Hose Burst Kit Loader Bucket Cylinder	1218	Loader Controls Control Valve	1370
Hose Burst Kit Boom Cylinder	1222	Loader Controls - Hydraulic Valve Inlet	1372
Hose Burst Kit Dipper Cylinder	1224	Loader Controls - Hydraulic Valve Loader Arm Section	1374
Loader Controls Upper Control Levers	1226	Loader Controls - Hydraulic Valve Standard Bucket Section	1376
Loader Controls Lower Control Levers	1230	Loader Controls - Hydraulic Valve Standard Bucket Section	1378
Loader Controls Control Valve	1234	Loader Controls - Hydraulic Valve Standard Bucket Section	1380
Loader Controls - Hydraulic Valve Inlet	1236	Loader Controls Upper Control Levers	1382
Loader Controls - Hydraulic Valve Loader Arm Section	1238	Loader Controls Lower Control Levers	1386
Loader Controls - Hydraulic Valve Standard Bucket Section	1240	Loader Controls Control Valve	1390
Loader Controls - Hydraulic Valve Standard Bucket Section	1242	Loader Controls - Hydraulic Valve Inlet	1392
Loader Controls - Hydraulic Valve Standard Bucket Section	1244	Loader Controls - Hydraulic Valve Loader Arm Section	1394
Loader Controls Upper Control Levers	1246	Loader Controls - Hydraulic Valve Standard Bucket Section	1396
Loader Controls Lower Control Levers	1250	Loader Controls - Hydraulic Valve Standard Bucket Section	1398
Loader Controls Control Valve	1254	Loader Controls - Hydraulic Valve Standard Bucket Section	1400
Loader Controls - Hydraulic Valve Inlet	1256	Loader Controls Upper Control Levers	1402
Loader Controls - Hydraulic Valve Loader Arm Section	1258	Loader Controls Lower Control Levers	1404
Loader Controls - Hydraulic Valve Standard Bucket Section	1260	Loader Controls Control Valve	1408
Loader Controls - Hydraulic Valve Standard Bucket Section	1262	Loader Controls - Hydraulic Valve Inlet	1410
Loader Controls - Hydraulic Valve Standard Bucket Section	1264	Loader Controls - Hydraulic Valve Loader Arm Section	1412
Loader Controls Upper Control Levers	1266	Loader Controls - Hydraulic Valve Standard Bucket Section	1414
Loader Controls Lower Control Levers	1268	Loader Controls - Hydraulic Valve Standard Bucket Section	1416
Loader Controls Control Valve	1272	Loader Controls - Hydraulic Valve Standard Bucket Section	1418
Loader Controls - Hydraulic Valve Inlet	1274	Loader Controls Upper Control Levers	1420
Loader Controls - Hydraulic Valve Loader Arm Section	1276	Loader Controls Lower Control Levers	1424
Loader Controls - Hydraulic Valve Standard Bucket Section	1278	Loader Controls Control Valve	1428
Loader Controls - Hydraulic Valve Standard Bucket Section	1280	Loader Controls - Hydraulic Valve Inlet	1430
Loader Controls - Hydraulic Valve Standard Bucket Section	1282	Loader Controls - Hydraulic Valve Loader Arm Section	1432

Loader Controls - Hydraulic Valve Standard Bucket Section	1434	Digger Hydraulics - Sideshift Swing Components	1572
Loader Controls - Hydraulic Valve Standard Bucket Section	1436	Digger Hydraulics - Sideshift Clamp	1574
Loader Controls - Hydraulic Valve Standard Bucket Section	1438	Digger Hydraulics - Sideshift Attachment	1576
Boom Transport Lock Sideshift Digger	1444	Digger Hydraulics - Sideshift Attachment	1580
Boom Transport Lock Centre Mounted Digger	1446	Digger Hydraulics - Sideshift Bucket	1584
Digger Stabilisers - Sideshift Hydraulic Installation	1448	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1588
Digger Stabilisers - Sideshift Mechanical Installation	1450	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1590
Digger Stabilisers - Sideshift Hydraulic Installation	1452	Digger Hydraulics - Sideshift Telescopic Dipper	1592
Digger Stabilisers - Sideshift Stabilizer Cylinder	1454	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1594
Digger Stabilisers - Sideshift Stabilizer Cylinder	1456	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1596
Digger Stabilisers - Sideshift Lock-Out Valve	1458	Digger Hydraulics - Sideshift Boom	1598
Not Serviced	1460	Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1600
Digger Swing Pivot - Sideshift	1462	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1602
Digger Swing Pivot - Sideshift Swing Cylinder Pacoma	1466	Digger Hydraulics - Sideshift Swing Components	1604
Digger Swing Pivot - Sideshift Swing Cylinder Wipro	1468	Digger Hydraulics - Sideshift Clamp	1606
Digger Swing Pivot - Centremount	1470	Digger Hydraulics - Sideshift Attachment	1608
Digger Swing Pivot - Centremount Swing Cylinder Pacoma	1472	Digger Hydraulics - Sideshift Attachment	1612
Digger Swing Pivot - Centremount Swing Cylinder Wipro	1474	Digger Hydraulics - Sideshift Bucket	1616
Boom	1476	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1620
Not Serviced	1478	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1622
Dipper - Standard	1480	Digger Hydraulics - Sideshift Standard Dipper	1624
Dipper - Standard	1482	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1626
Dipper - Extendahoe	1484	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1628
Dipper - Extendahoe Cylinder	1490	Digger Hydraulics - Sideshift Boom	1630
Dipper - Extendahoe	1492	Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1632
Dipper - Extendahoe Cylinder	1498	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1634
Dipper - Standard Case Bucket	1500	Digger Hydraulics - Sideshift Swing Components	1636
Dipper - Standard Case Bucket	1502	Digger Hydraulics - Sideshift Clamp	1638
Dipper - Extendahoe Case Bucket	1504	Digger Hydraulics - Sideshift Attachment	1640
Dipper - Extendahoe Cylinder	1510	Digger Hydraulics - Sideshift Attachment	1644
Dipper - Extendahoe Case Bucket	1512	Digger Hydraulics - Sideshift Bucket	1648
Dipper - Extendahoe Cylinder	1518	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1652
Dipper - Standard Jcb Bucket	1520	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1654
Dipper - Standard Jcb Bucket	1522	Digger Hydraulics - Sideshift Telescopic Dipper	1656
Dipper - Extendahoe Jcb Bucket	1524	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1658
Dipper - Extendahoe Cylinder	1530	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1660
Dipper - Extendahoe Jcb Bucket	1532	Digger Hydraulics - Sideshift Boom	1662
Dipper - Extendahoe Cylinder	1538	Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1664
Digger Bucket Linkage	1540	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1666
Digger Bucket Linkage	1542	Digger Hydraulics - Sideshift Swing Components	1668
Digger Bucket Linkage - Jcb Buckets	1544	Digger Hydraulics - Sideshift Clamp	1670
Digger Bucket Linkage - Jcb Buckets	1546	Digger Hydraulics - Sideshift Attachment	1672
Digger Bucket Linkage - Case Buckets	1548	Digger Hydraulics - Sideshift Attachment	1676
Digger Bucket Linkage - Case Buckets	1550	Digger Hydraulics - Centremount Bucket	1680
Digger Hydraulics - Sideshift Bucket	1552	Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1684
Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1556	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1686
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1558	Digger Hydraulics - Centremount Standard Dipper	1688
Digger Hydraulics - Sideshift Standard Dipper	1560	Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1690
Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1562	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1692
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1564	Digger Hydraulics - Centremount Boom 4.5m	1694
Digger Hydraulics - Sideshift Boom	1566	Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1696
Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1568	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1698
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1570	Digger Hydraulics - Centremount Swing Components	1700


Digger Hydraulics - Centremount Bucket	1702	Auxiliary Hydraulics - Sideshift Telescopic Dipper	1828
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1706	Auxiliary Hydraulics - Sideshift Telescopic Dipper	1832
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1708	Auxiliary Hydraulics - Sideshift Telescopic Dipper	1838
Digger Hydraulics - Centremount Telescopic Dipper	1710	Auxiliary Hydraulics - Sideshift Standard Dipper	1844
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1712	Auxiliary Hydraulics - Sideshift Standard Dipper	1848
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1714	Auxiliary Hydraulics - Sideshift Control Pedal	1852
Digger Hydraulics - Centremount Boom 4.5m	1716	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1854
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1718	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1856
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1720	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1860
Digger Hydraulics - Centremount Swing Components	1722	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1862
Digger Hydraulics - Centremount Bucket	1724	Auxiliary Hydraulics - Centremount Standard Dipper	1866
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1728	Auxiliary Hydraulics - Centremount Standard Dipper	1868
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1730	Auxiliary Hydraulics - Centremount Control Pedal	1870
Digger Hydraulics - Centremount Standard Dipper	1732	Not Serviced	1872
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1734	Digger Bucket - Standard	1874
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1736	Digger Bucket - Standard	1876
Digger Hydraulics - Centremount Boom 4.5m	1738	Digger Bucket - Standard	1878
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1740	Digger Bucket - Standard	1880
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1742	Digger Bucket - Standard 305 Mm	1882
Digger Hydraulics - Centremount Swing Components	1744	Digger Bucket - Ditch Cleaning	1884
Digger Hydraulics - Centremount Bucket	1746	Digger Bucket - Ditch Cleaning	1886
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1750	Digger Bucket - Gannon 12 In	1888
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1752	Digger Bucket - Gannon 18 In	1890
Digger Hydraulics - Centremount Telescopic Dipper	1754	Digger Bucket - Gannon 24 In	1892
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1756	Not Serviced	1894
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1758	Digger Bucket - Premium	1896
Digger Hydraulics - Centremount Boom 4.5m	1760	Digger Bucket - Premium	1898
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1762	Digger Bucket - Premium	1900
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1764	Digger Bucket - Premium	1902
Digger Hydraulics - Centremount Swing Components	1766	Digger Bucket - Premium	1904
Digger Controls Standard	1768	Digger Bucket - Ditch Maintenance	1906
Digger Controls ISO	1770	Digger Bucket - Ditch Maintenance	1908
Digger Controls X Pattern	1774	Digger Bucket - Ditch Digging	1910
Digger Controls ISO / Sae	1776	Digger Bucket - Jcb	1912
Extendahoe Hydraulics - Sideshift Without Auxiliary Hydraulics	1780	Digger Bucket - Jcb	1914
Extendahoe Hydraulics - Sideshift Control Pedal	1782	Digger Bucket - Jcb	1916
Extendahoe Hydraulics - Sideshift With Auxiliary Hydraulics	1784	Digger Bucket - Jcb	1918
Extendahoe Hydraulics - Sideshift Control Pedal	1786	Digger Bucket - Jcb	1920
Extendahoe Hydraulics - Centremount Without Auxiliary Hydraulics	1788	Digger Bucket - Ditch Maintenance Jcb Bucket	1922
Extendahoe Hydraulics - Centremount Control Pedal	1790	Digger Bucket - Ditch Maintenance Jcb Bucket	1924
Extendahoe Hydraulics - Centremount With Auxiliary Hydraulics	1792	Not Serviced	1926
Extendahoe Hydraulics - Centremount Control Pedal	1794	Rear Fenders 2 Wheel Steer	1928
Extendahoe Hydraulics Less Control Pedal	1796	Rear Fenders - Sideshift Mudguard	1930
Extendahoe Hydraulics Control Pedal	1798	Rear Fenders 2 Wheel Steer	1932
Not Serviced	1800	Rear Fenders 2 Wheel Steer	1934
Stabiliser Controls - Sideshift Digger	1802	Rear Fenders 2 Wheel Steer	1936
Stabiliser Controls - Sideshift Digger	1806	Rear Fenders - Sideshift Mudguard	1938
Stabiliser Controls - Centremount Digger	1808	Rear Fenders 4 Post ROPS	1940
Stabiliser Controls - Centremount Digger	1812	Rear Fenders 4 Post ROPS	1942
Stabiliser Controls - Centremount Digger 4 Post ROPS	1814	Rear Fenders 2 Wheel Steer	1946
Stabiliser Controls - Sideshift Digger 4 Post ROPS	1816	Decals - Machine Identity	1948
Auxiliary Hydraulics - Sideshift Telescopic Dipper	1818	Decals - Warnings General Markets	1950
Auxiliary Hydraulics - Sideshift Telescopic Dipper	1822	Decals - Instructions General Markets	1952

Decals - Miscellaneous General Markets	1954	Decals - Instructions	2060
Decals - Warnings French	1956	Decals - Miscellaneous	2062
Decals - Instructions French	1958	Kit - Forks Loader Bucket	2064
Decals - Miscellaneous French	1960	Kit - Loader Quick Attach Pins	2066
Decals - Warnings German	1962	Kit - Loader Quick Attach Tubes	2068
Decals - Instructions German	1964	Kit - Loader Quick Attach	2070
Decals - Miscellaneous German	1966	Quick Attach, Loader	2072
Decals - Warnings Italian	1968	Tooth Guard Kit - With Decal Loader Bucket, 7-In-1	2074
Decals - Instructions Italian	1970	Tooth Guard Kit - With Decal Standard Loader Bucket	2076
Decals - Miscellaneous Italian	1972	Transport Height Decal Kit	2078
Decals - Warnings	1974	Position Indicator - Loader Arm	2080
Decals - Instructions	1976	Headlamp Extension	2082
Decals - Miscellaneous	1978	Digger Stabilisers - Safety Kit	2084
Decals - Warnings General Markets	1980	Transport Lock - Loader	2086
Decals - Instructions General Markets	1982	Decals - Craning Valve Kit	2088
Decals - Miscellaneous General Markets	1984	Seat Belt Kit	2090
Decals - Warnings Austria	1986	Fan Guard Without Air Conditioning	2092
Decals - Instructions Austria	1988	Fan Guard With Air Conditioning	2094
Decals - Miscellaneous Austria	1990	Reverse Alarm	2096
Decals - Warnings	1992	Kit - Boom Guard	2098
Decals - Instructions	1994	Bucket Pins Kit Single	2100
Decals - Miscellaneous	1996	Bucket Pins Kit Double	2102
Decals - Warnings	1998	Jcb Bucket Pins Kit Single	2104
Decals - Instructions	2000	Jcb Bucket Pins Kit Double	2106
Decals - Miscellaneous	2002	Bucket Pins Kit Loader	2108
Decals - Warnings	2004	Not Serviced	2110
Decals - Instructions	2006	Not Serviced	2112
Decals - Miscellaneous	2008	Digger Craning Eye Kit Sideshift Digger	2116
Decals - Warnings	2010	Digger Craning Eye Kit Centre Mounted Digger	2118
Decals - Instructions	2012	Digger Craning Eye Kit Sideshift Digger	2120
Decals - Miscellaneous	2014	Digger Craning Eye Kit Centre Mounted Digger	2122
Decals - Warnings North America	2016	Craning Valve Kit Cab	2124
Decals - Instructions North America	2018	Craning Valve Kit 4 Post ROPS	2128
Decals - Miscellaneous North America	2020	Front Counterweight Kit	2132
Decals - Warnings General Markets	2022	Fuel Strainer Kit	2134
Decals - Instructions General Markets	2024	Not Serviced	2136
Decals - Miscellaneous General Markets	2026	Anti Vandal Kit	2138
Decals - Warnings General Markets	2028	Street Pads Kit Sideshift Digger	2140
Decals - Instructions General Markets	2030	Service Tool Kit	2142
Decals - Miscellaneous General Markets	2032	Rotating Beacon Kit Single	2144
Decals - Warnings Costa Rica	2034	Rotating Beacon Kit Double	2146
Decals - Instructions Costa Rica	2036	Worklight Kit	2148
Decals - Miscellaneous Costa Rica	2038	Seat Armrest Kit	2150
Decals - Warnings Costa Rica	2040	Kit - Headrest	2152
Decals - Instructions Costa Rica	2042	Steering Wheel Spinner Knob Kit	2154
Decals - Miscellaneous Costa Rica	2044	Bucket Blade Kit Narrow	2156
Decals - Warnings	2046	Bucket Tooth Kit Loader Bucket, 7-In-1	2158
Decals - Instructions	2048	Hose Burst Kit - Quick Attach Boom Cylinder	2160
Decals - Miscellaneous	2050	Hose Burst Kit - Quick Attach Boom Cylinder	2164
Decals - Warnings	2052	Hose Bust Kit - Less Quick Attach Boom Cylinder	2168
Decals - Instructions	2054	Hose Bust Kit - Less Quick Attach Boom Cylinder	2172
Decals - Miscellaneous	2056	Hose Bust Kit - Less Quick Attach Boom Cylinder	2176
Decals - Warnings	2058	Literature Operator Manual - English	2178

Literature Operator Manual - Spanish	2180	Literature Greek	2290
Literature Operator Manual - French	2182	Literature Bulgarian	2292
Literature Operator Manual - German	2184	Literature Spanish Non Eu	2294
Literature Operator Manual - Danish	2186	Literature Russian	2296
Rockguard Kit	2188	Literature French Non Eu	2298
Spare Wheels - Rear (M27a)	2190	Literature Portuguese Non Eu	2300
Spare Wheels - Rear (M02, M06, M08 & M11)	2192	Literature Turkish	2302
Spare Wheels - Rear (M07, M10 & M12)	2194	Quick Attach, Digger - Sideshift Standard Dipper	2304
Spare Wheels - Rear (M05, M09, M14 & M21)	2196	Quick Attach, Digger - Sideshift Standard Dipper	2306
Spare Wheels - Rear (M03 & M13)	2198	Quick Attach, Digger - Sideshift Solenoid Valve	2308
Spare Wheels - Rear (M01 & M04)	2200	Quick Attach, Digger - Sideshift Quick Coupler	2310
Spare Wheels - Rear (M02, M06, M08 & M11)	2202	Quick Attach, Digger - Sideshift Standard Dipper	2312
Spare Wheels - Rear (M07, M10 & M12)	2204	Quick Attach, Digger - Sideshift Standard Dipper	2314
Spare Wheels - Rear (M05, M09, M14 & M21)	2206	Quick Attach, Digger - Sideshift Solenoid Valve	2316
Spare Wheels - Rear (M03 & M13)	2208	Quick Attach, Digger - Sideshift Telescopic Dipper	2318
Spare Wheels - Rear (M01 & M04)	2210	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2320
Spare Wheels - Rear (M23a & M28a)	2212	Quick Attach, Digger - Sideshift Solenoid Valve	2322
Spare Wheels - Rear (M23a & M28a)	2214	Quick Attach, Digger - Sideshift Quick Coupler	2324
Spare Wheels - Rear (M24a)	2216	Quick Attach, Digger - Sideshift Telescopic Dipper	2326
Spare Wheels - Rear (M24a)	2218	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2328
Spare Wheels - Rear (M25a & M29a)	2220	Quick Attach, Digger - Sideshift Solenoid Valve	2330
Spare Wheels - Rear (M25a & M29a)	2222	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2332
Spare Wheels - Rear (M27a)	2224	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2334
Stepguards	2226	Quick Attach, Digger - Centremount Solenoid Valve	2336
Spare Wheel - Front - White	2228	Quick Attach, Digger - Centremount Quick Coupler	2338
Spare Wheel - Front - Yellow	2230	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2340
Spare Wheel - Front - White	2232	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2342
Spare Wheel - Front - Yellow	2234	Quick Attach, Digger - Centremount Solenoid Valve	2344
Spare Wheel - Front - White	2236	Quick Attach, Digger - Centremount Quick Coupler	2346
Spare Wheel - Front - Yellow	2238	Quick Attach, Digger - Sideshift Standard Dipper	2348
Bucket Pins Kit Case Bucket	2240	Quick Attach, Digger - Sideshift Standard Dipper	2350
Street Pads Kit Sideshift Digger	2242	Quick Attach, Digger - Sideshift Solenoid Valve	2352
Soundproofing	2244	Quick Attach, Digger - Sideshift Telescopic Dipper	2354
Literature English	2246	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2356
Literature French	2248	Quick Attach, Digger - Sideshift Solenoid Valve	2358
Literature German	2250	Quick Attach, Digger - Centremount Standard Dipper	2360
Literature Italian	2252	Quick Attach, Digger - Centremount Standard Dipper	2362
Literature Spanish	2254	Quick Attach, Digger - Centremount Solenoid Valve	2364
Literature Portuguese	2256	Quick Attach, Digger - Centremount Telescopic Dipper	2366
Literature Danish	2258	Quick Attach, Digger - Centremount Telescopic Dipper	2368
Literature Dutch	2260	Quick Attach, Digger - Centremount Solenoid Valve	2370
Literature Finnish	2262	Quick Attach, Digger - Abiljo	2372
Literature North America	2264	Not Serviced	2374
Literature Romanian	2270	Quick Attach, Digger - Sideshift Standard Dipper	2376
Literature Croatian	2272	Quick Attach, Digger - Sideshift Solenoid Valve	2378
Literature Czech	2274	Quick Attach, Digger - Sideshift Standard Dipper	2380
Literature Estonian	2276	Quick Attach, Digger - Sideshift Quick Coupler	2382
Literature Hungarian	2278	Quick Attach, Digger - Sideshift Telescopic Dipper	2384
Literature Latvian	2280	Quick Attach, Digger - Sideshift Telescopic Dipper	2386
Literature Lithuanian	2282	Quick Attach, Digger - Sideshift Solenoid Valve	2388
Literature Polish	2284	Quick Attach, Digger - Sideshift Quick Coupler	2390
Literature Slovakian	2286	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2392
Literature Slovenian	2288	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2394


Quick Attach, Digger - Centremount Solenoid Valve	2396
Quick Attach, Digger - Centremount Quick Coupler	2398
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2400
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2402
Quick Attach, Digger - Centremount Solenoid Valve	2404
Quick Attach, Digger - Centremount Quick Coupler	2406
Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2408
Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2410
Quick Attach, Digger - Sideshift Solenoid Valve	2412
Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2414
Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2416
Quick Attach, Digger - Sideshift Solenoid Valve	2418
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2420
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2422
Quick Attach, Digger - Centremount Solenoid Valve	2424
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2426
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2428
Quick Attach, Digger - Centremount Solenoid Valve	2430
Quick Attach - Miller Mechanical	2432

C-10011-01.1-B




Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6112049M91	1	Chassis Complete 2ws Long Ss	Chassis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	

C-10011-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10011c03.1 1 10011c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	






Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3622129M94GY02	2	Cylinder Stab Ss Only (Benford Grey)	L´Hie Hydraulique	Zylinder Hydr.	Gato, Conj.	Tba [10011c02.1 4]
2	3623297M92	1	Barrel Assy	Cylindre De Vérin	Zylinderrohr	Cilindro De Gato	
3	1607690M1	1	Lock Nut M30	Ecrou Frein	Kontermutter	Tuerca	
4	3487067M1	1	Piston Guide Ring 70*10*2	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
5	3485241M1	1	Wear Ring Piston	Anneau	Ring	Aro	
6	3485254M1	1	Ring Pressure	Anneau	Ring	Aro	
7	3487067M1	1	Piston Guide Ring 70*10*2	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
8	3623299M1	1	Piston	Piston	Kolben	Pistón De Gato	
9	359181X1	1	O-Ring (44.04 Mm Nominal I/D) Shore A90	Joint Torique	O - Ring	Junta De Tipo O	
10	359187X1	1	O-Ring-63,09*3,53	Joint Torique	O Ring	Junta De Tipo O	
11	1884170M1	1	Backring-64.06*3*02	Contre-Joint	Stützring	ContraJunta	
12	3487205M1	1	O Ring, Hydr. Cylinder	Joint Torique	O Ring	Junta De Tipo O	
13	3623298M1	1	Bearing Cylinder	Roulement	Lager	Palier De Gato	
14	3443386M1	1	Retaining Plug	Bouchon	Stopfen	Tapón	
15	3491486M1	1	Bush, Piston Rod/Gland	Douille	Büchse	Anillo	
16	3443341M1	1	Ring Buffer	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
17	1606464M1	1	Seal	Joint D´Arbre	Wellendichtring	Junta	
18	1606575M1	1	Wiper Ring	Anneau	Ring	Junta Raspador	
19	3441606M91	1	Piston Rod Assy	Tige De Vérin	Kolbenstange	Vástago Cilindro	
20	3623300M91	1	Kit Seal	Jeu Étanchéité	Dichtringsatz	Juego De Juntas	




C-10011-03.2-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6111068M91GY03	2	Cylinder Stabiliser S/S	Cylindre	Zylinder	Gato, Conj.	Tba [10011c02.1 4]
2	6194596M91	1	Barrel - Cylinder	Corps Cylindre	Zylindergehause	Tubo	
3	6194600M1	1	Nut - Nyloc	Ecrou Blocage	Flachmutter	Tuerca	
4	6194606M1	1	Bearing - Piston	Coussinet	Lager	Teniendo - Pistón	
5	6194604M1	1	Seal - Piston	Joint Étanchéité	Dichtring	Junta	
6	6194605M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
7	6194598M1	1	Piston	Piston	Kolben	Pistón	
8	6194607M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
9	6194601M1	1	Stop Tube	Tube Butee	Rohr Anschlag	Pare - Tubo	
10	6194613M1	1	Ring - Back Up	Contre Bague	Stutzring	ContraJunta	
11	6194612M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
12	6194602M1	1	Bush - Bimetal	Douille	Büchse	Juego De Anillos	
13	6194599M1	1	End Cover - Head	Couvercle	Deckel	Tapa	
14	6194609M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
15	6194608M1	1	Seal - Rod (Primary)	Joint Étanchéité	Dichtring	Junta	
16	6194610M1	1	Seal- Rod (Secondary)	Joint Étanchéité	Dichtring	Junta	
17	6194611M1	1	Wiper	Essuyeur	Wischer	Raspador, Escobilla	
18	6194603M1	1	Ring - Snap	Fermeoir	Sprengring	Anillo De Resorte	
19	6194597M91	1	Rod - Piston	Bielle De Piston	Pleuelstange	Rod - Pistón	
20	6194614M91	0	Seal Kit	Jeu Etancheite	Dichtringsatz	Juego De Juntas	




C-10013-01.1-B




Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6110037M93	1	Chassis - Centremount (W/Assy) Short	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passstift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	

C-10014-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6110038M94	1	Chassis - Centremount (W/Assy) Long	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passtift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	


C-10020-01.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6112382M91	1	Chassis Complete 2ws Long Ss	Chassis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	6112726M1	1	Seal - Cooling Pack - Long Drop Chassis	Joint	Dichtung	Junta	Tier 3 Only



C-10020-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10020c03.1 1 10020c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	




Digger Stabilisers - Sideshift Stabilizer Cylinder

4067 10020

Product: 2010 TEREX 820 Backhoe Loader Workshop Parts Manual

Full Download: <https://www.arepairmanual.com/downloads/2010-terex-820-backhoe-loader-workshop-parts-manual/>

C-10020-03.1-A



Sample of manual. Download All 2435 pages at:
<https://www.arepairmanual.com/downloads/2010-terex-820-backhoe-loader-workshop-parts-manual/>