

Product: 2010 TEREX 880SX Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-880sx-backhoe-loader-workshop-parts-manual/>

SPARES

BACKHOE LOADER

880SX

Publication No. August 2010

Sample of manual. Download All 2343 pages at:

<https://www.terexce.com/central-boulevard-10-prologis-park-coventry-cv6-4BX-England>

Tel.: +44 (0)2476 339400 - Fax: +44 (0)2476 339500

www.terexce.com - Email : parts@terexce.com - sales@terexce.com

Product: 2010 TEREX 880SX Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-880sx-backhoe-loader-workshop-parts-manual/>

Sample of manual. Download All 2343 pages at:
<https://www.arepairmanual.com/downloads/2010-terex-880sx-backhoe-loader-workshop-parts-manual/>

Contents

Chassis - Sideshift Short	12
Digger Stabilisers - Sideshift Mechanical Installation	14
Digger Stabilisers - Sideshift Stabilizer Cylinder	16
Digger Stabilisers - Sideshift Stabilizer Cylinder	18
Chassis - Centremount Short	20
Chassis - Sideshift Short	22
Digger Stabilisers - Sideshift Mechanical Installation	24
Digger Stabilisers - Sideshift Stabilizer Cylinder	26
Digger Stabilisers - Sideshift Stabilizer Cylinder	28
Chassis - Centremount Short	30
Engine Cover Yellow	32
Engine Cover White	36
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	40
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	42
Front Axle - Installation	44
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	46
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	48
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	50
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	52
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	54
Steering System 2 Wheel Steer	56
Front Wheels	58
Rear Wheels	60
Front Wheels	62
Rear Wheels	64
Rear Wheels	66
Front Wheels	68
Front Wheels	70
Rear Wheels	72
Front Wheels	74
Rear Wheels	76
Front Wheels	78
Rear Wheels	80
Hardnose And Grille	82
Engine - Engine Installation Rg38099	84
Engine - Cylinder Block Rg38099	86
Engine - Pistons And Crankshaft Rg38099	88
Engine - Cylinder Head Rg38099	92
Engine - Rockers Rg38099	94
Engine - Camshaft Rg38099	96
Engine - Lubricating Oil Filler And Breather Rg38099	98
Engine - Turbocharger Connections Rg38099	102
Engine - Exhaust Manifold Rg38099	104
Engine - Thermostat And Water Filter Rg38099	106
Engine - Water Pump Rg38099	108
Engine - Crankshaft Pulley Rg38099	110
Engine - Flywheel Rg38099	112
Engine - Flywheel Housing Rg38099	114
Engine - Oil Pan Rg38099	116
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38099	118
Engine - Oil Pump Rg38099	120
Engine - Fuel System Rg38099	122

Engine - Fuel Lift Pump Rg38099	126	Engine - Fuel System Tier 3	240
Engine - Filter With Fuel Separator Up To Serial Number Tba	128	Engine - Fuel Lift Pump Tier 3	244
Engine - Filter With Fuel Separator From Serial Number Tba	130	Engine - Fuel Pipes Tier 3	246
Engine - Alternator And Mounting Rg38099	132	Engine - Filter With Fuel Separator Tier 3	248
Engine - Glow Plugs Rg38099	134	Engine - Alternator And Mounting Tier 3	250
Engine - Engine Lifting Rg38099	136	Engine - Fan Drive Tier 3	252
Engine - Plug And Blank-Off Plug Rg38099	138	Engine - Glow Plugs Tier 3	254
Engine - Joints And Gaskets Rg38099	140	Engine - Starter Motor Tier 3	256
Engine - Joints And Gaskets Rg38099	142	Engine - Plugs And Mounts Tier 3	258
Engine - Engine Installation Rg38044	144	Engine - Cylinder Head Auxiliaries Tier 3	260
Engine - Cylinder Block Rg38044	146	Fuel System Tier 3	262
Engine - Pistons And Crankshaft Rg38044	148	Fuel System - Fuel Tank Tier 3	264
Engine - Cylinder Head Rg38044	152	Exhaust System From Serial Number H200 7 1093	266
Engine - Rockers Rg38044	154	Induction System - Air Filtration	268
Engine - Camshaft Rg38044	156	Induction System - Air Filter	270
Engine - Lubricating Oil Filler And Breather Rg38044	158	Induction System - Air Filtration With Pre Cleaner	272
Engine - Turbocharger Connections Rg38044	162	Induction System - Air Filter	274
Engine - Exhaust Manifold Rg38044	164	Cooling System ROPS	276
Engine - Thermostat And Water Filter Rg38044	166	Cooling System - Radiator Assembly ROPS	278
Engine - Water Pump Rg38044	168	Cooling System Without Air Conditioning	280
Engine - Crankshaft Pulley Rg38044	170	Cooling System - Radiator Assembly Without Air Conditioning	284
Engine - Flywheel Rg38044	172	Cooling System With Air Conditioning	286
Engine - Flywheel Housing Rg38044	174	Cooling System - Radiator Assembly With Air Conditioning	290
Engine - Oil Pan Rg38044	176	Cooling System ROPS	292
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38044	178	Cooling System - Radiator Assembly ROPS	296
Engine - Oil Pump Rg38044	180	Cooling System Without Air Conditioning	298
Engine - Fuel System Rg38044	182	Cooling System - Radiator Assembly Without Air Conditioning	302
Engine - Fuel Lift Pump Rg38044	186	Cooling System With Air Conditioning	304
Engine - Filter With Fuel Separator Up To Serial Number Tba	188	Cooling System - Radiator Assembly With Air Conditioning	308
Engine - Filter With Fuel Separator From Serial Number Tba	190	Torque Converter	310
Engine - Alternator And Mounting Rg38044	192	Drive Line Bolting	312
Engine - Glow Plugs Rg38044	194	Drive Line Bolting	316
Engine - Engine Lifting Rg38044	196	Transmission - Drive Shaft 4 Wheel Drive	320
Engine - Plug And Blank-Off Plug Rg38044	198	Transmission - Oil Filler 4 Wheel Drive	322
Engine - Joints And Gaskets Rg38044	200	Transmission - Oil Filler 4 Wheel Drive	324
Engine - Joints And Gaskets Rg38044	202	Transmission - Oil Filter 4 Wheel Drive	326
Engine - Engine Installation Tier 3	204	Transmission - Charging Pump 4 Wheel Drive	328
Engine - Cylinder Block Tier 3	206	Transmission - Oil Strainer 4 Wheel Drive	330
Engine - Pistons And Crankshaft Tier 3	208	Transmission - Housing 4 Wheel Drive	332
Engine - Cylinder Head Tier 3	210	Transmission - Input Shaft 4 Wheel Drive	336
Engine - Rockers And Camshaft Tier 3	212	Transmission - Reverse / First Shaft 4 Wheel Drive	340
Engine - Timing Case Tier 3	214	Transmission - Second Shaft 4 Wheel Drive	342
Engine - Lubricating Oil Filler And Breather Tier 3	216	Transmission - 4 Wheel Drive Shaft 4 Wheel Drive	346
Engine - Turbocharger Connections Tier 3	220	Transmission - Fork And Gearshift Rails 4 Wheel Drive	348
Engine - Exhaust Manifold Tier 3	222	Transmission - Control Valve 4 Wheel Drive	350
Engine - Thermostat And Water Pipes Tier 3	224	Transmission - Control Valve 4 Wheel Drive	354
Engine - Water Pump Tier 3	226	Transmission - Solenoid Valve 4 Wheel Drive	358
Engine - Crankshaft Pulley Tier 3	228	Consumable	360
Engine - Flywheel Tier 3	230	Consumables	362
Engine - Flywheel Housing Tier 3	232	Consumable	366
Engine - Oil Pan Tier 3	234	Consumable	368
Engine - Oil Filter And Integral Oil Cooler Tier 3	236	Consumable	370
Engine - Oil Pump Tier 3	238	Consumable	372

Consumable	374	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	490
Consumable	376	Torque Converter - Hydraulic Lines	492
Consumable	378	Main Hydraulics - Hydraulic Lines Synchro Shuttle	494
Consumable	380	Main Hydraulics - Hydraulic Lines Synchro Shuttle	498
Consumable	382	Main Hydraulics - Oil Filter Synchro Shuttle	502
Consumable	384	Main Hydraulics - Solenoid Valve Synchro Shuttle	504
Gear Change - Control Lever 4 Speed	386	Hydraulic Reservoir Synchro Shuttle	506
Gear Change - Control Lever 3 Speed	388	Main Hydraulics - Tandem Pump Synchro Shuttle	508
Rear Axle 2 Wheel Steer	390	Control Box - Installation From Serial Number Tba	510
Rear Axle 2 Wheel Steer	392	Control Box Control Pedals	512
Rear Axle 2 Wheel Steer	394	Control Box Hydraulics	516
Rear Axle 2 Wheel Steer	396	Control Box Brake Cylinder	518
Rear Axle 2 Wheel Steer	398	Control Box Steering	520
Rear Axle 2 Wheel Steer	400	Throttle Controls	522
Rear Axle 2 Wheel Steer	402	Throttle Controls Lever, Control	524
Rear Axle 2 Wheel Steer	404	Tool Kit - Wheel Brace + Grease Gun	526
Rear Axle 2 Wheel Steer	406	Service Brake - Brake Circuit From Serial Number Tba	528
Rear Axle - Brake Caliper	408	Service Brake - Brake Circuit From Serial Number Tba	530
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	410	Differential Lock Synchro Shuttle	532
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	414	Parking Brake	534
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	416	Parking Brake 4 Post ROPS	536
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	418	Cab - 4 Post ROPS	538
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	420	Cab - Rear Worklight	540
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	422	Cab - Relay Bracket	542
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	424	Cab - Frame	544
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	426	Cab - Door	548
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	428	Cab - Rear Window	554
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	430	Cab - Outer Roof	558
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	434	Cab - Front Worklight	562
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	436	Cab - Rear Worklight	564
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	438	Cab - Inner Roof	566
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	440	Cab - Frame	568
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	442	Cab - Door	572
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	444	Cab - Rear Window	578
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	446	Cab - Outer Roof	582
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	448	Cab - Inner Roof	586
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	450	Cab Trim - Windscreen Wiper	588
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	456	Cab - Front Worklight	590
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	458	Cab - Rear Worklight	592
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	460	Cab Trim - Heater	594
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	462	Cab Trim - Console	596
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	464	Cab Trim - Console RH	598
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	466	Cab Side Console - Fuse & Relay Board	600
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	468	Cab Trim - Cab Mounting	604
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	470	Cab Trim - Floorplate	606
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	472	Cab Trim - Console	608
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	476	Cab Trim - Windscreen Wiper	610
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	478	Cab Trim - Cab Mounting 4 Post ROPS	612
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	480	Cab Trim - Floorplate 4 Post ROPS	614
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	482	Cab Trim - Mats	616
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	484	Cab Trim - Mats	618
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	486	Not Serviced	620
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	488	Cab Environment - Heater Installation Front	622

Cab Environment - Heater Installation Rear	626	Battery - Single From Serial Number H200 4 2919	746
Cab Environment - Heater Unit	628	Battery - Dual From Serial Number H200 4 2919	748
Cab Environment - Air Conditioning Installation	630	Battery - Single Tier 3	750
Cab Environment - Heater Installation Front	634	Battery - Dual Tier 3	752
Cab Environment - Air Conditioning Installation Rear	638	Rear Lighting - Sideshift	754
Cab Environment - Air Conditioning Unit	640	Rear Lighting - Centremount	756
Cab Environment - Less Heater Unit ROPS	644	Rear Lighting - ROPS	758
Front Console - Installation ROPS	646	Rear Lighting - ROPS 4 Post ROPS	760
Front Console ROPS	648	Front Lighting - Headlights Left Hand Dip	762
Front Console - Instrument Panel ROPS	650	Front Lighting - Headlights Right Hand Dip	764
Front Console - Forward/Reverse Switch ROPS	652	Mirrors - Cab	766
Front Console - Installation ROPS	654	Mirrors - ROPS 4 Post ROPS	768
Front Console ROPS	656	Seat - Seat Installation Fabric Trim - Cab Machines	770
Front Console - Instrument Panel ROPS	658	Seat - Fabric Trim Cab	772
Front Console - Forward/Reverse Switch ROPS	660	Seat - Seat Installation Air Suspension	774
Front Console - Installation Cab	662	Seat - Fabric Trim Air Suspension	776
Front Console Cab	664	Seat - Seat Installation Weatherproof P.V.C. Trim	778
Front Console - Instrument Panel Cab	666	Seat - Weatherproof P.V.C. Trim 4 Post ROPS	780
Front Console - Forward/Reverse Switch Cab	668	Seat - Weatherproof P.V.C. Trim Air Suspension	782
Front Console - Installation Cab	670	Seat - Seat Installation Air Suspension	784
Front Console Cab	672	Front Fenders 2 Wheel Steer	790
Front Console - Instrument Panel Cab	674	Ride Control - Hydraulic Circuit English	792
Front Console - Forward/Reverse Switch Cab	676	Ride Control - Hydraulic Circuit English	794
Front Console - Installation ROPS	678	Ride Control - Hydraulic Circuit Less Ride Control	796
Front Console ROPS	680	Ride Control - Hydraulic Circuit French	798
Front Console - Instrument Panel ROPS	682	Ride Control - Hydraulic Circuit French	800
Front Console - Forward/Reverse Switch ROPS	684	Ride Control - Hydraulic Circuit German	802
Front Console - Installation ROPS	686	Ride Control - Hydraulic Circuit German	804
Front Console ROPS	688	Ride Control - Hydraulic Circuit Italian	806
Front Console - Instrument Panel ROPS	690	Ride Control - Hydraulic Circuit Italian	808
Front Console - Forward/Reverse Switch ROPS	692	Ride Control - Hydraulic Circuit Spanish	810
Front Console - Installation Cab	694	Ride Control - Hydraulic Circuit Spanish	812
Front Console Cab	696	Ride Control - Hydraulic Circuit Dutch	814
Front Console - Instrument Panel Cab	698	Ride Control - Hydraulic Circuit Dutch	816
Front Console - Forward/Reverse Switch Cab	700	Ride Control - Hydraulic Circuit Danish	818
Front Console - Installation Cab	702	Ride Control - Hydraulic Circuit Danish	820
Front Console Cab	704	Ride Control - Hydraulic Circuit	822
Front Console - Instrument Panel Cab	706	Ride Control - Hydraulic Circuit Solenoid Valve	824
Front Console - Forward/Reverse Switch Cab	708	Ride Control - Hydraulic Circuit	826
Side Console Switchpack	710	Ride Control - Hydraulic Circuit Solenoid Valve	828
Side Console - Instrument Panel Switchpack	714	Ride Control - Hydraulic Circuit ROPS	830
Side Console - Fuse & Relay Board	716	Ride Control - Hydraulic Circuit Solenoid Valve	832
Side Console Switchpack	718	Ride Control - Hydraulic Circuit ROPS	834
Side Console - Instrument Panel Switchpack	722	Ride Control - Hydraulic Circuit Solenoid Valve	836
Side Console - Fuse & Relay Board	724	Loader - Arms Yellow	838
Side Console 4 Post ROPS	726	Loader - Links Yellow	842
Side Console - Instrument Panel Rocker Switch	730	Loader - Return To Dig Mechanical	844
Side Console - Fuse & Relay Board	732	Loader - Return To Dig Mechanical	848
Side Console Switchpack	734	Loader - Safety Strut	852
Side Console - Instrument Panel Switchpack	736	Loader - Arms White	854
Side Console Switchpack	738	Loader - Links White	858
Side Console - Instrument Panel Switchpack	740	Loader - Return To Dig Mechanical	860
Chassis Electrics Synchro Shuttle - Carraro	742	Loader - Return To Dig Mechanical	864

Loader - Safety Strut	868	Loader Controls Lower Control Levers	1002
Loader Bucket - Standard For Use With Forks	870	Loader Controls Control Valve	1006
Loader Bucket - Standard For Use With Forks	872	Loader Controls - Hydraulic Valve Inlet	1008
Loader Bucket - 7 In 1	874	Loader Controls - Hydraulic Valve Loader Arm Section	1010
Loader Bucket - 7 In 1 Bucket Pipework	876	Loader Controls - Hydraulic Valve Standard Bucket Section	1012
Loader Bucket - 7 In 1 Cylinder	878	Loader Controls - Hydraulic Valve Standard Bucket Section	1014
Loader Bucket - 7 In 1	880	Loader Controls - Hydraulic Valve Standard Bucket Section	1016
Loader Bucket - 7 In 1 Bucket Pipework	882	Loader Controls Upper Control Levers	1018
Loader Bucket - 7 In 1 Cylinder	884	Loader Controls Lower Control Levers	1022
Loader Bucket Less Bucket	886	Loader Controls Control Valve	1026
Loader Hydraulics - Lift Cylinder High Specification	888	Loader Controls - Hydraulic Valve Inlet	1028
Loader Hydraulics - Lift Cylinder High Specification Pacoma	892	Loader Controls - Hydraulic Valve Loader Arm Section	1030
Loader Hydraulics - Lift Cylinder High Specification Wipro	894	Loader Controls - Hydraulic Valve Standard Bucket Section	1032
Loader Hydraulics - Bucket Cylinder High Specification	896	Loader Controls - Hydraulic Valve Standard Bucket Section	1034
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	900	Loader Controls - Hydraulic Valve Standard Bucket Section	1036
Loader Hydraulics - Bucket Cylinder High Specification Wipro	902	Loader Controls Upper Control Levers	1038
Loader Hydraulics - Lift Cylinder High Specification	904	Loader Controls Lower Control Levers	1040
Loader Hydraulics - Lift Cylinder High Specification Pacoma	908	Loader Controls Control Valve	1044
Loader Hydraulics - Lift Cylinder High Specification Wipro	910	Loader Controls - Hydraulic Valve Inlet	1046
Loader Hydraulics - Bucket Cylinder High Specification	912	Loader Controls - Hydraulic Valve Loader Arm Section	1048
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	916	Loader Controls - Hydraulic Valve Standard Bucket Section	1050
Loader Hydraulics - Bucket Cylinder High Specification Wipro	918	Loader Controls - Hydraulic Valve Standard Bucket Section	1052
Loader Hydraulics - Lift Cylinder High Specification	920	Loader Controls - Hydraulic Valve Standard Bucket Section	1054
Loader Hydraulics - Lift Cylinder High Specification Pacoma	924	Loader Controls Upper Control Levers	1056
Loader Hydraulics - Lift Cylinder High Specification Wipro	926	Loader Controls Lower Control Levers	1058
Loader Hydraulics - Bucket Cylinder Standard Specification	928	Loader Controls Control Valve	1062
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	930	Loader Controls - Hydraulic Valve Inlet	1064
Loader Hydraulics - Bucket Cylinder High Specification Wipro	932	Loader Controls - Hydraulic Valve Loader Arm Section	1066
Loader Hydraulics - Lift Cylinder High Specification	934	Loader Controls - Hydraulic Valve Standard Bucket Section	1068
Loader Hydraulics - Lift Cylinder High Specification Pacoma	938	Loader Controls - Hydraulic Valve Standard Bucket Section	1070
Loader Hydraulics - Lift Cylinder High Specification Wipro	940	Loader Controls - Hydraulic Valve Standard Bucket Section	1072
Loader Hydraulics - Bucket Cylinder High Specification	942	Loader Controls - Upper Control Levers 7 In 1 Bucket	1074
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	946	Loader Controls - Lower Control Levers 7 In 1 Bucket	1078
Loader Hydraulics - Bucket Cylinder High Specification Wipro	948	Loader Controls - Control Valve 7 In 1 Bucket	1082
Loader Hydraulics - Lift Cylinder High Specification	950	Loader Controls - Hydraulic Valve Inlet	1084
Loader Hydraulics - Lift Cylinder High Specification Pacoma	954	Loader Controls - Hydraulic Valve Loader Arm Section	1086
Loader Hydraulics - Lift Cylinder High Specification Wipro	956	Loader Controls - Hydraulic Valve Standard Bucket Section	1092
Loader Hydraulics - Bucket Cylinder High Specification	958	Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1098
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	962	Loader Controls - Hydraulic Valve Outlet	1104
Loader Hydraulics - Bucket Cylinder High Specification Wipro	964	Loader Controls - Upper Control Levers	1106
Loader Hydraulics - Lift Cylinder High Specification	966	Loader Controls - Lower Control Levers	1108
Loader Hydraulics - Lift Cylinder High Specification Pacoma	970	Loader Controls - Control Valve	1112
Loader Hydraulics - Lift Cylinder High Specification Wipro	972	Loader Controls - Hydraulic Valve Inlet	1114
Loader Hydraulics - Bucket Cylinder High Specification	974	Loader Controls - Hydraulic Valve Loader Arm Section	1116
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	978	Loader Controls - Hydraulic Valve Standard Bucket Section	1122
Loader Hydraulics - Bucket Cylinder High Specification Wipro	980	Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1128
Hose Burst Kit Loader Arm Cylinder	982	Loader Controls - Hydraulic Valve Outlet	1134
Hose Burst Kit Loader Bucket Cylinder	986	Loader Controls Upper Control Levers	1136
Hose Burst Kit Boom Cylinder	990	Loader Controls Lower Control Levers	1138
Hose Burst Kit Dipper Cylinder	992	Loader Controls Control Valve	1142
Hose Burst Kit Boom Cylinder	994	Loader Controls - Hydraulic Valve Inlet	1144
Hose Burst Kit Dipper Cylinder	996	Loader Controls - Hydraulic Valve Loader Arm Section	1146
Loader Controls Upper Control Levers	998	Loader Controls - Hydraulic Valve Standard Bucket Section	1148

Loader Controls - Hydraulic Valve Standard Bucket Section	1150	Dipper - Extendahoe Cylinder	1284
Loader Controls - Hydraulic Valve Standard Bucket Section	1152	Dipper - Standard Jcb Bucket	1286
Loader Controls Upper Control Levers	1154	Dipper - Standard Jcb Bucket	1288
Loader Controls Lower Control Levers	1158	Dipper - Extendahoe Jcb Bucket	1290
Loader Controls Control Valve	1162	Dipper - Extendahoe Cylinder	1296
Loader Controls - Hydraulic Valve Inlet	1164	Dipper - Extendahoe Jcb Bucket	1298
Loader Controls - Hydraulic Valve Loader Arm Section	1166	Dipper - Extendahoe Cylinder	1304
Loader Controls - Hydraulic Valve Standard Bucket Section	1168	Digger Bucket Linkage	1306
Loader Controls - Hydraulic Valve Standard Bucket Section	1170	Digger Bucket Linkage	1308
Loader Controls - Hydraulic Valve Standard Bucket Section	1172	Digger Bucket Linkage - Jcb Buckets	1310
Loader Controls Upper Control Levers	1174	Digger Bucket Linkage - Jcb Buckets	1312
Loader Controls Lower Control Levers	1176	Digger Bucket Linkage - Case Buckets	1314
Loader Controls Control Valve	1180	Digger Bucket Linkage - Case Buckets	1316
Loader Controls - Hydraulic Valve Inlet	1182	Digger Hydraulics - Sideshift Bucket	1318
Loader Controls - Hydraulic Valve Loader Arm Section	1184	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1322
Loader Controls - Hydraulic Valve Standard Bucket Section	1186	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1324
Loader Controls - Hydraulic Valve Standard Bucket Section	1188	Digger Hydraulics - Sideshift Standard Dipper	1326
Loader Controls - Hydraulic Valve Standard Bucket Section	1190	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1328
Loader Controls Upper Control Levers	1192	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1330
Loader Controls Lower Control Levers	1196	Digger Hydraulics - Sideshift Boom	1332
Loader Controls Control Valve	1200	Digger Hydraulics - Sideshift Boom Cylinder Pacoma	1334
Loader Controls - Hydraulic Valve Inlet	1202	Digger Hydraulics - Sideshift Boom Cylinder Wipro	1336
Loader Controls - Hydraulic Valve Loader Arm Section	1204	Digger Hydraulics - Sideshift Swing Components	1338
Loader Controls - Hydraulic Valve Standard Bucket Section	1206	Digger Hydraulics - Sideshift Clamp	1340
Loader Controls - Hydraulic Valve Standard Bucket Section	1208	Digger Hydraulics - Sideshift Attachment	1342
Loader Controls - Hydraulic Valve Standard Bucket Section	1210	Digger Hydraulics - Sideshift Attachment	1346
Boom Transport Lock Sideshift Digger	1212	Digger Hydraulics - Sideshift Bucket	1350
Boom Transport Lock Centre Mounted Digger	1214	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1354
Digger Stabilisers - Sideshift Hydraulic Installation	1216	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1356
Digger Stabilisers - Sideshift Mechanical Installation	1218	Digger Hydraulics - Sideshift Telescopic Dipper	1358
Digger Stabilisers - Sideshift Hydraulic Installation	1220	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1360
Digger Stabilisers - Sideshift Stabilizer Cylinder	1222	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1362
Digger Stabilisers - Sideshift Stabilizer Cylinder	1224	Digger Hydraulics - Sideshift Boom	1364
Digger Stabilisers - Sideshift Lock-Out Valve	1226	Digger Hydraulics - Sideshift Boom Cylinder Pacoma	1366
Digger Swing Pivot - Sideshift	1228	Digger Hydraulics - Sideshift Boom Cylinder Wipro	1368
Digger Swing Pivot - Sideshift Swing Cylinder Pacoma	1232	Digger Hydraulics - Sideshift Swing Components	1370
Digger Swing Pivot - Sideshift Swing Cylinder Wipro	1234	Digger Hydraulics - Sideshift Clamp	1372
Digger Swing Pivot - Centremount	1236	Digger Hydraulics - Sideshift Attachment	1374
Digger Swing Pivot - Centremount Swing Cylinder Pacoma	1238	Digger Hydraulics - Sideshift Attachment	1378
Digger Swing Pivot - Centremount Swing Cylinder Wipro	1240	Digger Hydraulics - Sideshift Bucket	1382
Boom	1242	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1386
Boom	1244	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1388
Dipper - Standard	1246	Digger Hydraulics - Sideshift Standard Dipper	1390
Dipper - Standard	1248	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1392
Dipper - Extendahoe	1250	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1394
Dipper - Extendahoe Cylinder	1256	Digger Hydraulics - Sideshift Boom	1396
Dipper - Extendahoe	1258	Digger Hydraulics - Sideshift Boom Cylinder Pacoma	1398
Dipper - Extendahoe Cylinder	1264	Digger Hydraulics - Sideshift Boom Cylinder Wipro	1400
Dipper - Standard Case Bucket	1266	Digger Hydraulics - Sideshift Swing Components	1402
Dipper - Standard Case Bucket	1268	Digger Hydraulics - Sideshift Clamp	1404
Dipper - Extendahoe Case Bucket	1270	Digger Hydraulics - Sideshift Attachment	1406
Dipper - Extendahoe Cylinder	1276	Digger Hydraulics - Sideshift Attachment	1410
Dipper - Extendahoe Case Bucket	1278	Digger Hydraulics - Sideshift Bucket	1414

Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1418
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1420
Digger Hydraulics - Sideshift Telescopic Dipper	1422
Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1424
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1426
Digger Hydraulics - Sideshift Boom	1428
Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1430
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1432
Digger Hydraulics - Sideshift Swing Components	1434
Digger Hydraulics - Sideshift Clamp	1436
Digger Hydraulics - Sideshift Attachment	1438
Digger Hydraulics - Sideshift Attachment	1442
Digger Hydraulics - Centremount Bucket	1446
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1450
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1452
Digger Hydraulics - Centremount Standard Dipper	1454
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1456
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1458
Digger Hydraulics - Centremount Boom 4.5m	1460
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1462
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1464
Digger Hydraulics - Centremount Swing Components	1466
Digger Hydraulics - Centremount Bucket	1468
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1472
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1474
Digger Hydraulics - Centremount Telescopic Dipper	1476
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1478
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1480
Digger Hydraulics - Centremount Boom 4.5m	1482
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1484
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1486
Digger Hydraulics - Centremount Swing Components	1488
Digger Hydraulics - Centremount Bucket	1490
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1494
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1496
Digger Hydraulics - Centremount Standard Dipper	1498
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1500
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1502
Digger Hydraulics - Centremount Boom	1504
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1506
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1508
Digger Hydraulics - Centremount Swing Components	1510
Digger Hydraulics - Centremount Bucket	1512
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1516
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1518
Digger Hydraulics - Centremount Telescopic Dipper	1520
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1522
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1524
Digger Hydraulics - Centremount Boom	1526
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1528
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1530
Digger Hydraulics - Centremount Swing Components	1532
Digger Hydraulics - Centremount Bucket	1534

Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1538
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1540
Digger Hydraulics - Centremount Standard Dipper	1542
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1544
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1546
Digger Hydraulics - Centremount Boom 4.5m	1548
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1550
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1552
Digger Hydraulics - Centremount Swing Components	1554
Digger Hydraulics - Centremount Bucket	1556
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1560
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1562
Digger Hydraulics - Centremount Telescopic Dipper	1564
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1566
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1568
Digger Hydraulics - Centremount Boom 4.5m	1570
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1572
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1574
Digger Hydraulics - Centremount Swing Components	1576
Digger Hydraulics - Centremount Bucket	1578
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1582
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1584
Digger Hydraulics - Centremount Standard Dipper	1586
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1588
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1590
Digger Hydraulics - Centremount Boom	1592
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1594
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1596
Digger Hydraulics - Centremount Swing Components	1598
Digger Hydraulics - Centremount Bucket	1600
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1604
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1606
Digger Hydraulics - Centremount Telescopic Dipper	1608
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1610
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1612
Digger Hydraulics - Centremount Boom	1614
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1616
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1618
Digger Hydraulics - Centremount Swing Components	1620
Digger Controls - Servo Pivot	1622
Digger Controls - Servo Control Bar	1624
Digger Controls - Servo Pilot Control	1626
Digger Controls - Servo Joystick	1628
Digger Controls - Servo Trim	1630
Digger Controls - Servo Change Over Valve	1632
Digger Controls - Servo Decals	1636
Digger Controls - Servo Pivot	1638
Digger Controls - Servo Control Bar	1640
Digger Controls - Servo Pilot Control	1642
Digger Controls - Servo Joystick	1644
Digger Controls - Servo Trim	1646
Digger Controls - Servo Change Over Valve	1648
Digger Controls - Servo Decals	1652


Extendahoe Hydraulics - Sideshift Without Auxiliary Hydraulics	1654	Digger Bucket - Premium	1784
Extendahoe Hydraulics - Sideshift Control Pedal	1656	Digger Bucket - Premium	1786
Extendahoe Hydraulics - Sideshift With Auxiliary Hydraulics	1658	Digger Bucket - Premium	1788
Extendahoe Hydraulics - Sideshift Control Pedal	1660	Digger Bucket - Ditch Maintenance	1790
Extendahoe Hydraulics - Centremount Without Auxiliary Hydraulics	1662	Digger Bucket - Ditch Maintenance	1792
Extendahoe Hydraulics - Centremount Control Pedal	1664	Digger Bucket - Ditch Digging	1794
Extendahoe Hydraulics - Centremount Without Auxiliary Hydraulics	1666	Digger Bucket - Jcb	1796
Extendahoe Hydraulics - Centremount Control Pedal	1668	Digger Bucket - Jcb	1798
Extendahoe Hydraulics - Centremount With Auxiliary Hydraulics	1670	Digger Bucket - Jcb	1800
Extendahoe Hydraulics - Centremount Control Pedal	1672	Digger Bucket - Jcb	1802
Extendahoe Hydraulics - Centremount With Auxiliary Hydraulics	1674	Digger Bucket - Jcb	1804
Extendahoe Hydraulics - Centremount Control Pedal	1676	Digger Bucket - Ditch Maintenance Jcb Bucket	1806
Extendahoe Hydraulics Less Control Pedal	1678	Digger Bucket - Ditch Maintenance Jcb Bucket	1808
Extendahoe Hydraulics Control Pedal	1680	Not Serviced	1810
Not Serviced	1682	Rear Fenders 2 Wheel Steer	1812
Stabiliser Controls - Sideshift Digger	1684	Rear Fenders - Sideshift Mudguard	1814
Stabiliser Controls - Sideshift Digger	1688	Rear Fenders 2 Wheel Steer	1816
Stabiliser Controls - Centremount Digger	1690	Rear Fenders 2 Wheel Steer	1818
Stabiliser Controls - Centremount Digger	1694	Rear Fenders 2 Wheel Steer	1820
Stabiliser Controls - Centremount Digger ROPS	1696	Rear Fenders - Sideshift Mudguard	1822
Auxiliary Hydraulics - Sideshift Telescopic Dipper	1700	Rear Fenders 4 Post ROPS	1824
Auxiliary Hydraulics - Sideshift Telescopic Dipper	1704	Rear Fenders 4 Post ROPS	1826
Auxiliary Hydraulics - Sideshift Standard Dipper	1710	Rear Fenders 2 Wheel Steer	1830
Auxiliary Hydraulics - Sideshift Standard Dipper	1714	Decals - Warnings General Markets	1832
Auxiliary Hydraulics - Sideshift Control Pedal	1718	Decals - Instructions General Markets	1834
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1720	Decals - Miscellaneous General Markets	1836
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1722	Decals - Warnings French	1838
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1726	Decals - Instructions French	1840
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1728	Decals - Miscellaneous French	1842
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1732	Decals - Warnings German	1844
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	1734	Decals - Instructions German	1846
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1738	Decals - Miscellaneous German	1848
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1740	Decals - Warnings Italian	1850
Auxiliary Hydraulics - Centremount Standard Dipper	1744	Decals - Instructions Italian	1852
Auxiliary Hydraulics - Centremount Standard Dipper	1746	Decals - Miscellaneous Italian	1854
Auxiliary Hydraulics - Centremount Control Pedal	1748	Decals - Warnings	1856
Auxiliary Hydraulics - Centremount Standard Dipper	1750	Decals - Instructions	1858
Auxiliary Hydraulics - Centremount Standard Dipper	1752	Decals - Miscellaneous	1860
Auxiliary Hydraulics - Centremount Control Pedal	1754	Decals - Warnings General Markets	1862
Not Serviced	1756	Decals - Instructions General Markets	1864
Digger Bucket - Standard	1758	Decals - Miscellaneous General Markets	1866
Digger Bucket - Standard	1760	Decals - Warnings Austria	1868
Digger Bucket - Standard	1762	Decals - Instructions Austria	1870
Digger Bucket - Standard	1764	Decals - Miscellaneous Austria	1872
Digger Bucket - Standard 305 Mm	1766	Decals - Warnings	1874
Digger Bucket - Ditch Cleaning	1768	Decals - Instructions	1876
Digger Bucket - Ditch Cleaning	1770	Decals - Miscellaneous	1878
Digger Bucket - Gannon 12 In	1772	Decals - Warnings	1880
Digger Bucket - Gannon 18 In	1774	Decals - Instructions	1882
Digger Bucket - Gannon 24 In	1776	Decals - Miscellaneous	1884
Not Serviced	1778	Decals - Warnings	1886
Digger Bucket - Premium	1780	Decals - Instructions	1888
Digger Bucket - Premium	1782	Decals - Miscellaneous	1890

Decals - Warnings	1892	Not Serviced	1998
Decals - Instructions	1894	Not Serviced	2000
Decals - Miscellaneous	1896	Digger Craning Eye Kit Sideshift Digger	2002
Decals - Warnings North America	1898	Digger Craning Eye Kit Centre Mounted Digger	2004
Decals - Instructions North America	1900	Digger Craning Eye Kit Sideshift Digger	2006
Decals - Miscellaneous North America	1902	Digger Craning Eye Kit Centre Mounted Digger	2008
Decals - Warnings General Markets	1904	Craning Valve Kit Cab	2010
Decals - Instructions General Markets	1906	Craning Valve Kit 4 Post ROPS	2014
Decals - Miscellaneous General Markets	1908	Front Counterweight Kit	2018
Decals - Warnings General Markets	1910	Fuel Strainer Kit	2020
Decals - Instructions General Markets	1912	Not Serviced	2022
Decals - Miscellaneous General Markets	1914	Anti Vandal Kit	2024
Decals - Warnings Costa Rica	1916	Street Pads Kit Sideshift Digger	2026
Decals - Instructions Costa Rica	1918	Service Tool Kit	2028
Decals - Miscellaneous Costa Rica	1920	Rotating Beacon Kit Single	2030
Decals - Warnings Costa Rica	1922	Rotating Beacon Kit Double	2032
Decals - Instructions Costa Rica	1924	Worklight Kit	2034
Decals - Miscellaneous Costa Rica	1926	Seat Armrest Kit	2036
Decals - Warnings	1928	Kit - Headrest	2038
Decals - Instructions	1930	Steering Wheel Spinner Knob Kit	2040
Decals - Miscellaneous	1932	Bucket Blade Kit Narrow	2042
Decals - Warnings	1934	Bucket Blade Kit Wide	2044
Decals - Instructions	1936	Bucket Tooth Kit Loader Bucket, 7-In-1	2046
Decals - Miscellaneous	1938	Hose Burst Kit - Quick Attach Boom Cylinder	2048
Decals - Warnings	1940	Hose Burst Kit - Quick Attach Boom Cylinder	2052
Decals - Instructions	1942	Hose Bust Kit - Less Quick Attach Boom Cylinder	2056
Decals - Miscellaneous	1944	Hose Bust Kit - Less Quick Attach Boom Cylinder	2060
Kit - Forks Loader Bucket	1946	Hose Bust Kit - Less Quick Attach Boom Cylinder	2064
Kit - Forks Loader Bucket	1948	Hose Burst Kit - Quick Attach Boom Cylinder	2066
Kit - Loader Quick Attach Pins	1950	Hose Burst Kit - Quick Attach Boom Cylinder	2070
Kit - Loader Quick Attach Tubes	1952	Hose Bust Kit - Less Quick Attach Boom Cylinder	2074
Kit - Loader Quick Attach	1954	Hose Bust Kit - Less Quick Attach Boom Cylinder	2078
Quick Attach, Loader	1956	Hose Bust Kit - Less Quick Attach Boom Cylinder	2082
Tooth Guard Kit - With Decal Loader Bucket, 7-In-1	1958	Literature Operator Manual - English	2084
Tooth Guard Kit - With Decal Loader Bucket, 7-In-1	1960	Literature Operator Manual - Spanish	2086
Tooth Guard Kit - With Decal Standard Loader Bucket	1962	Literature Operator Manual - French	2088
Tooth Guard Kit - With Decal Standard Loader Bucket	1964	Literature Operator Manual - German	2090
Transport Height Decal Kit	1966	Literature Operator Manual - Danish	2092
Position Indicator - Loader Arm	1968	Rockguard Kit	2094
Headlamp Extension	1970	Spare Wheels - Rear (M07, M10 & M12)	2096
Digger Stabilisers - Safety Kit	1972	Spare Wheels - Rear (M05, M09, M14 & M21)	2098
Transport Lock - Loader	1974	Spare Wheels - Rear (M03 & M13)	2100
Decals - Craning Valve Kit	1976	Spare Wheels - Rear (M01 & M04)	2102
Seat Belt Kit	1978	Spare Wheels - Rear (M20)	2104
Fan Guard Without Air Conditioning	1980	Spare Wheels - Rear (M22)	2106
Fan Guard With Air Conditioning	1982	Spare Wheels - Rear (M07, M10 & M12)	2108
Reverse Alarm	1984	Spare Wheels - Rear (M05, M09, M14 & M21)	2110
Kit - Boom Guard	1986	Spare Wheels - Rear (M03 & M13)	2112
Bucket Pins Kit Single	1988	Spare Wheels - Rear (M01 & M04)	2114
Bucket Pins Kit Double	1990	Spare Wheels - Rear (M20)	2116
Jcb Bucket Pins Kit Single	1992	Spare Wheels - Rear (M22)	2118
Jcb Bucket Pins Kit Double	1994	Spare Wheels - Rear (M23a & M28a)	2120
Bucket Pins Kit Loader	1996	Spare Wheels - Rear (M23a & M28a)	2122

Spare Wheels - Rear (M24a)	2124	Quick Attach, Digger - Centremount Standard Dipper	2234
Spare Wheels - Rear (M24a)	2126	Quick Attach, Digger - Centremount Standard Dipper	2236
Spare Wheels - Rear (M25a & M29a)	2128	Quick Attach, Digger - Centremount Solenoid Valve	2238
Spare Wheels - Rear (M25a & M29a)	2130	Quick Attach, Digger - Centremount Telescopic Dipper	2240
Stepguards	2132	Quick Attach, Digger - Centremount Telescopic Dipper	2242
Spare Wheel - Front - White	2134	Quick Attach, Digger - Centremount Solenoid Valve	2244
Spare Wheel - Front - Yellow	2136	Quick Attach, Digger - Centremount Telescopic Dipper	2246
Spare Wheel - Front - White	2138	Quick Attach, Digger - Centremount Telescopic Dipper	2248
Spare Wheel - Front - Yellow	2140	Quick Attach, Digger - Centremount Solenoid Valve	2250
Spare Wheel - Front - White	2142	Quick Attach, Digger - Abiljo	2252
Spare Wheel - Front - Yellow	2144	Not Serviced	2254
Bucket Pins Kit Case Bucket	2146	Quick Attach, Digger - Sideshift Standard Dipper	2256
Street Pads Kit Sideshift Digger	2148	Quick Attach, Digger - Sideshift Solenoid Valve	2258
Service Kit - Tier 3 Engine Upgrade	2150	Quick Attach, Digger - Sideshift Standard Dipper	2260
Quick Attach, Digger - Sideshift Standard Dipper	2156	Quick Attach, Digger - Sideshift Quick Coupler	2262
Quick Attach, Digger - Sideshift Standard Dipper	2158	Quick Attach, Digger - Sideshift Telescopic Dipper	2264
Quick Attach, Digger - Sideshift Solenoid Valve	2160	Quick Attach, Digger - Sideshift Telescopic Dipper	2266
Quick Attach, Digger - Sideshift Quick Coupler	2162	Quick Attach, Digger - Sideshift Solenoid Valve	2268
Quick Attach, Digger - Sideshift Standard Dipper	2164	Quick Attach, Digger - Sideshift Quick Coupler	2270
Quick Attach, Digger - Sideshift Standard Dipper	2166	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2272
Quick Attach, Digger - Sideshift Solenoid Valve	2168	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2274
Quick Attach, Digger - Sideshift Telescopic Dipper	2170	Quick Attach, Digger - Centremount Solenoid Valve	2276
Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2172	Quick Attach, Digger - Centremount Quick Coupler	2278
Quick Attach, Digger - Sideshift Solenoid Valve	2174	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2280
Quick Attach, Digger - Sideshift Quick Coupler	2176	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2282
Quick Attach, Digger - Sideshift Telescopic Dipper	2178	Quick Attach, Digger - Centremount Solenoid Valve	2284
Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2180	Quick Attach, Digger - Centremount Quick Coupler	2286
Quick Attach, Digger - Sideshift Solenoid Valve	2182	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2288
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2184	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2290
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2186	Quick Attach, Digger - Centremount Solenoid Valve	2292
Quick Attach, Digger - Centremount Solenoid Valve	2188	Quick Attach, Digger - Centremount Quick Coupler	2294
Quick Attach, Digger - Centremount Quick Coupler	2190	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2296
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2192	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2298
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2194	Quick Attach, Digger - Centremount Solenoid Valve	2300
Quick Attach, Digger - Centremount Solenoid Valve	2196	Quick Attach, Digger - Centremount Quick Coupler	2302
Quick Attach, Digger - Centremount Quick Coupler	2198	Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2304
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2200	Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2306
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2202	Quick Attach, Digger - Sideshift Solenoid Valve	2308
Quick Attach, Digger - Centremount Solenoid Valve	2204	Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2310
Quick Attach, Digger - Centremount Quick Coupler	2206	Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2312
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2208	Quick Attach, Digger - Sideshift Solenoid Valve	2314
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2210	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2316
Quick Attach, Digger - Centremount Solenoid Valve	2212	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2318
Quick Attach, Digger - Centremount Quick Coupler	2214	Quick Attach, Digger - Centremount Solenoid Valve	2320
Quick Attach, Digger - Sideshift Standard Dipper	2216	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m - Less Q/A	2322
Quick Attach, Digger - Sideshift Standard Dipper	2218	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m - Less Q/A	2324
Quick Attach, Digger - Sideshift Solenoid Valve	2220	Quick Attach, Digger - Centremount Solenoid Valve	2326
Quick Attach, Digger - Sideshift Telescopic Dipper	2222	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2328
Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2224	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2330
Quick Attach, Digger - Sideshift Solenoid Valve	2226	Quick Attach, Digger - Centremount Solenoid Valve	2332
Quick Attach, Digger - Centremount Standard Dipper	2228	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m - Less Q/A	2334
Quick Attach, Digger - Centremount Standard Dipper	2230	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m - Less Q/A	2336
Quick Attach, Digger - Centremount Solenoid Valve	2232	Quick Attach, Digger - Centremount Solenoid Valve	2338

Quick Attach - Miller Mechanical2340


C-10010-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6112048M91	1	Chassis Complete 2ws Short Ss	Chassis	Fahrgestell	Chasis	Ref. 1
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	




C-10010-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D'Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10010c03.1 1 10010c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D'Arrêt	Sicherungsring	Anillo De Resorte	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	






Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3622129M94GY02	2	Cylinder Stab Ss Only (Benford Grey)	L 'Hie Hydraulique	Zylinder Hydr.	Gato, Conj.	Tba [10010c02.1 4]
2	3623297M92	1	Barrel Assy	Cylindre De Vérin	Zylinderrohr	Cilindro De Gato	
3	1607690M1	1	Lock Nut M30	Ecrou Frein	Kontermutter	Tuerca	
4	3487067M1	1	Piston Guide Ring 70*10*2	Bague D'Étanchéité	Dichtungsring	Anillo, Estanqueidad	
5	3485241M1	1	Wear Ring Piston	Anneau	Ring	Aro	
6	3485254M1	1	Ring Pressure	Anneau	Ring	Aro	
7	3487067M1	1	Piston Guide Ring 70*10*2	Bague D'Étanchéité	Dichtungsring	Anillo, Estanqueidad	
8	3623299M1	1	Piston	Piston	Kolben	Pistón De Gato	
9	359181X1	1	O-Ring (44.04 Mm Nominal I/D) Shore A90	Joint Torique	O - Ring	Junta De Tipo O	
10	359187X1	1	O-Ring-63,09*3,53	Joint Torique	O Ring	Junta De Tipo O	
11	1884170M1	1	Backring-64.06*3*02	Contre-Joint	Stützring	Contrajunta	
12	3487205M1	1	O Ring, Hydr. Cylinder	Joint Torique	O Ring	Junta De Tipo O	
13	3623298M1	1	Bearing Cylinder	Roulement	Lager	Palier De Gato	
14	3443386M1	1	Retaining Plug	Bouchon	Stopfen	Tapón	
15	3491486M1	1	Bush, Piston Rod/Gland	Douille	Büchse	Anillo	
16	3443341M1	1	Ring Buffer	Bague D'Étanchéité	Dichtungsring	Anillo, Estanqueidad	
17	1606464M1	1	Seal	Joint D 'Arbre	Wellendichtring	Junta	
18	1606575M1	1	Wiper Ring	Anneau	Ring	Junta Raspador	
19	3441606M91	1	Piston Rod Assy	Tige De Vérin	Kolbenstange	Vástago Cilindro	
20	3623300M91	1	Kit Seal	Jeu Étanchéité	Dichtringsatz	Juego De Juntas	




C-10010-03.2-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6111068M91GY03	2	Cylinder Stabiliser S/S	Cylindre	Zylinder	Gato, Conj.	Tba [10010c02.1 4]
2	6194596M91	1	Barrel - Cylinder	Corps Cylindre	Zylindergehäuse	Tubo	
3	6194600M1	1	Nut - Nylloc	Ecrou Blocage	Flachmutter	Tuerca	
4	6194606M1	1	Bearing - Piston	Coussinet	Lager	Teniendo - Pistón	
5	6194604M1	1	Seal - Piston	Joint Étanchéité	Dichtring	Junta	
6	6194605M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
7	6194598M1	1	Piston	Piston	Kolben	Pistón	
8	6194607M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
9	6194601M1	1	Stop Tube	Tube Butee	Rohr Anschlag	Pare - Tubo	
10	6194613M1	1	Ring - Back Up	Contre Bague	Stutzring	ContraJunta	
11	6194612M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
12	6194602M1	1	Bush - Bimetal	Douille	Büchse	Juego De Anillos	
13	6194599M1	1	End Cover - Head	Couvercle	Deckel	Tapa	
14	6194609M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
15	6194608M1	1	Seal - Rod (Primary)	Joint Étanchéité	Dichtring	Junta	
16	6194610M1	1	Seal- Rod (Secondary)	Joint Étanchéité	Dichtring	Junta	
17	6194611M1	1	Wiper	Essuyeur	Wischer	Raspador, Escobilla	
18	6194603M1	1	Ring - Snap	Fermeoir	Sprengring	Anillo De Resorte	
19	6194597M91	1	Rod - Piston	Bielle De Piston	Pleuelstange	Rod - Pistón	
20	6194614M91	0	Seal Kit	Jeu Etancheite	Dichtringsatz	Juego De Juntas	




C-10013-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6110037M93	1	Chassis - Centremount (W/Assy) Short	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passstift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	




C-10019-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6112381M91	1	Chassis Complete 2ws Short Ss	Chassis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	6112725M1	1	Seal - Cooling Pack - Short Drop Chassis	Joint	Dichtung	Junta	Tier 3 Only




C-10019-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D'Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10019c03.1 1 10019c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D'Arrêt	Sicherungsring	Anillo De Resorte	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D'Usure	Verschleißkissen	Patín De Desgaste	
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	






Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3622129M94GY02	2	Cylinder Stab Ss Only (Benford Grey)	L 'Hie Hydraulique	Zylinder Hydr.	Gato, Conj.	Tba [10019c02.1 4]
2	3623297M92	1	Barrel Assy	Cylindre De Vérin	Zylinderrohr	Cilindro De Gato	
3	1607690M1	1	Lock Nut M30	Ecrou Frein	Kontermutter	Tuerca	
4	3487067M1	1	Piston Guide Ring 70*10*2	Bague D'Étanchéité	Dichtungsring	Anillo, Estanqueidad	
5	3485241M1	1	Wear Ring Piston	Anneau	Ring	Aro	
6	3485254M1	1	Ring Pressure	Anneau	Ring	Aro	
7	3487067M1	1	Piston Guide Ring 70*10*2	Bague D'Étanchéité	Dichtungsring	Anillo, Estanqueidad	
8	3623299M1	1	Piston	Piston	Kolben	Pistón De Gato	
9	359181X1	1	O-Ring (44.04 Mm Nominal I/D) Shore A90	Joint Torique	O - Ring	Junta De Tipo O	
10	359187X1	1	O-Ring-63,09*3,53	Joint Torique	O Ring	Junta De Tipo O	
11	1884170M1	1	Backring-64.06*3*02	Contre-Joint	Stützring	Contrajunta	
12	3487205M1	1	O Ring, Hydr. Cylinder	Joint Torique	O Ring	Junta De Tipo O	
13	3623298M1	1	Bearing Cylinder	Roulement	Lager	Palier De Gato	
14	3443386M1	1	Retaining Plug	Bouchon	Stopfen	Tapón	
15	3491486M1	1	Bush, Piston Rod/Gland	Douille	Büchse	Anillo	
16	3443341M1	1	Ring Buffer	Bague D'Étanchéité	Dichtungsring	Anillo, Estanqueidad	
17	1606464M1	1	Seal	Joint D 'Arbre	Wellendichtring	Junta	
18	1606575M1	1	Wiper Ring	Anneau	Ring	Junta Raspador	
19	3441606M91	1	Piston Rod Assy	Tige De Vérin	Kolbenstange	Vástago Cilindro	
20	3623300M91	1	Kit Seal	Jeu Étanchéité	Dichtringsatz	Juego De Juntas	



C-10019-03.2-A



Sample of manual. Download All 2343 pages at:

<https://www.arepairmanual.com/downloads/2010-terex-880sx-backhoe-loader-workshop-parts-manual/>