

Product: 2010 TEREX TX760B Backhoe Loader Workshop Parts Manual  
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-tx760b-backhoe-loader-workshop-parts-manual/>

# **SPARES**

# **BACKHOE LOADER**

# **TX760B**

Publication No.    August 2010

Product: 2010 TEREX TX760B Backhoe Loader Workshop Parts Manual  
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-tx760b-backhoe-loader-workshop-parts-manual/>

Sample of manual. Download All 2449 pages at:  
<https://www.arepairmanual.com/downloads/2010-terex-tx760b-backhoe-loader-workshop-parts-manual/>

# Contents

Chassis - Sideshift Long	12
Digger Stabilisers - Sideshift Mechanical Installation	14
Digger Stabilisers - Sideshift Stabilizer Cylinder	16
Digger Stabilisers - Sideshift Stabilizer Cylinder	18
Chassis - Centremount Short	20
Chassis - Centremount Long	22
Chassis - Sideshift Long	24
Digger Stabilisers - Sideshift Mechanical Installation	26
Digger Stabilisers - Sideshift Stabilizer Cylinder	28
Digger Stabilisers - Sideshift Stabilizer Cylinder	30
Chassis - Centremount Short	32
Chassis - Centremount Long	34
Engine Cover Yellow	36
Engine Cover White	40
Front Axle - Installation 2 Wheel Drive/2 Wheel Steer	44
Front Axle - Housing 2 Wheel Drive/2 Wheel Steer	46
Front Axle - Steering Pivot 2 Wheel Drive/2 Wheel Steer	48
Front Axle - Wheel Hub 2 Wheel Drive/2 Wheel Steer	50
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	52
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	54
Front Axle - Installation	56
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	58
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	60
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	62
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	64
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	66
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	68
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	70
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	72
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	74
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	76
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	78
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	80
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	82
Steering System 2 Wheel Steer	84
Front Wheels	86
Rear Wheels	88
Front Wheels	90
Rear Wheels	92
Rear Wheels	94
Front Wheels	96
Front Wheels	98
Rear Wheels	100
Front Wheels	102
Rear Wheels	104
Front Wheels	106
Rear Wheels	108
Front Wheels	110
Rear Wheels	112
Front Wheels	114
Rear Wheels	116
Front Wheels	118

Rear Wheels	120	Engine - Glow Plugs Rg38043	238
Front Wheels	122	Engine - Engine Lifting Rg38043	240
Rear Wheels	124	Engine - Plug And Blank-Off Plug Rg38043	242
Hardnose And Grille	126	Engine - Joints And Gaskets Rg38043	244
Engine - Engine Installation Rg38100	128	Engine - Joints And Gaskets Rg38043	246
Engine - Cylinder Block Rg38100	130	Engine - Engine Installation Tier 3	248
Engine - Pistons And Crankshaft Rg38100	132	Engine - Cylinder Block Tier 3	250
Engine - Cylinder Head Rg38100	136	Engine - Pistons And Crankshaft Tier 3	252
Engine - Rockers Rg38100	138	Engine - Cylinder Head Tier 3	254
Engine - Camshaft Rg38100	140	Engine - Rockers And Camshaft Tier 3	256
Engine - Lubricating Oil Filler And Breather Rg38100	142	Engine - Timing Case Tier 3	258
Engine - Turbocharger Connections Rg38100	146	Engine - Lubricating Oil Filler And Breather Tier 3	260
Engine - Exhaust Manifold Rg38100	148	Engine - Turbocharger Connections Tier 3	264
Engine - Thermostat And Water Filter Rg38100	150	Engine - Exhaust Manifold Tier 3	266
Engine - Water Pump Rg38100	152	Engine - Thermostat And Water Pipes Tier 3	268
Engine - Crankshaft Pulley Rg38100	154	Engine - Water Pump Tier 3	270
Engine - Flywheel Rg38100	156	Engine - Crankshaft Pulley Tier 3	272
Engine - Flywheel Housing Rg38100	158	Engine - Flywheel Tier 3	274
Engine - Oil Pan Rg38100	160	Engine - Flywheel Housing Tier 3	276
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38100	162	Engine - Oil Pan Tier 3	278
Engine - Oil Pump Rg38100	164	Engine - Oil Filter And Integral Oil Cooler Tier 3	280
Engine - Fuel System Rg38100	166	Engine - Oil Pump Tier 3	282
Engine - Fuel Lift Pump Rg38100	170	Engine - Fuel System Tier 3	284
Engine - Filter With Fuel Separator Up To Serial Number Tba	172	Engine - Fuel Lift Pump Tier 3	288
Engine - Filter With Fuel Separator From Serial Number Tba	174	Engine - Fuel Pipes Tier 3	290
Engine - Alternator And Mounting Rg38100	176	Engine - Filter With Fuel Separator Tier 3	292
Engine - Glow Plugs Rg38100	178	Engine - Alternator And Mounting Tier 3	294
Engine - Engine Lifting Rg38100	180	Engine - Fan Drive Tier 3	296
Engine - Plug And Blank-Off Plug Rg38100	182	Engine - Glow Plugs Tier 3	298
Engine - Joints And Gaskets Rg38100	184	Engine - Starter Motor Tier 3	300
Engine - Joints And Gaskets Rg38100	186	Engine - Plugs And Mounts Tier 3	302
Engine - Engine Installation Rg38043	188	Engine - Cylinder Head Auxiliaries Tier 3	304
Engine - Cylinder Block Rg38043	190	Fuel System Tier 3	306
Engine - Pistons And Crankshaft Rg38043	192	Fuel System - Fuel Tank Tier 3	308
Engine - Cylinder Head Rg38043	196	Exhaust System From Serial Number H200 7 1093	310
Engine - Rockers Rg38043	198	Induction System - Air Filtration	312
Engine - Camshaft Rg38043	200	Induction System - Air Filter	314
Engine - Lubricating Oil Filler And Breather Rg38043	202	Induction System - Air Filtration With Pre Cleaner	316
Engine - Turbocharger Connections Rg38043	206	Induction System - Air Filter	318
Engine - Exhaust Manifold Rg38043	208	Cooling System ROPS	320
Engine - Thermostat And Water Filter Rg38043	210	Cooling System - Radiator Assembly ROPS	322
Engine - Water Pump Rg38043	212	Cooling System Without Air Conditioning	324
Engine - Crankshaft Pulley Rg38043	214	Cooling System - Radiator Assembly Without Air Conditioning	328
Engine - Flywheel Rg38043	216	Cooling System With Air Conditioning	330
Engine - Flywheel Housing Rg38043	218	Cooling System - Radiator Assembly With Air Conditioning	334
Engine - Oil Pan Rg38043	220	Cooling System ROPS	336
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38043	222	Cooling System - Radiator Assembly ROPS	340
Engine - Oil Pump Rg38043	224	Cooling System Without Air Conditioning	342
Engine - Fuel System Rg38043	226	Cooling System - Radiator Assembly Without Air Conditioning	346
Engine - Fuel Lift Pump Rg38043	230	Cooling System With Air Conditioning	348
Engine - Filter With Fuel Separator Up To Serial Number Tba	232	Cooling System - Radiator Assembly With Air Conditioning	352
Engine - Filter With Fuel Separator From Serial Number Tba	234	Torque Converter	354
Engine - Alternator And Mounting Rg38043	236	Drive Line Bolting	356

Drive Line Bolting	360	Rear Axle - Centre Housing 2 Wheel Steer	494
Drive Line Bolting	364	Rear Axle - Wheel Hub 2 Wheel Steer	496
Transmission - Oil Filler 2 Wheel Drive	368	Rear Axle - Epicyclic Reduction Gear 2 Wheel Steer	498
Transmission - Drive Shaft 2 Wheel Drive	370	Rear Axle - Brakes 2 Wheel Steer	500
Transmission - Housing 2 Wheel Drive	372	Rear Axle - Brake Caliper	502
Transmission - Input Shaft 2 Wheel Drive	378	Rear Axle - Brake Caliper	504
Transmission - Reverse Idler Shaft 2 Wheel Drive	382	Rear Axle - Differential Bevel Gear - 2 Wheel Steer	506
Transmission - Main Shaft 2 Wheel Drive	384	Rear Axle - Differential 2 Wheel Steer	508
Transmission - Output Shaft 2 Wheel Drive	386	Rear Axle - Differential Lock Mechanism 2 Wheel Steer	510
Transmission - Drive Shaft 4 Wheel Drive	390	Rear Axle 2 Wheel Steer	512
Transmission - Oil Filler 4 Wheel Drive	392	Rear Axle 2 Wheel Steer	514
Transmission - Oil Filler 4 Wheel Drive	394	Rear Axle 2 Wheel Steer	516
Transmission - Oil Filter 4 Wheel Drive	396	Rear Axle 2 Wheel Steer	518
Transmission - Charging Pump 4 Wheel Drive	398	Rear Axle 2 Wheel Steer	520
Transmission - Oil Strainer 4 Wheel Drive	400	Rear Axle 2 Wheel Steer	522
Transmission - Housing 4 Wheel Drive	402	Rear Axle 2 Wheel Steer	524
Transmission - Input Shaft 4 Wheel Drive	406	Rear Axle 2 Wheel Steer	526
Transmission - Reverse / First Shaft 4 Wheel Drive	410	Rear Axle 2 Wheel Steer	528
Transmission - Second Shaft 4 Wheel Drive	412	Rear Axle - Brake Caliper	530
Transmission - 4 Wheel Drive Shaft 4 Wheel Drive	416	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	532
Transmission - Fork And Gearshift Rails 4 Wheel Drive	418	Hydraulic Valve - Backhoe Control Inlet	534
Transmission - Control Valve 4 Wheel Drive	420	Hydraulic Valve - Backhoe Control Slew	538
Transmission - Control Valve 4 Wheel Drive	424	Hydraulic Valve - Backhoe Control Boom	544
Transmission - Solenoid Valve 4 Wheel Drive	428	Hydraulic Valve - Backhoe Control Dipper	550
Transmission - Drive Shaft 2 Wheel Drive	430	Hydraulic Valve - Backhoe Control Bucket	556
Transmission - Oil Filler 2 Wheel Drive	432	Hydraulic Valve - Backhoe Control Stabilizer	562
Transmission - Oil Filter 2 Wheel Drive	434	Hydraulic Valve - Backhoe Control Auxiliary	566
Transmission - Charging Pump 2 Wheel Drive	436	Hydraulic Valve - Backhoe Control Outlet	572
Transmission - Oil Strainer 2 Wheel Drive	438	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	574
Transmission - Housing 2 Wheel Drive	440	Hydraulic Valve - Backhoe Control Inlet	576
Transmission - Input Shaft 2 Wheel Drive	442	Hydraulic Valve - Backhoe Control Slew	580
Transmission - Reverse / First Shaft 2 Wheel Drive	444	Hydraulic Valve - Backhoe Control Boom	586
Transmission - Second Shaft 2 Wheel Drive	446	Hydraulic Valve - Backhoe Control Dipper	592
Transmission - Fork And Gearshift Rails 2 Wheel Drive	450	Hydraulic Valve - Backhoe Control Bucket	598
Transmission - Control Valve 2 Wheel Drive	452	Hydraulic Valve - Backhoe Control Stabilizer	604
Consumable	456	Hydraulic Valve - Backhoe Control Auxiliary	608
Consumables	458	Hydraulic Valve - Backhoe Control Outlet	614
Consumable	462	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	616
Consumable	464	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	620
Consumable	466	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	622
Consumable	468	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	624
Consumable	470	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	626
Consumable	472	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	628
Consumable	474	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	630
Consumable	476	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	632
Consumable	478	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	634
Consumable	480	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	636
Gear Change - Control Lever 4 Speed	482	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	638
Gear Change - Control Lever 3 Speed	484	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	640
Gear Change - Control Lever 4 Speed	486	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	642
Gear Change - Control Lever 3 Speed	488	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	644
Rear Axle 2 Wheel Steer	490	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	646
Rear Axle - Housing 2 Wheel Steer	492	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	648

Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	650	Control Box Control Pedals	774
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	652	Control Box Hydraulics	778
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	654	Control Box Brake Cylinder	780
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	658	Control Box Steering	782
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	660	Throttle Controls	784
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	662	Throttle Controls Lever, Control	786
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	664	Tool Kit - Wheel Brace + Grease Gun	788
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	666	Service Brake - Brake Circuit From Serial Number Tba	790
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	668	Service Brake - Brake Circuit From Serial Number Tba	792
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	670	Service Brake - Brake Circuit From Serial Number Tba	794
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	672	Service Brake - Brake Circuit From Serial Number Tba	796
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	674	Differential Lock Synchro Shuttle	798
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	678	Differential Lock - Controls Solenoid Valve	800
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	680	Differential Lock Synchro Shuttle	802
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	682	Parking Brake	804
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	684	Parking Brake 4 Post ROPS	806
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	686	Cab - 4 Post ROPS	808
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	688	Cab - Rear Worklight	810
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	690	Cab - Relay Bracket	812
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	692	Cab - Frame	814
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	694	Cab - Door	818
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	700	Cab - Rear Window	824
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	702	Cab - Outer Roof	828
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	704	Cab - Front Worklight	832
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	706	Cab - Rear Worklight	834
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	708	Cab - Inner Roof	836
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	710	Cab - Frame	838
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	712	Cab - Door	842
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	714	Cab - Rear Window	848
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	716	Cab - Outer Roof	852
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	720	Cab - Inner Roof	856
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	722	Cab Trim - Windscreen Wiper	858
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	724	Cab - Front Worklight	860
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	726	Cab - Rear Worklight	862
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	728	Cab Trim - Heater	864
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	730	Cab Trim - Console	866
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	732	Cab Trim - Console RH	868
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	734	Cab Side Console - Fuse & Relay Board	870
Torque Converter - Hydraulic Lines	736	Cab Trim - Cab Mounting	874
Torque Converter - Hydraulic Lines	738	Cab Trim - Floorplate Cab	876
Main Hydraulics - Hydraulic Lines Synchro Shuttle	740	Cab Trim - Console	878
Main Hydraulics - Hydraulic Lines Synchro Shuttle	744	Cab Trim - Windscreen Wiper	880
Main Hydraulics - Oil Filter Synchro Shuttle	748	Cab Trim - Cab Mounting 4 Post ROPS	882
Main Hydraulics - Solenoid Valve Synchro Shuttle	750	Cab Trim - Floorplate 4 Post ROPS	884
Hydraulic Reservoir Synchro Shuttle	752	Cab Trim - Cab Mounting	886
Main Hydraulics - Tandem Pump Synchro Shuttle	754	Cab Trim - Floorplate	888
Main Hydraulics - Hydraulic Lines Synchro Shuttle	756	Cab Trim - Console	890
Main Hydraulics - Hydraulic Lines Synchro Shuttle	760	Cab Trim - Windscreen Wiper	892
Main Hydraulics - Oil Filter Synchro Shuttle	764	Cab Trim - Cab Mounting 4 Post ROPS	894
Main Hydraulics - Solenoid Valve Synchro Shuttle	766	Cab Trim - Floorplate 4 Post ROPS	896
Hydraulic Reservoir Synchro Shuttle	768	Cab Trim - Cab Mounting	898
Main Hydraulics - Tandem Pump Synchro Shuttle	770	Cab Trim - Floorplate & Digger Tower	900
Control Box - Installation From Serial Number Tba	772	Cab Trim - Mats	902

Cab Trim - Mats	904	Front Console - Forward/Reverse Switch Cab	1018
Not Serviced	906	Front Console - Installation Cab	1020
Cab Environment - Heater Installation Front	908	Front Console Cab	1022
Cab Environment - Heater Installation Rear	912	Front Console - Instrument Panel Cab	1024
Cab Environment - Heater Unit	914	Front Console - Forward/Reverse Switch Cab	1026
Cab Environment - Air Conditioning Installation	916	Side Console Switchpack	1028
Cab Environment - Heater Installation Front	920	Side Console - Instrument Panel Switchpack	1032
Cab Environment - Air Conditioning Installation Rear	924	Side Console - Fuse & Relay Board	1034
Cab Environment - Air Conditioning Unit	926	Side Console Switchpack	1036
Cab Environment - Less Heater Unit ROPS	930	Side Console - Instrument Panel Switchpack	1040
Front Console - Installation ROPS	932	Side Console - Fuse & Relay Board	1042
Front Console ROPS	934	Side Console 4 Post ROPS	1044
Front Console - Instrument Panel ROPS	936	Side Console - Instrument Panel Rocker Switch	1048
Front Console - Forward/Reverse Switch ROPS	938	Side Console - Fuse & Relay Board	1050
Front Console - Installation Cab	940	Side Console 4 Post ROPS	1052
Front Console Cab	942	Side Console - Instrument Panel Rocker Switch	1056
Front Console - Instrument Panel Cab	944	Side Console - Fuse & Relay Board	1058
Front Console - Forward/Reverse Switch Cab	946	Side Console Switchpack	1060
Front Console - Installation ROPS	948	Side Console - Instrument Panel Switchpack	1062
Front Console ROPS	950	Side Console Switchpack	1064
Front Console - Instrument Panel ROPS	952	Side Console - Instrument Panel Switchpack	1066
Front Console - Forward/Reverse Switch ROPS	954	Chassis Electrics	1068
Front Console - Installation ROPS	956	Chassis Electrics Synchro Shuttle - Carraro	1072
Front Console ROPS	958	Battery - Single From Serial Number H200 4 2919	1076
Front Console - Instrument Panel ROPS	960	Battery - Dual From Serial Number H200 4 2919	1078
Front Console - Forward/Reverse Switch ROPS	962	Battery - Single Tier 3	1080
Front Console - Installation Cab	964	Battery - Dual Tier 3	1082
Front Console Cab	966	Rear Lighting - Sideshift	1084
Front Console - Instrument Panel Cab	968	Rear Lighting - Centremount	1086
Front Console - Forward/Reverse Switch Cab	970	Rear Lighting - ROPS	1088
Front Console - Installation Cab	972	Rear Lighting - ROPS 4 Post ROPS	1090
Front Console Cab	974	Front Lighting - Headlights Left Hand Dip	1092
Front Console - Instrument Panel Cab	976	Front Lighting - Headlights Right Hand Dip	1094
Front Console - Forward/Reverse Switch Cab	978	Mirrors - Cab	1096
Front Console - Installation ROPS	980	Mirrors - ROPS 4 Post ROPS	1098
Front Console ROPS	982	Seat - Seat Installation Fabric Trim - Cab Machines	1100
Front Console - Instrument Panel ROPS	984	Seat - Fabric Trim Cab	1102
Front Console - Forward/Reverse Switch ROPS	986	Seat - Seat Installation Air Suspension	1104
Front Console - Installation ROPS	988	Seat - Fabric Trim Air Suspension	1106
Front Console ROPS	990	Seat - Seat Installation Weatherproof P.V.C. Trim	1108
Front Console - Instrument Panel ROPS	992	Seat - Weatherproof P.V.C. Trim 4 Post ROPS	1110
Front Console - Forward/Reverse Switch ROPS	994	Seat - Seat Installation Weatherproof P.V.C. Trim	1112
Front Console - Installation Cab	996	Seat - Weatherproof P.V.C. Trim 4 Post ROPS	1114
Front Console Cab	998	Seat - Weatherproof P.V.C. Trim Air Suspension	1116
Front Console - Instrument Panel Cab	1000	Seat - Seat Installation Air Suspension	1118
Front Console - Forward/Reverse Switch Cab	1002	Front Fenders 2 Wheel Steer	1124
Front Console - Installation ROPS	1004	Ride Control - Hydraulic Circuit English	1126
Front Console ROPS	1006	Ride Control - Hydraulic Circuit English	1128
Front Console - Instrument Panel ROPS	1008	Ride Control - Hydraulic Circuit Less Ride Control	1130
Front Console - Forward/Reverse Switch ROPS	1010	Ride Control - Hydraulic Circuit French	1132
Front Console - Installation Cab	1012	Ride Control - Hydraulic Circuit French	1134
Front Console Cab	1014	Ride Control - Hydraulic Circuit German	1136
Front Console - Instrument Panel Cab	1016	Ride Control - Hydraulic Circuit German	1138

Ride Control - Hydraulic Circuit Italian	1140	Loader Hydraulics - Bucket Cylinder Standard Specification	1272
Ride Control - Hydraulic Circuit Italian	1142	Loader Hydraulics - Bucket Cylinder Standard Specification	1274
Ride Control - Hydraulic Circuit Spanish	1144	Loader Hydraulics - Lift Cylinder Standard Specification	1276
Ride Control - Hydraulic Circuit Spanish	1146	Loader Hydraulics - Lift Cylinder Standard Specification	1280
Ride Control - Hydraulic Circuit Dutch	1148	Loader Hydraulics - Lift Cylinder Standard Specification	1282
Ride Control - Hydraulic Circuit Dutch	1150	Loader Hydraulics - Bucket Cylinder Standard Specification	1284
Ride Control - Hydraulic Circuit Danish	1152	Loader Hydraulics - Bucket Cylinder Standard Specification	1288
Ride Control - Hydraulic Circuit Danish	1154	Loader Hydraulics - Bucket Cylinder Standard Specification	1290
Ride Control - Hydraulic Circuit	1156	Loader Hydraulics - Lift Cylinder Standard Specification	1292
Ride Control - Hydraulic Circuit Solenoid Valve	1158	Loader Hydraulics - Lift Cylinder Standard Specification	1296
Ride Control - Hydraulic Circuit	1160	Loader Hydraulics - Lift Cylinder Standard Specification	1298
Ride Control - Hydraulic Circuit Solenoid Valve	1162	Loader Hydraulics - Bucket Cylinder Standard Specification	1300
Ride Control - Hydraulic Circuit ROPS	1164	Loader Hydraulics - Bucket Cylinder Standard Specification	1304
Ride Control - Hydraulic Circuit Solenoid Valve	1166	Loader Hydraulics - Bucket Cylinder Standard Specification	1306
Ride Control - Hydraulic Circuit ROPS	1168	Hose Burst Kit Loader Arm Cylinder	1308
Ride Control - Hydraulic Circuit Solenoid Valve	1170	Hose Burst Kit Loader Bucket Cylinder	1312
Loader - Arms Yellow	1172	Hose Burst Kit Boom Cylinder	1316
Loader - Links Yellow	1176	Hose Burst Kit Dipper Cylinder	1318
Loader - Return To Dig Mechanical	1178	Hose Burst Kit Boom Cylinder	1320
Loader - Return To Dig Mechanical	1182	Hose Burst Kit Dipper Cylinder	1322
Loader - Safety Strut	1186	Hose Burst Kit Boom Cylinder	1324
Loader - Arms White	1188	Hose Burst Kit Dipper Cylinder	1326
Loader - Links White	1192	Loader Controls Upper Control Levers	1328
Loader - Return To Dig Mechanical	1194	Loader Controls Lower Control Levers	1332
Loader - Return To Dig Mechanical	1198	Loader Controls Control Valve	1336
Loader - Safety Strut	1202	Loader Controls - Hydraulic Valve Inlet	1338
Loader Bucket - Standard For Use With Forks	1204	Loader Controls - Hydraulic Valve Loader Arm Section	1340
Loader Bucket - 7 In 1	1206	Loader Controls - Hydraulic Valve Standard Bucket Section	1342
Loader Bucket - 7 In 1 Bucket Pipework	1208	Loader Controls - Hydraulic Valve Standard Bucket Section	1344
Loader Bucket - 7 In 1 Cylinder	1210	Loader Controls - Hydraulic Valve Standard Bucket Section	1346
Loader Bucket Less Bucket	1212	Loader Controls Upper Control Levers	1348
Loader Hydraulics - Lift Cylinder Standard Specification	1214	Loader Controls Lower Control Levers	1352
Loader Hydraulics - Lift Cylinder Standard Specification	1218	Loader Controls Control Valve	1356
Loader Hydraulics - Lift Cylinder Standard Specification	1220	Loader Controls - Hydraulic Valve Inlet	1358
Loader Hydraulics - Bucket Cylinder Standard Specification	1222	Loader Controls - Hydraulic Valve Loader Arm Section	1360
Loader Hydraulics - Bucket Cylinder Standard Specification	1226	Loader Controls - Hydraulic Valve Standard Bucket Section	1362
Loader Hydraulics - Bucket Cylinder Standard Specification	1228	Loader Controls - Hydraulic Valve Standard Bucket Section	1364
Loader Hydraulics - Lift Cylinder Standard Specification	1230	Loader Controls - Hydraulic Valve Standard Bucket Section	1366
Loader Hydraulics - Lift Cylinder Standard Specification	1234	Loader Controls Upper Control Levers	1368
Loader Hydraulics - Lift Cylinder Standard Specification	1236	Loader Controls Lower Control Levers	1370
Loader Hydraulics - Bucket Cylinder Standard Specification	1238	Loader Controls Control Valve	1374
Loader Hydraulics - Bucket Cylinder Standard Specification	1242	Loader Controls - Hydraulic Valve Inlet	1376
Loader Hydraulics - Bucket Cylinder Standard Specification	1244	Loader Controls - Hydraulic Valve Loader Arm Section	1378
Loader Hydraulics - Lift Cylinder Standard Specification	1246	Loader Controls - Hydraulic Valve Standard Bucket Section	1380
Loader Hydraulics - Lift Cylinder Standard Specification	1250	Loader Controls - Hydraulic Valve Standard Bucket Section	1382
Loader Hydraulics - Lift Cylinder Standard Specification	1252	Loader Controls - Hydraulic Valve Standard Bucket Section	1384
Loader Hydraulics - Bucket Cylinder Standard Specification	1254	Loader Controls Upper Control Levers	1386
Loader Hydraulics - Bucket Cylinder Standard Specification	1256	Loader Controls Lower Control Levers	1388
Loader Hydraulics - Bucket Cylinder Standard Specification	1258	Loader Controls Control Valve	1392
Loader Hydraulics - Lift Cylinder Standard Specification	1260	Loader Controls - Hydraulic Valve Inlet	1394
Loader Hydraulics - Lift Cylinder Standard Specification	1264	Loader Controls - Hydraulic Valve Loader Arm Section	1396
Loader Hydraulics - Lift Cylinder Standard Specification	1266	Loader Controls - Hydraulic Valve Standard Bucket Section	1398
Loader Hydraulics - Bucket Cylinder Standard Specification	1268	Loader Controls - Hydraulic Valve Standard Bucket Section	1400

Loader Controls - Hydraulic Valve Standard Bucket Section	1402	Digger Stabilisers - Sideshift Hydraulic Installation	1554
Loader Controls - Upper Control Levers 7 In 1 Bucket	1404	Digger Stabilisers - Sideshift Stabilizer Cylinder	1556
Loader Controls - Lower Control Levers 7 In 1 Bucket	1408	Digger Stabilisers - Sideshift Stabilizer Cylinder	1558
Loader Controls - Control Valve 7 In 1 Bucket	1412	Digger Stabilisers - Sideshift Lock-Out Valve	1560
Loader Controls - Hydraulic Valve Inlet	1414	Not Serviced	1562
Loader Controls - Hydraulic Valve Loader Arm Section	1416	Digger Swing Pivot - Sideshift	1564
Loader Controls - Hydraulic Valve Standard Bucket Section	1422	Digger Swing Pivot - Sideshift Swing Cylinder Pacoma	1568
Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1428	Digger Swing Pivot - Sideshift Swing Cylinder Wipro	1570
Loader Controls - Hydraulic Valve Outlet	1434	Digger Swing Pivot - Centremount	1572
Loader Controls - Upper Control Levers	1436	Digger Swing Pivot - Centremount Swing Cylinder Pacoma	1574
Loader Controls - Lower Control Levers	1438	Digger Swing Pivot - Centremount Swing Cylinder Wipro	1576
Loader Controls - Control Valve	1442	Boom	1578
Loader Controls - Hydraulic Valve Inlet	1444	Not Serviced	1580
Loader Controls - Hydraulic Valve Loader Arm Section	1446	Dipper - Standard	1582
Loader Controls - Hydraulic Valve Standard Bucket Section	1452	Dipper - Standard	1584
Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1458	Dipper - Extendahoe	1586
Loader Controls - Hydraulic Valve Outlet	1464	Dipper - Extendahoe Cylinder	1592
Loader Controls Upper Control Levers	1466	Dipper - Extendahoe	1594
Loader Controls Lower Control Levers	1468	Dipper - Extendahoe Cylinder	1600
Loader Controls Control Valve	1472	Dipper - Standard Case Bucket	1602
Loader Controls - Hydraulic Valve Inlet	1474	Dipper - Standard Case Bucket	1604
Loader Controls - Hydraulic Valve Loader Arm Section	1476	Dipper - Extendahoe Case Bucket	1606
Loader Controls - Hydraulic Valve Standard Bucket Section	1478	Dipper - Extendahoe Cylinder	1612
Loader Controls - Hydraulic Valve Standard Bucket Section	1480	Dipper - Extendahoe Case Bucket	1614
Loader Controls - Hydraulic Valve Standard Bucket Section	1482	Dipper - Extendahoe Cylinder	1620
Loader Controls Upper Control Levers	1484	Dipper - Standard Jcb Bucket	1622
Loader Controls Lower Control Levers	1488	Dipper - Standard Jcb Bucket	1624
Loader Controls Control Valve	1492	Dipper - Extendahoe Jcb Bucket	1626
Loader Controls - Hydraulic Valve Inlet	1494	Dipper - Extendahoe Cylinder	1632
Loader Controls - Hydraulic Valve Loader Arm Section	1496	Dipper - Extendahoe Jcb Bucket	1634
Loader Controls - Hydraulic Valve Standard Bucket Section	1498	Dipper - Extendahoe Cylinder	1640
Loader Controls - Hydraulic Valve Standard Bucket Section	1500	Digger Bucket Linkage	1642
Loader Controls - Hydraulic Valve Standard Bucket Section	1502	Digger Bucket Linkage	1644
Loader Controls Upper Control Levers	1504	Digger Bucket Linkage - Jcb Buckets	1646
Loader Controls Lower Control Levers	1506	Digger Bucket Linkage - Jcb Buckets	1648
Loader Controls Control Valve	1510	Digger Bucket Linkage - Case Buckets	1650
Loader Controls - Hydraulic Valve Inlet	1512	Digger Bucket Linkage - Case Buckets	1652
Loader Controls - Hydraulic Valve Loader Arm Section	1514	Digger Hydraulics - Sideshift Bucket	1654
Loader Controls - Hydraulic Valve Standard Bucket Section	1516	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1658
Loader Controls - Hydraulic Valve Standard Bucket Section	1518	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1660
Loader Controls - Hydraulic Valve Standard Bucket Section	1520	Digger Hydraulics - Sideshift Standard Dipper	1662
Loader Controls Upper Control Levers	1522	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1664
Loader Controls Lower Control Levers	1526	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1666
Loader Controls Control Valve	1530	Digger Hydraulics - Sideshift Boom	1668
Loader Controls - Hydraulic Valve Inlet	1532	Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1670
Loader Controls - Hydraulic Valve Loader Arm Section	1534	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1672
Loader Controls - Hydraulic Valve Standard Bucket Section	1536	Digger Hydraulics - Sideshift Swing Components	1674
Loader Controls - Hydraulic Valve Standard Bucket Section	1538	Digger Hydraulics - Sideshift Clamp	1676
Loader Controls - Hydraulic Valve Standard Bucket Section	1540	Digger Hydraulics - Sideshift Attachment	1678
Boom Transport Lock Sideshift Digger	1546	Digger Hydraulics - Sideshift Attachment	1682
Boom Transport Lock Centre Mounted Digger	1548	Digger Hydraulics - Sideshift Bucket	1686
Digger Stabilisers - Sideshift Hydraulic Installation	1550	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1690
Digger Stabilisers - Sideshift Mechanical Installation	1552	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1692


Digger Hydraulics - Sideshift Telescopic Dipper	1694	Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1820
Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1696	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1822
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1698	Digger Hydraulics - Centremount Swing Components	1824
Digger Hydraulics - Sideshift Boom	1700	Digger Hydraulics - Centremount Bucket	1826
Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1702	Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1830
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1704	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1832
Digger Hydraulics - Sideshift Swing Components	1706	Digger Hydraulics - Centremount Standard Dipper	1834
Digger Hydraulics - Sideshift Clamp	1708	Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1836
Digger Hydraulics - Sideshift Attachment	1710	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1838
Digger Hydraulics - Sideshift Attachment	1714	Digger Hydraulics - Centremount Boom 4.5m	1840
Digger Hydraulics - Sideshift Bucket	1718	Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1842
Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1722	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1844
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1724	Digger Hydraulics - Centremount Swing Components	1846
Digger Hydraulics - Sideshift Standard Dipper	1726	Digger Hydraulics - Centremount Bucket	1848
Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1728	Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1852
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1730	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1854
Digger Hydraulics - Sideshift Boom	1732	Digger Hydraulics - Centremount Telescopic Dipper	1856
Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1734	Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1858
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1736	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1860
Digger Hydraulics - Sideshift Swing Components	1738	Digger Hydraulics - Centremount Boom 4.5m	1862
Digger Hydraulics - Sideshift Clamp	1740	Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1864
Digger Hydraulics - Sideshift Attachment	1742	Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1866
Digger Hydraulics - Sideshift Attachment	1746	Digger Hydraulics - Centremount Swing Components	1868
Digger Hydraulics - Sideshift Bucket	1750	Digger Controls Standard	1870
Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1754	Digger Controls ISO	1872
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1756	Digger Controls X Pattern	1876
Digger Hydraulics - Sideshift Telescopic Dipper	1758	Digger Controls - Servo Pivot	1878
Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1760	Digger Controls - Servo Control Bar	1880
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1762	Digger Controls - Servo Pilot Control	1882
Digger Hydraulics - Sideshift Boom	1764	Digger Controls - Servo Joystick	1884
Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1766	Digger Controls - Servo Trim	1886
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1768	Digger Controls - Servo Change Over Valve	1888
Digger Hydraulics - Sideshift Swing Components	1770	Digger Controls - Servo Decals	1892
Digger Hydraulics - Sideshift Clamp	1772	Digger Controls - Servo Pivot	1894
Digger Hydraulics - Sideshift Attachment	1774	Digger Controls - Servo Control Bar	1896
Digger Hydraulics - Sideshift Attachment	1778	Digger Controls - Servo Pilot Control	1898
Digger Hydraulics - Centremount Bucket	1782	Digger Controls - Servo Joystick	1900
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1786	Digger Controls - Servo Trim	1902
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1788	Digger Controls - Servo Change Over Valve	1904
Digger Hydraulics - Centremount Standard Dipper	1790	Digger Controls - Servo Decals	1908
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1792	Digger Controls ISO / Sae	1910
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1794	Extendahoe Hydraulics - Sideshift Without Auxiliary Hydraulics	1914
Digger Hydraulics - Centremount Boom 4.5m	1796	Extendahoe Hydraulics - Sideshift Control Pedal	1916
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1798	Extendahoe Hydraulics - Sideshift With Auxiliary Hydraulics	1918
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1800	Extendahoe Hydraulics - Sideshift Control Pedal	1920
Digger Hydraulics - Centremount Swing Components	1802	Extendahoe Hydraulics - Centremount Without Auxiliary Hydraulics	1922
Digger Hydraulics - Centremount Bucket	1804	Extendahoe Hydraulics - Centremount Control Pedal	1924
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1808	Extendahoe Hydraulics - Centremount With Auxiliary Hydraulics	1926
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1810	Extendahoe Hydraulics - Centremount Control Pedal	1928
Digger Hydraulics - Centremount Telescopic Dipper	1812	Extendahoe Hydraulics Less Control Pedal	1930
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1814	Extendahoe Hydraulics Control Pedal	1932
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1816	Not Serviced	1934
Digger Hydraulics - Centremount Boom 4.5m	1818	Stabiliser Controls - Sideshift Digger	1936

Stabiliser Controls - Sideshift Digger . . . . .	1940	Rear Fenders 2 Wheel Steer . . . . .	2076
Stabiliser Controls - Centremount Digger . . . . .	1942	Rear Fenders 2 Wheel Steer . . . . .	2078
Stabiliser Controls - Centremount Digger . . . . .	1946	Rear Fenders - Sideshift Mudguard . . . . .	2080
Stabiliser Controls - Centremount Digger 4 Post ROPS . . . . .	1948	Rear Fenders 4 Post ROPS . . . . .	2082
Stabiliser Controls - Sideshift Digger 4 Post ROPS . . . . .	1950	Rear Fenders 4 Post ROPS . . . . .	2084
Stabiliser Controls - Centremount Digger ROPS . . . . .	1952	Rear Fenders 2 Wheel Steer . . . . .	2088
Stabiliser Controls - Sideshift Digger ROPS . . . . .	1956	Decals - Machine Identity . . . . .	2090
Auxiliary Hydraulics - Sideshift Telescopic Dipper . . . . .	1960	Decals - Warnings General Markets . . . . .	2092
Auxiliary Hydraulics - Sideshift Telescopic Dipper . . . . .	1964	Decals - Instructions General Markets . . . . .	2094
Auxiliary Hydraulics - Sideshift Telescopic Dipper . . . . .	1970	Decals - Miscellaneous General Markets . . . . .	2096
Auxiliary Hydraulics - Sideshift Telescopic Dipper . . . . .	1974	Decals - Warnings General Markets . . . . .	2098
Auxiliary Hydraulics - Sideshift Telescopic Dipper . . . . .	1980	Decals - Instructions General Markets . . . . .	2100
Auxiliary Hydraulics - Sideshift Standard Dipper . . . . .	1986	Decals - Miscellaneous General Markets . . . . .	2102
Auxiliary Hydraulics - Sideshift Standard Dipper . . . . .	1990	Decals - Warnings North America . . . . .	2104
Auxiliary Hydraulics - Sideshift Control Pedal . . . . .	1994	Decals - Instructions North America . . . . .	2106
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m . . . . .	1996	Decals - Miscellaneous North America . . . . .	2108
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m . . . . .	1998	Decals - Warnings North America . . . . .	2110
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m . . . . .	2002	Decals - Instructions North America . . . . .	2112
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m . . . . .	2004	Decals - Miscellaneous North America . . . . .	2114
Auxiliary Hydraulics - Centremount Standard Dipper . . . . .	2008	Decals - Warnings General Markets . . . . .	2116
Auxiliary Hydraulics - Centremount Standard Dipper . . . . .	2010	Decals - Instructions General Markets . . . . .	2118
Auxiliary Hydraulics - Centremount Control Pedal . . . . .	2012	Decals - Miscellaneous General Markets . . . . .	2120
Not Serviced . . . . .	2014	Decals - Warnings Costa Rica . . . . .	2122
Digger Bucket - Standard . . . . .	2016	Decals - Instructions Costa Rica . . . . .	2124
Digger Bucket - Standard . . . . .	2018	Decals - Miscellaneous Costa Rica . . . . .	2126
Digger Bucket - Standard . . . . .	2020	Decals - Warnings Costa Rica . . . . .	2128
Digger Bucket - Standard . . . . .	2022	Decals - Instructions Costa Rica . . . . .	2130
Digger Bucket - Standard 305 Mm . . . . .	2024	Decals - Miscellaneous Costa Rica . . . . .	2132
Digger Bucket - Ditch Cleaning . . . . .	2026	Kit - Forks Loader Bucket . . . . .	2134
Digger Bucket - Ditch Cleaning . . . . .	2028	Kit - Loader Quick Attach Pins . . . . .	2136
Digger Bucket - Gannon 12 In . . . . .	2030	Kit - Loader Quick Attach Tubes . . . . .	2138
Digger Bucket - Gannon 18 In . . . . .	2032	Kit - Loader Quick Attach . . . . .	2140
Digger Bucket - Gannon 24 In . . . . .	2034	Quick Attach, Loader . . . . .	2142
Not Serviced . . . . .	2036	Tooth Guard Kit - With Decal Loader Bucket, 7-In-1 . . . . .	2144
Digger Bucket - Premium . . . . .	2038	Tooth Guard Kit - With Decal Standard Loader Bucket . . . . .	2146
Digger Bucket - Premium . . . . .	2040	Transport Height Decal Kit . . . . .	2148
Digger Bucket - Premium . . . . .	2042	Position Indicator - Loader Arm . . . . .	2150
Digger Bucket - Premium . . . . .	2044	Headlamp Extension . . . . .	2152
Digger Bucket - Premium . . . . .	2046	Digger Stabilisers - Safety Kit . . . . .	2154
Digger Bucket - Ditch Maintenance . . . . .	2048	Transport Lock - Loader . . . . .	2156
Digger Bucket - Ditch Maintenance . . . . .	2050	Decals - Craning Valve Kit . . . . .	2158
Digger Bucket - Ditch Digging . . . . .	2052	Seat Belt Kit . . . . .	2160
Digger Bucket - Jcb . . . . .	2054	Fan Guard Without Air Conditioning . . . . .	2162
Digger Bucket - Jcb . . . . .	2056	Fan Guard With Air Conditioning . . . . .	2164
Digger Bucket - Jcb . . . . .	2058	Reverse Alarm . . . . .	2166
Digger Bucket - Jcb . . . . .	2060	Kit - Boom Guard . . . . .	2168
Digger Bucket - Jcb . . . . .	2062	Bucket Pins Kit Single . . . . .	2170
Digger Bucket - Ditch Maintenance Jcb Bucket . . . . .	2064	Bucket Pins Kit Double . . . . .	2172
Digger Bucket - Ditch Maintenance Jcb Bucket . . . . .	2066	Jcb Bucket Pins Kit Single . . . . .	2174
Not Serviced . . . . .	2068	Jcb Bucket Pins Kit Double . . . . .	2176
Rear Fenders 2 Wheel Steer . . . . .	2070	Bucket Pins Kit Loader . . . . .	2178
Rear Fenders - Sideshift Mudguard . . . . .	2072	Not Serviced . . . . .	2180
Rear Fenders 2 Wheel Steer . . . . .	2074	Not Serviced . . . . .	2182

Digger Craning Eye Kit Sideshift Digger	2186	Spare Wheel - Front - Yellow	2304
Digger Craning Eye Kit Centre Mounted Digger	2188	Spare Wheel - Front - White	2306
Digger Craning Eye Kit Sideshift Digger	2190	Spare Wheel - Front - Yellow	2308
Digger Craning Eye Kit Centre Mounted Digger	2192	Bucket Pins Kit Case Bucket	2310
Craning Valve Kit Cab	2194	Street Pads Kit Sideshift Digger	2312
Craning Valve Kit 4 Post ROPS	2198	Quick Attach, Digger - Sideshift Standard Dipper	2318
Front Counterweight Kit	2202	Quick Attach, Digger - Sideshift Standard Dipper	2320
Fuel Strainer Kit	2204	Quick Attach, Digger - Sideshift Solenoid Valve	2322
Not Serviced	2206	Quick Attach, Digger - Sideshift Quick Coupler	2324
Anti Vandal Kit	2208	Quick Attach, Digger - Sideshift Standard Dipper	2326
Street Pads Kit Sideshift Digger	2210	Quick Attach, Digger - Sideshift Standard Dipper	2328
Service Tool Kit	2212	Quick Attach, Digger - Sideshift Solenoid Valve	2330
Rotating Beacon Kit Single	2214	Quick Attach, Digger - Sideshift Telescopic Dipper	2332
Rotating Beacon Kit Double	2216	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2334
Worklight Kit	2218	Quick Attach, Digger - Sideshift Solenoid Valve	2336
Seat Armrest Kit	2220	Quick Attach, Digger - Sideshift Quick Coupler	2338
Kit - Headrest	2222	Quick Attach, Digger - Sideshift Telescopic Dipper	2340
Steering Wheel Spinner Knob Kit	2224	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2342
Bucket Blade Kit Narrow	2226	Quick Attach, Digger - Sideshift Solenoid Valve	2344
Bucket Tooth Kit Loader Bucket, 7-In-1	2228	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2346
Hose Burst Kit - Quick Attach Boom Cylinder	2230	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2348
Hose Burst Kit - Quick Attach Boom Cylinder	2234	Quick Attach, Digger - Centremount Solenoid Valve	2350
Hose Bust Kit - Less Quick Attach Boom Cylinder	2238	Quick Attach, Digger - Centremount Quick Coupler	2352
Hose Bust Kit - Less Quick Attach Boom Cylinder	2242	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2354
Hose Bust Kit - Less Quick Attach Boom Cylinder	2246	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2356
Literature Operator Manual - English	2248	Quick Attach, Digger - Centremount Solenoid Valve	2358
Literature Operator Manual - Spanish	2250	Quick Attach, Digger - Centremount Quick Coupler	2360
Literature Operator Manual - French	2252	Quick Attach, Digger - Sideshift Standard Dipper	2362
Literature Operator Manual - German	2254	Quick Attach, Digger - Sideshift Standard Dipper	2364
Literature Operator Manual - Danish	2256	Quick Attach, Digger - Sideshift Solenoid Valve	2366
Rockguard Kit	2258	Quick Attach, Digger - Sideshift Telescopic Dipper	2368
Spare Wheels - Rear (M27a)	2260	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2370
Spare Wheels - Rear (M02, M06, M08 & M11)	2262	Quick Attach, Digger - Sideshift Solenoid Valve	2372
Spare Wheels - Rear (M07, M10 & M12)	2264	Quick Attach, Digger - Centremount Standard Dipper	2374
Spare Wheels - Rear (M05, M09, M14 & M21)	2266	Quick Attach, Digger - Centremount Standard Dipper	2376
Spare Wheels - Rear (M03 & M13)	2268	Quick Attach, Digger - Centremount Solenoid Valve	2378
Spare Wheels - Rear (M01 & M04)	2270	Quick Attach, Digger - Centremount Telescopic Dipper	2380
Spare Wheels - Rear (M02, M06, M08 & M11)	2272	Quick Attach, Digger - Centremount Telescopic Dipper	2382
Spare Wheels - Rear (M07, M10 & M12)	2274	Quick Attach, Digger - Centremount Solenoid Valve	2384
Spare Wheels - Rear (M05, M09, M14 & M21)	2276	Quick Attach, Digger - Abiljo	2386
Spare Wheels - Rear (M03 & M13)	2278	Not Serviced	2388
Spare Wheels - Rear (M01 & M04)	2280	Quick Attach, Digger - Sideshift Standard Dipper	2390
Spare Wheels - Rear (M23a & M28a)	2282	Quick Attach, Digger - Sideshift Solenoid Valve	2392
Spare Wheels - Rear (M23a & M28a)	2284	Quick Attach, Digger - Sideshift Standard Dipper	2394
Spare Wheels - Rear (M24a)	2286	Quick Attach, Digger - Sideshift Quick Coupler	2396
Spare Wheels - Rear (M24a)	2288	Quick Attach, Digger - Sideshift Telescopic Dipper	2398
Spare Wheels - Rear (M25a & M29a)	2290	Quick Attach, Digger - Sideshift Telescopic Dipper	2400
Spare Wheels - Rear (M25a & M29a)	2292	Quick Attach, Digger - Sideshift Solenoid Valve	2402
Spare Wheels - Rear (M27a)	2294	Quick Attach, Digger - Sideshift Quick Coupler	2404
Stepguards	2296	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2406
Spare Wheel - Front - White	2298	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2408
Spare Wheel - Front - Yellow	2300	Quick Attach, Digger - Centremount Solenoid Valve	2410
Spare Wheel - Front - White	2302	Quick Attach, Digger - Centremount Quick Coupler	2412

Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2414
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2416
Quick Attach, Digger - Centremount Solenoid Valve	2418
Quick Attach, Digger - Centremount Quick Coupler	2420
Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2422
Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2424
Quick Attach, Digger - Sideshift Solenoid Valve	2426
Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2428
Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2430
Quick Attach, Digger - Sideshift Solenoid Valve	2432
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2434
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2436
Quick Attach, Digger - Centremount Solenoid Valve	2438
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2440
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2442
Quick Attach, Digger - Centremount Solenoid Valve	2444
Quick Attach - Miller Mechanical	2446


C-10011-01.1-B



<b>Item</b>	<b>Part No.</b>	<b>Qty.</b>	<b>English</b>	<b>French</b>	<b>German</b>	<b>Spanish</b>	<b>Remarks</b>
1	6112049M91	1	Chassis Complete 2ws Long Ss	Chassis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	




C-10011-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10011c03.1 1 10011c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	






Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3622129M94GY02	2	Cylinder Stab Ss Only (Benford Grey)	L´Hie Hydraulique	Zylinder Hydr.	Gato, Conj.	Tba [10011c02.1 4]
2	3623297M92	1	Barrel Assy	Cylindre De Vérin	Zylinderrohr	Cilindro De Gato	
3	1607690M1	1	Lock Nut M30	Ecrou Frein	Kontermutter	Tuerca	
4	3487067M1	1	Piston Guide Ring 70*10*2	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
5	3485241M1	1	Wear Ring Piston	Anneau	Ring	Aro	
6	3485254M1	1	Ring Pressure	Anneau	Ring	Aro	
7	3487067M1	1	Piston Guide Ring 70*10*2	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
8	3623299M1	1	Piston	Piston	Kolben	Pistón De Gato	
9	359181X1	1	O-Ring (44.04 Mm Nominal I/D) Shore A90	Joint Torique	O - Ring	Junta De Tipo O	
10	359187X1	1	O-Ring-63,09*3,53	Joint Torique	O Ring	Junta De Tipo O	
11	1884170M1	1	Backring-64.06*3*02	Contre-Joint	Stützring	ContraJunta	
12	3487205M1	1	O Ring, Hydr. Cylinder	Joint Torique	O Ring	Junta De Tipo O	
13	3623298M1	1	Bearing Cylinder	Roulement	Lager	Palier De Gato	
14	3443386M1	1	Retaining Plug	Bouchon	Stopfen	Tapón	
15	3491486M1	1	Bush, Piston Rod/Gland	Douille	Büchse	Anillo	
16	3443341M1	1	Ring Buffer	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
17	1606464M1	1	Seal	Joint D´Arbre	Wellendichtring	Junta	
18	1606575M1	1	Wiper Ring	Anneau	Ring	Junta Raspador	
19	3441606M91	1	Piston Rod Assy	Tige De Vérin	Kolbenstange	Vástago Cilindro	
20	3623300M91	1	Kit Seal	Jeu Étanchéité	Dichtringsatz	Juego De Juntas	




C-10011-03.2-A




Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6111068M91GY03	2	Cylinder Stabiliser S/S	Cylindre	Zylinder	Gato, Conj.	Tba [10011c02.1 4]
2	6194596M91	1	Barrel - Cylinder	Corps Cylindre	Zylindergehause	Tubo	
3	6194600M1	1	Nut - Nyloc	Ecrou Blocage	Flachmutter	Tuerca	
4	6194606M1	1	Bearing - Piston	Coussinet	Lager	Teniendo - Pistón	
5	6194604M1	1	Seal - Piston	Joint Étanchéité	Dichtring	Junta	
6	6194605M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
7	6194598M1	1	Piston	Piston	Kolben	Pistón	
8	6194607M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
9	6194601M1	1	Stop Tube	Tube Butee	Rohr Anschlag	Pare - Tubo	
10	6194613M1	1	Ring - Back Up	Contre Bague	Stutzring	ContraJunta	
11	6194612M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
12	6194602M1	1	Bush - Bimetal	Douille	Büchse	Juego De Anillos	
13	6194599M1	1	End Cover - Head	Couvercle	Deckel	Tapa	
14	6194609M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
15	6194608M1	1	Seal - Rod (Primary)	Joint Étanchéité	Dichtring	Junta	
16	6194610M1	1	Seal- Rod (Secondary)	Joint Étanchéité	Dichtring	Junta	
17	6194611M1	1	Wiper	Essuyeur	Wischer	Raspador, Escobilla	
18	6194603M1	1	Ring - Snap	Fermeoir	Sprengring	Anillo De Resorte	
19	6194597M91	1	Rod - Piston	Bielle De Piston	Pleuelstange	Rod - Pistón	
20	6194614M91	0	Seal Kit	Jeu Etancheite	Dichtringsatz	Juego De Juntas	

C-10013-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6110037M93	1	Chassis - Centremount (W/Assy) Short	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passstift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	


C-10014-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6110038M94	1	Chassis - Centremount (W/Assy) Long	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passtift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	




C-10020-01.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6112382M91	1	Chassis Complete 2ws Long Ss	Chassis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	6112726M1	1	Seal - Cooling Pack - Long Drop Chassis	Joint	Dichtung	Junta	Tier 3 Only



C-10020-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10020c03.1 1 10020c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	



# Digger Stabilisers - Sideshift Stabilizer Cylinder


4067 10020

Product: 2010 TEREX TX760B Backhoe Loader Workshop Parts Manual

Full Download: <https://www.arepairmanual.com/downloads/2010-terex-tx760b-backhoe-loader-workshop-parts-manual/>

[ckhoe-loader-workshop-parts-manual/](https://www.arepairmanual.com/downloads/2010-terex-tx760b-backhoe-loader-workshop-parts-manual/)

C-10020-03.1-A



Sample of manual. Download All 2449 pages at:

<https://www.arepairmanual.com/downloads/2010-terex-tx760b-backhoe-loader-workshop-parts-manual/>