

Product: 2010 TEREX TX860B Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-tx860b-backhoe-loader-workshop-parts-manual/>

SPARES

BACKHOE LOADER

TX860B

Publication No. August 2010

Sample of manual. Download All 2657 pages at:

<https://www.terexce.com/central-boards/2010-terex-tx860b-backhoe-loader-workshop-parts-manual/>

TEREX, Central Boards 2010, Protegis Park, Coventry CV6 4BX, England
Tel.: +44 (0)2476 339400 - Fax: +44 (0)2476 339500
www.terexce.com - Email : parts@terexce.com - sales@terexce.com

Product: 2010 TEREX TX860B Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-terex-tx860b-backhoe-loader-workshop-parts-manual/>

Sample of manual. Download All 2657 pages at:
<https://www.arepairmanual.com/downloads/2010-terex-tx860b-backhoe-loader-workshop-parts-manual/>

Contents

Chassis - Sideshift Short	14
Digger Stabilisers - Sideshift Mechanical Installation	16
Digger Stabilisers - Sideshift Stabilizer Cylinder	18
Digger Stabilisers - Sideshift Stabilizer Cylinder	20
Chassis - Centremount Short	22
Chassis - Sideshift Short	24
Digger Stabilisers - Sideshift Mechanical Installation	26
Digger Stabilisers - Sideshift Stabilizer Cylinder	28
Digger Stabilisers - Sideshift Stabilizer Cylinder	30
Chassis - Centremount Short	32
Engine Cover Yellow	34
Engine Cover White	38
Front Axle - Installation 2 Wheel Drive/2 Wheel Steer	42
Front Axle - Housing 2 Wheel Drive/2 Wheel Steer	44
Front Axle - Steering Pivot 2 Wheel Drive/2 Wheel Steer	46
Front Axle - Wheel Hub 2 Wheel Drive/2 Wheel Steer	48
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	50
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	52
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	54
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	56
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	58
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	60
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	62
Front Axle - Installation	64
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	66
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	68
Front Axle - Installation	70
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	72
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	74
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	76
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	78
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	80
Steering System 2 Wheel Steer	82
Front Wheels	84
Rear Wheels	86
Front Wheels	88
Rear Wheels	90
Rear Wheels	92
Front Wheels	94
Front Wheels	96
Rear Wheels	98
Front Wheels	100
Rear Wheels	102
Front Wheels	104
Rear Wheels	106
Hardnose And Grille	108
Engine - Engine Installation Rg38099	110
Engine - Cylinder Block Rg38099	112
Engine - Pistons And Crankshaft Rg38099	114
Engine - Cylinder Head Rg38099	118
Engine - Rockers Rg38099	120
Engine - Camshaft Rg38099	122

Engine - Lubricating Oil Filler And Breather Rg38099	124	Engine - Timing Case Tier 3	240
Engine - Turbocharger Connections Rg38099	128	Engine - Lubricating Oil Filler And Breather Tier 3	242
Engine - Exhaust Manifold Rg38099	130	Engine - Turbocharger Connections Tier 3	246
Engine - Thermostat And Water Filter Rg38099	132	Engine - Exhaust Manifold Tier 3	248
Engine - Water Pump Rg38099	134	Engine - Thermostat And Water Pipes Tier 3	250
Engine - Crankshaft Pulley Rg38099	136	Engine - Water Pump Tier 3	252
Engine - Flywheel Rg38099	138	Engine - Crankshaft Pulley Tier 3	254
Engine - Flywheel Housing Rg38099	140	Engine - Flywheel Tier 3	256
Engine - Oil Pan Rg38099	142	Engine - Flywheel Housing Tier 3	258
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38099	144	Engine - Oil Pan Tier 3	260
Engine - Oil Pump Rg38099	146	Engine - Oil Filter And Integral Oil Cooler Tier 3	262
Engine - Fuel System Rg38099	148	Engine - Oil Pump Tier 3	264
Engine - Fuel Lift Pump Rg38099	152	Engine - Fuel System Tier 3	266
Engine - Filter With Fuel Separator Up To Serial Number Tba	154	Engine - Fuel Lift Pump Tier 3	270
Engine - Filter With Fuel Separator From Serial Number Tba	156	Engine - Fuel Pipes Tier 3	272
Engine - Alternator And Mounting Rg38099	158	Engine - Filter With Fuel Separator Tier 3	274
Engine - Glow Plugs Rg38099	160	Engine - Alternator And Mounting Tier 3	276
Engine - Engine Lifting Rg38099	162	Engine - Fan Drive Tier 3	278
Engine - Plug And Blank-Off Plug Rg38099	164	Engine - Glow Plugs Tier 3	280
Engine - Joints And Gaskets Rg38099	166	Engine - Starter Motor Tier 3	282
Engine - Joints And Gaskets Rg38099	168	Engine - Plugs And Mounts Tier 3	284
Engine - Engine Installation Rg38044	170	Engine - Cylinder Head Auxiliaries Tier 3	286
Engine - Cylinder Block Rg38044	172	Fuel System	288
Engine - Pistons And Crankshaft Rg38044	174	Fuel System - Fuel Tank	290
Engine - Cylinder Head Rg38044	178	Fuel System Tier 3	292
Engine - Rockers Rg38044	180	Fuel System - Fuel Tank Tier 3	294
Engine - Camshaft Rg38044	182	Exhaust System From Serial Number H200 7 1093	296
Engine - Lubricating Oil Filler And Breather Rg38044	184	Induction System - Air Filtration	298
Engine - Turbocharger Connections Rg38044	188	Induction System - Air Filter	300
Engine - Exhaust Manifold Rg38044	190	Induction System - Air Filtration With Pre Cleaner	302
Engine - Thermostat And Water Filter Rg38044	192	Induction System - Air Filter	304
Engine - Water Pump Rg38044	194	Cooling System ROPS	306
Engine - Crankshaft Pulley Rg38044	196	Cooling System - Radiator Assembly ROPS	308
Engine - Flywheel Rg38044	198	Cooling System Without Air Conditioning	310
Engine - Flywheel Housing Rg38044	200	Cooling System - Radiator Assembly Without Air Conditioning	314
Engine - Oil Pan Rg38044	202	Cooling System With Air Conditioning	316
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38044	204	Cooling System - Radiator Assembly With Air Conditioning	320
Engine - Oil Pump Rg38044	206	Cooling System ROPS	322
Engine - Fuel System Rg38044	208	Cooling System - Radiator Assembly ROPS	326
Engine - Fuel Lift Pump Rg38044	212	Cooling System Without Air Conditioning	328
Engine - Filter With Fuel Separator Up To Serial Number Tba	214	Cooling System - Radiator Assembly Without Air Conditioning	332
Engine - Filter With Fuel Separator From Serial Number Tba	216	Cooling System With Air Conditioning	334
Engine - Alternator And Mounting Rg38044	218	Cooling System - Radiator Assembly With Air Conditioning	338
Engine - Glow Plugs Rg38044	220	Torque Converter	340
Engine - Engine Lifting Rg38044	222	Drive Line Bolting	342
Engine - Plug And Blank-Off Plug Rg38044	224	Drive Line Bolting	346
Engine - Joints And Gaskets Rg38044	226	Drive Line Bolting	350
Engine - Joints And Gaskets Rg38044	228	Drive Line Bolting Powershift	354
Engine - Engine Installation Tier 3	230	Transmission - Oil Filler 2 Wheel Drive	358
Engine - Cylinder Block Tier 3	232	Transmission - Drive Shaft 2 Wheel Drive	360
Engine - Pistons And Crankshaft Tier 3	234	Transmission - Housing 2 Wheel Drive	362
Engine - Cylinder Head Tier 3	236	Transmission - Input Shaft 2 Wheel Drive	368
Engine - Rockers And Camshaft Tier 3	238	Transmission - Reverse Idler Shaft 2 Wheel Drive	372

Transmission - Main Shaft 2 Wheel Drive	374	Consumable	514
Transmission - Output Shaft 2 Wheel Drive	376	Consumables	516
Transmission - Oil Filler 2 Wheel Steer	380	Consumables	518
Transmission - Drive Shaft 2 Wheel Steer	382	Consumable	520
Transmission - Converter Housing Powershift	384	Consumables	522
Transmission - Housing Powershift	390	Consumable	528
Transmission - Charging Pump Powershift	394	Consumable	530
Transmission - Charging Pump Powershift	396	Consumable	532
Transmission - Fwd Low / Fwd High Shaft Powershift	398	Consumable	534
Transmission - Reverse / First Shaft Powershift	402	Consumable	536
Transmission - Input Shaft Powershift	406	Consumable	538
Transmission - Second Shaft Powershift	408	Consumable	540
Transmission - Second Shaft Powershift	412	Consumable	542
Transmission - Control Valve Mounting Powershift	416	Consumable	544
Transmission - Control Valve Powershift	418	Consumable	546
Transmission - Drive Plate Powershift	422	Gear Change - Control Lever 4 Speed	548
Transmission - Drive Shaft 4 Wheel Drive	424	Gear Change - Transmission Control Unit 4 Speed	550
Transmission - Oil Filler 4 Wheel Drive	426	Gear Change - Transmission Control Unit 3 Speed	552
Transmission - Oil Filler 4 Wheel Drive	428	Gear Change - Control Lever 4 Speed	554
Transmission - Oil Filter 4 Wheel Drive	430	Gear Change - Control Lever 3 Speed	556
Transmission - Charging Pump 4 Wheel Drive	432	Gear Change - Transmission Control Unit 4 Speed	558
Transmission - Oil Strainer 4 Wheel Drive	434	Rear Axle 2 Wheel Steer	560
Transmission - Housing 4 Wheel Drive	436	Rear Axle - Housing 2 Wheel Steer	562
Transmission - Input Shaft 4 Wheel Drive	440	Rear Axle - Centre Housing 2 Wheel Steer	564
Transmission - Reverse / First Shaft 4 Wheel Drive	444	Rear Axle - Wheel Hub 2 Wheel Steer	566
Transmission - Second Shaft 4 Wheel Drive	446	Rear Axle - Epicyclic Reduction Gear 2 Wheel Steer	568
Transmission - 4 Wheel Drive Shaft 4 Wheel Drive	450	Rear Axle - Brakes 2 Wheel Steer	570
Transmission - Fork And Gearshift Rails 4 Wheel Drive	452	Rear Axle - Brake Caliper	572
Transmission - Control Valve 4 Wheel Drive	454	Rear Axle - Brake Caliper	574
Transmission - Control Valve 4 Wheel Drive	458	Rear Axle - Differential Bevel Gear - 2 Wheel Steer	576
Transmission - Solenoid Valve 4 Wheel Drive	462	Rear Axle - Differential 2 Wheel Steer	578
Transmission - Drive Shaft 2 Wheel Drive	464	Rear Axle - Differential Lock Mechanism 2 Wheel Steer	580
Transmission - Oil Filler 2 Wheel Drive	466	Rear Axle 2 Wheel Steer	582
Transmission - Oil Filter 2 Wheel Drive	468	Rear Axle - Housing 2 Wheel Steer	584
Transmission - Charging Pump 2 Wheel Drive	470	Rear Axle - Centre Housing 2 Wheel Steer	586
Transmission - Oil Strainer 2 Wheel Drive	472	Rear Axle - Wheel Hub 2 Wheel Steer	588
Transmission - Housing 2 Wheel Drive	474	Rear Axle - Epicyclic Reduction Gear 2 Wheel Steer	590
Transmission - Input Shaft 2 Wheel Drive	476	Rear Axle - Brakes 2 Wheel Steer	592
Transmission - Reverse / First Shaft 2 Wheel Drive	478	Rear Axle - Brake Caliper	594
Transmission - Second Shaft 2 Wheel Drive	480	Rear Axle - Brake Caliper	596
Transmission - Fork And Gearshift Rails 2 Wheel Drive	484	Rear Axle - Differential Bevel Gear	598
Transmission - Control Valve 2 Wheel Drive	486	Rear Axle - Differential 2 Wheel Steer	600
Transmission - Drive Shaft 4 Wheel Drive	490	Rear Axle - Differential Lock Mechanism 2 Wheel Steer	602
Transmission - Oil Filler 4 Wheel Drive	492	Rear Axle 2 Wheel Steer	604
Transmission - Oil Filter 4 Wheel Drive	494	Rear Axle 2 Wheel Steer	606
Transmission - Charging Pump 4 Wheel Drive	496	Rear Axle 2 Wheel Steer	608
Transmission - Housing 4 Wheel Drive	498	Rear Axle 2 Wheel Steer	610
Transmission - Housing 4 Wheel Drive	500	Rear Axle 2 Wheel Steer	612
Transmission - Input Shaft 4 Wheel Drive	502	Rear Axle 2 Wheel Steer	614
Transmission - Reverse / First Shaft 4 Wheel Drive	504	Rear Axle 2 Wheel Steer	616
Transmission - Second Shaft 4 Wheel Drive	506	Rear Axle 2 Wheel Steer	618
Transmission - Output Shaft 4 Wheel Drive	510	Rear Axle 2 Wheel Steer	620
Transmission - Control Valve 4 Wheel Drive	512	Rear Axle - Brake Caliper	622

Hydraulic Valve - Backhoe Control Sideshift Digger Installation	624	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	784
Hydraulic Valve - Backhoe Control Inlet	626	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	786
Hydraulic Valve - Backhoe Control Slew	630	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	792
Hydraulic Valve - Backhoe Control Boom	636	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	794
Hydraulic Valve - Backhoe Control Dipper	642	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	796
Hydraulic Valve - Backhoe Control Bucket	648	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	798
Hydraulic Valve - Backhoe Control Stabilizer	654	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	800
Hydraulic Valve - Backhoe Control Auxiliary	658	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	802
Hydraulic Valve - Backhoe Control Outlet	664	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	804
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	666	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	806
Hydraulic Valve - Backhoe Control Inlet	668	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	808
Hydraulic Valve - Backhoe Control Slew	672	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	812
Hydraulic Valve - Backhoe Control Boom	678	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	814
Hydraulic Valve - Backhoe Control Dipper	684	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	816
Hydraulic Valve - Backhoe Control Bucket	690	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	818
Hydraulic Valve - Backhoe Control Stabilizer	696	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	820
Hydraulic Valve - Backhoe Control Auxiliary	700	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	822
Hydraulic Valve - Backhoe Control Outlet	706	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	824
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	708	Hydraulic Valve - Backhoe Control Sideshift Digger Installation	826
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	712	Torque Converter - Hydraulic Lines	828
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	714	Torque Converter - Hydraulic Lines	830
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	716	Main Hydraulics - Hydraulic Lines Synchro Shuttle	832
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	718	Main Hydraulics - Hydraulic Lines Synchro Shuttle	836
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	720	Main Hydraulics - Oil Filter Synchro Shuttle	840
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	722	Main Hydraulics - Solenoid Valve Synchro Shuttle	842
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	724	Hydraulic Reservoir Synchro Shuttle	844
Hydraulic Valve - Backhoe Control Sideshift Digger Installation	726	Main Hydraulics - Tandem Pump Synchro Shuttle	846
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	728	Main Hydraulics - Tandem Pump Synchro Shuttle	848
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	730	Main Hydraulics - Hydraulic Lines Synchro Shuttle	850
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	732	Main Hydraulics - Hydraulic Lines Synchro Shuttle	854
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	734	Main Hydraulics - Oil Filter Synchro Shuttle	858
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	736	Main Hydraulics - Solenoid Valve Synchro Shuttle	860
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	738	Hydraulic Reservoir Synchro Shuttle	862
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	740	Main Hydraulics - Tandem Pump Synchro Shuttle	864
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	742	Control Box - Installation From Serial Number Tba	866
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	744	Control Box Control Pedals	868
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	746	Control Box Hydraulics	872
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	750	Control Box Brake Cylinder	874
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	752	Control Box Steering	876
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	754	Throttle Controls	878
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	756	Throttle Controls Lever, Control	880
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	758	Tool Kit - Wheel Brace + Grease Gun	882
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	760	Service Brake - Brake Circuit From Serial Number Tba	884
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	762	Service Brake - Brake Circuit From Serial Number Tba	886
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	764	Service Brake - Brake Circuit From Serial Number Tba	888
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	766	Service Brake - Brake Circuit From Serial Number Tba	890
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	770	Service Brake - Brake Circuit From Serial Number Tba	892
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	772	Service Brake - Brake Circuit From Serial Number Tba	894
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	774	Differential Lock Synchro Shuttle	896
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	776	Differential Lock - Controls Solenoid Valve	898
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	778	Differential Lock Powershift	900
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	780	Differential Lock Synchro Shuttle	902
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	782	Parking Brake	904

Parking Brake 4 Post ROPS	906	Cab Trim - Cab Mounting	1034
Cab - 4 Post ROPS	908	Cab Trim - Floorplate & Digger Tower	1036
Cab - Rear Worklight	910	Cab Trim - Mats	1038
Cab - Relay Bracket	912	Cab Trim - Mats	1040
Cab - Frame	914	Cab Trim - Mats	1042
Cab - Door	918	Cab Trim - Mats	1044
Cab - Rear Window	924	Not Serviced	1046
Cab - Outer Roof	928	Cab Environment - Heater Installation Front	1048
Cab - Front Worklight	932	Cab Environment - Heater Installation Rear	1052
Cab - Rear Worklight	934	Cab Environment - Heater Unit	1054
Cab - Inner Roof	936	Cab Environment - Air Conditioning Installation	1056
Cab - Frame	938	Cab Environment - Heater Installation Front	1060
Cab - Door	942	Cab Environment - Air Conditioning Installation Rear	1064
Cab - Rear Window	948	Cab Environment - Air Conditioning Unit	1066
Cab - Outer Roof	952	Cab Environment - Less Heater Unit ROPS	1070
Cab - Inner Roof	956	Front Console - Installation ROPS	1072
Cab Trim - Windscreen Wiper	958	Front Console ROPS	1074
Cab - Front Worklight	960	Front Console - Instrument Panel ROPS	1076
Cab - Rear Worklight	962	Front Console - Forward/Reverse Switch ROPS	1078
Cab Trim - Heater	964	Front Console - Installation Cab	1080
Cab Trim - Console	966	Front Console Cab	1082
Cab Trim - Console RH	968	Front Console - Instrument Panel Cab	1084
Cab Side Console - Fuse & Relay Board	970	Front Console - Forward/Reverse Switch Cab	1086
Cab Trim - Cab Mounting	974	Front Console - Installation ROPS	1088
Cab Trim - Floorplate Cab	976	Front Console ROPS	1090
Cab Trim - Console	978	Front Console - Instrument Panel ROPS	1092
Cab Trim - Windscreen Wiper	980	Front Console - Forward/Reverse Switch ROPS	1094
Cab Trim - Cab Mounting 4 Post ROPS	982	Front Console - Installation ROPS	1096
Cab Trim - Floorplate 4 Post ROPS	984	Front Console ROPS	1098
Cab Trim - Cab Mounting 4 Post ROPS	986	Front Console - Instrument Panel ROPS	1100
Cab Trim - Floorplate 4 Post ROPS	988	Front Console - Forward/Reverse Switch ROPS	1102
Cab Trim - Cab Mounting	990	Front Console - Installation Cab	1104
Cab Trim - Floorplate	992	Front Console Cab	1106
Cab Trim - Console	994	Front Console - Instrument Panel Cab	1108
Cab Trim - Windscreen Wiper	996	Front Console - Forward/Reverse Switch Cab	1110
Cab Trim - Cab Mounting 4 Post ROPS	998	Front Console - Installation ROPS	1112
Cab Trim - Floorplate 4 Post ROPS	1000	Front Console ROPS	1114
Cab Trim - Cab Mounting 4 Post ROPS	1002	Front Console - Instrument Panel ROPS	1116
Cab Trim - Floorplate 4 Post ROPS	1004	Front Console - Forward/Reverse Switch ROPS	1118
Cab Trim - Cab Mounting	1006	Front Console - Installation ROPS	1120
Cab Trim - Floorplate Cab	1008	Front Console ROPS	1122
Cab Trim - Console	1010	Front Console - Instrument Panel ROPS	1124
Cab Trim - Windscreen Wiper	1012	Front Console - Forward/Reverse Switch ROPS	1126
Cab Trim - Cab Mounting 4 Post ROPS	1014	Front Console - Installation Cab	1128
Cab Trim - Floorplate 4 Post ROPS	1016	Front Console Cab	1130
Cab Trim - Cab Mounting	1018	Front Console - Instrument Panel Cab	1132
Cab Trim - Floorplate	1020	Front Console - Forward/Reverse Switch Cab	1134
Cab Trim - Console	1022	Front Console - Installation ROPS	1136
Cab Trim - Windscreen Wiper	1024	Front Console ROPS	1138
Cab Trim - Cab Mounting 4 Post ROPS	1026	Front Console - Instrument Panel ROPS	1140
Cab Trim - Floorplate 4 Post ROPS	1028	Front Console - Forward/Reverse Switch ROPS	1142
Cab Trim - Cab Mounting	1030	Front Console - Installation ROPS	1144
Cab Trim - Floorplate & Digger Tower	1032	Front Console ROPS	1146

Front Console - Instrument Panel ROPS	1148	Side Console Switchpack	1256
Front Console - Forward/Reverse Switch ROPS	1150	Side Console - Instrument Panel Switchpack	1260
Front Console - Installation Cab	1152	Side Console - Fuse & Relay Board	1262
Front Console Cab	1154	Side Console 4 Post ROPS	1264
Front Console - Instrument Panel Cab	1156	Side Console - Instrument Panel Rocker Switch	1268
Front Console - Forward/Reverse Switch Cab	1158	Side Console - Fuse & Relay Board	1270
Front Console - Installation Cab	1160	Side Console Switchpack	1272
Front Console Cab	1162	Side Console - Instrument Panel Switchpack	1274
Front Console - Instrument Panel Cab	1164	Side Console Switchpack	1276
Front Console - Forward/Reverse Switch Cab	1166	Side Console - Instrument Panel Switchpack	1278
Front Console - Installation ROPS	1168	Chassis Electrics	1280
Front Console ROPS	1170	Chassis Electrics	1284
Front Console - Instrument Panel ROPS	1172	Chassis Electrics Synchro Shuttle - Carraro	1288
Front Console - Forward/Reverse Switch ROPS	1174	Battery - Single From Serial Number H200 4 2919	1292
Front Console - Installation ROPS	1176	Battery - Dual From Serial Number H200 4 2919	1294
Front Console ROPS	1178	Battery - Single Tier 3	1296
Front Console - Instrument Panel ROPS	1180	Battery - Dual Tier 3	1298
Front Console - Forward/Reverse Switch ROPS	1182	Rear Lighting - Sideshift	1300
Front Console - Installation Cab	1184	Rear Lighting - Centremount	1302
Front Console Cab	1186	Rear Lighting - ROPS	1304
Front Console - Instrument Panel Cab	1188	Rear Lighting - ROPS 4 Post ROPS	1306
Front Console - Forward/Reverse Switch Cab	1190	Front Lighting - Headlights Left Hand Dip	1308
Front Console - Installation ROPS	1192	Front Lighting - Headlights Right Hand Dip	1310
Front Console ROPS	1194	Mirrors - Cab	1312
Front Console - Instrument Panel ROPS	1196	Mirrors - ROPS 4 Post ROPS	1314
Front Console - Forward/Reverse Switch ROPS	1198	Seat - Seat Installation Fabric Trim - Cab Machines	1316
Front Console - Installation Cab	1200	Seat - Fabric Trim Cab	1318
Front Console Cab	1202	Seat - Seat Installation Air Suspension	1320
Front Console - Instrument Panel Cab	1204	Seat - Fabric Trim Air Suspension	1322
Front Console - Forward/Reverse Switch Cab	1206	Seat - Seat Installation Weatherproof P.V.C. Trim	1324
Front Console - Installation Cab	1208	Seat - Weatherproof P.V.C. Trim 4 Post ROPS	1326
Front Console Cab	1210	Seat - Weatherproof P.V.C. Trim Air Suspension	1328
Front Console - Instrument Panel Cab	1212	Seat - Seat Installation Air Suspension	1330
Front Console - Forward/Reverse Switch Cab	1214	Front Fenders 2 Wheel Steer	1336
Front Console - Installation ROPS	1216	Ride Control - Hydraulic Circuit English	1338
Front Console ROPS	1218	Ride Control - Hydraulic Circuit English	1340
Front Console - Instrument Panel ROPS	1220	Ride Control - Hydraulic Circuit Less Ride Control	1342
Front Console - Forward/Reverse Switch ROPS	1222	Ride Control - Hydraulic Circuit French	1344
Front Console - Installation ROPS	1224	Ride Control - Hydraulic Circuit French	1346
Front Console ROPS	1226	Ride Control - Hydraulic Circuit German	1348
Front Console - Instrument Panel ROPS	1228	Ride Control - Hydraulic Circuit German	1350
Front Console - Forward/Reverse Switch ROPS	1230	Ride Control - Hydraulic Circuit Italian	1352
Front Console - Installation Cab	1232	Ride Control - Hydraulic Circuit Italian	1354
Front Console Cab	1234	Ride Control - Hydraulic Circuit Spanish	1356
Front Console - Instrument Panel Cab	1236	Ride Control - Hydraulic Circuit Spanish	1358
Front Console - Forward/Reverse Switch Cab	1238	Ride Control - Hydraulic Circuit Dutch	1360
Front Console - Installation Cab	1240	Ride Control - Hydraulic Circuit Dutch	1362
Front Console Cab	1242	Ride Control - Hydraulic Circuit Danish	1364
Front Console - Instrument Panel Cab	1244	Ride Control - Hydraulic Circuit Danish	1366
Front Console - Forward/Reverse Switch Cab	1246	Ride Control - Hydraulic Circuit	1368
Side Console Switchpack	1248	Ride Control - Hydraulic Circuit Solenoid Valve	1370
Side Console - Instrument Panel Switchpack	1252	Ride Control - Hydraulic Circuit	1372
Side Console - Fuse & Relay Board	1254	Ride Control - Hydraulic Circuit Solenoid Valve	1374

Ride Control - Hydraulic Circuit ROPS	1376	Loader Hydraulics - Lift Cylinder High Specification	1512
Ride Control - Hydraulic Circuit Solenoid Valve	1378	Loader Hydraulics - Lift Cylinder High Specification Pacoma	1516
Ride Control - Hydraulic Circuit ROPS	1380	Loader Hydraulics - Lift Cylinder High Specification Wipro	1518
Ride Control - Hydraulic Circuit Solenoid Valve	1382	Loader Hydraulics - Bucket Cylinder High Specification	1520
Loader - Arms Yellow	1384	Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1524
Loader - Links Yellow	1388	Loader Hydraulics - Bucket Cylinder High Specification Wipro	1526
Loader - Return To Dig Mechanical	1390	Hose Burst Kit Loader Arm Cylinder	1528
Loader - Return To Dig Mechanical	1394	Hose Burst Kit Loader Bucket Cylinder	1532
Loader - Safety Strut	1398	Hose Burst Kit Boom Cylinder	1536
Loader - Arms White	1400	Hose Burst Kit Dipper Cylinder	1538
Loader - Links White	1404	Hose Burst Kit Boom Cylinder	1540
Loader - Return To Dig Mechanical	1406	Hose Burst Kit Dipper Cylinder	1542
Loader - Return To Dig Mechanical	1410	Hose Burst Kit Boom Cylinder	1544
Loader - Safety Strut	1414	Hose Burst Kit Dipper Cylinder	1546
Loader Bucket - Standard For Use With Forks	1416	Loader Controls Upper Control Levers	1548
Loader Bucket - Standard For Use With Forks	1418	Loader Controls Lower Control Levers	1552
Loader Bucket - 7 In 1	1420	Loader Controls Control Valve	1556
Loader Bucket - 7 In 1 Bucket Pipework	1422	Loader Controls - Hydraulic Valve Inlet	1558
Loader Bucket - 7 In 1 Cylinder	1424	Loader Controls - Hydraulic Valve Loader Arm Section	1560
Loader Bucket - 7 In 1	1426	Loader Controls - Hydraulic Valve Standard Bucket Section	1562
Loader Bucket - 7 In 1 Bucket Pipework	1428	Loader Controls - Hydraulic Valve Standard Bucket Section	1564
Loader Bucket - 7 In 1 Cylinder	1430	Loader Controls - Hydraulic Valve Standard Bucket Section	1566
Loader Bucket Less Bucket	1432	Loader Controls Upper Control Levers	1568
Loader Hydraulics - Lift Cylinder High Specification	1434	Loader Controls Lower Control Levers	1572
Loader Hydraulics - Lift Cylinder High Specification Pacoma	1438	Loader Controls Control Valve	1576
Loader Hydraulics - Lift Cylinder High Specification Wipro	1440	Loader Controls - Hydraulic Valve Inlet	1578
Loader Hydraulics - Bucket Cylinder High Specification	1442	Loader Controls - Hydraulic Valve Loader Arm Section	1580
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1446	Loader Controls - Hydraulic Valve Standard Bucket Section	1582
Loader Hydraulics - Bucket Cylinder High Specification Wipro	1448	Loader Controls - Hydraulic Valve Standard Bucket Section	1584
Loader Hydraulics - Lift Cylinder High Specification	1450	Loader Controls - Hydraulic Valve Standard Bucket Section	1586
Loader Hydraulics - Lift Cylinder High Specification Pacoma	1454	Loader Controls Upper Control Levers	1588
Loader Hydraulics - Lift Cylinder High Specification Wipro	1456	Loader Controls Lower Control Levers	1590
Loader Hydraulics - Bucket Cylinder High Specification	1458	Loader Controls Control Valve	1594
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1462	Loader Controls - Hydraulic Valve Inlet	1596
Loader Hydraulics - Bucket Cylinder High Specification Wipro	1464	Loader Controls - Hydraulic Valve Loader Arm Section	1598
Loader Hydraulics - Lift Cylinder High Specification	1466	Loader Controls - Hydraulic Valve Standard Bucket Section	1600
Loader Hydraulics - Lift Cylinder High Specification Pacoma	1470	Loader Controls - Hydraulic Valve Standard Bucket Section	1602
Loader Hydraulics - Lift Cylinder High Specification Wipro	1472	Loader Controls - Hydraulic Valve Standard Bucket Section	1604
Loader Hydraulics - Bucket Cylinder Standard Specification	1474	Loader Controls Upper Control Levers	1606
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1476	Loader Controls Lower Control Levers	1608
Loader Hydraulics - Bucket Cylinder High Specification Wipro	1478	Loader Controls Control Valve	1612
Loader Hydraulics - Lift Cylinder High Specification	1480	Loader Controls - Hydraulic Valve Inlet	1614
Loader Hydraulics - Lift Cylinder High Specification Pacoma	1484	Loader Controls - Hydraulic Valve Loader Arm Section	1616
Loader Hydraulics - Lift Cylinder High Specification Wipro	1486	Loader Controls - Hydraulic Valve Standard Bucket Section	1618
Loader Hydraulics - Bucket Cylinder High Specification	1488	Loader Controls - Hydraulic Valve Standard Bucket Section	1620
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1492	Loader Controls - Hydraulic Valve Standard Bucket Section	1622
Loader Hydraulics - Bucket Cylinder High Specification Wipro	1494	Loader Controls - Upper Control Levers 7 In 1 Bucket	1624
Loader Hydraulics - Lift Cylinder High Specification	1496	Loader Controls - Lower Control Levers 7 In 1 Bucket	1628
Loader Hydraulics - Lift Cylinder High Specification Pacoma	1500	Loader Controls - Control Valve 7 In 1 Bucket	1632
Loader Hydraulics - Lift Cylinder High Specification Wipro	1502	Loader Controls - Hydraulic Valve Inlet	1634
Loader Hydraulics - Bucket Cylinder High Specification	1504	Loader Controls - Hydraulic Valve Loader Arm Section	1636
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1508	Loader Controls - Hydraulic Valve Standard Bucket Section	1642
Loader Hydraulics - Bucket Cylinder High Specification Wipro	1510	Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1648

Loader Controls - Hydraulic Valve Outlet	1654	Digger Swing Pivot - Centremount	1792
Loader Controls - Upper Control Levers	1656	Digger Swing Pivot - Centremount Swing Cylinder Pacoma	1794
Loader Controls - Lower Control Levers	1658	Digger Swing Pivot - Centremount Swing Cylinder Wipro	1796
Loader Controls - Control Valve	1662	Boom	1798
Loader Controls - Hydraulic Valve Inlet	1664	Not Serviced	1800
Loader Controls - Hydraulic Valve Loader Arm Section	1666	Dipper - Standard	1802
Loader Controls - Hydraulic Valve Standard Bucket Section	1672	Dipper - Standard	1804
Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1678	Dipper - Extendahoe	1806
Loader Controls - Hydraulic Valve Outlet	1684	Dipper - Extendahoe Cylinder	1812
Loader Controls Upper Control Levers	1686	Dipper - Extendahoe	1814
Loader Controls Lower Control Levers	1688	Dipper - Extendahoe Cylinder	1820
Loader Controls Control Valve	1692	Dipper - Standard Case Bucket	1822
Loader Controls - Hydraulic Valve Inlet	1694	Dipper - Standard Case Bucket	1824
Loader Controls - Hydraulic Valve Loader Arm Section	1696	Dipper - Extendahoe Case Bucket	1826
Loader Controls - Hydraulic Valve Standard Bucket Section	1698	Dipper - Extendahoe Cylinder	1832
Loader Controls - Hydraulic Valve Standard Bucket Section	1700	Dipper - Extendahoe Case Bucket	1834
Loader Controls - Hydraulic Valve Standard Bucket Section	1702	Dipper - Extendahoe Cylinder	1840
Loader Controls Upper Control Levers	1704	Dipper - Standard Jcb Bucket	1842
Loader Controls Lower Control Levers	1708	Dipper - Standard Jcb Bucket	1844
Loader Controls Control Valve	1712	Dipper - Extendahoe Jcb Bucket	1846
Loader Controls - Hydraulic Valve Inlet	1714	Dipper - Extendahoe Cylinder	1852
Loader Controls - Hydraulic Valve Loader Arm Section	1716	Dipper - Extendahoe Jcb Bucket	1854
Loader Controls - Hydraulic Valve Standard Bucket Section	1718	Dipper - Extendahoe Cylinder	1860
Loader Controls - Hydraulic Valve Standard Bucket Section	1720	Digger Bucket Linkage	1862
Loader Controls - Hydraulic Valve Standard Bucket Section	1722	Digger Bucket Linkage	1864
Loader Controls Upper Control Levers	1724	Digger Bucket Linkage - Jcb Buckets	1866
Loader Controls Lower Control Levers	1726	Digger Bucket Linkage - Jcb Buckets	1868
Loader Controls Control Valve	1730	Digger Bucket Linkage - Case Buckets	1870
Loader Controls - Hydraulic Valve Inlet	1732	Digger Bucket Linkage - Case Buckets	1872
Loader Controls - Hydraulic Valve Loader Arm Section	1734	Digger Hydraulics - Sideshift Bucket	1874
Loader Controls - Hydraulic Valve Standard Bucket Section	1736	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1878
Loader Controls - Hydraulic Valve Standard Bucket Section	1738	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1880
Loader Controls - Hydraulic Valve Standard Bucket Section	1740	Digger Hydraulics - Sideshift Standard Dipper	1882
Loader Controls Upper Control Levers	1742	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1884
Loader Controls Lower Control Levers	1746	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1886
Loader Controls Control Valve	1750	Digger Hydraulics - Sideshift Boom	1888
Loader Controls - Hydraulic Valve Inlet	1752	Digger Hydraulics - Sideshift Boom Cylinder Pacoma	1890
Loader Controls - Hydraulic Valve Loader Arm Section	1754	Digger Hydraulics - Sideshift Boom Cylinder Wipro	1892
Loader Controls - Hydraulic Valve Standard Bucket Section	1756	Digger Hydraulics - Sideshift Swing Components	1894
Loader Controls - Hydraulic Valve Standard Bucket Section	1758	Digger Hydraulics - Sideshift Clamp	1896
Loader Controls - Hydraulic Valve Standard Bucket Section	1760	Digger Hydraulics - Sideshift Attachment	1898
Boom Transport Lock Sideshift Digger	1766	Digger Hydraulics - Sideshift Attachment	1902
Boom Transport Lock Centre Mounted Digger	1768	Digger Hydraulics - Sideshift Bucket	1906
Digger Stabilisers - Sideshift Hydraulic Installation	1770	Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1910
Digger Stabilisers - Sideshift Mechanical Installation	1772	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1912
Digger Stabilisers - Sideshift Hydraulic Installation	1774	Digger Hydraulics - Sideshift Telescopic Dipper	1914
Digger Stabilisers - Sideshift Stabilizer Cylinder	1776	Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1916
Digger Stabilisers - Sideshift Stabilizer Cylinder	1778	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1918
Digger Stabilisers - Sideshift Lock-Out Valve	1780	Digger Hydraulics - Sideshift Boom	1920
Not Serviced	1782	Digger Hydraulics - Sideshift Boom Cylinder Pacoma	1922
Digger Swing Pivot - Sideshift	1784	Digger Hydraulics - Sideshift Boom Cylinder Wipro	1924
Digger Swing Pivot - Sideshift Swing Cylinder Pacoma	1788	Digger Hydraulics - Sideshift Swing Components	1926
Digger Swing Pivot - Sideshift Swing Cylinder Wipro	1790	Digger Hydraulics - Sideshift Clamp	1928

Digger Hydraulics - Sideshift Attachment	1930	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	2058
Digger Hydraulics - Sideshift Attachment	1934	Digger Hydraulics - Centremount Boom 4.5m	2060
Digger Hydraulics - Sideshift Bucket	1938	Digger Hydraulics - Centremount Boom Cylinder - Pacoma	2062
Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1942	Digger Hydraulics - Centremount Boom Cylinder - Wipro	2064
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1944	Digger Hydraulics - Centremount Swing Components	2066
Digger Hydraulics - Sideshift Standard Dipper	1946	Digger Hydraulics - Centremount Bucket	2068
Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1948	Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	2072
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1950	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	2074
Digger Hydraulics - Sideshift Boom	1952	Digger Hydraulics - Centremount Telescopic Dipper	2076
Digger Hydraulics - Sideshift Boom Cylinder Pacoma	1954	Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	2078
Digger Hydraulics - Sideshift Boom Cylinder Wipro	1956	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	2080
Digger Hydraulics - Sideshift Swing Components	1958	Digger Hydraulics - Centremount Boom 4.5m	2082
Digger Hydraulics - Sideshift Clamp	1960	Digger Hydraulics - Centremount Boom Cylinder - Pacoma	2084
Digger Hydraulics - Sideshift Attachment	1962	Digger Hydraulics - Centremount Boom Cylinder - Wipro	2086
Digger Hydraulics - Sideshift Attachment	1966	Digger Hydraulics - Centremount Swing Components	2088
Digger Hydraulics - Sideshift Bucket	1970	Digger Controls Standard	2090
Digger Hydraulics - Sideshift Bucket Cylinder - Pacoma	1974	Digger Controls ISO	2092
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1976	Digger Controls X Pattern	2096
Digger Hydraulics - Sideshift Telescopic Dipper	1978	Digger Controls - Servo Pivot	2098
Digger Hydraulics - Sideshift Dipper Cylinder - Pacoma	1980	Digger Controls - Servo Control Bar	2100
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1982	Digger Controls - Servo Pilot Control	2102
Digger Hydraulics - Sideshift Boom	1984	Digger Controls - Servo Joystick	2104
Digger Hydraulics - Sideshift Boom Cylinder - Pacoma	1986	Digger Controls - Servo Trim	2106
Digger Hydraulics - Sideshift Boom Cylinder - Wipro	1988	Digger Controls - Servo Change Over Valve	2108
Digger Hydraulics - Sideshift Swing Components	1990	Digger Controls - Servo Decals	2112
Digger Hydraulics - Sideshift Clamp	1992	Digger Controls - Servo Pivot	2114
Digger Hydraulics - Sideshift Attachment	1994	Digger Controls - Servo Control Bar	2116
Digger Hydraulics - Sideshift Attachment	1998	Digger Controls - Servo Pilot Control	2118
Digger Hydraulics - Centremount Bucket	2002	Digger Controls - Servo Joystick	2120
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	2006	Digger Controls - Servo Trim	2122
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	2008	Digger Controls - Servo Change Over Valve	2124
Digger Hydraulics - Centremount Standard Dipper	2010	Digger Controls - Servo Decals	2128
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	2012	Digger Controls ISO / Sae	2130
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	2014	Extendahoe Hydraulics - Sideshift Without Auxiliary Hydraulics	2134
Digger Hydraulics - Centremount Boom 4.5m	2016	Extendahoe Hydraulics - Sideshift Control Pedal	2136
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	2018	Extendahoe Hydraulics - Sideshift With Auxiliary Hydraulics	2138
Digger Hydraulics - Centremount Boom Cylinder - Wipro	2020	Extendahoe Hydraulics - Sideshift Control Pedal	2140
Digger Hydraulics - Centremount Swing Components	2022	Extendahoe Hydraulics - Centremount Without Auxiliary Hydraulics	2142
Digger Hydraulics - Centremount Bucket	2024	Extendahoe Hydraulics - Centremount Control Pedal	2144
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	2028	Extendahoe Hydraulics - Centremount With Auxiliary Hydraulics	2146
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	2030	Extendahoe Hydraulics - Centremount Control Pedal	2148
Digger Hydraulics - Centremount Telescopic Dipper	2032	Extendahoe Hydraulics Less Control Pedal	2150
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	2034	Extendahoe Hydraulics Control Pedal	2152
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	2036	Not Serviced	2154
Digger Hydraulics - Centremount Boom 4.5m	2038	Stabiliser Controls - Sideshift Digger	2156
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	2040	Stabiliser Controls - Sideshift Digger	2160
Digger Hydraulics - Centremount Boom Cylinder - Wipro	2042	Stabiliser Controls - Centremount Digger	2162
Digger Hydraulics - Centremount Swing Components	2044	Stabiliser Controls - Centremount Digger	2166
Digger Hydraulics - Centremount Bucket	2046	Stabiliser Controls - Centremount Digger 4 Post ROPS	2168
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	2050	Stabiliser Controls - Centremount Digger ROPS	2170
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	2052	Auxiliary Hydraulics - Sideshift Telescopic Dipper	2174
Digger Hydraulics - Centremount Standard Dipper	2054	Auxiliary Hydraulics - Sideshift Telescopic Dipper	2178
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	2056	Auxiliary Hydraulics - Sideshift Standard Dipper	2184


Auxiliary Hydraulics - Sideshift Standard Dipper	2188	Decals - Warnings North America	2302
Auxiliary Hydraulics - Sideshift Control Pedal	2192	Decals - Instructions North America	2304
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	2194	Decals - Miscellaneous North America	2306
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	2196	Decals - Warnings North America	2308
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	2200	Decals - Instructions North America	2310
Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.5m	2202	Decals - Miscellaneous North America	2312
Auxiliary Hydraulics - Centremount Standard Dipper	2206	Decals - Warnings General Markets	2314
Auxiliary Hydraulics - Centremount Standard Dipper	2208	Decals - Instructions General Markets	2316
Auxiliary Hydraulics - Centremount Control Pedal	2210	Decals - Miscellaneous General Markets	2318
Not Serviced	2212	Decals - Warnings Costa Rica	2320
Digger Bucket - Standard	2214	Decals - Instructions Costa Rica	2322
Digger Bucket - Standard	2216	Decals - Miscellaneous Costa Rica	2324
Digger Bucket - Standard	2218	Decals - Warnings Costa Rica	2326
Digger Bucket - Standard	2220	Decals - Instructions Costa Rica	2328
Digger Bucket - Standard 305 Mm	2222	Decals - Miscellaneous Costa Rica	2330
Digger Bucket - Ditch Cleaning	2224	Kit - Forks Loader Bucket	2332
Digger Bucket - Ditch Cleaning	2226	Kit - Forks Loader Bucket	2334
Digger Bucket - Gannon 12 In	2228	Kit - Loader Quick Attach Pins	2336
Digger Bucket - Gannon 18 In	2230	Kit - Loader Quick Attach Tubes	2338
Digger Bucket - Gannon 24 In	2232	Kit - Loader Quick Attach	2340
Not Serviced	2234	Quick Attach, Loader	2342
Digger Bucket - Premium	2236	Tooth Guard Kit - With Decal Loader Bucket, 7-In-1	2344
Digger Bucket - Premium	2238	Tooth Guard Kit - With Decal Loader Bucket, 7-In-1	2346
Digger Bucket - Premium	2240	Tooth Guard Kit - With Decal Standard Loader Bucket	2348
Digger Bucket - Premium	2242	Tooth Guard Kit - With Decal Standard Loader Bucket	2350
Digger Bucket - Premium	2244	Transport Height Decal Kit	2352
Digger Bucket - Ditch Maintenance	2246	Position Indicator - Loader Arm	2354
Digger Bucket - Ditch Maintenance	2248	Headlamp Extension	2356
Digger Bucket - Ditch Digging	2250	Digger Stabilisers - Safety Kit	2358
Digger Bucket - Jcb	2252	Transport Lock - Loader	2360
Digger Bucket - Jcb	2254	Decals - Craning Valve Kit	2362
Digger Bucket - Jcb	2256	Seat Belt Kit	2364
Digger Bucket - Jcb	2258	Fan Guard Without Air Conditioning	2366
Digger Bucket - Jcb	2260	Fan Guard With Air Conditioning	2368
Digger Bucket - Ditch Maintenance Jcb Bucket	2262	Reverse Alarm	2370
Digger Bucket - Ditch Maintenance Jcb Bucket	2264	Kit - Boom Guard	2372
Not Serviced	2266	Bucket Pins Kit Single	2374
Rear Fenders 2 Wheel Steer	2268	Bucket Pins Kit Double	2376
Rear Fenders - Sideshift Mudguard	2270	Jcb Bucket Pins Kit Single	2378
Rear Fenders 2 Wheel Steer	2272	Jcb Bucket Pins Kit Double	2380
Rear Fenders 2 Wheel Steer	2274	Bucket Pins Kit Loader	2382
Rear Fenders 2 Wheel Steer	2276	Not Serviced	2384
Rear Fenders - Sideshift Mudguard	2278	Not Serviced	2386
Rear Fenders 4 Post ROPS	2280	Digger Craning Eye Kit Sideshift Digger	2390
Rear Fenders 4 Post ROPS	2282	Digger Craning Eye Kit Centre Mounted Digger	2392
Rear Fenders 2 Wheel Steer	2286	Digger Craning Eye Kit Sideshift Digger	2394
Decals - Machine Identity	2288	Digger Craning Eye Kit Centre Mounted Digger	2396
Decals - Warnings General Markets	2290	Craning Valve Kit Cab	2398
Decals - Instructions General Markets	2292	Craning Valve Kit 4 Post ROPS	2402
Decals - Miscellaneous General Markets	2294	Front Counterweight Kit	2406
Decals - Warnings General Markets	2296	Fuel Strainer Kit	2408
Decals - Instructions General Markets	2298	Not Serviced	2410
Decals - Miscellaneous General Markets	2300	Anti Vandal Kit	2412

Street Pads Kit Sideshift Digger	2414	Quick Attach, Digger - Sideshift Quick Coupler	2532
Service Tool Kit	2416	Quick Attach, Digger - Sideshift Standard Dipper	2534
Rotating Beacon Kit Single	2418	Quick Attach, Digger - Sideshift Standard Dipper	2536
Rotating Beacon Kit Double	2420	Quick Attach, Digger - Sideshift Solenoid Valve	2538
Worklight Kit	2422	Quick Attach, Digger - Sideshift Telescopic Dipper	2540
Seat Armrest Kit	2424	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2542
Kit - Headrest	2426	Quick Attach, Digger - Sideshift Solenoid Valve	2544
Steering Wheel Spinner Knob Kit	2428	Quick Attach, Digger - Sideshift Quick Coupler	2546
Bucket Blade Kit Narrow	2430	Quick Attach, Digger - Sideshift Telescopic Dipper	2548
Bucket Blade Kit Wide	2432	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2550
Bucket Tooth Kit Loader Bucket, 7-In-1	2434	Quick Attach, Digger - Sideshift Solenoid Valve	2552
Hose Burst Kit - Quick Attach Boom Cylinder	2436	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2554
Hose Burst Kit - Quick Attach Boom Cylinder	2440	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2556
Hose Bust Kit - Less Quick Attach Boom Cylinder	2444	Quick Attach, Digger - Centremount Solenoid Valve	2558
Hose Bust Kit - Less Quick Attach Boom Cylinder	2448	Quick Attach, Digger - Centremount Quick Coupler	2560
Hose Bust Kit - Less Quick Attach Boom Cylinder	2452	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2562
Literature Operator Manual - English	2454	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2564
Literature Operator Manual - Spanish	2456	Quick Attach, Digger - Centremount Solenoid Valve	2566
Literature Operator Manual - French	2458	Quick Attach, Digger - Centremount Quick Coupler	2568
Literature Operator Manual - German	2460	Quick Attach, Digger - Sideshift Standard Dipper	2570
Literature Operator Manual - Danish	2462	Quick Attach, Digger - Sideshift Standard Dipper	2572
Rockguard Kit	2464	Quick Attach, Digger - Sideshift Solenoid Valve	2574
Spare Wheels - Rear (M07, M10 & M12)	2466	Quick Attach, Digger - Sideshift Telescopic Dipper	2576
Spare Wheels - Rear (M05, M09, M14 & M21)	2468	Quick Attach, Digger - Sideshift Telescopic Dipper - Boom 4.5m	2578
Spare Wheels - Rear (M03 & M13)	2470	Quick Attach, Digger - Sideshift Solenoid Valve	2580
Spare Wheels - Rear (M01 & M04)	2472	Quick Attach, Digger - Centremount Standard Dipper	2582
Spare Wheels - Rear (M20)	2474	Quick Attach, Digger - Centremount Standard Dipper	2584
Spare Wheels - Rear (M22)	2476	Quick Attach, Digger - Centremount Solenoid Valve	2586
Spare Wheels - Rear (M07, M10 & M12)	2478	Quick Attach, Digger - Centremount Telescopic Dipper	2588
Spare Wheels - Rear (M05, M09, M14 & M21)	2480	Quick Attach, Digger - Centremount Telescopic Dipper	2590
Spare Wheels - Rear (M03 & M13)	2482	Quick Attach, Digger - Centremount Solenoid Valve	2592
Spare Wheels - Rear (M01 & M04)	2484	Quick Attach, Digger - Abiljo	2594
Spare Wheels - Rear (M20)	2486	Not Serviced	2596
Spare Wheels - Rear (M22)	2488	Quick Attach, Digger - Sideshift Standard Dipper	2598
Spare Wheels - Rear (M23a & M28a)	2490	Quick Attach, Digger - Sideshift Solenoid Valve	2600
Spare Wheels - Rear (M23a & M28a)	2492	Quick Attach, Digger - Sideshift Standard Dipper	2602
Spare Wheels - Rear (M24a)	2494	Quick Attach, Digger - Sideshift Quick Coupler	2604
Spare Wheels - Rear (M24a)	2496	Quick Attach, Digger - Sideshift Telescopic Dipper	2606
Spare Wheels - Rear (M25a & M29a)	2498	Quick Attach, Digger - Sideshift Telescopic Dipper	2608
Spare Wheels - Rear (M25a & M29a)	2500	Quick Attach, Digger - Sideshift Solenoid Valve	2610
Stepguards	2502	Quick Attach, Digger - Sideshift Quick Coupler	2612
Spare Wheel - Front - White	2504	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2614
Spare Wheel - Front - Yellow	2506	Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m	2616
Spare Wheel - Front - White	2508	Quick Attach, Digger - Centremount Solenoid Valve	2618
Spare Wheel - Front - Yellow	2510	Quick Attach, Digger - Centremount Quick Coupler	2620
Spare Wheel - Front - White	2512	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2622
Spare Wheel - Front - Yellow	2514	Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m	2624
Bucket Pins Kit Case Bucket	2516	Quick Attach, Digger - Centremount Solenoid Valve	2626
Street Pads Kit Sideshift Digger	2518	Quick Attach, Digger - Centremount Quick Coupler	2628
Service Kit - Tier 3 Engine Upgrade	2520	Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2630
Quick Attach, Digger - Sideshift Standard Dipper	2526	Quick Attach, Digger - Sideshift Standard Dipper - Less Q/A	2632
Quick Attach, Digger - Sideshift Standard Dipper	2528	Quick Attach, Digger - Sideshift Solenoid Valve	2634
Quick Attach, Digger - Sideshift Solenoid Valve	2530	Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2636

Quick Attach, Digger - Sideshift Telescopic Dipper - Less Q/A	2638
Quick Attach, Digger - Sideshift Solenoid Valve	2640
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2642
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.5m - Less Q/A	2644
Quick Attach, Digger - Centremount Solenoid Valve	2646
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2648
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.5m - Less Q/A	2650
Quick Attach, Digger - Centremount Solenoid Valve	2652
Quick Attach - Miller Mechanical	2654

THIS PAGE INTENTIONALLY LEFT BLANK


C-10010-01.1-B




Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6112048M91	1	Chassis Complete 2ws Short Ss	Chassis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	



C-10010-02.1-A




Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10010c03.1 1 10010c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3622129M94GY02	2	Cylinder Stab Ss Only (Benford Grey)	L´Hie Hydraulique	Zylinder Hydr.	Gato, Conj.	Tba [10010c02.1 4]
2	3623297M92	1	Barrel Assy	Cylindre De Vérin	Zylinderrohr	Cilindro De Gato	
3	1607690M1	1	Lock Nut M30	Ecrou Frein	Kontermutter	Tuerca	
4	3487067M1	1	Piston Guide Ring 70*10*2	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
5	3485241M1	1	Wear Ring Piston	Anneau	Ring	Aro	
6	3485254M1	1	Ring Pressure	Anneau	Ring	Aro	
7	3487067M1	1	Piston Guide Ring 70*10*2	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
8	3623299M1	1	Piston	Piston	Kolben	Pistón De Gato	
9	359181X1	1	O-Ring (44.04 Mm Nominal I/D) Shore A90	Joint Torique	O - Ring	Junta De Tipo O	
10	359187X1	1	O-Ring-63,09*3,53	Joint Torique	O Ring	Junta De Tipo O	
11	1884170M1	1	Backring-64.06*3*02	Contre-Joint	Stützring	ContraJunta	
12	3487205M1	1	O Ring, Hydr. Cylinder	Joint Torique	O Ring	Junta De Tipo O	
13	3623298M1	1	Bearing Cylinder	Roulement	Lager	Palier De Gato	
14	3443386M1	1	Retaining Plug	Bouchon	Stopfen	Tapón	
15	3491486M1	1	Bush, Piston Rod/Gland	Douille	Büchse	Anillo	
16	3443341M1	1	Ring Buffer	Bague D`Étanchéité	Dichtungsring	Anillo, Estanqueidad	
17	1606464M1	1	Seal	Joint D´Arbre	Wellendichtring	Junta	
18	1606575M1	1	Wiper Ring	Anneau	Ring	Junta Raspador	
19	3441606M91	1	Piston Rod Assy	Tige De Vérin	Kolbenstange	Vástago Cilindro	
20	3623300M91	1	Kit Seal	Jeu Étanchéité	Dichtringsatz	Juego De Juntas	




C-10010-03.2-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6111068M91GY03	2	Cylinder Stabiliser S/S	Cylindre	Zylinder	Gato, Conj.	Tba [10010c02.1 4]
2	6194596M91	1	Barrel - Cylinder	Corps Cylindre	Zylindergehause	Tubo	
3	6194600M1	1	Nut - Nyloc	Ecrou Blocage	Flachmutter	Tuerca	
4	6194606M1	1	Bearing - Piston	Coussinet	Lager	Teniendo - Pistón	
5	6194604M1	1	Seal - Piston	Joint Étanchéité	Dichtring	Junta	
6	6194605M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
7	6194598M1	1	Piston	Piston	Kolben	Pistón	
8	6194607M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
9	6194601M1	1	Stop Tube	Tube Butee	Rohr Anschlag	Pare - Tubo	
10	6194613M1	1	Ring - Back Up	Contre Bague	Stutzring	ContraJunta	
11	6194612M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
12	6194602M1	1	Bush - Bimetal	Douille	Büchse	Juego De Anillos	
13	6194599M1	1	End Cover - Head	Couvercle	Deckel	Tapa	
14	6194609M1	1	O Ring (Std)	Joint Torique	O Ring	Junta De Tipo O	
15	6194608M1	1	Seal - Rod (Primary)	Joint Étanchéité	Dichtring	Junta	
16	6194610M1	1	Seal- Rod (Secondary)	Joint Étanchéité	Dichtring	Junta	
17	6194611M1	1	Wiper	Essuyeur	Wischer	Raspador, Escobilla	
18	6194603M1	1	Ring - Snap	Fermeoir	Sprengring	Anillo De Resorte	
19	6194597M91	1	Rod - Piston	Bielle De Piston	Pleuelstange	Rod - Pistón	
20	6194614M91	0	Seal Kit	Jeu Etancheite	Dichtringsatz	Juego De Juntas	




C-10013-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6110037M93	1	Chassis - Centremount (W/Assy) Short	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passstift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	


C-10019-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6112381M91	1	Chassis Complete 2ws Short Ss	Chassis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	6112725M1	1	Seal - Cooling Pack - Short Drop Chassis	Joint	Dichtung	Junta	Tier 3 Only



C-10019-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	3521289M3	2	Pin Stabiliser Cyl.	Axe	Bolzen	Pasador	
2	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
3	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
4	#CYLINDER ASSY	2	Cylinder Assy	Cylinder Assy	Cylinder Assy	Cylinder Assy	10019c03.1 1 10019c03.2 1
5	3521279M2	2	Spacer	Entretoise	Distanzstück	Traviesa	
6	1440478X1	2	Circlip 45mm	Segment D´Arrêt	Sicherungsring	Anillo De Resorte	
7	3518936M1	0	Pad Wear Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3518965M1	0	Wear Pad Natural-6.0mm	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3517077M1	0	Pad Sq Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108416M1	0	Wear Pad-Sq're Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	6108417M1	0	Wear Pad-Sq're Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3521199M3	0	Pad Square Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
7	3516684M2	0	Pad Square Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
8	6108420M91	2	Stabiliser Leg Assy Inner S/S	Tige	Schaft	Varilla	
9	3519716M1	0	Pad Round Red 6.5/6.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519714M1	0	Pad Round Grey 5.5/5.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519713M1	0	Pad Round Blac 5.0/4.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519712M1	0	Pad Round Yell 4.5/4.25	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	3519715M1	0	Pad Round Natl 6.0/5.75	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108419M1	0	Wear Pad-Round Green 3.60/3.40	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
9	6108418M1	0	Wear Pad-Round Blue 4.00/3.80	Patin D¿Usure	Verschleißkissen	Patín De Desgaste	
10	6102864M1	2	Foot Stabiliser S/S	Pied	Fuß	Pie	Feb 2008
10	6112386M1	2	Stabiliser Foot - Sideshift	Pied	Fuß	Pie	Feb 2008
11	3522879M2	2	Pin Stabiliser Foot S/S	Axe	Bolzen	Pasador	
12	1442169X1	2	Cap Screw Soc.Hd.M10 X 90	Vis A Tete Six Pans	Zylinderschraube	Tornillo	
13	1440329X1	2	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	



Digger Stabilisers - Sideshift Stabilizer Cylinder


4067 10019

Product: 2010 TEREX TX860B Backhoe Loader Workshop Parts Manual

Full Download: <https://www.arepairmanual.com/downloads/2010-terex-tx860b-backhoe-loader-workshop-parts-manual/>

[ckhoe-loader-workshop-parts-manual/](https://www.arepairmanual.com/downloads/2010-terex-tx860b-backhoe-loader-workshop-parts-manual/)

C-10019-03.1-A



Sample of manual. Download All 2657 pages at:

<https://www.arepairmanual.com/downloads/2010-terex-tx860b-backhoe-loader-workshop-parts-manual/>