

Product: 2010 Terex TX870B Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-tx870b-backhoe-loader-workshop-parts-manual/>

SPARES

BACKHOE LOADER

TX870B

Publication No. August 2010

Product: 2010 Terex TX870B Backhoe Loader Workshop Parts Manual
Full Download: <https://www.arepairmanual.com/downloads/2010-tx870b-backhoe-loader-workshop-parts-manual/>

Sample of manual. Download All 2241 pages at:
<https://www.arepairmanual.com/downloads/2010-tx870b-backhoe-loader-workshop-parts-manual/>

Contents

Chassis - Centremount Short	12
Chassis - Centremount Short	14
Engine Cover Yellow	16
Engine Cover White	20
Front Axle - Installation 2 Wheel Drive/2 Wheel Steer	24
Front Axle - Housing 2 Wheel Drive/2 Wheel Steer	26
Front Axle - Steering Pivot 2 Wheel Drive/2 Wheel Steer	28
Front Axle - Wheel Hub 2 Wheel Drive/2 Wheel Steer	30
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	32
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	34
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	36
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	38
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	40
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	42
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	44
Front Axle - Installation	46
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	48
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	50
Front Axle - Installation	52
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	54
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	56
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	58
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	60
Front Axle - Installation 4 Wheel Drive/2 Wheel Steer	62
Steering System 2 Wheel Steer	64
Front Wheels	66
Rear Wheels	68
Front Wheels	70
Rear Wheels	72
Rear Wheels	74
Front Wheels	76
Front Wheels	78
Rear Wheels	80
Front Wheels	82
Rear Wheels	84
Front Wheels	86
Rear Wheels	88
Hardnose And Grille	90
Engine - Engine Installation Rg38099	92
Engine - Cylinder Block Rg38099	94
Engine - Pistons And Crankshaft Rg38099	96
Engine - Cylinder Head Rg38099	100
Engine - Rockers Rg38099	102
Engine - Camshaft Rg38099	104
Engine - Lubricating Oil Filler And Breather Rg38099	106
Engine - Turbocharger Connections Rg38099	110
Engine - Exhaust Manifold Rg38099	112
Engine - Thermostat And Water Filter Rg38099	114
Engine - Water Pump Rg38099	116
Engine - Crankshaft Pulley Rg38099	118
Engine - Flywheel Rg38099	120
Engine - Flywheel Housing Rg38099	122

Engine - Oil Pan Rg38099	124	Engine - Flywheel Housing Tier 3	240
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38099	126	Engine - Oil Pan Tier 3	242
Engine - Oil Pump Rg38099	128	Engine - Oil Filter And Integral Oil Cooler Tier 3	244
Engine - Fuel System Rg38099	130	Engine - Oil Pump Tier 3	246
Engine - Fuel Lift Pump Rg38099	134	Engine - Fuel System Tier 3	248
Engine - Filter With Fuel Separator Up To Serial Number Tba	136	Engine - Fuel Lift Pump Tier 3	252
Engine - Filter With Fuel Separator From Serial Number Tba	138	Engine - Fuel Pipes Tier 3	254
Engine - Alternator And Mounting Rg38099	140	Engine - Filter With Fuel Separator Tier 3	256
Engine - Glow Plugs Rg38099	142	Engine - Alternator And Mounting Tier 3	258
Engine - Engine Lifting Rg38099	144	Engine - Fan Drive Tier 3	260
Engine - Plug And Blank-Off Plug Rg38099	146	Engine - Glow Plugs Tier 3	262
Engine - Joints And Gaskets Rg38099	148	Engine - Starter Motor Tier 3	264
Engine - Joints And Gaskets Rg38099	150	Engine - Plugs And Mounts Tier 3	266
Engine - Engine Installation Rg38044	152	Engine - Cylinder Head Auxiliaries Tier 3	268
Engine - Cylinder Block Rg38044	154	Fuel System	270
Engine - Pistons And Crankshaft Rg38044	156	Fuel System - Fuel Tank	272
Engine - Cylinder Head Rg38044	160	Fuel System Tier 3	274
Engine - Rockers Rg38044	162	Fuel System - Fuel Tank Tier 3	276
Engine - Camshaft Rg38044	164	Exhaust System From Serial Number H200 7 1093	278
Engine - Lubricating Oil Filler And Breather Rg38044	166	Induction System - Air Filtration	280
Engine - Turbocharger Connections Rg38044	170	Induction System - Air Filter	282
Engine - Exhaust Manifold Rg38044	172	Induction System - Air Filtration With Pre Cleaner	284
Engine - Thermostat And Water Filter Rg38044	174	Induction System - Air Filter	286
Engine - Water Pump Rg38044	176	Cooling System ROPS	288
Engine - Crankshaft Pulley Rg38044	178	Cooling System - Radiator Assembly ROPS	290
Engine - Flywheel Rg38044	180	Cooling System Without Air Conditioning	292
Engine - Flywheel Housing Rg38044	182	Cooling System - Radiator Assembly Without Air Conditioning	296
Engine - Oil Pan Rg38044	184	Cooling System With Air Conditioning	298
Engine - Lubricating Oil Filter And Integral Oil Cooler Rg38044	186	Cooling System - Radiator Assembly With Air Conditioning	302
Engine - Oil Pump Rg38044	188	Cooling System ROPS	304
Engine - Fuel System Rg38044	190	Cooling System - Radiator Assembly ROPS	308
Engine - Fuel Lift Pump Rg38044	194	Cooling System Without Air Conditioning	310
Engine - Filter With Fuel Separator Up To Serial Number Tba	196	Cooling System - Radiator Assembly Without Air Conditioning	314
Engine - Filter With Fuel Separator From Serial Number Tba	198	Cooling System With Air Conditioning	316
Engine - Alternator And Mounting Rg38044	200	Cooling System - Radiator Assembly With Air Conditioning	320
Engine - Glow Plugs Rg38044	202	Torque Converter	322
Engine - Engine Lifting Rg38044	204	Drive Line Bolting	324
Engine - Plug And Blank-Off Plug Rg38044	206	Drive Line Bolting	328
Engine - Joints And Gaskets Rg38044	208	Drive Line Bolting	332
Engine - Joints And Gaskets Rg38044	210	Drive Line Bolting Powershift	336
Engine - Engine Installation Tier 3	212	Transmission - Oil Filler 2 Wheel Drive	340
Engine - Cylinder Block Tier 3	214	Transmission - Drive Shaft 2 Wheel Drive	342
Engine - Pistons And Crankshaft Tier 3	216	Transmission - Housing 2 Wheel Drive	344
Engine - Cylinder Head Tier 3	218	Transmission - Input Shaft 2 Wheel Drive	350
Engine - Rockers And Camshaft Tier 3	220	Transmission - Reverse Idler Shaft 2 Wheel Drive	354
Engine - Timing Case Tier 3	222	Transmission - Main Shaft 2 Wheel Drive	356
Engine - Lubricating Oil Filler And Breather Tier 3	224	Transmission - Output Shaft 2 Wheel Drive	358
Engine - Turbocharger Connections Tier 3	228	Transmission - Oil Filler 2 Wheel Steer	362
Engine - Exhaust Manifold Tier 3	230	Transmission - Drive Shaft 2 Wheel Steer	364
Engine - Thermostat And Water Pipes Tier 3	232	Transmission - Converter Housing Powershift	366
Engine - Water Pump Tier 3	234	Transmission - Housing Powershift	372
Engine - Crankshaft Pulley Tier 3	236	Transmission - Charging Pump Powershift	376
Engine - Flywheel Tier 3	238	Transmission - Charging Pump Powershift	378

Transmission - Fwd Low / Fwd High Shaft Powershift	380	Consumable	516
Transmission - Reverse / First Shaft Powershift	384	Consumable	518
Transmission - Input Shaft Powershift	388	Consumable	520
Transmission - Second Shaft Powershift	390	Consumable	522
Transmission - Second Shaft Powershift	394	Consumable	524
Transmission - Control Valve Mounting Powershift	398	Consumable	526
Transmission - Control Valve Powershift	400	Consumable	528
Transmission - Drive Plate Powershift	404	Gear Change - Control Lever 4 Speed	530
Transmission - Drive Shaft 4 Wheel Drive	406	Gear Change - Transmission Control Unit 4 Speed	532
Transmission - Oil Filler 4 Wheel Drive	408	Gear Change - Transmission Control Unit 3 Speed	534
Transmission - Oil Filler 4 Wheel Drive	410	Gear Change - Control Lever 4 Speed	536
Transmission - Oil Filter 4 Wheel Drive	412	Gear Change - Control Lever 3 Speed	538
Transmission - Charging Pump 4 Wheel Drive	414	Gear Change - Transmission Control Unit 4 Speed	540
Transmission - Oil Strainer 4 Wheel Drive	416	Rear Axle 2 Wheel Steer	542
Transmission - Housing 4 Wheel Drive	418	Rear Axle - Housing 2 Wheel Steer	544
Transmission - Input Shaft 4 Wheel Drive	422	Rear Axle - Centre Housing 2 Wheel Steer	546
Transmission - Reverse / First Shaft 4 Wheel Drive	426	Rear Axle - Wheel Hub 2 Wheel Steer	548
Transmission - Second Shaft 4 Wheel Drive	428	Rear Axle - Epicyclic Reduction Gear 2 Wheel Steer	550
Transmission - 4 Wheel Drive Shaft 4 Wheel Drive	432	Rear Axle - Brakes 2 Wheel Steer	552
Transmission - Fork And Gearshift Rails 4 Wheel Drive	434	Rear Axle - Brake Caliper	554
Transmission - Control Valve 4 Wheel Drive	436	Rear Axle - Brake Caliper	556
Transmission - Control Valve 4 Wheel Drive	440	Rear Axle - Differential Bevel Gear - 2 Wheel Steer	558
Transmission - Solenoid Valve 4 Wheel Drive	444	Rear Axle - Differential 2 Wheel Steer	560
Transmission - Drive Shaft 2 Wheel Drive	446	Rear Axle - Differential Lock Mechanism 2 Wheel Steer	562
Transmission - Oil Filler 2 Wheel Drive	448	Rear Axle 2 Wheel Steer	564
Transmission - Oil Filter 2 Wheel Drive	450	Rear Axle - Housing 2 Wheel Steer	566
Transmission - Charging Pump 2 Wheel Drive	452	Rear Axle - Centre Housing 2 Wheel Steer	568
Transmission - Oil Strainer 2 Wheel Drive	454	Rear Axle - Wheel Hub 2 Wheel Steer	570
Transmission - Housing 2 Wheel Drive	456	Rear Axle - Epicyclic Reduction Gear 2 Wheel Steer	572
Transmission - Input Shaft 2 Wheel Drive	458	Rear Axle - Brakes 2 Wheel Steer	574
Transmission - Reverse / First Shaft 2 Wheel Drive	460	Rear Axle - Brake Caliper	576
Transmission - Second Shaft 2 Wheel Drive	462	Rear Axle - Brake Caliper	578
Transmission - Fork And Gearshift Rails 2 Wheel Drive	466	Rear Axle - Differential Bevel Gear	580
Transmission - Control Valve 2 Wheel Drive	468	Rear Axle - Differential 2 Wheel Steer	582
Transmission - Drive Shaft 4 Wheel Drive	472	Rear Axle - Differential Lock Mechanism 2 Wheel Steer	584
Transmission - Oil Filler 4 Wheel Drive	474	Rear Axle 2 Wheel Steer	586
Transmission - Oil Filter 4 Wheel Drive	476	Rear Axle 2 Wheel Steer	588
Transmission - Charging Pump 4 Wheel Drive	478	Rear Axle 2 Wheel Steer	590
Transmission - Housing 4 Wheel Drive	480	Rear Axle 2 Wheel Steer	592
Transmission - Housing 4 Wheel Drive	482	Rear Axle 2 Wheel Steer	594
Transmission - Input Shaft 4 Wheel Drive	484	Rear Axle 2 Wheel Steer	596
Transmission - Reverse / First Shaft 4 Wheel Drive	486	Rear Axle 2 Wheel Steer	598
Transmission - Second Shaft 4 Wheel Drive	488	Rear Axle 2 Wheel Steer	600
Transmission - Output Shaft 4 Wheel Drive	492	Rear Axle 2 Wheel Steer	602
Transmission - Control Valve 4 Wheel Drive	494	Rear Axle - Brake Caliper	604
Consumable	496	Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	606
Consumables	498	Hydraulic Valve - Backhoe Control Inlet	608
Consumables	500	Hydraulic Valve - Backhoe Control Slew	612
Consumable	502	Hydraulic Valve - Backhoe Control Boom	618
Consumables	504	Hydraulic Valve - Backhoe Control Dipper	624
Consumable	510	Hydraulic Valve - Backhoe Control Bucket	630
Consumable	512	Hydraulic Valve - Backhoe Control Stabilizer	636
Consumable	514	Hydraulic Valve - Backhoe Control Auxiliary	640

Hydraulic Valve - Backhoe Control Outlet	646	Service Brake - Brake Circuit From Serial Number Tba	766
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	648	Service Brake - Brake Circuit From Serial Number Tba	768
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	650	Service Brake - Brake Circuit From Serial Number Tba	770
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	652	Service Brake - Brake Circuit From Serial Number Tba	772
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	654	Differential Lock Synchro Shuttle	774
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	656	Differential Lock - Controls Solenoid Valve	776
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	658	Differential Lock Powershift	778
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	660	Differential Lock Synchro Shuttle	780
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	662	Parking Brake	782
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	664	Parking Brake 4 Post ROPS	784
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	666	Cab - 4 Post ROPS	786
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	670	Cab - Rear Worklight	788
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	672	Cab - Relay Bracket	790
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	674	Cab - Frame	792
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	676	Cab - Door	796
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	678	Cab - Rear Window	802
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	680	Cab - Outer Roof	806
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	682	Cab - Front Worklight	810
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	684	Cab - Rear Worklight	812
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	686	Cab - Inner Roof	814
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	690	Cab - Frame	816
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	692	Cab - Door	820
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	694	Cab - Rear Window	826
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	696	Cab - Outer Roof	830
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	698	Cab - Inner Roof	834
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	700	Cab Trim - Windscreen Wiper	836
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	702	Cab - Front Worklight	838
Hydraulic Valve - Backhoe Control Centre Mounted Digger Installation	704	Cab - Rear Worklight	840
Torque Converter - Hydraulic Lines	706	Cab Trim - Heater	842
Torque Converter - Hydraulic Lines	708	Cab Trim - Console	844
Main Hydraulics - Hydraulic Lines Synchro Shuttle	710	Cab Trim - Console RH	846
Main Hydraulics - Hydraulic Lines Synchro Shuttle	714	Cab Side Console - Fuse & Relay Board	848
Main Hydraulics - Oil Filter Synchro Shuttle	718	Cab Trim - Cab Mounting	852
Main Hydraulics - Solenoid Valve Synchro Shuttle	720	Cab Trim - Floorplate Cab	854
Hydraulic Reservoir Synchro Shuttle	722	Cab Trim - Console	856
Main Hydraulics - Tandem Pump Synchro Shuttle	724	Cab Trim - Windscreen Wiper	858
Main Hydraulics - Tandem Pump Synchro Shuttle	726	Cab Trim - Cab Mounting 4 Post ROPS	860
Main Hydraulics - Hydraulic Lines Synchro Shuttle	728	Cab Trim - Floorplate 4 Post ROPS	862
Main Hydraulics - Hydraulic Lines Synchro Shuttle	732	Cab Trim - Cab Mounting 4 Post ROPS	864
Main Hydraulics - Oil Filter Synchro Shuttle	736	Cab Trim - Floorplate 4 Post ROPS	866
Main Hydraulics - Solenoid Valve Synchro Shuttle	738	Cab Trim - Cab Mounting	868
Hydraulic Reservoir Synchro Shuttle	740	Cab Trim - Floorplate	870
Main Hydraulics - Tandem Pump Synchro Shuttle	742	Cab Trim - Console	872
Control Box - Installation From Serial Number Tba	744	Cab Trim - Windscreen Wiper	874
Control Box Control Pedals	746	Cab Trim - Cab Mounting 4 Post ROPS	876
Control Box Hydraulics	750	Cab Trim - Floorplate 4 Post ROPS	878
Control Box Brake Cylinder	752	Cab Trim - Cab Mounting 4 Post ROPS	880
Control Box Steering	754	Cab Trim - Floorplate 4 Post ROPS	882
Throttle Controls	756	Cab Trim - Cab Mounting	884
Throttle Controls Lever, Control	758	Cab Trim - Floorplate Cab	886
Tool Kit - Wheel Brace + Grease Gun	760	Cab Trim - Console	888
Service Brake - Brake Circuit From Serial Number Tba	762	Cab Trim - Windscreen Wiper	890
Service Brake - Brake Circuit From Serial Number Tba	764	Cab Trim - Cab Mounting 4 Post ROPS	892

Cab Trim - Floorplate 4 Post ROPS	894	Front Console Cab	1008
Cab Trim - Cab Mounting	896	Front Console - Instrument Panel Cab	1010
Cab Trim - Floorplate	898	Front Console - Forward/Reverse Switch Cab	1012
Cab Trim - Console	900	Front Console - Installation ROPS	1014
Cab Trim - Windscreen Wiper	902	Front Console ROPS	1016
Cab Trim - Cab Mounting 4 Post ROPS	904	Front Console - Instrument Panel ROPS	1018
Cab Trim - Floorplate 4 Post ROPS	906	Front Console - Forward/Reverse Switch ROPS	1020
Cab Trim - Cab Mounting	908	Front Console - Installation ROPS	1022
Cab Trim - Floorplate & Digger Tower	910	Front Console ROPS	1024
Cab Trim - Cab Mounting	912	Front Console - Instrument Panel ROPS	1026
Cab Trim - Floorplate & Digger Tower	914	Front Console - Forward/Reverse Switch ROPS	1028
Cab Trim - Mats	916	Front Console - Installation Cab	1030
Cab Trim - Mats	918	Front Console Cab	1032
Cab Trim - Mats	920	Front Console - Instrument Panel Cab	1034
Cab Trim - Mats	922	Front Console - Forward/Reverse Switch Cab	1036
Not Serviced	924	Front Console - Installation Cab	1038
Cab Environment - Heater Installation Front	926	Front Console Cab	1040
Cab Environment - Heater Installation Rear	930	Front Console - Instrument Panel Cab	1042
Cab Environment - Heater Unit	932	Front Console - Forward/Reverse Switch Cab	1044
Cab Environment - Air Conditioning Installation	934	Front Console - Installation ROPS	1046
Cab Environment - Heater Installation Front	938	Front Console ROPS	1048
Cab Environment - Air Conditioning Installation Rear	942	Front Console - Instrument Panel ROPS	1050
Cab Environment - Air Conditioning Unit	944	Front Console - Forward/Reverse Switch ROPS	1052
Cab Environment - Less Heater Unit ROPS	948	Front Console - Installation ROPS	1054
Front Console - Installation ROPS	950	Front Console ROPS	1056
Front Console ROPS	952	Front Console - Instrument Panel ROPS	1058
Front Console - Instrument Panel ROPS	954	Front Console - Forward/Reverse Switch ROPS	1060
Front Console - Forward/Reverse Switch ROPS	956	Front Console - Installation Cab	1062
Front Console - Installation Cab	958	Front Console Cab	1064
Front Console Cab	960	Front Console - Instrument Panel Cab	1066
Front Console - Instrument Panel Cab	962	Front Console - Forward/Reverse Switch Cab	1068
Front Console - Forward/Reverse Switch Cab	964	Front Console - Installation ROPS	1070
Front Console - Installation ROPS	966	Front Console ROPS	1072
Front Console ROPS	968	Front Console - Instrument Panel ROPS	1074
Front Console - Instrument Panel ROPS	970	Front Console - Forward/Reverse Switch ROPS	1076
Front Console - Forward/Reverse Switch ROPS	972	Front Console - Installation Cab	1078
Front Console - Installation ROPS	974	Front Console Cab	1080
Front Console ROPS	976	Front Console - Instrument Panel Cab	1082
Front Console - Instrument Panel ROPS	978	Front Console - Forward/Reverse Switch Cab	1084
Front Console - Forward/Reverse Switch ROPS	980	Front Console - Installation Cab	1086
Front Console - Installation Cab	982	Front Console Cab	1088
Front Console Cab	984	Front Console - Instrument Panel Cab	1090
Front Console - Instrument Panel Cab	986	Front Console - Forward/Reverse Switch Cab	1092
Front Console - Forward/Reverse Switch Cab	988	Front Console - Installation ROPS	1094
Front Console - Installation ROPS	990	Front Console ROPS	1096
Front Console ROPS	992	Front Console - Instrument Panel ROPS	1098
Front Console - Instrument Panel ROPS	994	Front Console - Forward/Reverse Switch ROPS	1100
Front Console - Forward/Reverse Switch ROPS	996	Front Console - Installation ROPS	1102
Front Console - Installation ROPS	998	Front Console ROPS	1104
Front Console ROPS	1000	Front Console - Instrument Panel ROPS	1106
Front Console - Instrument Panel ROPS	1002	Front Console - Forward/Reverse Switch ROPS	1108
Front Console - Forward/Reverse Switch ROPS	1004	Front Console - Installation Cab	1110
Front Console - Installation Cab	1006	Front Console Cab	1112

Front Console - Instrument Panel Cab	1114	Ride Control - Hydraulic Circuit Solenoid Valve	1234
Front Console - Forward/Reverse Switch Cab	1116	Ride Control - Hydraulic Circuit	1236
Front Console - Installation Cab	1118	Ride Control - Hydraulic Circuit Solenoid Valve	1238
Front Console Cab	1120	Ride Control - Hydraulic Circuit ROPS	1240
Front Console - Instrument Panel Cab	1122	Ride Control - Hydraulic Circuit Solenoid Valve	1242
Front Console - Forward/Reverse Switch Cab	1124	Ride Control - Hydraulic Circuit ROPS	1244
Side Console Switchpack	1126	Ride Control - Hydraulic Circuit Solenoid Valve	1246
Side Console - Instrument Panel Switchpack	1130	Loader - Arms Yellow	1248
Side Console - Fuse & Relay Board	1132	Loader - Links Yellow	1252
Side Console 4 Post ROPS	1134	Loader - Return To Dig Mechanical	1254
Side Console - Instrument Panel Rocker Switch	1138	Loader - Return To Dig Mechanical	1258
Side Console - Fuse & Relay Board	1140	Loader - Safety Strut	1262
Side Console Switchpack	1142	Loader - Arms White	1264
Side Console - Instrument Panel Switchpack	1144	Loader - Links White	1268
Chassis Electrics	1146	Loader - Return To Dig Mechanical	1270
Chassis Electrics	1150	Loader - Return To Dig Mechanical	1274
Chassis Electrics Synchro Shuttle - Carraro	1154	Loader - Safety Strut	1278
Battery - Single From Serial Number H200 4 2919	1158	Loader Bucket - Standard For Use With Forks	1280
Battery - Dual From Serial Number H200 4 2919	1160	Loader Bucket - Standard For Use With Forks	1282
Battery - Single Tier 3	1162	Loader Bucket - 7 In 1	1284
Battery - Dual Tier 3	1164	Loader Bucket - 7 In 1 Bucket Pipework	1286
Rear Lighting - Centremount	1166	Loader Bucket - 7 In 1 Cylinder	1288
Rear Lighting - ROPS	1168	Loader Bucket - 7 In 1	1290
Rear Lighting - ROPS 4 Post ROPS	1170	Loader Bucket - 7 In 1 Bucket Pipework	1292
Front Lighting - Headlights Left Hand Dip	1172	Loader Bucket - 7 In 1 Cylinder	1294
Front Lighting - Headlights Right Hand Dip	1174	Loader Bucket Less Bucket	1296
Mirrors - Cab	1176	Loader Hydraulics - Lift Cylinder High Speci•cation	1298
Mirrors - ROPS 4 Post ROPS	1178	Loader Hydraulics - Lift Cylinder High Speci•cation Pacoma	1302
Seat - Seat Installation Fabric Trim - Cab Machines	1180	Loader Hydraulics - Lift Cylinder High Speci•cation Wipro	1304
Seat - Fabric Trim Cab	1182	Loader Hydraulics - Bucket Cylinder High Speci•cation	1306
Seat - Seat Installation Air Suspension	1184	Loader Hydraulics - Bucket Cylinder High Speci•cation Pacoma	1310
Seat - Fabric Trim Air Suspension	1186	Loader Hydraulics - Bucket Cylinder High Speci•cation Wipro	1312
Seat - Seat Installation Weatherproof P.V.C. Trim	1188	Loader Hydraulics - Lift Cylinder High Speci•cation	1314
Seat - Weatherproof P.V.C. Trim 4 Post ROPS	1190	Loader Hydraulics - Lift Cylinder High Speci•cation Pacoma	1318
Seat - Weatherproof P.V.C. Trim Air Suspension	1192	Loader Hydraulics - Lift Cylinder High Speci•cation Wipro	1320
Seat - Seat Installation Air Suspension	1194	Loader Hydraulics - Bucket Cylinder High Speci•cation	1322
Front Fenders 2 Wheel Steer	1200	Loader Hydraulics - Bucket Cylinder High Speci•cation Pacoma	1326
Ride Control - Hydraulic Circuit English	1202	Loader Hydraulics - Bucket Cylinder High Speci•cation Wipro	1328
Ride Control - Hydraulic Circuit English	1204	Loader Hydraulics - Lift Cylinder High Speci•cation	1330
Ride Control - Hydraulic Circuit Less Ride Control	1206	Loader Hydraulics - Lift Cylinder High Speci•cation Pacoma	1334
Ride Control - Hydraulic Circuit French	1208	Loader Hydraulics - Lift Cylinder High Speci•cation Wipro	1336
Ride Control - Hydraulic Circuit French	1210	Loader Hydraulics - Bucket Cylinder Standard Speci•cation	1338
Ride Control - Hydraulic Circuit German	1212	Loader Hydraulics - Bucket Cylinder High Speci•cation Pacoma	1340
Ride Control - Hydraulic Circuit German	1214	Loader Hydraulics - Bucket Cylinder High Speci•cation Wipro	1342
Ride Control - Hydraulic Circuit Italian	1216	Loader Hydraulics - Lift Cylinder High Speci•cation	1344
Ride Control - Hydraulic Circuit Italian	1218	Loader Hydraulics - Lift Cylinder High Speci•cation Pacoma	1348
Ride Control - Hydraulic Circuit Spanish	1220	Loader Hydraulics - Lift Cylinder High Speci•cation Wipro	1350
Ride Control - Hydraulic Circuit Spanish	1222	Loader Hydraulics - Bucket Cylinder High Speci•cation	1352
Ride Control - Hydraulic Circuit Dutch	1224	Loader Hydraulics - Bucket Cylinder High Speci•cation Pacoma	1356
Ride Control - Hydraulic Circuit Dutch	1226	Loader Hydraulics - Bucket Cylinder High Speci•cation Wipro	1358
Ride Control - Hydraulic Circuit Danish	1228	Loader Hydraulics - Lift Cylinder High Speci•cation	1360
Ride Control - Hydraulic Circuit Danish	1230	Loader Hydraulics - Lift Cylinder High Speci•cation Pacoma	1364
Ride Control - Hydraulic Circuit	1232	Loader Hydraulics - Lift Cylinder High Speci•cation Wipro	1366

Loader Hydraulics - Bucket Cylinder High Specification	1368	Loader Controls - Hydraulic Valve Loader Arm Section	1500
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1372	Loader Controls - Hydraulic Valve Standard Bucket Section	1506
Loader Hydraulics - Bucket Cylinder High Specification Wipro	1374	Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1512
Loader Hydraulics - Lift Cylinder High Specification	1376	Loader Controls - Hydraulic Valve Outlet	1518
Loader Hydraulics - Lift Cylinder High Specification Pacoma	1380	Loader Controls - Upper Control Levers	1520
Loader Hydraulics - Lift Cylinder High Specification Wipro	1382	Loader Controls - Lower Control Levers	1522
Loader Hydraulics - Bucket Cylinder High Specification	1384	Loader Controls - Control Valve	1526
Loader Hydraulics - Bucket Cylinder High Specification Pacoma	1388	Loader Controls - Hydraulic Valve Inlet	1528
Loader Hydraulics - Bucket Cylinder High Specification Wipro	1390	Loader Controls - Hydraulic Valve Loader Arm Section	1530
Hose Burst Kit Loader Arm Cylinder	1392	Loader Controls - Hydraulic Valve Standard Bucket Section	1536
Hose Burst Kit Loader Bucket Cylinder	1396	Loader Controls - Hydraulic Valve Bucket Section, 7 In-1	1542
Hose Burst Kit Boom Cylinder	1400	Loader Controls - Hydraulic Valve Outlet	1548
Hose Burst Kit Dipper Cylinder	1402	Loader Controls Upper Control Levers	1550
Hose Burst Kit Boom Cylinder	1404	Loader Controls Lower Control Levers	1552
Hose Burst Kit Dipper Cylinder	1406	Loader Controls Control Valve	1556
Hose Burst Kit Boom Cylinder	1408	Loader Controls - Hydraulic Valve Inlet	1558
Hose Burst Kit Dipper Cylinder	1410	Loader Controls - Hydraulic Valve Loader Arm Section	1560
Loader Controls Upper Control Levers	1412	Loader Controls - Hydraulic Valve Standard Bucket Section	1562
Loader Controls Lower Control Levers	1416	Loader Controls - Hydraulic Valve Standard Bucket Section	1564
Loader Controls Control Valve	1420	Loader Controls - Hydraulic Valve Standard Bucket Section	1566
Loader Controls - Hydraulic Valve Inlet	1422	Loader Controls Upper Control Levers	1568
Loader Controls - Hydraulic Valve Loader Arm Section	1424	Loader Controls Lower Control Levers	1572
Loader Controls - Hydraulic Valve Standard Bucket Section	1426	Loader Controls Control Valve	1576
Loader Controls - Hydraulic Valve Standard Bucket Section	1428	Loader Controls - Hydraulic Valve Inlet	1578
Loader Controls - Hydraulic Valve Standard Bucket Section	1430	Loader Controls - Hydraulic Valve Loader Arm Section	1580
Loader Controls Upper Control Levers	1432	Loader Controls - Hydraulic Valve Standard Bucket Section	1582
Loader Controls Lower Control Levers	1436	Loader Controls - Hydraulic Valve Standard Bucket Section	1584
Loader Controls Control Valve	1440	Loader Controls - Hydraulic Valve Standard Bucket Section	1586
Loader Controls - Hydraulic Valve Inlet	1442	Loader Controls Upper Control Levers	1588
Loader Controls - Hydraulic Valve Loader Arm Section	1444	Loader Controls Lower Control Levers	1590
Loader Controls - Hydraulic Valve Standard Bucket Section	1446	Loader Controls Control Valve	1594
Loader Controls - Hydraulic Valve Standard Bucket Section	1448	Loader Controls - Hydraulic Valve Inlet	1596
Loader Controls - Hydraulic Valve Standard Bucket Section	1450	Loader Controls - Hydraulic Valve Loader Arm Section	1598
Loader Controls Upper Control Levers	1452	Loader Controls - Hydraulic Valve Standard Bucket Section	1600
Loader Controls Lower Control Levers	1454	Loader Controls - Hydraulic Valve Standard Bucket Section	1602
Loader Controls Control Valve	1458	Loader Controls - Hydraulic Valve Standard Bucket Section	1604
Loader Controls - Hydraulic Valve Inlet	1460	Loader Controls Upper Control Levers	1606
Loader Controls - Hydraulic Valve Loader Arm Section	1462	Loader Controls Lower Control Levers	1610
Loader Controls - Hydraulic Valve Standard Bucket Section	1464	Loader Controls Control Valve	1614
Loader Controls - Hydraulic Valve Standard Bucket Section	1466	Loader Controls - Hydraulic Valve Inlet	1616
Loader Controls - Hydraulic Valve Standard Bucket Section	1468	Loader Controls - Hydraulic Valve Loader Arm Section	1618
Loader Controls Upper Control Levers	1470	Loader Controls - Hydraulic Valve Standard Bucket Section	1620
Loader Controls Lower Control Levers	1472	Loader Controls - Hydraulic Valve Standard Bucket Section	1622
Loader Controls Control Valve	1476	Loader Controls - Hydraulic Valve Standard Bucket Section	1624
Loader Controls - Hydraulic Valve Inlet	1478	Boom Transport Lock Centre Mounted Digger	1630
Loader Controls - Hydraulic Valve Loader Arm Section	1480	Not Serviced	1632
Loader Controls - Hydraulic Valve Standard Bucket Section	1482	Digger Swing Pivot - Centremount	1634
Loader Controls - Hydraulic Valve Standard Bucket Section	1484	Digger Swing Pivot - Centremount Swing Cylinder Pacoma	1636
Loader Controls - Hydraulic Valve Standard Bucket Section	1486	Digger Swing Pivot - Centremount Swing Cylinder Wipro	1638
Loader Controls - Upper Control Levers 7 In 1 Bucket	1488	Boom	1640
Loader Controls - Lower Control Levers 7 In 1 Bucket	1492	Dipper - Standard	1642
Loader Controls - Control Valve 7 In 1 Bucket	1496	Dipper - Standard	1644
Loader Controls - Hydraulic Valve Inlet	1498	Dipper - Extendahoe	1646


Dipper - Extendahoe Cylinder	1652	Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1786
Dipper - Extendahoe	1654	Digger Hydraulics - Centremount Telescopic Dipper	1788
Dipper - Extendahoe Cylinder	1660	Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1790
Dipper - Standard Case Bucket	1662	Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1792
Dipper - Standard Case Bucket	1664	Digger Hydraulics - Centremount Boom	1794
Dipper - Extendahoe Case Bucket	1666	Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1796
Dipper - Extendahoe Cylinder	1672	Digger Hydraulics - Centremount Boom Cylinder - Wipro	1798
Dipper - Extendahoe Case Bucket	1674	Digger Hydraulics - Centremount Swing Components	1800
Dipper - Extendahoe Cylinder	1680	Digger Controls Standard	1802
Dipper - Standard Jcb Bucket	1682	Digger Controls ISO	1804
Dipper - Standard Jcb Bucket	1684	Digger Controls X Pattern	1808
Dipper - Extendahoe Jcb Bucket	1686	Digger Controls - Servo Pivot	1810
Dipper - Extendahoe Cylinder	1692	Digger Controls - Servo Control Bar	1812
Dipper - Extendahoe Jcb Bucket	1694	Digger Controls - Servo Pilot Control	1814
Dipper - Extendahoe Cylinder	1700	Digger Controls - Servo Joystick	1816
Digger Bucket Linkage	1702	Digger Controls - Servo Trim	1818
Digger Bucket Linkage	1704	Digger Controls - Servo Change Over Valve	1820
Digger Bucket Linkage - Jcb Buckets	1706	Digger Controls - Servo Decals	1824
Digger Bucket Linkage - Jcb Buckets	1708	Digger Controls - Servo Pivot	1826
Digger Bucket Linkage - Case Buckets	1710	Digger Controls - Servo Control Bar	1828
Digger Bucket Linkage - Case Buckets	1712	Digger Controls - Servo Pilot Control	1830
Digger Hydraulics - Centremount Bucket	1714	Digger Controls - Servo Joystick	1832
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1718	Digger Controls - Servo Trim	1834
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1720	Digger Controls - Servo Change Over Valve	1836
Digger Hydraulics - Centremount Standard Dipper	1722	Digger Controls - Servo Decals	1840
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1724	Digger Controls ISO / Sae	1842
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1726	Extendahoe Hydraulics - Centremount Without Auxiliary Hydraulics	1846
Digger Hydraulics - Centremount Boom	1728	Extendahoe Hydraulics - Centremount Control Pedal	1848
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1730	Extendahoe Hydraulics - Centremount With Auxiliary Hydraulics	1850
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1732	Extendahoe Hydraulics - Centremount Control Pedal	1852
Digger Hydraulics - Centremount Swing Components	1734	Extendahoe Hydraulics Less Control Pedal	1854
Digger Hydraulics - Centremount Bucket	1736	Extendahoe Hydraulics Control Pedal	1856
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1740	Not Serviced	1858
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1742	Stabiliser Controls - Centremount Digger	1860
Digger Hydraulics - Centremount Telescopic Dipper	1744	Stabiliser Controls - Centremount Digger	1864
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1746	Stabiliser Controls - Centremount Digger 4 Post ROPS	1866
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1748	Stabiliser Controls - Centremount Digger ROPS	1868
Digger Hydraulics - Centremount Boom	1750	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1872
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1752	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1874
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1754	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1878
Digger Hydraulics - Centremount Swing Components	1756	Auxiliary Hydraulics - Centremount Telescopic Dipper - Boom 4.9m	1880
Digger Hydraulics - Centremount Bucket	1758	Auxiliary Hydraulics - Centremount Standard Dipper	1884
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1762	Auxiliary Hydraulics - Centremount Standard Dipper	1886
Digger Hydraulics - Sideshift Bucket Cylinder - Wipro	1764	Auxiliary Hydraulics - Centremount Control Pedal	1888
Digger Hydraulics - Centremount Standard Dipper	1766	Not Serviced	1890
Digger Hydraulics - Centremount Dipper Cylinder - Pacoma	1768	Digger Bucket - Standard	1892
Digger Hydraulics - Sideshift Dipper Cylinder - Wipro	1770	Digger Bucket - Standard	1894
Digger Hydraulics - Centremount Boom	1772	Digger Bucket - Standard	1896
Digger Hydraulics - Centremount Boom Cylinder - Pacoma	1774	Digger Bucket - Standard	1898
Digger Hydraulics - Centremount Boom Cylinder - Wipro	1776	Digger Bucket - Standard 305 Mm	1900
Digger Hydraulics - Centremount Swing Components	1778	Digger Bucket - Ditch Cleaning	1902
Digger Hydraulics - Centremount Bucket	1780	Digger Bucket - Ditch Cleaning	1904
Digger Hydraulics - Centremount Bucket Cylinder - Pacoma	1784	Digger Bucket - Gannon 12 In	1906

Digger Bucket - Gannon 18 In	1908	Tooth Guard Kit - With Decal Standard Loader Bucket	2016
Digger Bucket - Gannon 24 In	1910	Transport Height Decal Kit	2018
Not Serviced	1912	Position Indicator - Loader Arm	2020
Digger Bucket - Premium	1914	Transport Lock - Loader	2022
Digger Bucket - Premium	1916	Seat Belt Kit	2024
Digger Bucket - Premium	1918	Fan Guard Without Air Conditioning	2026
Digger Bucket - Premium	1920	Fan Guard With Air Conditioning	2028
Digger Bucket - Premium	1922	Reverse Alarm	2030
Digger Bucket - Ditch Maintenance	1924	Kit - Boom Guard	2032
Digger Bucket - Ditch Maintenance	1926	Bucket Pins Kit Single	2034
Digger Bucket - Ditch Digging	1928	Bucket Pins Kit Double	2036
Digger Bucket - Jcb	1930	Jcb Bucket Pins Kit Single	2038
Digger Bucket - Jcb	1932	Jcb Bucket Pins Kit Double	2040
Digger Bucket - Jcb	1934	Bucket Pins Kit Loader	2042
Digger Bucket - Jcb	1936	Not Serviced	2044
Digger Bucket - Jcb	1938	Not Serviced	2046
Digger Bucket - Ditch Maintenance Jcb Bucket	1940	Digger Craning Eye Kit Centre Mounted Digger	2050
Digger Bucket - Ditch Maintenance Jcb Bucket	1942	Digger Craning Eye Kit Centre Mounted Digger	2052
Not Serviced	1944	Craning Valve Kit Cab	2054
Rear Fenders 2 Wheel Steer	1946	Craning Valve Kit 4 Post ROPS	2058
Rear Fenders 2 Wheel Steer	1948	Front Counterweight Kit	2062
Rear Fenders 4 Post ROPS	1950	Fuel Strainer Kit	2064
Rear Fenders 4 Post ROPS	1952	Not Serviced	2066
Decals - Warnings General Markets	1956	Anti Vandal Kit	2068
Decals - Instructions General Markets	1958	Service Tool Kit	2070
Decals - Miscellaneous General Markets	1960	Rotating Beacon Kit Single	2072
Decals - Warnings General Markets	1962	Rotating Beacon Kit Double	2074
Decals - Instructions General Markets	1964	Worklight Kit	2076
Decals - Miscellaneous General Markets	1966	Seat Armrest Kit	2078
Decals - Warnings North America	1968	Kit - Headrest	2080
Decals - Instructions North America	1970	Steering Wheel Spinner Knob Kit	2082
Decals - Miscellaneous North America	1972	Bucket Blade Kit Narrow	2084
Decals - Warnings North America	1974	Bucket Blade Kit Wide	2086
Decals - Instructions North America	1976	Bucket Tooth Kit Loader Bucket, 7-In-1	2088
Decals - Miscellaneous North America	1978	Hose Burst Kit - Quick Attach Boom Cylinder	2090
Decals - Warnings General Markets	1980	Hose Burst Kit - Quick Attach Boom Cylinder	2094
Decals - Instructions General Markets	1982	Hose Bust Kit - Less Quick Attach Boom Cylinder	2098
Decals - Miscellaneous General Markets	1984	Hose Bust Kit - Less Quick Attach Boom Cylinder	2102
Decals - Warnings Costa Rica	1986	Hose Bust Kit - Less Quick Attach Boom Cylinder	2106
Decals - Instructions Costa Rica	1988	Literature Operator Manual - English	2108
Decals - Miscellaneous Costa Rica	1990	Literature Operator Manual - Spanish	2110
Decals - Warnings Costa Rica	1992	Literature Operator Manual - French	2112
Decals - Instructions Costa Rica	1994	Literature Operator Manual - German	2114
Decals - Miscellaneous Costa Rica	1996	Literature Operator Manual - Danish	2116
Kit - Forks Loader Bucket	1998	Rockguard Kit	2118
Kit - Forks Loader Bucket	2000	Spare Wheels - Rear (M07, M10 & M12)	2120
Kit - Loader Quick Attach Pins	2002	Spare Wheels - Rear (M05, M09, M14 & M21)	2122
Kit - Loader Quick Attach Tubes	2004	Spare Wheels - Rear (M03 & M13)	2124
Kit - Loader Quick Attach	2006	Spare Wheels - Rear (M01 & M04)	2126
Quick Attach, Loader	2008	Spare Wheels - Rear (M20)	2128
Tooth Guard Kit - With Decal Loader Bucket, 7-In-1	2010	Spare Wheels - Rear (M22)	2130
Tooth Guard Kit - With Decal Loader Bucket, 7-In-1	2012	Spare Wheels - Rear (M07, M10 & M12)	2132
Tooth Guard Kit - With Decal Standard Loader Bucket	2014	Spare Wheels - Rear (M05, M09, M14 & M21)	2134

Spare Wheels - Rear (M03 & M13)	2136
Spare Wheels - Rear (M01 & M04)	2138
Spare Wheels - Rear (M20)	2140
Spare Wheels - Rear (M22)	2142
Spare Wheels - Rear (M23a & M28a)	2144
Spare Wheels - Rear (M23a & M28a)	2146
Spare Wheels - Rear (M24a)	2148
Spare Wheels - Rear (M24a)	2150
Spare Wheels - Rear (M25a & M29a)	2152
Spare Wheels - Rear (M25a & M29a)	2154
Stepguards	2156
Spare Wheel - Front - White	2158
Spare Wheel - Front - Yellow	2160
Spare Wheel - Front - White	2162
Spare Wheel - Front - Yellow	2164
Spare Wheel - Front - White	2166
Spare Wheel - Front - Yellow	2168
Bucket Pins Kit Case Bucket	2170
Service Kit - Tier 3 Engine Upgrade	2172
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2178
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2180
Quick Attach, Digger - Centremount Solenoid Valve	2182
Quick Attach, Digger - Centremount Quick Coupler	2184
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2186
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2188
Quick Attach, Digger - Centremount Solenoid Valve	2190
Quick Attach, Digger - Centremount Quick Coupler	2192
Quick Attach, Digger - Centremount Standard Dipper	2194
Quick Attach, Digger - Centremount Standard Dipper	2196
Quick Attach, Digger - Centremount Solenoid Valve	2198
Quick Attach, Digger - Centremount Telescopic Dipper	2200
Quick Attach, Digger - Centremount Telescopic Dipper	2202
Quick Attach, Digger - Centremount Solenoid Valve	2204
Quick Attach, Digger - Abiljo	2206
Not Serviced	2208
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2210
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m	2212
Quick Attach, Digger - Centremount Solenoid Valve	2214
Quick Attach, Digger - Centremount Quick Coupler	2216
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2218
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m	2220
Quick Attach, Digger - Centremount Solenoid Valve	2222
Quick Attach, Digger - Centremount Quick Coupler	2224
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m - Less Q/A	2226
Quick Attach, Digger - Centremount Standard Dipper - Boom 4.9m - Less Q/A	2228
Quick Attach, Digger - Centremount Solenoid Valve	2230
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m - Less Q/A	2232
Quick Attach, Digger - Centremount Telescopic Dipper - Boom 4.9m - Less Q/A	2234
Quick Attach, Digger - Centremount Solenoid Valve	2236
Quick Attach - Miller Mechanical	2238

THIS PAGE INTENTIONALLY LEFT BLANK


C-10013-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6110037M93	1	Chassis - Centremount (W/Assy) Short	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passstift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	




C-10021-01.1-B



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6111968M91	1	Chassis - 2ws Short Cm W/A	Châssis	Fahrgestell	Chasis	
2	#CHASSIS	1	Chassis	Chassis	Chassis	Chassis	Ref. 1
3	1470375M1	6	Threaded Mount Plate	Support De Fixation	Befestigung	Soporte De Fijación	
4	3522954M1	2	Dowel 12 X 55	Goupille Position.	Passtift	Peón	
5	#MOUNT	1	Mount	Mount	Mount	Mount	Ref. 1
6	3521388M5	4	Bush, Lower - Mast/Pivot	Douille	Buechse	Anillo	
7	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
8	3517246M2	2	Bush, Digger Pivot - Centremount	Douille	Büchse	Anillo	
9	339608X1	3	Grease Nipple - M10 X 1 (Zinc)	Nipple De Graissage	Schmiernippel	Engrasador	
10	6112725M1	1	Seal - Cooling Pack - Short Drop Chassis	Joint	Dichtung	Junta	Tier 3 Only




C-12001-01.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6109917M91	1	Bonnet Assy. Complete - Benford Yellow	Capot	Motorhaube	Capó De Motor, Conj.	
2	6100722M91	1	Bonnet: Fermec Yellow (Less Nose-Piece) - N1a	Capot	Motorhaube	Tapa	
3	6101058M92	1	Softnose Assy Bonnet	Ensemble De Nez	Schnauze Kpl.	Morro, Conj.	
4	#NOSE	1	Nose	Nose	Nose	Nose	Ref. 3
5	6101246M1	8	Jack Nut M6	Ecrou	Mutter	Tuerca Especial	
6	6100785M1	2	Insert-M6	Ecrou	Mutter	Inserción	
7	6102674M2	4	Latch Bar - Bonnet Catch	Loquet	Riegel	Picaporte	
8	339804X1	8	Bolt, Hex, - M6 X 25	Goupille	Maschschrb Metr - M6	Tornillo	
9	390971X1	8	Washer M6-12-1 Zwl	Rondelle - M6	Scheibe - M6	Arandela	
10	1440329X1	1	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	
11	6108647M1	1	Bolt - Bonnet Lock	Goupille	Bolzen	Leva	
12	6108646M91	1	Lock Assy. - Bonnet, (Excluding Key)	Ensemble De Verrou	Schloss Kpl.	Cerradura, Conj.	
13	339124X1	2	Bolt M8-16 Z5f	Goupille	Maschschrb Metr - M8	Tornillo	
14	339374X1	2	Washer M8 -21-2 Z	Rondelle Frein - M8	Federring - M8	Arandela De Freno	
15	390972X1	2	Washer M8-17-1 Zwl	Rondelle M8	Scheibe - M8	Arandela	
16	6100960M92	1	Catch Assy., Safety - Bonnet	Loquet Porte	Falle	Picaporte	
17	#BRACKET	1	Bracket	Bracket	Bracket	Bracket	Ref. 16
18	6101529M1	1	Spacer	Entretoise	Distanzstück	Travesa	
19	3521090M3	1	Spring Torsion	Siège De Ressort	Federsitz	Muelle	
20	6106050M91	1	Catch, Safety - Bonnet	Loquet Porte	Falle	Picaporte	
21	390972X1	1	Washer M8-17-1 Zwl	Rondelle M8	Scheibe - M8	Arandela	
22	1440522X1	1	Circlip Ext	Segment D'Arrêt	Sicherungsring	Anillo De Resorte	
23	6101175M2	1	Panel-Soundpro*ng-Top	Isolation	Schalldämmung	Aislante	
24	6101176M1	1	Panel-Soundpro*ng-Side-Lh	Isolation	Schalldämmung	Aislante	
25	6101177M1	1	Panel-Soundpro*ng-Side-Rh	Isolation	Schalldämmung	Aislante	
26	6101241M1	2	Seal Bonnet	Joint	Dichtung	Junta	
27	339124X1	2	Bolt M8-16 Z5f	Goupille	Maschschrb Metr - M8	Tornillo	
28	385361X1	2	Washer M8 Hardened	Rondelle M8	Scheibe M8	Arandela	
29	6102023M1	2	Support Tube	Tube	Röhrleitung	Tubo	
30	394367X1	4	Nut, Hex. - Nyloc, M8	Ecrou Blocage M8	Flachmutter - M8	Tuerca De Retención	




C-12001-01.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
31	385361X1	4	Washer M8 Hardened	Rondelle M8	Scheibe M8	Arandela	
32	339124X1	6	Bolt M8-16 Z5f	Goupille	Maschschrb Metr - M8	Tornillo	
33	390972X1	6	Washer M8-17-1 Zwl	Rondelle M8	Scheibe - M8	Arandela	
34	6102084M91	1	Support Bracket W/A - Gas Strut	Patte Fixation	Halter	Soporte De Fijación	
35	6102086M1	2	Hinge-Block	Entretoise	Distanzstück	Soporte	
36	1441664X1	2	Washer M16-30-3 Z	Rondelle	Scheibe	Arandela	
37	1462583M1	2	Plate-Clamp	Plaque	Platte	Placa	
38	339229X1	4	Bolt M6-40 Z5s Lk	Boulon M6 X 40	Schraube M6 X 40	Tornillo	
39	394367X1	2	Nut, Hex. - Nyloc, M8	Ecrou Blocage M8	Flachmutter - M8	Tuerca De Retención	
40	6111404M91	2	Gas Strut - With Sleeve (Bonnet)	Vérin À Gaz	Gaszylinder	Gato De Gas	
41	394367X1	2	Nut, Hex. - Nyloc, M8	Ecrou Blocage M8	Flachmutter - M8	Tuerca De Retención	
42	6101133M91	1	Grille-Fermec	Grille	Grill	Rejilla	
43	391884X1	2	Bolt M6-50 Z5s	Goupille	Bolzen	Tornillo	
44	391038X1	2	Washer M6 - Large Zinc Hardened	Rondelle	Scheibe	Arandela	
45	339560X1	2	Bolt - M6 X 16mm (Hex.)	Boulon M6 X 16	Maschschraube - M6	Tornillo	
46	391038X1	2	Washer M6 - Large Zinc Hardened	Rondelle	Scheibe	Arandela	
47	6107891M1	2	Key, Multipurpose - 1 Pair	Clé	Schlüssel	Juego De Llaves	




C-12002-01.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6109918M91	1	Bonnet Assy. Complete - Terex White	Capot	Motorhaube	Capó De Motor, Conj.	
2	6107887M91	1	Bonnet Assy. Less Nosecone - Terex White	Capot	Motorhaube	Tapa	
3	6101058M92	1	Softnose Assy Bonnet	Ensemble De Nez	Schnauze Kpl.	Morro, Conj.	
4	#NOSE	1	Nose	Nose	Nose	Nose	Ref. 3
5	6101246M1	8	Jack Nut M6	Ecrou	Mutter	Tuerca Especial	
6	6100785M1	2	Insert-M6	Ecrou	Mutter	Inserción	
7	6102674M2	4	Latch Bar - Bonnet Catch	Loquet	Riegel	Picaporte	
8	339804X1	8	Bolt, Hex, - M6 X 25	Goupille	Maschschrb Metr - M6	Tornillo	
9	390971X1	8	Washer M6-12-1 Zwl	Rondelle - M6	Scheibe - M6	Arandela	
10	1440329X1	1	Nut, Hex. - Nyloc, M10	Ecrou Blocage	Flachmutter M10	Tuerca De Retención	
11	6108647M1	1	Bolt - Bonnet Lock	Goupille	Bolzen	Leva	
12	6108646M91	1	Lock Assy. - Bonnet, (Excluding Key)	Ensemble De Verrou	Schloss Kpl.	Cerradura, Conj.	
13	339124X1	2	Bolt M8-16 Z5f	Goupille	Maschschrb Metr - M8	Tornillo	
14	339374X1	2	Washer M8 -21-2 Z	Rondelle Frein - M8	Federring - M8	Arandela De Freno	
15	390972X1	2	Washer M8-17-1 Zwl	Rondelle M8	Scheibe - M8	Arandela	
16	6100960M92	1	Catch Assy., Safety - Bonnet	Loquet Porte	Falle	Picaporte	
17	#BRACKET	1	Bracket	Bracket	Bracket	Bracket	Ref. 16
18	6101529M1	1	Spacer	Entretoise	Distanzstück	Traviesa	
19	3521090M3	1	Spring Torsion	Siège De Ressort	Federsitz	Muelle	
20	6106050M91	1	Catch, Safety - Bonnet	Loquet Porte	Falle	Picaporte	
21	390972X1	1	Washer M8-17-1 Zwl	Rondelle M8	Scheibe - M8	Arandela	
22	1440522X1	1	Circlip Ext	Segment D'Arrêt	Sicherungsring	Anillo De Resorte	
23	6101175M2	1	Panel-Soundpro*ng-Top	Isolation	Schalldämmung	Aislante	
24	6101176M1	1	Panel-Soundpro*ng-Side-Lh	Isolation	Schalldämmung	Aislante	
25	6101177M1	1	Panel-Soundpro*ng-Side-Rh	Isolation	Schalldämmung	Aislante	
26	6101241M1	2	Seal Bonnet	Joint	Dichtung	Junta	
27	339124X1	2	Bolt M8-16 Z5f	Goupille	Maschschrb Metr - M8	Tornillo	
28	385361X1	2	Washer M8 Hardened	Rondelle M8	Scheibe M8	Arandela	
29	6102023M1	2	Support Tube	Tube	Rohrleitung	Tubo	
30	394367X1	4	Nut, Hex. - Nyloc, M8	Ecrou Blocage M8	Flachmutter - M8	Tuerca De Retención	




C-12002-01.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
31	385361X1	4	Washer M8 Hardened	Rondelle M8	Scheibe M8	Arandela	
32	339124X1	6	Bolt M8-16 Z5f	Goupille	Maschschrb Metr - M8	Tornillo	
33	390972X1	6	Washer M8-17-1 Zwl	Rondelle M8	Scheibe - M8	Arandela	
34	6102084M91	1	Support Bracket W/A - Gas Strut	Patte Fixation	Halter	Soporte De Fijación	
35	6102086M1	2	Hinge-Block	Entretoise	Distanzstück	Soporte	
36	1441664X1	2	Washer M16-30-3 Z	Rondelle	Scheibe	Arandela	
37	1462583M1	2	Plate-Clamp	Plaque	Platte	Placa	
38	339229X1	4	Bolt M6-40 Z5s Lk	Boulon M6 X 40	Schraube M6 X 40	Tornillo	
39	394367X1	2	Nut, Hex. - Nyloc, M8	Ecrou Blocage M8	Flachmutter - M8	Tuerca De Retención	
40	6111404M91	2	Gas Strut - With Sleeve (Bonnet)	Vérin À Gaz	Gaszylinder	Gato De Gas	
41	394367X1	2	Nut, Hex. - Nyloc, M8	Ecrou Blocage M8	Flachmutter - M8	Tuerca De Retención	
42	6101133M91	1	Grille-Fermec	Grille	Grill	Rejilla	
43	391884X1	2	Bolt M6-50 Z5s	Goupille	Bolzen	Tornillo	
44	391038X1	2	Washer M6 - Large Zinc Hardened	Rondelle	Scheibe	Arandela	
45	339560X1	2	Bolt - M6 X 16mm (Hex.)	Boulon M6 X 16	Maschschraube - M6	Tornillo	
46	391038X1	2	Washer M6 - Large Zinc Hardened	Rondelle	Scheibe	Arandela	
47	6107891M1	2	Key, Multipurpose - 1 Pair	Clé	Schlüssel	Juego De Llaves	




C-16010-01.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6109606M91	1	Axle-2ws 2wd Synchro 700	Essieu	Achse	Puente Delantero, Conj.	
2	6110099M1	1	Pin - 2ws Axle Pivot	Axe	Bolzen	Pasador	
3	1440330X1	1	Nut Nyloc M12	Ecrou	Flachmutter M12	Tuerca	
4	3009518X1	1	Bolt - M12 X 110lg	Goupille	Bolzen M12 X 110	Perno	
5	1441858X1	1	Grease Nipple - Straight, M6	Graisser Coude	Schmiernippel	Engrasador	
6	3009694X1	1	Nut M10 Z1 Thin	Ecrou	Mutter M10	Tuerca De Retención	
7	3521240M1	1	Union Bulkhead	Union	Schraubanschluss	Racor	
8	6110196M91	1	Hose Assembly - Grease	Flexible	Schlauch	Flexible, Conj.	
9	358760X91	1	Elbow 90#7/16-7/16 Unf	Coude, 90	Kniestück, 90°	Codo, 90°	
10	#ELBOW	1	Elbow	Elbow	Elbow	Elbow	Ref. 9
11	831495M1	1	O-Ring	Joint Torique	O-Ring	Junta De Tipo O	
12	6110204M1	16	Stud - Wheel	Goujon	Stehbolzen	Espárrago	



C-16010-02.1-A



Item	Part No.	Qty.	English	French	German	Spanish	Remarks
1	6109606M91	1	Axle-2ws 2wd Synchro 700	Essieu	Achse	Puente Delantero, Conj.	
2	6194091M91	1	Axle Housing	Carter De Pont	Achsgehäuse	Cárter De Puente	
3	6193344M1	1	Plug - Brake Cylinder Housing	Bouchon	Stopfen	Tapón	
4	6194017M1	1	Oil Seal	Joint D´Arbre	Wellendichtring	Junta De Aceite	
5	6194022M1	1	Bush - Front	Douille	Buechse	Casquillo	
6	6194021M1	1	Bush 60 X 50 19 X 54	Douille	Buechse	Casquillo	
7	6194017M1	1	Oil Seal	Joint D´Arbre	Wellendichtring	Junta De Aceite	
8	6194092M1	2	Washer	Rondelle	Scheibe	Arandela De Resorte	
9	6194093M1	2	Bushing	Bague	Büchse	Anillo	
10	3523057M1	2	Bearing, Spherical - Swivel Pins	Roul Spherique	Lager Ballig	Anillo	
11	3523555M1	2	Washer - Belleville	Rondelle	Unterlegscheibe	Arandela	




Front Axle - Steering Pivot 2 Wheel Drive/2 Wheel Steer

4067 16010

Product: 2010 Terex TX870B Backhoe Loader Workshop Parts Manual

Full Download: <https://www.arepairmanual.com/downloads/2010-tx870b-backhoe-loader-workshop-parts-manual/>

C-16010-03.1-B



Sample of manual. Download All 2241 pages at:
<https://www.arepairmanual.com/downloads/2010-tx870b-backhoe-loader-workshop-parts-manual/>