

Product: 2007 TEREX TA35 G7 (OCDB) Articulated Truck Workshop Parts Manual[PN15503340]

Full Download: <https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/>



TEREX

Publication Part Number: **15503340**

Published by : Customer Support Department - TEREX Equipment Limited, Motherwell, Scotland


PARTS BOOK

CLICK HERE FOR
TRACTOR
TABLE OF CONTENTS

CLICK HERE FOR
TRACTOR OPTIONAL
TABLE OF CONTENTS

CLICK HERE FOR
TRAILER
TABLE OF CONTENTS

CLICK HERE FOR
TRAILER OPTIONAL
TABLE OF CONTENTS



TA35 G7 (OCDB) Articulated Truck

(Detroit Diesel Series 60 Engine with Allison 4500 ORS_R Trans)

Serial Nos. A9171011 and above

February 2007

Sample of manual. Download All 538 pages at:

<https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/>

Revised: 23rd June 2010

Product: 2007 TEREX TA35 G7 (OCDB) Articulated Truck Workshop Parts Manual[PN15503340]

Full Download: <https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/>

[cdb-articulated-truck-workshop-parts-manualpn15503340/](https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/)

THIS PAGE IS INTENTIONALLY LEFT BLANK

Sample of manual. Download All 538 pages at:

<https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/>



WARRANTY ON PARTS AND ATTACHMENTS

Terex Equipment Limited warrants that for a period of six months or 1000 hours, whichever comes first, after the sale of new Terex replacement parts or attachments by an authorised Terex dealer it will repair, or at its option, replace any defective or malfunctioning part or attachment. This warranty covers only malfunctions resulting from defects in material or workmanship.

This warranty does not cover malfunctions resulting from negligence, alteration, accident or overloading; use for a purpose for which the part or attachment is not designed or approved by Terex; loss of time, inconvenience, loss of use of the vehicle or other consequential damages; or labour for removal or reinstallation of defective or malfunctioning parts or attachments.

Repairs or replacements qualifying under this warranty will be performed by any authorised Terex dealer within a reasonable time following delivery of the malfunctioning part or attachment to the dealer's place of business.

Defective or malfunctioning parts or attachments must be delivered to an authorised Terex dealer's place of business during regular business hours for warranty repairs or replacements. The dealer must be furnished with the purchaser's copy of the sales slip or repair order to validate date of purchase.

* * * * *

SOLE WARRANTY

This is the only express warranty applicable to new Terex parts and attachments sold by Terex dealers and Terex neither assumes nor authorises anyone to assume for it any other obligation or liability in connection with such parts or attachments.

THIS PAGE IS INTENTIONALLY LEFT BLANK

INSTRUCTIONS FOR USE OF TEREX PARTS BOOK

This Parts Book is divided into Major Sections which cover components corresponding to specific areas of the machine.

Printed at the top left hand corner of each Parts Page is an Index Code which includes three numbers - the first of these relates to a Major Section, the second indicates a Sub-section within a Major Section and the last the model PLI number. Certain Major Sections may not apply to the particular model covered in this Parts Book and, consequently, will be omitted.

An illustrated Index page shows all the Major Component Section numbers included in the book. For example -

SECTION 100 - CHASSIS

SECTION 140 - FRONT AXLE GROUP

SECTION 230 - BODY HOIST SYSTEM etc.

Major Component Sections are listed in the 'Table Of Contents' pages together with Sub-section headings. For example to locate the serviceable items of a Steering Cylinder -

1. The Table of Contents shows the steering components to be in Major Section 220.
2. The steering cylinder is listed in Major Section 220, Sub-section 0120
3. Select the Parts Page Code that applies to the unit Serial number for which parts are needed and locate the Page with reference number.
EXAMPLE - 220-0120.

SERIAL NUMBERS - Each Parts Book covers a particular range of unit Serial Numbers.

It is important that unit Serial Numbers are quoted on all orders for Parts.

PARTS LISTS - Parts Forms usually consist of detailed parts information listed on one page together with a parts illustration on the opposite page. The parts list is printed in the order of the reference numbers shown on the parts illustration. The first column lists Note Letters; the second lists the reference numbers; the third shows quantity required and the fourth gives the parts descriptions. Parts which are part of an assembly have their descriptions indented beneath the assembly description.

ILLUSTRATIONS - These show typical assemblies and individual piece parts. They are intended for general reference only and may not always show exact details of parts. Parts are identified on each illustration with an item number. Note the item number of the part required and locate it in the parts list. The part number opposite the item number is the part to order.

INDENTATIONS - Parts which are indented under another part are Sub-groups of a Major Assembly or Sub-assembly. Parts which are not indented are major assemblies or individual component parts which do not belong to a major assembly.

EXAMPLE - 1 9052564 Pump Assy.
2 9058512 . Shaft
3 9024169 . Ring
4 9058132 . Control Assy.
5 9058135 . . Spring
6 9072162 Gasket

- If you order Item 1, you will receive Items 1 - 5.
- If you order Item 4, you will receive Items 4 and 5.
- If you order Item 6, you will receive only Item 6.

NOTES - Whenever there is an alphabetical symbol to the left of the item number, refer to the corresponding note at the bottom of the form for information regarding ordering or application of the particular part number(s) noted.

ABBREVIATIONS - The abbreviations in this book have the following meanings -

Amps	Amperes	Hsg	Housing	N.I	Not Illustrated
As R	As Required	I.D	Inside Diameter	N.L.A	No Longer Available
Assy	Assembly	L.H	Left Hand	N.S.S	Not Sold Separately
Brkt	Bracket	L.W	Lockwasher	O.D	Outside Diameter
Cad-Pltd	Cadium Plated	Lg	Long	Pr	Pair
Comm	Commencement of production	Lkg	Linkage	P.T.O	Power-Take-Off
E.S.N	Elastic Stop Nut	Mtg	Mounting	R.H	Right Hand
Ftgs	Fittings	N.C	Note Code	Std	Standard



Articulated Truck



TRACTOR SECTIONS

	CHASSIS	100		COOLING SYSTEM	210
	ENGINE	110		MAIN HYDRAULIC VALVE	215
	TRANSMISSION	120		STEERING SYSTEM	220
	TRANSMISSION DROPBOX	125		BODY HOIST SYSTEM	230
	DRIVELINE	130		BRAKING SYSTEM	250
	FRONT AXLE	140		CAB	260
	BRAKE PARTS	165		DECALS	290
	SUSPENSION SYSTEM	180		MISCELLANEOUS	300
	ELECTRICAL SYSTEM	190			
	FUEL SYSTEM	200			

TABLE OF CONTENTS FOR MODEL TA35 G7 OCDB TRACTOR

FROM SERIAL NO A9171011

REVISED 06/10

SECT-PAGE-PLI	DESCRIPTION	SERIAL NO. EFFECTIVITY	REVISION AND DATE
<u>SECTION 100</u>			
	<u>CHASSIS</u>		
100-0010-9181	CHASSIS	A9171011 TO A9171044	R1 11/07
100-0010-9181	CHASSIS	A9171045	11/08
100-0030-9181	SOUND INSULATION		R1 01/09
100-0040-9181	HOOD AND MOUNTING		
100-0070-9181	FENDERS AND MOUNTING	A9171011 TO A9171044	R1 10/07
100-0070-9181	FENDERS AND MOUNTING	A9171045	11/08
100-0085-9181	PIVOT & ACCUMULATOR GUARD		
100-0135-9181	ROCK AND SUMP GUARDS		
<u>SECTION 110</u>			
	<u>ENGINE</u>		
110-0020-9181	ENGINE ORDERING INSTRUCTIONS		
110-0030-9181	ENGINE AND MOUNTING		R2 01/09
110-0050-9181	AIR CLEANER ASSEMBLY		
110-0060-9181	AIR CLEANER MOUNTING PIPES AND HOSES		
110-0070-9181	EXHAUST AND MOUNTING	A9171011 TO A9171050	R5 06/09
110-0070-9181	EXHAUST AND MOUNTING	A9171051	09/09
<u>SECTION 120</u>			
	<u>TRANSMISSION</u>		
120-0010-9181	TRANSMISSION MOUNTING		R2 10/08
120-0020-9181	TRANSMISSION BREAKDOWN		R1 10/08
120-0040-9181	P1 PLANETARY GROUP		
120-0045-9181	P2 PLANETARY GROUP		
120-0046-9181	P3 PLANETARY & REAR COVER/RETARDER		
120-0050-9181	CONTROL VALVE		
120-0070-9181	SHIFT CONTROL		
120-0090-9181	POWER TAKE-OFF MAIN PUMP		
120-0100-9181	TRANS OIL FILTERS		
120-0125-9181	OIL COOLER GROUP		R1 04/09
120-0135-9181	FRONT SUPPORT & OIL PUMP		
120-0200-9181	FRONT COVER & CONVERTER GROUP		
120-0210-9181	CONVERTER HOUSING GROUP		
120-0215-9181	FLEXPLATE AND ADAPTOR		
120-0225-9181	ROTATING CLUTCH		
120-0235-9181	MAIN SHAFT		
120-0255-9181	RETARDER CONTROLS		
120-0290-9181	MAIN HOUSING GROUP		

TABLE OF CONTENTS FOR MODEL TA35 G7 OCDB TRACTOR

FROM SERIAL NO A9171011

REVISED 06/10

SECT-PAGE-PLI	DESCRIPTION	SERIAL NO. EFFECTIVITY	REVISION AND DATE
<u>SECTION 125</u>	<u>TRANSMISSION DROPBOX</u>		
125-0010-9181	DROPBOX MOUNTING	A9171011 TO A9171014	
125-0010-9181	DROPBOX MOUNTING	A9171015	R1 11/08
125-0020-9181	DROPBOX ASSEMBLY	A9171011 TO A9171014	R1 06/10
125-0020-9181	DROPBOX ASSEMBLY	A9171015 TO A9171043	R2 11/08
125-0020-9181	DROPBOX ASSEMBLY	A9171044 TO A9171050	R1 11/08
125-0020-9181	DROPBOX ASSEMBLY	A9171051	R1 12/09
125-0025-9181	CONTROL VALVE-DROPBOX	A9171011 TO A9171014	
125-0025-9181	CONTROL VALVE-DROPBOX	A9171015	R1 11/07
125-0026-9181	PRESSURE RELIEF VALVE-DROPBOX		11/07
125-0030-9181	EMERGENCY STEERING PUMP ASSEMBLY		R1 05/07
125-0035-9181	PUMP ASSEMBLY-DROPBOX		
125-0040-9181	DIFFERENTIAL-LOCK LINES & FTGS	A9171011 TO A9171044	R1 10/07
125-0040-9181	DIFFERENTIAL-LOCK LINES & FTGS	A9171045	R1 06/09
125-0045-9181	FILTER ASSEMBLY-DROPBOX	A9171011 TO A9171045	R3 03/10
125-0045-9181	FILTER ASSEMBLY-DROPBOX	A9171046	06/08
125-0050-9181	SUCTION FILTER ASSY-DROPBOX		06/07
<u>SECTION 130</u>	<u>DRIVELINE</u>		
130-0010-9181	FRONT DRIVELINE		
<u>SECTION 140</u>	<u>FRONT AXLE</u>		
140-0010-9181	AXLE COMPLETE-FRONT		R2 06/09
140-0020-9181	AXLE GROUP-FRONT	A9171011 TO A9171050	R1 10/08
140-0020-9181	AXLE GROUP-FRONT	A9171051	06/09
140-0030-9181	PLANETARY GEARING-FRONT	A9171011 TO A9171044	
140-0030-9181	PLANETARY GEARING-FRONT	A9171045	R1 06/09
140-0040-9181	WHEEL, RIM AND TYRE-FRONT		R1 04/09
140-0060-9181	DIFFERENTIAL-FRONT		R1 10/08
<u>SECTION 165</u>	<u>BRAKE PARTS</u>		
165-0015-9181	BRAKE ASSEMBLY-OCDB(ARTICS)	A9171011 TO A9171044	
165-0015-9181	BRAKE ASSEMBLY-OCDB(ARTICS)	A9171045	10/08
<u>SECTION 180</u>	<u>SUSPENSION SYSTEM</u>		
180-0020-9181	FRONT SUSPENSION		R3 04/09

TABLE OF CONTENTS FOR MODEL TA35 G7 OCDB TRACTOR

FROM SERIAL NO A9171011

REVISED 06/10

SECT-PAGE-PLI	DESCRIPTION	SERIAL NO. EFFECTIVITY	REVISION AND DATE
<u>SECTION 190</u>	<u>ELECTRICAL SYSTEM</u>		
190-0010-9181	TERMINALS		
190-0011-9181	CONNECTORS		
190-0030-9181	CABLES/HARNESSES-CAB	A9171011 TO A9171021	R1 05/07
190-0030-9181	CABLES/HARNESSES-CAB	A9171022 TO A9171043	06/07
190-0030-9181	CABLES/HARNESSES-CAB	A9171044	R1 01/09
190-0040-9181	CABLES/HARNESSES-CHASS/ENG	A9171011 TO A9171021	
190-0040-9181	CABLES/HARNESSES-CHASS/ENG	A9171022 TO A9171044	R2 08/08
190-0040-9181	CABLES/HARNESSES-CHASS/ENG	A9171045	11/08
190-0070-9181	BATTERY AND CABLES	A9171011 TO A9171044	R1 06/08
190-0070-9181	BATTERY AND CABLES	A9171045	11/08
190-0080-9181	BATTERY MOUNTING	A9171011 TO A9171044	
190-0080-9181	BATTERY MOUNTING	A9171045	11/08
190-0085-9181	ECU-HYD.SYSTEM MONITORING		R3 01/09
190-0100-9181	ELECTRICAL LIGHTING SYSTEM		
190-0110-9181	ALTERNATOR AND MOUNTING		
190-0120-9181	STARTER		
190-0270-9181	SWITCHES AND SENSORS	A9171011 TO A9171044	R3 11/08
190-0270-9181	SWITCHES AND SENSORS	A9171045	R1 11/08
190-0300-9181	RADIO CASSETTE AND SPEAKERS		
190-0310-9181	ELECTRICAL HORN		
190-0330-9181	CCTV REAR VIEW SYSTEM		04/09
<u>SECTION 200</u>	<u>FUEL SYSTEM</u>		
200-0010-9181	FUEL TANK AND MOUNTING	A9171011 TO A9171044	R1 02/09
200-0010-9181	FUEL TANK AND MOUNTING	A9171045	R1 02/09
200-0040-9181	FUEL LINES	A9171011 TO A9171031	
200-0040-9181	FUEL LINES	A9171032	R1 01/09
200-0050-9181	ACCELERATOR CONTROLS		R1 06/08
<u>SECTION 210</u>	<u>COOLING SYSTEM</u>		
210-0015-9181	COMBINATION COOLER RH		R1 09/09
210-0016-9181	COMBINATION COOLER LH		
210-0020-9181	RADIATOR MOUNTING		R1 05/07
210-0025-9181	RADIATOR FAN MOTOR-HYD LINES	A9171011 TO A9171044	R5 06/08
210-0025-9181	RADIATOR FAN MOTOR-HYD LINES	A9171045	R2 03/10
210-0030-9181	RADIATOR PIPING		
210-0035-9181	CHARGE AIR COOLER & PIPING		R3 06/09
210-0040-9181	RADIATOR HEADER TANK & HOSES		R2 09/09
210-0044-9181	FAN DISCONNECT VALVE		
210-0045-9181	LOW TEMP UNLOADER VALVE		

TABLE OF CONTENTS FOR MODEL TA35 G7 OCDB TRACTOR

FROM SERIAL NO A9171011

REVISED 06/10

SECT-PAGE-PLI	DESCRIPTION	SERIAL NO. EFFECTIVITY	REVISION AND DATE
<u>SECTION 210</u>	<u>COOLING SYSTEM-CONTINUED</u>		
210-0052-9181	OIL COOLING LINES-DISC BRAKES	A9171011 TO A9171044	R2 02/08
210-0052-9181	OIL COOLING LINES-DISC BRAKES	A9171045	R1 01/09
210-0062-9181	TRANS OIL COOLER LINES	A9171011 TO A9171039	
210-0062-9181	TRANS OIL COOLER LINES	A9171040	R5 09/09
210-0063-9181	DROPBOX OIL COOLING & LUBE LINES	A9171011 TO A9171044	R5 06/08
210-0063-9181	DROPBOX OIL COOLING & LUBE LINES	A9171045 TO A9171048	11/08
210-0063-9181	DROPBOX OIL COOLING & LUBE LINES	A9171049	04/09
210-0100-9181	OIL COOLER AND LINES-HYDRAULIC	A9171011 TO A9171031	R1 08/07
210-0100-9181	OIL COOLER AND LINES-HYDRAULIC	A9171032	R2 01/09
<u>SECTION 215</u>	<u>MAIN HYDRAULIC VALVE</u>		
215-0050-9181	MAIN HYDRAULIC VALVE ASSY		R2 06/10
<u>SECTION 220</u>	<u>STEERING SYSTEM</u>		
220-0010-9181	STEERING LINES	A9171011 TO A9171044	R2 06/08
220-0010-9181	STEERING LINES	A9171045	R1 09/09
220-0090-9181	STEERING VALVE		
220-0120-9181	STEERING CYLINDER		
220-0140-9181	EMERGENCY STEERING VALVE		
220-0230-9181	STEERING COLUMN MOUNTING		
<u>SECTION 230</u>	<u>BODY HOIST SYSTEM</u>		
230-0020-9181	LINES AND FITTINGS-BODY HOIST		R4 10/09
230-0050-9181	MAIN HYDRAULIC PUMP ASSEMBLY	A9171011 TO A9171037	R1 02/08
230-0050-9181	MAIN HYDRAULIC PUMP ASSEMBLY	A9171038 TO A9171048	06/08
230-0050-9181	MAIN HYDRAULIC PUMP ASSEMBLY	A9171049	04/09
230-0055-9181	PORTING BLOCK-MAIN PUMP		R2 03/10
230-0081-9181	JOYSTICK-BODY CONTROL		
230-0135-9181	LOAD SENSE CONTROL VALVE		10/07
<u>SECTION 250</u>	<u>BRAKING SYSTEM</u>		
250-0020-9181	BRAKE LINES-HYDRAULIC	A9171011 TO A9171044	R4 06/08
250-0020-9181	BRAKE LINES-HYDRAULIC	A9171045	R1 10/09
250-0025-9181	BRAKE COOLANT/HYDRAULIC TANK	A9171011 TO A9171029	R4 06/09
250-0025-9181	BRAKE COOLANT/HYDRAULIC TANK	A9171030 TO A9171044	R4 06/09
250-0025-9181	BRAKE COOLANT/HYDRAULIC TANK	A9171045	R2 06/09
250-0026-9181	HYDRAULIC TANK PRESSURISATION	A9171011 TO A9171044	R3 11/08
250-0045-9181	MOTOR/TRIPLE PUMP ASSEMBLY		R2 01/09
250-0060-9181	BRAKE ACCUMULATOR		

TABLE OF CONTENTS FOR MODEL TA35 G7 OCDB TRACTOR

FROM SERIAL NO A9171011

REVISED 06/10

SECT-PAGE-PLI	DESCRIPTION	SERIAL NO. EFFECTIVITY	REVISION AND DATE
<u>SECTION 250</u>	<u>BRAKING SYSTEM-CONTINUED</u>		
250-0070-9181	TREADLE VALVE (MICO)	A9171011 TO A9171027	R1 08/07
250-0070-9181	TREADLE VALVE (MICO)	A9171028	R1 01/08
250-0240-9181	FILTER ASSY-OCDB		
<u>SECTION 260</u>	<u>CAB</u>		
260-0010-9181	CAB ASSEMBLY		R2 08/08
260-0015-9181	CAB MOUNTING	A9171011 TO A917 TBA	R2 08/07
260-0015-9181	CAB MOUNTING	A917 TBA	04/09
260-0018-9181	CAB TILT MECHANISM		R1 01/09
260-0030-9181	CAB DOOR-LEFT HAND		
260-0080-9181	SWITCHES AND INSTRUMENTS	A9171011 TO A9171044	R1 06/07
260-0080-9181	SWITCHES AND INSTRUMENTS	A9171045	R7 04/09
260-0090-9181	SEAT-DRIVER	A9171011 TO A9171027	R1 10/08
260-0090-9181	SEAT-DRIVER	A9171028	R1 04/09
260-0110-9181	SEAT-INSTRUCTOR		R1 06/07
260-0130-9181	AIR CONDITIONER/HEATER		
260-0140-9181	HEATER LINES AND WIRING		R2 04/09
260-0145-9181	AIR CONDITIONER LINES		R3 06/09
260-0190-9181	WINDSCREEN WASHER		
<u>SECTION 290</u>	<u>DECALS</u>		
290-0010-9181	DECALS-ENGLISH (ISO)	A9171011 TO A9171044	R3 02/08
290-0010-9181	DECALS-ENGLISH (ISO)	A9171045	R2 06/09
290-0011-9181	DECALS-ENGLISH (ANSI)	A9171011 TO A9171044	R3 02/08
290-0011-9181	DECALS-ENGLISH (ANSI)	A9171045	R2 06/09
290-0100-9181	WALKWAY SURFACES (ANTI-SLIP)	A9171011 TO A9171044	06/07
290-0100-9181	WALKWAY SURFACES (ANTI-SLIP)	A9171045	11/08
<u>SECTION 300</u>	<u>MISCELLANEOUS</u>		
300-0040-9181	MULTI-TUBE CLAMPS AND HARDWARE		
300-0045-9181	POLYPROPELENE CLAMPS		
300-0200-9181	UNIT FILTERS & ELEMENT KITS		R4 04/09
300-0250-9181	HIGH TEMPERATURE HOSE ASSY CROSS-REF		11/08


THIS PAGE IS INTENTIONALLY LEFT BLANK

R1 11/07 (ECN 109096)

100-0010-9181 CHASSIS
FROM SERIAL NO. A9171011 TO A9171044

DRAWING NO. P11828

P11828



100-0010-9181 CHASSIS

FROM SERIAL NO. A9171011 TO A9171044

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
001	001		15323646	FRAME ASSY-TRACTOR		
002	001		15319635	.FRAME-FRONT SUB ASSY		
003	001		15319764	.CAB MOUNT ASSY		
004	001		15319726	.SUSPENSION MOUNT-LH		
005	001		15320693	.SUSPENSION FRAME		
006	001		15319763	.CAB MOUNT ASSY		
007	001		15319684	.CROSSMEMBER		
008	001		15319098	.CAB MOUNT ASSY		
009	001		15319727	.SUSPENSION MOUNT-RH		
010	001		15319099	.CAB MOUNT ASSY		
011	001		15319712	.BRACKET ASSY(PANHARD)		
012	001		15322887	.HEADLIGHT PLATE ASSY-LH		
013	001		15322888	.HEADLIGHT PLATE ASSY-RH		
014	001		15322718	.PLATE-TANK SUPPORT-RH		
015	001		15322717	.PLATE-TANK SUPPORT-LH		
016	002		15322886	.HOOD HINGE ASSY		
017	004		15319780	.PLATE-CROSSMEMBER		
018	001		15321276	.HOOD PROP FRAME ASSY		
019	001		15323495	.BRACKET-CAB PROP		
020	002		15330267	BOLT-M24		
021	004		15234742	WASHER		
022	002		06642401	LOCKNUT		
023	001		15322527	PANEL-ACCESS COVER		
024	002		06351220	BOLT		
025	002		07161230	LOCKWASHER		
026	001		15330134	SUMP GUARD ASSY		
027	002		15324298	.INSPECTION COVER		
028	006		06351230	.BOLT		
029	006		09217321	.WASHER		
030	004		06351035	.BOLT		
031	008		07151020	.WASHER		
032	004		06471001	.LOCKNUT		
033	002		06351655	BOLT		
034	004		07151630	WASHER		
035	002		06471601	LOCKNUT		
036	001		15323047	CROSSMEMBER ASSY		

100-0010-9181 CHASSIS
FROM SERIAL NO. A9171045


NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
001	001		15344188	FRAME ASSY-TRACTOR		
002	001		15319635	.FRAME-FRONT SUB ASSY		
003	001		15319764	.CAB MOUNT ASSY		
004	001		15336646	.SUSPENSION MOUNT-LH		
005	001		15320693	.SUSPENSION FRAME		
006	001		15319763	.CAB MOUNT ASSY		
007	001		15319684	.CROSSMEMBER		
008	001		15319098	.CAB MOUNT ASSY		
009	001		15336647	.SUSPENSION MOUNT-RH		
010	001		15319099	.CAB MOUNT ASSY		
011	001		15319712	.BRACKET ASSY(PANHARD)		
012	001		15322887	.HEADLIGHT PLATE ASSY-LH		
013	001		15322888	.HEADLIGHT PLATE ASSY-RH		
014	001		15336509	.PLATE-TANK SUPPORT-RH		
015	001		15336508	.PLATE-TANK SUPPORT-LH		
016	002		15322886	.HOOD HINGE ASSY		
017	004		15319780	.PLATE-CROSSMEMBER		
018	001		15321276	.HOOD PROP FRAME ASSY		
019	001		15323495	.BRACKET-CAB PROP		
020	002		15330267	BOLT-M24		
021	004		15234742	WASHER		
022	002		06642401	LOCKNUT		
023	001		15322527	PANEL-ACCESS COVER		
024	002		06351220	BOLT		
025	002		07161230	LOCKWASHER		
026	001		15330134	SUMP GUARD ASSY		
027	002		15324298	.INSPECTION COVER		
028	006		06351230	.BOLT		
029	006		09217321	.WASHER		
030	004		06351035	.BOLT		
031	008		07151020	.WASHER		
032	004		06471001	.LOCKNUT		
033	002		06351655	BOLT		
034	004		07151630	WASHER		
035	002		06471601	LOCKNUT		
036	001		15323047	CROSSMEMBER ASSY		

R1 01/09 (ECN 109564)

100-0030-9181 SOUND INSULATION
FROM SERIAL NO. A9171011

DRAWING NO. P11922

P11922






100-0030-9181 SOUND INSULATION
 FROM SERIAL NO. A9171011

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
001	001		15333049	QUILT-HOOD RIGHT/MID		
002	001		15333051	QUILT-HOOD LEFT/MID		
003	001		15333055	QUILT-HOOD RIGHT/MID		
004	001		15333057	QUILT-HOOD LEFT/REAR		
005	001		15333059	QUILT-HOOD TOP/REAR	A9171011	A9171045
005	001		15347290	QUILT-HOOD TOP/REAR	A9171046	
006	001		15333060	QUILT-HOOD TOP/FRONT	A9171011	A9171045
006	001		15347291	QUILT-HOOD TOP/FRONT	A9171046	
007	ASR		15319946	LIP SEAL		
008	002		15333041	QUILT-SUMP GUARD		
009	001		15333063	QUILT-AIR INTAKE		
010	001		15334598	TIE BAR ASSY		
011	001		15334607	TIE BAR ASSY		
012	001		15334216	QUILT-ENGINE/RADIATOR		
013	001		15334213	QUILT-ENGINE/RADIATOR		
014	001		15333032	QUILT-ENGINE/RADIATOR		
015	001		15333037	QUILT-ENGINE/RADIATOR		
016	015		15316089	WASHER		
017	015		06470601	LOCKNUT		
018	014		06351030	BOLT		
019	014		00106264	WASHER		
020	002		06351025	BOLT		
021	002		07151020	WASHER		
022	ASR		15501136	CAP		
023	ASR		15503209	STUD-LONG 55MM		
024	ASR		15503210	STUD-SHORT 35MM		

100-0040-9181 HOOD AND MOUNTING
FROM SERIAL NO. A9171011


DRAWING NO. P11882

P11882



100-0070-9181 FENDERS AND MOUNTING
FROM SERIAL NO. A9171011 TO A9171044

P11885




100-0070-9181 FENDERS AND MOUNTING
FROM SERIAL NO. A9171011 TO A9171044

100-0070-9181 FENDERS AND MOUNTING
FROM SERIAL NO. A9171011 TO A9171044

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO	NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
001	001		15323684	FENDER ASSY-LH			040	001		15331211	SUPPORT ARM ASSY-RH		
002	002		15332628	HANDRAIL-OUTER			041	004		15320662	TREADPLATE-STEP		
003	001		15323203	DIAGNOSTIC PANEL			042	001		15331159	WALKWAY (ANTI SLIP)		
004	001		15323239	COVER-ACCESS PANEL			043	001		15332504	FENDER LINER-FRONT		
005	001		15323683	HANDRAIL-INNER LH			044	001		15331295	FENDER LINER REINFORCING		
006	001		15323667	SUPPORT ARM-LH			045	001		15331288	FENDER MTG PLATE		
007	008		15320662	TREADPLATE-STEP			046	001		15331251	RUBBER-FENDER LINER		
008	001		15323678	ANTI-SLIP WALKWAY			047	001		15331287	RUBBER-FENDER LINER		
009	005		15323231	DZUZ FASTENER			048	001		15331228	MOUNT-FENDER EXTN		
010	005		15323826	DZUZ RETAINER			049	001		15331229	MOUNT-FENDER EXTN		
011	005		15323232	DZUZ RECEPTICLE			050	001		15323749	HANDRAIL RH		
012	001		15323229	COVER-DIAG. PANEL			051	001		15330251	PLATFORM ASSY		
013	002		15303970	WIRE STEP			052	001		15320662	.TREADPLATE-STEP		
014	001		15332504	FENDER LINER-FRONT			053	004		00181400	.BOLT		
015	001		15331295	FENDER LINER REINF.			054	004		09354846	.LOCKNUT		
016	001		15331289	MOUNT-FENDER EXTN.			055	004		07151020	.WASHER		
017	001		15331251	RUBBER FENDER LINER			056	005		06351025	BOLT		
018	001		15331227	RUBBER FENDER EXTN LH			057	005		07151020	WASHER		
019	001		15331228	MOUNT-FENDER EXTN			058	002		15310942	SOCKET SCREW		
020	001		15331229	MOUNT-FENDER EXTN			059	002		06351250	BOLT		
021	001		15323748	HANDRAIL LH			060	004		07151220	WASHER		
022	008		15311176	BOLT			061	002		06471201	NUT		
023	008		07151630	WASHER			062	001		15332714	WALKWAY-ANTI SLIP		
024	008		07161630	LOCKWASHER			063				NOT USED		
025	028		06351225	BOLT			064				NOT USED		
026	056		06351230	BOLT			065	004		06350820	BOLT		
027	004		06351235	BOLT			066	004		07150815	WASHER		
028	006		15244017	BOLT			067	004		07160830	WASHER		
029	004		06431201	NUT			068	001		15332664	FILLER-HANDRAIL		
030	040		06471201	LOCKNUT			069	001		15332502	PLATE-BENT		
031	118		07151220	WASHER			070	001		15332503	PLATE		
032	056		07161230	LOCKWASHER			071	016		09267660	WASHER-HDN		
033	002		06351025	BOLT			072	028		09024430	WASHER		
034	032		07151020	WASHER			073	004		06350825	BOLT		
035	032		15244817	SCREW			074	004		07160830	LOCKWASHER		
036	032		06471001	LOCKNUT			075	004		15334927	PLATE		
037	001		15331147	FENDER ASSY-RH			076	001		15332502	PLATE-MOUNT LINER		
038	001		15323682	HANDRAIL-OUTER			077	001		15332503	PLATE-MOUNT LINER		
039	001		15331212	HANDRAIL-INNER RH			078	001		15330253	RUBBER COVER		

100-0070-9181 FENDERS AND MOUNTING
FROM SERIAL NO. A9171045

P12307



100-0070-9181 FENDERS AND MOUNTING
FROM SERIAL NO. A9171045


100-0070-9181 FENDERS AND MOUNTING
FROM SERIAL NO. A9171045

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO	NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
001	001		15344578	FENDER ASSY-POS H/TANK			041	001		15331212	HANDRAIL INNER-FENDER		
002	001		15332628	HANDRAIL-OUTER			042	001		15331211	SUPPORT ARM ASSY-FENDER		
003	001		15323203	PLATE-DIAGNOSTIC			043	001		15331288	PLATE-MOUNTING FENDER		
004	001		15323239	PLATE-ACCESS COVER			044	001		15331287	RUBBER SHEET-FENDER EXTN		
005	001		15323683	HANDRAIL-INNER LH			045	001		15323749	HANDRAIL-RH		
006	001		15323667	STEP ASSY-SUPPORT ARM			046	001		15330251	PLATFORM ASSY		
007	009		15320662	FOOTSTEP-TREADPLATE			047	002		15310942	SCREW-S/HEAD C/S M8X20		
008	004		15334927	PLATE-MOUNTING FENDER			048	002		06351250	BOLT		
009	005		15323231	SCREW			049	008		07151220	WASHER		
010	005		15323826	RETAINER			050	002		06471201	LOCKNUT		
011	005		15323232	RECEPTICLE			051	005		06351030	BOLT		
012	001		15323229	COVER PLATE-DIAGNOSTIC			052	005		00106264	WASHER		
013	002		15303970	STEP ASSY			053	001		15330253	COVER-RUBBER		
014	002		15332504	RUBBER SHEET-FENDER LINER									
015	002		15331295	PLATE-REINFORCING									
016	001		15331289	PLATE-MOUNTING FENDER									
017	002		15331251	RUBBER SHEET-FENDER LINER									
018	001		15331227	RUBBER SHEET-FENDER EXTN									
019	002		15331228	PLATE-MTG FENDER EXTN									
020	002		15331229	PLATE-MTG FENDER EXTN									
021	001		15323748	HANDRAIL-LH									
022	008		15311176	BOLT									
023	008		07151630	WASHER									
024	008		07161630	LOCKWASHER									
025	004		07160830	LOCKWASHER									
026	086		06351230	BOLT									
027	004		06350825	BOLT									
028	004		15244017	BOLT									
029	028		09024430	WASHER									
030	044		06471201	LOCKNUT									
031	084		07151220	WASHER									
032	024		07161230	LOCKWASHER									
033	002		06351025	BOLT									
034	016		09267660	WASHER									
035	036		15244817	SCREW-SOCKET HEAD									
036	002		15332503	PLATE-RUBBER LINER									
037	001		15332664	TUBE-HANDRAIL FILLER									
038	002		15332502	PLATE BENT-RUBBER LINER									
039	001		15339383	FENDER ASSY-RHS									
040	001		15323682	HANDRAIL-OUTER									


100-0085-9181 PIVOT AND ACCUMULATOR GUARDS
FROM SERIAL NO. A9171011

DRAWING NO. P11787

P11787




REF. SEC. 110-0070



100-0085-9181 PIVOT AND ACCUMULATOR GUARDS
FROM SERIAL NO. A9171011

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
001	001		15330402	SPILLGUARD		
002	001		15324044	GUARD-ACCUMULATOR		
003	001		15330400	BRACE-SPILL GUARD		
004	001		15324043	PARTITION PLATE		
005	015		06351025	BOLT		
006	007		07161030	LOCKWASHER		
007	016		07151220	WASHER		
008	014		06471001	LOCKNUT		
009	009		15300442	U-BOLT		
010	006		00103339	WASHER		
011	006		07181020	WASHER		



100-0135-9181 ROCK AND SUMP GUARDS
FROM SERIAL NO. A9171011

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
----	-----	-----	----------	-------------	-----------------	---------------

001	001		15323057	SUMP GUARD-DROPBOX		
002	001		15330423	BOLT M20		
003	001		07162030	LOCKWASHER		
004	001		09176228	WASHER		
005	002		06351670	BOLT M16		
006	002		07151630	WASHER		
007	002		06471601	LOCKNUT		

Product: 2007 TEREX TA35 G7 (OCDB) Articulated Truck Workshop Parts Manual[PN15503340]

Full Download: <https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/>

[cdb-articulated-truck-workshop-parts-manualpn15503340/](https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/)

THIS PAGE IS INTENTIONALLY LEFT BLANK

Sample of manual. Download All 538 pages at:

<https://www.arepairmanual.com/downloads/2007-terex-ta35-g7-ocdb-articulated-truck-workshop-parts-manualpn15503340/>