

Product: New Holland Boomer 20/Boomer 25 Compact Tractor Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-boomer-20-boomer-25-compact-tractor-service-repair-manual/>

SERVICE MANUAL

Boomer™ 20 / Boomer™ 25 Compact Tractor

Part number 48017684

English

June 2016



Sample of manual. Download All 873 pages at:

<https://www.arepairmanual.com/downloads/new-holland-boomer-20-boomer-25-compact-tractor-service-repair-manual/>

© 2016 CNH Industrial America LLC. All Rights Reserved.

Product: New Holland Boomer 20/Boomer 25 Compact Tractor Service Repair Manual

Full Download: <https://www.arepairmanual.com/downloads/new-holland-boomer-20-boomer-25-compact-tractor-service-repair-manual/>



SERVICE MANUAL

Boomer™ 20

Boomer™ 25

Sample of manual. Download All 873 pages at:

<https://www.arepairmanual.com/downloads/new-holland-boomer-20-boomer-25-compact-tractor-service-repair-manual/>

48017684 02/06/2016

EN

Link Product / Engine

| Product | Market Product | Engine |
|------------|----------------|--------|
| Boomer™ 20 | Europe | S3L2 |
| Boomer™ 25 | Europe | S3L2 |

Contents

INTRODUCTION

| | |
|---|------|
| Engine..... | 10 |
| [10.001] Engine and crankcase | 10.1 |
| [10.304] Engine lubrication system..... | 10.2 |
| [10.400] Engine cooling system | 10.3 |
| Clutch | 18 |
| [18.110] Clutch and components | 18.1 |
| [18.112] Slip clutch or flywheel damper | 18.2 |
| Transmission..... | 21 |
| [21.114] Mechanical transmission | 21.1 |
| Front axle system | 25 |
| [25.100] Powered front axle | 25.1 |
| [25.102] Front bevel gear set and differential | 25.2 |
| [25.108] Final drive hub, steering knuckles, and shafts | 25.3 |
| [25.310] Final drives | 25.4 |
| Rear axle system..... | 27 |
| [27.106] Rear bevel gear set and differential | 27.1 |
| [27.124] Final drive hub, steering knuckles, and shafts | 27.2 |
| Hydrostatic drive..... | 29 |
| [29.100] Transmission and steering hydrostatic control | 29.1 |
| [29.202] Hydrostatic transmission | 29.2 |
| [29.204] Reservoir, cooler, and lines | 29.3 |
| [29.218] Pump and motor components..... | 29.4 |
| Power Take-Off (PTO)..... | 31 |
| [31.101] Rear mechanical control | 31.1 |
| [31.104] Rear electro-hydraulic control..... | 31.2 |

| | |
|--|-----------|
| [31.110] One-speed rear Power Take-Off (PTO) | 31.3 |
| [31.120] Central Power Take-Off (PTO) | 31.4 |
| Brakes and controls | 33 |
| [33.110] Parking brake or parking lock | 33.1 |
| [33.120] Mechanical service brakes | 33.2 |
| Hydraulic systems..... | 35 |
| [35.000] Hydraulic systems..... | 35.1 |
| [35.104] Fixed displacement pump..... | 35.2 |
| [35.114] Three-point hitch control valve | 35.3 |
| [35.116] Three-point hitch cylinder | 35.4 |
| [35.204] Remote control valves | 35.5 |
| [35.300] Reservoir, cooler, and filters..... | 35.6 |
| [35.350] Safety and main relief valves | 35.7 |
| Hitches, drawbars, and implement couplings..... | 37 |
| [37.110] Rear three-point hitch | 37.1 |
| Steering..... | 41 |
| [41.106] Tie rods..... | 41.1 |
| [41.200] Hydraulic control components..... | 41.2 |
| [41.216] Cylinders | 41.3 |
| Wheels..... | 44 |
| [44.511] Front wheels..... | 44.1 |
| [44.520] Rear wheels | 44.2 |
| Electrical systems..... | 55 |
| [55.000] Electrical system | 55.1 |
| [55.010] Fuel injection system..... | 55.2 |
| [55.011] Fuel tank system | 55.3 |
| [55.012] Engine cooling system | 55.4 |

| | |
|--|-------|
| [55.013] Engine oil system | 55.5 |
| [55.031] Parking brake electrical system | 55.6 |
| [55.048] Rear Power Take-Off (PTO) control system | 55.7 |
| [55.100] Harnesses and connectors..... | 55.8 |
| [55.201] Engine starting system..... | 55.9 |
| [55.202] Cold start aid | 55.10 |
| [55.302] Battery..... | 55.11 |
| [55.404] External lighting | 55.12 |
| [55.405] External lighting switches and relays | 55.13 |
| [55.408] Warning indicators, alarms, and instruments | 55.14 |
| Platform, cab, bodywork, and decals | 90 |
| [90.120] Mechanically-adjusted operator seat..... | 90.1 |



INTRODUCTION

Contents

INTRODUCTION

| | |
|--|----|
| Foreword | 3 |
| Foreword - Important notice regarding equipment servicing | 4 |
| International symbols | 5 |
| Safety rules | 6 |
| Safety rules | 7 |
| Safety rules - Ecology and the environment | 8 |
| Basic instructions hardware | 9 |
| Torque - Standard torque data for hydraulic connections | 10 |
| Basic instructions - Shop and assembly | 17 |
| General specification - Tractors with Hydrostatic Transmission (HST) | 19 |
| General specification - Tractor with mechanical transmission | 23 |
| General specification | 26 |
| Dimension | 27 |
| Consumables | 30 |
| Capacities | 31 |
| Product identification | 32 |
| Product identification machine orientation | 34 |

Foreword

This repair manual provides the technical information needed to properly service the NEW HOLLAND models Boomer 20 and 25 tractors. Use this manual in conjunction with the operator's manual for complete operation, adjustment, and maintenance information.

On NEW HOLLAND equipment, left and right are determined by standing behind the unit, looking in the direction of travel.

Foreword - Important notice regarding equipment servicing

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your NEW HOLLAND Sales and Service Networks.

International symbols

As a guide to the operation of the machine, various universal symbols have been utilized on the instruments, controls, switches, and fuse box. The symbols are shown below with an indication of their meaning.

| | | | | | | | |
|---|----------------------------|---|------------------------------|---|-----------------------------|---|------------------------------------|
|  | Thermostat starting aid |  | Radio |  | PTO |  | Position Control |
|  | Alternator charge | KAM | Keep alive memory | N | Transmission in neutral |  | Draft Control |
|  | Fuel level |  | Turn signals |  | Creeper gears |  | Accessory socket |
|  | Automatic Fuel shut-off |  | Turn signals -one trailer |  | Slow or low setting |  | Implement socket |
|  | Engine speed (RPM x 100) |  | Turn signals -two trailers |  | Fast or high setting |  | %age slip |
|  | Hours recorded |  | Front wind-screen wash/wipe |  | Ground speed |  | Hitch raise (rear) |
|  | Engine oil pressure |  | Rear wind-screen wash/wipe |  | Differential lock |  | Hitch lower (rear) |
|  | Engine coolant temperature |  | Heater temperature control |  | Rear axle oil temperature |  | Hitch height limit (rear) |
|  | Coolant level |  | Heater fan |  | Transmission oil pressure |  | Hitch height limit (front) |
|  | Tractor lights |  | Air conditioner |  | FWD engaged |  | Hitch disabled |
|  | Headlamp main beam |  | Air filter blocked |  | FWD disengaged |  | Hydraulic and transmission filters |
|  | Headlamp dipped beam |  | Parking brake |  | Warning! |  | Remote valve extend |
|  | Work lamps |  | Brake fluid level |  | Hazard warning lights |  | Remote valve retract |
|  | Stop lamps |  | Trailer brake |  | Variable control |  | Remote valve float |
|  | Horn |  | Roof beacon |  | Pressurised! Open carefully |  | Malfunction! See Operator's Manual |
| | |  | Warning! Corrosive substance | | |  | Malfunction! (alternative symbol) |

Safety rules

**CALIFORNIA
PROPOSITION 65 WARNING**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery post, terminals and related accessories contain lead and lead compounds.

Wash hands after handling

Safety rules

Personal safety



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

⚠ DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

⚠ WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

⚠ CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.

Machine safety

NOTICE: *Notice indicates a situation that, if not avoided, could result in machine or property damage.*

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

Information

NOTE: *Note indicates additional information that clarifies steps, procedures, or other information in this manual.*

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

Safety rules - Ecology and the environment

Soil, air, and water quality is important for all industries and life in general. When legislation does not yet rule the treatment of some of the substances that advanced technology requires, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

Familiarize yourself with the relative legislation applicable to your country, and make sure that you understand this legislation. Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, anti-freeze, cleaning agents, etc., with regard to the effect of these substances on man and nature and how to safely store, use, and dispose of these substances.

Helpful hints

- Avoid the use of cans or other inappropriate pressurized fuel delivery systems to fill tanks. Such delivery systems may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of these products contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when you drain fluids such as used engine coolant mixtures, engine oil, hydraulic fluid, brake fluid, etc. Do not mix drained brake fluids or fuels with lubricants. Store all drained fluids safely until you can dispose of the fluids in a proper way that complies with all local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- The air-conditioning system contains gases that should not be released into the atmosphere. Consult an air-conditioning specialist or use a special extractor to recharge the system properly.
- Repair any leaks or defects in the engine cooling system or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding. Penetrating weld splatter may burn a hole or weaken hoses, allowing the loss of oils, coolant, etc.

Battery recycling

Batteries and electric accumulators contain several substances that can have a harmful effect on the environment if the batteries are not properly recycled after use. Improper disposal of batteries can contaminate the soil, groundwater, and waterways. NEW HOLLAND strongly recommends that you return all used batteries to a NEW HOLLAND dealer, who will dispose of the used batteries or recycle the used batteries properly. In some countries, this is a legal requirement.



Mandatory battery recycling

NOTE: The following requirements are mandatory in Brazil.

Batteries are made of lead plates and a sulfuric acid solution. Because batteries contain heavy metals such as lead, CONAMA Resolution 401/2008 requires you to return all used batteries to the battery dealer when you replace any batteries. Do not dispose of batteries in your household garbage.

Points of sale are obliged to:

- Accept the return of your used batteries
- Store the returned batteries in a suitable location
- Send the returned batteries to the battery manufacturer for recycling

Basic instructions hardware

General

Your tractor has been built using metric hardware.

NOTE: Be sure to use the hardware specified when using tapped holes, as trying to install a metric bolt in an inch thread, or an inch bolt in a metric thread, will damage the thread.

Certain hardware must be tightened to specific torque specifications. If specific torque specifications are not noted, tighten the hardware to the standard torque chart specification listed in this manual.

Plating

Hardware used on NEW HOLLAND balers is plated with zinc chromate (gold color). Gold colored hardware has different torquing requirements from unplated or zinc plated (silver color) hardware because of the difference in the coefficient of friction of the plating material. The torque charts in this manual list the correct specifications for gold, silver, and unplated bolts.

Nut tightening

Whenever possible, the nut should be tightened, not the head of the bolt. When tightening using the bolt head, the clamp load can be lost because some of the torque applied twists the bolt instead of tensioning (stretching) it. The tension on the bolt is what holds the joint together.

Approximately 90% of the torque applied during assembly goes to overcoming friction between the parts. The other 10% is used to tension (stretch) the bolt. After assembly, the frictional forces disappear, which is the basis for the saying 'If it does not fail during assembly, it will not fail in service.' The bolt may later fail due to other factors, but not from being over tightened.

Locknuts

Most locknuts are coated with a special lubricant that is dry to the touch. Anytime a locknut is used, a lower than normal torque is required. Refer to the torque charts in this manual for specific values.

Jam nuts

When using a jam nut to lock a regular nut, the jam nut should be installed first and tightened to one half the recommended torque, then held in place while installing a regular nut to the recommended torque.

Thread lubrication

The addition of antiseize compound, Molykote, oil, graphite, or any other lubricant to a bolt decreases the friction between it and a nut. This makes it necessary to reduce the recommended torque to prevent over tensioning of the bolt. When using the torque charts in this manual, decrease the value by 20% whenever a lubricant is used.

Torque - Standard torque data for hydraulic connections

General information

- Hydraulic connections require a minimum assembly torque in order to provide zero leakage at rated pressure with adequate fatigue resistance. Over-torquing of a hydraulic connection can also lead to leakage or failure. For some connections, NEW HOLLAND requires a different torque value than is listed in the ISO and SAE standards.
- The torque values in this document should be used whenever possible or applicable.

NOTICE: Always follow the instructions in this manual for specific torque values when you service components. The information in this section is for general guidance only when a procedure contains no specific torque value.

Tolerance

- The tolerance for all torque values is **± 10 %**. This tolerance must include all assembly variation, not only the torque wrench repeatability.

Lubrication

Application of grease or other lubricants to hydraulic connectors should be avoided. If clean hydraulic oil is already on the connection, it is not required to remove the oil. Generally, application of grease:

- May cause a significant change in the torque required to properly tighten the connection.
- May reduce the connection's resistance to vibration.
- Excessive grease may displace an elastomer seal during tightening.
- Grease extrusion when connection is tightened may be mistaken for leakage.

NEW HOLLAND products generally use O-Ring Boss (ORB) connectors that have Teflon™-coated O-rings, eliminating the need for O-ring lubrication during installation. For connections which are made into aluminum manifolds or with stainless steel connectors, it may be required to apply a lubricant to prevent galling.

Use of Loctite® and other thread-locking compounds is prohibited. These compounds:

- May cause a significant change in the torque required to properly tighten the connections.
- Reduce the serviceability of the joint.
- May prevent the O-ring from properly sealing if the compound gets on the O-ring.

Torque values for metric O-Ring Boss (ORB) port connections

| Metric thread | S-Series * | | L-Series ** | |
|----------------------|---|---|---|---|
| | Ferrous N·m (lb ft) ± 10 % | Non-Ferrous N·m (lb ft) ± 10 % | Ferrous N·m (lb ft) ± 10 % | Non-Ferrous N·m (lb ft) ± 10 % |
| M8 x 1 | 10.5 (7.7) | 6.3 (4.6) | 8.5 (6.3) | 5 (3.7) |
| M10 x 1 | 21 (15.5) | 12.5 (9.2) | 15.5 (11.4) | 9.3 (6.9) |
| M12 x 1.5 | 37 (27.3) | 22 (16.2) | 27 (19.9) | 16 (11.8) |
| M14 x 1.5 | 47 (34.7) | 28 (20.7) | 37 (27.3) | 22 (16.2) |
| M16 x 1.5 | 58 (42.8) | 35 (25.8) | 42 (31) | 25 (18.4) |
| M18 x 1.5 | 74 (54.6) | 44 (32.5) | 47 (34.7) | 28 (20.7) |
| M22 x 1.5 | 105 (77.4) | 63 (46.5) | 63 (46.5) | 38 (28) |
| M27 x 2 | 178 (131.3) | 107 (78.9) | 105 (77.4) | 63 (46.5) |
| M30 x 2 | 225 (166) | 135 (99.6) | 136 (100.3) | 82 (60.5) |
| M33 x 2 | 325 (239.7) | 195 (143.8) | 168 (123.9) | 101 (74.5) |
| M42 x 2 | 345 (254.5) | 207 (152.7) | 220 (162.3) | 132 (97.4) |
| M48 x 2 | 440 (324.5) | 264 (194.7) | 273 (201.4) | 164 (121) |
| M60 x 2 | 525 (387.2) | 315 (232.3) | 330 (243.4) | 198 (146) |

* S-Series connectors are used with O-Ring Face Seals (ORFS).

** L-Series connectors are used with 37 ° flare.

Torque values for metric O-Ring Boss (ORB) port plugs

| Metric thread | Ferrous | | Non-ferrous |
|----------------------|--|--|---------------------------|
| | Internal hex N·m (lb ft) ± 10 % | External hex N·m (lb ft) ± 10 % | N·m (lb ft) ± 10 % |
| M8 x 1 | 8.5 (6.3) | 10.5 (7.7) | 6.3 (4.6) |
| M10 x 1 | 16 (11.8) | 21 (15.5) | 12.5 (9.2) |
| M12 x 1.5 | 23 (17) | 37 (27.3) | 22 (16.2) |
| M14 x 1.5 | 47 (34.7) | 47 (34.7) | 28 (20.7) |
| M16 x 1.5 | 58 (42.8) | 58 (42.8) | 35 (25.8) |
| M18 x 1.5 | 74 (54.6) | 74 (54.6) | 44 (32.5) |
| M22 x 1.5 | 105 (77.4) | 105 (77.4) | 63 (46.5) |
| M27 x 2 | 178 (131.3) | 178 (131.3) | 107 (78.9) |
| M30 x 2 | 225 (166) | 225 (166) | 135 (99.6) |
| M33 x 2 | 325 (239.7) | 325 (239.7) | 195 (143.8) |
| M42 x 2 | 345 (254.5) | 345 (254.5) | 207 (152.7) |
| M48 x 2 | 440 (324.5) | 440 (324.5) | 264 (194.7) |
| M60 x 2 | 525 (387.2) | 525 (387.2) | 315 (232.3) |

INTRODUCTION

Torque values for port connections (British Standard Pipe Parallel (BSPP) thread ports and stud ends)

| Metric tube Outside Diameter (OD) mm (in) | | Ferrous | | Non-Ferrous | | |
|--|--------------------------------|--------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|
| BSPP thread G- Gas; A- medium coarse threads | S-Series * | L-Series ** | S-Series N·m (lb ft) ± 10 % | L-Series N·m (lb ft) ± 10 % | S-Series N·m (lb ft) ± 10 % | L-Series N·m (lb ft) ± 10 % |
| G 1/8 A | — | 6 (0.236) | — | 21 (15.5) | — | 12.5 (9.2) |
| G 1/4 A | 6 (0.236) or 8 (0.315) | 8 (0.315) or 10 (0.394) | 63 (46.5) | 53 (39.1) | 38 (28) | 32 (23.6) |
| G 3/8 A | 10 (0.394) or 12 (0.472) | 12 (0.472) | 95 (70.1) | 84 (62) | 57 (42) | 50 (36.9) |
| G 1/2 A | 16 (0.630) | 15 (0.591) or 18 (0.709) | 136 (100.3) | 105 (77.4) | 82 (60.5) | 63 (46.5) |
| G 3/4 A | 20 (0.787) | 22 (0.866) | 210 (154.9) | 210 (154.9) | 126 (92.9) | 126 (92.9) |
| G 1 A | 25 (0.984) | 28 (1.102) | 400 (295) | 400 (295) | 240 (177) | 240 (177) |
| G 1 1/4 A | 30 (1.181) | 35 (1.378) | 525 (387.2) | 525 (387.2) | 315 (232.3) | 315 (232.3) |
| G 1 1/2 A | 38 (1.496) | 42 (1.654) | 660 (486.8) | 660 (486.8) | 396 (292.1) | 396 (292.1) |

* S-Series connectors are used with O-Ring Face Seals (ORFS).

** L-Series connectors are used with 37 ° flare.

Torque values for metric port connections (Metric face-seal ports and stud ends)

| Metric tube Outside Diameter (OD) mm (in) | | Ferrous | | Non-Ferrous | | |
|---|------------|-------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|
| Metric thread | S-Series * | L-Series ** | S-Series N·m (lb ft) ± 10 % | L-Series N·m (lb ft) ± 10 % | S-Series N·m (lb ft) ± 10 % | L-Series N·m (lb ft) ± 10 % |
| M10 x 1 | — | 4 (0.157) | — | 21 (15.5) | — | 12.5 (9.2) |
| M12 x 1.5 | 4 (0.157) | 6 (0.236) | 47 (34.7) | 32 (23.6) | 28 (20.7) | 19 (14) |
| M14 x 1.5 | 5 (0.197) | 7 (0.276) | 63 (46.5) | 53 (39.1) | 38 (28) | 32 (23.6) |
| M16 x 1.5 | 7 (0.276) | 9 (0.354) | 84 (62) | 63 (46.5) | 50 (36.9) | 38 (28) |
| M18 x 1.5 | 8 (0.315) | 11 (0.433) | 105 (77.4) | 84 (62) | 63 (46.5) | 50 (36.9) |
| M20 x 1.5 | 10 (0.394) | — | 147 (108.4) | — | 88 (64.9) | — |
| M22 x 1.5 | 12 (0.472) | 14 (0.551) | 158 (116.5) | 147 (108.4) | 95 (70.1) | 88 (64.9) |
| M26 x 1.5 | — | 18 (0.709) | — | 210 (154.9) | — | 126 (92.9) |
| M27 x 1.2 | 16 (0.630) | — | 210 (154.9) | — | 126 (92.9) | — |
| M33 x 2 | 20 (0.787) | 23 (0.906) | 400 (295) | 400 (295) | 240 (177) | 240 (177) |
| M42 x 2 | 25 (0.984) | 30 (1.181) | 525 (387.2) | 525 (387.2) | 315 (232.3) | 315 (232.3) |
| M48 x 2 | 32 (1.260) | 36 (1.417) | 630 (464.7) | 630 (464.7) | 396 (292.1) | 396 (292.1) |

* S-Series connectors are used with O-Ring Face Seals (ORFS).

** L-Series connectors are used with 37 ° flare.

INTRODUCTION

Torque values for Inch O-Ring Boss (ORB) port non-adjustable connections

| SAE dash size | UN/UNF thread size | Inch tube OD mm (in) | S-Series * | | L-Series ** | |
|------------------|-----------------------|----------------------------|----------------------------------|--|----------------------------------|--|
| | | | Ferrous N·m (lb ft) ± 10 % | Non- Ferrous N·m (lb ft) ± 10 % | Ferrous N·m (lb ft) ± 10 % | Non- Ferrous N·m (lb ft) ± 10 % |
| 2 | 5/16-24 | 3.18 (0.125) | — | — | 8.5 (6.3) | 5 (3.7) |
| 3 | 3/8-24 | 4.76 (0.187) | 15.5 (11.4) | 9.3 (6.9) | 10.5 (7.7) | 6.3 (4.6) |
| 4 | 7/16-20 | 6.35 (0.250) | 37 (27.3) | 22 (16.2) | 19 (14) | 11.5 (8.5) |
| 5 | 1/2-20 | 7.94 (0.313) | 42 (31) | 25 (18.4) | 26 (19.2) | 15.5 (11.4) |
| 6 | 9/16-18 | 9.52 (0.375) | 47 (34.7) | 28 (20.7) | 32 (23.6) | 19 (14) |
| 8 | 3/4-16 | 12.7 (0.500) | 89 (65.6) | 53 (39.1) | 53 (39.1) | 32 (23.6) |
| 10 | 7/8-14 | 15.88 (0.625) | 121 (89.2) | 73 (53.8) | 63 (46.5) | 38 (28) |
| 12 | 1-1/16-12 | 19.05 (0.750) | 178 (131.3) | 107 (78.9) | 100 (73.8) | 60 (44.3) |
| 14 | 1-3/16-12 | 22.22 (0.875) | 225 (166) | 135 (99.6) | 131 (96.6) | 79 (58.3) |
| 16 | 1-5/16-12 | 25.4 (1.000) | 283 (208.7) | 170 (125.4) | 156 (115.1) | 94 (69.3) |
| 20 | 1-5/8-12 | 31.75 (1.250) | 300 (221.3) | 180 (132.8) | 210 (154.9) | 126 (92.9) |
| 24 | 1-7/8-12 | 38.1 (1.500) | 388 (286.2) | 233 (171.9) | 220 (162.3) | 132 (97.4) |
| 32 | 2-1/2-12 | 50.8 (2.000) | 388 (286.2) | 233 (171.9) | 315 (232.3) | 189 (139.4) |

* S-Series connectors are used with O-Ring Face Seals (ORFS).

** L-Series connectors are used with 37 ° flare.

Torque values for inch O-Ring Boss (ORB) port adjustable connections

| SAE dash size | UN/UNF thread size | Inch tube OD mm (in) | S-Series * | | L-Series ** | |
|------------------|-----------------------|----------------------------|----------------------------------|--|----------------------------------|--|
| | | | Ferrous N·m (lb ft) ± 10 % | Non- Ferrous N·m (lb ft) ± 10 % | Ferrous N·m (lb ft) ± 10 % | Non- Ferrous N·m (lb ft) ± 10 % |
| 2 | 5/16-24 | 3.18 (0.125) | — | — | 8.5 (6.3) | 5 (3.7) |
| 3 | 3/8-24 | 4.76 (0.187) | 10.5 (7.7) | 9.3 (6.9) | 10.5 (7.7) | 6.3 (4.6) |
| 4 | 7/16-20 | 6.35 (0.250) | 21 (15.5) | 21 (15.5) | 19 (14) | 11.5 (8.5) |
| 5 | 1/2-20 | 7.94 (0.313) | 42 (31) | 25 (18.4) | 26 (19.2) | 15.5 (11.4) |
| 6 | 9/16-18 | 9.52 (0.375) | 47 (34.7) | 28 (20.7) | 32 (23.6) | 19 (14) |
| 8 | 3/4-16 | 12.7 (0.500) | 89 (65.6) | 53 (39.1) | 53 (39.1) | 32 (23.6) |
| 10 | 7/8-14 | 15.88 (0.625) | 121 (89.2) | 73 (53.8) | 63 (46.5) | 38 (28) |
| 12 | 1-1/16-12 | 19.05 (0.750) | 178 (131.3) | 107 (78.9) | 100 (73.8) | 60 (44.3) |
| 14 | 1-3/16-12 | 22.22 (0.875) | 225 (166) | 135 (99.6) | 131 (96.6) | 79 (58.3) |
| 16 | 1-5/16-12 | 25.4 (1.000) | 285 (210.2) | 170 (125.4) | 156 (115.1) | 94 (69.3) |
| 20 | 1-5/8-12 | 31.75 (1.250) | 300 (221.3) | 180 (132.8) | 210 (154.9) | 126 (92.9) |
| 24 | 1-7/8-12 | 38.1 (1.500) | 388 (286.2) | 233 (171.9) | 220 (162.3) | 132 (97.4) |
| 32 | 2-1/2-12 | 50.8 (2.000) | 388 (286.2) | 233 (171.9) | 315 (232.3) | 189 (139.4) |

* S-Series connectors are used with O-Ring Face Seals (ORFS).

** L-Series connectors are used with 37 ° flare.

INTRODUCTION

Torque values for inch O-Ring Boss (ORB) port plugs

| SAE dash size | UN/UNF thread size | Ferrous | | Non-Ferrous |
|------------------|-----------------------|---------------------------------------|---------------------------------------|-----------------------|
| | | Internal hex N·m (lb ft) ± 10 % | External hex N·m (lb ft) ± 10 % | N·m (lb ft) ± 10 % |
| 2 | 5/16-24 | 7.5 (5.5) | 12.5 (9.2) | 7.5 (5.5) |
| 3 | 3/8-24 | 14.5 (10.7) | 21 (15.5) | 12.5 (9.2) |
| 4 | 7/16-20 | 21 (15.5) | 37 (27.3) | 22 (16.2) |
| 5 | 1/2-20 | 28 (20.7) | 42 (31) | 25 (18.4) |
| 6 | 9/16-18 | 47 (34.7) | 47 (34.7) | 28 (20.7) |
| 8 | 3/4-16 | 89 (65.6) | 89 (65.6) | 53 (39.1) |
| 10 | 7/8-14 | 116 (85.6) | 116 (85.6) | 70 (51.6) |
| 12 | 1-1/16-12 | 176 (129.8) | 176 (129.8) | 106 (78.2) |
| 14 | 1-3/16-12 | 247 (182.2) | 247 (182.2) | 148 (109.2) |
| 16 | 1-5/16-12 | 284 (209.5) | 284 (209.5) | 170 (125.4) |
| 20 | 1-5/8-12 | 357 (263.3) | 357 (263.3) | 214 (157.8) |
| 24 | 1-7/8-12 | 441 (325.3) | 441 (325.3) | 265 (195.5) |
| 32 | 2-1/2-12 | 536 (395.3) | 536 (395.3) | 322 (237.5) |

Torque values for four-bolt flange connections (Metric Screws, Class 10.9)

| Metric size mm | Imperial size in | Screw code 61 | Code 61 N·m (lb ft) ± 10 % | Screw code 62 | Code 62 N·m (lb ft) ± 10 % |
|-------------------|---------------------|------------------|----------------------------------|------------------|----------------------------------|
| 13 | 1/2 | M8 x 1.25 | 34 (25.1) | M8 x 1.25 | 34 (25.1) |
| 19 | 3/4 | M10 x 1.5 | 74 (54.6) | M10 x 1.5 | 74 (54.6) |
| 25 | 1 | M10 x 1.5 | 74 (54.6) | M12 x 1.75 | 137 (101) |
| 32 | 1-1/4 | M10 x 1.5 | 74 (54.6) | M12 x 1.75 | 137 (101) |
| | | | | M14 x 1.5 | 189 (139.4) |
| 38 | 1-1/2 | M12 x 1.75 | 137 (101) | M16 x 2 | 310 (228.6) |
| 51 | 2 | M12 x 1.75 | 137 (101) | M20 x 2.5 | 575 (424.1) |
| 64 | 2-1/2 | M12 x 1.75 | 137 (101) | M24 x 3 | 575 (424.1) |
| 76 | 3 | M16 x 2 | 310 (228.6) | M30 x 3.5 | 680 (501.5) |
| 89 | 3-1/2 | M16 x 2 | 310 (228.6) | — | — |
| 102 | 4 | M16 x 2 | 310 (228.6) | — | — |
| 127 | 5 | M16 x 2 | 310 (228.6) | — | — |

Torque values for four-bolt flange connections (Metric Screws, Class 8.8)

| Metric size mm | Imperial size in | Screw code 61 | Code 61 N·m (lb ft) ± 10 % | Screw code 62 | Code 62 N·m (lb ft) ± 10 % |
|-------------------|---------------------|------------------|----------------------------------|------------------|----------------------------------|
| 13 | 1/2 | M8 x 1.25 | 29 (21.4) | M8 x 1.25 | 29 (21.4) |
| 19 | 3/4 | M10 x 1.5 | 57(42) | M10 x 1.5 | 57(42) |
| 25 | 1 | M10 x 1.5 | 57(42) | M12 x 1.75 | 100 (73.8) |
| 32 | 1-1/4 | M10 x 1.5 | 57(42) | M12 x 1.75 | 100 (73.8) |
| | | | | M14 x 1.5 | 160 (118) |
| 38 | 1-1/2 | M12 x 1.75 | 100 (73.8) | M16 x 2 | 250 (184.4) |
| 51 | 2 | M12 x 1.75 | 100 (73.8) | M20 x 2.5 | 500 (368.8) |
| 64 | 2-1/2 | M12 x 1.75 | 100 (73.8) | M24 x 3 | 575 (424.1) |
| 76 | 3 | M16 x 2 | 250 (184.4) | M30 x 3.5 | 680 (501.5) |
| 89 | 3-1/2 | M16 x 2 | 250 (184.4) | — | — |
| 102 | 4 | M16 x 2 | 250 (184.4) | — | — |
| 127 | 5 | M16 x 2 | 250 (184.4) | — | — |

INTRODUCTION

Torque values for four-bolt flange connections (Inch Screws, Grade 8)

| Metric size mm | Imperial size in | Screw code 61 | Code 61 N·m (lb ft) $\pm 10\%$ | Screw code 62 | Code 62 N·m (lb ft) $\pm 10\%$ |
|----------------|------------------|---------------|--------------------------------|---------------|--------------------------------|
| 13 | 1/2 | 5/16-18 | 34 (25.1) | 5/16-18 | 34 (25.1) |
| 19 | 3/4 | 3/8-16 | 63 (46.5) | 3/8-16 | 63 (46.5) |
| 25 | 1 | 3/8-16 | 63 (46.5) | 7/16-14 | 97 (71.5) |
| 32 | 1-1/4 | 7/16-14 | 97 (71.5) | 1/2-13 | 158 (116.5) |
| 38 | 1-1/2 | 1/2-13 | 158 (116.5) | 5/8-11 | 310 (228.6) |
| 51 | 2 | 1/2-13 | 158 (116.5) | 3/4-10 | 473 (348.9) |
| 64 | 2-1/2 | 1/2-13 | 158 (116.5) | — | — |
| 76 | 3 | 5/8-11 | 310 (228.6) | — | — |
| 89 | 3-1/2 | 5/8-11 | 310 (228.6) | — | — |
| 102 | 4 | 5/8-11 | 310 (228.6) | — | — |
| 127 | 5 | 5/8-11 | 310 (228.6) | — | — |

Tapered thread connection tightening

| British Standard Pipe Taper (BSPT) thread size (inch) | National Pipe Thread Fuel (NPTF) thread size (inch) | Turns from finger tight |
|---|---|-------------------------|
| 1/8-28 | 1/8-27 | 2 - 3 |
| 1/4-19 | 1/4-18 | 2 - 3 |
| 3/8-19 | 3/8-18 | 2 - 3 |
| 1/2-14 | 1/2-14 | 2 - 3 |
| 3/4-14 | 3/4-14 | 2 - 3 |
| 1-11 | 1-11 1/2 | 1.5 - 2.5 |
| 1-1/4-11 | 1-1/4-11 1/2 | 1.5 - 2.5 |
| 1-1/2-11 | 1-1/2-11 1/2 | 1.5 - 2.5 |
| 2-11 | 2-11 1/2 | 1.5 - 2.5 |

Torque values for banjo bolt connections (Copper washer style)

| Bolt thread (metric) | Hex size (mm) | Torque N·m (lb ft) $\pm 10\%$ |
|----------------------|---------------|-------------------------------|
| M8 x 1.25 | 13 | 13 (9.6) |
| M10 x 1.25 | 17 | 16 (11.8) |
| M12 x 1.5 | 17 | 40 (29.5) |
| M14 x 1.5 | 19 | 45 (33.2) |
| M16 x 1.5 | 22 | 48 (35.4) |
| M18 x 1.5 | 24 | 50 (36.9) |
| M20 x 1.5 | 27 | 73 (53.8) |
| M22 x 1.5 | 32 | 73 (53.8) |
| M24 x 1.5 | 32 | 73 (53.8) |

INTRODUCTION

Torque values for O-Ring Face Seals (ORFS) connections

| SAE dash size | UN/UNF thread size | Inch tube OD (mm) | Metric tube OD (mm) | Hex size (mm) (Reference only) | * Swivel nut torque N·m (lb ft) ± 10 % | ** Swivel nut torque N·m (lb ft) ± 10 % |
|---------------|--------------------|-------------------|---------------------|--------------------------------|--|---|
| 4 | 9/16-18 | 6.35 | 6 | 17 | 27 (19.9) | 27 (19.9) |
| 5 | 5/8-18 | 7.94 | 8 | 19 | 34 (25.1) | 34 (25.1) |
| 6 | 11/16-16 | 9.52 | 10 | 22 | 44 (32.5) | 44 (32.5) |
| 8 | 13/16-16 | 12.7 | 12 | 24 | 65 (47.9) | 65 (47.9) |
| 10 | 1-14 | 15.88 | 16 | 30 | 100 (73.8) | 100 (73.8) |
| 12 | 1-3/16-12 | 19.05 | 20 | 36 | 150 (110.6) | 131 (96.6) |
| 14 | 1-5/16-12 | 22.23 | 22 | 41 | 163 (120.2) | 131 (96.6) |
| 16 | 1-7/16-12 | 25.4 | 25 | 41 | 210 (154.9) *** | 131 (96.9) |
| 20 | 1-11/16-12 | 31.75 | 30 | 50 | 280 (206.5) *** | 178 (131.3) |
| 24 | 2-12 | 38.1 | 38 | 60 | 375 (276.6) *** | 210 (154.9) |

* High/Medium-pressure applications > 50 bar (725 psi).

** Low-pressure applications < 50 bar (725 psi).

*** It is recommended to use a four-bolt flange connection instead of O-Ring Face Seals (ORFS) sizes "16" and up.

Torque values for 37 ° flare connections - Joint Industry Council (JIC)

| SAE dash size | UN/UNF thread size | Metric tube OD (mm) | Inch tube OD (mm) | Swivel nut torque N·m (lb ft) ± 10 % |
|---------------|--------------------|---------------------|-------------------|--------------------------------------|
| 2 | 5/16-24 | — | 3.18 | 8.25 (6.1) |
| 3 | 3/8-24 | — | 4.76 | 11.5 (8.5) |
| 4 | 7/16-20 | 6 | 6.35 | 15.5 (11.4) |
| 5 | 1/2-20 | 8 | 7.94 | 20 (14.8) |
| 6 | 9/16-18 | 10 | 9.52 | 25 (18.4) |
| 8 | 3/4-16 | 12 | 12.7 | 52 (38.4) |
| 10 | 7/8-14 | 16 | 15.88 | 81 (59.7) |
| 12 | 1-1/16-12 | 20 | 19.05 | 112 (82.6) |
| 14 | 1-3/16-12 | — | 22.22 | 133 (98.1) |
| 16 | 1-5/16-12 | 25 | 25.4 | 155 (114.3) |
| 20 | 1-5/8-12 | 30/32 | 31.75 | 180 (132.8) |
| 24 | 1-7/8-12 | 38 | 38.1 | 225 (166) |
| 32 | 2-1/2-12 | 50 | 50.8 | 348 (256.7) |

Torque values for 30 ° flare, 60 ° cone connections

| Nominal size (mm) | British Standard Pipe Parallel (BSPP) thread size | Hex size (mm) | Swivel nut torque N·m (lb ft) ± 10 % |
|-------------------|---|---------------|--------------------------------------|
| 5, 6, 6.3 | G 1/4 | 17 | 25 (18.4) |
| 8, 9, 10 | G 3/8 | 19 | 34 (25.1) |
| 12, 12.5 | G 1/2 | 22 | 64 (47.2) |
| 15, 16, 19 | G 3/4 | 30 | 132 (97.4) |
| 25 | G 1 | 36 | 196 (144.6) |
| 31.5, 32 | G 1-1/4 | 46 | 225 (166) |
| 38 | G 1-1/2 | 50 | 255 (188.1) |
| 50, 51 | G 2 | 65 | 316 (223.1) |

Basic instructions - Shop and assembly

Shimming

For each adjustment operation, select adjusting shims and measure the adjusting shims individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value shown on each shim.

Rotating shaft seals

For correct rotating shaft seal installation, proceed as follows:

1. Before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes.
2. Thoroughly clean the shaft and check that the working surface on the shaft is not damaged.
3. Position the sealing lip facing the fluid.

NOTE: *With hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will move the fluid towards the inner side of the seal.*

4. Coat the sealing lip with a thin layer of lubricant (use oil rather than grease). Fill the gap between the sealing lip and the dust lip on double lip seals with grease.
5. Insert the seal in its seat and press down using a flat punch or seal installation tool. Do not tap the seal with a hammer or mallet.
6. While you insert the seal, check that the seal is perpendicular to the seat. When the seal settles, make sure that the seal makes contact with the thrust element, if required.
7. To prevent damage to the seal lip on the shaft, position a protective guard during installation operations.

O-ring seals

Lubricate the O-ring seals before you insert them in the seats. This will prevent the O-ring seals from overturning and twisting, which would jeopardize sealing efficiency.

Sealing compounds

Apply a sealing compound on the mating surfaces when specified by the procedure. Before you apply the sealing compound, prepare the surfaces as directed by the product container.

Spare parts

Only use CNH Original Parts or NEW HOLLAND Original Parts.

Only genuine spare parts guarantee the same quality, duration, and safety as original parts, as they are the same parts that are assembled during standard production. Only CNH Original Parts or NEW HOLLAND Original Parts can offer this guarantee.

When ordering spare parts, always provide the following information:

- Machine model (commercial name) and Product Identification Number (PIN)
- Part number of the ordered part, which can be found in the parts catalog

Protecting the electronic and/or electrical systems during charging and welding

To avoid damage to the electronic and/or electrical systems, always observe the following practices:

1. Never make or break any of the charging circuit connections when the engine is running, including the battery connections.
2. Never short any of the charging components to ground.
3. Always disconnect the ground cable from the battery before arc welding on the machine or on any machine attachment.
 - Position the welder ground clamp as close to the welding area as possible.
 - If you weld in close proximity to a computer module, then you should remove the module from the machine.
 - Never allow welding cables to lie on, near, or across any electrical wiring or electronic component while you weld.
4. Always disconnect the negative cable from the battery when charging the battery in the machine with a battery charger.

NOTICE: *If you must weld on the unit, you must disconnect the battery ground cable from the machine battery. The electronic monitoring system and charging system will be damaged if this is not done.*

5. Remove the battery ground cable. Reconnect the cable when you complete welding.

⚠ WARNING

Battery acid causes burns. Batteries contain sulfuric acid.

Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately.

Failure to comply could result in death or serious injury.

W0111A

Special tools

The special tools that NEW HOLLAND suggests and illustrate in this manual have been specifically researched and designed for use with NEW HOLLAND machines. The special tools are essential for reliable repair operations. The special tools are accurately built and rigorously tested to offer efficient and long-lasting operation.

By using these tools, repair personnel will benefit from:

- Operating in optimal technical conditions
- Obtaining the best results
- Saving time and effort
- Working in safe conditions

General specification - Tractors with Hydrostatic Transmission (HST)

| | Model Boomer 20 - Hydrostatic | Model Boomer 25 - Hydrostatic |
|--|---|---|
| ENGINE | | |
| Type | Diesel | Diesel |
| Model | S3L | S3L2 |
| Engine Gross Horsepower | 17 kW (23 Hp) | 20 kW (27 Hp) |
| Cylinders | 4 | 4 |
| Bore | 78 mm (3.07 in) | 78 mm (3.07 in) |
| Stroke | 78.5 mm (3.09 in) | 92 mm (3.62 in) |
| Displacement | 1.125 l (69 in³) | 1.318 l (80 in³) |
| Compression Ratio | 22.0:1 | 20.0:1 |
| Firing Order | 1-3-2 | 1-3-2 |
| Low Idle Speed | 970±30 RPM | 970±30 RPM |
| Maximum Speed: | | |
| High Idle | 29000±20 RPM | 2900±20 RPM |
| Rated | 2700 RPM | 2700 RPM |
| Valve Clearance (Cold) | | |
| Intake | 0.020 - 0.050 mm (0.0008 - 0.0020 in) | 0.020 - 0.050 mm (0.0008 - 0.0020 in) |
| Exhaust | 0.050 - 0.085 mm (0.0020 - 0.0033 in) | 0.050 - 0.085 mm (0.0020 - 0.0033 in) |
| | | |
| | | |
| | | |
| CAPACITIES | | |
| Fuel Tank | 25 l (6.6 US gal) | 25 l (6.6 US gal) |
| Cooling System | 3.8 l (1.0 US gal) | 3.8 l (1.0 US gal) |
| Engine Crankcase: | | |
| With Filter | 4 l (1.10 US gal) | 4 l (1.10 US gal) |
| Rear Axle & Transmission (Includes Hydraulics) | | |
| HST | 20 l (5.28 US gal) | 20 l (5.28 US gal) |
| Front Axle | 3 l (1 US gal) | 3 l (1 US gal) |
| | | |
| | | |
| | | |
| COOLING SYSTEM | | |
| Type | Pressurized Liquid with Recirculating Bypass | Pressurized Liquid with Recirculating Bypass |
| Water Pump: | | |
| Type | Centrifugal | Centrifugal |
| Drive | V-Belt | V-Belt |
| Belt Deflection | 10 - 12 mm (0.39 - 0.47 in) when 10 kg (22 lb) pressure is applied midway between belt pulleys | 10 - 12 mm (0.39 - 0.47 in) when 10 kg (22 lb) pressure is applied midway between belt pulleys |
| Fan Diameter | 356 mm (14 in) | 356 mm (14 in) |
| Thermostat: | | |
| Start to Open | 76.5 °C (170 °F) | 76.5 °C (170 °F) |
| Fully Open | 90 °C (194 °F) | 90 °C (194 °F) |
| Radiator Cap | 90 kPa (13 psi) | 90 kPa (13 psi) |

INTRODUCTION

| | Model Boomer 20 - Hydrostatic | Model Boomer 25 - Hydrostatic |
|--|---|---|
| ELECTRICAL SYSTEM | | |
| Alternator | 12 V, Heavy Duty, 50 A | 12 V, Heavy Duty, 50 A |
| Battery | 12 V, w/ negative ground, 660 cca BCI Group 34 | 12 V, w/ negative ground, 660 cca BCI Group 34 |
| Starting Motor | Solenoid Pre-Engaged Reduction | Solenoid Pre-Engaged Reduction |
| FUEL SYSTEM | | |
| Fuel Type | Diesel | Diesel |
| Type of Fuel to Use if Above 4 °C (40 °F) | No. 2-Diesel, Cetane Rating: Minimum 40 | No. 2-Diesel, Cetane Rating: Minimum 40 |
| Type of Fuel to Use if Below 4 °C (40 °F) | No. 1-Diesel, Cetane Rating: Minimum 40 | No. 1-Diesel, Cetane Rating: Minimum 40 |
| Injection Pump: | | |
| Type | In-Line | In-Line |
| Timing | 19 ° BTDC | 17 ° BTDC |
| BRAKES | | |
| Type | Wet Disc | Wet Disc |
| 2 Disc per Side | 223 mm (8.78 in) x 174 mm (6.85 in) | 223 mm (8.78 in) x 174 mm (6.85 in) |
| STEERING | | |
| Type | Power | Power |
| Turns Lock-to-Lock: | | |
| FWD | 3 L to R 3.30 R to L | 3 L to R 3.30 R to L |
| Front Wheel | | |
| Toe-In | 0 - 5 mm (0 - 0.20 in) | 0 - 5 mm (0 - 0.20 in) |
| Turning Radius w/o Brakes: | | |
| FWD | 2.5 m (8 ft) Right turn 2.5 m (8 ft) Left turn | 2.5 m (8 ft) Right turn 2.5 m (8 ft) Left turn |
| POWER TAKE-OFF | | |
| Type | Independent | Independent |
| Shaft Size: | | |
| Rear PTO | 35 mm (1.4 in) | 35 mm (1.4 in) |
| Mid PTO | 25.4 mm (1 in) | 25.4 mm (1 in) |
| Engine Speed for 540 RPM Rear PTO Operation | 2603 RPM (2603 RPM) | 2603 RPM (2603 RPM) - HST Transmission |
| Engine Speed for 2000 RPM Mid PTO operation | 2660 RPM (2660 RPM) | 2660 RPM (2660 RPM) |
| Horsepower PTO Observed | 12.9 kW (18 Hp) | 15.1 kW (21 Hp) |
| POWER TAKE-OFF | | |
| Engine Speed for 2000 RPM Mid PTO Operation | 2660 RPM - HST | 2660 RPM - HST |

INTRODUCTION

| | Model Boomer 20 - Hydrostatic | Model Boomer 25 - Hydrostatic |
|--|---|---|
| Direction of Rotation (As viewed from rear of tractor) | | |
| Rear PTO | Clockwise | Clockwise |
| Mid PTO | Clockwise | Clockwise |
| <hr/> | | |
| HYDRAULIC LIFT SYSTEM | | |
| Type | Open Center | Open Center |
| Pump Type | Gear | Gear |
| Pump Capacity | 27.1 (7 US gal) | 27.1 (7 US gal) |
| System Relief Valve Setting | 14997 kPa (2175.1 psi) | 14997 kPa (2175.1 psi) |
| <hr/> | | |
| TRANSMISSION SPEEDS (HYDROSTATIC) | | |
| | (2700 RPM Engine Rated Speed with 33 x 12-16.5 Rear tires | (2700 RPM Engine Rated Speed with 33 x 12-16.5 Rear tires |
| Gear Position: | | |
| Low | 0 - 5.23 km/h (0 - 3.251 mph) | 0 - 5.23 km/h (0 - 3.251 mph) |
| High | 0 - 10.69 km/h (0 - 6.64 mph) | 0 - 10.69 km/h (0 - 6.64 mph) |
| | | |
| Reverse Low | 0 - 5.23 km/h (0 - 3.25 mph) | 0 - 5.23 km/h (0 - 3.25 mph) |
| Reverse High | 0 - 10.69 km/h (0 - 6.64 mph) | 0 - 10.69 km/h (0 - 6.64 mph) |
| | | |
| | | |
| CAST IRON WEIGHTS | | |
| Front End: | | |
| With weight extension bracket installed | (5) weights @ 26 kg (60 lb) each | (5) weights @ 26 kg (60 lb) each |
| With weight extension bracket installed | Optional (3) weights @ 45 kg (100 lb) each | Optional (3) weights @ 45 kg (100 lb) each |
| | | |
| Rear Wheel: | | |
| R-4 Tires | (4) weights (2) per wheel @ 34 kg (75 lb) each | (4) weights (2) per wheel @ 34 kg (75 lb) each |
| Turf Tires | NA | NA |
| Ag. Tires | (4) weights (2) per wheel @ 48 kg (106 lb) each | (4) weights (2) per wheel @ 48 kg (106 lb) each |
| | | |
| DRAWBARS | | |
| Extendible | Standard | Standard |
| <hr/> | | |
| TIRES | | |
| FRONT | | |
| Turf: | 23.5 x 8.5-12 4PR, R3 | 23.5 x 8.5-12 4PR, R3 |
| Industrial: | 23.5 x 8.5-12 4PR, R4 | 23.5 x 8.5-12 4PR, R4 |
| | | |
| REAR: | | |
| Turf | 33 x 12.00-16.5 4PR, R3 | 33 x 12.00-16.5 4PR, R3 |
| Industrial | 33 x 12.00-16.5, 4PR, R4 | 33 x 12.00-16.5, 4PR, R4 |
| | | |
| | | |

INTRODUCTION

| | Model Boomer 20 - Hydrostatic | Model Boomer 25 - Hydrostatic |
|--|--|--|
| WHEEL BOLT TORQUES | | |
| Front Wheel --- Disc-to-Hub: | | |
| FWD | 93 - 108 N·m (69 - 80 lb ft) | 93 - 108 N·m (69 - 80 lb ft) |
| Rear Wheel --- Disc-to Axle | 176 - 196 N·m (130 - 145 lb ft) | 176 - 196 N·m (130 - 145 lb ft) |
| | | |
| ROPS ATTACHING BOLT TORQUES | | |
| ROPS to Rear Axle | 85 N·m (63 lb ft) | 85 N·m (63 lb ft) |
| Seat Belt | 49 - 54 N·m (36 - 40 lb ft) | 49 - 54 N·m (36 - 40 lb ft) |

General specification - Tractor with mechanical transmission

| | Model Boomer 20 - Mechanical | Model Boomer 25 - Mechanical |
|--|---|---|
| ENGINE | | |
| Type | Diesel | Diesel |
| Model | S3L | S3L2 |
| Engine Gross Horsepower | 17 kW (23 Hp) @ 2700 RPM | 20 kW (27 Hp) @ 2700 RPM |
| Cylinders | 3 | 3 |
| Bore | 78 mm (3.07 in) | 78 mm (3.07 in) |
| Stroke | 92 mm (3.62 in) | 92 mm (3.62 in) |
| Displacement | 1.126 l (68.65 in³) | 1.318 l (80.4 in³) |
| Compression Ratio | 22.0:1 | 22.0:1 |
| Firing Order | 1-3-2 | 1-3-2 |
| Low Idle Speed | 1000 RPM | 1000 RPM |
| Maximum Speed: | 2900 RPM | 2900 RPM |
| High Idle | 2900 RPM | 2900 RPM |
| Rated | 2700 RPM | 2700 RPM |
| Valve Clearance (Cold) | | |
| Intake | 0.25 mm (0.010 in) | 0.25 mm (0.010 in) |
| Exhaust | 0.25 mm (0.010 in) | 0.25 mm (0.010 in) |
| CAPACITIES | | |
| Fuel Tank | 25.0 l (6.6 US gal) | 25.0 l (6.6 US gal) |
| Cooling System | 3.8 l (4.0 US qt) | 3.8 l (4.0 US qt) |
| Engine Crankcase: | | |
| With Filter | 4.2 l (4.4 US qt) | 4.2 l (4.4 US qt) |
| Rear Axle & Transmission (Includes Hydraulics) | 24 l (6.3 US gal) | 24 l (6.3 US gal) |
| Front Axle | 3.0 l (3.2 US qt) | 3.0 l (3.2 US qt) |
| COOLING SYSTEM | | |
| Type | Pressurized Liquid with Recirculating Bypass | Pressurized Liquid with Recirculating Bypass |
| Water Pump: | | |
| Type | Centrifugal | Centrifugal |
| Drive | V-Belt | V-Belt |
| Belt Deflection | 10 - 13 mm (0.4 - 0.5 in) when 10 kg (22 lb) pressure is applied midway between belt pulleys | 10 - 13 mm (0.4 - 0.5 in) when 10 kg (22 lb) pressure is applied midway between belt pulleys |
| Fan Diameter | 340 mm (13.4 in) | 340 mm (13.4 in) |
| Thermostat: | | |
| Start to Open | 76.5 °C (170 °F) | 76.5 °C (170 °F) |
| Fully Open | 90 °C (194 °F) | 90 °C (194 °F) |
| Radiator Cap | 90 kPa (13 psi) | 90 kPa (13 psi) |
| ELECTRICAL SYSTEM | | |
| Alternator | 12 V, Heavy Duty, 50 A | 12 V, Heavy Duty, 50 A |
| Battery | 12 V, w/ negative ground, 560 cca BCI Group 85 | 12 V, w/ negative ground, 560 cca BCI Group 85 |
| Starting Motor | Solenoid Pre-Engaged Reduction | Solenoid Pre-Engaged Reduction |
| FUEL SYSTEM | | |
| Fuel Type | Diesel | Diesel |
| Type of Fuel to Use if Above 4 °C (40 °F) | No. 2-Diesel, Cetane Rating: Minimum 40 | No. 2-Diesel, Cetane Rating: Minimum 40 |

Sample of manual. Download All 873 pages at:

<https://www.arepairmanual.com/downloads/new-holland-boomer-20-boomer-25-compact-tractor-service-repair-manual/>