

# HP Mopier 320 System Service Manual

Product: 1998 HP Mopier 320 System Printer Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/1998-hp-mopier-320-system-printer-service-repair-workshop-manual/>

Sample of manual. Download All 815 pages at:  
<https://www.arepairmanual.com/downloads/1998-hp-mopier-320-system-printer-service-repair->

# Service Manual

## **HP Mopier 320 System Service Manual**

© Copyright  
Hewlett-Packard Company 1998  
All Rights Reserved.  
Reproduction, adaptation, or  
translation without prior written  
permission is prohibited, except  
as allowed under the copyright  
laws.  
Publication number  
C4229-90911  
First edition, October 1998

#### **Trademark Credits**

Adobe and PostScript are  
trademarks of Adobe Systems  
Incorporated which may be  
registered in certain  
jurisdictions.

Windows is a U.S. registered  
trademark of Microsoft  
Corporation.

#### **Warranty**

The information contained in  
this document is subject to  
change without notice.

Hewlett-Packard makes no  
warranty of any kind with regard  
to this material, including, but  
not limited to, the implied  
warranties or merchantability  
and fitness for a particular  
purpose.

Hewlett-Packard shall not be  
liable for errors contained herein  
or for incidental or  
consequential damages in  
connection with the furnishing,  
performance, or use of this  
material.

#### **WARNING**

Electrical Shock Hazard

To avoid electrical shock, use  
only supplied power cords and  
connect only to properly  
grounded wall outlets.

# Conventions

This manual uses the following conventions:

The names of major printer parts and assemblies are Capitalized.

**Color** is used to emphasize items which are important to the material under discussion.

**Bold** is used for emphasis, particularly in situations where *italic* type would be confusing.

*Italic type* is used to indicate related documents or emphasis.

## Note

Notes contain important information set off from the text.


## CAUTION

Caution messages alert you to the possibility of damage to equipment or loss of data.

## WARNING!

Warning messages alert you to the possibility of personal injury.

The illustration below shows the orientation of the paper-handling accessories as they are referred to in this publication.



# Chapter Descriptions

## **1 Product Information**

Contains printer features and product overview, tray capacities and sizes, media specifications, how to get technical assistance, and required safety and compliance statements.

## **2 Site Requirements**

Contains space and environmental requirements.

## **3 Operating Overview**

Contains details about control panel menus, restoring factory defaults, and resetting and testing the printer.

## **4 Maintenance and Adjustments**

Contains cleaning and preventive maintenance information, and adjustment procedures for all paper trays.

## **5 Functional Overview**

Contains block diagrams and basic theory of operation for the printer systems, paper paths, and paper handling devices. Contains basic cabling information.

## **6 Removal and Replacement**

Contains step-by-step procedures for replacing field replaceable units (FRUs) in the printer and paper-handling devices.

## **7 Troubleshooting**

Contains a preliminary troubleshooting table, a table with descriptions and recommended actions for all control panel messages, image defect samples, paper handling problems, service approach, and troubleshooting checks and tools.

## **8 Parts and Diagrams**

Contains exploded view drawings and part number listings for all replaceable parts in the printer and paper-handling devices.

Contains two replaceable parts tables: one sorted alphabetically by part name, and one sorted numerically by part number. Both tables are cross referenced to the diagrams in the chapter.

## **Subject Index**

Contains an alphabetical, cross referenced listing of information found in the main body of the manual.



# Table of Contents

## List of Figures

## List of Tables

## 1 Product Information

|   |    |
|---|----|
| Features of the HP Digital Copy 320 . . . . .                     | 2  |
| Features of the Mopier . . . . .                                  | 2  |
| Features of the Copy Module . . . . .                             | 4  |
| Product Overview . . . . .  | 5  |
| External View of Mopier . . . . .                                 | 5  |
| Formatter Assemblies . . . . .                                    | 7  |
| External View of HP Digital Copy 320 . . . . .                    | 8  |
| Configurations . . . . .  | 9  |
| Paper Capacities and Sizes . . . . .                              | 11 |
| Mopier and Paper-handling Devices . . . . .                       | 11 |
| Mopier Media Selection Guidelines . . . . .                       | 13 |
| Paper . . . . .   | 13 |
| Envelopes . . . . .   | 13 |
| Adhesive Labels . . . . .   | 14 |
| Transparencies . . . . .  | 15 |
| Storing Print Media . . . . .                                     | 15 |
| Shipping Print Media . . . . .                                    | 15 |
| Copy Module Media Selection Guidelines . . . . .                  | 17 |
| Paper Specifications . . . . .                                    | 17 |
| Paper Size . . . . .  | 17 |
| Paper Conditions . . . . .  | 18 |
| Document Quality . . . . .  | 18 |
| Identification . . . . .  | 22 |
| Model and Serial Numbers . . . . .                                | 22 |
| Paper-handling Devices, Accessories, and Options . . . . .        | 23 |
| Ordering Information . . . . .                                    | 24 |
| Hard Disk . . . . .   | 30 |
| Determining Memory Requirements . . . . .                         | 30 |
| Technical Assistance . . . . .                                    | 32 |
| HP FIRST (Fax Information Retrieval Support Technology) . . . . . | 32 |
| Internet . . . . .  | 33 |
| World Wide Web . . . . .  | 33 |
| HP Reseller Sales and Service Support Line (US Only) . . . . .    | 33 |
| Other Areas . . . . .   | 33 |

|  |     |
|--|-----|
| Regulatory Information . . . . .           | .34 |
| FCC Regulations. . . . .                   | .34 |
| Environmental Product Stewardship. . . . . | .35 |
| Material Safety Data Sheet. . . . .        | .37 |
| Environmental Conformity. . . . .          | .38 |
| Declarations of Conformity . . . . .       | .39 |
| Safety Statements. . . . .                 | .42 |

## 2 Site Requirements

|  |     |
|--|-----|
| Operating Environment . . . . .            | .46 |
| Space Requirements . . . . .               | .47 |
| Environmental Requirements . . . . .       | .50 |
| Specifications . . . . .                   | .51 |
| Mopier and Paper-handling Devices. . . . . | .51 |
| Copy Module. . . . .                       | .55 |

## 3 Operating Overview

### HP Mopier 320

|   |     |
|---|-----|
| Using the Mopier Control Panel . . . . .                              | .58 |
| Control Panel Layout . . . . .  | .58 |
| Indicator Lights . . . . .  | .59 |
| Settings and Defaults . . . . .                                       | .60 |
| Printer Driver Information . . . . .                                  | .60 |
| Paper Source Default . . . . .  | .61 |
| Performing a Cold Reset. . . . .                                      | .62 |
| Setting the Display Language. . . . .                                 | .62 |
| Control Panel Menus. . . . .  | .65 |
| Quick Copy Jobs Menu. . . . .   | .66 |
| Private/Stored Jobs Menu. . . . .                                     | .66 |
| Information Menu . . . . .  | .67 |
| Paper Handling Menu . . . . .   | .68 |
| Print Quality Menu . . . . .  | .70 |
| Printing Menu . . . . .   | .72 |
| Configuration Menu. . . . .   | .75 |
| I/O Menu . . . . .  | .80 |
| EIO Menu . . . . .  | .82 |
| Resets Menu. . . . .  | .84 |
| Mopier Service Mode . . . . .   | .85 |
| Setting Page Count, Maintenance Count,<br>and Serial Number . . . . . | .87 |
| Setting the Cold Reset Default Paper Size. . . . .                    | .88 |
| Testing the Mopier. . . . .   | .89 |
| Paper Path Test . . . . .   | .89 |
| Configuration Page . . . . .  | .89 |

## **HP Digital Copy 320**

|   |     |
|---|-----|
| Using the HP Digital Copy 320 Front Panel . . . . . | 90  |
| HP Digital Copy 320 Front Panel . . . . .           | 91  |
| HP Digital Copy 320 Settings . . . . .              | 100 |
| Loading documents into the ADF . . . . .            | 102 |
| Loading documents onto the Flatbed . . . . .        | 104 |
| Copy Module Service Mode . . . . .                  | 105 |
| HP Resource Manager . . . . .                       | 107 |
| Accessing the HP Resource Manager . . . . .         | 107 |
| Downloading Copy Module Firmware . . . . .          | 108 |

## **4 Maintenance and Adjustments**

### **HP Mopier 320**

|  |     |
|--|-----|
| Cleaning the Mopier and Accessories . . . . .        | 112 |
| Cleaning the Mopier . . . . .                        | 113 |
| Cleaning Spilled Toner . . . . .                     | 114 |
| Preventive Maintenance . . . . .                     | 115 |
| Tray Adjustment Procedure . . . . .                  | 116 |
| 2000-sheet Input Tray Adjustment Procedure . . . . . | 118 |

### **HP Digital Copy 320**

|  |     |
|--|-----|
| Cleaning the HP Digital Copy 320 . . . . .                                   | 120 |
| Materials . . . . .  | 120 |
| Vacuum Specifications . . . . .  | 120 |
| Cleaning ADF and Glass . . . . .   | 121 |
| Cleaning the Document Cover, Document Holder, and Flatbed<br>Glass . . . . . | 121 |
| Cleaning the ADF . . . . .   | 122 |
| Complete Optics Cleaning . . . . .   | 124 |
| Cleaning the ADF Lamp and Mirrors . . . . .                                  | 124 |
| Lubricating the ADF Gears . . . . .  | 124 |
| Cleaning the Carrier Unit and Mechanical Assemblies . . . . .                | 125 |
| Lubricating the Carrier Unit Shaft . . . . .                                 | 125 |
| Lubricating the Top of the Carrier Guide Rail . . . . .                      | 125 |
| Lubricating the Flatbed Motor Gears . . . . .                                | 125 |
| Cleaning the Front Panel . . . . .   | 125 |
| Maintaining the HP Digital Copy 320 . . . . .                                | 126 |
| HP Digital Copy 320 Maintenance Parts . . . . .                              | 126 |
| Calibrating the HP Digital Copy 320 . . . . .                                | 126 |
| Types of Calibration . . . . .   | 126 |
| When to Calibrate . . . . .  | 127 |
| Calibration Target . . . . .   | 127 |
| Entering the Calibration Menu in Service Mode . . . . .                      | 127 |
| How to Perform an Offset Adjustment Calibration . . . . .                    | 128 |
| How to Perform a Density Calibration Adjustment . . . . .                    | 128 |
| How to Perform an ADF Vertical Magnification Adjustment . . . . .            | 128 |

## 5 Functional Overview

### HP Mopier 320

|   |     |
|---|-----|
| Printer Functional Block Diagram . . . . .                            | 130 |
| Power Distribution System . . . . .                                   | 131 |
| AC Power Distribution . . . . .                                       | 132 |
| Overcurrent/Overvoltage Protection . . . . .                          | 132 |
| High Voltage Power Distribution . . . . .                             | 133 |
| Formatter System . . . . .  | 134 |
| DC Controller System . . . . .  | 137 |
| Laser and Scanner Drive . . . . .                                     | 137 |
| Paper Motion Monitoring and Control . . . . .                         | 137 |
| Clutches . . . . .  | 137 |
| Engine Test Microswitch . . . . .                                     | 138 |
| Motors . . . . .  | 138 |
| Image Formation System . . . . .                                      | 139 |
| Toner Cartridge . . . . .   | 140 |
| Drum Cleaning . . . . .   | 142 |
| Drum Conditioning . . . . .   | 143 |
| Image Writing . . . . .   | 144 |
| Image Developing . . . . .  | 146 |
| Image Transferring and Media Separation . . . . .                     | 148 |
| Image Fusing . . . . .  | 149 |
| Paper Paths and Components . . . . .                                  | 150 |
| Printer, Duplexer, and Envelope Feeder . . . . .                      | 150 |
| Paper Size Switches (Trays 2 and 3) . . . . .                         | 153 |
| Printing from Tray 1 . . . . .  | 153 |
| Printing from Trays 2 and 3 . . . . .                                 | 153 |
| Printing from the Envelope Feeder . . . . .                           | 154 |
| Printing with the Duplexer . . . . .                                  | 154 |
| 2000-sheet Input Tray (Tray 4) Components . . . . .                   | 155 |
| 2000-Sheet Input Tray Operation . . . . .                             | 157 |
| 2 x 500-sheet Input Tray . . . . .                                    | 160 |
| 2 x 500-sheet Input Tray Operation . . . . .                          | 162 |
| 7-bin Tabletop Mailbox Components . . . . .                           | 164 |
| 7-bin Tabletop Mailbox Operation . . . . .                            | 166 |
| 8-bin Mailbox Components . . . . .                                    | 170 |
| 8-bin Mailbox Operation . . . . .                                     | 173 |
| Finisher Components . . . . .   | 175 |
| Stapler Unit Operation . . . . .                                      | 177 |
| Main Functional Cycles of the Stapler (Internal Paper Path) . . . . . | 179 |
| Communication Link (Daisy Chain) . . . . .                            | 180 |
| Paper Jam Detection . . . . .   | 182 |
| Printer Timing . . . . .  | 182 |
| IEEE 1284 Parallel Cable Information . . . . .                        | 184 |

## HP Digital Copy 320

|  |     |
|--|-----|
| Copy Module Functional Overview . . . . .          | 185 |
| Copy Module System . . . . .                       | 185 |
| Function and Layout of the Copy Processor. . . . . | 187 |
| Power Up Process. . . . .                          | 189 |
| Copy Processor Board . . . . .                     | 189 |
| Copy Module. . . . .                               | 191 |
| Mopier. . . . .                                    | 192 |
| Notes About the HP Mopier 320 Product ID. . . . .  | 192 |
| ADF Simplex Operation. . . . .                     | 193 |
| ADF Duplex Operation . . . . .                     | 194 |
| Flatbed Operation . . . . .                        | 194 |
| Image Path . . . . .                               | 196 |
| Communication to the Mopier . . . . .              | 198 |
| Communication Channels. . . . .                    | 198 |
| Print Job Interrupt . . . . .                      | 198 |
| Paper Path and Sensors. . . . .                    | 199 |

## 6 Removal and Replacement

|   |     |
|---|-----|
| Removal and Replacement Strategy. . . . .           | 202 |
| Electrostatic Discharge (ESD) Precautions . . . . . | 202 |
| Required Tools . . . . .                            | 203 |
| User Installable Accessories . . . . .              | 204 |
| Memory and Personality Upgrade . . . . .            | 204 |
| Duplexer . . . . .                                  | 206 |
| Envelope Feeder. . . . .                            | 206 |
| 2000-sheet or 2 x 500-sheet Input Tray . . . . .    | 207 |
| 8-bin Mailbox/5-bin Mailbox with Stapler . . . . .  | 208 |
| 7-bin Tabletop Mailbox . . . . .                    | 209 |
| Hardware Table. . . . .                             | 212 |

### HP Mopier 320

|  |     |
|--|-----|
| Engine Removal and Replacement. . . . .              | 214 |
| Control Panel . . . . .                              | 215 |
| Covers. . . . .                                      | 217 |
| Delivery Unit (for Face-down Bin). . . . .           | 226 |
| Diverter Assembly. . . . .                           | 229 |
| Diverter Door Assembly . . . . .                     | 230 |
| Lower Right Door Assembly . . . . .                  | 231 |
| Fan 1, Laser/Scanner and Housing (Exhaust) . . . . . | 234 |
| Fan 2, Low Voltage Power Supply (Exhaust) . . . . .  | 236 |
| Fan 3, Formatter Fan and Housing (Intake) . . . . .  | 237 |
| Fan 4, Delivery Unit (Exhaust) . . . . .             | 238 |
| Fan 5, Tray 1 (Intake). . . . .                      | 239 |
| Tray 1 . . . . .                                     | 241 |
| Tray 1 Pickup Assembly . . . . .                     | 244 |

|   |      |
|---|------|
| Engine Removal and Replacement (continued)                  |      |
| Feeder Assembly . . . . .                                   | .248 |
| Formatter Assembly . . . . .                                | .250 |
| Fusing Assembly. . . . .                                    | .252 |
| Laser/Scanner Assembly . . . . .                            | .254 |
| Main Gear Assembly. . . . .                                 | .256 |
| Main Motor Assembly . . . . .                               | .259 |
| Paper Input Unit (PIU). . . . .                             | .260 |
| PCA, DC Controller. . . . .                                 | .261 |
| Output Paper Sensor PCA . . . . .                           | .262 |
| High Voltage Power Supply (HVPS). . . . .                   | .269 |
| Low Voltage Power Supply (LVPS) . . . . .                   | .270 |
| Registration Assembly . . . . .                             | .271 |
| Tray 1 Feed Roller and Separation Pad . . . . .             | .274 |
| Tray 2 and 3 Pickup, Feed, and Separation Rollers . . . . . | .276 |
| Paper Input Unit Sensor (PS2) . . . . .                     | .277 |
| Registration Sensor (PS1) . . . . .                         | .279 |
| Face-up Solenoid Assembly (SL3) . . . . .                   | .281 |
| Transfer Roller Assembly . . . . .                          | .282 |
| Tray 2 and 3 Assemblies . . . . .                           | .284 |

**Paper-handling Devices**

|  |      |
|--|------|
| 2000-sheet Input Tray Removal and Replacement. . . . . | .285 |
| Orientation . . . . .                                  | .286 |
| Front Cover . . . . .                                  | .287 |
| Back Cover . . . . .                                   | .288 |
| Left Cover . . . . .                                   | .289 |
| Right Cover . . . . .                                  | .290 |
| Main Drive Assembly . . . . .                          | .291 |
| Paper Tray . . . . .                                   | .293 |
| Main Cable Harness . . . . .                           | .294 |
| Controller PCA . . . . .                               | .296 |
| Front LED PCA Assembly. . . . .                        | .298 |
| Pickup Assembly. . . . .                               | .300 |
| Power Supply . . . . .                                 | .302 |
| Pickup, Feed, and Separation Rollers . . . . .         | .304 |
| Paper Quantity Switch Assembly . . . . .               | .306 |
| Paper Size Switch Assembly . . . . .                   | .306 |
| Vertical Transfer Unit (VTU) . . . . .                 | .308 |
| Tension Springs . . . . .                              | .310 |
| Locating Pins . . . . .                                | .311 |
| Casters and Stabilizing Feet. . . . .                  | .312 |
| Adjustable Foot. . . . .                               | .313 |

|   |     |
|---|-----|
| 2 x 500-sheet Input Tray Removal and Replacement . . . . .    | 314 |
| Orientation of the 2 x 500-sheet Input Tray . . . . .         | 315 |
| Back Cover . . . . .  | 316 |
| Left Cover . . . . .  | 317 |
| Vertical Transfer Unit (VTU) . . . . .                        | 318 |
| Right Cover . . . . .   | 321 |
| Front Top Cover . . . . .                                     | 324 |
| Trays 4 and 5 . . . . .                                       | 327 |
| Pickup Assembly . . . . .                                     | 329 |
| Paper Deck Drive Assembly . . . . .                           | 331 |
| Pickup, Feed, and Separation Rollers . . . . .                | 333 |
| Controller PCA . . . . .                                      | 334 |
| Tray-Size Sensing PCA . . . . .                               | 335 |
| Power Supply . . . . .  | 337 |
| Main Cable . . . . .  | 338 |
| Storage Paper Tray . . . . .                                  | 340 |
| Front Door (Storage Area) . . . . .                           | 341 |
| Casters . . . . .   | 342 |
| Foot Tip and Adjustable Foot Tip (Stabilizing Feet) . . . . . | 343 |
| 2 x 500-sheet Input Tray Removal and Replacement              |     |
| Locating Pins . . . . .                                       | 344 |
| Front LED PCA . . . . .                                       | 345 |
| 7-bin Tabletop Mailbox Removal and Replacement . . . . .      | 347 |
| Orientation of the 7-bin Tabletop Mailbox . . . . .           | 348 |
| Front Cover . . . . .   | 349 |
| Back Cover . . . . .  | 352 |
| Top Cover . . . . .   | 354 |
| Controller PCA . . . . .                                      | 358 |
| Power Supply . . . . .  | 359 |
| Right Door Assembly (Paper Path Cover) . . . . .              | 360 |
| Face-down Bins . . . . .                                      | 364 |
| Empty Bin Sensor PCA . . . . .                                | 367 |
| Full Bin and Interlock Sensor PCA . . . . .                   | 369 |
| LED PCA . . . . .   | 371 |
| Face-up Sensors PCA . . . . .                                 | 372 |
| Reversing Mechanism Motor . . . . .                           | 373 |
| Face-up/Diverter Assembly (Flipper) . . . . .                 | 375 |
| Short Tray 7 . . . . .  | 378 |
| Solenoid Reversing Mechanism . . . . .                        | 379 |
| Flipper Solenoid . . . . .                                    | 380 |
| Handle . . . . .  | 381 |
| Latching Mechanism . . . . .                                  | 382 |
| Cover Latch . . . . .   | 383 |

|  |     |
|--|-----|
| 8-bin Mailbox Removal and Replacement . . . . .  | 384 |
| Orientation . . . . .  | 385 |
| Front and Back Covers . . . . .  | 386 |
| Top Cover . . . . .  | 387 |
| Power Supply . . . . .   | 388 |
| Paper Bins and Blind Cover . . . . .   | 389 |
| Flipper Assembly . . . . .   | 390 |
| Delivery Head Motor . . . . .  | 393 |
| Transport Belt Motor . . . . .   | 394 |
| Input Paper Guide . . . . .  | 396 |
| Metal Tape and Housing Assembly . . . . .  | 398 |
| Controller PCA . . . . .   | 400 |
| Anticurl Strings . . . . .   | 402 |
| Delivery Head Assembly . . . . .   | 404 |
| Interlock Switch . . . . .   | 409 |
| Diagnostic LED PCA . . . . .   | 410 |
| User Status LED PCA . . . . .  | 412 |
| Adjustable and Fixed Casters . . . . .   | 414 |
| Attachment Assembly . . . . .  | 415 |
| Stapler Assembly Removal and Replacement . . . . .                                     | 416 |
| Mailbox with Stapler, Stapler Removal or Installation . . . . .                        | 417 |
| Back Plate . . . . .   | 419 |
| Stapler Controller PCA . . . . .   | 421 |
| Top Cover Assembly . . . . .   | 424 |
| Stapler Bed Assembly . . . . .   | 425 |
| Hinges . . . . .   | 427 |
| <br>   |     |
| <b>HP Digital Copy 320</b>   |     |
| HP Digital Copy 320 Removal and Replacement . . . . .                                  | 429 |
| Installing the HP Digital Copy 320 . . . . .   | 430 |
| Install the HP Digital Copy 320 on the Optional HP Digital Copy<br>320 Stand . . . . . | 430 |
| Install the Mopier on the Optional Input Accessory . . . . .                           | 432 |
| Roll the Mopier onto the Optional HP Digital Copy 320 Stand                            | 432 |
| Install the Optional Output Accessory . . . . .  | 433 |
| Install the Copy Connect EIO Board into the Mopier . . . . .                           | 434 |
| Install the Copy Connect Cable . . . . .   | 435 |
| Install the Y Power Cord . . . . .   | 436 |
| Hardware Table . . . . .   | 437 |
| Orientation of the HP Digital Copy 320 . . . . .                                       | 439 |
| Copy Module Maintenance Parts . . . . .  | 440 |
| Separation Pad Assembly . . . . .  | 440 |
| Pick Roller Assembly . . . . .   | 441 |

|  |      |
|--|------|
| Copy Module Skins . . . . .                              | .445 |
| Document Holding Pad . . . . .                           | .445 |
| Paper Chute Flip-out . . . . .                           | .446 |
| Output Tray Flip-out . . . . .                           | .447 |
| Output Tray . . . . .                                    | .447 |
| Flatbed (FB) Cover Assembly . . . . .                    | .448 |
| ADF Latch Cap . . . . .                                  | .451 |
| ADF Cover . . . . .                                      | .452 |
| Front Panel . . . . .                                    | .454 |
| Panel Cover . . . . .                                    | .459 |
| Front Panel Brackets . . . . .                           | .460 |
| Upper Cover . . . . .                                    | .462 |
| Copy Module Power Supply/Main Board Assemblies . . . . . | .464 |
| Copy Processor Board . . . . .                           | .464 |
| Power Supply and Main Board Tray . . . . .               | .465 |
| RFI Cover . . . . .                                      | .467 |
| Control PCA . . . . .                                    | .469 |
| Fan . . . . .  | .472 |
| Power Supply . . . . .                                   | .473 |
| Back PCA . . . . .                                       | .474 |
| Copy Module ADF Unit Assemblies . . . . .                | .475 |
| Optical Unit . . . . .                                   | .475 |
| ADF Lamp PCA . . . . .                                   | .477 |
| ADF Lamp . . . . .                                       | .479 |
| Sensor Unit Assembly . . . . .                           | .480 |
| ADF Motor Unit . . . . .                                 | .483 |
| ADF Belt . . . . .                                       | .484 |
| LED Assembly PCA . . . . .                               | .486 |
| ADF Unit . . . . .                                       | .487 |
| Copy Module Flatbed Assemblies . . . . .                 | .488 |
| Front Panel Frame Ground Spring . . . . .                | .488 |
| Output Tray Brackets . . . . .                           | .489 |
| Glass Plate Assembly . . . . .                           | .490 |
| Home Position Sensor . . . . .                           | .492 |
| Carrier Unit Lamp . . . . .                              | .494 |
| Carrier Unit . . . . .                                   | .497 |
| Felt Pad . . . . .                                       | .501 |
| Feet . . . . .   | .502 |
| Frame Ground Spring . . . . .                            | .503 |
| Front Lamp PCA . . . . .                                 | .504 |
| Junction PCA and Cover . . . . .                         | .505 |
| Front Panel Ribbon Cable . . . . .                       | .507 |
| Carrier Belt and Motor . . . . .                         | .509 |

## 7 Troubleshooting

|   |     |
|---|-----|
| Service Approach . . . . .  | 512 |
| Ordering Parts . . . . .  | 512 |
| Exchange Program . . . . .  | 513 |
| Consumables . . . . .   | 513 |
| Toner Cartridge Life . . . . .                                      | 513 |
| Refilled Toner Cartridges and Non-HP Staple Cartridges . . . . .    | 514 |
| Recycling Toner Cartridges . . . . .                                | 514 |
| Troubleshooting Process . . . . .                                   | 515 |
| Mopier System Troubleshooting Process . . . . .                     | 517 |
| Mopier/Paper-Handling Troubleshooting Process . . . . .             | 518 |
| Copy Module Troubleshooting Process . . . . .                       | 520 |
| <br>  |     |
| <b>HP Mopier 320</b>  |     |
| Troubleshooting the Mopier System . . . . .                         | 522 |
| Preliminary Operating Checks . . . . .                              | 522 |
| Communication . . . . .   | 523 |
| Interface Troubleshooting . . . . .                                 | 523 |
| Network Troubleshooting . . . . .                                   | 525 |
| Verify Host System Operation . . . . .                              | 527 |
| Verify Network and Server Operation . . . . .                       | 527 |
| General Troubleshooting Information . . . . .                       | 528 |
| Miscellaneous Problems and Solutions . . . . .                      | 528 |
| Paper Curl . . . . .  | 533 |
| Troubleshooting the Mopier and Paper-handling Devices . . . . .     | 534 |
| <b>Step 1</b> Power On . . . . .                                    | 534 |
| Engine Test . . . . .   | 537 |
| <b>Step 2</b> Display . . . . .                                     | 538 |
| Event Log . . . . .   | 538 |
| <b>Step 3</b> Printer and Paper-Handling Devices Messages . . . . . | 542 |
| Printer Message Tables . . . . .                                    | 544 |
| Engine Error Messages . . . . .                                     | 545 |
| Input Device Messages . . . . .                                     | 557 |
| Output Device Messages . . . . .                                    | 565 |
| Finisher Devices Messages . . . . .                                 | 576 |
| Paper Handling Controller Error Messages . . . . .                  | 580 |
| <b>Step 4</b> Paper Path Troubleshooting . . . . .                  | 581 |
| Paper Jams . . . . .  | 582 |
| Paper Path Test . . . . .   | 584 |
| <b>Step 5</b> Information Pages . . . . .                           | 587 |
| Menu Map . . . . .  | 587 |
| Configuration Pages . . . . .                                       | 589 |
| File Directory Page . . . . .                                       | 592 |
| Usage Page . . . . .  | 593 |
| <b>Step 6</b> Image Quality . . . . .                               | 597 |
| Check the Toner Cartridge . . . . .                                 | 598 |

|   |      |
|---|------|
| Troubleshooting the Mopier and Paper-handling Devices (continued) |      |
| Image Quality Tables . . . . .                                    | .599 |
| Repetitive Defect Ruler . . . . .                                 | .612 |
| Image System Troubleshooting . . . . .                            | .614 |
| High-Voltage Power Supply Check . . . . .                         | .615 |
| Self-Diagnostics on Paper-handling Devices . . . . .              | .617 |
| 2000-sheet Input Tray Stand-alone Diagnostics . . . . .           | .617 |
| 2 x 500-sheet Input Tray Standalone Diagnostics . . . . .         | .621 |
| 7-bin Tabletop Mailbox Standalone Diagnostics . . . . .           | .625 |
| 8-bin Mailbox Stand-alone Diagnostics . . . . .                   | .630 |
| Diagrams . . . . .  | .638 |

### **HP Digital Copy 320**

|   |      |
|---|------|
| Troubleshooting the HP Digital Copy 320 . . . . .   | .651 |
| <b>Step 1</b> Power On . . . . .                    | .652 |
| <b>Step 2</b> Display and Communication . . . . .   | .653 |
| <b>Step 3</b> Error Messages and Problems . . . . . | .654 |
| Status Messages . . . . .                           | .654 |
| <b>Step 4</b> Information Pages . . . . .           | .659 |
| <b>Step 5</b> Paper Path . . . . .                  | .660 |
| <b>Step 6</b> Image Quality . . . . .               | .661 |
| Testing the HP Digital Copy 320 . . . . .           | .664 |
| Copy Processor LED Test . . . . .                   | .664 |
| Copy Module Boot Up Icon Conditions . . . . .       | .666 |
| Copy Module Offline Test . . . . .                  | .667 |
| Other Tests . . . . .                               | .669 |
| Service Mode Tests . . . . .                        | .671 |

## **8 Parts and Diagrams**

|  |      |
|--|------|
| How to Use the Part Lists and Diagrams . . . . . | .674 |
| Ordering Parts . . . . .                         | .674 |
| Common Hardware . . . . .                        | .674 |
| Illustrations and Parts Lists . . . . .          | .675 |

### **HP Mopier 320**

|   |      |
|---|------|
| Mopier and Paper-handling Components . . . . .                        | .676 |
| Printer Parts and Diagrams . . . . .                                  | .680 |
| Paper-Handling Devices Parts and Diagrams . . . . .                   | .694 |
| Input Devices . . . . .   | .694 |
| Output Devices . . . . .  | .702 |
| Alphabetical Parts List (Mopier and Paper Handling Devices) . . . . . | .714 |
| Numerical Parts List (Mopier and Paper Handling Devices) . . . . .    | .724 |

**HP Digital Copy 320**

HP Digital Copy 320 Parts and Diagrams . . . . .735  
Alphabetical Parts List (Copy Module) . . . . .750  
Numerical Parts List (Copy Module) . . . . .754

**Index**

# List of Figures

|             |  |     |
|-------------|--|-----|
| Figure 1-1  | Copy System - - - - -  | 2   |
| Figure 1-2  | Mopier - Front and Right Side View with Tray 1 Open - - - - -                | 5   |
| Figure 1-3  | Rear and Left Side View - - - - -  | 7   |
| Figure 1-4  | Front view of HP Digital Copy 320- - - - -                                   | 8   |
| Figure 1-5  | Rear view of HP Digital Copy 320 - - - - -                                   | 8   |
| Figure 1-6  | Preferred Configuration - - - - -  | 9   |
| Figure 1-7  | Tabletop Configuration - - - - -   | 10  |
| Figure 1-8  | Paper size specification - - - - -   | 17  |
| Figure 1-9  | Paper orientation - - - - -  | 20  |
| Figure 1-10 | Areas of the Paper that Should Not Be Perforated - - - - -                   | 21  |
| Figure 1-11 | Sample Model and Serial Number Label for the Mopier - - - - -                | 22  |
| Figure 1-12 | Paper Handling Devices - - - - -   | 23  |
| Figure 2-1  | Mopier Space Requirements (Top view) - - - - -                               | 47  |
| Figure 2-2  | Mopier Space Requirements (Side view) - - - - -                              | 47  |
| Figure 2-3  | Mopier Space Requirements (with Mailbox and Input Device) - - - - -          | 48  |
| Figure 2-4  | Mopier and Copy Module Space requirements- - - - -                           | 49  |
| Figure 2-5  | Dimensions of Paper Handling Devices - - - - -                               | 53  |
| Figure 3-1  | Control Panel Layout - - - - -   | 58  |
| Figure 3-2  | Front Panel Layout - - - - -   | 91  |
| Figure 3-3  | Button/LED Functions- - - - -  | 98  |
| Figure 3-4  | Copy Module Service Mode - - - - -   | 105 |
| Figure 3-5  | HP Resource Manager (1 of 2) - - - - -                                       | 108 |
| Figure 3-6  | HP Resource Manager (2 of 2) - - - - -                                       | 109 |
| Figure 4-1  | Image Area Margins - - - - -   | 116 |
| Figure 4-2  | Tray Position Adjustment - - - - -   | 117 |
| Figure 4-3  | Tray 4 Position Adjustment - - - - -   | 118 |
| Figure 4-4  | Cleaning the Document Cover, Document Holder,<br>and Flatbed Glass - - - - - | 121 |
| Figure 4-5  | Parts of the ADF - - - - -   | 122 |
| Figure 4-6  | Creating an Offset Target - - - - -  | 127 |
| Figure 5-1  | Printer Functional Block Diagram - - - - -                                   | 130 |
| Figure 5-2  | Low Voltage Power Distribution System - - - - -                              | 131 |
| Figure 5-3  | Low Voltage Power Supply - - - - -   | 132 |
| Figure 5-4  | High Voltage Power Supply Contacts - - - - -                                 | 133 |
| Figure 5-5  | Normal Mode vs EconoMode - - - - -   | 136 |
| Figure 5-6  | Image Formation Block Diagram - - - - -                                      | 139 |
| Figure 5-7  | Photosensitive Drum - - - - -  | 141 |
| Figure 5-8  | Drum Cleaning - - - - -  | 142 |
| Figure 5-9  | Primary Charging Roller- - - - -   | 143 |
| Figure 5-10 | Image Writing- - - - -   | 144 |
| Figure 5-11 | Image Development - - - - -  | 147 |

|             |  |     |
|-------------|--|-----|
| Figure 5-12 | Image Transferring and Media Separation - - - - -                | 148 |
| Figure 5-13 | Image Fusing - - - - -   | 149 |
| Figure 5-14 | Printer Paper Paths - - - - -                                    | 150 |
| Figure 5-15 | Printer Sensors, Solenoids, Clutches, Motors, and Fans - - - - - | 152 |
| Figure 5-16 | 2000-sheet Input Tray Paper Path- - - - -                        | 155 |
| Figure 5-17 | 2000-sheet Input Tray Sensors, Switches, Clutches, and Motors -  | 157 |
| Figure 5-18 | 2 x 500-sheet Input Tray Paper Path - - - - -                    | 160 |
| Figure 5-19 | 2 x 500-sheet input Tray Sensors and Switches - - - - -          | 161 |
| Figure 5-20 | 7-bin Tabletop Mailbox Components (1 of 2)- - - - -              | 164 |
| Figure 5-21 | 7-bin Tabletop Mailbox Components (2 of 2)- - - - -              | 165 |
| Figure 5-22 | 7-bin Tabletop Mailbox Block Diagram- - - - -                    | 169 |
| Figure 5-23 | 8-bin Mailbox Paper Path - - - - -                               | 170 |
| Figure 5-24 | 8-bin Mailbox Sensors, Switches, Motors, and Controller PCA - -  | 172 |
| Figure 5-25 | Finisher Paper Path- - - - -                                     | 176 |
| Figure 5-26 | Stapler Motors, Sensors, and Switches - - - - -                  | 176 |
| Figure 5-27 | Stapler Cycles - - - - -   | 179 |
| Figure 5-28 | Recommended C-link Configuration (Daisy Chain)- - - - -          | 181 |
| Figure 5-29 | General Timing Diagram - - - - -                                 | 183 |
| Figure 5-30 | Copy Module System Block Diagram - - - - -                       | 185 |
| Figure 5-31 | Copy Processor and key components - - - - -                      | 187 |
| Figure 5-32 | Image path (1 of 2) - - - - -                                    | 196 |
| Figure 5-33 | Locations of ADF Sensors - - - - -                               | 199 |
| Figure 5-34 | ADF Sensors functional diagram - - - - -                         | 200 |
| Figure 6-1  | Phillips vs. Posidriv Screwdrivers - - - - -                     | 203 |
| Figure 6-2  | Disk Drive - - - - -   | 205 |
| Figure 6-3  | Control Panel (1 of 2) - - - - -                                 | 215 |
| Figure 6-4  | Control Panel (2 of 2) - - - - -                                 | 216 |
| Figure 6-5  | AC Access Cover - - - - -  | 218 |
| Figure 6-6  | Back Cover - - - - -   | 219 |
| Figure 6-7  | Front Cover (1 of 2) - - - - -                                   | 220 |
| Figure 6-8  | Front Cover (2 of 2) - - - - -                                   | 221 |
| Figure 6-9  | Left Lower Cover - - - - -                                       | 222 |
| Figure 6-10 | Top Cover (1 of 2) - - - - -                                     | 223 |
| Figure 6-11 | Top Cover (2 of 2) - - - - -                                     | 224 |
| Figure 6-12 | Delivery Unit (1 of 2) - - - - -                                 | 226 |
| Figure 6-13 | Delivery Unit (2 of 2) - - - - -                                 | 227 |
| Figure 6-14 | Diverter Assembly - - - - -                                      | 229 |
| Figure 6-15 | Diverter Door Assembly - - - - -                                 | 230 |
| Figure 6-16 | Lower Right Door Assembly (1 of 3) - - - - -                     | 231 |
| Figure 6-17 | Right Lower Door Assembly (2 of 3) - - - - -                     | 232 |
| Figure 6-18 | Right Lower Door Assembly (3 of 3) - - - - -                     | 233 |
| Figure 6-19 | Fan 1, Laser/Scanner (1 of 2) - - - - -                          | 234 |
| Figure 6-20 | Fan 1, Laser/Scanner (2 of 2) - - - - -                          | 235 |
| Figure 6-21 | Fan 2, Low Voltage Power Supply- - - - -                         | 236 |
| Figure 6-22 | Fan 3, Formatter Fan - - - - -                                   | 237 |
| Figure 6-23 | Fan 4, Delivery Unit- - - - -                                    | 238 |
| Figure 6-24 | Fan 5 Removal (1 of 2) - - - - -                                 | 239 |

|             |  |     |
|-------------|--|-----|
| Figure 6-25 | Fan 5 Removal (2 of 2) - - - - -                             | 240 |
| Figure 6-26 | Tray 1 Removal (1 of 3) - - - - -                            | 241 |
| Figure 6-27 | Tray 1 Removal (2 of 3) - - - - -                            | 242 |
| Figure 6-28 | Tray 1 Removal (3 of 3) - - - - -                            | 243 |
| Figure 6-29 | Tray 1 Pickup Unit Removal (1 of 4) - - - - -                | 244 |
| Figure 6-30 | Tray 1 Pickup Unit Removal (2 of 4) - - - - -                | 245 |
| Figure 6-31 | Tray 1 Pickup Unit Removal (3 of 4) - - - - -                | 246 |
| Figure 6-32 | Tray 1 Pickup Unit Removal (4 of 4) - - - - -                | 247 |
| Figure 6-33 | Feeder Assembly (1 of 2) - - - - -                           | 248 |
| Figure 6-34 | Feeder Assembly (2 of 2) - - - - -                           | 249 |
| Figure 6-35 | Formatter Assembly - - - - -                                 | 251 |
| Figure 6-36 | Fusing Assembly - - - - -                                    | 252 |
| Figure 6-37 | Laser/Scanner Assembly - - - - -                             | 254 |
| Figure 6-38 | Main Gear Assembly (1 of 3) - - - - -                        | 256 |
| Figure 6-39 | Main Gear Assembly (2 of 3) - - - - -                        | 257 |
| Figure 6-40 | Main Gear Assembly (3 of 3) - - - - -                        | 258 |
| Figure 6-41 | Main Motor - - - - -   | 259 |
| Figure 6-42 | Paper Input Unit - - - - -                                   | 260 |
| Figure 6-43 | DC Controller PCA - - - - -                                  | 261 |
| Figure 6-44 | Output Paper Sensor PCA (1 of 4) - - - - -                   | 262 |
| Figure 6-45 | Output Paper Sensor PCA (2 of 4) - - - - -                   | 263 |
| Figure 6-46 | Output Paper Sensor PCA (3 of 4) - - - - -                   | 264 |
| Figure 6-47 | Output Paper Sensor PCA (4 of 4) - - - - -                   | 265 |
| Figure 6-48 | Paper Size PCA (1 of 3) - - - - -                            | 266 |
| Figure 6-49 | Paper Size PCA (2 of 3) - - - - -                            | 267 |
| Figure 6-50 | Paper Size PCA (3 of 3) - - - - -                            | 268 |
| Figure 6-51 | High Voltage Power Supply - - - - -                          | 269 |
| Figure 6-52 | Low Voltage Power Supply - - - - -                           | 270 |
| Figure 6-53 | Registration Assembly (1 of 3) - - - - -                     | 271 |
| Figure 6-54 | Registration Assembly (2 of 3) - - - - -                     | 272 |
| Figure 6-55 | Registration Assembly (3 of 3) - - - - -                     | 273 |
| Figure 6-56 | Tray 1 Feed Roller - - - - -                                 | 274 |
| Figure 6-57 | Tray 1 Separation Pad - - - - -                              | 275 |
| Figure 6-58 | Tray 2 and 3, Pickup, Feed, and Separation Rollers - - - - - | 276 |
| Figure 6-59 | Paper Input Unit Sensor (PS2) - - - - -                      | 278 |
| Figure 6-60 | Registration Sensor (PS1) - - - - -                          | 280 |
| Figure 6-61 | Face-up Solenoid Assembly, SL3 - - - - -                     | 281 |
| Figure 6-62 | Transfer Roller Assembly - - - - -                           | 282 |
| Figure 6-63 | 2000-sheet Input Tray Orientation - - - - -                  | 286 |
| Figure 6-64 | 2000-sheet Input Tray Front Cover - - - - -                  | 287 |
| Figure 6-65 | 2000-sheet Input Tray Back Cover - - - - -                   | 288 |
| Figure 6-66 | 2000-sheet Input Tray Left Cover - - - - -                   | 289 |
| Figure 6-67 | 2000-sheet Input Tray Right Cover - - - - -                  | 290 |
| Figure 6-68 | 2000-sheet Input Tray Main Drive Assembly - - - - -          | 291 |
| Figure 6-69 | 2000-sheet Input Tray Paper Tray - - - - -                   | 293 |
| Figure 6-70 | 2000-sheet Input Tray Main Cable Harness - - - - -           | 295 |
| Figure 6-71 | 2000-sheet Input Tray Controller PCA - - - - -               | 296 |

|              |  |           |     |
|--------------|--|-----------|-----|
| Figure 6-72  | 2000-sheet Input Tray Front LED PCA  | - - - - - | 299 |
| Figure 6-73  | 2000-sheet Input Tray Pickup Assembly  | - - - - - | 300 |
| Figure 6-74  | 2000-sheet Input Tray Power Supply   | - - - - - | 302 |
| Figure 6-75  | 2000-sheet Input Tray Rollers: Pickup, Feed, and Separation                    | - - - - - | 304 |
| Figure 6-76  | 2000-sheet Input Tray Paper Size and Paper Quantity Switch                     | - - - - - | 307 |
| Figure 6-77  | 2000-sheet Input Tray Paper Size and Paper Quantity Switch Assemblies (2 of 2) | - - - - - | 307 |
| Figure 6-78  | 2000-sheet Input Tray Vertical Transfer Unit (VTU)                             | - - - - - | 308 |
| Figure 6-79  | 2000-sheet Input Tray Tension Springs  | - - - - - | 310 |
| Figure 6-80  | 2000-sheet Input Tray Locating Pins  | - - - - - | 311 |
| Figure 6-81  | 2000-sheet Input Tray Casters  | - - - - - | 312 |
| Figure 6-82  | 2000-sheet Input Tray Adjustable Foot  | - - - - - | 313 |
| Figure 6-83  | Orientation of the 2 x 500-sheet Input Tray                                    | - - - - - | 315 |
| Figure 6-84  | Back Cover   | - - - - - | 316 |
| Figure 6-85  | Left Cover   | - - - - - | 317 |
| Figure 6-86  | Vertical Transfer Unit (VTU) (1 of 3)  | - - - - - | 318 |
| Figure 6-87  | Vertical Transfer Unit (VTU) (2 of 3)  | - - - - - | 319 |
| Figure 6-88  | Vertical Transfer Unit (VTU) (3 of 3)  | - - - - - | 320 |
| Figure 6-89  | Right Cover (1 of 3)   | - - - - - | 321 |
| Figure 6-90  | Right Cover (2 of 3)   | - - - - - | 322 |
| Figure 6-91  | Right Cover (3 of 3)   | - - - - - | 323 |
| Figure 6-92  | Front Top Cover (1 of 3)   | - - - - - | 324 |
| Figure 6-93  | Front Top Cover (2 of 3)   | - - - - - | 325 |
| Figure 6-94  | Front Top Cover (3 of 3)   | - - - - - | 326 |
| Figure 6-95  | Trays 4 and 5 (1 of 2)   | - - - - - | 327 |
| Figure 6-96  | Trays 4 and 5 (2 of 2)   | - - - - - | 328 |
| Figure 6-97  | Pickup Assembly (1 of 2)   | - - - - - | 329 |
| Figure 6-98  | Pickup Assembly (2 of 2)   | - - - - - | 330 |
| Figure 6-99  | Paper Deck Drive Assembly (1 of 2)   | - - - - - | 331 |
| Figure 6-100 | Paper Deck Drive Assembly (2 of 2)   | - - - - - | 332 |
| Figure 6-101 | Pickup, Feed, and Separation Rollers   | - - - - - | 333 |
| Figure 6-102 | 2 x 500-sheet Input Tray Controller PCA  | - - - - - | 334 |
| Figure 6-103 | Tray-Size Sensing PCA (1 of 2)   | - - - - - | 335 |
| Figure 6-104 | Tray-Size Sensing PCA (2 of 2)   | - - - - - | 336 |
| Figure 6-105 | Power Supply   | - - - - - | 337 |
| Figure 6-106 | Main Cable (1 of 2)  | - - - - - | 338 |
| Figure 6-107 | Main Cable (2 of 2)  | - - - - - | 339 |
| Figure 6-108 | Storage Paper Tray   | - - - - - | 340 |
| Figure 6-109 | Front Door (Storage Area)  | - - - - - | 341 |
| Figure 6-110 | Casters  | - - - - - | 342 |
| Figure 6-111 | Foot Tip and Adjustable Foot Tip   | - - - - - | 343 |
| Figure 6-112 | Locating Pins  | - - - - - | 344 |
| Figure 6-113 | Front LED PCA  | - - - - - | 345 |
| Figure 6-114 | Orientation of the 7-bin Tabletop Mailbox                                      | - - - - - | 348 |
| Figure 6-115 | Front cover (1 of 3)   | - - - - - | 349 |
| Figure 6-116 | Front cover (2 of 3)   | - - - - - | 350 |
| Figure 6-117 | Front cover (3 of 3)   | - - - - - | 351 |

|              |  |           |     |
|--------------|--|-----------|-----|
| Figure 6-118 | Back cover (1 of 2)                                    | - - - - - | 352 |
| Figure 6-119 | Back cover (2 of 2)                                    | - - - - - | 353 |
| Figure 6-120 | Top cover (1 of 4)                                     | - - - - - | 354 |
| Figure 6-121 | Top cover (2 of 4)                                     | - - - - - | 355 |
| Figure 6-122 | Top cover (3 of 4)                                     | - - - - - | 356 |
| Figure 6-123 | Top cover (4 of 4)                                     | - - - - - | 357 |
| Figure 6-124 | Mailbox Controller PCA                                 | - - - - - | 358 |
| Figure 6-125 | Mailbox Power Supply                                   | - - - - - | 359 |
| Figure 6-126 | Right Door Assembly (Paper Path Cover) (1 of 5)        | - - - - - | 360 |
| Figure 6-127 | Right Door Assembly (Paper Path Cover) (2 of 5)        | - - - - - | 361 |
| Figure 6-128 | Right Door Assembly (Paper Path Cover) (3 of 5)        | - - - - - | 361 |
| Figure 6-129 | Right Door Assembly (Paper Path Cover) (3 of 5)        | - - - - - | 362 |
| Figure 6-130 | Right Door Assembly (Paper Path Cover) (4 of 5)        | - - - - - | 363 |
| Figure 6-131 | Face-down Bins (1 of 3)                                | - - - - - | 364 |
| Figure 6-132 | Face-down Bins (2 of 3)                                | - - - - - | 365 |
| Figure 6-133 | Face-down Bins (3 of 3)                                | - - - - - | 366 |
| Figure 6-134 | Empty Bin Sensor PCA (1 of 2)                          | - - - - - | 367 |
| Figure 6-135 | Empty Bin Sensor PCA (2 of 2)                          | - - - - - | 368 |
| Figure 6-136 | Full Bin and Interlock Sensor PCA (1 of 2)             | - - - - - | 369 |
| Figure 6-137 | Full Bin and Interlock Sensor PCA (2 of 2)             | - - - - - | 370 |
| Figure 6-138 | LED PCA  | - - - - - | 371 |
| Figure 6-139 | Face-up Sensors PCA                                    | - - - - - | 372 |
| Figure 6-140 | Reversing Mechanism Motor (1 of 2)                     | - - - - - | 373 |
| Figure 6-141 | Reversing Mechanism Motor (2 of 2)                     | - - - - - | 374 |
| Figure 6-142 | Face-up/Diverter Assembly (Flipper) (1 of 3)           | - - - - - | 375 |
| Figure 6-143 | Face-up/Diverter Assembly (Flipper) (2 of 3)           | - - - - - | 376 |
| Figure 6-144 | Face-up/Diverter Assembly (Flipper) (3 of 3)           | - - - - - | 377 |
| Figure 6-145 | Short Tray 7   | - - - - - | 378 |
| Figure 6-146 | Solenoid Reversing Mechanism                           | - - - - - | 379 |
| Figure 6-147 | Flipper Solenoid                                       | - - - - - | 380 |
| Figure 6-148 | 7-bin Tabletop Mailbox Handle                          | - - - - - | 381 |
| Figure 6-149 | Latching Mechanism                                     | - - - - - | 382 |
| Figure 6-150 | Cover Latch  | - - - - - | 383 |
| Figure 6-151 | Orientation of the 8-bin Mailbox                       | - - - - - | 385 |
| Figure 6-152 | 8-bin Mailbox Covers (Front and Back)                  | - - - - - | 386 |
| Figure 6-153 | 8-bin Mailbox Top Cover                                | - - - - - | 387 |
| Figure 6-154 | 8-bin Mailbox Power Supply                             | - - - - - | 388 |
| Figure 6-155 | 8-bin Mailbox Paper Bins and Blind Cover               | - - - - - | 389 |
| Figure 6-156 | 8-bin Mailbox Flipper Assembly (1 of 3)                | - - - - - | 390 |
| Figure 6-157 | 8-bin Mailbox Flipper Assembly (2 of 3)                | - - - - - | 391 |
| Figure 6-158 | 8-bin Mailbox Flipper Assembly (3 of 3)                | - - - - - | 392 |
| Figure 6-159 | 8-bin Mailbox Delivery Head Motor                      | - - - - - | 393 |
| Figure 6-160 | 8-bin Mailbox Transport Belt Motor                     | - - - - - | 394 |
| Figure 6-161 | 8-bin Mailbox Input Paper Guide (1 of 2)               | - - - - - | 396 |
| Figure 6-162 | 8-bin Mailbox Input Paper Guide (2 of 2)               | - - - - - | 397 |
| Figure 6-163 | 8-bin Mailbox Metal Tape and Housing Assembly (1 of 2) | - - - - - | 398 |
| Figure 6-164 | 8-bin Mailbox Metal Tape and Housing Assembly (2 of 2) | - - - - - | 399 |

|              |   |           |     |
|--------------|---|-----------|-----|
| Figure 6-165 | 8-bin Mailbox Controller PCA (1 of 2)                         | - - - - - | 400 |
| Figure 6-166 | 8-bin Mailbox Controller PCA (2 of 2)                         | - - - - - | 401 |
| Figure 6-167 | 8-bin Mailbox Anticurl Strings (1 of 2)                       | - - - - - | 402 |
| Figure 6-168 | 8-bin Mailbox Anticurl Strings (2 of 2)                       | - - - - - | 403 |
| Figure 6-169 | 8-bin Mailbox Delivery Head Assembly (1 of 4)                 | - - - - - | 404 |
| Figure 6-170 | 8-bin Mailbox Delivery Head Assembly (2 of 4)                 | - - - - - | 405 |
| Figure 6-171 | 8-bin Mailbox Delivery Head Assembly (3 of 4)                 | - - - - - | 406 |
| Figure 6-172 | 8-bin Mailbox Delivery Head Assembly (4 of 4)                 | - - - - - | 407 |
| Figure 6-173 | 8-bin Mailbox Interlock Switch                                | - - - - - | 409 |
| Figure 6-174 | 8-bin Mailbox Diagnostic LED PCA (1 of 2)                     | - - - - - | 410 |
| Figure 6-175 | 8-bin Mailbox Diagnostic LED PCA (2 of 2)                     | - - - - - | 411 |
| Figure 6-176 | 8-bin Mailbox User Status LED PCA (1 of 2)                    | - - - - - | 412 |
| Figure 6-177 | 8-bin Mailbox User Status LED PCA (2 of 2)                    | - - - - - | 413 |
| Figure 6-178 | 8-bin Mailbox Adjustable and Fixed Casters                    | - - - - - | 414 |
| Figure 6-179 | 8-bin Mailbox Attachment Assembly                             | - - - - - | 415 |
| Figure 6-180 | Mailbox with Stapler, Stapler Removal or Installation         | - - - - - | 417 |
| Figure 6-181 | C-link Cable on Mailbox with Stapler                          | - - - - - | 418 |
| Figure 6-182 | Back Plate (1 of 2)   | - - - - - | 419 |
| Figure 6-183 | Back Plate (2 of 2)   | - - - - - | 420 |
| Figure 6-184 | Stapler Controller PCA (1 of 3)                               | - - - - - | 421 |
| Figure 6-185 | Stapler Controller PCA (2 of 3)                               | - - - - - | 422 |
| Figure 6-186 | Stapler Controller PCA (3 of 3)                               | - - - - - | 423 |
| Figure 6-187 | Top Cover Assembly  | - - - - - | 424 |
| Figure 6-188 | Stapler Bed Assembly  | - - - - - | 425 |
| Figure 6-189 | Hinges  | - - - - - | 427 |
| Figure 6-190 | Optional Output Accessory                                     | - - - - - | 433 |
| Figure 6-191 | Copy Connect EIO Board (slot 3)                               | - - - - - | 434 |
| Figure 6-192 | View with HP Digital Copy 320 Stand (preferred configuration) | - - - - - | 435 |
| Figure 6-193 | View with HP Digital Copy 320 on Tabletop                     | - - - - - | 435 |
| Figure 6-194 | Orientation of the HP Digital Copy 320                        | - - - - - | 439 |
| Figure 6-195 | Separation Pad Assembly                                       | - - - - - | 440 |
| Figure 6-196 | Pick Roller Cover   | - - - - - | 441 |
| Figure 6-197 | Pick Rollers (1 of 2)   | - - - - - | 442 |
| Figure 6-198 | Pick Rollers (2 of 2)   | - - - - - | 443 |
| Figure 6-199 | Document Holding Pad  | - - - - - | 445 |
| Figure 6-200 | Paper Chute Flip-out  | - - - - - | 446 |
| Figure 6-201 | Output Tray   | - - - - - | 447 |
| Figure 6-202 | FB Cover Assembly   | - - - - - | 448 |
| Figure 6-203 | Thumb Screw for Document Cover Assembly                       | - - - - - | 449 |
| Figure 6-204 | Removing the Cover from the Posts                             | - - - - - | 450 |
| Figure 6-205 | ADF Latch Cap   | - - - - - | 451 |
| Figure 6-206 | ADF Cover (1 of 2)  | - - - - - | 452 |
| Figure 6-207 | ADF Cover (2 of 2)  | - - - - - | 453 |
| Figure 6-208 | Front Panel (1 of 2)  | - - - - - | 454 |
| Figure 6-209 | Front Panel (2 of 2)  | - - - - - | 455 |
| Figure 6-210 | Front Panel Cable Clamp and Front Panel Frame Ground Plate    | - - - - - | 456 |
| Figure 6-211 | Front Panel Ribbon Cable                                      | - - - - - | 457 |

|              |   |           |     |
|--------------|---|-----------|-----|
| Figure 6-212 | Unplugging the Ribbon Cable               | - - - - - | 458 |
| Figure 6-213 | Panel Cover (bottom view)                 | - - - - - | 459 |
| Figure 6-214 | Front Panel Brackets (1 of 2)             | - - - - - | 460 |
| Figure 6-215 | Front Panel Brackets (2 of 2)             | - - - - - | 461 |
| Figure 6-216 | Upper Cover (1 of 2)                      | - - - - - | 462 |
| Figure 6-217 | Upper Cover (2 of 2)                      | - - - - - | 463 |
| Figure 6-218 | Copy Processor Board                      | - - - - - | 464 |
| Figure 6-219 | Power Supply and Main Board Tray (1 of 2) | - - - - - | 465 |
| Figure 6-220 | Power Supply and Main Board Tray (2 of 2) | - - - - - | 466 |
| Figure 6-221 | RFI Cover (inside/rear view)              | - - - - - | 467 |
| Figure 6-222 | RFI Cover (outside/front view)            | - - - - - | 468 |
| Figure 6-223 | Control PCA                               | - - - - - | 469 |
| Figure 6-224 | Card Cage                                 | - - - - - | 470 |
| Figure 6-225 | EEPROM                                    | - - - - - | 471 |
| Figure 6-226 | Fan                                       | - - - - - | 472 |
| Figure 6-227 | Power Supply                              | - - - - - | 473 |
| Figure 6-228 | Back PCA                                  | - - - - - | 474 |
| Figure 6-229 | Optical Unit (1 of 2)                     | - - - - - | 475 |
| Figure 6-230 | Optical Unit (2 of 2)                     | - - - - - | 476 |
| Figure 6-231 | ADF Lamp PCA (1 of 2)                     | - - - - - | 477 |
| Figure 6-232 | ADF Lamp PCA (2 of 2)                     | - - - - - | 478 |
| Figure 6-233 | ADF Lamp                                  | - - - - - | 479 |
| Figure 6-234 | Sensor Unit Assembly (1 of 3)             | - - - - - | 480 |
| Figure 6-235 | Sensor Unit Assembly (2 of 3)             | - - - - - | 481 |
| Figure 6-236 | Sensor Unit Assembly (3 of 3)             | - - - - - | 482 |
| Figure 6-237 | ADF Motor Unit                            | - - - - - | 483 |
| Figure 6-238 | ADF Belt                                  | - - - - - | 484 |
| Figure 6-239 | LED Assembly PCA                          | - - - - - | 486 |
| Figure 6-240 | ADF Unit (shown without Optical Unit)     | - - - - - | 487 |
| Figure 6-241 | Front Panel Frame Ground Spring           | - - - - - | 488 |
| Figure 6-242 | Output Tray Brackets                      | - - - - - | 489 |
| Figure 6-243 | Glass Plate Assembly                      | - - - - - | 490 |
| Figure 6-244 | Idle Roller Coil Spring                   | - - - - - | 491 |
| Figure 6-245 | Home Position Sensor (1 of 2)             | - - - - - | 492 |
| Figure 6-246 | Home Position Sensor (2 of 2)             | - - - - - | 493 |
| Figure 6-247 | Dust Cover                                | - - - - - | 494 |
| Figure 6-248 | Lamp (1 of 2)                             | - - - - - | 495 |
| Figure 6-249 | Lamp (2 of 2)                             | - - - - - | 496 |
| Figure 6-250 | Carrier Unit (1 of 2)                     | - - - - - | 497 |
| Figure 6-251 | Carrier Unit (2 of 2)                     | - - - - - | 498 |
| Figure 6-252 | Carrier Belt                              | - - - - - | 499 |
| Figure 6-253 | Unplugging the Ribbon Cable               | - - - - - | 500 |
| Figure 6-254 | Felt Pad                                  | - - - - - | 501 |
| Figure 6-255 | Feet                                      | - - - - - | 502 |
| Figure 6-256 | Frame Ground Spring                       | - - - - - | 503 |
| Figure 6-257 | Front Lamp PCA                            | - - - - - | 504 |
| Figure 6-258 | Junction PCA Cover                        | - - - - - | 505 |

|              |   |     |
|--------------|---|-----|
| Figure 6-259 | Junction PCA - - - - -  | 506 |
| Figure 6-260 | Front Panel Ribbon Cable- - - - -   | 507 |
| Figure 6-261 | Unplugging the Ribbon Cable - - - - -   | 508 |
| Figure 6-262 | Carrier Belt and Motor (1 of 2)- - - - -  | 509 |
| Figure 6-263 | Carrier Belt and Motor (2 of 2)- - - - -  | 510 |
| Figure 7-1   | Troubleshooting Process - - - - -   | 515 |
| Figure 7-2   | Mopier System Troubleshooting Process - - - - -                                     | 517 |
| Figure 7-3   | Mopier and Paper-Handling Troubleshooting Process (1 of 2) - - - - -                | 518 |
| Figure 7-4   | Mopier and Paper-Handling Troubleshooting Process (2 of 2) - - - - -                | 519 |
| Figure 7-5   | Copy Module Troubleshooting Process (1 of 2) - - - - -                              | 520 |
| Figure 7-6   | Copy Module Troubleshooting Process (2 of 2) - - - - -                              | 521 |
| Figure 7-7   | Communications Link (C-link) Cables, Supported<br>Daisy Chain Connections - - - - - | 523 |
| Figure 7-8   | Sample JetDirect Configuration Page - - - - -                                       | 526 |
| Figure 7-9   | Fan Location and Airflow - - - - -  | 536 |
| Figure 7-10  | Engine Test Button - - - - -  | 537 |
| Figure 7-11  | Sample Event Log - - - - -  | 539 |
| Figure 7-12  | Error Format for Paper Handling - - - - -   | 543 |
| Figure 7-13  | Paper Path Jam Locations - - - - -  | 583 |
| Figure 7-14  | Paper Path Test Source and Output Selection - - - - -                               | 585 |
| Figure 7-15  | Sample Menu Map - - - - -   | 588 |
| Figure 7-16  | Sample Mopier Configuration Page (1 of 2) - - - - -                                 | 590 |
| Figure 7-17  | Sample Copy Module Configuration Page - - - - -                                     | 591 |
| Figure 7-18  | Sample File Directory Page - - - - -  | 592 |
| Figure 7-19  | Sample Usage Page - - - - -   | 594 |
| Figure 7-20  | Repetitive Defect Ruler - - - - -   | 613 |
| Figure 7-21  | High Voltage Power Supply Contacts - - - - -  | 616 |
| Figure 7-22  | 8-bin Mailbox LEDs Description - - - - -  | 630 |
| Figure 7-23  | 8-bin Mailbox Power Supply Test Mode Switch - - - - -                               | 631 |
| Figure 7-24  | Printer Sensors and Switches - - - - -  | 639 |
| Figure 7-25  | Printer Motor, Clutches, and Solenoids - - - - -                                    | 640 |
| Figure 7-26  | DC Controller Inputs and Outputs (1 of 5) - - - - -                                 | 641 |
| Figure 7-27  | DC Controller Inputs and Outputs (2 of 5) - - - - -                                 | 642 |
| Figure 7-28  | DC Controller Inputs and Outputs (3 of 5) - - - - -                                 | 643 |
| Figure 7-29  | DC Controller Inputs and Outputs (4 of 5) - - - - -                                 | 644 |
| Figure 7-30  | DC Controller Inputs and Outputs (5 of 5) - - - - -                                 | 645 |
| Figure 7-31  | Mailbox with Stapler Wiring Diagram - - - - -                                       | 646 |
| Figure 7-32  | 2000-sheet Input Tray Controller PCA Inputs - - - - -                               | 647 |
| Figure 7-33  | 2000-sheet Input Tray Controller PCA Outputs - - - - -                              | 648 |
| Figure 7-34  | 2000-sheet Input Tray Main Wiring Diagram - - - - -                                 | 649 |
| Figure 7-35  | 8-bin Mailbox Main Wiring Diagram - - - - -   | 650 |
| Figure 7-36  | Copy Processor LEDs - - - - -   | 664 |
| Figure 7-37  | Locations of ADF Sensors - - - - -  | 667 |
| Figure 8-1   | HP Mopier 320 Paper-Handling Components - - - - -                                   | 676 |
| Figure 8-2   | Printer Covers and Doors - - - - -  | 680 |
| Figure 8-3   | Printer Internal Components (1 of 4)- - - - -                                       | 682 |
| Figure 8-4   | Printer Internal Components (2 of 4)- - - - -                                       | 684 |

|             |   |           |     |
|-------------|---|-----------|-----|
| Figure 8-5  | Printer Internal Components (3 of 4)-         | - - - - - | 686 |
| Figure 8-6  | Printer Internal Components (4 of 4)-         | - - - - - | 688 |
| Figure 8-7  | Detail of Assemblies                          | - - - - - | 690 |
| Figure 8-8  | PCB Assembly Location Diagram                 | - - - - - | 692 |
| Figure 8-9  | Face-up Solenoid Assembly-                    | - - - - - | 693 |
| Figure 8-10 | 2000-sheet Input Tray Components (1 of 2)     | - - - - - | 694 |
| Figure 8-11 | 2000-sheet Input Tray Components (2 of 2)     | - - - - - | 696 |
| Figure 8-12 | 2 x 500-sheet Input Tray Internal Components- | - - - - - | 698 |
| Figure 8-13 | 7-bin Tabletop Mailbox Internal Components    | - - - - - | 702 |
| Figure 8-14 | 8-bin Mailbox Components (1 of 3)             | - - - - - | 706 |
| Figure 8-15 | 8-bin Mailbox Components (2 of 3)             | - - - - - | 708 |
| Figure 8-16 | 8-bin Mailbox Components (3 of 3)             | - - - - - | 710 |
| Figure 8-17 | Stapler Internal Components                   | - - - - - | 712 |
| Figure 8-18 | Assembly Location Diagram-                    | - - - - - | 735 |
| Figure 8-19 | Covers  | - - - - - | 736 |
| Figure 8-20 | Flatbed                                       | - - - - - | 738 |
| Figure 8-21 | Glass Plate and PCA Assembly                  | - - - - - | 740 |
| Figure 8-22 | Carrier Unit                                  | - - - - - | 742 |
| Figure 8-23 | ADF Unit                                      | - - - - - | 744 |
| Figure 8-24 | Optical Unit                                  | - - - - - | 746 |
| Figure 8-25 | Document Cover Assembly                       | - - - - - | 747 |
| Figure 8-26 | Screws (1 of 4)                               | - - - - - | 748 |
| Figure 8-27 | Screws (2 of 4)                               | - - - - - | 748 |
| Figure 8-28 | Screws (3 of 4)                               | - - - - - | 749 |
| Figure 8-29 | Screws (4 of 4)                               | - - - - - | 749 |

Product: 1998 HP Mopier 320 System Printer Service Repair Workshop Manual  
Full Download: <https://www.arepairmanual.com/downloads/1998-hp-mopier-320-system-printer-service-repair-workshop-manual/>

Sample of manual. Download All 815 pages at:  
<https://www.arepairmanual.com/downloads/1998-hp-mopier-320-system-printer-service-repair->